

vlan id

Syntax `vlan id idValue [icr-control-interface] [untagged] [mac-address macAddress]`

Release Information Command introduced before JUNOS Release 7.1.0.
 icr-control-interface keyword added in JUNOS Release 10.3.0.

Description Specifies a VLAN ID to a VLAN subinterface. Assigns a VLAN ID to a VLAN subinterface on which an ICR partition is to be configured. There is no **no** version.

- Options**
- *idValue*—Number unique within the Ethernet interface, in the range 0–4095.
 - *icr-control-interface*—Sets the VLAN subinterface as an ICR control interface on which you want to configure the ICR partition. We recommend that you use this option only if you want the VLAN subinterface to be used to create ICR partitions.
 - *untagged*—Specifies that frames be sent untagged; valid only for VLAN ID 0.
 - *macAddress*—MAC address of the interface; when you do not specify a unique MAC address, the VLAN uses the MAC address of the Ethernet interface.

Mode Interface Configuration

- Related Topics**
- *Configuring Ethernet/VLAN Layer 2 Services, Configuring Local ATM Cross-Connect with AAL5 Encapsulation, and Configuring Local Cross-Connects Between Ethernet/VLAN Interfaces* in the *JUNOS BGP and MPLS Configuration Guide*

Published: 2010-01-07