

## controlled-interface-type

---

**Syntax**    controlled-interface-type { *controlledInterfaceType* | set | superset }  
no controlled-interface-type { *controlledInterfaceType* | all }

**Release Information**    Command introduced in JUNOS Release 7.1.0.  
set and superset keywords added in JUNOS Release 9.2.0.

**Description**    Assigns controlled-interface types to a QoS parameter definition. Controlled-interface types specify the types of logical interfaces whose queues and nodes can be controlled by instances of the parameter definition. You can specify up to four controlled-interface types for each parameter definition. The **no** version removes the controlled-interface type from the parameter definition.

- Options**
- *controlledInterfaceType*—One of the following controlled-interface types: atm, atm-vc, atm-vp, bridge, ethernet, fr-vc, ip, ip-tunnel, ipv6, l2tp-session, l2tp-tunnel, lsp, serial, svlan, server-port, vlan
  - set—Specifies an interface set as a controlled-interface type
  - superset—Specifies an interface superset as a controlled-interface type
  - all—Removes all controlled-interface types

**Mode**    QoS Parameter Definition

- Related Topics**
- [Configuring a Basic Parameter Definition for QoS Administrators](#)
  - [Creating a QoS Parameter on an Interface Superset or Interface Set](#)

---

Published: 2010-04-09