

hello-authentication-key

Syntax	hello-authentication-key <i>password</i> ;
Hierarchy Level	[edit logical-systems <i>logical-system-name</i> protocols isis interface <i>interface-name</i> level <i>number</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> protocols isis interface <i>interface-name</i> level <i>number</i>], [edit protocols isis interface <i>interface-name</i> level <i>number</i>], [edit routing-instances <i>routing-instance-name</i> protocols isis interface <i>interface-name</i> level <i>number</i>]
Release Information	Statement introduced before JUNOS Release 7.4. Statement introduced in JUNOS Release 9.0 for EX Series switches.
Description	Configure an authentication key (password) for hello packets. Neighboring routing devices use the password to verify the authenticity of packets sent from an interface. For the key to work, you also must include the hello-authentication-type statement.
Default	By default, hello authentication is not configured on an interface. However, if IS-IS authentication is configured, the hello packets are authenticated using the IS-IS authentication type and password.
Options	<i>password</i> —Authentication password. The password can be up to 255 characters. Characters can include any ASCII strings. If you include spaces, enclose all characters in quotation marks (“ ”).
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ authentication-key■ authentication-type■ hello-authentication-type■ Configuring Levels on IS-IS Interfaces

Published: 2010-04-14