

Juniper Mist Location Services Guide

Published
2025-12-04

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, the Juniper Networks logo, Juniper, and Junos are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Juniper Mist Location Services Guide

Copyright © 2025 Juniper Networks, Inc. All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <https://support.juniper.net/support/eula/>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

1

Get Started

Juniper Mist Location Services Overview | 2

Activate Subscriptions | 7

APs for Location Services | 8

AP Placement for Location Services | 9

AP Deployment Assessment | 11

2

BLE Settings

Enable Bluetooth Based Location Services | 21

BLE Beacons | 22

Change the BLE Power Settings for Access Points | 24

Change the BLE and vBLE Power Settings for an AP | 24

Change the Power Settings for Multiple APs as a Batch | 26

BLE Power Settings for Juniper Access Points | 27

3

Floorplan Setup

Floorplan Setup Overview | 30

Deploy Mist with Ease using Wireless Design Tools | 31

Requirements and Considerations | 33

Match APs in the Project Files to Your Physical Mist APs | 34

Export Ekahau Design Files and Import them to Mist | 34

Export Hamina Design Files for Automatic Import to Mist | 35

Automatically Import Mist Floorplans to Hamina | 37

Export iBwave Design Files and Import them to Mist | 37

Add Wayfinding Paths to a Floorplan | 38

- Add Walls to Improve Wayfinding | 40
- Add Exclusion Zones to Improve Wayfinding | 41

Add Other Items to a Floorplan | 43

- Add Third-Party Beacons to a Floorplan | 43
- Add Location Zones to a Floorplan | 47
- Auto Zone: Add Location Zones to a Floorplan (BETA) | 48
- Add Proximity Zones to a Floorplan | 51
- Add Virtual Beacons to a Floorplan | 54

Validate Your Floorplan | 57

4

Wayfinding and User Engagement

- Wayfinding Use Case | 61
- AR and VR Wayfinding Use Case | 63
- Hybrid Use Case | 65
- Daisy-Chain BT11 APs | 68
- Configure Push Notifications for User Engagement | 70

5

Asset Visibility and Room Occupancy

- View and Manage BLE Clients | 75
 - Prerequisites | 75
 - Find the BLE Clients Page | 76
 - Filter the Data | 77
 - Adjust the Columns | 78
 - Add, Modify, or Remove Assets | 78
- Create Named Assets | 79
 - Select BLE Clients to Name | 79
 - Use a Filter to Generate a Common Name for Similar Assets | 81

Use a CSV File to Assign Names to Assets | 81

Create Asset Filters | 82

Import Assets | 85

Guidelines for BLE Beacon Tags | 86

Rubber Band Model | 87

Find Equipment Use Case | 88

Room Utilization Use Case | 91

Find the Current Location of a Named Asset | 93

6

Analytics

Analytics Overview | 96

MAC Randomization and Location Analytics | 96

7

Location-Based Application Development

Juniper Mist SDK | 100

Webhooks for Location Services | 101

8

Troubleshoot Location Services

Location SLEs | 105

Overview | 105

Location SLE Blocks | 106

Search in Live View | 110

Troubleshoot Location Services Using the RF Environment | 112

Verify and Enable the vBLE Array | 116

Check Your Site's Beam Density Coverage | 117

Troubleshoot the Juniper Mist SDK | 120

Troubleshoot Incorrect Latitude and Longitude (SDK) | 122

Marvis Client and Location Services Integration for Troubleshooting | 126

Other Troubleshooting Tips for Location Services | 127

1

CHAPTER

Get Started

IN THIS CHAPTER

- Juniper Mist Location Services Overview | [2](#)
- Activate Subscriptions | [7](#)
- APs for Location Services | [8](#)
- AP Placement for Location Services | [9](#)
- AP Deployment Assessment | [11](#)

Juniper Mist Location Services Overview

SUMMARY

Get familiar with the major components of location-based services to understand how Juniper Mist™ ensures location accuracy for wayfinding, asset visibility, and user engagement.

IN THIS SECTION

- [How It Works: vBLE Antenna Array | 2](#)
- [How It Works: Probability Surfaces | 3](#)
- [How It Works: Indoor Location Experiences | 4](#)
- [Use Cases | 5](#)
- [Wayfinding | 5](#)
- [Asset Visibility | 6](#)
- [User Engagement | 6](#)
- [What's Next? | 7](#)

Virtual Bluetooth LE (vBLE) is a patented technology for indoor Location Services, using virtual beacons to locate BLE devices with great precision. Juniper Networks access points (APs) use a dynamic 8-directional antenna array that blankets an area with BLE signals and is capable of both transmitting and receiving BLE signals.

Virtual beacons are an efficient alternative when compared to physical beacons in terms of time and cost savings. With virtual beacons, there is no need to install and configure physical beacons, no need for site surveys, and no need for additional hardware. This makes for simpler, more efficient deployments and makes adding and moving vBeacons a hassle-free experience, as you configure everything from the Juniper Mist™ portal.




[Video: Location Services with Mist](#)

How It Works: vBLE Antenna Array

Juniper Mist APs transmit BLE signals using an 8-element directional vBLE antenna array.

Figure 1: vBLE Antenna Array



[Video: Location - How it Works](#)


How It Works: Probability Surfaces

When your customer or visitor uses your Juniper Mist SDK-enabled application, the Juniper Mist cloud uses probability surfaces to determine the user's location. Probability surfaces provide the best possible location accuracy with sub-second latency.

The Juniper Mist cloud uses the RF fingerprints sent by the SDK client to create probability surfaces. This is done by splitting the floorplan up into 1-meter squares and calculating the estimated RF fingerprints for each square.

Each of the AP's eight directional beams contribute to the likely location of the client device, examining all the probability surfaces (one for each beam) and combining them to find the likely point on the map where the device is located.

In this example, the center of the red area is the peak of the surface and the highest probability of the client's location. The blue area depicts the lowest area of the surface and the least probability of the client's location.



As the SDK client sends RF fingerprints to the Juniper Mist cloud, Juniper Mist enters the machine learning process, and the location model is optimized for that device.

How It Works: Indoor Location Experiences


The Juniper Mist SDK provides the tools that you need for building customer-facing applications that deliver indoor location services. When you integrate the Juniper Mist SDK with Juniper Mist Wi-Fi and location-based services, you can determine a user's location and deliver proximity-based notifications using Juniper Mist's patented vBLE Technology.

SDK-integrated mobile devices listen for and receive the Bluetooth Low Energy (BLE) packets that are transmitted by the APs. The information in these packets gets packaged up by the SDK client and sent to the Juniper Mist cloud. Finally, the cloud returns the x,y coordinates to the mobile device every second based on the information that it received.

For more information, see ["Juniper Mist SDK" on page 100](#).

Your application uses this information to provide relevant experiences, such as wayfinding directions and push notifications.

Figure 2: How Mist Shows User Location With vBLE



[Video: Modern RF Glass](#)

Use Cases

Juniper Mist supports many location-based use cases. A few possibilities are described below.

Wayfinding

Wayfinding is just like the Google and Apple Maps experience, navigating you from point A to point B.

Picture a retail location. A customer is shopping at a store, and they have the retailer's mobile application on their cell phone. APs transmitting BLE are located all over the store. If you integrate the SDK into your customer-facing app, you can support wayfinding. The retail customer can search for an item and then be guided turn by turn to the location of the item within the store.

For more information, see ["Wayfinding Use Case" on page 61](#).



[Video: Wayfinding Use Case](#)

Asset Visibility

Quickly locate assets such as electronics and equipment. To support asset tracking, you attach BLE beacon tags to the assets that you want to track. When the AP hears the BLE transmission from the tag, it locates that asset on the Live View in the Juniper Mist portal. Staff at a hospital can use this feature to track down the location of medical equipment, such as wheelchairs.

For more information, see ["Find Equipment Use Case" on page 88](#).

Figure 3: Asset Tracking Example




Figure 3 on page 6

6



Video: User Experiences with Location Services Webinar

User Engagement

When a site visitor enters a virtual beacon's coverage area, the Location Engine sends a push notification to display a greeting. One example of this is when a person enters through the front door of an office building and a redirect link to the company homepage is sent to their device.

Figure 4: User Engagement Example



[Video: Juniper Mist User Engagement Demo](#)

What's Next?

- Obtain and activate your subscriptions. See ["Activate Subscriptions" on page 7](#).
- Select your APs. See ["APs for Location Services" on page 8](#).
- Place your APs to ensure full BLE coverage. See ["AP Placement for Location Services" on page 9](#).
- Set up your floorplan to ensure location accuracy. See ["Floorplan Setup Overview" on page 30](#).
- Implement your use cases.

For example, see:

- ["Wayfinding Use Case" on page 61](#)
- ["Find Equipment Use Case" on page 88](#)

Activate Subscriptions

SUMMARY

To implement location services for your organization, purchase the appropriate subscriptions, and activate them.

Decide which [Mist AI and Cloud Services](#) you need, and then contact MistRenewal@juniper.net to purchase them. For location-based services, relevant subscriptions include:

- [Juniper Mist Asset Visibility](#)
- [Juniper Mist Premium Analytics](#)
- [Juniper Mist User Engagement](#)

After you purchase a subscription, Juniper emails the activation code(s) to you.

To activate a subscription:

1. From the left menu of the Juniper Mist portal, select **Organization > Subscriptions**.
2. Click **Apply Activation Code**.
3. Enter the code.
4. Click **Activate**.

APs for Location Services

SUMMARY

Get familiar with the access points (APs) that you can use with Juniper Mist™ Location Services.

The following access points include Juniper's patented virtual Bluetooth Low Energy (vBLE) technology:

- Indoor access points: AP45, AP43, AP41, AP33, and AP21
- Outdoor access points: AP63 and AP61
- BLE only: BT11



NOTE: You can use the BT11 to ensure full BLE coverage in areas where you don't need an AP for Wi-Fi coverage.

Compare these [access points](#) at Juniper.net.

AP Placement for Location Services

SUMMARY


Learn the do's and don'ts to ensure location accuracy when planning and installing access points (APs) at your site.

To ensure the best possible accuracy and stability, follow these guidelines:

- Mount the access points (APs) on the ceiling, with the LED facing the floor.

Example

- Ceiling mounting results in the best directionality for the Bluetooth Low Energy (BLE) beams.
- If ceiling mounting isn't possible and you must mount the AP on a wall, pole, column, or similar structure, use brackets to position the AP with the LED facing the floor.
- Ensure that the AP is 9 to 15 feet (2.7 to 4.5 meters) above the floor.
 - The height requirement ensures that BLE clients receive a strong received signal strength indicator (RSSI) and the best possible directionality for the BLE beams.
 - If you need to install APs in an area with ceilings higher than 15 feet, consult with a sales engineer.
 - We do not recommend above-ceiling mounting. Again, consult with a sales engineer.
- Each AP should have an unobstructed line of sight to at least two other APs.
- Optimal BLE range is a radius of approximately 15 meters (49 feet) from the AP.



- Install APs within 10 to 15 meters (32 to 49 feet) of one another.
- For wayfinding, be sure to provide coverage at junction points and corners.
- Don't place APs any closer than 8 meters (26 feet) in the same room or space. Closer placement offers no benefit in terms of coverage and could cause interference.



NOTE: If APs are in different rooms, separated by a wall, close placement doesn't pose an issue.

- For corners, hallways, and areas where you need only BLE and not Wi-Fi services, consider using [Juniper BT11 access points](#).
- Don't install an AP:
 - Behind, inside, or on top of other objects.
 - On the floor.
 - Next to metal, glass, or concrete.

AP Deployment Assessment

SUMMARY

Do you have enough access points (APs) at your site? Assess your deployment by using Marvis Actions, Wireless Service Level Expectations (SLEs), and the RF Health and Utilization dashboard in Premium Analytics.

IN THIS SECTION

- [Overview | 11](#)
- [Juniper Mist Tools | 12](#)
- [Wireless SLE Analysis | 14](#)
- [RF Health and Utilization Dashboard in Premium Analytics | 16](#)
- [Recommendations | 18](#)

Overview

Determine if you need more APs for optimal connectivity and user experience. Consider our recommendations as you optimize your deployment.

Methodology

Use the following tools and features to conduct the assessment:

- **Marvis Actions:** Utilize Marvis, the virtual network assistant, to analyze network issues, troubleshoot problems, and optimize performance.
- **Wireless SLE:** Monitor key performance indicators related to coverage, roaming, throughput, and capacity to gauge the effectiveness of the current AP deployment.
- **RF Health and Utilization dashboard in Premium Analytics:** Evaluate the radio frequency (RF) health, interference, and utilization to identify potential areas of improvement in the wireless network.

Assessment Criteria

The assessment will focus on the following aspects:

1. **Signal Coverage:** Analyze the signal strength and quality across the site to ensure comprehensive coverage and minimal dead zones.

2. **Roaming Performance:** Assess the seamless transition of client devices between APs to maintain uninterrupted connectivity.
3. **Throughput Analysis:** Evaluate the data transfer speeds and capacity to accommodate the expected user load and application demands.
4. **RF Health and Utilization:** Monitor RF health, interference, and spectrum utilization to optimize the performance of the wireless network.

Juniper Mist Tools

Juniper Mist™ is a subscription-based service. For more details about Juniper Mist subscriptions, see [Juniper Mist Subscriptions](#) and [Subscription Requirements for Marvis Actions](#).


Marvis Actions

In order to ensure optimal network performance and coverage, it is essential to regularly assess the sufficiency of the APs in your network. By leveraging the Marvis Actions in Juniper Mist portal, you can efficiently identify and address any issues affecting your APs.

To view the Marvis Actions dashboard, select **Marvis > Marvis Actions** from the left menu.

When you click the **Wireless** button on the Actions dashboard, you'll see a list of all available actions. You can then click an action to investigate further.

Figure 5: Marvis Actions



See [Marvis Actions Overview](#) for details.

Offline AP Detection

Marvis can detect APs that are offline due to various reasons, such as power loss or loss of cloud connectivity. This report indicates a need for further investigation or potential troubleshooting to restore connectivity.

Investigate the Offline AP action on the Actions dashboard to address any APs that are showing as offline. This report helps in restoring network connectivity and ensuring seamless operation.

If Marvis identifies multiple APs as offline, it signals the need for immediate attention to resolve the connectivity issues impacting network performance.

Health Check Failures

Health check failures reported by Marvis might indicate underlying hardware or software issues affecting APs within the network. Swift action is required to rectify these issues to prevent any network disruptions.

Use the Health Check Failed action to investigate and address any APs experiencing health check failures. Consider hardware replacement or firmware upgrades as necessary steps to resolve the issue.

An AP that continuously fails health checks might need to be replaced or have its firmware upgraded to ensure proper functioning within the network.

Non-Compliant Firmware

The Non-Compliant action flags APs running outdated firmware versions compared with other APs of the same model at the site. Updating firmware is crucial to ensure security, stability, and performance improvements.

Upgrade the firmware of Non-Compliant APs from the Marvis Actions page to align with the latest version. This step helps in maintaining consistency across APs and mitigating potential vulnerabilities.


A prompt upgrade of firmware on Non-Compliant APs can enhance network security and performance, ensuring all APs operate optimally within the network.

Coverage Hole Detection

The Coverage Hole action identifies areas within your network experiencing poor coverage, allowing you to optimize placement and configuration of APs to improve network efficiency.



Utilize the floor plan visual provided by Marvis to pinpoint areas with coverage issues and take necessary steps such as adding APs, adjusting placements, or increasing power output to address the coverage gaps.




By identifying and resolving coverage holes promptly, you can enhance network connectivity and user experience, ensuring seamless communication across all areas.

Insufficient Capacity Alert

The Insufficient Capacity action detects capacity issues arising from increased utilization, especially during peak client traffic. Addressing capacity constraints is vital to maintain network performance and avoid congestion.



Analyze the floor plan visual provided by Marvis to identify APs experiencing capacity issues and make design improvements to alleviate congestion and optimize network capacity.




Wireless SLE Analysis

Juniper Mist uses Service Level Expectations (SLEs) to measure user experiences, with customizable thresholds for factors like throughput, capacity, and device health. If experiences fall short, Juniper Mist identifies the root causes and provides detailed information for resolution. The SLE dashboard offers a quick overview of service levels and issues needing attention.

See [Wireless SLEs Dashboard](#) for more information.

Select **Monitor > Service Levels** from the left menu, and then click the **Wireless** button.



Use the following SLE to assess your users' experiences with signal strength, throughput, RF channel capacity, roaming between APs, and APs availability.


- 1. Signal Coverage:** Analyze the Received Signal Strength Indicator (RSSI) and signal quality data to identify areas with weak coverage or potential signal asymmetry.
- 2. Roaming Performance:** Evaluate the success rate of client device roams between APs and identify any issues related to latency or signal stability.
- 3. Throughput Analysis:** Assess the estimated per-client throughput and investigate any capacity or coverage-related constraints impacting user experience.
- 4. Capacity Analysis:** Review the RF channel capacity availability and potential limitations due to interference or client usage.

5. **AP Health Status:** Track AP health to assess your users' experience with AP availability. Get percentage of time the APs are operational without rebooting or losing connectivity to the cloud.

RF Health and Utilization Dashboard in Premium Analytics

The RF Health and Utilization dashboard provides long-term radio frequency (RF) health and utilization pattern for your network. With the information, you can analyze channel utilization trends for different radio bands across various sites, floors, and APs, ensuring optimal performance and capacity planning.

In Juniper Mist portal, click **Analytics** > **Premium Analytics**. On the Premium Analytics page, click **RF Health and Utilization**.



Here you can analyze channel utilization trends for different APs.

SLE Coverage and Capacity: This report evaluates the SLE coverage and capacity across APs and sites, identifying sites with poor signal strength, high interference, or coverage gaps. By analyzing these metrics, you can determine where additional APs are needed to improve coverage and signal quality.

Average Neighbor AP Count: This value indicates the average number of APs at the site that can detect each other. A high count signifies a dense deployment, while a low count indicates a sparse deployment. Ideally, the value should range between 3 and 5 for optimal performance.

Average Co-Channel Neighbor Count: This value represents the number of APs broadcasting on the same channel, averaged across all Juniper APs at the site. A high count suggests frequent co-channel interference on the site. While individual APs use Radio Resource Management (RRM) to mitigate interference, a high site-wide count points to broader density challenges.

By using RF health and utilization data, you can make informed decisions about where to place new APs to balance the network load and enhance overall performance.

See [RF Health and Utilization](#) for details.

Recommendations

Based on the assessment findings, the following recommendations are proposed:

- Optimize the placement and configuration of existing APs to improve signal coverage and address any identified dead zones. For help placing APs for location services, see the [Juniper Mist Location Service Guide](#).
- Implement recommended actions provided by Marvis to address ongoing network issues and enhance overall network performance.
- Consider the deployment of additional APs in areas with high client density or limited coverage to improve user experience and accommodate growing demand.
- Mitigate any identified RF interference sources and optimize spectrum utilization to ensure a healthy RF environment for the wireless network. For help with radio management, see the [Juniper Mist Wireless Assurance Guide](#).

Regularly monitoring and addressing the actions highlighted by Marvis can help you maintain an efficient and reliable network infrastructure. This action ensures that the deployed APs are functioning optimally and meet the demands of your network environment.

RELATED DOCUMENTATION

[Wireless Actions](#)

AP Placement for Location Services

RF Health and Utilization

2

CHAPTER

BLE Settings

IN THIS CHAPTER

- [Enable Bluetooth Based Location Services | 21](#)
- [BLE Beacons | 22](#)
- [Change the BLE Power Settings for Access Points | 24](#)

Enable Bluetooth Based Location Services

SUMMARY

Set up your site configuration to enable Virtual Bluetooth LE (vBLE) and related options that are required to support various location-based services.

Virtual Bluetooth LE (vBLE) enables businesses to deliver location-based services to their customers and employees. Juniper Networks Access Points (APs) use a dynamic 8-antenna array that transmits BLE signals and blankets an entire area with BLE.


Enable vBLE Engagement if you want the vBLE antenna array to transmit BLE signals for indoor location wayfinding. This comes in handy in a retail setting, for example, when a customer in a store needs directions for how to get to a particular department.

Enable Asset Visibility if you also want to use the APs for asset tracking. When you enable Asset Visibility, the AP will listen for and locate devices containing BLE tags. This comes in handy for tracking equipment, monitoring occupancy, or analyzing staffing.

You can enable vBLE Engagement and Asset Visibility in the site configuration or the device profiles in the Juniper Mist portal. In this procedure, you'll enable them at the site level.

To enable Bluetooth Based Location Services:

1. From the left menu of the Juniper Mist portal, select **Organization > Site Configuration**.
2. Select the **Site** where you want to enable location-based services.
3. Scroll down to **Bluetooth based Location Services**.
4. Select the **vBLE Engagement** check box.



This enables the vBLE array for all APs at this site; all APs will transmit BLE signals for location wayfinding.

5. (Optional) Select the **App Wakeup** check box if you want the AP to transmit a ninth omni beam ("super beacon").

For example, a retailer might want “super beacons” at the front of a store. When customers enter, they get a notification on the retailer’s Mist SDK-enabled mobile application. There are many other use cases that you can implement based on your business goals.

6. (Optional) Select the **Asset Visibility** check box if you want to use the APs to track assets.

Note:

- When you enable Asset Visibility, the APs listen for BLE signals and will indicate the location of these BLE clients and assets on the Live View.
- If you enable both vBLE Engagement and Asset Visibility, the AP must transmit and receive BLE signals. To optimize performance, enable only the features that you need for your use cases.

The following table shows how your selections affect the rate at which the AP sends data to the Juniper Mist cloud.

Table 1: Transmission Rates

Location Service Enabled	Transmission Rate
Both vBLE Engagement and Asset Visibility	Every 2 seconds
Only vBLE Engagement	Every second
Only Asset Visibility	Every 2 seconds

BLE Beacons

SUMMARY


Enable virtual beacons that communicate to Apple and Android devices.

Virtualized Bluetooth® Low Energy (vBLE) beaconing technology allows exact calculations for locating BLE-enabled devices. Juniper Mist access points (APs) use this technology and can simulate third-party beacons to locate devices containing BLE sensors. Beacons can be broadcast with different payload structures.

Juniper Mist APs broadcasts three types of beacons:

- **iBeacon**—iBeacon is a protocol Apple developed that mobile devices use that allows the device to act as a Bluetooth transmitter. When the device gets within range of an AP broadcasting iBeacon, the AP detects the device signal and then uses the installed mobile application to trigger an action or push a notification to the user's mobile device. Both iOS and Android devices can use iBeacon.
- **Eddystone UID**—Eddystone (Unique beacon ID) is a protocol that Google developed. It allows mobile devices to act as Bluetooth transmitters. When the device is within range of an AP broadcasting Eddystone UID, the AP detects it and uses an installed mobile application to trigger an action on the mobile device. Both iOS and Android devices can use Eddystone UID.
- **Eddystone URL**—Eddystone URL is a protocol that Google developed. When a device is within range of an AP broadcasting Eddystone-URL, the AP will detect it and send a URL from the web in the form of a notification to the mobile device. A mobile application is not needed for this to work. Eddystone URL is compatible only with Android devices.

1. From the left menu of the Juniper Mist portal, select **Access Points**.
2. Select the **Access Point** that is going to broadcast BLE beacons.
3. Scroll down to the **BLE Settings** configuration block.
4. Select **Enable** for each type of BLE beacon you want to broadcast, and then update the payload according to the payload structure.



5. Click **Save** (in the top right corner).



NOTE: To verify that the beacons are broadcasting, you can use the Beacon Simulator Application. You can download the app from the Apple App Store or from the Google Play Store. Make sure to turn on Bluetooth on your mobile device prior to using the app.

Change the BLE Power Settings for Access Points

SUMMARY

When needed, you can adjust an access point's Bluetooth Low Energy (BLE) and Virtual Bluetooth Low Energy (vBLE) power levels.

IN THIS SECTION

- [Change the BLE and vBLE Power Settings for an AP | 24](#)
- [Change the Power Settings for Multiple APs as a Batch | 26](#)
- [BLE Power Settings for Juniper Access Points | 27](#)

It's rarely necessary to change the BLE power settings for an access point (AP). Typically, you would change them only if you want to fine-tune the location-based services at your site.


You can change these settings for a single AP or for multiple APs as a batch.

- ["Change the BLE and vBLE Power Settings for an AP" on page 24](#)
- ["Change the Power Settings for Multiple APs as a Batch" on page 26](#)


Change the BLE and vBLE Power Settings for an AP

Follow these steps if you need to adjust only one AP.

1. From the left menu of the Juniper Mist™ portal, select **Access Points**.
2. Click the AP that you want to adjust.
3. Under **BLE Settings**, drag the **BLE Beacon Power** slider left (lower power) or right (higher power).



4. Under **vBLE Array**, drag the **VBLE Beacon Power** slider left (lower power) or right (higher power).




The power level options are from Level 1 (the lowest power) up to Level 7 (the highest power). The corresponding transmission power (in dBm) varies for each AP model. For more information, see ["BLE Power Settings for Juniper Access Points" on page 27](#).

5. Click **Save** (near the top right corner of the page).


Change the Power Settings for Multiple APs as a Batch

Follow these steps if you want several APs to have the same BLE and vBLE power levels.

1. From the left menu of the Juniper Mist portal, select **Access Points**.
2. Select the check boxes for the APs that you want to adjust.
3. Click **More**, and then click **Batch Edit**.



4. Drag the **Set Beacon Power** control left (lower power) or right (higher power).



The power level options are from Level 1 (the lowest power) up to Level 7 (the highest power). The corresponding transmission power (in dBm) varies for each AP model. For more information, see ["BLE Power Settings for Juniper Access Points" on page 27](#).

5. If you want these same settings to apply to vBLE on the selected APs, enable **Virtual BLE Array**.
6. Click **OK**.

BLE Power Settings for Juniper Access Points

SUMMARY

Understand the meaning of power levels 1-6 on your Juniper access points (APs).

Table 2: BLE Power Settings for BT11, AP41-US, and AP61-US

Level	Power
6	12 dBm

Table 2: BLE Power Settings for BT11, AP41-US, and AP61-US *(Continued)*

Level	Power
5	8 dBm
4	4 dBm
3	0 dBm
2	-4 dBm
1	-8 dBm

Table 3: BLE Power Settings for AP21, AP33, AP41-WW, AP43, AP45, AP61-WW, and AP63

Level	Power
6	9 dBm
5	5 dBm
4	1 dBm
3	-3 dBm
2	-7 dBm
1	-11 dBm

3

CHAPTER

Floorplan Setup

IN THIS CHAPTER

- Floorplan Setup Overview | **30**
- Deploy Mist with Ease using Wireless Design Tools | **31**
- Add Wayfinding Paths to a Floorplan | **38**
- Add Other Items to a Floorplan | **43**
- Validate Your Floorplan | **57**

Floorplan Setup Overview

SUMMARY

Understand the importance of floorplans and get familiar with the process of adding them to your sites.

IN THIS SECTION

- Importance of the Floorplan | 30
- Video Overview | 30
- Process Overview | 30

Importance of the Floorplan

The floorplan is an essential component of location services. Your floorplan provides Juniper Mist™ with accurate information about the site and the access points (APs).

An accurate floorplan enables the location engine to generate accurate location estimates for the client devices, assets, and users at your site.

The floorplan must be correctly scaled, must include all APs, and must correctly represent their positions, heights, and orientations. If an AP is installed at your site but not represented on the floorplan, it does not participate in location services.

Video Overview



[Video: Adding a Floorplan](#)

Process Overview

To implement the scenario, do these tasks.

Table 4: Floorplan Setup Process

Step	Action	More Information
1	Add your floorplans, scale them, and add your access points to your floorplans.	See these topics in the Onboarding Section of the Wireless Guide: <ul style="list-style-type: none"> • Adding and Scaling a Floorplan • Adding Access Points to a Floorplan
3	Add other elements as needed for the use cases that you're implementing.	See the use cases chapters of this guide and the other sections of this Floorplan Setup chapter.
4	Validate your floorplan.	"Validate Your Floorplan" on page 57

Deploy Mist with Ease using Wireless Design Tools

SUMMARY

Read this topic to learn how you can use wireless design tools to easily import floorplans and related attributes into the Juniper Mist™ portal.

IN THIS SECTION

- Requirements and Considerations | [33](#)
- Match APs in the Project Files to Your Physical Mist APs | [34](#)
- Export Ekahau Design Files and Import them to Mist | [34](#)
- Export Hamina Design Files for Automatic Import to Mist | [35](#)
- Automatically Import Mist Floorplans to Hamina | [37](#)
- Export iBwave Design Files and Import them to Mist | [37](#)

You can manually import a floorplan and related attributes into the Juniper Mist™ portal simply by importing the files you already created in wireless design tools such as Ekahau Pro, iBwave, and Hamina.

Wireless design tools provide a one-stop-shop for all of your floorplan and building design needs. They enable you to design your floorplan and related aspects such as access point (AP) placement, AP orientation, channel settings, and more. Importing the resulting files saves you time, as the design work you have already done in your project within the design tool automatically carries over when you import the file into Mist. Using these completed floorplan maps reduces duplication of effort.

Hamina also offers an integration with the Mist cloud API that enables automatic import of floorplan designs into Mist. Once you provide your Mist API key, simply export your floorplan designs from the third-party tool and they carry over automatically to Mist. Hamina uses the export function to drive the automatic floorplan import to Mist.

This topic demonstrates the following (in sequential order):

- **Manual Import:** How to export design files from wireless design tools and how to manually import those files into Mist.
- **Automatic Import (with integrations):** How to export design files from wireless design tools for automatic import to Mist.

Each of the wireless design tools is introduced in their own sections of this topic.

As part of the *manual*/file import, Mist automatically:

- Imports floorplan images from the file.
- Sets the scale of the floorplan for you.
- Imports any APs from the file along with their associated settings, as long as you have completed "[AP Matching](#)" on page 34.
 - Assigns the AP's x,y coordinates, height, and orientation.
 - Assigns the AP to a site if it has not already assigned to one. This requires Super User or Org Network Admin privilege.
 - Places the AP on a floorplan if it has not already been placed on a floorplan.
 - Names the AP if it has not already been named in the wireless design tool. Otherwise, the name given in the design tool is carried over as part of the import.



NOTE: The import action in Mist never changes an AP's assigned site, name, or floorplan if one has already been assigned in the design tool.

Mist currently allows you to import a floorplan using the following file types:

- Ekahau (.esx files)

- iBwave (.mist.ibwc files)
- Hamina (there is no file type necessary for importing Hamina floorplans into Mist, as the items you select and export in Hamina are imported directly to Mist as part of the integration).

The *automatic* file import from wireless network tools into Mist (via API integrations) includes the following:

- Hamina:
 - Uploads the floorplan to Mist
 - Matches simulated APs from the Hamina project to the APs in Mist
 - Assesses Wi-Fi coverage needs
 - Scales the floorplan
 - Places the APs on the floorplan
 - Assigns APs to the site
 - Assigns AP names, height, orientation, MAC addresses, location, transmit power, channel, and channel width settings
 - Deploys new sites in Mist

Requirements and Considerations

To import a floorplan into Mist from a third-party project file, you must follow these requirements and keep the following information in mind:

- iBwave—You must use a minimum version of iBwave Wi-Fi 14.2 or a later.
- Ekahau Pro—Survey data is *not* supported for *file import*. All survey data must be deleted from the project prior to importing into Mist.
- Floorplan image size—The size of the floorplan file you import to Mist must be less than 8 MB (less than 1 MB is recommended).
- You must ["Match APs in the Project Files to Your Physical Mist APs" on page 34](#).

Match APs in the Project Files to Your Physical Mist APs

Prior to using the Import Floorplan feature in Mist, you must match the simulated APs in the project files to your physical Mist APs. There are several ways to accomplish this:

- • Match via MAC address—Within the project file, use the <apname> - <apmac> notation to name APs.
 - This is useful if you manually allocate APs ahead of time.
 - Alternatively, you can simply enter the MAC address of the AP name in the project file. This is demonstrated in the Ekahau video below. Use this method if you don't want to name APs in Mist.
- Match via AP name—Name the AP in the project file so that is matches the exact name of the AP within Mist.
 - This method is most commonly used in conjunction with the Mist AI Mobile App. The advantage is you can pick any AP at random out of the box, and then use the application to scan the QR code and enter a name at the time of installation. You do not need to pre-allocate APs. See No Link Title.
- Match via CSV file—Name the AP in the project file, and also import a CSV file with AP name to MAC address mapping.
 - This is the most flexible and scalable method. It's especially useful when third-party contractors are used to install the APs, as they typically provide a spreadsheet with AP and serial number or mac address.
- Manually match APs when you ingest the project files.
 - This method is only recommended for small deployments, as it is the most time consuming method.

Export Ekahau Design Files and Import them to Mist

Ekahau is a tool you can use to design your floorplan with granularity for network optimization. It enables you to design your floorplan and related devices so that it mirrors the real-world setup. You can export your Ekahau floorplan designs from within the tool and then manually import them into Mist.

1. In Ekahau Pro, navigate to **File > Save** and save the .esx file which you will import to Mist in an upcoming step to a location on your local drive.
2. df
3. On the Mist portal, navigate to **Location > Live View > Import Floorplan**.

4. On the Import Floorplans window, drag and drop the .esx file you want to import and select any AP settings you want to include under **More Options**. See step 4 in Import a Floorplan for more details about what these options do.
5. Click **Import**.
6. To complete "AP Matching" on page 34, select the **Match APs** button, or click **Finish** if you are done. You should now see your floorplans have been imported along with any associated settings.

The following videos provide a start-to-finish look at how to design and plan your network using Ekahau.



[Video: Create Your Floorplan Design in Ekahau](#)



[Video: AP Placement in Ekahau for Indoor Location Wayfinding](#)



[Video: AP Height and Orientation Considerations in Ekahau](#)



[Video: RRM Planning in Ekahau](#)



[Video: Import Your Ekahau Floorplan Design into Mist](#)

Export Hamina Design Files for Automatic Import to Mist

The Hamina Planner is a web-based planning and design tool. It is integrated with Juniper Mist so that, when you export your floorplan design from Hamina, it is automatically imported to Mist. This is accomplished through Hamina's integration with the Mist cloud API.

Prior to exporting your Hamina design files, ensure the following:

- Your design includes:
 - Background map
 - Scaled layout
 - AP locations
 - AP model and type
 - BLE directionality
 - Height settings

- Walls and attenuating objects
- Scope zones
- AP naming is consistent:
 - Helps Mist match APs more easily during import
 - Optional: Preload MAC addresses if known

1. In Hamina, select your project name from the drop-down menu in the top left corner, then select **Export**.
2. Under the Juniper Mist section of the Export window, make the appropriate selections in the **Region** and **Choose credentials** fields. The credentials field is where you select your Mist API credentials. Or, you can click the three dots to the right of the field to enter a new API key. Refer to [No Link Title](#) if you need to obtain your Mist API Key.

NOTE: The Mist API enables Hamina floorplan designs and AP settings to be brought over automatically to Mist.

3. Select the appropriate Organization, Site, Floorplans, and APs to export, then click **Export**. This action sends all of the selections over to Mist.
To see the export steps in action, watch the video under the **Import & Export, Reimagined** section of this [blog](#).
4. On the Mist portal, navigate to **Location > Live View**. You should see your floorplan imported from Hamina.

Watch the video below for a closer look into the power of the Juniper Mist and Hamina integration.

[Video: Future of Wi-Fi Tools](#)

Automatically Import Mist Floorplans to Hamina

On the flip side, you can import Juniper Mist floorplans and associated inventory into Hamina. Follow the instructions outlined in [Import From Juniper Mist to Hamina](#) to see how this is done.

If you wish to make changes to a Mist floorplan you imported to Hamina, you can push those changes back to Mist by following the export steps in the section above.

You can also see the steps for importing Mist Floorplans to Hamina in the second half of the video under the **Import & Export, Reimagined** section of this [blog](#).

Export iBwave Design Files and Import them to Mist

iBwave is a wireless network design software that enables you to design floorplans and related aspects, ensuring an exceptional wireless experience in your buildings. You can export your iBwave floorplan designs from within the tool and then manually import into Mist.

1. Complete the steps outlined in iBwave's [Quick Start Guide](#) to create a project in iBwave Express.
2. In iBwave Express, navigate to **File > Export > Export to MIST**.
3. Save the file to a location on your local drive.
4. On the Mist portal, navigate to **Location > Live View > Import Floorplan**.
5. On the Import Floorplans window, select the **.mist.ibwc** file you want to import and select any AP settings you want to be included under **More Options**. See step 4 in Import a Floorplan for more details about what these options do.
6. Click **Import**.
7. To complete AP matching, select the **Match APs** button, or click **Finish** if you are done.

You should now see your floorplans have been imported.

The following videos provide a start-to-finish look at how to design and plan your network using iBwave.



[Video: Create Your Floorplan Design in iBwave](#)



[Video: Place APs on a Floorplan in iBwave](#)



[Video: RRM Planning in iBwave](#)



[Video: Import Your iBwave Floorplan Design into Mist](#)

SEE ALSO

No Link Title

<https://docs.hamina.com/planner/import-export/juniper-mist>

<https://blog.hamina.com/hamina-wireless-x-juniper-integration-brings-network-design-and-operations-together>

<https://support.ekahau.com/hc/en-us/articles/20294597049883-Ekahau-Juniper-Mist-Dashboard-Integration-How-To-Guide>

Add Wayfinding Paths to a Floorplan

SUMMARY

Follow these steps to ensure successful wayfinding experiences by including wayfinding paths on your floorplans.

IN THIS SECTION

- [Add Walls to Improve Wayfinding | 40](#)
- [Add Exclusion Zones to Improve Wayfinding | 41](#)

In a Juniper Mist™ implementation, indoor location wayfinding paths are just like roads in a GPS navigation application. The wayfinding paths are the routes that users travel to reach their indoor destination, usually in the form of hallways, corridors, or intersections. You should be familiar with the physical space before you add wayfinding paths to the floorplan.



NOTE: Wayfinding paths are not required for indoor location wayfinding. However, we strongly recommend that you configure these paths so that the blue dot on the user's mobile app will snap to the path that you want users to follow. The blue dot will separate from the path when a user strays away.

When creating a wayfinding path, follow these best practices:

- Minimize the number of wayfinding paths on the floorplan. Draw a single, long path for a single hallway, for example. This approach reduces error and prevents gaps between paths. It also reduces the chance of the blue dot moving around jumpily while the user is on the path.
- If you have multiple paths, make sure that they are truly connected and that no gaps exist. To avoid potential issues, draw paths so that they intersect one another.
- Delete any excess segments or nodes by selecting them and then clicking **Delete** on your keyboard.


- Add paths for narrow walkway areas such as hallways, corridors, or any areas where your users need guidance.

You do not need to add paths to open areas, such as a cafeteria. As users move around the area, the blue dot guides them toward nearby paths.



Video: Adding Wayfinding Paths to a Floorplan

1. From the left menu of the Juniper Mist portal, select **Location > Live View**.
2. Select the site and the floorplan.
3. Click **Wayfinding Paths**.
4. Under **Drawing Tool** on the right, click **Insert Path**.
5. Start drawing your path, as follows:
 - a. Click inside the floorplan to indicate the starting point of the path.
 - b. Move to the next point that you want the path to include and click there to continue drawing the path.
 - c. Click the last point drawn to finish drawing the path. This exits the drawing tool.



NOTE: To replay the animation, refresh the web page.

6. Fine-tune your paths.
 - If you added multiple lines, zoom in on the floorplan to verify that no gaps exist.
 - Add walls to keep the blue dot contained within a desired vicinity. For example, if there are walls around the room that a user is in, the blue dot will be contained within that space. Walls prevent

the blue dot from snapping to paths outside of an enclosed area. For more information, see ["Add Walls to Improve Wayfinding" on page 40](#).

- Add **Exclusion Zones** to indicate areas where you don't want the blue dot to go, such as restrooms and outdoor areas. For more information, see ["Add Exclusion Zones to Improve Wayfinding" on page 41](#).

7. Click **Save**.


Add Walls to Improve Wayfinding

SUMMARY

Fine tune blue dot behavior in wayfinding applications by drawing walls on your floorplan.

You can add walls to the floorplan to keep the blue dot contained within a desired vicinity. For example, if there are walls around the room that a user is in, the blue dot will be contained within that space. Walls prevent the blue dot from snapping to paths outside of an enclosed area.

1. From the left menu of the Juniper Mist™ portal, select **Location > Live View**.
2. Select the site and the floorplan.
3. Click **Wayfinding Paths**.
4. Under **Drawing Tool** on the right, click **Insert Wall**.
5. Start drawing your wall, as follows:
 - a. Click inside the floorplan to indicate the starting point of the wall.
 - b. Move to the next point that you want the wall to include and click there to continue drawing the wall.
 - c. Click the last point drawn to finish drawing the wall. This exits the drawing tool.



NOTE: To replay the animation, refresh the web page.

- Make sure that the walls and the wayfinding paths do *not* intersect.
- Do not block doorways with walls, or your app will not be able to lead your users through those doors. Make sure there is enough space for the blue dot to enter and exit as needed.

6. Delete any excess segments or nodes by selecting them and then pressing Delete.
7. Click **Save**.

Add Exclusion Zones to Improve Wayfinding


SUMMARY

Further fine tune wayfinding experiences by identifying zones where you don't want the blue dot to appear.

Add exclusion zones to indicate areas where you don't want the blue dot to go, such as restrooms and outdoor areas. Completely enclose these areas, without any gaps, so that the blue dot cannot enter the exclusion zone.

1. From the left menu of the Juniper Mist™ portal, select **Location > Live View**.

2. Select the site and the floorplan.
3. Click **Wayfinding Paths**.
4. Under **Drawing Tool** on the right, click **Insert Wall**.
5. Start drawing the boundaries of the exclusion zone, as follows:
 - a. Click inside the floorplan to indicate the starting point of the exclusion zone.
 - b. Move to the next point that you want to include and click there to continue drawing the exclusion zone.
 - c. Click the last point drawn to finish drawing the exclusion zone. This exits the drawing tool.



NOTE: To replay the animation, refresh the web page.

- Enclose Exclusion Zones fully by overlapping the corners of the walls with one another as you draw them.
- The blue dot will stop at the edge of the Exclusion Zone and cannot enter by any means. Juniper Mist will not collect data while a client or asset is within those areas.

6. Delete any excess segments or nodes by selecting them and then pressing Delete.
7. Click **Save**.

Add Other Items to a Floorplan

IN THIS SECTION

- [Add Third-Party Beacons to a Floorplan | 43](#)
- [Add Location Zones to a Floorplan | 47](#)
- [Auto Zone: Add Location Zones to a Floorplan \(BETA\) | 48](#)
- [Add Proximity Zones to a Floorplan | 51](#)
- [Add Virtual Beacons to a Floorplan | 54](#)



NOTE: Before adding items to a floorplan, ensure that it is accurately scaled. See *Scale a Floorplan*.

You must add your access points to the floorplan. Only APs that are on the floorplan can participate in location-based services.

You also can add many other items, including:

- ["Location zones" on page 47](#)
- Third-party beacons
- Virtual beacons
- Wayfinding paths, walls, and exclusion zones

For details, continue to the next topics in this guide.

Add Third-Party Beacons to a Floorplan

SUMMARY

If you've installed battery-operated beacons to extend your BLE coverage, follow these steps to add them to your floorplan.

Access point (AP) installation can be challenging in certain types of buildings or structures. One example is an atrium, where cabling might interfere with aesthetics. In this case, you can use third-party, battery-operated beacons to help provide coverage.



NOTE:


- To ensure location accuracy, always use Juniper Mist™ APs. Third-party beacons are not meant as a replacement for Juniper Mist APs. Third-party beacons can supplement Juniper Mist APs in Mist SDK-enabled wayfinding deployments where AP placement proves difficult.
- Don't confuse third-party beacons with Juniper Mist's virtual beacons. Third-party beacons are physical, battery-operated beacons that exist onsite. You can deploy them to help provide coverage. Juniper Mist's virtual beacons, on the other hand, do not provide coverage. For more information about virtual beacons, see ["Add Virtual Beacons to a Floorplan" on page 54](#).

To add third-party beacons to a floorplan:

1. From the left menu of the Juniper Mist portal, select **Location > Live View**.
2. Click the floorplan to which you want to add the third-party beacons.
3. To ensure that the floorplan displays beacons:
 - a. Click the **Settings** button (near the top right corner of the page).




- b. Select the **Show 3rd Party Beacons** check box.



- c. Close the **Location Settings** window.
4. Click **Beacons and Zones** (above the map).




5. Click **Add Beacon** (above the map).



The third-party beacon appears at the center of the floorplan. The icon is a black-and-white circle. Above the icon is the default name, Anonymous.



6. Drag the new Anonymous beacon into the correct position on the floorplan.
 7. On the right side of the screen, under **3rd Party Beacons**, select the check box for the new Anonymous beacon.
 8. Click **Edit**.



9. Enter the information about the beacon:

- For **Type**, select **BLE Eddystone UID** (required).
- Enter a unique **Name** so that you can easily identify the various beacons that you add.
- Ensure that the **Namespace**, **Instance**, and **Mac Address** fields contain the correct information.
- Drag the **Transmit Power** slider left or right so that it shows the transmission power that is configured on the physical beacon.
- Ensure that the **X position** and the **Y position** match the physical location of the beacon.

Quick Edit Beacon

Type	BLE Eddystone UID
Name	TestBeacon
Namespace	f7826da6bc5b71e0893e
Mac Address	765030744870
Transmit Power	Custom: 4 dBm (1.6m immediate, 3.2m near, 9.5m far)
X position (m)	30.1586
Y position (m)	-21.0213
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	



NOTE: Juniper Mist will neither manage the beacon nor detect its health.

10. Click Save.

Your third-party beacon is visible on the floorplan.



The AI engine adds the beacon to the beams received. The engine uses the X,Y coordinates and transmission power to help calculate beacon location.

Add Location Zones to a Floorplan

SUMMARY

Follow these steps to identify areas of particular interest on your floorplan.

Location zones are useful whether you're developing applications or using the occupancy and engagement analytics pages in the Juniper Mist™ portal.


After you add location zones to a floorplan, you can use these zones in several ways.

- On the Occupancy Analytics page, you can monitor each zone's occupancy.
- On the Engagement Analytics page, you can analyze visitor and employee dwell times in each zone.
- With API calls, you can capture every zone entry and exit event for client devices, assets, and SDK clients.
- With your Juniper Mist SDK-enabled applications, you can trigger alerts when people enter and exit high-security zones.

To add location zones to a floorplan:

1. From the left menu of the Juniper Mist portal, select **Location > Live View**.
2. Select the site and the floorplan.
3. Click **Beacons and Zones**.
4. Click **Add Location Zone**.
5. Drag the mouse to define the zone.

Start from the top left corner of the area that you want to define. Release the mouse at the lower right corner of the area.






TIP: To replay the animation, refresh the page or open the image in a new tab.

6. Give the zone a unique name:

- a. On the **Location Zones** list, select the check box for the zone.
- b. Click **Edit**.



- c. Enter a name.

- d. Click **OK**.

7. Add other zones as needed.

8. Click **Save**.

Auto Zone: Add Location Zones to a Floorplan (BETA)

Auto Zone automatically identifies location zones for you based on the boundaries of a given floorplan. This can be especially useful for large deployments containing a vast number of buildings and rooms, as

it automatically identifies and names the zones for you, thus allowing for more precise analytics to be gathered. For more information on location zones, see ["Add Location Zones to a Floorplan" on page 47](#).

Auto Zone identifies location zones on a floorplan via Juniper's AI-powered image segmentation models, which extract zone information directly from the floorplan and enable logical zone grouping. These models also provide insight into occupancy and traffic flow. For more information, see *Occupancy Analytics Zone*.



NOTE: Auto Zone merely suggests location zones for you. You must make adjustments and finalize as you see fit.

Prior to using Auto Zone, ensure the following:


- Your floorplan is properly scaled. See [Scale a Floorplan](#).
- Your floorplan is as clean as possible. For example, when rooms are the only thing featured on the floorplan, and there is no additional clutter such as furniture or excessive lines, this ensures the most accuracy.
- Clear all existing zones from the floorplan to avoid overlapping zones. You can do this from the list in the Location Zones tab to the right of the floorplan.

To use Auto Zone:

1. From the Juniper Mist portal, navigate to **Location > Live View**.
2. Select the **floorplan**.
3. Select the **Beacons and Zones** button.
4. Select the **Auto Zone** button in the top right corner of the screen.
5. At the bottom of the Auto Zone window, select **Start Auto Zone**.



6. Confirm that you want to start Auto Zone by selecting **Yes** from the pop-up window that appears.
7. Once Auto Zone completes, review the zones, then select **Accept** or **Reject**. A pop-up window will appear asking you to confirm your action.



8. If needed, adjust the proposed zones by physically dragging the corners of the zone with your mouse.
9. Select the Location Zones tab to right of the floorplan to see the list of Location Zones that Auto Zone has created for you. You can remove and rename zones from here as needed.

- a. To remove a zone from the floorplan, select the checkbox next to the zone name, then select the **Remove** button at the top.
- b. To rename a zone, simply select the name to highlight it from the righthand list, then click **Edit** at the bottom of the screen. Rename the zone, then select **Save**.



NOTE: You can also select a zone from the floorplan and it will highlight the corresponding zone in the Location Zones list for you. This helps to ensure you have the correct zone selected before editing or removing. If your floorplan is pre-labeled with names, Auto Zone will automatically carry the zone names over for you.

10. When you are done making changes, select the **Save** button in the top right corner of the screen.

Add Proximity Zones to a Floorplan

SUMMARY

If you're implementing proximity tracing at your site, follow these steps to identify the areas that you want to monitor.

You can create and use Proximity Zones to gather occupancy and engagement data for SDK clients, named assets, and connected and unconnected WiFi clients. Users can create individual or grouped Proximity Zones for each AP (access point). Proximity Zones triggering is based on the RSSI data received from the clients.

When creating Proximity Zones, you can create:

- An individual Proximity Zone per AP
- Multiple Proximity Zones per AP
- Grouped Proximity Zones per grouped APs


After you add proximity zones to a floorplan, you can use these zones in several ways.

- On the Occupancy Analytics page, you can monitor each zone's occupancy by selecting Client Density and Proximity Zones. Make sure to enable the Public Occupancy Dashboard in the site configuration.

- On the Engagement Analytics page, you can analyze visitor and employee dwell times in each zone.
- With API calls, you can capture every zone entry and exit event for client devices, assets, and SDK clients. Make sure Proximity Zones is selected as the Streaming API under Webhooks in the site configuration.
- With your Juniper Mist™ SDK-enabled applications, you can trigger alerts when people enter and exit high-security zones.

To add proximity zones to a floorplan:

1. From the left menu, select **Location > Live View**.
2. Select the site and the floorplan.
3. Click **Beacons and Zones**.
4. Click **Add Proximity Zone**.



5. Select the AP or group of APs that you want to be in the proximity zone.
If you selected a group of APs, also select the **Group APs into one proximity zone** check box to add them all to a single proximity zone.
6. Give the proximity zone a name.
7. Set the RSSI threshold.

2 APs on the Floorplan

<input checked="" type="checkbox"/>	
<input checked="" type="checkbox"/>	AP1_MistDev ac:23:16:ed:76:c7
<input checked="" type="checkbox"/>	AP2_MistDev ac:23:16:ed:78:98

2 APs Selected

Group APs into one proximity zone

Name
TestProximityZone1

Distance: 6m (-70 dBm)


ⓘ APs will be grouped into a single proximity zone.

CANCEL CREATE

When a client reaches the indicated RSSI threshold or higher, an `in_event` is triggered. Similarly, if the client travels further away from the AP and the RSSI goes lower than the threshold, an `out_event` will occur.

8. Click `Create`.

You will see the proximity zone on the floorplan based on the information you provided.



9. Add other proximity zones as needed.

Add Virtual Beacons to a Floorplan

SUMMARY

To send push notifications to your application users as they progress through your site, add virtual beacons to your floorplan.

A virtual beacon is an object on the floorplan that you can use to trigger proximity-based events through your Juniper Mist™ SDK-enabled applications.

Examples

- At your building entrance: When visitors arrive, display a greeting on their mobile devices.
- Inside a store: Offer coupons as shoppers pass special displays.
- At a conference: Prompt attendees to download lecture slides when they enter a breakout room.



NOTE: A virtual beacon does not transmit or receive signals. It is purely virtual, for the purpose of defining a coverage area for a Juniper Mist SDK-enabled interaction.

1. From the left menu of the Juniper Mist portal, select **Location > Live View**.
2. Click the site and the floorplan.
3. Ensure that the floorplan is showing the virtual beacons and their coverage areas:

- a. Click the **Settings** button (near the top right corner of the page).



- b. In the pop-up window, select the check boxes for **Show Virtual Beacons** and **Show Virtual Beacons Coverage**.




- c. Close the pop-up window.

4. Click **Beacons and Zones**.



5. Add a virtual beacon:

- a. Click **Add VBeacon**.
- b. Drag the new **Anonymous** beacon to the area where you want the users to see the notification.



- c. As needed, add and position more virtual beacons. Click **Save**.

The floorplan shows the virtual beacons, surrounded by pink circles that indicate their coverage area.



6. Set the name and coverage area for each virtual beacon:
 - a. Click the virtual beacon.
 - b. Click **Quick Edit** (near the bottom right corner of the page).
 - c. Enter a **Name** to uniquely identify this virtual beacon on the floorplan.
 - d. Adjust the **Transmit Power** to make the coverage area larger or smaller.

Quick Edit Virtual Beacon

Name	WelcomeBeacon
Message	Welcome to the office!
UUID	00000000-0000-1000-8000-000000000000
Transmit Power <input type="range" value="4"/> Custom: 4 dBm (1.6m immediate, 3.2m near, 9.5m far)	
Major	0
Minor	0
X position (m)	10.0263
Y position (m)	-7.9849
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

- If the pink area on the map is smaller than the desired coverage area, drag the **Transmit Power** control to the right. After you save the settings, the pink circles will widen.

- If the pink area is too large, drag the **Transmit Power** to the left. After you save the settings, the pink circles will become narrower.
- e. Click **Save** to save the settings in the **Quick Edit** pop-up window.

Next Steps

Configure the message that you want to display or the webpage that you want to launch when people enter a virtual beacon's coverage area. See ["Configure Push Notifications for User Engagement" on page 70](#).

Validate Your Floorplan

SUMMARY


Double-check everything to ensure that your floorplan is valid.

Most issues with location can be traced to floorplan inaccuracies. To enable the AP to generate accurate location estimates, the position information in the Juniper Mist portal must match the AP's actual position at your site.

1. From the left menu of the Juniper Mist portal, select **Location > Live View**.
2. Select the site and the floorplan.
3. If APs are not visible on the floorplan:
 - a. Click the **Settings** button (near the top right corner of the page).



- b. Select the check boxes to show BT11 and Wi-Fi APs.



- c. Close the **Location Settings** window.
4. Check the scale to ensure that distances on the floorplan match the actual distances at the site.

- a. Click **Ruler**.
- b. Draw a line between two points on the floorplan, such as two walls of a room.
- c. Verify that the line length in the blue box matches the actual measurement at the site.



- d. Click **Done** to put away the ruler.

If you need to change the scale, click **Setup Floorplan**, and then make the changes. For help, review the other topics in this chapter.

5. Click each AP, and verify the information in the **Selected Access Point** area of the page.



- The MAC address shown on the floorplan must match the MAC address of the corresponding AP at the site. If the MAC addresses don't match, then Juniper Mist has inaccurate information about the location of the AP, and the location estimates will be incorrect.
- The position, height, and orientation must be accurate to enable Juniper Mist to generate correct location estimates.

If you need to make changes, click **Setup Floorplan**. Make changes by dragging the AP or by editing the position details. For help, review the other topics in this chapter.

4

CHAPTER

Wayfinding and User Engagement

SUMMARY

Use the information in this chapter to get started with wayfinding and user engagement.

IN THIS CHAPTER

- Wayfinding Use Case | **61**
- AR and VR Wayfinding Use Case | **63**
- Hybrid Use Case | **65**
- Daisy-Chain BT11 APs | **68**
- Configure Push Notifications for User Engagement | **70**

Video Overview



Video: [NOW in 60: Juniper Mist User Engagement](#)

What Do You Want to Do?

Table 5: Top Tasks

If you want to...	Use these resources:
Implement wayfinding to help your customers and visitors find their way to rooms, events, and products. <i>This use case shows how you can use your Juniper Mist User Engagement Subscription and the Juniper Mist SDK, you can create wayfinding applications to support your customers and visitors.</i>	"Wayfinding Use Case" on page 61
Implement a mix of services including wayfinding, push notifications, and asset tracking to promote user engagement at your site or event. <i>This use case shows how a large retailer integrated wayfinding with publish notifications and asset tracking.</i>	"Hybrid Use Case" on page 65
Get configuration tips.	Explore the other topics in this chapter.

Wayfinding Use Case

SUMMARY

Are you interested in implementing indoor wayfinding at your site? Read through this use case to see one way to proceed, and get familiar with the components and the an overview of the various tasks involved.

IN THIS SECTION

- Benefits | [61](#)
- Scenario | [61](#)
- Components | [61](#)
- Process Overview | [62](#)

Benefits

With virtual Bluetooth LE (vBLE)-equipped Access Points (APs), a Juniper Mist User Engagement subscription, and the Juniper Mist SDK, you can integrate turn-by-turn wayfinding into your on-site customer engagement applications.

You can implement wayfinding at large-scale locations such as conference centers, sporting events, theme parks, museums, hospitals, department stores, and universities. Wayfinding helps your app users find their way to rooms, events, and products.

[See more information about the Juniper Mist User Engagement Subscription.](#)

Scenario

For this scenario, let's imagine that your professional association is hosting a large conference at a busy convention center. You want to integrate wayfinding into an app that attendees can use to find their conference rooms, dining facilities, and other important locations.



[Video: Wayfinding Use Case](#)

Components

Juniper Mist uses the following devices and systems to compute location precision.

- Access Points—APs with the vBLE antenna array transmit BLE signals and broadcast BLE Beacons.
For more information, see "[APs for Location Services](#)" on page 8.
- Mobile Devices—Mobile devices use Bluetooth to listen to BLE beacons broadcast from APs.
For more information, see "[BLE Beacons](#)" on page 22.
- Mobile Device Application with Juniper Mist SDK—The SDK (in the mobile app) receives data from the AP and sends that data to the cloud.
For more information, see "[Juniper Mist SDK](#)" on page 100.
- Juniper Mist Cloud—The cloud takes the data that the device sends and runs it through the Location Engine. The Location System then returns the location wayfinding information to the user on the mobile application.

Process Overview

To implement the scenario, do these tasks.

Table 6: Wayfinding Setup Process

Step	Action	More Information
1	Purchase a Juniper Mist User Engagement subscription, and activate it in the Juniper Mist portal.	<ul style="list-style-type: none"> • Juniper User Engagement information • "Activate Subscriptions" on page 7
2	Ensure that vBLE Engagement is enabled for the site. NOTE: vBLE Engagement is enabled by default after you activate your User Engagement subscription.	"Enable Bluetooth Based Location Services" on page 21
3	Ensure that the Live View floorplan includes accurate position, height, and orientation data for your APs.	"Floorplan Setup" on page 30
4	Add wayfinding paths to the floorplan.	"Add Wayfinding Paths to a Floorplan" on page 38

Table 6: Wayfinding Setup Process (Continued)

Step	Action	More Information
5	Obtain the Juniper Mist SDK and integrate it into your customer-facing mobile application.	"Juniper Mist SDK" on page 100
6	Configure push notifications to provide feedback and information to customers as they pass through specific areas on their route.	"Configure Push Notifications for User Engagement" on page 70

AR and VR Wayfinding Use Case

SUMMARY

You can implement indoor wayfinding via Augmented and Virtual reality to help your employees, visitors, and customers find their way around your sites.

IN THIS SECTION

- [Scenario | 64](#)
- [WHAT's NEXT | 64](#)


Juniper Mist location services offers indoor location wayfinding via augmented reality (AR) and virtual reality (VR), enabling application users to navigate the premises using their enhanced real-world surroundings. You can implement AR/VR wayfinding at large-scale locations where your app users need assistance finding their way around.

A Juniper Mist User Engagement subscription and the Juniper Mist SDK enables you to integrate bluedot wayfinding into your on-site mobile workplace and mapping applications. In this, the partner application provides the camera-based AR/VR wayfinding experience, and the Mist SDK provides the bluedot within that. In order for your employees, customers, or visitors to use AR/VR wayfinding, camera access on their device must be enabled for the application. In-app alerts can also be pushed in real-time, such as to alert visitors as they approach or enter restricted areas.

Scenario

Let's say your company has a large campus with various buildings and rooms, some of which are restricted to visitors. You want to integrate wayfinding into an application that both employees and visitors can use to find their way around.

For example, employees may need assistance navigating within large storage facilities to find the location of certain items, or they may need help navigating in buildings that they do not typically work in. Visitors need assistance navigating within buildings to find areas such as conference rooms or offices, and you also want to ensure they stay out of restricted areas.



WHAT's NEXT

To get started, see:

- ["Components" on page 61](#)
- ["Process Overview" on page 62](#)

RELATED DOCUMENTATION

[Wayfinding Use Case | 61](#)

[Juniper Mist SDK | 100](#)

Hybrid Use Case

SUMMARY

See how a retail store achieves a variety of business goals by implementing several types of location services together.

IN THIS SECTION

- [Super Beacons | 65](#)
- [Indoor Location Wayfinding | 66](#)
- [Zones for Zone Analytics | 66](#)
- [Asset Tracking | 67](#)
- [Guidelines | 68](#)

Juniper Mist™ offers a wide variety of indoor location services that you can mix and match (a hybrid approach) depending on your use cases.

Below is a real-life example of a Mist customer (a large retailer) who uses the following mix of location services:

- Super beacons
- Indoor location wayfinding
- Zones for zone analytics
- Asset tracking

Super Beacons

This Juniper Mist customer placed access points (APs) transmitting a ninth omni beam (“super beacons”) at the entrances of the store. When customers enter, they get a notification on the retailer’s Mist SDK-enabled mobile application. For details about implementing this location service, see ["Enable Bluetooth Based Location Services" on page 21](#).

Indoor Location Wayfinding

All main aisles and concrete pathways are wayfinding paths for indoor location wayfinding. See ["Wayfinding Use Case" on page 61](#).

The customer installed the APs with drop-threaded rods over the center of an aisle, approximately every two aisles.




This customer used daisy chaining in several parts of the store where it made sense to save switch ports. See ["Daisy-Chain BT11 APs" on page 68](#).

Zones for Zone Analytics

Departments in the center of the store, such as infants' apparel or men's clothing, are zones for the purpose of gathering zone analytics. See ["Add Location Zones to a Floorplan" on page 47](#).

Notice that the customer mounted BT11 APs on existing support columns and structural poles. In these areas, the retail customer leaves the established wayfinding paths and provides X and Y coordinates to the back end for the zone analytics engine to process for retail customers' shopping habits.



Asset Tracking

This Mist customer uses asset tracking so that store employees can locate misplaced items, such as warehouse pallets. The customer placed Bluetooth Low Energy (BLE) beacon tags on the items to be tracked. With those tags in place, employees can track the location of the assets on the Live View page of the Juniper Mist portal. See ["Find Equipment Use Case" on page 88](#).

Guidelines

- We always recommend that you refer to the ["AP Placement for Location Services" on page 9](#) to ensure that you have proper coverage.
- You must ensure that products on the shelves do not block APs, as this blockage can interfere with Bluetooth.
- When placing your APs, be sure that you follow the Rubber Band Model to ensure location accuracy and keep customers inside of the APs at the outer edges of the floorplan. See ["Rubber Band Model" on page 87](#).
- If you cover a large area with Mist APs, you may experience AP Reflection. The AP Reflection Detection event on the Analytics > Events page means that the AP is receiving packets sent from its own Ethernet port (the source address for inbound packets is the address of the AP itself). Double check your physical connections to fix any loops that you may have inadvertently created on your network.

Daisy-Chain BT11 APs

SUMMARY


Follow these guidelines to economically power multiple BT11 access points (APs) from one Power over Ethernet (PoE) port.

It can be challenging to support turn-by-turn indoor wayfinding in long hallways. To provide continuous Bluetooth Low Energy (BLE) coverage, the access points (APs) must be within 30 to 50 feet (10 to 15 meters) of one another. If your site has several long hallways, you'll need a lot of access points (APs).

Purchasing a large number of full-featured APs can get expensive. And powering them can quickly use up your switch ports.

The BLE-only BT11 is an economical choice in any area where you're either overlaying an existing wireless network or supporting only location-based services (not Wi-Fi).

By daisy chaining these APs, you can power four APs per switch port (the directly connected AP and three others).



Before You Begin

Place your APs to ensure continuous BLE coverage and location accuracy. See ["AP Placement for Location Services" on page 9](#).

To daisy chain BT11 access points:

Enable PoE Passthrough to extend power from the first AP to the *enabled* Ethernet ports and/or the module port. This allows the first AP to provide Power over Ethernet (PoE) to devices connected to Eth1 on the AP. To configure PoE Passthrough, see *PoE Passthrough*.

Connect the first BT11 AP to a Link Layer Discovery Protocol (LLDP)-enabled switch or a 30-watt (W) power injector. Then connect up to three other APs in a daisy chain.

 **NOTE:** If you use a 15W power injector or a switch without LLDP enabled, you can power only two daisy-chained units (the directly connected AP and one other).

Tips

- If the APs lack sufficient power, they will reboot. This issue can occur if:
 - The first AP is not connected to an LLDP-enabled port or 30W power injector.
 - The daisy chain includes more than the recommended number of APs.
- Be mindful of the cable length between the switch and the first BT11. A device loses 4.5W of power for every 100 meters of cable separating it from its power source.
- If the switch port has MAC limiting enabled, increase the limit to allow the actual number of APs in the daisy chain.

Configure Push Notifications for User Engagement

SUMMARY

After enabling virtual beacons, add the messages for your push notifications and fine-tune the power settings for optimal impact.

When developing applications with the Juniper Mist SDK (Software Development Kit), you can include notifications. For example, you can display a greeting when a user enters your building. You can display a special offer when a customer approaches a sales display.

To set up these notifications, add ["virtual beacons" on page 54](#) to your floor plan. Because the beacons are virtual, you can add as many of them as you need. For each one, specify the message or web page to display, and define the coverage area. When your mobile app user enters the virtual beacon's coverage area, as shown in pink below, the specified message or web page appears in the app.

Video Overview



[Video: What are Virtual Beacons](#)

Before You Begin

Add virtual beacons to the floorplan. See ["Add Virtual Beacons to a Floorplan" on page 54](#).

To configure push notifications:

1. From the left menu of the Juniper Mist portal, select **Location > Live View**.
2. Click the site and the floorplan.
3. Ensure that the floorplan is showing the virtual beacons and their coverage areas:
 - a. Click the **Settings** button (near the top right corner of the page).




- b. In the pop-up window, select the check boxes for **Show Virtual Beacons** and **Show Virtual Beacons Coverage**.



- c. Close the pop-up window.

4. Configure the notifications for each virtual beacon:
 - a. Click the virtual beacon.
 - b. Click **Quick Edit** (near the bottom right corner of the page).
 - c. Enter a **Name** to uniquely identify this virtual beacon on the floorplan.
 - d. Enter the **Message** or **URL** that you want to display in your application when users enter the coverage area of this virtual beacon.



- e. Click **Save** to save the settings in the **Quick Edit** pop-up window.
5. Test your application to ensure that the notifications appear when expected. If needed, adjust the coverage area of the virtual beacon.

A pink circle represents a virtual beacon's coverage area.



To adjust the coverage area:

- Click the virtual beacon.
- Click **Quick Edit** (near the bottom right corner of the page).
- Adjust the **Transmit Power** to make the coverage area larger or smaller.

Quick Edit Virtual Beacon

Name	WelcomeBeacon
Message	Welcome to the office!
UUID	00000000-0000-1000-8000-000000000000
Major	0
Minor	0
Url	
X position (m)	10.0263
Y position (m)	-7.9849
Transmit Power	Custom: 4 dBm (1.6m immediate, 3.2m near, 9.5m far)
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

- If the pink area on the map is smaller than the desired coverage area, drag the **Transmit Power** control to the right. After you save the settings, the pink circles will widen.
- If the pink area is too large, drag the **Transmit Power** to the left. After you save the settings, the pink circles will become narrower.

- Click **Save** to save the settings in the **Quick Edit** pop-up window.

5

CHAPTER

Asset Visibility and Room Occupancy

SUMMARY

Use the information in this chapter to get started with asset visibility and room occupancy.

IN THIS CHAPTER

- View and Manage BLE Clients | [75](#)
- Create Named Assets | [79](#)
- Create Asset Filters | [82](#)
- Import Assets | [85](#)
- Guidelines for BLE Beacon Tags | [86](#)
- Rubber Band Model | [87](#)
- Find Equipment Use Case | [88](#)
- Room Utilization Use Case | [91](#)
- Find the Current Location of a Named Asset | [93](#)

Video Overview



[Video: NOW in 60: Juniper Mist Asset Visibility](#)

What Do You Want to Do?

Table 7: Top Tasks

If you want to...	Use these resources:
Find equipment at your site. <i>With your Asset Visibility subscription, you can easily find equipment and other assets, with detailed analytics based on their location.</i>	"Find Equipment Use Case" on page 88
Track your staff's usage of facilities. <i>With your Asset Visibility subscription, you can track your staff's usage of your facilities.</i>	"Room Utilization Use Case" on page 91
Understand guidelines for optimizing location-based experiences. <i>Get tips for using BLE beacon tags, positioning your access points, and managing assets.</i>	<ul style="list-style-type: none"> • "Guidelines for BLE Beacon Tags" on page 86 • "Rubber Band Model" on page 87 • "Import Assets" on page 85 • "Create Named Assets" on page 79
Explore further. <i>Explore use cases and concepts to benefit from your Asset Visibility subscription.</i>	Other topics in this chapter

With a Premium Analytics subscription, you can use the [Asset Insights Dashboard](#) to collect data about BLE-tagged asset location, status, and usage. This dashboard provides details about the assets in your organization as well as insights into asset inventory across sites. You can also view inactive assets, monitor movement trends across zones, and much more.

View and Manage BLE Clients

SUMMARY

The BLE Clients page shows information about all Bluetooth Low Energy (BLE) clients that have been active at the selected site and floorplan.

IN THIS SECTION

- [Prerequisites | 75](#)
- [Find the BLE Clients Page | 76](#)
- [Filter the Data | 77](#)
- [Adjust the Columns | 78](#)
- [Add, Modify, or Remove Assets | 78](#)


[Juniper Mist Asset Visibility](#) is a cloud service that provides real-time tracking and historical location analytics for people, Bluetooth Low Energy (BLE) assets, and IoT devices. For example, with asset location and tracking configured on a site, you can quickly account for high-value construction equipment, or pinpoint the location of key human resources such as nurses or security guards. It's not uncommon, however, for the number of assets under management to scale to the thousands and even tens of thousands, making it hard to find and track individual items or groups in a meaningful way.

Juniper Mist provides multiple ways to name, filter, and categorize BLE assets so you can organize and identify them at scale.

Prerequisites

The BLE Clients page is available only if Asset Visibility is enabled. First purchase and enable an Asset Visibility subscription, and then enable Asset Visibility in the site configuration.

1. Purchase and activate your Asset Visibility subscription. See ["Activate Subscriptions" on page 7](#).
2. From the left menu of the Juniper Mist portal, select **Organization > Site Configuration**.
3. Select the site.
4. Scroll down to the Bluetooth based Location Services section of the site configuration.
5. Select the **Asset Visibility** check box.



Find the BLE Clients Page

Juniper Mist Asset Visibility solves this by providing a variety of ways that you can use to name, filter, and categorize your BLE assets.

To view your existing BLE Clients in the Mist dashboard, select a site with BLE clients and then choose the following:

- **Clients > BLE Clients**

Figure 6: BLE Clients

The screenshot shows the Juniper Mist Asset Visibility interface. On the left is a navigation sidebar with icons for Monitor, Marvis, Clients, Access Points, Switches, WAN Edges, Mist Edges, Private 5G, Location, Analytics, Site, and Organization. The 'Clients' icon is selected. The main content area has a header 'LIVE DEMO' with '1059 BLE Clients' and a 'Filter' search bar. Below the header are tabs: All, Named Assets, Assets Filter, and site: Live-Demo. The 'All' tab is selected, showing a table of tracked assets. The table columns include: MAC Address, Name, Active, Last Seen, Last Floorplan, Manufacturer, Labels, iBeacon UUID, iBeacon Major, and iBeacon Minor. The table lists several entries, including an 'Apple AirLocate' device and a 'Kontakt Micro-Lo' device. A blue line highlights the 'Kontakt Micro-Lo' entry. To the right of the table is a 'Location History' section with a table showing floorplan, zone, and total time. The '01 - Office' floorplan is selected. Below this is a '01 - Office Marvis' section showing a floor plan diagram with various rooms and sensor locations. The 'Kontakt Micro-Lo' device is highlighted in the floor plan.

Figure 1 shows a typical list of BLE clients (also called tracked assets, and BLE tags) along with the Live View and location history of one selected BLE client. By default, Juniper Mist Asset tracking supports BLE MAC addresses and RSSI signal strength. The omnidirectional Bluetooth antenna in Juniper Mist APs also works in conjunction with RSSI signal strength identify the quadrant, or relative direction, of the asset to the AP.

From BLE clients page, you can select the site and use the tabs to quickly filter assets that have already been grouped:

- **By Site**—Select a site from the drop down. Note that if the site does not have any BLE clients, that option will not show up in the menu.
- **By Tab:**
 - **All**—Shows all client BLE assets in the site. If a Juniper Mist AP can hear the signal, the asset will be listed, regardless of whether the tag is named or labeled or otherwise.
 - "[Create Named Assets](#)" on page 79—Use named assets to find and display assets by their custom Mist asset label and beacon type.
 - "[Create Asset Filters](#)" on page 82—The Asset Filters tab shown a list of existing asset filters, if any, that are available in the Mist portal.
 - To add assets to the list, click the **Add Asset** button to create the filters, as explained below.
- **By Attribute**—To filter based on an attribute such as MAC address or manufacturer, start typing in the Filter box. For example, you only need to type **uni** to find assets with "Juniper Networks" in the name. You can also use multiple filters to further narrow the list, as shown here:



Filter the Data

Use the buttons and the Filter box to narrow or expand the data that is displayed on the BLE Clients page.

- To show only named assets, click the **Named Assets** button near the top of the page.



NOTE: For help naming assets, see "[Create Named Assets](#)" on page 79.

- To select a site, use the **Site** drop-down list near the top of the page.
- To filter by BLE advertisement details, click the tabs above the table: **iBeacon**, **Eddystone UID**, **Eddystone URL**, **Eddystone TLM**. For example, if you select iBeacon, the table shows only the clients that are advertising iBeacon UUID/Major/Minor packets.

See "[BLE Beacons](#)" on page 22.


Adjust the Columns

You can add, remove, and sort the columns on the BLE Clients page.

- To sort by a column, click the column heading. To reverse the sort order, click the column heading again.
- To view the column options, click the settings button at the top right corner of the page.



In the Table Settings window, select the check box for each column to include. Clear the check box for each column to remove. Close the window to apply the changes.



Add, Modify, or Remove Assets

- To add an asset, click **Add Asset**. Then enter the name, select any labels that you want to apply, and enter the MAC address.



NOTE: You also can import a list of assets. See "[Import Assets](#)" on page 85.

- To add or remove labels for assets, select the check boxes for the assets, and then click **Edit Assets**. Then make your changes, and click **OK**.
- To delete assets, select the check boxes for the assets, and then click **Delete Assets**.

Create Named Assets

SUMMARY

For asset visibility use cases, it's helpful to assign names to the assets.

IN THIS SECTION

- [Select BLE Clients to Name | 79](#)
- [Use a Filter to Generate a Common Name for Similar Assets | 81](#)
- [Use a CSV File to Assign Names to Assets | 81](#)

Naming assets helps you to identify them in Live View and other areas of the Juniper Mist™ portal. Behind the scenes, Juniper Mist prioritizes named assets, compared to the unnamed BLE client devices in your environment. This prioritization results in even better location accuracy for the assets that you want to track.


You can use any of these methods to name assets:

- ["Select BLE clients to name." on page 79](#)
- ["Use a filter to generate a common name for similar assets." on page 81](#)
- ["Use a CSV file to assign names to assets." on page 81](#)

Select BLE Clients to Name

You can select any Bluetooth Low Energy (BLE) client and enter a name manually or use variables to generate a name that includes details such as the site name. Or select multiple clients and use a counter to assign similar names, such as Asset 1, Asset 2, and so on.

1. From the left menu of the Juniper Mist portal, select **Clients > BLE Clients**.
2. Select the check box for each client that you want to name.
3. At the top of the page, click **Locate this as an asset** (if you selected one client) or click **Locate these as assets** (if you selected multiple clients).



4. In the pop-up window:

- a. Select the check box.
- b. In the **Generate names with format** box, enter characters, variables, or both.

The asset name can include characters that you type, plus information that Juniper Mist generates from variables. Read the on-page information to learn more about the variables. To enter a variable, type it as shown, including the square brackets.



NOTE: If you selected multiple clients, you must use a counter variable, such as [ctr] or [ctr.3], to give each client a unique name.

Example: Let's say that you've attached BLE beacon tags to three wheelchairs. You want to name them Wheelchair_1, Wheelchair_2, and Wheelchair_3. You'd enter the text, *Wheelchair_*, along with the [ctr] variable.



TIP: If you have multiple sites, consider including the [site] variable. Then, when viewing the BLE Clients page, you can use the site name as a filter.

5. Click **Save**.

Use a Filter to Generate a Common Name for Similar Assets

You can use a filter to identify and name assets that have a common attribute, such as the manufacturer or the iBeacon UUID. For example, let's say that you attached BLE beacon tags to the inventory carts that your employees use in your retail store. You want to name all of these assets *Inventory Cart* so that you can easily identify them in **Live View**.

1. From the left menu of the Juniper Mist portal, select **Clients > BLE Clients**.

2. In the **Filter** box, enter the value that you want to use for this filter.

For this example, the tags on the inventory carts have a common UUID, so you'd enter the complete UUID in the **Filter** box.

3. Click **Create Label**.



4. In the pop-up window, enter the name that you want to assign to these assets.

For our example, you'd enter *Inventory Cart* as the name.

5. To confirm that the label was added, you can look for the assets on the BLE Clients page and in the Live View.

- On the BLE Clients page, enter the name in the **Filter** box, and press Enter. The table is filtered to show the assets with that name.
- On the Live View page, click the **Assets** tab and then scroll through the list to see the assets with the new name.

Use a CSV File to Assign Names to Assets

With this approach, you enter the names and MAC addresses in a file, and then upload it on the BLE Clients page.

For instructions, see "[Import Assets](#)" on page 85.

Create Asset Filters

SUMMARY

Create asset filters that you can use to categorize and track your BLE assets.


IN THIS SECTION

- [Create an Asset Filter | 83](#)
- [BLE Beacons for Filtering | 83](#)
- [Requirement: Asset Visibility | 84](#)

Juniper Mist provides multiple ways to name, filter, and categorize BLE assets so you can organize and identify them at scale. One of them is asset filters, which is a method for identifying and tracking asset using the asset's existing tags. Many IoT devices and BLE clients come pre-configured with a manufacturer's tag, asset name, or other identifier that they broadcast along with the BLE beacon. The device manufacturer may also provide a way for you to create your own custom tag for their assets.

Mist BLE can read these values, which means you just need to create a corresponding filter to automatically select asset groups according to their filter value. Thus in a hospital setting, for example where you may have tens of thousands of tracked assets, asset filters gives you a way to quickly focus on just the asset class or type you want, such as EKG stations, IV tables, or Medicine Carts.

Figure 7: Adding an Asset Filter



Create an Asset Filter

As explained below, you can use asset filters to find and display assets according to their beacon type and embedded asset value, which can be a very practical way to call-out specific assets from what may otherwise be a very long list.

- In the BLE Clients page, click the **Add Asset** button and select **Asset Filter** to open the asset filter page.
- For **Filter Type**, specify the beacon used by the assets you want to identify.
- For **Value**, used the value embedded in the beacon you want to identify and/or track.

Figure 8: Create an Asset Filter

MAC Address	Name	Active	Last Seen	Last Floorplan	Manufacturer	Labels
00:00:00:34:33:33	VHM Lite-ble	Jun 26, 2024 10:58:29 AM	01 - Office	XEROX CORPO...		
00:25:cf:32:e1:fa	Taser International Inc.	Jun 26, 2024 1:53:38 PM	01 - Office	Taser Internati...		
00:25:cf:33:21:0d	Taser International Inc.	Jun 26, 2024 1:54:05 PM	01 - Office	Taser Internati...		
00:25:cf:33:21:f0	Laser International Inc.	May 30, 2024 1:13:27 AM	01 - Office	Laser Internati...		
00:25:cf:33:28:95	Taser International Inc.	Jun 26, 2024 1:54:50 PM	01 - Office	Taser Internati...		
00:25:cf:42:c7:a1	Laser International Inc.	Jun 26, 2024 1:51:06 PM	01 - Office	Laser Internati...		
00:25:cf:4a:2b:b0	Taser International Inc.	Jun 26, 2024 1:53:11 PM	01 - Office	Taser Internati...		
00:25:cf:4a:2c:78	Laser International Inc.	Jun 26, 2024 1:54:48 PM	01 - Office	Laser Internati...		
00:25:cf:4a:2d:4e	Taser International Inc.	Jun 26, 2024 1:54:06 PM	01 - Office	Taser Internati...		
00:3e:73:07:a3:cc	Mist Systems	Jun 26, 2024 1:54:15 PM	01 - Office	Mist Systems		

You can combine up to six different filter types (that is, the existing tag data embedded in on the asset) and values per asset filter, although in many cases a single, unique and class-identifying value such as a manufacture's ID is sufficient for the filter to produce the needed specificity.

BLE Beacons for Filtering

BLE provide two types of data exchange modes, connected and advertising. Connected mode transfers data in a one-to-one connection (which means both data transmission and receipt are acknowledged), and advertising mode, which broadcasts data out to anyone who is listening (which means there is no guarantee of receipt).

The two main types of BLE beacons used by BLE assets are iBeacons, created by Apple Computers, and Eddystone, developed by Google. Both these operate in advertising mode and periodically broadcast specially formatted advertising packets, which can include corresponding data fields.

To read the data field correctly and thus perform filtering, Mist needs to know how to interpret the BLE signal (what we call the *asset type* in the GUI) and where to look for the payload (what we call the *value* in the GUI).

- • **iBeacon**—this is an Apple standard that lets mobile devices listen for BLE advertisements "through" the lock screen. iBeacon sub-classifier fields for additional levels of distinction, as described below:
 - **Proximity UUID** (Universally Unique Identifier)—A 128-bit value that uniquely identifies the beacon by type or organization. They look like this: *f7826da6-4fa2-4e98-8024-bc5b71e0893e*
 - **Major**—A 16-bit unsigned integer that can be used to group related beacons that have the same proximity UUID.
 - **Minor**—A 16-bit unsigned integer that differentiates beacons with the same proximity UUID and major value.
- **Eddystone UID**—A 128-bit beacon ID that is comprised of an 80-bit namespace and a 48-bit instance ID. The namespace can be used to group beacons, while the instance ID identifies individual devices in the group.
- **Eddystone URL**—A URL compressed to fit within the limits of the advertisement frame, that, once decoded, the Wi-Fi client can use to access the internet.
- **Eddystone TLM**—This frame broadcasts telemetry such as battery voltage and device temperature. This frame must be paired with an identifying frame of type Eddystone-UID or Eddystone-URL to include an ID.
- **Service UUID**—A 128-bit value that uniquely identifies the beacon. They can look like this: *Service UUID: 0000f7fd-0000-1000-8000-00805f9b34fb*
- **MFG Data**—When used, displays the name of the device manufacture or other selected data.

Requirement: Asset Visibility

Asset Visibility must be enabled for the AP to receive BLE signals. Go to **Organization | Admin > Site Configuration > Site Name > Bluetooth based Location Services**.

On the same page, you can also, optionally, enable vBLE Engagement for wayfinding. On the APs (or via device profile), you may also need to ["Enable Bluetooth Based Location Services" on page 21](#) for the beacon type. These options are explained here:

- Enable **Asset Visibility** to have the APs *listen* for BLE signals from nearby devices and display a Live View of the locations on the floor plan (note that the APs must already be placed on a floor plan).
- Enable **vBLE Engagement** to have the APs *transmit* BLE signals APs for location wayfinding.
- Enable **App Wakeup** to have APs send a "super beacon" that works in conjunction with your customized Mist-SDK implementation and mobile app, for example, to pop-up a notification on customer's mobile phone when the enter a premises.

See also ["Activate Subscriptions" on page 7](#).

Import Assets

SUMMARY

Quickly add dozens or hundreds of BLE assets by using a CSV (Comma-Separated Values) file.

1. Create a CSV file that includes the asset names and MAC addresses.

CSV Example

Asset Name,MAC Address

Asset 1,00:00:00:00:00:01

Asset 2,00:00:00:00:00:02



NOTE: If you use a spreadsheet application to create the CSV file, enter the data in two columns. The column headings must be *Asset Name* and *MAC Address*.

2. From the left menu of the Juniper Mist™ portal, select **Clients > BLE Clients**.
3. Click **Import Assets**.
4. Upload the file, and then click **Import**.
5. Click **OK** to close the pop-up window.

6. To confirm that the assets were added, scroll down the **BLE Clients** page, or use the **Filter** box.

Guidelines for BLE Beacon Tags

SUMMARY

Follow these guidelines when selecting Bluetooth Low Energy (BLE) beacon tags to use with Juniper Mist™ Asset Visibility.

Consult with the tag vendor to ensure that your BLE beacon tags meet the following requirements:

- 1000 to 100 millisecond (ms) interval rate

The interval rate is the rate at which the BLE tag broadcasts BLE signals. Any setting from 1 second (1000 ms) to 0.1 seconds (100 ms) is suitable for asset tracking. More frequent transmissions mean that the AP location sensor has more data to use. However, the battery life of the BLE tag will be shorter.

- 0 decibel milliwatt (dBm) for power

If the power setting is less than 0 dBm, the ceiling-mounted AP will have trouble detecting the BLE signal.

- Static MAC Address

Juniper Mist uses the MAC address to identify the asset and to match it to the named assets that you configure in the portal. If the address is not static, Juniper Mist cannot match it to your named assets.

If your BLE tags don't meet these standards, reach out to Juniper Mist Support for assistance. To contact Support, click the question button in the top right corner of the portal, and then click **Support Tickets**.

Rubber Band Model

SUMMARY


Use the "rubber band model" to properly place your access points (APs) for BLE coverage.

When placing access points (APs) for asset visibility use cases, apply the "rubber band model" to ensure location accuracy.



NOTE: We recommend the rubber band model for asset visibility only; it is not necessary for other use cases such as wayfinding.

To apply this model, envision a rubber band that encompasses the desired coverage area. Imagine anchoring the rubber band with four APs, one at each corner of the space. Then apply the ["AP placement guidelines" on page 9](#) to distribute additional APs, as needed, within that space.



This approach differs from the way that you'd deploy APs for Wi-Fi coverage. For Wi-Fi, you'd typically work from the center outward.

If you've already deployed APs without this model in mind, consider deploying Juniper BT11 APs to fill in. Place these APs at the outer edges of the space to provide the anchor points for the imaginary rubber band.

Find Equipment Use Case

SUMMARY

Watch this video and follow the example to see how you can use Juniper Mist™ Asset Visibility to locate items across your site, whether tracking equipment such as wheelchairs, machinery, and mobile devices, or personnel via their company badges or student IDs.

IN THIS SECTION

- Benefits | [88](#)
- Scenario | [88](#)
- Components | [89](#)
- Process Overview for Equipment Finding | [89](#)

Benefits

With an Asset Visibility subscription, you can easily find equipment and other assets, with detailed analytics based on their location.


You can use Asset Visibility in many settings and industries (education, energy, government, health care, entertainment, retail, and more).



[Video: Introducing Mist Asset Visibility](#)

Scenario

For this scenario, let's consider an example in health care. People often abandon wheelchairs in the lobby or hallways. When a patient needs a wheelchair, you need to find one quickly. As shown below, you can go to the **Live View** floorplan and quickly spot a wheelchair that was left in the lobby.



Components

This scenario relies on these components:

- Bluetooth Low Energy (BLE) Beacon Tags—BLE tags broadcast a BLE signal at a regular interval. You can use any tag that meets our ["Guidelines for BLE Beacon Tags" on page 86](#).
- Access Point (APs)—The AP detects the signals from the BLE tags.
- Juniper Mist Location Engine—The location engine in the Juniper Mist Cloud processes the available information to determine the location of the asset.



NOTE: With BLE beacon tags, the only available information is the BLE signal itself. With this limited information, Juniper Mist can provide zonal accuracy, identifying the location within 3 to 5 meters.

- Juniper Mist Portal—In the portal, you'll activate your subscription, enter names for your assets, and use **Live View** to track them.

Process Overview for Equipment Finding

To implement the scenario, do these tasks.

Table 8: Setup Process

Step	Action	More Information
1	Purchase a Juniper Mist Asset Visibility subscription, and activate it in the Mist portal.	<ul style="list-style-type: none"> • Juniper Mist Asset Visibility information • "Activate Subscriptions" on page 7
2	<p>Go to Organization > Site Configuration, and complete both of these tasks:</p> <ul style="list-style-type: none"> • Ensure that Asset Visibility is enabled. <p>NOTE: This feature is enabled by default after you activate your Asset Visibility subscription.</p> <ul style="list-style-type: none"> • To optimize performance for asset tracking, disable vBLE Engagement. When both features are enabled, the AP must transmit and receive. Giving the AP extra tasks means that it has less time to scan for signals from your BLE tags. 	
3	Ensure that your APs are placed according to the "rubber band model."	"Rubber Band Model" on page 87
4	Ensure that the floorplan includes accurate position, height, and orientation data for your APs.	"Floorplan Setup" on page 30
5	Obtain compatible BLE beacon tags and attach them to the assets that you want to track.	"Guidelines for BLE Beacon Tags" on page 86
6	Name the assets.	"Create Named Assets" on page 79
7	Track the assets in Live View .	"Find the Current Location of a Named Asset" on page 93

Also see [Asset Insights Dashboard](#).

Room Utilization Use Case

SUMMARY

Watch this video and follow the example to see how you can use Juniper Mist™ Asset Visibility to see which rooms at your site are most used, and at what times of day.

IN THIS SECTION

- [Benefits | 91](#)
- [Scenario | 91](#)
- [Components | 91](#)
- [Process Overview | 92](#)

Benefits

With a Juniper Mist Asset Visibility subscription, you can find assets and people, with detailed analytics based on their location. You can use asset tracking in many settings and industries (education, energy, government, health care, entertainment, retail, and more).

Scenario

This scenario takes place in a busy medical clinic. The main goal is to track the doctors' use of various examination rooms. Another goal is to quickly locate a doctor's laptop if the doctor leaves it behind anywhere in the facility. You can use location data from the in-room BT11 access points (APs) and the APs that provide wireless throughout the clinic.



[Video: Generic Guest Wi-Fi and In-Room Analytics](#)

Components

This scenario relies on these components:

- Bluetooth Low Energy (BLE) beacon tags—BLE tags that are attached to the doctors' badges and the laptops. You can use any tag that meets Juniper's ["Guidelines for BLE Beacon Tags" on page 86](#).

- APs—The AP detects the signals from the BLE tags. In situations where you want BLE coverage but don't need wireless coverage, you can use BT11 APs. For best results, install the AP on the ceiling at the exact center of the room.
- Juniper Mist location engine—The location engine in the Juniper Mist cloud processes the available information to determine the location of the BLE beacon tag. With BLE beacon tags, Juniper Mist can provide zonal accuracy, identifying the location within 3 to 5 meters.
- Juniper Mist portal—In the portal, you'll activate your subscription, enter names for your assets, and use **Live View** to track the assets.
- Juniper Mist API—You can use the programmable API to collect the data that you need for your business goals.
- (Optional) Third-party software—You can pull the data into your favorite third-party software and then create colorful data visualizations and reports.

Process Overview

Table 9: Asset Tracking Setup Process

Step	Action	More Information
1	Purchase a Juniper Mist Asset Visibility subscription, and activate it in the Mist portal.	<ul style="list-style-type: none"> • Juniper Mist Asset Visibility information • "Activate Subscriptions" on page 7
2	Go to Organization > Site Configuration , and complete both of these tasks: <ul style="list-style-type: none"> • Ensure that Asset Visibility is enabled. • To optimize performance for asset tracking, disable vBLE Engagement. When both features are enabled, the AP must transmit and receive. Giving the AP extra tasks means that it has less time to scan for signals from your BLE tags. 	

Table 9: Asset Tracking Setup Process (Continued)

Step	Action	More Information
3	Ensure that your APs are placed according to the "rubber band model."	"Rubber Band Model" on page 87
4	Ensure that the floorplan includes accurate position, height, and orientation data for your APs.	"Floorplan Setup" on page 30
5	Purchase BLE badges and assign them to your employees.	"Guidelines for BLE Beacon Tags" on page 86
6	Name the badges so that you can quickly identify each doctor.	"Create Named Assets" on page 79
7	Use the Juniper Mist API to collect the data that you need.	API documentation is available in the Juniper Mist portal. At the top right corner of the Juniper Mist portal, select the question icon, and then select API Documentation .
8	<i>With a Premium Analytics subscription,</i> you can use the Asset Insights dashboard to gather data about asset location, status, and usage.	Asset Insights Dashboard

Find the Current Location of a Named Asset

SUMMARY

Follow these steps to search for an asset by name in Location Live View.


1. From the left menu of the Juniper Mist portal, select **Location > Live View**.

2. (Optional) To simplify the display:

- Select the **Settings** button (near the top right corner of the page).



- Clear all check boxes except **Show Assets**.




- Close the pop-up window.

3. Select the **Assets** tab (on the right side of the page).

4. Scroll down the list to find the name of the asset.

For this example, we selected Wheelchair 1. When you click on the asset name, the asset appears with a green icon on the floorplan. All other assets are grayed out to make the selected asset more visible.



NOTE: Juniper Mist provides zonal accuracy, within 3 to 5 meters. Pinpoint accuracy is not possible, due to the limited information from the BLE beacon tags.

- If you want to see more information about the asset, select **Location History** (in the lower right corner of the page).

You can select the time frame to see the asset's locations over time and the percentage of time spent in various zones.

6

CHAPTER

Analytics

IN THIS CHAPTER

- [Analytics Overview | 96](#)
- [MAC Randomization and Location Analytics | 96](#)

Analytics Overview

SUMMARY

Get started with analytics.

Once you've set up your sites and floorplans for Location Services, you can use the following Analytics Dashboards to gather various types of location services data:

- Engagement Analytics
- Occupancy Analytics
- Premium Analytics

These dashboards provide insights into space occupancy, user visits, user dwell times, location history, proximity zones, and so on.



NOTE: Engagement and Premium Analytics require a subscription. You will need to purchase and activate these subscriptions in order for these dashboards to appear in the Juniper Mist™ portal. See ["Activate Subscriptions" on page 7](#).

MAC Randomization and Location Analytics

SUMMARY

Learn about MAC randomization and how it can limit the usefulness of data you can gather from client devices.

IN THIS SECTION

- Available Data from Bluetooth Devices | 97
- MAC Randomization | 97
- Impact of MAC Randomization | 97
- Active Analytics | 98

Certain data can be collected passively from Bluetooth devices, without any active engagement with the users. However, passive analytics has limitations. Read further to understand the issues and how active analytics can help.

Available Data from Bluetooth Devices

A Bluetooth device, like any wireless device, announces itself to the world by sending advertisement packets. The most common payloads are:

- Local Name
- Power Level
- Manufacturer-Specific Data (including payloads for iBeacon, AltBeacon, and Eddystone)

However, BLE devices do not advertise constantly. For example, a phone might not advertise when ringing or when receiving a text message.

MAC Randomization

While advertising, the device can also indicate if it is using its physical MAC address or a random MAC address.

Generally, MAC randomization does not occur with BLE beacon tags or accessories such as wireless headsets. However, most mobile devices randomize their MAC address. For example, each time that an iOS or MacOS device wakes up, it uses a new, random MAC address.

Impact of MAC Randomization

MAC randomization benefits users by protecting their privacy and ensuring that the device is not easily trackable. However, if you're relying on passive analytics, MAC randomization poses some challenges.

- Hidden MAC addresses—If you try to search the data by using a device's physical MAC address, you won't find it. Only a random MAC address is advertised, so the physical MAC address is not detectable.
- Multiple MAC addresses—Because certain devices advertise new MAC addresses whenever they wake up, you might see multiple addresses from one device.

Active Analytics

Passive analytics has challenges due to the limited data in the advertisement packets, the fact that devices do not transmit constantly, and MAC randomization.

Active analytics can be a much more valuable approach. By developing Juniper Mist™ SDK-enabled applications, you can drive user engagement and collect more information. For example, you can collect information when users log in, click buttons, and follow links. Because the users identify themselves when they log in, the data that you collect is de-anonymized. You're counting and tracking the actual users of your application, without the issues that can result from MAC randomization.

7

CHAPTER

Location-Based Application Development

IN THIS CHAPTER

- Juniper Mist SDK | [100](#)
- Webhooks for Location Services | [101](#)

Juniper Mist SDK

SUMMARY

Get started using the Juniper Mist™ Software Development Kit (SDK) to develop your location-based applications.

IN THIS SECTION

- [How to Get the Juniper Mist SDK | 100](#)

How to Get the Juniper Mist SDK

The Juniper Mist SDK provides the tools you need to build customer-facing applications that deliver indoor location services. Use these resources to install the SDK for Android and iOS.

For installation and integration steps, see the Juniper Mist SDK Manual on github for [Android Devices](#) and [iOS Devices](#).

For Android devices, you can add the dependency with the latest version of the Juniper Mist SDK in the build.gradle file or manually download the .aar files from github. See the [Juniper Mist Location SDK Android latest version](#).

For iOS, you can use CocoaPods to include SDK in code, or download a framework file from github. See the [Juniper Mist Location SDK iOS latest version](#).



NOTE: In the legacy version of the Juniper Mist SDK, the MSTCentralManager class was used when integrating the SDK. Now, with the latest release of the Juniper Mist SDK, the IndoorLocationManager class is used. For integration steps, please see:

- [Android SDK Integration Steps](#)
- [iOS SDK Integration Steps](#)

Webhooks for Location Services

SUMMARY

Learn about the location-based webhooks that you can configure to obtain real-time data for your location-based applications.

IN THIS SECTION

- [Location-Based Webhooks | 101](#)
- [Requirements for Using Webhooks | 101](#)
- [Learn More | 102](#)

When you configure webhooks, Juniper Mist™ automatically pushes data to a provided URL. You'll get real-time notifications in the Juniper Mist portal as events happen across your organization or within a particular site. You can use this data in your Juniper Mist SDK-enabled applications or analyze the data with third-party software.

Location-Based Webhooks

Location-based webhooks include:

- **Location coordinates**—Updated at regular intervals of less than 1 second.
- **Zone entry and exit events**—Updated when a client device enters or exits a location zone.
- **Virtual beacon entry and exit events**—Updated when a client device enters or exits the coverage area of a virtual beacon.


Requirements for Using Webhooks

- Correctly scale the floorplan.
- Place the access points (APs) on the floorplan. Ensure that the orientation and the position on the floorplan match the physical orientation and location of the AP at the site.
- For zone entry and exit events, add zones to the floorplan.
- For virtual beacon entry and exit events, add virtual beacons to the floorplan.

Learn More

For more information about webhooks:

- In the Juniper Mist portal, click the question mark icon, and then click **API Documentation**. See the Webhooks section of that site.



- In the Juniper Technical Library, see the Webhooks chapter of the [Juniper Mist Automation and Integration Guide](#).

8

CHAPTER

Troubleshoot Location Services

SUMMARY

Use the information in this chapter to troubleshoot location issues.

IN THIS CHAPTER

- Location SLEs | [105](#)
- Search in Live View | [110](#)
- Troubleshoot Location Services Using the RF Environment | [112](#)
- Verify and Enable the vBLE Array | [116](#)
- Check Your Site's Beam Density Coverage | [117](#)
- Troubleshoot the Juniper Mist SDK | [120](#)
- Troubleshoot Incorrect Latitude and Longitude (SDK) | [122](#)
- Marvis Client and Location Services Integration for Troubleshooting | [126](#)
- Other Troubleshooting Tips for Location Services | [127](#)

What Do You Want to Do?

Table 10: Top Tasks

If you want to...	Use these resources:
Search for items on your floorplans. <i>Use Live View to look for APs, beacons, zones, and other elements. View details to check the settings.</i>	"Search in Live View" on page 110
Use the RF Environment to investigate issues with location accuracy. <i>This tool helps you gain insight into what is going on with Mist SDK-enabled clients and named assets.</i>	"Troubleshoot Location Services Using the RF Environment " on page 112
Check on AP coverage. <i>Check current coverage to see if you need to add APs.</i>	"Check Your Site's Beam Density Coverage" on page 117
Get help troubleshooting specific issues.	Explore the other topics in this chapter.
Get help from the Marvis conversational assistant. <i>If you have a Marvis subscription, use the conversational assistant for immediate insights into current conditions, and help resolving issues.</i>	Marvis Conversational Assistant (topic in the Juniper Mist AI-Driven Operations Guide)

Location SLEs

SUMMARY

Use the Location Service Level Experiences (SLE) dashboard to assess the service levels for user-impacting factors such as SDK connection issues, latency, dropped requests, access point health, and more.

IN THIS SECTION

- [Overview | 105](#)
- [Location SLE Blocks | 106](#)


Overview

IN THIS SECTION

- [Finding the Location SLEs Dashboard | 105](#)
- [Success Threshold Settings | 106](#)

Finding the Location SLEs Dashboard

To find the Location SLEs dashboard, select **Monitor > Service Levels** from the left menu of the Juniper Mist™ portal, and then click the **Location** button.



NOTE: Your subscriptions determine which buttons appear.

Success Threshold Settings

You can adjust the thresholds that determine success or failure. To do so, click the **Settings** button at the right top corner of the location SLEs section. In the settings window, follow the on-screen instructions to set each threshold.




NOTE: Most SLEs allow you to increase or decrease the threshold. Certain SLEs are not adjustable.

Location SLE Blocks

As shown in the following example, each SLE block provides valuable information.

- At the left, you see that this SLE has a 77 percent success rate. If you select the Value filter button, you'll see a number instead.
- At the center, the timeline shows variations across the time period. You can hover your mouse pointer over any point to see the exact time and SLE outcome.

At the right, the classifiers show the percentage of the issues that were attributed to each root cause. In this example, the issues were almost evenly distributed among Beam Density (33 percent of the issues), Beacon Density (33 percent), and Weak RSSI (32 percent). Another 2 percent of issues were attributed to Machine Learning.



- If you click a classifier, you'll see more information on the Root Cause Analysis page. Most classifiers have sub-classifiers for greater insight into the exact causes. The Root Cause Analysis page also provides additional details about the scope and impact of the issues. For all location SLEs, the Root Cause Analysis page includes a Location tab, where you can see exactly where the issues occurred on your floor plans.

See the following table for more information about the location SLEs and classifiers.

Table 11: Location SLE Descriptions

SLEs	SLE Descriptions	Classifiers	Classifier Descriptions
SDK Connect Time	Juniper Mist measures the time when your SDK-enabled app clients are connected to location services at your site.	User Usage	<p>Incidents when the client connection time was below the threshold.</p> <p>For example, if you set the threshold to 60 seconds (by clicking the Settings button), then this classifier is triggered when a client is connected for less than a minute.</p>
Latency	Juniper Mist measures the latency of location responses and estimates to app clients.	Cellular	Latency on a cellular data connection
		WiFi	Latency on a wireless connection
		No Reported Connection Type	Latency with unknown connection type
Teleports	<p>Juniper Mist identifies instances when the app client's estimated location veers away (or "teleports") from the actual location.</p> <p>For example, if you set 3 meters as the service target, this SLE is triggered when the actual location is more than 3 meters from the estimated location.</p>	Beacon Density	The app client detected a low number of beacons from the access points (APs).
		Beam Density	The app client detected a low number of beams.
		Machine Learning	–Changes in machine learning affected location accuracy.

Table 11: Location SLE Descriptions (Continued)

SLEs	SLE Descriptions	Classifiers	Classifier Descriptions
		vBLE Placement	<p>The placement of the APs affected location accuracy.</p> <p>Sub-Classifiers:</p> <ul style="list-style-type: none"> • Device Sensor—Sensor issues in the device affected location accuracy with respect to motion, acceleration, etc. • Weak RSSI—The app client received a weak signal (low Received Signal Strength Indicator).
Dropped Requests	Juniper Mist monitors the instances when dropped location requests reduced location accuracy.	Reconnects	Reconnection attempts made after losing Internet connectivity
	The Pending Requests classifier uses the threshold that you set with the Settings button. The other classifiers act on a pass/fail basis, counting any incidents that result in dropped requests.	Offline	App offline due to issues such as Wi-Fi reception, poor cellular reception, connectivity problems, or user actions (for example, switching to airplane mode)
		Not Uniform Requests	<p>Inconsistent speeds when sending location requests</p> <p>The app relies on uniform requests for location accuracy.</p>

Table 11: Location SLE Descriptions (Continued)

SLEs	SLE Descriptions	Classifiers	Classifier Descriptions
		Dropped by Network	Network issues causing dropped requests
		Client Request Timeout	Client timeouts causing dropped requests
		Cellular	Dropped requests while using a cellular data connection
		WiFi	Dropped requests while using a Wi-Fi connection
		Pending Requests	<p>Excess requests above the configured SLE threshold</p> <p>A high number of pending requests is used as an indicator that future requests are likely to be dropped.</p>
AP Health	Juniper Mist counts the incidents when APs rebooted or lost connectivity to the cloud.	Low Power	Insufficient power for location features
		AP Disconnected	Disconnected from cloud due to issues such as site down, switch down, AP reboot, or AP unreachable
		Ethernet	Ethernet errors or speed mismatch
		Network	Issues such as tunnel down, latency, or jitter

Search in Live View


SUMMARY

Learn how to search for clients, access points (APs), assets, beacons, zones, and more in Location Live View.

Use the search button on the Live View page to help you find items on a floorplan quickly.

To search in Live View:

1. From the left menu of the Juniper Mist™ portal, select **Location > Live View**.
2. Select the site and the floorplan.
3. Click the search button at the top right corner of the floorplan.




4. Start typing the name of the item that you're looking for.

You can search the following items:

- AP name
- AP MAC address

- WiFi client name
- WiFi client MAC address
- SDK client name
- SDK client UUID
- BLE client name
- BLE client MAC
- Asset name
- Asset MAC address
- vBeacon name
- vBeacon UUID
- Third-party beacon name
- Third-party beacon UUID
- Zone name

As you start typing, the matching items appear in the drop-down list.






NOTE: The list displays only five elements for each category. A fraction in the top right corner of the list indicates the total number of possible matches. For example, *5/7* indicates that the list displays 5 out of 7 items.

- From the drop-down list, click the item that you want to see on the floorplan.

The item is now highlighted on the floorplan and is also selected in the list on right side of the page.



Troubleshoot Location Services Using the RF Environment

In your Juniper Mist network, you can use the RF Environment (also known as RF Glasses) for troubleshooting location accuracy issues. This tool helps you gain insight into what is going on with Mist SDK-enabled clients and named assets.


Video Demo



[Video: Modern RF Glasses](#)

Steps

- From the left menu of the Juniper Mist portal, select **Location > Live View**.
- Click the site and the floorplan that you want to troubleshoot.
- Adjust the page settings to show the app clients:
 - Click the **Settings** button (near the top right corner of the page).



- b. In the Location Settings window, select the **Show App Clients** and **Show App Clients (Cellular)** check boxes.



- c. Click **X** to close the Location Settings window.

The floorplan displays any clients that are running the Juniper Mist SDK.

4. Select a client and record the RF environment:

- a. Select the **Clients** tab on the right side of the page, and then select the client that you want to troubleshoot.
- b. Click **RF Environment** (near the bottom right corner of the page).

1 Clients

Kevin's Phone	00000000-0000-0...
---------------	--------------------

Selected App Client

Name	Kevin's Phone
UUID	00000000-0000-0000-0000-012347788aa
Zones	Zone_2
vBeacons	None
Last Seen	0m 1s
x, y (m)	6.5, -3.5
MAC Address	
Connection	
Signal Strength	
Client Details	RF Environment



NOTE: The **RF Environment** link is available only for SDK clients, named assets, and connected wireless clients.

- Click **Record Session** (near the top right corner of the page).
 - Your session begins recording. A progress bar appears at the top of the screen.
 - In the **Rename Session** window, you can rename the session recording or close the window to keep the current date and time as the session name.
 - When finished, click **Stop Recording**.




NOTE: If you do not stop the recording manually by clicking the button, the recording stops automatically after three minutes.

5. Replay the recording:

- From the left menu, select **Location > RF Environment Replay**.
- From the **Recorded Sessions** list, click the session you just recorded.

You will see your recording. You can use it to gain an understanding of the current issues, troubleshoot, or send to customer support for review.



Troubleshooting Tips

When troubleshooting in the RF Environment, pay attention to these elements:

- **Smoothed Location Estimate**

The lime green colored dot represents the smoothed location estimate. (See the Legend in the top right corner of the page.) This estimate takes the received signal strength indicator (RSSI) data and smooths it out for accuracy and user readability.

- **Beams and Beacons**

On the right side of the page, see how many access points (APs) the client detects. Look at:

- Beams per second

- Beacons per beam per second

These RSSI values come from the AP from the client's perspective. They indicate how many APs the client detects and the number of beams the client detects from the AP.

- **Speed and Direction**

On the right side of the page, **Speed** and **Direction** are updated as the client moves within the site.

- When the client is in motion, the probability surface spreads out.
- As the client slows down or becomes still, the probability surface shrinks.
- The red area depicts the peak of the surface and the highest probability of the client's location.
- The blue area depicts the lowest area of the surface and the least probability of the client's location.

Keep in mind:

- With a lower-than-average number of beams per second or beacons per beam per second, location accuracy might deteriorate.
- If the RSSI values are not updated for SDK clients, the client is offline.
- If the RSSI values are not updated for assets, data from the tag is not detected.
- If the RSSI values are missing, the environment has less data to work with. Less data means that location accuracy might deteriorate. If you notice missing RSSI values:
 - Check the organization settings to ensure that vBLE Engagement is enabled. See "[Enable Bluetooth Based Location Services](#)" on page 21.
 - Check the Access Points page to ensure that the vBLE array is turned on for all APs. See "[Verify and Enable the vBLE Array](#)" on page 116.
 - Ensure that the AP has been added to the floorplan. See "[Floorplan Setup Overview](#)" on page 30.

Verify and Enable the vBLE Array

SUMMARY


Troubleshoot location issues by verifying that virtual Bluetooth Low Energy (vBLE) array is enabled on your access points (APs).

Go to the Access Points page to verify that vBLE is enabled for all APs. If you see an X in the vBLE column, the vBLE array is off and needs to be turned on.

Status	Name	MAC Address	IP Address	No. Clients	Uptime	Total Bytes	Capabilities	vBLE	Model
Connected	LD_24_JSW	00:3e:73:07:e4:46	10.100.0.21	1	12d 7h 29m	7.6 GB	Wi-Fi	N/A	AP24
Connected	LD_Friday	d4:20:b0:f1:03:c5	10.100.0.16	3	1d 23h 38m	5.5 GB	Wi-Fi	<input checked="" type="checkbox"/>	AP45
Connected	LD_IDF_B_AP-3rd-Party-Switch	5c:5b:35:3e:4e:ca	10.100.0.44	0	15d 22h 53m	261 kB	Wi-Fi	<input checked="" type="checkbox"/>	AP41
Connected	LD_Kitchen	5c:5b:35:50:06:1d	10.100.0.47	1	15d 22h 44m	7.4 GB	Wi-Fi	<input checked="" type="checkbox"/>	AP43

To enable the vBLE array on an access point:

1. From the left menu of the Juniper Mist portal, select **Access Points**.
2. Check the vBLE column to see if any APs need to have vBLE enabled.
3. To enable vBLE for an AP:
 - a. Click the AP.
 - b. Under **BLE Settings**, select the **Enable Virtual BLE Array** check box.



- c. Click **Save**.

Check Your Site's Beam Density Coverage


SUMMARY

Troubleshoot location issues by using the Beam Density Map to find weak spots in your BLE coverage.

On the Location Diagnostics page of the Juniper Mist portal, you have the option to view “coverage” on the Beam Density Map. This map displays color coding to indicate how much coverage a Mist Access Point (AP) is providing a device based on the device's proximity to the AP. This color coding is based on the Received Signal Strength Indicator (RSSI) that the device sends to the AP. The RSSI values are based on the device's coordinate (X,Y) location estimate.

To view the Beam Density Coverage Map:


1. From the left menu of the Juniper Mist portal, select **Location > Location Diagnostics**.
2. Click **Beam Density Map** (near the top center of the page).
3. Ensure that you have the appropriate site and floorplan selected:




4. Click **Coverage**.




On the map, you have the option to view coverage for App (Mist SDK Mobile App clients), BLE (named assets), and WiFi (unconnected and connected WiFi clients). Select the device type from the drop-down list to view the coverage for that device type on the map. The App device type is the only device type that has the Beam Density option available in addition to Coverage.




You can choose to view All clients (selected by default), or you can select a specific client from the drop-down list (the options that appear depend on the device type that you select).



You can also select a time range for which to view coverage. For example, if you would like to see coverage from the past hour, you can select “1 hour”.



5. Notice the RSSI color scale in the top left corner of the page. Use this as your reference as you look at the coverage on the map. RSSI values closer to zero indicate that the device is in closer proximity to the APs.



6. Hover your mouse over a device on the map to see the average and maximum RSSI values. The values appear to the left of the color scale.

Troubleshoot the Juniper Mist SDK

SUMMARY

Explore these options to resolve issues with your SDK-enabled applications.

This topic provides information about how to troubleshoot common issues when you develop and test your Juniper Mist™ Software Development Kit (SDK).



To build a customer-facing application using the Juniper Mist SDK, your system must meet the following requirements:

- [iOS System Requirements](#)
- [Android System Requirements](#)

Prior to troubleshooting, ensure that you are using the correct API callbacks:

- iOS: [didUpdateRelativeLocation](#)
- Android: [onRelativeLocationUpdated](#)

To troubleshoot the SDK, identify the potential issue and then apply the recommended remedy:

Table 12: SDK Issues and Remedies

Potential Issue	Remedy
<p>For iOS devices only: You receive SDK errors, or you cannot develop and test the project on the simulator. (Testing requires a Juniper Mist SDK-enabled device on which to run the SDK.)</p> <p>NOTE: This issue applies only to iOS devices.</p>	<p>Use the following sample app and sample code to run the project on the simulator:</p> <p>Sample App (iOS only)</p> <p>Sample Code (iOS only)</p>
<p>The floorplan doesn't load, the blue dot is inaccurate, or the app doesn't work when you run it on a simulator.</p>	<ol style="list-style-type: none"> 1. Confirm that the X,Y placement of the access points (APs) on the floorplan matches the physical placement of the APs in your deployment. See <i>Manually Place an Access Point on a Floorplan</i>. 2. Scale the floorplan accurately. See <i>Scale a Floorplan</i>. 3. Ensure that you are running the SDK on a device. 4. Ensure that you enabled Bluetooth permission on the device. 5. Ensure that the Mobile SDK secret is correct.
<p>The blue dot is not accurate.</p>	<ol style="list-style-type: none"> 1. Confirm that you are using the latest version of the SDK. <p>To get the latest version, click the relevant link:</p> <ul style="list-style-type: none"> • Juniper Mist Location SDK Android latest version • Juniper Mist Location SDK iOS latest version <ol style="list-style-type: none"> 2. Ensure that you placed your APs according to the deployment guidelines. See <i>"AP Placement for Location Services" on page 9</i>. 3. Collect RF Environment recordings—specifically, the Received Signal Strength Indicator (RSSI) values—to see if the SDK receives a strong enough signal. See <i>"Troubleshoot Location Services Using the RF Environment" on page 112</i>.
<p>Juniper Mist cannot receive virtual beacon notifications.</p>	<ol style="list-style-type: none"> 1. Confirm that you placed the virtual beacons on the floorplan accurately. 2. Ensure that the Name, Message, and Url fields are complete.

Table 12: SDK Issues and Remedies (Continued)

Potential Issue	Remedy
Juniper Mist cannot receive zone notifications.	<ol style="list-style-type: none"> 1. Confirm that you placed the zones on the floorplan accurately. 2. Ensure that the zone has a name. See these topics: <ul style="list-style-type: none"> • "Add Location Zones to a Floorplan" on page 47 • "Add Proximity Zones to a Floorplan" on page 51
The SDK returns invalid latitude and longitude values.	To resolve this issue, follow the steps in "Troubleshoot Incorrect Latitude and Longitude (SDK)" on page 122 .

Troubleshoot Incorrect Latitude and Longitude (SDK)

SUMMARY

Go through these steps if the SDK returns invalid latitude and longitude values.

Prior to troubleshooting, ensure that you are using the correct API Callbacks:

- iOS: [didUpdateRelativeLocation](#)
- Android: [onRelativeLocationUpdated](#)


To troubleshoot incorrect latitude and longitude:

1. In the Juniper Mist™ portal, open the floorplan, click **Add VBeacon**, and then drag the virtual beacon (vBeacon) to any point on the floorplan.

Select a position that you can easily identify later when looking at your site on Google Maps or Apple Maps. For example, drag the vBeacon to a corner of the building.




NOTE: If you need general information about adding vBeacons, see ["Add Virtual Beacons to a Floorplan" on page 54](#).



2. Copy and save the X and Y values, which appear near the lower-right corner of the page. Both the values should be positive. In case of negative values, remove the negative signs from them.
3. Drag the vBeacon to a new, identifiable position and save the X and Y values. Then, repeat this step for one more point on the floorplan.
You should now have the X and Y values for three identifiable points on the floorplan.
4. Click **Cancel** so that you *do not* save the vBeacon.
5. Close the floorplan.
6. In Google Maps or Apple Maps, complete these steps to get the latitude and longitude values for the points that you selected on the floorplan:
 - a. Go to the map location for your site, and zoom in.
 - b. For each point that you selected on your floorplan, click the corresponding point on the Google Map or Apple Map, and save the latitude and longitude values.

As shown in the following illustration, the points on the map need to correspond to the points that you select on your floorplan:



For more information, go to the support site for Google Maps or Apple Maps.

Suggested topics:

- [Google Support topic](#) (See the information about getting the coordinates of a place.)
- [Apple Toolbox topic](#) (See the instructions about dropping a pin and getting the information.)



NOTE: The links are suggestions only. For up-to-date information, search the Google or Apple support site.

After completing the preceding steps, you should have the latitude and longitude values for the same three points that you identified on your floorplan.

7. Go to the GeoRefParamv2 payload, add the latitude and longitude values that you just obtained, and check the sample payload. See the following sample payload.

The following values match the coordinates shown:

- lat_lon X value—This is the latitude coordinate.
- lat_lon Y value—This is the longitude coordinate.

```
"GeoRefParamsv2": {
  "active": true,
  "p1": {
    "mist_xy": {
      "x": 13.4194,
      "y": 39.2581
    }
  }
}
```

```

  },
  "lat_lon": {
    "x": 37.29546,
    "y": -122.03323
  }
},
"p2": {
  "mist_xy": {
    "x": 23.3224,
    "y": 67.2408
  },
  "lat_lon": {
    "x": 37.29512,
    "y": -122.03306
  }
},
"p3": {
  "mist_xy": {
    "x": 52.3277,
    "y": 75.7614
  },
  "lat_lon": {
    "x": 37.29506,
    "y": -122.03269
  }
}
}
}

```

8. Add the PUT request for the GeoRefParamv2 payload into the maps API. `/api/v1/sites/:siteID/maps/:mapID`

By default, the SDK returns invalid latitude and longitude values if the GeoRefParams is not configured in the maps API.

Additional Troubleshooting

If the SDK encounters an error, it calls the `didErrorOccur` method, as follows:

```
didErrorOccur(_ withError:,withErrorMessage).
```

The SDK displays details of the errors in the following two values:

- `errorMessage` of type `NSString`

- `errorType` of type `ErrorType` Enum

For help, see the Integration Steps section of the Github Wiki.

[iOS SDK Github Wiki](#)

[Android SDK Github Wiki](#)

Marvis Client and Location Services Integration for Troubleshooting

SUMMARY

Read this topic to better understand the benefits of the integration between Marvis Client and Location Services and how it can assist with troubleshooting.

IN THIS SECTION

- [Benefits of the Marvis Client and Location Services Integration | 126](#)
- [WHAT's NEXT | 127](#)

Marvis Client enables you to view data about client experiences with regards to wireless connectivity from the device's perspective. In other words, it provides insight into how your device interacts with and experiences the wireless network. This enables you to gain a better understanding of client behavior and any potential issues on the network. The Marvis Client works with Location Services by coordinating with the Access Points' (APs) vBLE antenna array and on-device vBLE capabilities to create some powerful benefits, outlined below.

Benefits of the Marvis Client and Location Services Integration

- The Marvis Client now includes on-device location awareness via on-device vBLE location. This enables Marvis Client to provide enhanced visibility into the wireless network.
- Enhances network visibility, user experience, and troubleshooting.
 - For example, you can navigate to the floorplan in the Mist portal to use real-time location with client telemetry. This enables you to see where and when an issue occurred for the Wi-Fi client's applications, or to see any Wi-Fi issues being faced. On the floorplan, for example, a cluster of Wi-Fi clients in a single area experiencing coverage issues may indicate a *Coverage Hole* issue.

- Provides context-aware location insights (for example, location insights for handheld Zebra devices used in warehouse settings).
- Contextual insights into traffic flow and occupancy based on device movement and location trends.
- Provides a device location accuracy of 1-3-meters.

WHAT's NEXT

See the Marvis Client chapter of the *Juniper Mist AI-Native Operations Guide* to learn more about Marvis Client.

Other Troubleshooting Tips for Location Services

SUMMARY

If other troubleshooting efforts haven't resolve your location issues, consider these tips about what to check and how to improve location accuracy.


The majority of location accuracy issues come from an incorrect access point (AP) setup. **Ensure that the AP information on the floorplan of the Juniper Mist portal matches the APs in the physical deployment.**

After reviewing the issues and remedies below, we highly recommend that you refer to "["Troubleshoot Location Services Using the RF Environment "](#) on page 112.

Table 13: Other SDK Issues and Remedies

Potential Issue	Remedy
Significantly small or large movements occur on a floorplan.	<p>Scale. Scale the floorplan accurately. See <i>Scale a Floorplan</i>.</p> <p>TIP: If you don't know the actual dimensions, look for a standard door on the floorplan and scale that door to 0.91 meters (3 feet). This will get you close to the actual scale.</p>

Table 13: Other SDK Issues and Remedies (Continued)

Potential Issue	Remedy
An unexpected jump to another area of the floorplan (also known as “teleporting”).	<p>Placement. Confirm that the X,Y placement of the APs on the floorplan matches the physical placement of the APs in your deployment.</p> <p>See Manually Place an Access Point on a Floorplan.</p>
An inaccuracy with the client's or asset's location; for example, the client's or asset's location appears on the opposite side of the AP (also known as the location being “flipped”).	<p>Rotation. Confirm that the AP's LED is facing the same direction in which the green dot is facing on the floorplan.</p>  <p>See Manually Place an Access Point on a Floorplan.</p>
Other unspecified issues	<p>Height. Ceiling height of APs can also play a part in location-accuracy issues. For any issues you may be experiencing, refer to "AP Placement for Location Services" on page 9 to ensure that you have proper coverage.</p> <p>If your deployment calls for installing APs outside of these guidelines, contact support@mist.com to consult with a sales engineer.</p>