

interfaces

```
Syntax interfaces {
    ae-chassis/slot/port {
        aggregated-ether-options {
            lacp mode {
                periodic interval;
            }
        }
    }
    ge-chassis/slot/port {
        description text;
        ether-options {
            802.3ad aex;
            auto-negotiation;
            flow-control;
            link-mode mode;
        }
        mtu bytes;
        unit logical-unit-number {
            family ethernet-switching {
                native-vlan-id vlan-id;
                port-mode mode;
                vlan {
                    members [ (names | vlan-ids) ];
                }
                vlan-id vlan-id-number;
            }
        }
        vlan-tagging;
    }
}
```

Hierarchy Level [edit]

Release Information Statement introduced in JUNOS Release 9.0 for EX-series switches.

Description Configure interfaces. Most standard JUNOS configuration statements are available in the JUNOS software for EX-series switches. This topic lists JUNOS statements that you commonly use when configuring EX-series switches as well as statements added to support EX-series switches only.

Options *ae-chassis/slot/port* —Configure an aggregated Ethernet interface.

ge-chassis/slot/port —Configure a Gigabit Ethernet interface.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

- Related Topics**
- Configuring a Layer 3 Subinterface (CLI Procedure)
 - *JUNOS Software Network Interfaces Configuration Guide* at <http://www.juniper.net/techpubs/software/junos/junos90/index.html>
 - Configuring Interfaces on EX-series Switches (CLI Procedure)
 - EX-series Switches Interfaces Overview