

mode

Syntax	<code>mode <i>mode</i>;</code>
Hierarchy Level	[edit protocols mstp interface (all <i>interface-name</i>)], [edit protocols mstp msti <i>msti-id</i> interface <i>interface-name</i>], [edit protocols rstp interface (all <i>interface-name</i>)], [edit protocols stp interface (all <i>interface-name</i>)]
Release Information	Statement introduced in JUNOS Release 9.0 for EX-series switches.
Description	For Spanning Tree Protocol (STP), Rapid Spanning Tree Protocol (RSTP), or Multiple Spanning Tree Protocol (MSTP), configure the link mode to identify point-to-point links.
Default	For a full-duplex link, the default link mode is <code>point-to-point</code> . For a half-duplex link, the default link mode is <code>shared</code> .
Options	<i>mode</i> —Link mode: <ul style="list-style-type: none">■ <code>point-to-point</code>—Link is point to point.■ <code>shared</code>—Link is shared media.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ <code>show spanning-tree bridge</code>■ <code>show spanning-tree interface</code>■ Example: Configuring Network Regions for VLANs with MSTP on EX-series Switches■ Example: Configuring Faster Convergence and Improving Network Stability with RSTP on EX-series Switches■ Understanding MSTP for EX-series Switches■ Understanding STP for EX-series Switches

