

Creating Parameter Instances

You can create QoS parameter instances globally, for an interface, or for a subinterface.

Tasks to create parameter instances are:

- Creating a Global Parameter Instance on page 1
- Creating a Parameter Instance for an Interface on page 1
- Creating a Parameter Instance for an ATM VP on page 1
- Creating a Parameter Instance for an S-VLAN on page 2

Creating a Global Parameter Instance

To create a global parameter instance:

- Create a parameter instance in Global Configuration mode.

```
host1(config)#qos-parameter max-subscriber-bandwidth 6000000
```

Creating a Parameter Instance for an Interface

To create a parameter instance for an interface:

1. Specify an interface.

```
host1(config)#interface atm 11/0.1  
host1(config)#interface gigabitEthernet 2/0
```

2. Specify the parameter name and the value.

```
host1(config-subif)#qos-parameter max-subscriber-bandwidth 6000000
```

Creating a Parameter Instance for an ATM VP

Use this procedure to attach a parameter instance to a VP on the interface. Optionally, use the **qos-profile** keyword to attach a parameter instance to a QoS profile.

To create a parameter instance for an ATM VP:

1. Configure the ATM VP.

```
host1(config)#interface atm 2/0  
host1(config-if)#atm vp-tunnel 4
```

2. Do either of the following:

- Attach the parameter instance to an ATM VP on the interface.

```
host1(config-if)#atm-vp 4 qos-parameter max-subscriber-bandwidth 375000
```

- Attach the parameter instance and associate with the QoS profile.

```
host1(config-if)#atm-vp 4 qos-profile video qos-parameter  
max-subscriber-bandwidth 375000
```

Creating a Parameter Instance for an S-VLAN

Use this procedure to attach a parameter instance to a specified S-VLAN ID on the interface. Optionally, use the **qos-profile** keyword to attach a parameter instance to a QoS profile.

To create a parameter instance for an S-VLAN:

1. Specify the Ethernet interface and create the VLAN.

```
host1(config)#interface gigabitEthernet 3/0  
host1(config-if)#encapsulation vlan  
host1(config-if)#interface gigabitEthernet 3/0.1
```

2. Specify the S-VLAN ID.

```
host1(config-if)#svlan id 1 202
```

3. Attach the parameter instance to an S-VLAN ID on the interface.

```
host1(config-if)#svlan 202 qos-parameter max-subscriber-bandwidth 6000000
```

- Related Topics**
- Parameter Instances for QoS Clients Overview
 - For information about creating QoS parameter instances for Service Manager, see *JUNOSe Broadband Access Configuration Guide*
 - atm-vp qos-parameter
 - atm vp-tunnel
 - encapsulation vlan
 - interface
 - qos-parameter
 - svlan id
 - svlan qos-parameter

Published: 2009-10-07