



ERX-Supported RADIUS Attribute Descriptions

Table A-1 provides a description of all ERX-supported RADIUS attributes, sorted by standard number. Table A-2 lists all Juniper Networks vendor-specific attribute (VSA) formats, also sorted by standard number.

Table A-1 ERX-supported attributes

Standard Number	Attribute Name	Description
[1]	User-Name	<ul style="list-style-type: none">Name of user to be authenticatedConfigurable username override
[2]	User-Password	<ul style="list-style-type: none">Password of user to be authenticatedConfigurable password overridePAP (Password Authentication Protocol)
[3]	CHAP-Password	Response value provided by a PPP Challenge Handshake Authorization Protocol (CHAP) user in the response to an access challenge
[4]	NAS-IP-Address	<ul style="list-style-type: none">IP address of the network access server (NAS) that is requesting authentication of the userYou may configure the radius update-source-addr command to override this behavior; see <i>Chapter 1, Configuring Remote Access to the ERX System</i>.
[5]	NAS-Port	<ul style="list-style-type: none">Physical port number of the NAS that is authenticating the userSee the radius nas-port-format command in <i>Chapter 2, Configuring RADIUS Attributes</i>.
[6]	Service-Type	<ul style="list-style-type: none">Type of service the user has requested or the type of service to be providedAdmin, Login, NAS Prompt, or Framed only
[7]	Framed-Protocol	<ul style="list-style-type: none">Framing protocol used for framed accessStandard value of 1 set for PPP

Table A-1 ERX-supported attributes (continued)

Standard Number	Attribute Name	Description
[8]	Framed-IP-Address	<ul style="list-style-type: none"> IP address to be configured for the user 0.0.0.0 or absence is interpreted as 255.255.255.254 See the radius include framed-ip-add acct-start command in <i>Chapter 2, Configuring RADIUS Attributes</i>.
[9]	Framed-IP-Netmask	<ul style="list-style-type: none"> IP network to be configured for the user when the user is a router to a network Absence implies 255.255.255.255
[11]	Filter-Id	<ul style="list-style-type: none"> Name of the filter list for the user Interpreted as input policy name
[13]	Framed-Compression	Always set to "none."
[18]	Reply-Message	<ul style="list-style-type: none"> Text that may be displayed to the user Only the first instance of this attribute is used
[22]	Framed-Route	Provides routing information to be configured for the user on the NAS
[24]	State	<ul style="list-style-type: none"> An arbitrary value that the ERX includes in new Access-Request packets from the previous Accept-Challenge Applicable for CLI/telnet only
[25]	Class	An arbitrary value that the NAS includes in all accounting packets for the user if supplied by the RADIUS server
[26]	Vendor-Specific	Juniper Networks Enterprise number 0x0000130A
[26-1]	Juniper-Virtual-Router	<ul style="list-style-type: none"> Virtual router name for the B-RAS user's IP interface Allowed only from RADIUS server in default virtual router context For restricted users, specifies the only VR that the user may access. For nonrestricted users, specifies the initial VR that the user accesses. See the enable command in <i>ERX System Basics Configuration Guide, Chapter 6, Passwords and Security</i>.
[26-2]	Address-Pool-Name	<ul style="list-style-type: none"> Name of an assigned address pool that should be used to assign an address for the user Same as RADIUS attribute 88, Framed-Pool
[26-3]	Local-Interface	Interface to apply to the ERX side of the connection
[26-4]	Primary-DNS	<ul style="list-style-type: none"> B-RAS user's DNS address negotiated during IPCP 4-octet IP address
[26-5]	Secondary-DNS	<ul style="list-style-type: none"> B-RAS user's DNS address negotiated during IPCP 4-octet IP address
[26-6]	Primary-WINS (NBNS)	<ul style="list-style-type: none"> B-RAS user's WINS (NBNS) address negotiated during IPCP 4-octet IP address

Table A-1 ERX-supported attributes (continued)

Standard Number	Attribute Name	Description
[26-7]	Secondary-WINS (NBNS)	<ul style="list-style-type: none"> B-RAS user's WINS (NBNS) address negotiated during IPCP 4-octet IP address
[26-8]	Tunnel-Virtual-Router	Virtual router name for tunnel connection
[26-9]	Tunnel-Password	Tunnel password in cleartext
[26-10]	Ingress-Policy-Name	Input policy name to apply to B-RAS user's interface
[26-11]	Egress-Policy-Name	Output policy name to apply to B-RAS user's interface
[26-12]	Ingress-Statistics	Enable or disable input statistics on B-RAS user's interface
[26-13]	Egress-Statistics	Enable or disable output statistics on B-RAS user's interface
[26-14]	Atm-Service-Category	ATM service category to apply to B-RAS user's interface
[26-15]	Atm-PCR	<ul style="list-style-type: none"> Peak cell rate 4-octet integer
[26-16]	Atm-SCR	<ul style="list-style-type: none"> Sustained cell rate or CBR, depending on the Atm-Service-Category RADIUS attribute [26-14] 4-octet integer
[26-17]	Atm-MBS	<ul style="list-style-type: none"> Maximum burst rate 4-octet integer
[26-18]	Juniper-Initial-CLI-Access-Level	<ul style="list-style-type: none"> Specifies the initial level of access to CLI commands See the enable command in <i>ERX System Basics Configuration Guide, Chapter 6, Passwords and Security</i>.
[26-19]	Juniper-Allow-All-VR-Access	<ul style="list-style-type: none"> Specifies user access to all virtual routers See the enable command in <i>ERX System Basics Configuration Guide, Chapter 6, Passwords and Security</i>.
[26-20]	Juniper-Alt-CLI-Access-Level	<ul style="list-style-type: none"> Specifies other levels of access to CLI commands See the enable command in <i>ERX System Basics Configuration Guide, Chapter 6, Passwords and Security</i>.
[26-21]	Juniper-Alt-CLI-Virtual-Router-Name	<ul style="list-style-type: none"> For restricted users, specifies other VRs that the user may access. See the enable command in <i>ERX System Basics Configuration Guide, Chapter 6, Passwords and Security</i>.
[26-22]	Sa-Validate	<ul style="list-style-type: none"> Enable or disable source address validation on a user's interface 4-octet integer
[26-23]	Igmp-Enable	<ul style="list-style-type: none"> Enable or disable IGMP on a user's interface Allows the end user to register for the reception of multicast services 4-octet integer
[26-24]	Pppoe-Description	The string <i>pppoe <mac addr></i> sent to the RADIUS server supplied by PPPoE

Table A-1 ERX-supported attributes (continued)

Standard Number	Attribute Name	Description
[26-25]	Redirect-VR-Name	<ul style="list-style-type: none"> Virtual router name indicating the VR context in which to authenticate the user Behavior is similar to that of a remote domain-map lookup.
[26-26]	QoS-Profile-Name	Name of the QoS profile to attach to the user's interface
[26-31]	SSC-Service-Bundle-Name	Specifies the SSC service bundle
[26-34]	Framed-Ip-Route-Tag	Route tag to apply to returned framed-ip-address
[26-42]	Input-Gigapkts	Number of times input-packets attribute rolls over its 4-octet field
[26-43]	Output-Gigapkts	Number of times output-packets attribute rolls over its 4-octet field
[27]	Session-Timeout	Maximum number of seconds of service to be provided to the user before termination of the session
[28]	Idle-Timeout	Maximum number of consecutive seconds of idle connection allowed to the user before termination of the session
[30]	Called-Station-Id	<ul style="list-style-type: none"> Allows the NAS to send the phone number that the user called Not supported for non tunneled or LAC session side. For the LNS (L2TP), the format is the string passed in the Called Number AVP.
[31]	Calling-Station-Id	<ul style="list-style-type: none"> Allows the NAS to send the phone number from which the call originated See the radius calling-station-format and the radius calling-station-delimiter commands in <i>Chapter 2, Configuring RADIUS Attributes</i>.
[32]	NAS-Identifier	<ul style="list-style-type: none"> Identifies the NAS originating the request System-wide configurable hostname or VR-sensitive configurable NAS-identifier name
[40]	Acct-Status-Type	Indicates whether this Accounting-Request marks the beginning of the user service (Start), the end (Stop), or the interim (Interim-Update)
[41]	Acct-Delay-Time	Indicates how many seconds the client has been trying to send a particular record
[42]	Acct-Input-Octets	<ul style="list-style-type: none"> Indicates how many octets have been received from the port during the time this service has been provided PPP payload only
[43]	Acct-Output-Octets	<ul style="list-style-type: none"> Indicates how many octets have been sent to the port during the time this service has been provided PPP payload only
[44]	Acct-Session-Id	<ul style="list-style-type: none"> Unique accounting identifier that makes it easy to match start and stop records in a log file See the radius acct-session-id-format and the radius include acct-session-id access-request commands in <i>Chapter 2, Configuring RADIUS Attributes</i>.

Table A-1 ERX-supported attributes (continued)

Standard Number	Attribute Name	Description
[45]	Acct-Authentic	<ul style="list-style-type: none"> Indicates how the user was authenticated, whether by RADIUS, the NAS itself, or another remote authentication protocol Always 1
[46]	Acct-Session-Time	Indicates how long in seconds that the user has received service
[47]	Acct-Input-Packets	<ul style="list-style-type: none"> Indicates how many packets have been received from the port during the time this service has been provided to a framed user PPP payload only
[48]	Acct-Output-Packets	<ul style="list-style-type: none"> Indicates how many packets have been sent to the port in the course of delivering this service to a framed user PPP payload only
[49]	Acct-Terminate-Cause	<p>Contains the reason the service (a PPP session) was terminated. The service can be terminated for the following reasons:</p> <ul style="list-style-type: none"> User Request (1) – user initiated the disconnect (log out) Idle Timeout (4) – idle timer has expired Session Timeout (5) – client reached the maximum continuous time allowed on the service or session Admin Reset (6) – system administrator terminated the session Port Error (8) – PVC failed; no hardware or no interface NAS Error (9) – negotiation failures, connection failures, or address lease expiration NAS Request (10) – PPP challenge timeout, PPP request timeout, tunnel establishment failure, PPP bundle failure, IP address lease expiration, PPP keep-alive failure, Tunnel disconnect, or an unaccounted-for error
[52]	Acct-Input-Gigawords	<ul style="list-style-type: none"> Indicates how many times the Acct-Input-Octets counter has wrapped around 2^{32} during the time this service has been provided, and can be present in Accounting-Request records only where the Acct-Status-Type is set to Stop or Interim-Update PPP payload only
[53]	Acct-Output-Gigawords	<ul style="list-style-type: none"> Indicates how many times the Acct-Output-Octets counter has wrapped around 2^{32} in the course of delivering this service, and can be present in Accounting-Request records only where the Acct-Status-Type is set to Stop or Interim-Update PPP payload only
[55]	Event-Timestamp	Records the time that this event occurred on the NAS, in seconds, since January 1, 1970 00:00 UTC
[60]	CHAP-Challenge	Contains the CHAP challenge sent by the NAS to a PPP CHAP user
[61]	NAS-Port-Type	<ul style="list-style-type: none"> Indicates the type of physical port the NAS is using to authenticate the user See the radius dsl-port-type and the radius ethernet-port-type commands in <i>Chapter 2, Configuring RADIUS Attributes</i>.

Table A-1 ERX-supported attributes (continued)

Standard Number	Attribute Name	Description
[62]	Port-Limit	Specifies the maximum number of Multilink Point-to-Point protocol (MP) member links allowed for the subscriber
[64]	Tunnel-Type	<ul style="list-style-type: none"> Tunneling protocol(s) to be used (in the case of a tunnel initiator) or the tunneling protocol in use (in the case of a tunnel terminator) Only L2TP and L2F supported at this time
[65]	Tunnel-Medium-Type	<ul style="list-style-type: none"> Transport medium to use when creating a tunnel for those protocols (such as L2TP) that can operate over multiple transports Only Ipv4 supported at this time
[66]	Tunnel-Client Endpoint	Address of the initiator end of the tunnel
[67]	Tunnel-Server-Endpoint	Address of the server end of the tunnel
[68]	Acct-Tunnel-Connection	<ul style="list-style-type: none"> Indicates the identifier assigned to the tunnel session Value is L2TP call-serial number
[69]	Tunnel-Password	Password to be used to authenticate to a remote server
[77]	Connect-Info	Sent from the NAS to indicate the nature of the user's connection
[82]	Tunnel-Assignment-Id	Indicate to the tunnel initiator the particular tunnel to which a session is to be assigned
[83]	Tunnel-Preference	<ul style="list-style-type: none"> If more than one set of tunneling attributes is returned by the RADIUS server to the tunnel initiator, this attribute is included in each set to indicate the relative preference assigned to each tunnel. Included in the Tunnel-Link-Start, the Tunnel-Link-Reject, and the Tunnel-Link-Stop packets (LAC only)
[85]	Acct-Interval-Interval	Number of seconds between each interim accounting update in seconds for this specific session
[86]	Acct-Tunnel-Packets-Lost	Number of packets lost on a given link

Table A-1 ERX-supported attributes (continued)

Standard Number	Attribute Name	Description
[87]	NAS-Port-Id	<ul style="list-style-type: none"> Text string that identifies the physical interface of the NAS that is authenticating the user If the PPP user connects via ATM slot 12, port 2, vpi 100, vci 101, then the NAS-Port-Id value in the RADIUS packets will be atm 12/2:100.101 If the user is a PPP user that started as a result of the ERX LNS feature (that is, no physical port), then the NAS-Port-Id value is as follows: <i>media:local address:peer address:local tunnel id:peer tunnel id:local session id:peer session id:call serial number</i> <ul style="list-style-type: none"> For example: ip:172.81.1.98:172.81.1.99:18d:cb8:ce6:9f4:6 In this case, the local information refers to the LNS, and the peer information refers to the LAC NAS-Port-Id usually contains one of the following: <ul style="list-style-type: none"> atm <slot> / <port>:<vpi>.<vci> fastEthernet <slot> / <port> [<vlan>] gigabitEthernet <slot> / <port> [<vlan>] serial <slot>/<port> [<sonetPath> [/<sonetTributary (x/x/x)> [/<fractionalInterface>]]] from LNS – ip:local ip:peer ip:local tid:peer tid:local sid:peer sid:call serial number <ul style="list-style-type: none"> tid – tunnel id sid – session id
[88]	Framed-Pool	Name of an assigned address pool that should be used to assign an address for the user
[90]	Tunnel-Client-Auth-Id	Name used by the tunnel initiator during the authentication phase of tunnel establishment
[91]	Tunnel-Server-Auth-Id	Name used by the tunnel terminator during the authentication phase of tunnel establishment
[242]	Ascend-Data-Filter	<ul style="list-style-type: none"> RADIUS policy definitions allow you to configure a policy that consists of <i>Filter/Forward</i> rules based on classified packet flows. The RADIUS policy definitions use the Ascend-Data-Filter format or Filter-Id, Ingress-Policy-Name, and Egress-Policy-Name.

See Table A-2 for Juniper Networks VSA formats for RADIUS. The ERX system uses the vendor ID assigned to Juniper Networks (0x0000130A) by the Internet Assigned Numbers Authority (IANA).

Table A-2 ERX system RADIUS VSA formats

Standard Number	Attribute Name	Length	Subtype Length	Value
[26-1]	Juniper-Virtual-Router	len	sublen	string: virtual-router-name
[26-2]	Address-Pool-Name	len	sublen	string: address-pool-name
[26-3]	Local-Interface	len	sublen	string: local-interface
[26-4]	Primary-DNS	12	6	string: primary-dns-address
[26-5]	Secondary-DNS	12	6	string: secondary-dns-address
[26-6]	Primary-WINS (NBNS)	12	6	string: primary-wins-address
[26-7]	Secondary-WINS (NBNS)	12	6	string: secondary-wins-address
[26-8]	Tunnel-Virtual-Router	len	sublen	string: tunnel-virtual-router
[26-9]	Tunnel-Password	len	sublen	string: tunnel-password
[26-10]	Ingress-Policy-Name	len	sublen	string: input-policy-name
[26-11]	Egress-Policy-Name	len	sublen	string: output-policy-name
[26-12]	Ingress-Statistics	12	6	integer: 0 = disable, 1 = enable
[26-13]	Egress-Statistics	12	6	integer: 0 = disable, 1 = enable
[26-14]	Atm-Service-Category	12	6	integer: 1= UBR, 2= UBR PCR, 3=NRT VBR, 4=CBR
[26-15]	Atm-PCR	12	6	integer: 4-octet
[26-16]	Atm-SCR	12	6	integer: 4-octet
[26-17]	Atm-MBS	12	6	integer: 4-octet
[26-18]	Juniper-Initial-CLI-Access-Level	len	sublen	single attribute: enter 0, 1, 5, 10, or 15
[26-19]	Juniper-Allow-All-VR-Access	len	sublen	integer: 0 = disable, 1 = enable
[26-20]	Juniper-Alt-CLI-Access-Level	len	sublen	single attribute; enter 0, 1, 5, 10, or 15
[26-21]	Juniper-Alt-CLI-Virtual-Router-Name	len	sublen	string: virtual-router-name
[26-22]	Sa-Validate	len	sublen	integer: 0 = disable, 1 = enable
[26-23]	Igmp-Enable	len	sublen	integer: 0 = disable, 1 = enable
[26-24]	Pppoe-Description			string: pppoe<mac addr>
[26-25]	Redirect-VR-Name	len	sublen	authentication-redirection
[26-26]	QoS-Profile-Name	len	sublen	string: qos-profile-name
[26-31]	SSC-Service-Bundle-Name	len	sublen	string
[26-34]	Framed-Ip-Route-Tag	12	6	integer: 4-octet
[26-42]	Acct-Input-Gigapackets	12	6	integer
[26-43]	Acct-Output-GigaPackets	12	6	integer

For more information about RADIUS attributes, see the following resources:

- RFC 2865 – Remote Authentication Dial In User Service (RADIUS) (June 2000)
- RFC 2866 – RADIUS Accounting (June 2000)
- RFC 2867 – RADIUS Accounting Modifications for Tunnel Protocol Support (June 2000)
- RFC 2868 – RADIUS Attributes for Tunnel Protocol Support (June 2000)
- RFC 2869 – RADIUS Extensions (June 2000)

