

Chapter 37

DVMRP Configuration Guidelines

To configure DVMRP, you include statements at the [edit protocols dvmrp] hierarchy level of the configuration. You can include the following statements in the configuration:

```
protocols {
  dvmrp {
    disable;
    export [ policy-names ];
    import [ policy-names ];
    rib-group group-name;
    traceoptions {
      file name <replace> <size size> <files number> <no-stamp>
        <(world-readable | no-world-readable)>;
      flag flag <flag-modifier> <disable>;
    }
    interface interface-name {
      disable;
      hold-time seconds;
      metric metric;
    }
  }
}
```

By default, DVMRP is disabled.

This chapter describes the following tasks for configuring DVMRP:

Minimum DVMRP Configuration on page 392

Create Routing Tables for DVMRP Routes on page 392

Enable DVMRP on page 393

Modify the DVMRP Hold-Time Period on page 393

Modify the Metric Value on page 394

Disable DVMRP on an Interface on page 394

Configure DVMRP Routing Policy on page 394

Trace DVMRP Protocol Traffic on page 395

For a configuration example, see “Example: Configure DVMRP” on page 396.

Minimum DVMRP Configuration

To enable DVMRP on an interface, include at least the following statements in the configuration. All other DVMRP configuration statements are optional.

```
[edit]
routing-options {
  interface-routes {
    rib-group group-name1;
  }
  rib-groups {
    rib-group group-name1 {
      import-rib [ inet.0 inet.2 ];
    }
    rib-group group-name2 {
      import-rib inet.2;
      export-rib inet.2;
    }
  }
}
protocols {
  dvmrp {
    rib-group group-name2;
    interface interface-name;
  }
}
```

The ports of a DVMRP router can be either a physical interface to a directly attached subnetwork or a tunnel interface to another multicast-capable area of the MBone. All interfaces can be configured with a metric specifying cost for receiving packets on a given port. The default metric is 1.

Create Routing Tables for DVMRP Routes

For DVMRP to function correctly, it needs to access route information from the unicast routing table, inet.0, and from a separate routing table that is reserved for DVMRP. You need to create the routing table for DVMRP, and you need to create groups of routing tables so that the routing protocol process imports and exports routes properly. We recommend that you use routing table inet.2 for DVMRP routing information.

To create the necessary routing tables and routing table groups for DVMRP, include the following statements at the [edit routing-options] hierarchy level:

```
[edit]
routing-options {
  interface-routes {
    rib-group group-name1;
  }
  rib-groups {
    rib-group group-name1 {
      import-rib [ inet.0 inet.2 ];
    }
    rib-group group-name2 {
      import-rib inet.2;
      export-rib inet.2;
    }
  }
}
```

To associate the routing tables with DVMRP, include the `rib-group` at the [edit protocols dvmrp] hierarchy level, as described in “Enable DVMRP” on page 393.

Enable DVMRP

To enable DVMRP on the router, include the following statements at the [edit protocols] hierarchy level:

```
[edit protocols]
  dvmrp {
    rib-group group-name2;
    interface interface-name;
  }
```

The `rib-group` statement associates with DVMRP the routing table group that imports and exports routes into the specified routing table group. This is a group you defined with the `rib-groups` statement at the [edit routing-options] hierarchy level. For more information, see “Create Routing Table Groups” on page 123.

You must specify the interface or interfaces on which to enable DVMRP. Specify the full interface name, including the physical and logical address components. To configure all interfaces, specify the interface name as `all`. For details about specifying interfaces, see the *JUNOS Internet Software Configuration Guide: Interfaces and Chassis*.



Note

You cannot configure both DVMRP and PIM on the same interface.

Modify the DVMRP Hold-Time Period

The DVMRP hold-time period is the amount of time a neighbor should consider the sending router (this router) to be operative (up). The default hold-time period is 35 seconds.

To modify the hold-time value for the local router, include the `hold-time` statement at the [edit protocols dvmrp interface *interface-name*] hierarchy level:

```
[edit protocols dvmrp interface interface-name]
  hold-time seconds;
```

The hold-time period can range from 0 through 255 seconds.

Modify the Metric Value

For each source network reported, a route metric is associated with the unicast route being reported. The metric is the sum of the interface metrics between the router originating the report and the source network. A metric of 32 marks the source network as unreachable, thus limiting the breadth of the DVMRP network and placing an upper bound on the DVMRP convergence time.

By default, a metric value of 1 is associated with each DVMRP route. To modify the metric value, include the metric statement at the [edit protocols dvmrp interface *interface-name*] hierarchy level:

```
[edit protocols dvmrp interface interface-name]  
metric metric;
```

The metric can range from 1 through 31.

Disable DVMRP on an Interface

To disable DVMRP on an interface, include the disable statement at the [edit protocols dvmrp interface *interface-name*] hierarchy level:

```
[edit protocols dvmrp interface interface-name]  
disable;
```

Configure DVMRP Routing Policy

All routing protocols use the routing table to store the routes that they learn and to determine which routes they should advertise in their protocol packets. Routing policy allows you to control which routes the routing protocols store in and retrieve from the routing table. For information about routing policy, see “Configure Routing Policy” on page 35.

When configuring DVMRP routing policy, you can apply routing policies. To do this, include the import and export statements at the [edit protocols dvmrp] hierarchy level.

To apply policies to routes being imported into the routing table from DVMRP, include the import statement, listing the names of one or more policy filters to be evaluated. If you specify more than one policy, they are evaluated in the order specified, from first to last, and the first matching policy is applied to the route. If no match is found, DVMRP shares with the routing table only those routes that were learned from DVMRP routers.

```
[edit protocols dvmrp]  
import [ policy-names ];
```

To apply policies to routes being exported from the routing table into DVMRP, include the export statement, listing the names of one or more policies to be evaluated. If you specify more than one policy, they are evaluated in the order specified, from first to last, and the first matching policy is applied to the route. If no match is found, the routing table exports into DVMRP only the routes that it learned from DVMRP and direct routes.

```
[edit protocols dvmrp]  
export [ policy-names ];
```

Trace DVMRP Protocol Traffic

To trace DVMRP protocol traffic, you can specify options in the global traceoptions statement at the [edit routing-options] hierarchy level, and you can specify DVMRP-specific options by including the traceoptions statement at the [edit protocols dvmrp] hierarchy level:

```
[edit protocols dvmrp]
traceoptions {
  file name <replace> <size size> <files number> <no-stamp>
    <(world-readable | no-world-readable)>;
  flag flag <flag-modifier> <disable>;
}
```

You can specify the following DVMRP-specific options in the DVMRP traceoptions statement:

cache—Trace all packets in the DVMRP routing cache.

graft—Trace graft messages.

neighbor—Trace neighbor probe messages.

packets—Trace all DVMRP packets.

probe—Trace probe packets.

prune—Trace prune messages.

report—Trace DVMRP route report packets.

To trace the paths of multicast packets, use the mtrace command, as described in the *JUNOS Internet Software Command Reference*.

For general information about tracing and global tracing options, see “Trace Global Routing Protocol Operations” on page 128.

Example: Trace DVMRP Protocol Traffic

Trace only unusual or abnormal operations to routing-log, and trace detailed information about all DVMRP messages to dvmrp-log:

```
[edit]
routing-options {
  traceoptions {
    file routing-log;
  }
}
protocols {
  dvmrp {
    traceoptions {
      file dvmrp-log;
      flag packets;
    }
    interface so-0/0/0;
  }
}
```

Example: Configure DVMRP

Configure DVMRP on the router:

```
[edit]
routing-options {
  interface-routes {
    rib-group ifrg;
  }
  rib-groups {
    rib-group ifrg {
      import-rib [ inet.0 inet.2 ];
    }
    rib-group dvmrp-rib {
      import-rib inet.2;
      export-rib inet.2;
    }
  }
}
protocols {
  sap; # Listen for session announcements
  dvmrp { # Enable DVMRP on all interfaces and use the routing table group we defined above.
    rib-group dvmrp-rib;
    traceoptions {
      flag normal;
      flag state;
    }
    interface ip-f/p/0.0 {
      hold-time dvmrp 130; # Interfaces other than ip-f/p/0.0 have a hold time of 35
    }
  }
}
```