

## dhcp-trusted

---

<b>Syntax</b>	(dhcp-trusted   no-dhcp-trusted);
<b>Hierarchy Level</b>	[edit ethernet-switching-options secure-access-port interface (all   <i>interface-name</i> )]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX-series switches.
<b>Description</b>	<p>Allow DHCP responses from the specified interfaces (ports) or all interfaces.</p> <ul style="list-style-type: none"><li>■ <b>dhcp-trusted</b>—Allow DHCP responses.</li><li>■ <b>no-dhcp-trusted</b>—Deny DHCP responses.</li></ul>
<b>Default</b>	Trusted for trunk ports, untrusted for access ports.
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Configuring Port Security, with DHCP Snooping, DAI, MAC Limiting, and MAC Move Limiting, on an EX-series Switch</li><li>■ Example: Configuring a DHCP Server Interface as Untrusted to Protect the Switch from Rogue DHCP Server Attacks</li><li>■ Enabling a Trusted DHCP Server (CLI Procedure)</li><li>■ Enabling a Trusted DHCP Server (J-Web Procedure)</li></ul>

