

mode

Syntax	<code>mode <i>mode</i>;</code>
Hierarchy Level	[edit protocols mstp interface (all <i>interface-name</i>)], [edit protocols mstp msti <i>msti-id</i> interface <i>interface-name</i>], [edit protocols rstp interface (all <i>interface-name</i>)], [edit protocols stp interface (all <i>interface-name</i>)], [edit protocols vstp vlan <i>vlan-id</i> interface (all <i>interface-name</i>)]
Release Information	Statement introduced in JUNOS Release 9.0 for EX-series switches. Statement updated in JUNOS Release 9.4 for EX-series switches to add VSTP support.
Description	For Spanning Tree Protocol (STP), Rapid Spanning Tree Protocol (RSTP), VLAN Spanning Tree Protocol (VSTP), or Multiple Spanning Tree Protocol (MSTP), configure the link mode to identify point-to-point links.
Default	For a full-duplex link, the default link mode is point-to-point . For a half-duplex link, the default link mode is shared .
Options	<i>mode</i> —Link mode: <ul style="list-style-type: none">■ point-to-point—Link is point to point.■ shared—Link is shared media.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ show spanning-tree bridge■ show spanning-tree interface■ Example: Configuring Network Regions for VLANs with MSTP on EX-series Switches■ Example: Configuring Faster Convergence and Improving Network Stability with RSTP on EX-series Switches■ Understanding MSTP for EX-series Switches■ Understanding STP for EX-series Switches■ Understanding VSTP for EX-series Switches

