

authentication

Syntax authentication {
 password *password-string*;
 username-include {
 circuit-type;
 delimiter *delimiter-character*;
 domain-name *domain-name-string*;
 logical-system-name;
 mac-address;
 option-60;
 option-82 <circuit-id> <remote-id>;
 routing-instance-name;
 user-prefix *user-prefix-string*;
 }
}

Hierarchy Level [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server group *group-name*],
[edit logical-systems *logical-system-name* system services dhcp-local-server],
[edit logical-systems *logical-system-name* system services dhcp-local-server group *group-name*],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server group *group-name*],
[edit routing-instances *routing-instance-name* system services dhcp-local-server],
[edit routing-instances *routing-instance-name* system services dhcp-local-server group *group-name*],
[edit system services dhcp-local-server],
[edit system services dhcp-local-server group *group-name*]

Release Information Statement introduced in JUNOS Release 9.1.

Description Configure the parameters the router sends to the external AAA server. A group configuration takes precedence over a global DHCP relay or DHCP local server configuration.

The statements are explained separately.

Required Privilege Level system—To view this statement in the configuration.
system-control—To add this statement to the configuration.

Related Topics ■ Using External AAA Authentication Services with DHCP

