

## key

---

<b>Syntax</b>	<i>key number;</i>
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	For Adaptive Services PICs on M-series platforms (except the M320 and M120 routers), identify an individual traffic flow within a tunnel, as defined in RFC 2890, <i>Key and Sequence Number Extensions to GRE</i> .
<b>Options</b>	<i>number</i> —Value of the key. <b>Range:</b> 0 through 4,294,967,295
<b>Usage Guidelines</b>	See the <i>JUNOS Services Interfaces Configuration Guide</i> .
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

