

proxy

Syntax	proxy inet-address <i>address</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family tcc], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family tcc]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For Layer 2.5 VPNs using an Ethernet interface as the TCC routing platform, configure the IP address for which the TCC routing platform is proxying. Ethernet TCC is supported on interfaces that carry IPv4 traffic only. Ethernet TCC encapsulation is supported on 1-port Gigabit Ethernet, 2-port Gigabit Ethernet, 4-port Gigabit Ethernet, and 4-port Fast Ethernet PICs only. Ethernet TCC is not supported on the T640 routing node.
Options	inet-address—Configure the IP address of the neighbor to the TCC routing platform.
Usage Guidelines	See Configuring Ethernet TCC and Configuring Ethernet TCC.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	remote, <i>JUNOS VPNs Configuration Guide</i>

