

## burst-size-limit

---

<b>Syntax</b>	burst-size-limit <i>bytes</i> ;
<b>Hierarchy Level</b>	[edit firewall policer <i>policer-name</i> if-exceeding]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX Series switches.
<b>Description</b>	Specify the maximum allowed burst size to control the amount of traffic bursting.
<b>Options</b>	<i>bytes</i> —Decimal value or a decimal number followed by k (thousand) or m (million). <b>Range:</b> 1 through 2,147,450,880 bytes
<b>Required Privilege Level</b>	firewall—To view this statement in the configuration. firewall-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Configuring Firewall Filters for Port, VLAN, and Router Traffic on EX Series Switches</li><li>■ Configuring Policers to Control Traffic Rates (CLI Procedure)</li><li>■ Understanding the Use of Policers in Firewall Filters</li></ul>

---

Published: 2009-07-28