

forward-delay

Syntax	forward-delay <i>seconds</i> ;
Hierarchy Level	[edit protocols mstp], [edit protocols rstp], [edit protocols stp], [edit protocols vstp vlan <i>vlan-id</i>]
Release Information	Statement introduced in JUNOS Release 9.0 for EX Series switches. Statement updated in JUNOS Release 9.4 for EX Series switches to add VSTP support.
Description	For Spanning Tree Protocol (STP), Rapid Spanning Tree Protocol (RSTP), VLAN Spanning Tree Protocol (VSTP), or Multiple Spanning Tree Protocol (MSTP), specify how long a bridge interface remains in the listening and learning states before transitioning to the forwarding state.
Default	15 seconds
Options	<i>seconds</i> —Number of seconds the bridge interface remains in the listening and learning states. Range: 4 through 30 seconds Default: 15 seconds
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ show spanning-tree bridge■ show spanning-tree interface■ Example: Configuring Network Regions for VLANs with MSTP on EX Series Switches■ Example: Configuring Faster Convergence and Improving Network Stability with RSTP on EX Series Switches■ Understanding MSTP for EX Series Switches■ Understanding STP for EX Series Switches■ Understanding VSTP for EX Series Switches

Published: 2009-07-28