

mac-table-aging-time

Syntax	mac-table-aging-time <i>seconds</i> ;
Hierarchy Level	[edit ethernet-switching-options], [edit vlans <i>vlan-name</i>]
Release Information	Statement introduced in JUNOS Release 9.0 for EX Series switches. Statement updated in JUNOS Release 9.4 for EX Series switches to include [edit ethernet-switching-options] hierarchy level.
Description	Define how long entries remain in the Ethernet switching table before expiring: <ul style="list-style-type: none">■ If you specify this statement at the [edit ethernet-switching-options] hierarchy level, it applies to all VLANs on the switch.■ If you specify this statement at the [edit vlans] hierarchy level, it applies to the specified VLAN.
Default	Entries remain in the Ethernet switching table for 300 seconds
Options	<i>seconds</i> —Time that entries remain in the Ethernet switching table before being removed. <ul style="list-style-type: none">■ Range—60 through 1,000,000 seconds■ Default—300 seconds
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ show ethernet-switching statistics aging■ Example: Setting Up Basic Bridging and a VLAN for an EX Series Switch■ Configuring MAC Table Aging (CLI Procedure)■ Configuring VLANs for EX Series Switches (CLI Procedure)■ Understanding Bridging and VLANs on EX Series Switches

Published: 2009-07-22