

Chapter 22

Monitoring Network Connectivity with the C-Web Interface

This chapter describes how to use the C-Web interface to monitor network connectivity. Topics include:

- Viewing Information About the Routing Table with the C-Web Interface on page 189
- Viewing Information About System Interfaces with the C-Web Interface on page 190

Viewing Information About the Routing Table with the C-Web Interface

To view information about the route from the local system to a remote host:

1. Select **Route** from the side pane.

The Route pane appears.



2. To suppress symbolic addressing, select the **No Resolve** box.

3. To display detailed output, select the **Detail** box.
4. Click **OK**.

Viewing Information About System Interfaces with the C-Web Interface

To view information about all system interfaces:

1. Select **Interfaces** from the side pane.

The Interfaces pane appears.

The screenshot shows the Juniper C-Web Interface. On the left is a sidebar menu with items: Monitor, ACP, CLI, Component, Date, Disk, Interfaces... (highlighted), JPS, NIC, NTP, Redirect Server, Route..., SAE, Security, and System. The main content area is titled 'Interfaces' and contains a search box labeled 'Interface Name' with 'OK' and 'Reset' buttons below it. To the right of the search box is a text box with the following text: 'Name of an interface', 'Please enter: Interface name; for example eth0. If you do not specify an interface name, the command displays information for all interfaces.', and 'Default value: -a'. At the top right of the main area, there are links for 'About', 'Refresh', and 'Logout'. The bottom of the page features a blue footer with copyright information and the Juniper logo.

2. In the Interface name box, enter the name of the interface for which you want to view data.
3. Click **OK**.