

Viewing the State of JUNOS Device Drivers (C-Web Interface)

Problem Log files indicate a problem with a specific driver.

Solution Review the configuration of the associated JUNOS router driver with C-Web:

1. Select **SAE** from the side pane, and click **Drivers**.

The Drivers pane appears.

The screenshot shows the Juniper C-Web interface. On the left is a sidebar with a 'Monitor' section containing links to ACP, CLI, Component, Date, Disk, Interfaces..., JPS, NIC, NTP, Redirect Server, Route..., SAE (highlighted), Security, and System. The main content area is titled 'SAE Drivers'. It contains three input fields: 'Name Of Device Driver' (a text box), 'Style' (a dropdown menu), and 'Maximum Results' (a text box). To the right of these fields are help text boxes: 'Name of device drivers. Please enter: All or part of the device driver name. For JUNOS router drivers and PCMM drivers, use the format default@routerName.', 'Output style Choices: brief: Display only virtual router names', and 'Number of results to be displayed. Legal range: 1 .. INF Default value: 25'. Below the input fields are 'OK' and 'Reset' buttons. At the top right of the main area, it says 'Logged in as: admin' and has links for 'About', 'Refresh', and 'Logout'. A breadcrumb trail 'SAE > Drivers' is also present. The footer contains copyright information and the Juniper logo.

2. In the Name of Device Driver box, enter a full or partial device driver name for which you want to display information, or leave the box blank to display all devices. Use the format:

default@<router name>

3. Select an output style from the Style list.
4. In the Maximum Results box, enter the maximum number of results that you want to receive.
5. Click **OK**.

The Drivers pane displays information about the JUNOS device driver.

