

Before You Install the SRC-VTA

Because VTAs rely on other components in the SRC network, you must complete several tasks before you install the SRC-VTA software. After you install the software, you must also complete several configuration tasks before the application can function correctly.

Before you install and configure a VTA, you must:

1. Deploy a working SRC network.

To support the SRC-VTA, you must install SAEs to manage the routers or other devices through which subscribers connect to the network. You must also install and configure the directory in which you will store the SRC data.

2. Install a J2EE application server on the host that supports the SRC-VTA.

For information about installing JBoss (the J2EE application server provided with the SRC software), see *Installing Web Applications Inside JBoss*.

3. On the host that supports the SRC-VTA, install a relational database to store the data that the SRC-VTA tracks.

- Related Topics**
- Overview of the SRC-VTA
 - How the SRC-VTA Works
 - SRC-VTA Operation
 - Installing the SRC-VTA and Running the Configuration Script
 - SRC-VTA Architecture and Connections to SRC Components

