

Viewing Information About Congestion Points from an External Application by DN (C-Web Interface)

Purpose View information about congestion points from an external application by DN.

Action To view information about congestion points added through an external application by DN:

1. Click **ACP > Remote Update > Congestion Point > DN**.

The Remote Update/Congestion Point/DN pane appears.

The screenshot shows the Juniper C-Web Interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The user is logged in as 'admin'. The left sidebar lists various configuration categories: ACP, CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE, Security, and System. The main content area is titled 'Remote Update / Congestion Point / DN'. It contains three input fields: 'Congestion Point Dn' (a text box), 'Slot' (a text box), and 'Style' (a dropdown menu). To the right of these fields are descriptive text boxes: 'Congestion Point Dn' explains that it's the DN of the congestion point for which to list all matching congestion points, with a value of 'All or part of the congestion point DN' and a default of 'No value'. 'Slot' explains it's the number of the slot for which to configure values, with a value of 'Currently, the chassis has only one slot. The valid value is 0' and a default value of '0'. 'Style' explains it's the output style, with choices of 'brief: Display congestion point DN' and 'detail', and a default value of 'detail'. Below the input fields are 'OK' and 'Reset' buttons. The footer of the interface shows 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo with the tagline 'Juniper your Net.'

2. In the Congestion Point DN box, enter the DN of the congestion point, or leave the box blank to display information about all devices.
3. In the Slot box, enter the number of the slot for which you want to display congestion point information.
4. Select an output style from the Style list.
5. Click **OK**.

The Remote Update/Congestion Point/DN pane displays the congestion points.

- Related Topics**
- Configuring SRC-ACP to Manage the Backbone Network
 - Viewing Backbone Congestion Point Information by DN
 - Viewing Congestion Point Information by DN
 - Viewing Information About Congestion Points from an External Application by Interface Name (C-Web Interface)

