

Viewing Information About Congestion Points in a Backbone Network by DN (C-Web Interface)

Purpose View information about congestion points in a backbone network by DN.

Action To view information about congestion points by DN:

1. Click **ACP > Backbone > Congestion Point > DN**.

The Backbone/Congestion Point/DN pane appears.

The screenshot shows the Juniper C-Web Interface with the following elements:

- Top Navigation Bar:** Monitor, Configure, Diagnose, Manage. Logged in as: admin. Refresh, Preferences, About, Logout.
- Left Sidebar:** ACP, CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE, Security, System.
- Main Content Area:**
 - ACP** (selected)
 - Backbone / Congestion Point / DN**
 - Configuration Fields:**
 - Congestion Point Dn:** Input field. Description: DN of congestion point for which you want to list all matching congestion points. Value: All or part of the congestion point DN. Default: No value.
 - Slot:** Input field. Description: Number of the slot for which you want to configure values. Value: Currently, the chassis has only one slot. The valid value is 0. Default value: 0.
 - Style:** Dropdown menu. Description: Output style. Choices: brief: Display congestion point DN. Default value: detail.
 - Virtual Router Name:** Input field. Description: Name of virtual router from which to list congestion points. Value: Virtual router name. Default: No value.
 - Buttons:** OK, Reset.

2. In the Congestion Point DN box, enter a full or partial congestion point name to display information about one or more specific congestion points, or leave the box empty to display information about all congestion points.
3. In the Slot box, enter the number of the slot for which you want to display congestion point information.
4. Select an output style from the Style list.
5. In the Virtual Router Name box, enter a virtual router name to display information about a specific virtual router, or leave the box empty to display information about all virtual routers.
6. Click **OK**.

The Backbone/Congestion Point/DN pane displays a list of congestion points.

- Related Topics**
- Configuring Congestion Points in the Directory
 - Viewing Information About Services in the Backbone Network
 - Viewing Information About Congestion Points in a Backbone Network by Expression (C-Web Interface)
 - Viewing Information about Action Congestion Points in a Backbone Network by Service (C-Web Interface)

