



---

Junos<sup>®</sup> OS

# Interfaces Command Reference

Release

13.1



---

Published: 2013-03-14

Juniper Networks, Inc.  
1194 North Mathilda Avenue  
Sunnyvale, California 94089  
USA  
408-745-2000  
[www.juniper.net](http://www.juniper.net)

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986-1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by the Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, the Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirton's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

This product includes software developed by Maker Communications, Inc., copyright © 1996, 1997, Maker Communications, Inc.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

*Junos® OS Interfaces Command Reference*  
Release 13.1  
Copyright © 2013, Juniper Networks, Inc.  
All rights reserved.

Revision History  
January 2013—Junos OS 13.1

The information in this document is current as of the date on the title page.

## YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

## END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

# Abbreviated Table of Contents

	About This Guide .....	xiii
Part 1	About Interfaces	
Chapter 1	Interface Types .....	3
Chapter 2	Common Interface Commands .....	23
Chapter 3	Common Output Fields .....	141
Part 2	Ethernet Interfaces	
Chapter 4	Ethernet Interface Operational Mode Commands .....	151
Chapter 5	VRRP Operational Mode Commands .....	425
Part 3	Digital Transmission Interfaces	
Chapter 6	Digital Transmission Interface Operational Mode Commands .....	439
Part 4	IP Demux Interfaces	
Chapter 7	IP Demux Interface Operational Mode Commands .....	485
Part 5	PPP and PPPoE Interfaces	
Chapter 8	PPP Interface Operational Mode Commands .....	499
Chapter 9	PPPoE Interface Operational Mode Commands .....	521
Part 6	Serial Interfaces	
Chapter 10	Serial Interface Operational Mode Commands .....	563
Part 7	Optical Interfaces	
Chapter 11	SONET/SDH Interface Operational Mode Commands .....	581
Part 8	ATM Interfaces	
Chapter 12	ATM Interface Operational Mode Commands .....	637
Chapter 13	ILMI Interface Operational Mode Commands .....	691
Part 9	ISDN Interfaces	
Chapter 14	ISDN Interface Operational Mode Commands .....	699

Part 10	Channelized Interfaces	
Chapter 15	Channelized E1 Interface Operational Mode Commands .....	747
Chapter 16	Channelized OC Interface Operational Commands .....	765
Chapter 17	Channelized STM1 Interface Operational Mode Commands .....	799
Chapter 18	Channelized T1 and T3 Interface Operational Mode Commands .....	819
Part 11	Services Interfaces	
Chapter 19	Adaptive Services Interface Operational Mode Commands .....	855
Chapter 20	Encryption Interface Operational Mode Commands .....	869
Chapter 21	Flow Collector and Monitoring Interface Operational Mode Commands .....	877
Chapter 22	Link Services Interface Operational Mode Commands .....	893
Chapter 23	Tunnel Services Interface Operational Mode Commands .....	957
Chapter 24	VoIP Interface Operational Mode Commands .....	991
Part 12	Management Interfaces	
Chapter 25	Discard Interface Operational Mode Commands .....	1009
Chapter 26	Loopback Interface Operational Mode Commands .....	1017
Chapter 27	Management Ethernet and Internal Ethernet Interface Operational Mode Commands .....	1027
Part 13	Index	
	Index .....	1063
	Index of Statements and Commands .....	1073

# Table of Contents

	<b>About This Guide</b> .....	<b>xiii</b>
	Junos OS Documentation and Release Notes .....	xiii
	Objectives .....	xiii
	Audience .....	xiv
	Supported Platforms .....	xv
	Using the Indexes .....	xv
	Documentation Conventions .....	xv
	Documentation Feedback .....	xvii
	Requesting Technical Support .....	xvii
	Self-Help Online Tools and Resources .....	xvii
	Opening a Case with JTAC .....	xviii
<b>Part 1</b>	<b>About Interfaces</b>	
<b>Chapter 1</b>	<b>Interface Types</b> .....	<b>3</b>
	Interface Naming Conventions .....	3
	Physical Part of an Interface Name .....	3
	Interface Names for ACX Series Universal Access Routers .....	3
	J Series Interface Names .....	4
	Interface Names for M Series and T Series Routers and PTX Series Packet Transport Switches .....	4
	MX Series Router Interface Names .....	4
	Logical Part of an Interface Name .....	5
	Channel Identifier Part of an Interface Name .....	5
	Wildcard Characters in Interface Names .....	6
	Discard Interface .....	8
	Loopback Interface .....	8
	Management Ethernet and Internal Ethernet Interfaces .....	8
	Management Ethernet and Internal Ethernet Interfaces (M Series, MX Series, T Series) .....	9
	Management Ethernet and Internal Ethernet Interfaces Overview (M Series, MX Series, T Series) .....	9
	TX Matrix Plus and T1600 Router (Routing Matrix) Management Ethernet Interfaces .....	9
	TX Matrix Plus Router Internal Ethernet Interfaces .....	10
	T1600 Routers (Routing Matrix) Internal Ethernet Interfaces .....	10
	J Series Management Ethernet Interface .....	10
	Nonconfigurable Interfaces .....	11
	Physical Interfaces .....	11
	M Series and T Series Router Physical Interfaces .....	12
	MX Series Router Physical Interfaces .....	14

	J Series Router Physical Interfaces . . . . .	15
	Logical Interfaces Assigned to a Logical System . . . . .	16
	Logical Systems Overview . . . . .	16
	Logical System Configuration Overview . . . . .	16
	Scope of Logical System Administration . . . . .	16
	Example: show interfaces terse . . . . .	17
	Services Interfaces . . . . .	20
	M Series and T Series Services Interfaces . . . . .	20
	J Series Services Interfaces . . . . .	22
	Container Interfaces . . . . .	22
<b>Chapter 2</b>	<b>Common Interface Commands . . . . .</b>	<b>23</b>
	clear interfaces interval . . . . .	25
	clear interfaces statistics . . . . .	28
	clear interfaces interface-set statistics . . . . .	29
	show interfaces brief . . . . .	30
	show interfaces descriptions . . . . .	32
	show interfaces destination-class . . . . .	34
	show interfaces detail . . . . .	37
	show interfaces extensive . . . . .	40
	show interfaces filters . . . . .	60
	show interfaces interval . . . . .	62
	show interfaces media . . . . .	65
	show interfaces policers . . . . .	67
	show interfaces queue . . . . .	69
	show interfaces routing . . . . .	108
	show interfaces routing summary . . . . .	114
	show interfaces routing-instance . . . . .	118
	show interfaces snmp-index . . . . .	120
	show interfaces source-class . . . . .	121
	show interfaces statistics . . . . .	124
	show interfaces terse . . . . .	137
<b>Chapter 3</b>	<b>Common Output Fields . . . . .</b>	<b>141</b>
	Common Output Fields Description . . . . .	141
	Destination Class Field . . . . .	141
	Enabled Field . . . . .	141
	Filters Field . . . . .	142
	Flags Fields . . . . .	142
	Addresses, Flags Field . . . . .	142
	Device Flags Field . . . . .	143
	Family Flags Field . . . . .	143
	Interface Flags Field . . . . .	144
	Link Flags Field . . . . .	145
	Logical Interface Flags Field . . . . .	145
	Label-Switched Interface Traffic Statistics Field . . . . .	146
	Policer Field . . . . .	147
	Protocol Field . . . . .	147
	RPF Failures Field . . . . .	148
	Source Class Field . . . . .	148

## Part 2

## Chapter 4

## Ethernet Interfaces

<b>Ethernet Interface Operational Mode Commands</b>	<b>151</b>
clear auto-configuration interfaces	156
clear auto-configuration interfaces interface-set	157
clear lacp statistics	158
clear lacp timeouts	159
clear interfaces mac-database	160
clear interfaces mac-database statistics	161
clear interfaces interface-set statistics	162
clear oam ethernet connectivity-fault-management	
continuity-measurement	163
clear oam ethernet connectivity-fault-management delay-statistics	164
clear oam ethernet connectivity-fault-management linktrace	
path-database	165
clear oam ethernet connectivity-fault-management loss-statistics	166
clear oam ethernet connectivity-fault-management policer	167
clear oam ethernet connectivity-fault-management statistics	168
clear oam ethernet link-fault-management state	169
clear oam ethernet link-fault-management statistics	170
clear protection-group ethernet-ring statistics	171
ping ethernet	172
request interface rebalance (Aggregated Ethernet for Subscriber	
Management)	174
request interface (revert   switchover) (Aggregated Ethernet Link	
Protection)	175
request lacp link-switchover	176
request protection-group ethernet-aps clear	177
request protection-group ethernet-aps exercise	178
request protection-group ethernet-aps force-switch	179
request protection-group ethernet-aps lockout	180
request protection-group ethernet-aps manual-switch	181
show interfaces (Aggregated Ethernet)	182
show interfaces (far-end-interval)	192
show interfaces (Fast Ethernet)	194
show interfaces (Gigabit Ethernet)	212
show interfaces (10-Gigabit Ethernet)	236
show interfaces extensive	263
show interfaces interface-set (Ethernet Interface Set)	283
show interfaces interface-set queue	286
show interfaces diagnostics optics (Gigabit Ethernet, 10-Gigabit Ethernet, and	
100 Gigabit Ethernet)	295
show interfaces irb	312
show interfaces targeting (Aggregated Ethernet for Subscriber	
Management)	319
show lacp interfaces	321
show lacp statistics	325
show lacp timeouts	327
show interfaces mac-database (Gigabit Ethernet)	330

	show interfaces mc-ae . . . . .	335
	show oam ethernet connectivity-fault-management delay-statistics . . . . .	337
	show oam ethernet connectivity-fault-management forwarding-state . . . . .	341
	show oam ethernet connectivity-fault-management interfaces . . . . .	345
	show oam ethernet connectivity-fault-management linktrace	
	path-database . . . . .	355
	show oam ethernet connectivity-fault-management mep-database . . . . .	357
	show oam ethernet connectivity-fault-management mep-statistics . . . . .	367
	show oam ethernet connectivity-fault-management loss-statistics . . . . .	378
	show oam ethernet connectivity-fault-management mip . . . . .	384
	show oam ethernet connectivity-fault-management path-database . . . . .	386
	show oam ethernet connectivity-fault-management policer . . . . .	388
	show oam ethernet evc . . . . .	391
	show oam ethernet fnp interface . . . . .	392
	show oam ethernet fnp messages . . . . .	393
	show oam ethernet fnp status . . . . .	395
	show oam ethernet link-fault-management . . . . .	397
	show oam ethernet lmi . . . . .	403
	show oam ethernet lmi statistics . . . . .	405
	show protection-group ethernet-ring aps . . . . .	407
	show protection-group ethernet-ring data-channel . . . . .	409
	show protection-group ethernet-ring interface . . . . .	411
	show protection-group ethernet-ring node-state . . . . .	414
	show protection-group ethernet-ring statistics . . . . .	417
	show protection-group ethernet-ring vlan . . . . .	420
	traceroute ethernet . . . . .	422
<b>Chapter 5</b>	<b>VRRP Operational Mode Commands . . . . .</b>	<b>425</b>
	clear vrrp . . . . .	426
	show vrrp . . . . .	427
<b>Part 3</b>	<b>Digital Transmission Interfaces</b>	
<b>Chapter 6</b>	<b>Digital Transmission Interface Operational Mode Commands . . . . .</b>	<b>439</b>
	show interfaces (T1, E1, or DS) . . . . .	440
	show interfaces (T3 or E3) . . . . .	465
<b>Part 4</b>	<b>IP Demux Interfaces</b>	
<b>Chapter 7</b>	<b>IP Demux Interface Operational Mode Commands . . . . .</b>	<b>485</b>
	show interfaces demux0 (Demux Interfaces) . . . . .	486
<b>Part 5</b>	<b>PPP and PPPoE Interfaces</b>	
<b>Chapter 8</b>	<b>PPP Interface Operational Mode Commands . . . . .</b>	<b>499</b>
	clear ppp statistics . . . . .	500
	show ppp address-pool . . . . .	501
	show ppp interface . . . . .	503
	show ppp statistics . . . . .	512
	show ppp summary . . . . .	519



<b>Chapter 9</b>	<b>PPPoE Interface Operational Mode Commands . . . . .</b>	<b>521</b>
	clear pppoe lockout . . . . .	523
	clear pppoe sessions . . . . .	525
	clear pppoe statistics . . . . .	526
	show interfaces (PPPoE) . . . . .	527
	show pppoe interfaces . . . . .	539
	show pppoe lockout . . . . .	544
	show pppoe service-name-tables . . . . .	546
	show pppoe sessions . . . . .	549
	show pppoe statistics . . . . .	551
	show pppoe underlying-interfaces . . . . .	553
	show pppoe version . . . . .	558
<b>Part 6</b>	<b>Serial Interfaces</b>	
<b>Chapter 10</b>	<b>Serial Interface Operational Mode Commands . . . . .</b>	<b>563</b>
	show interfaces (Serial) . . . . .	564
<b>Part 7</b>	<b>Optical Interfaces</b>	
<b>Chapter 11</b>	<b>SONET/SDH Interface Operational Mode Commands . . . . .</b>	<b>581</b>
	show aps . . . . .	582
	show interfaces (Aggregated SONET/SDH) . . . . .	587
	show interfaces (SONET/SDH) . . . . .	595
	show interfaces diagnostics optics (SONET) . . . . .	624
<b>Part 8</b>	<b>ATM Interfaces</b>	
<b>Chapter 12</b>	<b>ATM Interface Operational Mode Commands . . . . .</b>	<b>637</b>
	show interfaces (ATM) . . . . .	638
	show interfaces (ATM-over-ADSL) . . . . .	673
	show interfaces (ATM-over-SHDSL) . . . . .	681
<b>Chapter 13</b>	<b>ILMI Interface Operational Mode Commands . . . . .</b>	<b>691</b>
	clear ilmi statistics . . . . .	692
	show ilmi . . . . .	693
	show ilmi statistics . . . . .	694
<b>Part 9</b>	<b>ISDN Interfaces</b>	
<b>Chapter 14</b>	<b>ISDN Interface Operational Mode Commands . . . . .</b>	<b>699</b>
	clear isdn q921 statistics . . . . .	701
	clear isdn q931 statistics . . . . .	702
	show dialer defaults . . . . .	703
	show dialer interfaces . . . . .	705
	show dialer pools . . . . .	707
	show interfaces (ISDN B-Channel) . . . . .	709
	show interfaces (ISDN BRI) . . . . .	715
	show interfaces (ISDN D-channel) . . . . .	720
	show interfaces (ISDN Dialer) . . . . .	726

	show isdn calls . . . . .	736
	show isdn history . . . . .	737
	show isdn q921 statistics . . . . .	738
	show isdn q931 statistics . . . . .	740
	show isdn status . . . . .	743
<b>Part 10</b>	<b>Channelized Interfaces</b>	
<b>Chapter 15</b>	<b>Channelized E1 Interface Operational Mode Commands . . . . .</b>	<b>747</b>
	show interfaces (Channelized E1) . . . . .	748
	show interfaces (Channelized E1 IQ) . . . . .	759
	show interfaces controller (Channelized E1 IQ) . . . . .	764
<b>Chapter 16</b>	<b>Channelized OC Interface Operational Commands . . . . .</b>	<b>765</b>
	show interfaces (Channelized OC3 IQ and IQE) . . . . .	766
	show interfaces (Channelized OC12) . . . . .	785
	show interfaces (Channelized OC12 IQ and IQE) . . . . .	789
	show interfaces controller (Channelized OC3 IQ and IQE) . . . . .	793
	show interfaces controller (Channelized OC12 IQ and IQE) . . . . .	794
	show interfaces (Channelized OC48 IQ and IQE) . . . . .	796
<b>Chapter 17</b>	<b>Channelized STM1 Interface Operational Mode Commands . . . . .</b>	<b>799</b>
	show interfaces (Channelized STM1) . . . . .	800
	show interfaces (Channelized STM1 IQ) . . . . .	815
	show interfaces controller (Channelized STM1 IQ) . . . . .	818
<b>Chapter 18</b>	<b>Channelized T1 and T3 Interface Operational Mode Commands . . . . .</b>	<b>819</b>
	show interfaces (Channelized DS3-to-DS0) . . . . .	821
	show interfaces (Channelized DS3-to-DS1) . . . . .	832
	show interfaces (Channelized T1 IQ) . . . . .	835
	show interfaces (Channelized T3 IQ) . . . . .	848
	show interfaces controller (Channelized T1 IQ) . . . . .	850
	show interfaces controller (Channelized T3 IQ) . . . . .	851
<b>Part 11</b>	<b>Services Interfaces</b>	
<b>Chapter 19</b>	<b>Adaptive Services Interface Operational Mode Commands . . . . .</b>	<b>855</b>
	request interface (revert   switchover) (Adaptive Services) . . . . .	856
	show interfaces (Adaptive Services) . . . . .	857
	show interfaces (Redundant Adaptive Services) . . . . .	865
	show interfaces redundancy . . . . .	867
<b>Chapter 20</b>	<b>Encryption Interface Operational Mode Commands . . . . .</b>	<b>869</b>
	show interfaces (Encryption) . . . . .	870
<b>Chapter 21</b>	<b>Flow Collector and Monitoring Interface Operational Mode Commands . . . . .</b>	<b>877</b>
	show interfaces (Dynamic Flow Capture) . . . . .	878
	show interfaces (Flow Collector) . . . . .	882
	show interfaces (Flow Monitoring) . . . . .	888

<b>Chapter 22</b>	<b>Link Services Interface Operational Mode Commands . . . . .</b>	<b>893</b>
	show interfaces (Link Services) . . . . .	894
	show interfaces (Link Services IQ) . . . . .	907
	show interfaces (Multilink Services) . . . . .	932
	show interfaces (Redundant Link Services IQ) . . . . .	941
<b>Chapter 23</b>	<b>Tunnel Services Interface Operational Mode Commands . . . . .</b>	<b>957</b>
	show interfaces (GRE) . . . . .	958
	show interfaces (IP-over-IP) . . . . .	966
	show interfaces (Logical Tunnel) . . . . .	971
	show interfaces (Multicast Tunnel) . . . . .	976
	show interfaces (PIM) . . . . .	982
	show interfaces (Virtual Loopback Tunnel) . . . . .	986
<b>Chapter 24</b>	<b>VoIP Interface Operational Mode Commands . . . . .</b>	<b>991</b>
	clear tgm fpc . . . . .	992
	request tgm login fpc . . . . .	993
	set tgm fpc . . . . .	994
	show interfaces (TGM550 Module) . . . . .	995
	show tgm dynamic-call-admission-control . . . . .	1003
	show tgm fpc . . . . .	1004
	show tgm telephony-interface-module status . . . . .	1006
<b>Part 12</b>	<b>Management Interfaces</b>	
<b>Chapter 25</b>	<b>Discard Interface Operational Mode Commands . . . . .</b>	<b>1009</b>
	show interfaces (Discard) . . . . .	1010
<b>Chapter 26</b>	<b>Loopback Interface Operational Mode Commands . . . . .</b>	<b>1017</b>
	show interfaces (Loopback) . . . . .	1018
<b>Chapter 27</b>	<b>Management Ethernet and Internal Ethernet Interface Operational Mode Commands . . . . .</b>	<b>1027</b>
	show interfaces (M Series and T Series Routers, and PTX Series Packet Transport Switches Management and Internal Ethernet) . . . . .	1029
	show interfaces (J Series Router Management Ethernet) . . . . .	1048
<b>Part 13</b>	<b>Index</b>	
	Index . . . . .	1063
	Index of Statements and Commands . . . . .	1073



# About This Guide

This preface provides the following guidelines for using the *Junos<sup>®</sup> OS Interfaces Command Reference*:

- [Junos OS Documentation and Release Notes on page xiii](#)
- [Objectives on page xiii](#)
- [Audience on page xiv](#)
- [Supported Platforms on page xv](#)
- [Using the Indexes on page xv](#)
- [Documentation Conventions on page xv](#)
- [Documentation Feedback on page xvii](#)
- [Requesting Technical Support on page xvii](#)

## Junos OS Documentation and Release Notes

---

For a list of related Junos OS documentation, see <http://www.juniper.net/techpubs/software/junos/>.

If the information in the latest release notes differs from the information in the documentation, follow the *Junos OS Release Notes*.

To obtain the most current version of all Juniper Networks<sup>®</sup> technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

Juniper Networks supports a technical book program to publish books by Juniper Networks engineers and subject matter experts with book publishers around the world. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration using the Junos operating system (Junos OS) and Juniper Networks devices. In addition, the Juniper Networks Technical Library, published in conjunction with O'Reilly Media, explores improving network security, reliability, and availability using Junos OS configuration techniques. All the books are for sale at technical bookstores and book outlets around the world. The current list can be viewed at <http://www.juniper.net/books>.

## Objectives

---

This reference provides descriptions of the Juniper Networks Junos OS commands that you use to monitor and troubleshoot all interfaces on the router, including physical

interfaces, service interfaces, the loopback interface, the management Ethernet interface, and the discard interface.

For additional commands, see these references:

- Junos OS Operational Mode Commands
- Junos OS Operational Mode Commands



**NOTE:** For additional information about the Junos OS—either corrections to or information that might have been omitted from this guide—see the software release notes at <http://www.juniper.net/>.

---

For information about configuration statements and guidelines related to the commands described in this reference, see the following configuration guides:

- Junos® OS Network Interfaces—Includes configuration statements for all router interfaces.
- Junos Services Interfaces Configuration Release 12.3—Includes configuration statements and guidelines for services interfaces and features.

For information about related tasks performed by Network Operations Center (NOC) personnel, see the *Junos OS Interfaces Network Operations Guide*.

---

## Audience

This guide is designed for network administrators who are configuring and monitoring a Juniper Networks M Series, MX Series, T Series, EX Series, or J Series router or switch.

To use this guide, you need a broad understanding of networks in general, the Internet in particular, networking principles, and network configuration. You must also be familiar with one or more of the following Internet routing protocols:

- Border Gateway Protocol (BGP)
- Distance Vector Multicast Routing Protocol (DVMRP)
- Intermediate System-to-Intermediate System (IS-IS)
- Internet Control Message Protocol (ICMP) router discovery
- Internet Group Management Protocol (IGMP)
- Multiprotocol Label Switching (MPLS)
- Open Shortest Path First (OSPF)
- Protocol-Independent Multicast (PIM)
- Resource Reservation Protocol (RSVP)
- Routing Information Protocol (RIP)
- Simple Network Management Protocol (SNMP)

Personnel operating the equipment must be trained and competent; must not conduct themselves in a careless, willfully negligent, or hostile manner; and must abide by the instructions provided by the documentation.

## Supported Platforms

For the features described in this manual, the Junos OS currently supports the following platforms:

- J Series
- M Series
- MX Series
- SRX Series
- T Series
- EX Series





## Using the Indexes

This reference contains two indexes: a standard index with topic entries, and an index of commands.

## Documentation Conventions

[Table 1 on page xv](#) defines notice icons used in this guide.

**Table 1: Notice Icons**

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

[Table 2 on page xvi](#) defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
<b>Bold text like this</b>	Represents text that you type.	To enter configuration mode, type the <b>configure</b> command:  user@host> <b>configure</b>
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> <b>show chassis alarms</b>  No alarms currently active
<i>Italic text like this</i>	<ul style="list-style-type: none"> <li>Introduces or emphasizes important new terms.</li> <li>Identifies book names.</li> <li>Identifies RFC and Internet draft titles.</li> </ul>	<ul style="list-style-type: none"> <li>A policy <i>term</i> is a named structure that defines match conditions and actions.</li> <li><i>Junos OS System Basics Configuration Guide</i></li> <li>RFC 1997, <i>BGP Communities Attribute</i></li> </ul>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name:  [edit] root@# <b>set system domain-name</b> <i>domain-name</i>
Text like this	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> <li>To configure a stub area, include the <b>stub</b> statement at the [edit <b>protocols ospf area area-id</b>] hierarchy level.</li> <li>The console port is labeled <b>CONSOLE</b>.</li> </ul>
< > (angle brackets)	Enclose optional keywords or variables.	<b>stub</b> <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	<b>broadcast</b>   <b>multicast</b>  ( <i>string1</i>   <i>string2</i>   <i>string3</i> )
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	<b>rsvp { # Required for dynamic MPLS only</b>
[ ] (square brackets)	Enclose a variable for which you can substitute one or more values.	<b>community name members</b> [ <i>community-ids</i> ]
Indentation and braces ( { } )	Identify a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	

---

#### J-Web GUI Conventions

---



Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
<b>Bold text like this</b>	Represents J-Web graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> <li>In the Logical Interfaces box, select <b>All Interfaces</b>.</li> <li>To cancel the configuration, click <b>Cancel</b>.</li> </ul>
> (bold right angle bracket)	Separates levels in a hierarchy of J-Web selections.	In the configuration editor hierarchy, select <b>Protocols&gt;Ospf</b> .

## Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to [techpubs-comments@juniper.net](mailto:techpubs-comments@juniper.net), or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version (if applicable)

## Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need postsales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the JTAC User Guide located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC Hours of Operation —The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

## Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Find product documentation: <http://www.juniper.net/techpubs/>

- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes:  
<http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications:  
<https://www.juniper.net/alerts/>
- Join and participate in the Juniper Networks Community Forum:  
<http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

## Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, visit us at <http://www.juniper.net/support/requesting-support.html>

## PART 1

# About Interfaces

- [Interface Types on page 3](#)
- [Common Interface Commands on page 23](#)
- [Common Output Fields on page 141](#)



## CHAPTER 1

# Interface Types

This chapter provides information about the following topics:

- [Interface Naming Conventions on page 3](#)
- [Discard Interface on page 8](#)
- [Loopback Interface on page 8](#)
- [Management Ethernet and Internal Ethernet Interfaces on page 8](#)
- [Nonconfigurable Interfaces on page 11](#)
- [Physical Interfaces on page 11](#)
- [Logical Interfaces Assigned to a Logical System on page 16](#)
- [Services Interfaces on page 20](#)
- [Container Interfaces on page 22](#)

## Interface Naming Conventions

---

- [Physical Part of an Interface Name on page 3](#)
- [Logical Part of an Interface Name on page 5](#)
- [Channel Identifier Part of an Interface Name on page 5](#)
- [Wildcard Characters in Interface Names on page 6](#)

## Physical Part of an Interface Name

- [Interface Names for ACX Series Universal Access Routers on page 3](#)
- [J Series Interface Names on page 4](#)
- [Interface Names for M Series and T Series Routers and PTX Series Packet Transport Switches on page 4](#)
- [MX Series Router Interface Names on page 4](#)

## Interface Names for ACX Series Universal Access Routers

---

ACX Series routers do not have actual PIC devices. Instead they have built-in network ports on the front panel of the router. These ports are named using the same naming convention used for routers with PIC devices with the understanding that the FPC, PIC and port are pseudo devices. When you display information about one of these ports,

you specify the interface type, the slot for the Flexible PIC Concentrator (FPC), the slot on the FPC for the Physical Interface Card (PIC), and the configured port number.

In the physical part of the interface name, a hyphen (-) separates the media type from the FPC number, and a slash (/) separates the FPC, PIC, and port numbers:

*type-fpc/pic/port*

---

### J Series Interface Names

On J Series routers, when you display information about an interface, you specify the interface type, the slot in which the Physical Interface Module (PIM) is installed, **O**, and the configured port number.

In the physical part of the interface name, a hyphen (-) separates the media type from the PIM number, and a slash (/) separates the PIM, **O**, and port numbers:

*type-pim/O/port*



**NOTE:** An exception to the *type-pim/O/port* physical description is the Integrated Services Digital Network (ISDN) dialer interface, which uses the syntax *dlnumber*.

---

### Interface Names for M Series and T Series Routers and PTX Series Packet Transport Switches

On M Series and T Series routers and PTX Series Packet Transport Switches, when you display information about an interface, you specify the interface type, the slot in which the Flexible PIC Concentrator (FPC) is installed, the slot on the FPC in which the Physical Interface Card (PIC) is located, and the configured port number.

In the physical part of the interface name, a hyphen (-) separates the media type from the FPC number, and a slash (/) separates the FPC, PIC, and port numbers:

*type-fpc/pic/port*



**NOTE:** Exceptions to the *type-fpc/pic/port* physical description include the aggregated Ethernet and aggregated SONET/SDH interfaces, which use the syntax *aenumber* and *asnumber*, respectively.

---

### MX Series Router Interface Names

On MX Series routers when you display information about an interface, you specify the interface type, the Dense Port Concentrator (DPC), Flexible PIC Concentrator (FPC), or Modular Port Concentrator (MPC) slot, the PIC or MIC slot, and the configured port number.



**NOTE:** Although the MX Series routers use DPCs, FPCs, MPCs, MICs, and PICs, command syntax in this book is shown as *fpc/pic/port* for simplicity.

In the physical part of the interface name, a hyphen (-) separates the media type from the FPC number, and a slash (/) separates the DPC, FPC or MPC, MIC or PIC, and port numbers:

***type-fpc/pic/port***

- *fpc*—Slot in which the DPC, FPC, or MPC is installed.
- *pic*—Slot on the FPC in which the PIC is located or slot on the MPC in which the MIC is located.

For DPCs, the PIC value is logically mapped to the DPC port numbers. The PIC-to-port mapping varies on different platforms.

- *port*—Port number on the DPC, PIC, or MIC.

## Logical Part of an Interface Name

The logical unit part of the interface name corresponds to the logical unit number, which can be a number from 0 through 16,384. In the virtual part of the name, a period (.) separates the port and logical unit numbers:

- J Series routers:

***type-pim/0/port.logical***

- Other platforms:

***type-fpc/pic/port.logical***

## Channel Identifier Part of an Interface Name

The channel identifier part of the interface name is required only on channelized interfaces. For channelized interfaces, channel 0 identifies the first channelized interface. For channelized intelligent queuing (IQ) interfaces, channel 1 identifies the first channelized interface.



**NOTE:** Depending on the type of channelized interface, up to three levels of channelization can be specified. For more information, see the *Junos Network Interfaces Configuration Guide*.

A colon (:) separates the physical and virtual parts of the interface name:

- M Series and T Series routers:

***type-fpc/pic/port:channel***  
***type-fpc/pic/port:channel:channel***  
***type-fpc/pic/port:channel:channel:channel***

- J Series routers

***type-pim/0/port:channel***  
***type-pim/0/port:channel:channel***  
***type-pim/0/port:channel:channel:channel***

## Wildcard Characters in Interface Names

In the **show interfaces** and **clear interfaces** commands, you can use wildcard characters in the **interface-name** option to specify groups of interface names without having to type each name individually. [Table 3 on page 6](#) lists the available wildcard characters. You must enclose all wildcard characters except the asterisk (\*) in quotation marks (" ").

**Table 3: Wildcard Characters for Specifying Interface Names**

Wildcard Character	Description
<b>*</b> (asterisk)	Match any string of characters in that position in the interface name. For example, <b>so*</b> matches all SONET/SDH interfaces.
<b>"[character&lt;character...&gt;]"</b>	Match one or more individual characters in that position in the interface name. For example, <b>so-"[03]"*</b> matches all SONET/SDH interfaces in slots 0 and 3.
<b>"[!character&lt;character...&gt;]"</b>	Match all characters except the ones included in the brackets. For example, <b>so-"[!03]"*</b> matches all SONET/SDH interfaces except those in slots 0 and 3.
<b>"[character1-character1character2]"</b>	Match a range of characters. For example, <b>so-"[0-3]"*</b> matches all SONET/SDH interfaces in slots 0, 1, 2, and 3.
<b>"[!character1-character2]"</b>	Match all characters that are not in the specified range of characters. For example, <b>so-"[!0-3]"*</b> matches all SONET/SDH interfaces in slots 4, 5, 6, and 7.

The following examples illustrate the use of wildcards with operational mode commands:



### show interfaces terse (SONET/SDH Interfaces)

```

user@host> show interfaces terse so*
Interface      Admin Link Proto Local Remote
so-1/0/0       up    up    inet  192.168.8.192  --> 192.168.2.250
so-1/0/0.0     up    up    iso
so-1/1/0       up    down
so-1/1/0.0     up    down inet  192.168.8.109/30
so-1/1/1       up    up
so-1/1/1.0     up    down inet  192.168.8.113/30
so-1/1/1.0     up    down iso
so-1/1/1.0     up    down mpls
...
so-1/3/3       up    down
so-5/0/0       up    up
so-5/0/0.0     up    down inet  192.168.8.208  --> 192.168.8.209
so-5/0/0.0     up    down iso
so-5/0/0.0     up    down mpls
so-5/0/1       down down
so-5/0/2       up    down
...

```

### show interfaces terse (SONET/SDH Interfaces in Slot 1)

```

user@host> show interfaces terse so- "[1]"*
Interface      Admin Link Proto Local Remote
so-1/0/0       up    up    inet  192.168.2.125  --> 192.168.2.250
so-1/0/0.0     up    up    iso
so-1/1/0       up    down
so-1/1/0.0     up    down inet  192.168.2.150/30
so-1/1/1       up    up
so-1/1/1.0     up    down inet  192.168.2.175/30
so-1/1/1.0     up    down iso
so-1/1/1.0     up    down mpls
so-1/1/2       up    up
so-1/1/2.0     up    down inet  192.168.2.110/30
so-1/1/2.0     up    down iso
so-1/2/0       up    down

```

### show interfaces terse (All Interface Types)

```

user@host> show interfaces terse "[sg]"*
Interface      Admin Link Proto Local Remote
so-1/0/0       up    up

```

**Starting with “S” or “G”)**

so-1/0/0.0	up	up	inet	192.168.2.125	--> 192.168.2.250
			iso		
so-1/1/0	up	down			
so-1/1/0.0	up	down	inet	192.168.2.150/30	
			iso		
so-1/1/1	up	up			
so-1/1/1.0	up	down	inet	192.168.2.175/30	
			iso		
			mpls		
so-1/1/2	up	up			
...					
so-5/1/3	up	down			
gre	up	up			

---

## Discard Interface

The discard (**dsc**) interface is not a physical interface, but a virtual interface that discards packets. You can configure one discard interface. This interface allows you to identify the ingress point of a denial-of-service (DoS) attack. When your network is under attack, the target host IP address is identified, and the local policy forwards attacking packets to the discard interface. Traffic routed out of the discard interface is silently discarded.

**Related Documentation**

- [show interfaces \(Discard\) on page 1010](#)

---

## Loopback Interface

The Junos OS automatically configures one loopback interface (**lo0**), choosing the first interface to come online as the default. You can also configure the loopback interface.

When you enter the **show interfaces** command, the loopback interface and its logical interfaces are displayed:

```
user@host> show interfaces ?
...
lo0
lo0.0
lo0.16385
...
```

The logical interface **lo0.16385** is a nonconfigurable interface for router control traffic.

**Related Documentation**

- [show interfaces \(Loopback\) on page 1018](#)

---

## Management Ethernet and Internal Ethernet Interfaces

- [Management Ethernet and Internal Ethernet Interfaces \(M Series, MX Series, T Series\) on page 9](#)
- [J Series Management Ethernet Interface on page 10](#)

## Management Ethernet and Internal Ethernet Interfaces (M Series, MX Series, T Series)

- [Management Ethernet and Internal Ethernet Interfaces Overview \(M Series, MX Series, T Series\) on page 9](#)
- [TX Matrix Plus and T1600 Router \(Routing Matrix\) Management Ethernet Interfaces on page 9](#)
- [TX Matrix Plus Router Internal Ethernet Interfaces on page 10](#)
- [T1600 Routers \(Routing Matrix\) Internal Ethernet Interfaces on page 10](#)

### Management Ethernet and Internal Ethernet Interfaces Overview (M Series, MX Series, T Series)

The M Series and T Series routers have both a management Ethernet interface and one or two internal Ethernet interfaces.

The Junos OS automatically creates the router's management Ethernet interface, **fxp0**, which is an out-of-band management interface for connecting to the router. To use **fxp0** as a management port, you must configure its logical interface, **fxp0.0**, with a valid IP address.

The Junos OS also creates the internal Ethernet interface, **fxp1**, which connects the Routing Engine (**re0**) to the Packet Forwarding Engine. If the router has redundant Routing Engines, another internal Ethernet interface, **fxp2**, is created on each Routing Engine (**re0** and **re1**) in order to support fault tolerance. Two physical links between **re0** and **re1** connect the independent control planes. If one of the links fails, both Routing Engines can use the other link for IP communication.

When you enter the **show interfaces** command, the management Ethernet and internal Ethernet interfaces (and logical interfaces) are displayed:

```
user@host> show interfaces ?
...
fxp0
fxp0.0
fxp1
fxp1.0
fxp2
fxp2.0
...
```

### TX Matrix Plus and T1600 Router (Routing Matrix) Management Ethernet Interfaces

For TX Matrix Plus Routers and for T1600 Core Routers with RE-C1800 configured in a routing matrix, the Junos OS automatically creates the router's management Ethernet interface, **em0**. To use **em0** as a management port, you must configure its logical port, **em0.0**, with a valid IP address.

When you enter the **show interfaces** command on a TX Matrix Plus router, the management Ethernet interfaces (and logical interfaces) are displayed:

```
user@host> show interfaces ?
```

```
...
em0
em0.0
...
```



**NOTE:** The Routing Engines in the TX Matrix Plus router and in the T1600 routers with RE-C1800 configured in a routing matrix do not support the management Ethernet interface `fxp0`, or the internal Ethernet interfaces `fxp1` or `fxp2`.

### TX Matrix Plus Router Internal Ethernet Interfaces

On a TX Matrix Plus router, the Routing Engine (RE-TXP-SFC) and Control Board (TXP-CB) function as a unit, or host subsystem. For each host subsystem in the router, the Junos OS automatically creates two internal Ethernet interfaces, `ixgbe0` and `ixgbe1`, for the two 10-Gigabit Ethernet ports on the Routing Engine.

When you enter the **show interfaces** command on a TX Matrix Plus router, the internal Ethernet interfaces (and logical interfaces) are displayed:

```
user@host> show interfaces ?
...
ixgbe0
ixgbe0.0
ixgbe1
ixgbe1.0
...
```

### T1600 Routers (Routing Matrix) Internal Ethernet Interfaces

On a T1600 router configured in a routing matrix, the Routing Engine (RE-TXP-LCC) and Control Board (LCC-CB) function as a unit, or host subsystem. For each host subsystem in the router, the Junos OS automatically creates two internal Ethernet interfaces, `bcm0` and `em1`, for the two Gigabit Ethernet ports on the Routing Engine.

For more information about the management Ethernet interface and internal Ethernet interfaces on a TX Matrix Plus router and T1600 routers configured in a routing matrix, see the *Junos Network Interfaces Configuration Guide*.

## J Series Management Ethernet Interface

The Junos OS automatically creates the router's management Ethernet interfaces, `ge-0/0/0` through `ge-0/0/3`, which are out-of-band management interfaces for connecting to the router. To use any of these interfaces as a management port, you must configure a corresponding logical interface, such as `ge-0/0/0.0`, with a valid IP address. When you enter the **show interfaces** command, the management Ethernet interfaces (and logical interfaces) are displayed:

```
user@host> show interfaces
...
ge-0/0/0
```

```
ge-0/0/0.0
...
```

## Nonconfigurable Interfaces

The Junos OS internally generates the nonconfigurable interfaces described in [Table 4](#) on page 11.



**NOTE:** M Series and T Series services interfaces are indicated by *type-fpc/pic/port*, whereas J Series services interfaces use the *type-pim/O/port* syntax.

**Table 4: Nonconfigurable Interfaces**

Syntax	Description	Related Configurable Tunnel Interface
<b>gre</b>	This generic routing encapsulation (GRE) interface is nonconfigurable, except when you use it as the control channel for Generalized MPLS (GMPLS). See the <i>Junos MPLS Applications Configuration Guide</i> .	<i>gr-fpc/pic/port</i> <i>gr-pim/O/port</i>
<b>ipip</b>	IP over IP (IP-IP) interface.	<i>ip-fpc/pic/port</i> <i>ip-pim/O/port</i>
<b>lsi</b>	Label-switched interface. In the system, each label-switched path (LSP) is treated as an interface.	—
<b>mtun</b>	Multicast tunnel interface.	<i>mt-fpc/pic/port</i> <i>mt-pim/O/port</i>
<b>pimd</b>	PIM de-encapsulation interface.	<i>pd-fpc/pic/port port</i> <i>pd-pim/O/port</i>
<b>pime</b>	PIM encapsulation interface.	<i>pe-fpc/pic/port</i> <i>pe-pim/O/port</i>
<b>tap</b>	When packets are discarded by the Packet Forwarding Engine (for example, because of a firewall filter), they are placed on this interface.	—

## Physical Interfaces

On M Series and T Series routers, physical interfaces are installed on PICs and use the syntax *type-fpc/pic/port*. On J Series routers, physical interfaces are installed on PIMs

and use the syntax ***type-pim/0/port***. Physical interfaces are described in the following sections:

- [M Series and T Series Router Physical Interfaces on page 12](#)
- [MX Series Router Physical Interfaces on page 14](#)
- [J Series Router Physical Interfaces on page 15](#)

## M Series and T Series Router Physical Interfaces

[Table 5 on page 12](#) lists the physical interfaces that are supported on the M Series and T Series routers.

**Table 5: M Series and T Series Router Physical Interfaces**

Physical Interface	Syntax	PIC
Aggregated Ethernet	<b><i>aenumber</i></b>	Fast Ethernet Gigabit Ethernet
Aggregated SONET/SDH	<b><i>asnumber</i></b>	SONET/SDH (all OC/STM)
ATM	<b><i>at-fpc/pic/port</i></b>	ATM1 and ATM2 IQ (all)
Channelized AU-4	<b><i>cau4-fpc/pic/port</i></b>	Channelized OC12 IQ and IQE Channelized STM1 IQ and IQE
Channelized E1 IQ	<b><i>ce1-fpc/pic/port</i></b>	Channelized E1 IQ Channelized STM1 IQ
Channelized OC1 IQ and IQE	<b><i>coc1-fpc/pic/port</i></b>	Channelized OC3 IQ and IQE Channelized OC12 IQ and IQE
Channelized OC3 IQ and IQE	<b><i>coc3-fpc/pic/port</i></b>	Channelized OC3 IQ and IQE
Channelized OC12 IQ	<b><i>coc12-fpc/pic/port</i></b>	Channelized OC12 IQ
Channelized STM1 IQ	<b><i>cstm1-fpc/pic/port</i></b>	Channelized STM1 IQ
Channelized STM4 IQ	<b><i>cstm4-fpc/pic/port</i></b>	Channelized OC12 IQ
Channelized T1 IQ	<b><i>ct1-fpc/pic/port</i></b>	Channelized DS3 IQ Channelized OC3 IQ Channelized OC12 IQ Channelized T1 IQ

Table 5: M Series and T Series Router Physical Interfaces (*continued*)

Physical Interface	Syntax	PIC
Channelized T3 IQ	<b>ct3-<i>fpc/pic/port</i></b>	Channelized DS3 IQ Channelized OC3 IQ Channelized OC12 IQ
DS0	<b>ds-<i>fpc/pic/port</i></b>	Channelized DS3-to-DS0 Channelized DS3 IQ Channelized E1 Channelized E1 IQ Channelized OC3 IQ Channelized OC12 IQ Channelized STM1 IQ Channelized T1 IQ Multichannel DS3
E1	<b>e1-<i>fpc/pic/port</i></b>	Channelized E1 IQ Channelized STM1 Channelized STM1 IQ E1
E3	<b>e3-<i>fpc/pic/port</i></b>	E3 E3 IQ
Fast Ethernet	<b>fe-<i>fpc/pic/port</i></b>	Fast Ethernet
Gigabit Ethernet	<b>ge-<i>fpc/pic/port</i></b> <b>xe-<i>fpc/pic/port</i></b>	Gigabit Ethernet 10-Gigabit Ethernet
OC3 IQ and IQE	<b>oc3-<i>fpc/pic/port</i></b>	Channelized OC3 IQ and IQE Channelized OC12 IQ and IQE
Point-to-Point Protocol over Ethernet (PPPoE)	<b>pp0</b>	Gigabit Ethernet, 10-Gigabit Ethernet
Serial (EIA-530, V.35, and X.21)	<b>se-<i>fpc/pic/port</i></b>	Serial
SONET/SDH	<b>so-<i>fpc/pic/port</i></b>	Channelized OC3 IQ and IQE Channelized OC12 IQ and IQE SONET/SDH (all OC/STM)

Table 5: M Series and T Series Router Physical Interfaces (*continued*)

Physical Interface	Syntax	PIC
T1	<b>t1-<i>fpc/pic/port</i></b>	Channelized DS3-to-DS1 Channelized DS3 IQ and IQE Channelized OC3 IQ and IQE Channelized OC12 IQ and IQE Channelized T1 IQ and IQE Multichannel DS3 T1 (all)
T3	<b>t3-<i>fpc/pic/port</i></b>	Channelized DS3 IQ and IQE Channelized OC3 IQ and IQE Channelized OC12 and IQE Channelized OC12 IQ and IQE DS3 T3 (all)

## MX Series Router Physical Interfaces

Table 6 on page 14 lists the physical interfaces that are supported on the MX Series routers.

Table 6: MX Series Router Physical Interfaces

Physical Interface	Syntax	PIC or DPC
Aggregated Ethernet	<b>ae <i>number</i></b>	Fast Ethernet Tri-Rate Ethernet copper Gigabit Ethernet
Fast Ethernet	<b>fe-<i>fpc/pic/port</i></b>	Fast Ethernet
Gigabit Ethernet	<b>ge-<i>fpc/pic/port</i></b>	Tri-Rate Ethernet copper Multi-Rate DPCs Gigabit Ethernet
	<b>xe-<i>fpc/pic/port</i></b>	10-Gigabit Ethernet Multi-Rate DPCs



## J Series Router Physical Interfaces

Table 7 on page 15 lists the physical interfaces that are supported on the J Series routers.

**Table 7: J Series Router Physical Interfaces**

Physical Interface	Syntax	PIM
Asynchronous Transfer Mode-over-asymmetrical DSL (ATM-over-ADSL)	<b><i>at-pim/0/port</i></b>	ADSL (Annex A and B)
ATM-over-symmetric high-speed DSL (ATM-over-SHDSL)	<b><i>at-pim/0/port</i></b>	G.SHDSL (Annex A and B)
Channelized E1	<b><i>ce1-pim/0/port</i></b>	Dual-Port Channelized E1
Channelized T1	<b><i>ct1-port/0/port</i></b>	Dual-Port Channelized T1
B-channel	<b><i>bc-pim/0/port</i></b>	4-Port Integrated Services Digital Network (ISDN) BRI
Basic Rate Interface (BRI)	<b><i>br-pim/0/port</i></b>	
D-channel	<b><i>dc-pim/0/portpim</i></b>	
Dialer	<b><i>dlnumber</i></b>	
E1	<b><i>e1-pim/0/port</i></b>	Dual-Port E1
E3	<b><i>e3-pim/0/port</i></b>	E3
Fast Ethernet	<b><i>fe-pim/0/port</i></b>	Dual-Port Fast Ethernet
Gigabit Ethernet	<b><i>ge-pim/0/port</i></b>	Gigabit Ethernet
Point-to-Point Protocol over Ethernet ()	<b><i>pp0</i></b>	Fast Ethernet
Serial (RS-232, RS-422/449, EIA-530, V.35, and X.21)	<b><i>se-pim/0/port</i></b>	Dual-Port Serial
T1	<b><i>t1-pim/0/port</i></b>	Dual-Port T1
T3	<b><i>t3-pim/0/port</i></b>	T3 (all)



**NOTE:** ADSL interfaces and SHDSL interfaces are supported on the J Series routers only. Both interfaces are configured over an underlying ATM interface. For more information, see *ATM Interface Operational Mode Commands*.



**NOTE:** Point-to-Point Protocol over Ethernet (PPPoE) interfaces (`pp0`) are supported on the J Series routers and the M120 router only. A PPPoE interface is configured over an underlying Ethernet interface. For more information, see *PPPoE Interface Operational Mode Commands*.

---

## Logical Interfaces Assigned to a Logical System

---

- [Logical Systems Overview on page 16](#)
- [Logical System Configuration Overview on page 16](#)
- [Scope of Logical System Administration on page 16](#)
- [Example: show interfaces terse on page 17](#)

### Logical Systems Overview

With Junos OS, you can partition a single physical system into multiple logical systems that perform independent routing tasks. Each logical system has its own unique routing tables, interfaces, policies, and routing instances. A set of logical systems within a single router can handle the functions otherwise performed by several small routers, offering an effective way to maximize the use of a single routing or switching platform.



**NOTE:** A virtual router does not have the same capabilities as a logical system. A virtual router is a type of simplified routing instance that has a single routing table. By contrast, a logical system is a partition of the main router and can contain multiple virtual router routing instances. As a result, these two entities are not equivalent.

---

### Logical System Configuration Overview

Configuring a logical system consists of a sequence of tasks, some of which can only be performed by you as the master administrator—a Junos user with superuser configuration and verification privileges on the router. Other tasks can be performed by a *logical system administrator*—a Junos user that you have assigned to the logical system and is thereby granted configuration and verification privileges for only the logical systems to which that user is assigned.

### Scope of Logical System Administration

Logical system administrators are confined to the context of the logical systems to which they are assigned. Any global configuration statements are restricted from them, and command output is restricted to the context to which the logical system administrators are assigned.

For Junos OS Release 9.1 and later, when a physical interface is specified within a logical system context, the **show interfaces** command output only displays information about the logical interfaces assigned to that logical system.

From within the context of a logical system (which you can select from the main router context by using the **set cli logical-systems *logical-system-name*** command), the **show interfaces** command output is limited to the resources assigned to the logical system:

- The physical interfaces are listed by name, but no statistics are displayed.
- Only the logical interfaces assigned to the logical system are listed, with statistics displayed.
- None of the special, system-generated logical interfaces with logical unit number **32767** are listed.

At the main router level (to which you can return from the logical system context by using the **clear cli logical system** command), the **show interfaces** command output displays statistics for all interfaces configured on the router:

- Statistics are displayed for all physical interfaces.
- Statistics are displayed for all logical interfaces.
- Statistics are displayed for all system-generated logical interfaces with logical unit number **32767**.

### Example: show interfaces terse

Consider a main router for which you have configured the physical interface **at-0/0/0** with ATM-specific physical interface properties and configured the physical interface with a logical interface at logical unit **0**. You have also configured logical system **ls1** and assigned a logical system administrator for this logical system. The logical system administrator has assigned the logical interface **at-0/0/0.0** to logical system **ls1**. The configuration is as follows:

```
logical-systems {
  ls1 {
    interfaces {
      at-0/0/0 {
        unit 0 {
          encapsulation atm-ccc-cell-relay;
          vpi 0;
        }
      }
    }
    protocols {
      mpls {
        label-switched-path base_config_r4r1_lsp {
          to 10.255.65.65;
        }
        interface all;
      }
    }
    connections {
      remote-interface-switch base_config_vp_mode_connection {
        interface at-0/0/0.0;
        transmit-lsp base_config_r1r4_lsp;
        receive-lsp base_config_r4r1_lsp;
      }
    }
  }
}
```

```
    }
  }
}
chassis {
  fpc 0 {
    pic 0 {
      atm-l2circuit-mode {
        cell;
      }
    }
  }
}
interfaces {
  at-0/0/0 {
    atm-options {
      pic-type atm2;
      promiscuous-mode {
        vpi 0;
      }
    }
    inactive: unit 0 {
      encapsulation atm-ccc-cell-relay;
      vpi 0;
    }
  }
}
protocols {
  mpls {
    interface all;
  }
  isis {
    disable;
    interface all {
      level 1 disable;
      level 2 metric 10;
    }
    interface fxp0.0 {
      disable;
    }
  }
  ospf {
    reference-bandwidth 4g;
    area 0.0.0.0 {
      interface all;
      interface fxp0.0 {
        disable;
      }
    }
  }
}
```

Within the context of a logical system, logical system administration is confined to the resources assigned to that logical system.

- The following example shows the output of the **show interfaces terse** command when you (as the master administrator) issue the command from the context of the main router:

```
user@host> show interfaces terse at-0/0/0
Interface           Admin Link Proto  Local           Remote
at-0/0/0            up    up
at-0/0/0.0          up    up    ccc
at-0/0/0.32767      up    up
```

The physical interface name **at-0/0/0** is reported, followed by all requested information (in the case of the **show interfaces terse** command, the Admin and Link states) about the physical interface.

The logical interface name **at-0/0/0.0** is reported, followed by all requested information.

The output also displays all requested information about the special, system-generated logical interface **at-0/0/0.32767**, which the Junos OS uses for handling traffic that is not part of the interface. In the case of the ATM interface **at-0/0/0**, which is configured for cell-relay promiscuous virtual path identifier (VPI) mode, the system-generated logical interface **at-0/0/0.32767** is used to track statistics associated with system-generated traffic, such as Operation, Administration, and Management (OAM) F4 cell flows.



**NOTE:** The **show interfaces extensive** command output displays the individual channel statistics associated with the special **.32767** logical interface, but only when the command is issued from the context of the main router.

- The following example shows how you can place yourself into the context of logical system **ls1**:

```
user@host> set cli logical-system ls1
Logical system: ls1

user@host:ls1>
```

- The following example shows the output of the **show interfaces terse** operational command when you (as the master administrator) issue it from the context of logical system **ls1** or when it is issued by a logical system administrator for the logical system **ls1**:

```
user@host:ls1> show interfaces terse at-0/0/0
Interface           Admin Link Proto  Local           Remote
at-0/0/0
at-0/0/0.0          up    up    ccc
```

The physical interface name **at-0/0/0** is reported, but any additional details about the physical interface (in the case of the **show interfaces terse** command, the Admin and Link states) are not displayed. The system-generated logical interface **at-0/0/0.32767** is not reported at all.

- The following example shows how you can move from the context of the logical system **ls1** back to the context of the main router:

```
user@host:ls1> clear cli logical-system
Cleared default logical system

user@host>
```

For more logical system configuration examples, including verification of proper operation and verification performed by logical system administrators, see the *Junos Feature Guide*.

## Services Interfaces

Services interfaces provide specific capabilities for manipulating traffic before it is delivered to its destination.



**NOTE:** On M Series and T Series routers, services interfaces are installed on PICs. On J Series routers, services interfaces are software-based.

Services interfaces are described in the following sections:

- [M Series and T Series Services Interfaces on page 20](#)
- [J Series Services Interfaces on page 22](#)

### M Series and T Series Services Interfaces

[Table 8 on page 20](#) lists the services interfaces that are supported on M Series and T Series routers.

**Table 8: M Series and T Series Services Interfaces**

Interface	Syntax	PIC
Adaptive services	<b>sp-fpc/pic/port</b>	Adaptive Services MultiServices
Generic routing encapsulation (GRE)	<b>gr-fpc/pic/port</b>	Adaptive Services Link Services MultiServices Tunnel Services
IP-over-IP encapsulation tunnel	<b>ip-fpc/pic/port</b>	Adaptive Services Link Services MultiServices Tunnel Services
Link services	<b>ls-fpc/pic/port</b>	Link Services

Table 8: M Series and T Series Services Interfaces (*continued*)

Interface	Syntax	PIC
Link services IQ	<b>lsq-<i>fpc/pic/port</i></b>	Adaptive Services MultiServices
Logical tunnel	<b>lt-<i>fpc/pic/port</i></b>	Adaptive Services Link Services MultiServices Tunnel Services
Multicast tunnel	<b>mt-<i>fpc/pic/port</i></b>	Adaptive Services Link Services MultiServices Tunnel Services
PIM de-encapsulation	<b>pd-<i>fpc/pic/port</i></b>	Adaptive Services Link Services MultiServices Tunnel Services
PIM encapsulation	<b>pe-<i>fpc/pic/port</i></b>	Adaptive Services Link Services MultiServices Tunnel Services
Encryption	<b>es-<i>fpc/pic/port</i></b>	ES
Dynamic flow capture	<b>dfc-<i>fpc/pic/port</i></b>	Monitoring Services III
Flow collector	<b>cp-<i>fpc/pic/port</i></b>	Monitoring Services II
Flow monitoring	<b>mo-<i>fpc/pic/port</i></b>	Monitoring Services Monitoring Services II
Multilink services	<b>ml-<i>fpc/pic/port</i></b>	Multilink Services
Redundant adaptive services	<b>rsp-<i>fpc/pic/port</i></b>	Adaptive Services MultiServices

Table 8: M Series and T Series Services Interfaces (*continued*)

Interface	Syntax	PIC
Redundant link services	<b><i>rlsq-fpc/pic/port</i></b>	Adaptive Services MultiServices
Virtual loopback tunnel	<b><i>vt-fpc/pic/port</i></b>	Adaptive Services Link Services MultiServices Tunnel Services

## J Series Services Interfaces

Table 9 on page 22 lists the services interfaces that are supported on J Series routers.

Table 9: J Series Router Services Interfaces

Interface	Syntax
Adaptive services	<b><i>sp-pim/0/port</i></b>
GRE	<b><i>gr-pim/0/port</i></b>
IP-over-IP encapsulation tunnel	<b><i>ip-pim/0/port</i></b>
Link services	<b><i>ls-pim/0/port</i></b>
Logical tunnel	<b><i>lt-pim/0/port</i></b>
Multicast tunnel	<b><i>mt-pim/0/port</i></b>
PIM de-encapsulation	<b><i>pd-pim/0/port</i></b>
PIM encapsulation	<b><i>pe-pim/0/port</i></b>

## Container Interfaces

The container interface allows routing protocols to run on the logical interfaces associated with a virtual *container interface* instead of the physical SONET interfaces. For more information about container interfaces, see the *Junos Network Interfaces Configuration Guide*.

Table 10: Container Interfaces

Interface	Syntax
Container Interface	<b><i>ci&lt;number&gt;</i></b>



## CHAPTER 2

# Common Interface Commands

Table 11 on page 23 summarizes common **clear interfaces** and **show interfaces** commands used to monitor and troubleshoot most interface types. Commands are listed in alphabetical order.

**Table 11: Common Interface Commands**

Task	Command
Clear the channel service unit (CSU) alarm and defect counters.	<code>clear interfaces interval</code>
Clear interface statistics to zero.	<code>clear interfaces statistics</code>
Display brief information about all configured interfaces.	<code>show interfaces brief</code>
Display interface descriptions.	<code>show interfaces descriptions</code>
Display interfaces grouped by destination class.	<code>show interfaces destination-class</code>
Display detailed information about all configured interfaces.	<code>show interfaces detail</code>
Display extensive information about all configured interfaces.	<code>show interfaces extensive</code>
Display all firewall filters that are installed on each interface.	<code>show interfaces filters</code>
Display CSU interface alarm and error counts for the past 24 hours.	<code>show interfaces interval</code>
Display media-specific information about all configured network interfaces.	<code>show interfaces media</code>
Display all firewall policers that are installed on each interface.	<code>show interfaces policers</code>
Display class-of-service (CoS) information per physical interface.	<code>show interfaces queue</code>

Table 11: Common Interface Commands (*continued*)

Task	Command
Display the routing protocol process view of the router's interfaces status.	<a href="#">show interfaces routing</a>
Display a summary of the routing protocol process view of the router's interfaces status.	<a href="#">show interfaces routing summary</a>
Display information about the SNMP index of an interface.	<a href="#">show interfaces snmp-index</a>
Display information about interfaces grouped by source class.	<a href="#">show interfaces source-class</a>
Display static interface statistics, such as errors.	<a href="#">show interfaces statistics</a>
Display summary information about interfaces.	<a href="#">show interfaces terse</a>



**NOTE:** For information about the `monitor interface` and `monitor traffic` commands, see the *Junos System Basics and Services Command Reference*. For information about the `show interfaces controller` command, see the *channelized interfaces* chapters in this reference.

## clear interfaces interval

---

<b>Syntax</b>	clear interfaces interval <i>interface-name</i>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Clear the channel service unit (CSU) alarm and defect counters so that only the current time interval is displayed. This operation affects the <b>show interface interval</b> command, but not an SNMP query.
<b>Options</b>	<i>interface-name</i> —Name of a particular interface.
<b>Required Privilege Level</b>	clear
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show interfaces interval on page 62</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear interfaces interval on page 26</a>
<b>Output Fields</b>	See <a href="#">show interfaces interval</a> for an explanation of output fields.

## Sample Output

### clear interfaces interval

The following example displays the output for a T3 interface before and after the **clear interfaces** command is entered:

```
user@host> show interfaces interval t3-0/3/0:4
Physical interface: t3-0/3/0:4, SNMP ifIndex: 23
  17:43-current:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
    SEFS: 0, UAS: 0
  17:28-17:43:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
    SEFS: 0, UAS: 0
  17:13-17:28:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
    SEFS: 0, UAS: 0
  16:58-17:13:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
    SEFS: 0, UAS: 0
  16:43-16:58:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
    SEFS: 0, UAS: 0
  16:28-16:43:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
    CES: 195, CSES: 195, SEFS: 195, UAS: 206
  14:58-15:13:
    LCV: 35, PCV: 163394, CCV: 54485, LES: 0, PES: 35, PSES: 35, CES:
    35, CSES: 35, SEFS: 35, UAS: 32
Interval Total:
  LCV: 230, PCV: 1145859, CCV: 455470, LES: 0, PES: 230, PSES: 230,
  CES: 230, CSES: 230, SEFS: 230, UAS: 238

user@host> clear interfaces interval t3-0/3/0:4
```

```
user@host> show interfaces interval t3-0/3/0:4
Physical interface: t3-0/3/0:4, SNMP ifIndex: 23
  17:43-current:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
    SEFS: 0, UAS: 0
  Interval Total:
    LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0, SEFS: 0,
    UAS: 0
```

## clear interfaces statistics

---

<b>Syntax</b>	clear interfaces statistics (all   <i>interface-name</i> )
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Set interface statistics to zero. If you issue the <b>clear interfaces statistics <i>interface-name</i></b> command and then perform a graceful Routing Engine switchover, the interface statistics are not cleared on the new master. Reissue the command to clear the interface statistics again.
<b>Options</b>	<b>all</b> —Set statistics on all interfaces to zero.  <b><i>interface-name</i></b> —Set statistics on a particular interface to zero.
<b>Required Privilege Level</b>	clear
<b>List of Sample Output</b>	<a href="#">clear interfaces statistics on page 28</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

<b>clear interfaces statistics</b>	user@host> clear interfaces statistics
------------------------------------	--

## clear interfaces interface-set statistics

---

<b>Syntax</b>	clear interfaces interface-set statistics <i>interface-set-name</i>
<b>Release Information</b>	Command introduced in Junos OS Release 8.5.
<b>Description</b>	Set interface set statistics to zero.
<b>Options</b>	<i>interface-set-name</i> —Set statistics on a specified interface set to zero. Wildcard values can be used in the interface set name. This command will not clear the statistics of the member logical interfaces.
<b>Required Privilege Level</b>	clear
<b>List of Sample Output</b>	<a href="#">clear interfaces interface-set statistics on page 29</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

<code>clear interfaces interface-set statistics</code>	<code>user@host&gt; clear interfaces interface-set statistics</code>
--	--

## show interfaces brief

---

<b>Syntax</b>	show interfaces brief
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display brief information about all interfaces configured on the router.
<b>Options</b>	This command has no options.
<b>Additional Information</b>	In a logical system, this command displays information only about the logical interfaces and not about the physical interfaces.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces brief on page 31</a> <a href="#">show interfaces brief (Encryption) on page 31</a> <a href="#">show interfaces brief (Gigabit Ethernet) on page 31</a>
<b>Output Fields</b>	For a description of output fields for specific interfaces, see the other chapters in this manual.



## Sample Output

### show interfaces brief

```

user@host> show interfaces brief
Physical interface: so-1/2/0, Enabled, Physical link is Down
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SONET mode, Speed: OC48,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running Down
  Interface flags: Hardware-Down Point-To-Point SNMP-Traps 16384
  Link flags     : Keepalives
  SONET alarms   : LOL, LOS
  SONET defects  : LOL, LOF, LOS, SEF, AIS-L, AIS-P
Physical interface: at-1/3/0, Enabled, Physical link is Up
  Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
  Speed: OC12, Loopback: None, Payload scrambler: Enabled
  Device flags   : Present Running
  Link flags     : None
Physical interface: at-1/3/1, Enabled, Physical link is Up
  Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
  Speed: OC12, Loopback: None, Payload scrambler: Enabled
  Device flags   : Present Running
  Link flags     : None
Physical interface: so-2/0/0, Enabled, Physical link is Up
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SONET mode, Speed: OC48,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps 16384
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 1978 (00:00:08 ago), Output: 1999 (00:00:03 ago)
  SONET alarms   : None
  SONET defects  : None
Logical interface so-2/0/0.0
  Flags: Point-To-Point SNMP-Traps Encapsulation: PPP
  soagg
...

```

### show interfaces brief (Encryption)

```

user@host> show interfaces brief es-0/2/0
Physical interface: es-0/2/0, Enabled, Physical link is Up
  Type: IPSEC, Link-level type: IPSEC-over-IP, MTU: 3900, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps

```

### show interfaces brief (Gigabit Ethernet)

```

user@host> show interfaces brief ge-3/0/2
Physical interface: ge-3/0/2, Enabled, Physical link is Up
  Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
  Speed-negotiation: Enabled, Auto-MDIX: Enabled
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps 16384
  Link flags     : None
Logical interface ge-3/0/2.0
  Flags: SNMP-Traps Encapsulation: ENET2
  aenet

```

## show interfaces descriptions

<b>Syntax</b>	show interfaces descriptions
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	<p>Display the interface descriptions that have been configured with the <b>description</b> statement at one of the following hierarchy levels:</p> <ul style="list-style-type: none"><li>• [edit interfaces <i>interface-name</i>]</li><li>• [edit interfaces <i>interface-name</i> unit <i>unit-number</i>]</li><li>• [edit logical-system <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>unit-number</i>]</li></ul>
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces descriptions on page 33</a>
<b>Output Fields</b>	<p><a href="#">Table 12 on page 32</a> lists the output fields for the <b>show interfaces description</b> command. Output fields are listed in the approximate order in which they appear.</p>

Table 12: show interfaces descriptions Output Fields

Field Name	Field Description
Interface	Name of the interface.
Link	Link state: up or down.
Admin	Interface status: up or down.
Description	Configured description for the interface.

## Sample Output

**show interfaces  
descriptions**

```
user@host> show interfaces descriptions
Interface      Admin Link Description
so-1/0/0       up    up    M20-3#1
so-2/0/0       up    up    GSR-12#1
ge-3/0/0       up    up    SMB-OSPF_Area300
so-3/3/0       up    up    GSR-13#1
so-3/3/1       up    up    GSR-13#2
ge-4/0/0       up    up    T320-7#1
ge-5/0/0       up    up    T320-7#2
so-7/1/0       up    up    M160-6#1
ge-8/0/0       up    up    T320-7#3
ge-9/0/0       up    up    T320-7#4
so-10/0/0      up    up    M160-6#2
so-13/0/0      up    up    M20-3#2
so-14/0/0      up    up    GSR-12#2
ge-15/0/0      up    up    SMB-OSPF_Area100
ge-15/0/1      up    up    GSR-13#3
```

## show interfaces destination-class

<b>Syntax</b>	show interfaces destination-class (all   <i>destination-class-name logical-interface-name</i> )
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. all option introduced in Junos OS Release 8.0.
<b>Description</b>	Display information about interfaces grouped by destination class.
<b>Options</b>	<p><b>all</b>—Display information about all configured destination classes.</p> <p><b><i>destination-class-name</i></b>—Name of a logical grouping of prefixes that count packets having the destination address matching those prefixes. Whenever a destination class is specified, you must also specify a particular logical interface, not all interfaces.</p> <p><b><i>logical interface-name</i></b>—Name of a logical interface.</p>
<b>Additional Information</b>	For interfaces that carry IPv4, IPv6, or Multiprotocol Label Switching (MPLS) traffic, you can maintain packet counts based on the entry and exit points for traffic passing through your network. Entry and exit points are identified by source and destination prefixes grouped into sets defined as source classes and destination classes. For more information, see the Junos® OS Network Interfaces.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces destination-class all on page 35</a>
<b>Output Fields</b>	<a href="#">Table 13 on page 34</a> lists the output fields for the <b>show interfaces destination-class</b> command. Output fields are listed in the approximate order in which they appear.

**Table 13: show interfaces destination-class Output Fields**

Field Name	Field Description
<b>Logical interface</b>	Name of the logical interface.
<b>Destination class</b>	Name of destination class usage (DCU) counters per class for this interface.
<b>Packets</b>	Packets going to designated user-selected prefixes.
<b>Bytes</b>	Bytes going to designated user-selected prefixes.

## Sample Output

**show interfaces  
destination-class all**

user@host> **show interfaces destination-class all**

Logical interface .local..1

Logical interface .local..2

Logical interface fxp0.0

Logical interface fxp1.0

Logical interface lo0.16384

Logical interface lo0.16385

Logical interface lo0.0

Logical interface .local..3

Logical interface .local..4

Logical interface .local..5

Logical interface .local..6

Logical interface .local..7

Logical interface .local..8

Logical interface .local..9

Logical interface .local..10

Logical interface lo0.3

Logical interface pfh-0/0/0.16383

Logical interface fe-0/1/0.0

Protocol inet

Destination class	Packets (packet-per-second)	Bytes (bits-per-second)
SILVER1	0	0
(	0)	(
SILVER2	0	0
(	0)	(
SILVER3	0	0
(	0)	(
v4-dest	0	0
(	0)	(

Protocol inet6

Destination class	Packets (packet-per-second)	Bytes (bits-per-second)
SILVER1	0	0
(	0)	(
SILVER2	0	0
(	0)	(
SILVER3	0	0
(	0)	(

```

                                v4-dest          0          0
                                (                0) (      0)

Logical interface fe-0/1/1.0

Logical interface fe-0/1/2.0
  Description: CE1-to-PE2

Logical interface ge-0/3/0.0
  Description: CE1-to-PE1

Logical interface ge-0/3/2.0
  Description: CE2-to-PE1

Logical interface pc-0/3/0.16383

Logical interface lt-1/2/0.3
  Description: LS3->LS2

Logical interface lt-1/2/0.5
  Description: LS3->LS1

Logical interface sp-1/2/0.16383

```

## [show interfaces detail](#)

---

<b>Syntax</b>	show interfaces detail
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display detailed information about all interfaces configured on the router.
<b>Options</b>	This command has no options.
<b>Additional Information</b>	In a logical system, this command displays information only about the logical interfaces and not about the physical interfaces.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces detail (SONET) on page 38</a>
<b>Output Fields</b>	For more information, see the output fields table for the particular interface type in which you are interested. For information about destination class and source class statistics, see the “Destination Class Field” section and the “Source Class Field” section under <a href="#">“Common Output Fields Description” on page 141</a> . For sample output for specific interfaces, see the other chapters in this manual.

## Sample Output

### show interfaces detail (SONET)

```
user@host> show interfaces so-1/1/0 detail
Physical interface: so-1/1/0, Enabled, Physical link is Up
  Interface index: 142, SNMP ifIndex: 47, Generation: 143
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SONET mode, Speed: OC12,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Hold-times     : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 1934 (last seen 17:35:39 ago)
    Output: 1927 (last sent 17:35:48 ago)
  LCP state: Down
  NCP state: inet: Down, inet6: Not-configured, iso: Down, mp1s: Not-configured
  CHAP state: Closed
  CoS queues   : 4 supported, 4 maximum usable queues
  Last flapped : 2006-04-19 15:22:33 PDT (05:25:55 ago)
  Statistics last cleared: 2006-04-18 03:58:02 PDT (1d 16:50 ago)
  Traffic statistics:
    Input bytes   :           7910882           0 bps
    Output bytes  :           5632131           0 bps
    Input packets :           89460           0 pps
    Output packets:          116043           0 pps
  SONET alarms   : None
  SONET defects  : None
Logical interface so-1/1/0.0 (Index 69) (SNMP ifIndex 61) (Generation 138)
  Flags: Hardware-Down Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  Protocol inet, MTU: 4470, Generation: 156, Route table: 2
  Flags: Protocol-Down, SCU-out
```



Source class	Packets (packet-per-second)	Bytes (bits-per-second)
gold1	0	0
(	0)	0)
gold2	0	0
(	0)	0)
gold3	0	0
(	0)	0)

Addresses, Flags: Dest-route-down Is-Preferred Is-Primary  
Destination: 10.27.248/24, Local: 10.27.248.1, Broadcast: 10.27.248.255,

Generation: 152

Protocol iso, MTU: 4470, Generation: 157, Route table: 2

Flags: Protocol-Down, Is-Primary

## show interfaces extensive

---

**Syntax**    show interfaces extensive

**Release Information**    Command introduced before Junos OS Release 7.4.  
Command introduced in Junos OS Release 12.1 for PTX Series Packet Transport Switches.

**Description**    Display extensive information about all interfaces configured on the router.



---

**NOTE:**

- At some times, the cumulative byte counters displayed with the `show interfaces extensive` command on the 10-Gigabit Ethernet MPC with SFP+ is not always increasing and cumulative and does not give the correct results. There is a time lag in collecting these statistics, during which the display might decrease or go from a nonzero number to zero. Eventually, the counter will display the correct result.
  - When the `show interfaces extensive` command is executed on a router with an MPC or a T4000 Type 5 FPC, the *Input packet rejects* counter of the *Filter statistics* field also displays statistics related to the following packet errors:
    - Invalid VLAN range
    - Tagged packet received on an untagged interface
  - When the `show interfaces extensive` command is executed on an interface that is configured on a T4000 Type 5 FPC, the *IPv6 transit statistics* field displays:
    - Total statistics (sum of transit and local statistics) at the physical interface level
    - Transit statistics at the logical interface level
  - When the `show interfaces extensive` command is executed on an aggregate interface in a T1600 Core Router, the *IPv6 Input bytes* is displayed for an aggregate interface. However, the *IPv6 Input bytes* is always zero on a member link of an aggregated bundle even when there are IPv6 transit traffic on the member link. This is because the logical interface index of the aggregate logical interface is updated but not the logical interface of the member links in the channel lookup table.
- 

**Options**    This command has no options.

**Required Privilege Level**    view

**List of Sample Output**    [show interfaces extensive \(Circuit Emulation\) on page 42](#)

[show interfaces extensive \(Fast Ethernet\) on page 42](#)  
[show interfaces extensive \(Gigabit Ethernet\) on page 44](#)  
[show interfaces extensive \(10-Gigabit Ethernet\) on page 44](#)  
[show interfaces extensive \(IQ2 and IQ2E\) on page 47](#)  
[show interfaces extensive \(100-Gigabit Ethernet\) on page 50](#)  
[show interfaces extensive \(PTX5000 Packet Transport Switch\) on page 51](#)  
[show interfaces extensive \(T4000 Routers with Type 5 FPCs\) on page 53](#)  
[show interfaces extensive \(T4000 Routers with 24-port 10-Gigabit Ethernet LAN/WAN PIC on Type 5 FPC\) on page 55](#)  
[show interfaces extensive \(Aggregated Ethernet\) on page 57](#)

**Output Fields** For more information, see the output fields table for the particular interface type in which you are interested. For information about destination class and source class statistics, see the “Destination Class Field” section and the “Source Class Field” section under [“Common Output Fields Description” on page 141](#). For sample output for specific interfaces, see the other topics in this collection.

## Sample Output

### show interfaces extensive (Circuit Emulation)

If a Circuit Emulation (CE) PIC is configured for SAToP pseudowire, then pseudowire statistics are displayed in the CE information section of the show interface extensive output. If SAToP pseudowire is not configured on the CE PIC, then all the CE information counters will be displayed as 0 (zero).

```
user@host> show interface tl-0/0/0 extensive
Physical interface :tl-0/0/0, Enabled, Physical Link : Up
  Interface index:61441
  Speed : 1.54 Mbps, Loopback: Disabled
  Operational state : Enabled, Encapsulation : Trans
  Encoding : b8zs, Framing : unframe, Build-out : 0-30
  Inversion : enable, Clock source : master
  Description :
  Traffic statistics:
  T1 media:      Seconds
  ES              1643
  SES            1643

  CE Info      Packets      Bytes
  CE Rx       : 2395529     306627712
  CE Tx       : 2396259     306721152
  CE Rx Drop: 0             0
  CE Tx Drop: 0             0

  CE Overrun  Events: 0
  CE Underrun Events: 0
```

## Sample Output

### show interfaces extensive (Fast Ethernet)

```
user@host> show interfaces fe-0/2/1 extensive
Physical interface: fe-0/2/0, Enabled, Physical link is Up
  Interface index: 129, SNMP ifIndex: 23, Generation: 130
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues   : 4 supported, 4 maximum usable queues
  Hold-times   : Up 0 ms, Down 0 ms
  Current address: 00:90:69:91:c4:3e, Hardware address: 00:90:69:91:c4:3e
  Last flapped : 2006-04-16 23:00:41 PDT (02:08:05 ago)
  Statistics last cleared: 2006-04-16 21:42:00 PDT (03:26:46 ago)
  Traffic statistics:
  Input bytes : 17539      152 bps
  Output bytes : 92968     224 bps
  Input packets: 348       0 pps
  Output packets: 1349     0 pps
  Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  FIFO errors: 0, Resource errors: 0
  Output errors:
  Carrier transitions: 3, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

  FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
  Egress queues: 4 supported, 4 in use
  Queue counters:      Queued packets  Transmitted packets      Dropped packets
```

0 best-effort	66	66	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	1283	1283	0

Active alarms : None  
Active defects : None

MAC statistics:

	Receive	Transmit
Total octets	24721	105982
Total packets	348	1349
Unicast packets	347	430
Broadcast packets	1	37
Multicast packets	0	882
CRC/Align errors	0	0
FIFO errors	0	0
MAC control frames	0	0
MAC pause frames	0	0
Oversized frames	0	
Jabber frames	0	
Fragment frames	0	
VLAN tagged frames	0	
Code violations	0	

Filter statistics:

Input packet count	348	
Input packet rejects	0	
Input DA rejects	0	
Input SA rejects	0	
Output packet count		1349
Output packet pad count		0
Output packet error count		0
CAM destination filters: 3, CAM source filters: 0		

Autonegotiation information:  
Negotiation status: Complete  
Link partner:  
Link mode: Full-duplex, Flow control: None, Remote fault: OK

Packet Forwarding Engine configuration:  
Destination slot: 0

CoS information:

CoS transmit queue	Bandwidth	Buffer	Priority	Limit
	%	bps	%	usec
0 best-effort	95	95000000	95	0
3 network-control	5	5000000	5	0

low none  
low none

Logical interface fe-0/2/0.0 (Index 66) (SNMP ifIndex 46) (Generation 133)  
Flags: SNMP-Traps Encapsulation: ENET2  
Protocol inet, MTU: 1500, Generation: 142, Route table: 0  
Flags: DCU, SCU-out

Destination class	Packets (packet-per-second)	Bytes (bits-per-second)
silv1_new	0	0
(	0)	(
silv2_new	0	0
(	0)	(
silv_misc	0	0
(	0)	(
silver0	0	0
(	0)	(

```

silver2          0          0
  (              0) (      0)
silver3          0          0
  (              0) (      0)
silver4          0          0
  (              0) (      0)
silver5          0          0
  (              0) (      0)
silver6          0          0
  (              0) (      0)
silver7          0          0
  (              0) (      0)
silver9          0          0
  (              0) (      0)
Source class      Packets      Bytes
                  (packet-per-second) (bits-per-second)
gold1             0          0
  (              0) (      0)
gold2            16600      1062400
  (              0) (      0)
gold3             0          0
  (              0) (      0)
Addresses, Flags: Is-Preferred Is-Primary
Destination: 12.1.1/24, Local: 12.1.1.1, Broadcast: 12.1.1.255,
Generation: 150

```

## Sample Output

show interfaces  
extensive (Gigabit  
Ethernet)

```

user@host> show interfaces ge-5/0/0.0 extensive

Logical interface ge-5/0/0.0 (Index 71) (SNMP ifIndex 1930) (Generation 139)
Flags: SNMP-Traps 0x4000 Encapsulation: ENET2
Traffic statistics:
  Input bytes :          0
  Output bytes :         42
  Input packets:          0
  Output packets:         1
Local statistics:
  Input bytes :          0
  Output bytes :         42
  Input packets:          0
  Output packets:         1
Transit statistics:
  Input bytes :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:          0          0 pps
  Output packets:          0          0 pps
Output Filters: f-any
Protocol inet, MTU: 1500, Generation: 155, Route table: 0
  Output Filters: f-inet,
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.11.1/24, Local: 10.11.1.1, Broadcast: 10.11.1.255,
    Generation: 170
Protocol multiservice, MTU: Unlimited, Generation: 156, Route table: 0
  Flags: Is-Primary
  Policer: Input: __default_arp_policer__

```

## Sample Output

**show interfaces  
extensive (10-Gigabit  
Ethernet)**

```

user@host> show interfaces xe-2/1/0 extensive

Physical interface: xe-2/1/0, Enabled, Physical link is Up
  Interface index: 258, SNMP ifIndex: 762, Generation: 2046
  Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, BPDU Error:
  None, Loopback: None, Source filtering: Disabled,
  Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues     : 8 supported, 8 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:1d:b5:f8:6d:eb, Hardware address: 00:1d:b5:f8:6d:eb
  Last flapped   : 2011-12-17 00:19:02 PST (07:36:37 ago)
  Statistics last cleared: 2011-12-17 07:55:24 PST (00:00:15 ago)
  Traffic statistics:
    Input bytes :          110000          0 bps
    Output bytes :           0          0 bps
    Input packets:           1000          0 pps
    Output packets:           0          0 pps
  IPv6 transit statistics:
    Input bytes :          110000
    Output bytes :           0
    Input packets:           1000
    Output packets:           0
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0, L2 channel errors: 0,
    L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
  FIFO errors: 0, HS link CRC errors: 0,
    MTU errors: 0, Resource errors: 0
  Egress queues: 8 supported, 4 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort          0              0              0
    1 expedited-fo        0              0              0
    2 assured-forw        0              0              0
    3 network-cont        0              0              0

  Queue number:      Mapped forwarding classes
    0                best-effort
    1                expedited-forwarding
    2                assured-forwarding
    3                network-control
  Active alarms : None
  Active defects : None
  PCS statistics
    Bit errors          0
    Errored blocks      0
  MAC statistics:
    Receive              Transmit
    Total octets        128000          0
    Total packets       1000          0
    Unicast packets     1000          0
    Broadcast packets   0          0
    Multicast packets   0          0
    CRC/Align errors    0          0

```

```

FIFO errors                                0                0
MAC control frames                        0                0
MAC pause frames                         0                0
Oversized frames                         0
Jabber frames                           0
Fragment frames                         0
VLAN tagged frames                      0
Code violations                          0
Filter statistics:
  Input packet count                      1000
  Input packet rejects                    0
  Input DA rejects                       0
  Input SA rejects                       0
  Output packet count                    0
  Output packet pad count                0
  Output packet error count              0
  CAM destination filters: 0, CAM source filters: 0
Packet Forwarding Engine configuration:
  Destination slot: 2
CoS information:
  Direction : Output
  CoS transmit queue                    Bandwidth          Buffer Priority
Limit
      0 best-effort                      95      95000000000    95      0      low
none
      3 network-control                  5      5000000000      5      0      low
none
Interface transmit statistics: Disabled

Logical interface xe-2/1/0.0 (Index 83) (SNMP ifIndex 1677) (Generation 10082)

Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2
Traffic statistics:
  Input bytes : 110000
  Output bytes : 0
  Input packets: 1000
  Output packets: 0
IPv6 transit statistics:
  Input bytes : 55000
  Output bytes : 0
  Input packets: 500
  Output packets: 0
Local statistics:
  Input bytes : 55000
  Output bytes : 0
  Input packets: 500
  Output packets: 0
Transit statistics:
  Input bytes : 55000      0 bps
  Output bytes : 0      0 bps
  Input packets: 500      0 pps
  Output packets: 0      0 pps
IPv6 transit statistics:
  Input bytes : 55000
  Output bytes : 0
  Input packets: 500
  Output packets: 0
Protocol inet6, MTU: 1500, Generation: 23739, Route table: 0
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 2001:1000:abcd:2312:1432:abcd:1234:0/112, Local:

```



```

2001:1000:abcd:2312:1432:abcd:1234:1234
  Generation: 506
  Addresses, Flags: Is-Preferred
    Destination: fe80::/64, Local: fe80::21d:b5ff:fe8:6deb
  Protocol multiservice, MTU: Unlimited, Generation: 508
  Generation: 23740, Route table: 0
  Policer: Input: __default_arp_policer__

```

## Sample Output

show interfaces  
extensive (IQ2 and  
IQ2E)

```

user@host> show interfaces ge-3/2/2 extensive
Physical interface: ge-3/2/2, Enabled, Physical link is Up
  Interface index: 156, SNMP ifIndex: 548, Generation: 159
  Link-level type: Ethernet, MTU: 1518, Speed: 1000mbps, BPDU Error: None,
MAC-REWRITE Error: None, Loopback: Disabled, Source filtering: Disabled,
Flow control: Enabled, Auto-negotiation: Enabled, Remote fault: Online
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
CoS queues     : 8 supported, 8 maximum usable queues
Schedulers    : 128
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:14:f6:12:86:fa, Hardware address: 00:14:f6:12:86:fa
Last flapped   : 2010-03-17 04:03:11 PDT (00:45:30 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :          1716096          0 bps
  Output bytes  :          1716448          0 bps
  Input packets :          13407          0 pps
  Output packets:          13411          0 pps
IPv6 total statistics:
  Input bytes   :          1716096
  Output bytes  :          1716096
  Input packets :          13407
  Output packets:          13407
Ingress traffic statistics at Packet Forwarding Engine:
  Input bytes   :          1716096          0 bps
  Input packets :          13407          0 pps
  Drop bytes   :           0          0 bps
  Drop packets :           0          0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
L3 incompletes: 0, L2 channel errors: 1, L2 mismatch timeouts: 0, FIFO errors:
0,
  Resource errors: 0
Output errors:
  Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets:
0, FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Ingress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped
packets
  0 best-effort          13407          13407
0
  1 expedited-fo           0           0
0
  2 assured-forw           0           0
0
  3 network-cont           0           0
0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped
packets

```

```

0      0 best-effort          13407          13407
0      1 expedited-fo         0              0
0      2 assured-forw         0              0
0      3 network-cont         4              4
0
Active alarms : None
Active defects : None
MAC statistics:
                                Receive          Transmit
Total octets                    1716096        1716448
Total packets                    13407         13411
Unicast packets                  13407         13407
Broadcast packets                 0              0
Multicast packets                 0              4
CRC/Align errors                  0              0
FIFO errors                       0              0
MAC control frames                 0              0
MAC pause frames                   0              0
Oversized frames                   0
Jabber frames                      0
Fragment frames                    0
VLAN tagged frames                 0
Code violations                     0
Filter statistics:
Input packet count                13407
Input packet rejects               0
Input DA rejects                   0
Input SA rejects                   0
Output packet count                0
Output packet pad count            13411
Output packet error count          0
CAM destination filters: 0, CAM source filters: 0
Autonegotiation information:
Negotiation status: Complete
Link partner:
Link mode: Full-duplex, Flow control: None, Remote fault: OK
Local resolution:
Flow control: Symmetric, Remote fault: Link OK
Packet Forwarding Engine configuration:
Destination slot: 3
CoS information:
Direction : Output
CoS transmit queue               Bandwidth          Buffer Priority
Limit
    0 best-effort                 %          bps      %          usec
none                             95    950000000    95           0      low
    3 network-control             5     50000000      5           0      low
none
Direction : Input
CoS transmit queue               Bandwidth          Buffer Priority
Limit
    0 best-effort                 %          bps      %          usec
none                             95    950000000    95           0      low
    3 network-control             5     50000000      5           0      low
none

Logical interface ge-3/2/2.0 (Index 83) (SNMP ifIndex 6080) (Generation

```

148)

```

Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.100 ] Encapsulation: ENET2
Traffic statistics:
  Input bytes :          0
  Output bytes :         336
  Input packets:          0
  Output packets:         4
IPv6 total statistics:
  Input bytes :       1716096
  Output bytes :       1716096
  Input packets:      13407
  Output packets:     13407
Local statistics:
  Input bytes :          0
  Output bytes :         336
  Input packets:          0
  Output packets:         4
Transit statistics:
  Input bytes :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:          0          0 pps
  Output packets:          0          0 pps
IPv6 total statistics:
  Input bytes :       1716096
  Output bytes :       1716096
  Input packets:      13407
  Output packets:     13407
Protocol inet6, MTU: 1500, Generation: 159, Route table: 0
  Flags: Is-Primary
  Addresses, Flags: Is-Default Is-Primary
    Destination: Unspecified, Local: 2000::2
Generation: 146
  Addresses, Flags: Is-Preferred
    Destination: fe80::/64, Local: fe80::214:f600:6412:86fa
Protocol multiservice, MTU: Unlimited, Generation: 148
Generation: 160, Route table: 0
  Policer: Input: __default_arp_policer__

```

Logical interface ge-3/2/2.32767 (Index 84) (SNMP ifIndex 6081) (Generation

149)

```

Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x0000.0 ] Encapsulation: ENET2
Traffic statistics:
  Input bytes :          0
  Output bytes :          0
  Input packets:          0
  Output packets:          0
Local statistics:
  Input bytes :          0
  Output bytes :          0
  Input packets:          0
  Output packets:          0
Transit statistics:
  Input bytes :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:          0          0 pps
  Output packets:          0          0 pps
Protocol multiservice, MTU: Unlimited, Generation: 161, Route table: 0
  Flags: None
  Policer: Input: __default_arp_policer__

```

## Sample Output

### show interfaces extensive (100-Gigabit Ethernet)

```

user@host> show interfaces et-0/0/0:0 extensive
Physical interface: et-0/0/0:0, Enabled, Physical link is Down
  Interface index: 156, SNMP ifIndex: 516, Generation: 163
  Link-level type: Ethernet, MTU: 9192, Speed: 50000mbps, BPDU Error: None,
  MAC-REWRITE Error: None,
  Loopback: Disabled, Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running Down
  Interface flags: Hardware-Down SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues     : 8 supported, 8 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:aa:aa:aa:aa:00, Hardware address: 00:21:59:5c:48:00
  Last flapped   : 2010-01-07 16:36:49 PST (18:02:35 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
  IPv6 transit statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0,
    L2 channel errors: 0, L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors:
0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0,
    HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
  Egress queues: 8 supported, 8 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 DEFAULT, NC-                0                0                0
    1 REALTIME                0                0                0
    2 PRIVATE, NC-                0                0                0
    3 CONTROL                1253                1253                0
    4 BC-H, CLASS_                0                0                0
    5 BC-M, CLASS_                0                0                0
    6 IA, CLASS_V_                0                0                0
    7 CLASS_S_OUTP                0                0                0

  Queue      Mapped Forwarding Class
  0          DEFAULT, NC-Q0
  1          REALTIME
  2          PRIVATE, NC-Q1
  3          CONTROL
  4          BC-H, CLASS-Q4
  5          BC-M, CLASS-Q5

```

```

6      IA, CLASS_V_OUTPUT
7      CLASS_S_OUTPUT
Active alarms : None
Active defects : None
MAC statistics:
Total octets          Receive      Transmit
Total packets        0          0
Unicast packets      0          0
Broadcast packets    0          0
Multicast packets    0          0
CRC/Align errors     0          0
FIFO errors          0          0
MAC control frames   0          0
MAC pause frames     0          0
Oversized frames     0
Jabber frames        0
Fragment frames      0
VLAN tagged frames   0
Code violations       0
Packet Forwarding Engine configuration:
Destination slot: 0
CoS information:
Direction : Output
CoS transmit queue    Bandwidth      Buffer Priority Limit

                                %      bps      %      usec
0 best-effort         95    47500000000    95      0      low none
3 network-control     5     25000000000     5      0      low none

Logical interface et-0/0/0:0.0 (Index 68) (SNMP ifIndex 546) (Generation 161)
Flags: Deviet-Down SNMP-Traps Encapsulation: ENET2
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Local statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0          0 bps
Output bytes : 0          0 bps
Input packets: 0          0 pps
Output packets: 0          0 pps
Protocol inet, MTU: 9178, Generation: 220, Route table: 0
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 210.160.0/24, Local: 210.160.0.1, Broadcast: 210.160.0.255,
Generation: 192
Protocol mpls, MTU: 9166, Maximum labels: 3, Generation: 221, Route table: 0

Protocol multiservice, MTU: Unlimited, Generation: 222, Route table: 0
Policer: Input: __default_arp_policer

```

## Sample Output

### show interfaces

```

user@host> show interfaces et-7/0/0 extensive
Physical interface: et-7/0/0, Enabled, Physical link is Up

```

# extensive (PTX5000 Packet Transport Switch)

```

Interface index: 168, SNMP ifIndex: 501, Generation: 171
Link-level type: Ethernet, MTU: 1514, Speed: 10Gbps, BPDU Error: None,
MAC-REWRITE Error: None,
Loopback: Disabled, Source filtering: Disabled, Flow control: Enabled
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags : None
CoS queues : 8 supported, 8 maximum usable queues
Hold-times : Up 0 ms, Down 0 ms
Current address: 88:e0:f3:3b:de:43, Hardware address: 88:e0:f3:3b:de:43
Last flapped : 2012-01-18 11:48:24 PST (01:47:08 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes : 3583014 0 bps
Output bytes : 758050 0 bps
Input packets: 17740 0 pps
Output packets: 3418 0 pps
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0,
L2 channel errors: 0, L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors:
0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0,
HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters: Queued packets Transmitted packets Dropped packets

0 best-effort 252 252 0
1 expedited-fo 0 0 0
2 assured-forw 0 0 0
3 network-cont 6196 6196 0

Queue number: Mapped forwarding classes
0 best-effort
1 expedited-forwarding
2 assured-forwarding
3 network-control
Active alarms : None
Active defects : None
MAC statistics:
Total octets 4108825 1159686
Total packets 21166 6448
Unicast packets 14824 3255
Broadcast packets 3 0
Multicast packets 6339 3193
CRC/Align errors 0 0
FIFO errors 0 0
MAC control frames 0 0
MAC pause frames 0 0
Oversized frames 0 0
Jabber frames 0 0

```

```

Fragment frames                                0
VLAN tagged frames                            16091
Code violations                                0
Filter statistics:
  Input packet count                          9
  Input packet rejects                        9
  Input DA rejects                           9
  Input SA rejects                           0
  Output packet count                        0
  Output packet pad count                    0
  Output packet error count                  0
  CAM destination filters: 0, CAM source filters: 0
Autonegotiation information:
  Negotiation status: Incomplete
Packet Forwarding Engine configuration:
  Destination slot: 7
CoS information:
  Direction : Output
  CoS transmit queue      Bandwidth      Buffer Priority
Limit
      %      bps      %      usec      low
0 best-effort      95      9500000000      95      0
none
3 network-control      5      500000000      5      0
none
Interface transmit statistics: Disabled

```

## Sample Output

**show interfaces  
extensive (T4000**

```

user@host> show interfaces xe-4/0/0 extensive
Physical interface: xe-4/0/0, Enabled, Physical link is Up
Interface index: 170, SNMP ifIndex: 859, Generation: 173

```

## Routers with Type 5 FPCs)

```

Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, Loopback:
None, Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : None
CoS queues    : 8 supported, 8 maximum usable queues
Hold-times    : Up 0 ms, Down 0 ms
Current address: 00:12:1e:37:53:f8, Hardware address: 00:12:1e:37:53:f8
Last flapped  : 2012-06-06 02:25:56 PDT (10:11:58 ago)
Statistics last cleared: 2012-06-06 12:36:59 PDT (00:00:55 ago)
Traffic statistics:
Input bytes   : 0                      0 bps
Output bytes  : 0                      0 bps
Input packets : 0                      0 pps
Output packets: 0                      0 pps
IPv6 transit statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0,
Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets  Dropped packets

0 best-effort        0                0                0
1 expedited-fo       0                0                0
2 assured-forw       0                0                0
3 network-cont       0                0                0

Queue number:      Mapped forwarding classes
0                  best-effort
1                  expedited-forwarding
2                  assured-forwarding
3                  network-control
Active alarms : None
Active defects : None
PCS statistics      Seconds
Bit errors         0
Errored blocks     0
MAC statistics:      Receive      Transmit
Total octets       0              0
Total packets      0              0
Unicast packets    0              0
Broadcast packets  0              0
Multicast packets  0              0
CRC/Align errors   0              0
FIFO errors        0              0
MAC control frames 0              0
MAC pause frames   0              0
Oversized frames   0
Jabber frames      0

```



```

    Fragment frames                                0
    VLAN tagged frames                             0
    Code violations                                0
  Filter statistics:
    Input packet count                             0
    Input packet rejects                           0
    Input DA rejects                               0
    Input SA rejects                               0
    Output packet count                             0
    Output packet pad count                         0
    Output packet error count                       0
    CAM destination filters: 0, CAM source filters: 0
  Packet Forwarding Engine configuration:
    Destination slot: 4
  CoS information:
    Direction : Output
    CoS transmit queue          Bandwidth          Buffer Priority
Limit
    %          bps          %          usec
    0 best-effort          95          4750000000          95          0          low
  none
    3 network-control          5          250000000          5          0          low
  none
  Interface transmit statistics: Disabled

Logical interface xe-4/0/0.0 (Index 93) (SNMP ifIndex 834) (Generation 158)
Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Transit statistics:
  Input bytes : 0          0 bps
  Output bytes : 0          0 bps
  Input packets: 0          0 pps
  Output packets: 0          0 pps
Protocol inet, MTU: 1500, Generation: 192, Route table: 0
Flags: Sendbcst-pkt-to-re
Addresses, Flags: Is-Preferred Is-Primary
Destination: 34.1.1/24, Local: 34.1.1.2, Broadcast: 34.1.1.255, Generation:
157
Protocol multiservice, MTU: Unlimited, Generation: 193, Route table: 0
Policer: Input: __default_arp_policer__

```

## Sample Output

show interfaces  
extensive (T4000  
Routers with 24-port  
10-Gigabit Ethernet

```

user@host> show interfaces xe-3/1/0 extensive
Physical interface: xe-3/1/0, Enabled, Physical link is Up
Interface index: 160, SNMP ifIndex: 1285, Generation: 163
Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, BPDU Error:
None, Loopback: None,

```

LAN/WAN PIC on Type  
5 FPC)

```

Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : None
CoS queues     : 8 supported, 8 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 2c:6b:f5:e1:cb:39, Hardware address: 2c:6b:f5:e1:cb:39
Last flapped   : 2012-05-09 07:15:54 UTC (03:39:52 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes  :                0                0 bps
  Output bytes :                0                0 bps
  Input packets:                0                0 pps
  Output packets:              0                0 pps
IPv6 transit statistics:
  Input bytes  :                0
  Output bytes :                0
  Input packets:                0
  Output packets:              0
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0, L2 channel errors: 0,
  L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors: 0
Output errors:
  Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0,
  HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort                0                0                0
  1 ay_q1                      0                0                0
  2 assured-forw              0                0                0
  3 network-cont              0                0                0

Queue number:      Mapped forwarding classes
  0                best-effort
  1                ay_q1
  2                assured-forwarding
  3                network-control
Active alarms  : None
Active defects : None
PCS statistics                      Seconds
  Bit errors                0
  Errored blocks            0
MAC statistics:                      Receive      Transmit
  Total octets              0                0
  Total packets             0                0
  Unicast packets           0                0
  Broadcast packets         0                0
  Multicast packets         0                0
  CRC/Align errors          0                0
  FIFO errors               0                0
  MAC control frames        0                0
  MAC pause frames          0                0
  Oversized frames          0
  Jabber frames             0
  Fragment frames           0

```

```

VLAN tagged frames          0
Code violations              0
Filter statistics:
  Input packet count        0
  Input packet rejects      0
  Input DA rejects          0
  Input SA rejects          0
  Output packet count       0
  Output packet pad count   0
  Output packet error count 0
  CAM destination filters: 0, CAM source filters: 0
Packet Forwarding Engine configuration:
  Destination slot: 3
CoS information:
  Direction : Output
  CoS transmit queue      Bandwidth      Buffer Priority  Limit

                                %      bps      %      usec
0 best-effort              95  9500000000  95      0      low  none
3 network-control          5   500000000   5      0      low  none

Preclassifier statistics:
Traffic Class      Received Packets  Transmitted Packets  Dropped Packets

network-control      0                  0                  0
best-effort          0                  0                  0
Interface transmit statistics: Disabled

```

## Sample Output

**show interfaces  
extensive (Aggregated  
Ethernet)**

```

user@host> show interfaces ae0 extensive
Physical interface: ae0, Enabled, Physical link is Up
Interface index: 199, SNMP ifIndex: 570, Generation: 202
Link-level type: Ethernet, MTU: 1514, Speed: 2Gbps, BPDU Error: None,
MAC-REWRITE Error: None, Loopback: Disabled, Source filtering: Disabled,
Flow control: Disabled, Minimum links needed: 1, Minimum bandwidth needed: 0
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Current address: 2c:6b:f5:d1:0f:c0, Hardware address: 2c:6b:f5:d1:0f:c0
Last flapped   : 2012-06-06 23:33:03 PDT (00:00:58 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes :          18532          1984 bps
Output bytes :           0           0 bps
Input packets:          158           2 pps
Output packets:           0           0 pps
IPv6 transit statistics:
Input bytes :           0
Output bytes :           0
Input packets:           0
Output packets:           0
Dropped traffic statistics due to STP State:
Input bytes :           0
Output bytes :           0
Input packets:           0
Output packets:           0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0,
Resource errors: 0

```

## Output errors:

Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:

0

Ingress queues: 8 supported, 4 in use

Queue counters:	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	0	0	0

Egress queues: 8 supported, 4 in use

Queue counters:	Queued packets	Transmitted packets	Dropped packets
0 best-effort	57	57	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	63605	63605	0

Queue number:	Mapped forwarding classes
0	best-effort
1	expedited-forwarding
2	assured-forwarding
3	network-control

Logical interface ae0.0 (Index 331) (SNMP ifIndex 583) (Generation 142)

Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2

Statistics	Packets	pps	Bytes	bps	
Bundle:					
Input :	149	2	17416	1984	
Output:	0	0	0	0	
Link:					
ge-3/2/5.0					
Input :	90	1	10100	992	
Output:	0	0	0	0	
ge-3/3/9.0					
Input :	59	1	7316	992	
Output:	0	0	0	0	
LACP info:					
Port	Port	Role	System	System	Port
		priority	identifier	priority	number
key					
ge-3/2/5.0	Actor	100	00:00:00:00:00:01	127	1
ge-3/2/5.0	Partner	127	00:24:dc:98:67:c0	127	1
ge-3/3/9.0	Actor	100	00:00:00:00:00:01	127	2
ge-3/3/9.0	Partner	127	00:24:dc:98:67:c0	127	2
LACP Statistics:					
	LACP Rx	LACP Tx	Unknown Rx	Illegal Rx	
ge-3/2/5.0	38	137	0	0	
ge-3/3/9.0	36	139	0	0	
Marker Statistics:					
	Marker Rx	Resp Tx	Unknown Rx	Illegal Rx	
ge-3/2/5.0	0	0	0	0	

```
ge-3/3/9.0          0          0          0          0
Protocol inet, MTU: 1500, Generation: 169, Route table: 0
Flags: Sendbcast-pkt-to-re
Addresses, Flags: Is-Preferred Is-Primary
Destination: 1.1.1/24, Local: 1.1.1.2, Broadcast: 1.1.1.255, Generation:
153
Protocol multiservice, MTU: Unlimited, Generation: 170, Route table: 0
Flags: Is-Primary
Policer: Input: __default_arp_policer__
```

## show interfaces filters

<b>Syntax</b>	<code>show interfaces filters</code> <code>&lt;interface-name&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Command introduced on PTX Series Packet Transport Switches for Junos OS Release 12.1.
<b>Description</b>	Display all firewall filters that are installed on each interface in a system.
<b>Options</b>	<b>none</b> —Display filter information about all interfaces.  <b>interface-name</b> —(Optional) Display filter information about a particular interface.
<b>Additional Information</b>	For information about how to configure firewall filters, see the Routing Policy Configuration Guide. For related operational mode commands, see the Junos OS Operational Mode Commands.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces filters on page 61</a> <a href="#">show interfaces filters interface-name on page 61</a> <a href="#">show interfaces filters (PTX Series Packet Transport Switches) on page 61</a>
<b>Output Fields</b>	<a href="#">Table 14 on page 60</a> lists the output fields for the <b>show interfaces filters</b> command. Output fields are listed in the approximate order in which they appear.

**Table 14: show interfaces filters Output Fields**

Field Name	Field Description
<b>Interface</b>	Name of the interface.
<b>Admin</b>	Interface state: <b>up</b> or <b>down</b> .
<b>Link</b>	Link state: <b>up</b> or <b>down</b> .
<b>Proto</b>	Protocol configured on the interface.
<b>Input Filter</b>	Names of any firewall filters to be evaluated when packets are received on the interface, including any filters attached through activation of dynamic service.
<b>Output Filter</b>	Names of any firewall filters to be evaluated when packets are transmitted on the interface, including any filters attached through activation of dynamic service.

## Sample Output

### show interfaces filters

```

user@host> show interfaces filters
Interface      Admin Link Proto Input Filter      Output Filter
ge-0/0/0       up    up
ge-0/0/0.0     up    up    inet
               iso
ge-5/0/0       up    up
ge-5/0/0.0     up    up    any
               inet
               multiservice    f-any
               f-inet
gr-0/3/0       up    up
ip-0/3/0       up    up
mt-0/3/0       up    up
pd-0/3/0       up    up
pe-0/3/0       up    up
vt-0/3/0       up    up
at-1/0/0       up    up
at-1/0/0.0     up    up    inet
               iso
at-1/1/0       up    down
at-1/1/0.0     up    down inet
               iso
....

```

### show interfaces filters interface-name

```

user@host> show interfaces filters so-2/1/0
Interface      Admin Link Proto Input Filter      Output Filter
so-2/1/0       up    down
so-2/1/0.0     up    down inet    goop    outfilter
               iso
               inet6 v6in    v6out

user@host > show interfaces filters ge-3/0/1
Interface      Admin Link Proto Input Filter      Output Filter
ge-3/0/1       up    up
ge-3/0/1.0     up    up    inet    F1-ge-3/0/1.0-in    F2-ge-3/0/1.0-out
               inet    F3-ge-3/0/1.0-in

```

### show interfaces filters (PTX Series Packet Transport Switches)

```

user@host > show interfaces filters em0
Interface      Admin Link Proto Input Filter      Output Filter
em0            up    up
em0.0          up    up    inet

```

## show interfaces interval

<b>Syntax</b>	<code>show interfaces interval</code> <code>&lt;interface-name&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display the channel service unit (CSU) interface alarm and error count in 15-minute intervals for the past 24 hours. If the system has been operational for less than 24 hours, the maximum number of intervals available is displayed.
<b>Options</b>	<i>interface-name</i> —(Optional) Name of a particular interface.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li><a href="#">clear interfaces interval on page 25</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces interval (Channelized OC12) on page 63</a> <a href="#">show interfaces interval (E3) on page 63</a> <a href="#">show interfaces interval (SONET/SDH) on page 63</a>
<b>Output Fields</b>	Table 15 on page 62 lists the output fields for the <b>show interfaces interval</b> command. Output fields are listed in the approximate order in which they appear.

**Table 15: show interfaces interval Output Fields**

Field Name	Field Description
Physical interface	Name of the interface.
SNMP ifIndex	SNMP index number for the physical interface.
hh:mm-current	Time of day (in hours and minutes) at the beginning of the latest counter interval. The value of the latest counter interval is always less than 15 minutes.
hh:mm-hh:mm	Time of day (in hours and minutes) at the beginning and end of each 15-minute interval.
alarm or event: n	Count of alarms and events within each 15-minute interval. The specific alarm or event depends on the interface media type. For a description of the alarm or event listed, see the <i>interface-type media</i> field (for example, <b>T1 media</b> ) under the <b>show interfaces</b> command for the particular interface type in which you are interested.
Interval Total	Sum of all the alarm and defect counters for the last 24-hour period.



## Sample Output

### show interfaces interval (Channelized OC12)

```
user@host> show interfaces interval t3-0/3/0:0
Physical interface: t3-0/3/0:0, SNMP ifIndex: 23
17:43-current:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
17:28-17:43:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
17:13-17:28:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
16:58-17:13:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
16:43-16:58:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  ...
Interval Total:
  LCV: 230, PCV: 1145859, CCV: 455470, LES: 0, PES: 230, PSES: 230,
  CES: 230, CSES: 230, SEFS: 230, UAS: 238
```

### show interfaces interval (E3)


```
user@host> show interfaces interval e3-0/3/0
Physical interface: e3-0/3/0, SNMP ifIndex: 23
17:43-current:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
17:28-17:43:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
17:13-17:28:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
16:58-17:13:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  SEFS: 0, UAS: 0
16:43-16:58:
  LCV: 0, PCV: 0, CCV: 0, LES: 0, PES: 0, PSES: 0, CES: 0, CSES: 0,
  ....
Interval Total:
  LCV: 230, PCV: 1145859, CCV: 455470, LES: 0, PES: 230, PSES: 230,
  CES: 230, CSES: 230, SEFS: 230, UAS: 238
```

### show interfaces interval (SONET/SDH)

```
user@host> show interfaces interval so-0/1/0
Physical interface: so-0/1/0, SNMP ifIndex: 19
20:02-current:
  ES-S: 0, SES-S: 0, SEFS-S: 0, ES-L: 0, SES-L: 0, UAS-L: 0, ES-P: 0,
  SES-P: 0, UAS-P: 0
19:47-20:02:
  ES-S: 267, SES-S: 267, SEFS-S: 267, ES-L: 267, SES-L: 267, UAS-L: 267,
  ES-P: 267, SES-P: 267, UAS-P: 267
19:32-19:47:
  ES-S: 56, SES-S: 56, SEFS-S: 56, ES-L: 56, SES-L: 56, UAS-L: 46, ES-P: 56,
  SES-P: 56, UAS-P: 46
19:17-19:32:
  ES-S: 0, SES-S: 0, SEFS-S: 0, ES-L: 0, SES-L: 0, UAS-L: 0, ES-P: 0,
  SES-P: 0, UAS-P: 0
```

19:02-19:17:  
.....

## show interfaces media

<b>Syntax</b>	show interfaces media
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Command introduced on PTX Series Packet Transport Switches for Junos OS Release 12.1.
<b>Description</b>	Display media-specific information about all configured network interfaces.
	<div>  <p><b>NOTE:</b> <code>show interfaces media</code> lists details for all interfaces, whereas <code>show interfaces media interface-name</code> lists details only for the specified interface.</p> </div>
<b>Options</b>	This command has no options.
<b>Additional Information</b>	Output from both the <code>show interfaces interface-name detail</code> and the <code>show interfaces interface-name extensive</code> commands includes all the information displayed in the output from the <code>show interfaces media</code> command.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces media (SONET/SDH) on page 66</a> <a href="#">show interfaces media (PTX Series Packet Transport Switches) on page 66</a>
<b>Output Fields</b>	<p>The output from the <code>show interfaces media</code> command includes fields that display interface media-specific information. These fields are also included in the <code>show interfaces interface-name</code> command for each particular interface type, and the information provided in the fields is unique to each interface type.</p> <p>One field unique to the <code>show interfaces media</code> command is <b>interface-type errors</b> (for example, <b>SONET errors</b>). This field appears for channelized E3, channelized T3, channelized OC, E1, E3, SONET, T1, and T3 interfaces. The information provided in this output field is also provided in the output from the <code>show interfaces interface-name</code> command. (For example, for SONET interfaces, these fields are <b>SONET section</b>, <b>SONET line</b>, and <b>SONET path</b>). For a description of errors, see the chapter with the particular interface type in which you are interested.</p>

## Sample Output

### **show interfaces media** **(SONET/SDH)**

The following example displays the output fields unique to the **show interfaces media** command for a SONET interface (with no level of output specified):

```
user@host> show interfaces media so-4/1/2
Physical interface: so-4/1/2, Enabled, Physical link is Up
  Interface index: 168, SNMP ifIndex: 495
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SONET mode, Speed: 0C48,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps 16384
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 1783 (00:00:00 ago), Output: 1786 (00:00:08 ago)
  LCP state: Opened
  NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Not-configured
  CoS queues    : 8 supported
  Last flapped  : 2005-06-15 12:14:59 PDT (04:31:29 ago)
  Input rate    : 0 bps (0 pps)
  Output rate   : 0 bps (0 pps)
  SONET alarms  : None
  SONET defects : None
  SONET errors:
    BIP-B1: 121, BIP-B2: 916, REI-L: 0, BIP-B3: 137, REI-P: 16747, BIP-BIP2: 0
  Received path trace: routerb so-1/1/2
  Transmitted path trace: routera so-4/1/2
```

### **show interfaces media** **(PTX Series Packet** **Transport Switches)**

```
user@host> show interfaces media em0
Physical interface: em0, Enabled, Physical link is Up
  Interface index: 8, SNMP ifIndex: 0
  Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Link type      : Full-Duplex
  Current address: 00:80:f9:25:00:1b, Hardware address: 00:80:f9:25:00:1b
  Last flapped   : Never
  Input packets  : 215151
  Output packets: 72
```

## show interfaces policers

<b>Syntax</b>	show interfaces policers <interface-name>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Command introduced on PTX Series Packet Transport Switches for Junos OS Release 12.1.
<b>Description</b>	Display all policers that are installed on each interface in a system.
<b>Options</b>	<b>none</b> —Display policer information about all interfaces.  <b>interface-name</b> —(Optional) Display filter information about a particular interface.
<b>Additional Information</b>	For information about how to configure policers, see the <i>Junos Policy Framework Configuration Guide</i> . For related operational mode commands, see the <i>Junos Routing Protocols and Policies Command Reference</i> .
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces policers on page 68</a> <a href="#">show interfaces policers interface-name on page 68</a> <a href="#">show interfaces policers (PTX Series Packet Transport Switches) on page 68</a>
<b>Output Fields</b>	<a href="#">Table 16 on page 67</a> lists the output fields for the <b>show interfaces policers</b> command. Output fields are listed in the approximate order in which they appear.

**Table 16: show interfaces policers Output Fields**

Field Name	Field Description
Interface	Name of the interface.
Admin	Interface state: <b>up</b> or <b>down</b> .
Link	Link state: <b>up</b> or <b>down</b> .
Proto	Protocol configured on the interface.
Input Policer	Policer to be evaluated when packets are received on the interface. It has the format <i>interface-name-in-policer</i> .
Output Policer	Policer to be evaluated when packets are transmitted on the interface. It has the format <i>interface-name-out-policer</i> .

## Sample Output

### show interfaces policers

```

user@host> show interfaces policers
Interface      Admin Link Proto Input Policer      Output Policer
ge-0/0/0       up    up
ge-0/0/0.0     up    up    inet
               iso
gr-0/3/0       up    up
ip-0/3/0       up    up
mt-0/3/0       up    up
pd-0/3/0       up    up
pe-0/3/0       up    up
...
so-2/0/0       up    up
so-2/0/0.0     up    up    inet    so-2/0/0.0-in-policer  so-2/0/0.0-out-policer
               iso
so-2/1/0       up    down
...

```

### show interfaces policers interface-name

```

user@host> show interfaces policers so-2/1/0
Interface      Admin Link Proto Input Policer      Output Policer
so-2/1/0       up    down
so-2/1/0.0     up    down inet    so-2/1/0.0-in-policer  so-2/1/0.0-out-policer
               iso
               inet6

```

### show interfaces policers (PTX Series Packet Transport Switches)

```

user@host> show interfaces policers em0
Interface      Admin Link Proto Input Policer      Output Policer
em0            up    up
em0.0          up    up
               inet

```

## show interfaces queue

<b>Syntax</b>	<pre>show interfaces queue &lt;aggregate   remaining-traffic&gt; &lt;both-ingress-egress&gt; &lt;egress&gt; &lt;forwarding-class forwarding-class&gt; &lt;ingress&gt; &lt;interface-name interface-name&gt; &lt;l2-statistics&gt; &lt;remaining-traffic&gt;</pre>
<b>Release Information</b>	<p>Command introduced before Junos OS Release 7.4.</p> <p><b>both-ingress-egress</b>, <b>egress</b>, and <b>ingress</b> options introduced in Junos OS Release 7.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p> <p><b>l2-statistics</b> option introduced in Junos OS Release 12.1.</p>
<b>Description</b>	Display class-of-service (CoS) queue information for physical interfaces.
<b>Options</b>	<p><b>none</b>—Show detailed CoS queue statistics for all physical interfaces.</p> <p><b>aggregate</b>—(Optional) Display the aggregated queuing statistics of all logical interfaces that have traffic-control profiles configured. (Not on the QFX Series.)</p> <p><b>both-ingress-egress</b>—(Optional) On Gigabit Ethernet Intelligent Queuing 2 (IQ2) PICs, display both ingress and egress queue statistics. (Not on the QFX Series.)</p> <p><b>egress</b>—(Optional) Display egress queue statistics.</p> <p><b>forwarding-class forwarding-class</b>—(Optional) Forwarding class name for this queue. Shows detailed CoS statistics for the queue associated with the specified forwarding class.</p> <p><b>ingress</b>—(Optional) On Gigabit Ethernet IQ2 PICs, display ingress queue statistics. (Not on the QFX Series.)</p> <p><b>interface-name interface-name</b>—(Optional) Show detailed CoS queue statistics for the specified interface.</p> <p><b>l2-statistics</b>—(optional) Display layer 2 statistics for MLPPP, FRF.15, and FRF.16 bundles</p>
<b>Overhead for Layer 2 Statistics</b>	<p>Transmitted packets and transmitted byte counts are displayed for the layer 2 level with the addition of encapsulation overheads applied for fragmentation, as shown in <a href="#">Table 17 on page 70</a>. Others counters, such as packets and bytes queued (input) and drop counters, are displayed at the layer 3 level. In the case of link fragmentation and interleaving (LFI) for which not fragmentation is applied, corresponding layer 2 overheads are added, as shown in <a href="#">Table 17 on page 70</a>.</p>

Table 17: Layer 2 Overhead, Transmitted Packets/Bytes

Protocol	Fragmentation		LFI
	First fragmentation	Second to n fragmentations	
	Bytes	Bytes	
MLPPP (Long)	13	12	8
MLPPP (short)	11	10	8
MLFR (FRF15)	12	10	8
MFR (FRF16)	10	8	-
MCMLPPP(Long)	13	12	-
MCMLPPP(Short)	11	10	-



## Layer 2 Statistics - Fragmentation Overhead Calculation

### MLPPP/MC-MLPPP Overhead details:

=====

#### Fragment 1:

Outer PPP header	: 4 bytes
Long or short sequence MLPPP header	: 4 bytes or 2 bytes
Inner PPP header	: 1 byte
HDLC flag and FCS bytes	: 4 bytes

#### Fragments 2 .. n :

Outer PPP header	: 4 bytes
Long or short sequence MLPPP header	: 4 bytes or 2 bytes
HDLC flag and FCS bytes	: 4 bytes

### MLFR (FRF15) Overhead details:

=====

#### Fragment 1:

Framereelay header	: 2 bytes
Control,NLPID	: 2 bytes
Fragmentaion header	: 2 bytes
Inner proto	: 2 bytes
HDLC flag and FCS	: 4 bytes

#### Fragments 2 ...n :

Framereelay header	: 2 bytes
Control,NLPID	: 2 bytes
Fragmentaion header	: 2 bytes
HDLC flag and FCS	: 4 bytes

### MFR (FRF16) Overhead details:

=====

#### Fragment 1:

Fragmentaion header	: 2 bytes
Framereelay header	: 2 bytes
Inner proto	: 2 bytes
HDLC flag and FCS	: 4 bytes

#### Fragments 2 ...n :

Fragmentaion header	: 2 bytes
Framereelay header	: 2 bytes
HDLC flag and FCS	: 4 bytes

## Overhead with LFI

### MLPPP(Long & short sequence):

=====

Outer PPP header	: 4 bytes
HDLC flag and FCS	: 4 bytes

### MLFR (FRF15):

=====

Framereelay header	: 2 bytes
Control,NLPID	: 2 bytes
HDLC flag and FCS	: 4 bytes

The following examples show overhead for different cases:

- A 1000-byte packet is sent to a mlppp bundle without any fragmentation. At the layer 2 level, bytes transmitted is 1013 in 1 packet. This overhead is for MLPPP long sequence encap.
- A 1000-byte packet is sent to a mlppp bundle with a fragment threshold of 250byte. At the layer 2 level, bytes transmitted is 1061 bytes in 5 packets.
- A 1000-byte LFI packet is sent to an mlppp bundle. At the layer 2 level, bytes transmitted is 1008 in 1 packet.

**remaining-traffic**—(Optional) Display the queuing statistics of all logical interfaces that do not have traffic-control profiles configured. (Not on the QFX Series.)

**Additional Information** On M Series routers (except for the M320 and M120 routers), this command is valid only for a PIC installed on an enhanced Flexible PIC Concentrator (FPC).

Queue statistics for aggregated interfaces are supported on the M Series and T Series routers only. Statistics for an aggregated interface are the summation of the queue statistics of the child links of that aggregated interface. You can view the statistics for a child interface by using the **show interfaces statistics** command for that child interface.

When you configure tricolor marking on a 10-port 1-Gigabit Ethernet PIC, for queues 6 and 7 only, the output does not display the number of queued bytes and packets, or the number of bytes and packets dropped because of RED. If you do not configure tricolor marking on the interface, these statistics are available for all queues.

For the 4-port Channelized OC12 IQE PIC and 1-port Channelized OC48 IQE PIC, the **Packet Forwarding Engine Chassis Queues** field represents traffic bound for a particular physical interface on the PIC. For all other PICs, the **Packet Forwarding Engine Chassis Queues** field represents the total traffic bound for the PIC.

For Gigabit Ethernet IQ2 PICs, the **show interfaces queue** command output does not display the number of tail-dropped packets. This limitation does not apply to Packet Forwarding Engine chassis queues.

When fragmentation occurs on the egress interface, the first set of packet counters shows the postfragmentation values. The second set of packet counters (under the **Packet Forwarding Engine Chassis Queues** field) shows the prefragmentation values.

The behavior of the **egress** queues for the **Routing Engine-Generated Traffic** is not same as the configured queue for MLPPP and MFR configurations.

For information about how to configure CoS, see the Junos® OS Network Interfaces. For related CoS operational mode commands, see the Junos OS Operational Mode Commands.

**Required Privilege Level** view

**List of Sample Output** [show interfaces queue \(Aggregated Ethernet on a T320 Router\) on page 78](#)  
[show interfaces queue \(Fast Ethernet on a J4300 Router\) on page 79](#)

[show interfaces queue \(Gigabit Ethernet on a T640 Router\) on page 80](#)  
[show interfaces queue aggregate \(Gigabit Ethernet Enhanced DPC\) on page 80](#)  
[show interfaces queue \(Gigabit Ethernet IQ2 PIC\) on page 84](#)  
[show interfaces queue both-ingress-egress \(Gigabit Ethernet IQ2 PIC\) on page 87](#)  
[show interfaces queue ingress \(Gigabit Ethernet IQ2 PIC\) on page 90](#)  
[show interfaces queue egress \(Gigabit Ethernet IQ2 PIC\) on page 90](#)  
[show interfaces queue remaining-traffic \(Gigabit Ethernet Enhanced DPC\) on page 92](#)  
[show interfaces queue \(Channelized OC12 IQE Type 3 PIC in SONET Mode\) on page 95](#)  
[show interfaces queue \(QFX Series\) on page 105](#)  
[show interfaces queue l2-statistics \(lsq interface\) on page 106](#)

**Output Fields** [Table 18 on page 73](#) lists the output fields for the **show interfaces queue** command. Output fields are listed in the approximate order in which they appear.

**Table 18: show interfaces queue Output Fields**

Field Name	Field Description
Physical interface	Name of the physical interface.
Enabled	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .
Interface index	Physical interface's index number, which reflects its initialization sequence.
SNMP ifIndex	SNMP index number for the interface.
Forwarding classes supported	Total number of forwarding classes supported on the specified interface.
Forwarding classes in use	Total number of forwarding classes in use on the specified interface.
Ingress queues supported	On Gigabit Ethernet IQ2 PICs only, total number of ingress queues supported on the specified interface.
Ingress queues in use	On Gigabit Ethernet IQ2 PICs only, total number of ingress queues in use on the specified interface.
Output queues supported	Total number of output queues supported on the specified interface.
Output queues in use	Total number of output queues in use on the specified interface.
Egress queues supported	Total number of egress queues supported on the specified interface.
Egress queues in use	Total number of egress queues in use on the specified interface.
Queue	Queue number.

Table 18: show interfaces queue Output Fields (*continued*)

Field Name	Field Description
<b>Queue counters (Ingress)</b>	CoS queue number and its associated user-configured forwarding class name. Displayed on IQ2 interfaces. <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>
<b>Burst size</b>	(Logical interfaces on IQ PICs only) Maximum number of bytes up to which the logical interface can burst. The burst size is based on the shaping rate applied to the interface.
<b>Forwarding classes</b>	Forwarding class name.
<b>Queued Packets</b>	Number of packets queued to this queue.  <b>NOTE:</b> For Gigabit Ethernet IQ2 interfaces, the Queued Packets count is calculated by the Junos OS interpreting one frame buffer as one packet. If the queued packets are very large or very small, the calculation might not be completely accurate for transit traffic. The count is completely accurate for traffic terminated on the router.
<b>Queued Bytes</b>	Number of bytes queued to this queue. The byte counts vary by PIC type. For more information, see <a href="#">Table 19 on page 76</a> .
<b>Transmitted Packets</b>	Number of packets transmitted by this queue. When fragmentation occurs on the egress interface, the first set of packet counters shows the postfragmentation values. The second set of packet counters (displayed under the <b>Packet Forwarding Engine Chassis Queues</b> field) shows the prefragmentation values.  <b>NOTE:</b> For layer 2 statistics, see <a href="#">“Overhead for Layer 2 Statistics” on page 69</a>
<b>Transmitted Bytes</b>	Number of bytes transmitted by this queue. The byte counts vary by PIC type. For more information, see <a href="#">Table 19 on page 76</a> .  <b>NOTE:</b> On MX Series routers, this number can be inaccurate when you issue the command for a physical interface repeatedly and in quick succession, because the statistics for the child nodes are collected infrequently. Wait ten seconds between successive iterations to avoid this situation.  <b>NOTE:</b> For layer 2 statistics, see <a href="#">“Overhead for Layer 2 Statistics” on page 69</a>
<b>Tail-dropped packets</b>	Number of packets dropped because of tail drop.

Table 18: show interfaces queue Output Fields (*continued*)

Field Name	Field Description
RED-dropped packets	<p>Number of packets dropped because of random early detection (RED).</p> <ul style="list-style-type: none"> <li>(M Series and T Series routers only) On M320 and M120 routers and the T Series routers, the total number of dropped packets is displayed. On all other M Series routers, the output classifies dropped packets into the following categories: <ul style="list-style-type: none"> <li><b>Low, non-TCP</b>—Number of low-loss priority non-TCP packets dropped because of RED.</li> <li><b>Low, TCP</b>—Number of low-loss priority TCP packets dropped because of RED.</li> <li><b>High, non-TCP</b>—Number of high-loss priority non-TCP packets dropped because of RED.</li> <li><b>High, TCP</b>—Number of high-loss priority TCP packets dropped because of RED.</li> </ul> </li> <li>(J Series routers and MX Series routers with enhanced DPCs, and T Series routers with enhanced FPCs only) The output classifies dropped packets into the following categories: <ul style="list-style-type: none"> <li><b>Low</b>—Number of low-loss priority packets dropped because of RED.</li> <li><b>Medium-low</b>—Number of medium-low loss priority packets dropped because of RED.</li> <li><b>Medium-high</b>—Number of medium-high loss priority packets dropped because of RED.</li> <li><b>High</b>—Number of high-loss priority packets dropped because of RED.</li> </ul> </li> </ul>
RED-dropped bytes	<p>Number of bytes dropped because of RED. The byte counts vary by PIC type. For more information, see <a href="#">Table 19 on page 76</a>.</p> <ul style="list-style-type: none"> <li>(M Series and T Series routers only) On M320 and M120 routers and the T Series routers, only the total number of dropped bytes is displayed. On all other M Series routers, the output classifies dropped bytes into the following categories: <ul style="list-style-type: none"> <li><b>Low, non-TCP</b>—Number of low-loss priority non-TCP bytes dropped because of RED.</li> <li><b>Low, TCP</b>—Number of low-loss priority TCP bytes dropped because of RED.</li> <li><b>High, non-TCP</b>—Number of high-loss priority non-TCP bytes dropped because of RED.</li> <li><b>High, TCP</b>—Number of high-loss priority TCP bytes dropped because of RED.</li> </ul> </li> <li>(J Series routers only) The output classifies dropped bytes into the following categories: <ul style="list-style-type: none"> <li><b>Low</b>—Number of low-loss priority bytes dropped because of RED.</li> <li><b>Medium-low</b>—Number of medium-low loss priority bytes dropped because of RED.</li> <li><b>Medium-high</b>—Number of medium-high loss priority bytes dropped because of RED.</li> <li><b>High</b>—Number of high-loss priority bytes dropped because of RED.</li> </ul> </li> </ul>

Byte counts vary by PIC type. [Table 19 on page 76](#) shows how the byte counts on the outbound interfaces vary depending on the PIC type. [Table 19 on page 76](#) is based on the assumption that outbound interfaces are sending IP traffic with 478 bytes per packet.

Table 19: Byte Count by PIC Type

PIC Type	Output Level	Byte Count Includes	Comments
Gigabit Ethernet IQ and IQE PICs	Interface	<p>Queued: 490 bytes per packet, representing 478 bytes of Layer 3 packet + 12 bytes</p> <p>Transmitted: 490 bytes per packet, representing 478 bytes of Layer 3 packet + 12 bytes</p> <p>RED dropped: 496 bytes per packet representing 478 bytes of Layer 3 packet + 18 bytes</p>	<p>The 12 additional bytes include 6 bytes for the destination MAC address + 4 bytes for the VLAN + 2 bytes for the Ethernet type.</p> <p>For RED dropped, 6 bytes are added for the source MAC address.</p>
	Packet forwarding component	<p>Queued: 478 bytes per packet, representing 478 bytes of Layer 3 packet</p> <p>Transmitted: 478 bytes per packet, representing 478 bytes of Layer 3 packet</p>	—
Non-IQ PIC	Interface	<p>T Series, TX Series, T1600, and MX Series routers:</p> <ul style="list-style-type: none"> <li>• Queued: 478 bytes of Layer 3 packet.</li> <li>• Transmitted: 478 bytes of Layer 3 packet.</li> </ul> <p>T4000 routers with Type 5 FPCs :</p> <ul style="list-style-type: none"> <li>• Queued: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes CRC + the full Layer 1 overhead 8 bytes preamble + 12 bytes Inter frame Gap.</li> <li>• Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes CRC + the full Layer 1 overhead 8 bytes preamble + 12 bytes Interframe Gap.</li> </ul> <p>M Series routers:</p> <ul style="list-style-type: none"> <li>• Queued: 478 bytes of Layer 3 packet.</li> <li>• Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead.</li> </ul> <p>PTX Series Packet Transport Switches:</p> <ul style="list-style-type: none"> <li>• Queued: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes FCS + the full Layer 1 overhead of the MAC header DA + SA + EtherType (non-VLAN).</li> <li>• Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes CRC + the full Layer 1 overhead of the MAC header DA + SA + EtherType (non-VLAN).</li> <li>• RED dropped: 478 bytes of Layer 3 packet + 22 bytes special header. To the TQ, this packet has 4 bytes more than queued or transmitted.</li> </ul>	<p>The Layer 2 overhead is 14 bytes for non-VLAN traffic and 18 bytes for VLAN traffic.</p>

Table 19: Byte Count by PIC Type (*continued*)

PIC Type	Output Level	Byte Count Includes	Comments
IQ and IQE PICs with a SONET/SDH interface	Interface	<p>Queued: 482 bytes per packet, representing 478 bytes of Layer 3 packet + 4 bytes</p> <p>Transmitted: 482 bytes per packet, representing 478 bytes of Layer 3 packet + 4 bytes</p> <p>RED dropped: 482 bytes per packet, representing 478 bytes of Layer 3 packet + 4 bytes</p>	The additional 4 bytes are for the Layer 2 Point-to-Point Protocol (PPP) header.
	Packet forwarding component	<p>Queued: 478 bytes per packet, representing 478 bytes of Layer 3 packet</p> <p>Transmitted: 486 bytes per packet, representing 478 bytes of Layer 3 packet + 8 bytes</p>	For transmitted packets, the additional 8 bytes includes 4 bytes for the PPP header and 4 bytes for a cookie.
Non-IQ PIC with a SONET/SDH interface	Interface	<p>T Series, TX Series, T1600, and MX Series routers:</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet.</li> <li>Transmitted: 478 bytes of Layer 3 packet.</li> </ul> <p>M Series routers:</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet.</li> <li>Transmitted: 483 bytes per packet, representing 478 bytes of Layer 3 packet + 5 bytes</li> <li>RED dropped: 478 bytes per packet, representing 478 bytes of Layer 3 packet</li> </ul>	For transmitted packets, the additional 5 bytes includes 4 bytes for the PPP header and 1 byte for the packet loss priority (PLP).
Interfaces configured with Frame Relay Encapsulation	Interface	The default Frame Relay overhead is 7 bytes. If you configure the Frame Check Sequence (FCS) to 4 bytes, then the overhead increases to 10 bytes.	
1-port 10-Gigabit Ethernet IQ2 and IQ2-E PICs	Interface	<p>Queued: 478 bytes of Layer 3 packet + the full Layer 2 overhead including CRC.</p> <p>Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead including CRC.</p>	The Layer 2 overhead is 18 bytes for non-VLAN traffic and 22 bytes for VLAN traffic.
4-port 1G IQ2 and IQ2-E PICs	Packet forwarding component	Queued: 478 bytes of Layer 3 packet.	—
8-port 1G IQ2 and IQ2-E PICs		Transmitted: 478 bytes of Layer 3 packet.	

## Sample Output

**show interfaces queue**  
(Aggregated Ethernet  
on a T320 Router)

The following example shows that the aggregated Ethernet interface, **ae1**, has traffic on queues **af1** and **af12**:

```
user@host> show interfaces queue ae1
Physical interface: ae1, Enabled, Physical link is Up
Interface index: 158, SNMP ifIndex: 33 Forwarding classes: 8 supported, 8 in use
Output queues: 8 supported, 8 in use
Queue: 0, Forwarding classes: be
  Queued:
    Packets      :           5           0 pps
    Bytes        :          242           0 bps
  Transmitted:
    Packets      :           5           0 pps
    Bytes        :          242           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 1, Forwarding classes: af1
  Queued:
    Packets      :        42603765        595484 pps
    Bytes        :       5453281920       609776496 bps
  Transmitted:
    Packets      :        42603765        595484 pps
    Bytes        :       5453281920       609776496 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 2, Forwarding classes: ef1
  Queued:
    Packets      :           0           0 pps
    Bytes        :           0           0 bps
  Transmitted:
    Packets      :           0           0 pps
    Bytes        :           0           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 3, Forwarding classes: nc
  Queued:
    Packets      :           45           0 pps
    Bytes        :          3930           0 bps
  Transmitted:
    Packets      :           45           0 pps
    Bytes        :          3930           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 4, Forwarding classes: af11
  Queued:
    Packets      :           0           0 pps
    Bytes        :           0           0 bps
  Transmitted:
    Packets      :           0           0 pps
    Bytes        :           0           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 5, Forwarding classes: ef11
```



```

Queued:
  Packets      :      0      0 pps
  Bytes       :      0      0 bps
Transmitted:
  Packets      :      0      0 pps
  Bytes       :      0      0 bps
  Tail-dropped packets :      0      0 pps
  RED-dropped packets :      0      0 pps
  RED-dropped bytes  :      0      0 bps
Queue: 6, Forwarding classes: af12
Queued:
  Packets      :      31296413      437436 pps
  Bytes       :      4005940864      447935200 bps
Transmitted:
  Packets      :      31296413      437436 pps
  Bytes       :      4005940864      447935200 bps
  Tail-dropped packets :      0      0 pps
  RED-dropped packets :      0      0 pps
  RED-dropped bytes  :      0      0 bps
Queue: 7, Forwarding classes: nc2
Queued:
  Packets      :      0      0 pps
  Bytes       :      0      0 bps
Transmitted:
  Packets      :      0      0 pps
  Bytes       :      0      0 bps
  Tail-dropped packets :      0      0 pps
  RED-dropped packets :      0      0 pps
  RED-dropped bytes  :      0      0 bps

```

#### show interfaces queue (Fast Ethernet on a J4300 Router)

```

user@host> show interfaces queue fe-4/0/0.0
Logical interface fe-4/0/0.0 (Index 71) (SNMP ifIndex 42)
Forwarding classes: 8 supported, 8 in use
Output queues: 8 supported, 8 in use
Queue: 0, Forwarding classes: be
Queued:
  Packets      :      5240762      3404 pps
  Bytes       :      3020710354      15934544 bps
Transmitted:
  Packets      :      5240762      3404 pps
  Bytes       :      3020710354      15934544 bps
  Tail-dropped packets :      0      0 pps
  RED-dropped packets :      0      0 pps
  Low         :      0      0 pps
  Medium-low  :      0      0 pps
  Medium-high :      0      0 pps
  High        :      0      0 pps
  RED-dropped bytes  :      0      0 bps
  Low         :      0      0 pps
  Medium-low  :      0      0 pps
  Medium-high :      0      0 pps
  High        :      0      0 pps
Queue: 1, Forwarding classes: af1
Queued:
  Packets      :      2480391      1650 pps
  Bytes       :      1304685666      6945704 bps
Transmitted:
  Packets      :      2478740      1650 pps
  Bytes       :      1303817240      6945704 bps
  Tail-dropped packets :      0      0 pps
  RED-dropped packets :      1651      0 pps

```

Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	1651	0 pps
RED-dropped bytes	:	868426	0 bps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	868426	0 pps

### show interfaces queue (Gigabit Ethernet on a T640 Router)

```

user@host> show interfaces queue
Physical interface: ge-7/0/1, Enabled, Physical link is Up
Interface index: 150, SNMP ifIndex: 42
Forwarding classes: 8 supported, 8 in use
Output queues: 8 supported, 8 in use
Queue: 0, Forwarding classes: be
  Queued:
    Packets      :           13          0 pps
    Bytes        :          622          0 bps
  Transmitted:
    Packets      :           13          0 pps
    Bytes        :          622          0 bps
    Tail-dropped packets :           0          0 pps
    RED-dropped packets :           0          0 pps
    RED-dropped bytes  :           0          0 bps
Queue: 1, Forwarding classes: af1
  Queued:
    Packets      :      1725947945      372178 pps
    Bytes        :      220921336960    381110432 bps
  Transmitted:
    Packets      :      1725947945      372178 pps
    Bytes        :      220921336960    381110432 bps
    Tail-dropped packets :           0          0 pps
    RED-dropped packets :           0          0 pps
    RED-dropped bytes  :           0          0 bps
Queue: 2, Forwarding classes: ef1
  Queued:
    Packets      :           0          0 pps
    Bytes        :           0          0 bps
  Transmitted:
    Packets      :           0          0 pps
    Bytes        :           0          0 bps
    Tail-dropped packets :           0          0 pps
    RED-dropped packets :           0          0 pps
    RED-dropped bytes  :           0          0 bps
Queue: 3, Forwarding classes: nc
  Queued:
    Packets      :           571          0 pps
    Bytes        :          49318         336 bps
  Transmitted:
    Packets      :           571          0 pps
    Bytes        :          49318         336 bps
    Tail-dropped packets :           0          0 pps
    RED-dropped packets :           0          0 pps
    RED-dropped bytes  :           0          0 bps

```

### show interfaces queue aggregate (Gigabit

```

user@host> show interfaces queue ge-2/2/9 aggregate
Physical interface: ge-2/2/9, Enabled, Physical link is Up
Interface index: 238, SNMP ifIndex: 71

```

Ethernet Enhanced  
DPC)

```

Forwarding classes: 16 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      148450735      947295 pps
    Bytes        :      8016344944    409228848 bps
  Transmitted:
    Packets      :      76397439      487512 pps
    Bytes        :      4125461868    210602376 bps
  Tail-dropped packets : Not Available
  RED-dropped packets :      72053285      459783 pps
    Low          :      72053285      459783 pps
    Medium-low   :              0          0 pps
    Medium-high  :              0          0 pps
    High         :              0          0 pps
  RED-dropped bytes  :      3890877444    198626472 bps
    Low          :      3890877444    198626472 bps
    Medium-low   :              0          0 bps
    Medium-high  :              0          0 bps
    High         :              0          0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :              0          0 pps
    Bytes        :              0          0 bps
  Transmitted:
    Packets      :              0          0 pps
    Bytes        :              0          0 bps
  Tail-dropped packets : Not Available
  RED-dropped packets :              0          0 pps
    Low          :              0          0 pps
    Medium-low   :              0          0 pps
    Medium-high  :              0          0 pps
    High         :              0          0 pps
  RED-dropped bytes  :              0          0 bps
    Low          :              0          0 bps
    Medium-low   :              0          0 bps
    Medium-high  :              0          0 bps
    High         :              0          0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :      410278257      473940 pps
    Bytes        :      22156199518    204742296 bps
  Transmitted:
    Packets      :      4850003        4033 pps
    Bytes        :      261900162    1742256 bps
  Tail-dropped packets : Not Available
  RED-dropped packets :      405425693      469907 pps
    Low          :      405425693      469907 pps
    Medium-low   :              0          0 pps
    Medium-high  :              0          0 pps
    High         :              0          0 pps
  RED-dropped bytes  :      21892988124    203000040 bps
    Low          :      21892988124    203000040 bps
    Medium-low   :              0          0 bps
    Medium-high  :              0          0 bps
    High         :              0          0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      :              0          0 pps
    Bytes        :              0          0 bps
  Transmitted:

```

```

Packets          :          0          0 pps
Bytes            :          0          0 bps
Tail-dropped packets : Not Available
RED-dropped packets :          0          0 pps
  Low            :          0          0 pps
  Medium-low     :          0          0 pps
  Medium-high    :          0          0 pps
  High           :          0          0 pps
RED-dropped bytes  :          0          0 bps
  Low            :          0          0 bps
  Medium-low     :          0          0 bps
  Medium-high    :          0          0 bps
  High           :          0          0 bps
Forwarding classes: 16 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      76605230      485376 pps
    Bytes        :      5209211400    264044560 bps
  Transmitted:
    Packets      :      76444631      484336 pps
    Bytes        :      5198235612    263478800 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :      160475      1040 pps
      Low        :      160475      1040 pps
      Medium-low :          0          0 pps
      Medium-high:          0          0 pps
      High       :          0          0 pps
    RED-dropped bytes  :      10912300    565760 bps
      Low            :      10912300    565760 bps
      Medium-low     :          0          0 bps
      Medium-high    :          0          0 bps
      High           :          0          0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
  Transmitted:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
      Low        :          0          0 pps
      Medium-low :          0          0 pps
      Medium-high:          0          0 pps
      High       :          0          0 pps
    RED-dropped bytes  :          0          0 bps
      Low            :          0          0 bps
      Medium-low     :          0          0 bps
      Medium-high    :          0          0 bps
      High           :          0          0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :      4836136      3912 pps
    Bytes        :      333402032    2139056 bps
  Transmitted:
    Packets      :      3600866      1459 pps
    Bytes        :      244858888    793696 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :      1225034      2450 pps
      Low        :      1225034      2450 pps

```

```

Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 83302312 1333072 bps
Low             : 83302312 1333072 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Transmitted:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
Low             : 0 0 pps
Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps

```

#### Packet Forwarding Engine Chassis Queues:

Queues: 4 supported, 4 in use

Queue: 0, Forwarding classes: best-effort

```

Queued:
Packets         : 77059796 486384 pps
Bytes           : 3544750624 178989576 bps
Transmitted:
Packets         : 77059797 486381 pps
Bytes           : 3544750670 178988248 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets : 0 0 pps
Low             : 0 0 pps
Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps

```

Queue: 1, Forwarding classes: expedited-forwarding

```

Queued:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Transmitted:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets : 0 0 pps
Low             : 0 0 pps
Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps

```

```

        Low                :                0                0 bps
        Medium-low         :                0                0 bps
        Medium-high        :                0                0 bps
        High                :                0                0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
  Packets                  :            4846580            3934 pps
  Bytes                    :            222942680          1447768 bps
Transmitted:
  Packets                  :            4846580            3934 pps
  Bytes                    :            222942680          1447768 bps
  Tail-dropped packets    :                0                0 pps
  RED-dropped packets     :                0                0 pps
    Low                   :                0                0 pps
    Medium-low            :                0                0 pps
    Medium-high           :                0                0 pps
    High                  :                0                0 pps
  RED-dropped bytes       :                0                0 bps
    Low                   :                0                0 bps
    Medium-low            :                0                0 bps
    Medium-high           :                0                0 bps
    High                  :                0                0 bps
Queue: 3, Forwarding classes: network-control
Queued:
  Packets                  :                0                0 pps
  Bytes                    :                0                0 bps
Transmitted:
  Packets                  :                0                0 pps
  Bytes                    :                0                0 bps
  Tail-dropped packets    :                0                0 pps
  RED-dropped packets     :                0                0 pps
    Low                   :                0                0 pps
    Medium-low            :                0                0 pps
    Medium-high           :                0                0 pps
    High                  :                0                0 pps
  RED-dropped bytes       :                0                0 bps
    Low                   :                0                0 bps
    Medium-low            :                0                0 bps
    Medium-high           :                0                0 bps
    High                  :                0                0 bps

```

### show interfaces queue (Gigabit Ethernet IQ2 PIC)

```

user@host> show interfaces queue ge-7/1/3
Physical interface: ge-7/1/3, Enabled, Physical link is Up
Interface index: 170, SNMP ifIndex: 70 Forwarding classes: 16 supported, 4 in
use Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
Queued:
  Packets                  :            418390039            10 pps
  Bytes                    :            38910269752          7440 bps
Transmitted:
  Packets                  :            418390039            10 pps
  Bytes                    :            38910269752          7440 bps
  Tail-dropped packets    : Not Available
  RED-dropped packets     :                0                0 pps
  RED-dropped bytes       :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
  Packets                  :                0                0 pps
  Bytes                    :                0                0 bps
Transmitted:
  Packets                  :                0                0 pps

```

```

Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
Packets : 0 0 pps
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets : 7055 1 pps
Bytes : 451552 512 bps
Transmitted:
Packets : 7055 1 pps
Bytes : 451552 512 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Forwarding classes: 16 supported, 4 in use Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
Queued:
Packets : 1031 0 pps
Bytes : 143292 0 bps
Transmitted:
Packets : 1031 0 pps
Bytes : 143292 0 bps
Tail-dropped packets : Not Available
RL-dropped packets : 0 0 pps
RL-dropped bytes : 0 0 bps
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
Packets : 0 0 pps
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RL-dropped packets : 0 0 pps
RL-dropped bytes : 0 0 bps
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
Packets : 0 0 pps
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RL-dropped packets : 0 0 pps
RL-dropped bytes : 0 0 bps
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps

```

## Queue: 3, Forwarding classes: network-control

## Queued:

Packets	:	77009	11 pps
Bytes	:	6894286	7888 bps

## Transmitted:

Packets	:	77009	11 pps
Bytes	:	6894286	7888 bps

Tail-dropped packets : Not Available

RL-dropped packets	:	0	0 pps
RL-dropped bytes	:	0	0 bps
RED-dropped packets	:	0	0 pps
RED-dropped bytes	:	0	0 bps

## Packet Forwarding Engine Chassis Queues:

Queues: 4 supported, 4 in use

## Queue: 0, Forwarding classes: best-effort

## Queued:

Packets	:	1031	0 pps
Bytes	:	147328	0 bps

## Transmitted:

Packets	:	1031	0 pps
Bytes	:	147328	0 bps

Tail-dropped packets : 0 0 pps

RED-dropped packets : 0 0 pps

Low, non-TCP : 0 0 pps

Low, TCP : 0 0 pps

High, non-TCP : 0 0 pps

High, TCP : 0 0 pps

RED-dropped bytes : 0 0 bps

Low, non-TCP : 0 0 bps

Low, TCP : 0 0 bps

High, non-TCP : 0 0 bps

High, TCP : 0 0 bps

## Queue: 1, Forwarding classes: expedited-forwarding

## Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

## Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Tail-dropped packets : 0 0 pps

RED-dropped packets : 0 0 pps

Low, non-TCP : 0 0 pps

Low, TCP : 0 0 pps

High, non-TCP : 0 0 pps

High, TCP : 0 0 pps

RED-dropped bytes : 0 0 bps

Low, non-TCP : 0 0 bps

Low, TCP : 0 0 bps

High, non-TCP : 0 0 bps

High, TCP : 0 0 bps

## Queue: 2, Forwarding classes: assured-forwarding

## Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

## Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Tail-dropped packets : 0 0 pps

RED-dropped packets : 0 0 pps

Low, non-TCP : 0 0 pps



```

      Low, TCP           :           0           0 pps
      High, non-TCP      :           0           0 pps
      High, TCP          :           0           0 pps
      RED-dropped bytes  :           0           0 bps
      Low, non-TCP       :           0           0 bps
      Low, TCP           :           0           0 bps
      High, non-TCP      :           0           0 bps
      High, TCP          :           0           0 bps
Queue: 3, Forwarding classes: network-control
Queued:
  Packets               :           94386           12 pps
  Bytes                 :          13756799          9568 bps
Transmitted:
  Packets               :           94386           12 pps
  Bytes                 :          13756799          9568 bps
  Tail-dropped packets :           0           0 pps
  RED-dropped packets  :           0           0 pps
  Low, non-TCP         :           0           0 pps
  Low, TCP             :           0           0 pps
  High, non-TCP        :           0           0 pps
  High, TCP            :           0           0 pps
  RED-dropped bytes    :           0           0 bps
  Low, non-TCP         :           0           0 bps
  Low, TCP             :           0           0 bps
  High, non-TCP        :           0           0 bps
  High, TCP            :           0           0 bps

```

**show interfaces queue  
both-ingress-egress**

```

user@host> show interfaces queue ge-6/2/0 both-ingress-egress
Physical interface: ge-6/2/0, Enabled, Physical link is Up
Interface index: 175, SNMP ifIndex: 121

```

**(Gigabit Ethernet IQ2  
PIC)**

```

Forwarding classes: 8 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                254                0 pps
    Bytes        :            16274                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Forwarding classes: 8 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                3                0 pps
    Bytes        :            126                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps

```

```

Tail-dropped packets : Not Available
RED-dropped packets  : 0 0 pps
RED-dropped bytes    : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
  Packets      : Not Available
  Bytes        : 0 0 bps
Transmitted:
  Packets      : 0 0 pps
  Bytes        : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets  : 0 0 pps
RED-dropped bytes    : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
  Packets      : Not Available
  Bytes        : 0 0 bps
Transmitted:
  Packets      : 0 0 pps
  Bytes        : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets  : 0 0 pps
RED-dropped bytes    : 0 0 bps
Packet Forwarding Engine Chassis Queues:
Queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
Queued:
  Packets      : 80564692 0 pps
  Bytes        : 3383717100 0 bps
Transmitted:
  Packets      : 80564692 0 pps
  Bytes        : 3383717100 0 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets  : 0 0 pps
RED-dropped bytes    : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
  Packets      : 80564685 0 pps
  Bytes        : 3383716770 0 bps
Transmitted:
  Packets      : 80564685 0 pps
  Bytes        : 3383716770 0 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets  : 0 0 pps
RED-dropped bytes    : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
  Packets      : 0 0 pps
  Bytes        : 0 0 bps
Transmitted:
  Packets      : 0 0 pps
  Bytes        : 0 0 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets  : 0 0 pps
RED-dropped bytes    : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
  Packets      : 9397 0 pps
  Bytes        : 3809052 232 bps
Transmitted:
  Packets      : 9397 0 pps

```

```

Bytes          :          3809052          232 bps
Tail-dropped packets :          0          0 pps
RED-dropped packets :          0          0 pps
RED-dropped bytes  :          0          0 bps

```

# show interfaces queue ingress (Gigabit Ethernet IQ2 PIC)

```

user@host> show interfaces queue ge-6/2/0 ingress
Physical interface: ge-6/2/0, Enabled, Physical link is Up
Interface index: 175, SNMP ifIndex: 121
Forwarding classes: 8 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets          : Not Available
    Bytes            :          0          0 bps
  Transmitted:
    Packets          :          288          0 pps
    Bytes            :         18450          0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
    RED-dropped bytes  :          0          0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets          : Not Available
    Bytes            :          0          0 bps
  Transmitted:
    Packets          :          0          0 pps
    Bytes            :          0          0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
    RED-dropped bytes  :          0          0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets          : Not Available
    Bytes            :          0          0 bps
  Transmitted:
    Packets          :          0          0 pps
    Bytes            :          0          0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
    RED-dropped bytes  :          0          0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets          : Not Available
    Bytes            :          0          0 bps
  Transmitted:
    Packets          :          0          0 pps
    Bytes            :          0          0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
    RED-dropped bytes  :          0          0 bps

```

# show interfaces queue egress

```

user@host> show interfaces queue ge-6/2/0 egress
Physical interface: ge-6/2/0, Enabled, Physical link is Up
Interface index: 175, SNMP ifIndex: 121

```

(Gigabit Ethernet IQ2  
PIC)

```

Forwarding classes: 8 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                3                0 pps
    Bytes        :               126                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Packet Forwarding Engine Chassis Queues:
Queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :                80564692            0 pps
    Bytes        :               3383717100            0 bps
  Transmitted:
    Packets      :                80564692            0 pps
    Bytes        :               3383717100            0 bps
    Tail-dropped packets :                0            0 pps
    RED-dropped packets :                0            0 pps
    RED-dropped bytes  :                0            0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :                80564685            0 pps
    Bytes        :               3383716770            0 bps
  Transmitted:
    Packets      :                80564685            0 pps
    Bytes        :               3383716770            0 bps

```

```
Tail-dropped packets :          0          0 pps
RED-dropped packets  :          0          0 pps
RED-dropped bytes   :          0          0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
  Packets           :          0          0 pps
  Bytes             :          0          0 bps
Transmitted:
  Packets           :          0          0 pps
  Bytes             :          0          0 bps
  Tail-dropped packets :          0          0 pps
  RED-dropped packets :          0          0 pps
  RED-dropped bytes   :          0          0 bps
Queue: 3, Forwarding classes: network-control
Queued:
  Packets           :          9538        0 pps
  Bytes             :        3819840      0 bps
Transmitted:
  Packets           :          9538        0 pps
  Bytes             :        3819840      0 bps
  Tail-dropped packets :          0          0 pps
  RED-dropped packets :          0          0 pps
  RED-dropped bytes   :          0          0 bps
```

**show interfaces queue  
remaining-traffic**

```
user@host> show interfaces queue ge-2/2/9 remaining-traffic
Physical interface: ge-2/2/9, Enabled, Physical link is Up
Interface index: 238, SNMP ifIndex: 71
```

(Gigabit Ethernet  
Enhanced DPC)

```

Forwarding classes: 16 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      110208969      472875 pps
    Bytes        :      5951284434    204282000 bps
  Transmitted:
    Packets      :      110208969      472875 pps
    Bytes        :      5951284434    204282000 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :      0      0 pps
      Low          :      0      0 pps
      Medium-low   :      0      0 pps
      Medium-high  :      0      0 pps
      High         :      0      0 pps
    RED-dropped bytes  :      0      0 bps
      Low          :      0      0 bps
      Medium-low   :      0      0 bps
      Medium-high  :      0      0 bps
      High         :      0      0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
  Transmitted:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :      0      0 pps
      Low          :      0      0 pps
      Medium-low   :      0      0 pps
      Medium-high  :      0      0 pps
      High         :      0      0 pps
    RED-dropped bytes  :      0      0 bps
      Low          :      0      0 bps
      Medium-low   :      0      0 bps
      Medium-high  :      0      0 bps
      High         :      0      0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
  Transmitted:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :      0      0 pps
      Low          :      0      0 pps
      Medium-low   :      0      0 pps
      Medium-high  :      0      0 pps
      High         :      0      0 pps
    RED-dropped bytes  :      0      0 bps
      Low          :      0      0 bps
      Medium-low   :      0      0 bps
      Medium-high  :      0      0 bps
      High         :      0      0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
  Transmitted:

```

```

Packets          :          0          0 pps
Bytes            :          0          0 bps
Tail-dropped packets : Not Available
RED-dropped packets :          0          0 pps
  Low            :          0          0 pps
  Medium-low     :          0          0 pps
  Medium-high    :          0          0 pps
  High           :          0          0 pps
RED-dropped bytes :          0          0 bps
  Low            :          0          0 bps
  Medium-low     :          0          0 bps
  Medium-high    :          0          0 bps
  High           :          0          0 bps
Forwarding classes: 16 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      109355853      471736 pps
    Bytes        :      7436199152    256627968 bps
  Transmitted:
    Packets      :      109355852      471736 pps
    Bytes        :      7436198640    256627968 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
      Low        :          0          0 pps
      Medium-low :          0          0 pps
      Medium-high :          0          0 pps
      High       :          0          0 pps
    RED-dropped bytes :          0          0 bps
      Low        :          0          0 bps
      Medium-low :          0          0 bps
      Medium-high :          0          0 bps
      High       :          0          0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
  Transmitted:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
      Low        :          0          0 pps
      Medium-low :          0          0 pps
      Medium-high :          0          0 pps
      High       :          0          0 pps
    RED-dropped bytes :          0          0 bps
      Low        :          0          0 bps
      Medium-low :          0          0 bps
      Medium-high :          0          0 bps
      High       :          0          0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
  Transmitted:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :          0          0 pps
      Low        :          0          0 pps

```



```

Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Transmitted:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
Low             : 0 0 pps
Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps

```

`show interfaces queue`  
 (Channelized OC12 IQE

```

user@host> show interfaces queue t3-1/1/0:7
Physical interface: t3-1/1/0:7, Enabled, Physical link is Up

```

## Type 3 PIC in SONET Mode)

Interface index: 192, SNMP ifIndex: 1948

Description: full T3 interface connect to 6ce13 t3-3/1/0:7 for FR testing - Lam

Forwarding classes: 16 supported, 9 in use

Egress queues: 8 supported, 8 in use

Queue: 0, Forwarding classes: DEFAULT

## Queued:

Packets : 214886 13449 pps

Bytes : 9884756 5164536 bps

## Transmitted:

Packets : 214886 13449 pps

Bytes : 9884756 5164536 bps

Tail-dropped packets : 0 0 pps

RED-dropped packets : 0 0 pps

Low : 0 0 pps

Medium-low : 0 0 pps

Medium-high : 0 0 pps

High : 0 0 pps

RED-dropped bytes : 0 0 bps

Low : 0 0 bps

Medium-low : 0 0 bps

Medium-high : 0 0 bps

High : 0 0 bps

Queue: 1, Forwarding classes: REALTIME

## Queued:

Packets : 0 0 pps

Bytes : 0 0 bps

## Transmitted:

Packets : 0 0 pps

Bytes : 0 0 bps

Tail-dropped packets : 0 0 pps

RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 2, Forwarding classes: PRIVATE

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 3, Forwarding classes: CONTROL

Queued:

Packets	:	60	0 pps
---------	---	----	-------

Bytes	:	4560	0 bps
Transmitted:			
Packets	:	60	0 pps
Bytes	:	4560	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps
Queue: 4, Forwarding classes: CLASS_B_OUTPUT			
Queued:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Transmitted:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps

Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 5, Forwarding classes: CLASS\_C\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 6, Forwarding classes: CLASS\_V\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps

Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 7, Forwarding classes: CLASS\_S\_OUTPUT, GETS

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Packet Forwarding Engine Chassis Queues:

Queues: 8 supported, 8 in use

Queue: 0, Forwarding classes: DEFAULT

## Queued:

Packets	:	371365	23620 pps
Bytes	:	15597330	7936368 bps

## Transmitted:

Packets	:	371365	23620 pps
Bytes	:	15597330	7936368 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

## Queue: 1, Forwarding classes: REALTIME

## Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

## Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps

Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 2, Forwarding classes: PRIVATE

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 3, Forwarding classes: CONTROL

Queued:

Packets	:	32843	0 pps
Bytes	:	2641754	56 bps

Transmitted:

Packets	:	32843	0 pps
Bytes	:	2641754	56 bps
Tail-dropped packets	:	0	0 pps



RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 4, Forwarding classes: CLASS\_B\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 5, Forwarding classes: CLASS\_C\_OUTPUT

Queued:

Packets	:	0	0 pps
---------	---	---	-------

Bytes	:	0	0 bps
Transmitted:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps
Queue: 6, Forwarding classes: CLASS_V_OUTPUT			
Queued:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Transmitted:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps

```

Medium-low      :                0                0 bps
Medium-high     :                0                0 bps
High            :                0                0 bps
Queue: 7, Forwarding classes: CLASS_S_OUTPUT, GETS
Queued:
Packets         :                0                0 pps
Bytes           :                0                0 bps
Transmitted:
Packets         :                0                0 pps
Bytes           :                0                0 bps
Tail-dropped packets :                0                0 pps
RED-dropped packets :                0                0 pps
Low             :                0                0 pps
Medium-low      :                0                0 pps
Medium-high     :                0                0 pps
High            :                0                0 pps
RED-dropped bytes :                0                0 bps
Low             :                0                0 bps
Medium-low      :                0                0 bps
Medium-high     :                0                0 bps
High            :                0                0 bps

```

### show interfaces queue (QFX Series)

```

user@switch> show interfaces queue xe-0/0/15
Physical interface: xe-0/0/15, Enabled, Physical link is Up
Interface index: 49165, SNMP ifIndex: 539
Forwarding classes: 12 supported, 8 in use
Egress queues: 12 supported, 8 in use
Queue: 0, Forwarding classes: best-effort
Queued:
Packets         :                0                0 pps
Bytes           :                0                0 bps
Transmitted:
Packets         :                0                0 pps
Bytes           :                0                0 bps
Tail-dropped packets : Not Available
Total-dropped packets:                0                0 pps
Total-dropped bytes :                0                0 bps
Queue: 3, Forwarding classes: fcoe
Queued:
Packets         :                0                0 pps

```

```

        Bytes           :           0           0 bps
    Transmitted:
        Packets         :           0           0 pps
        Bytes           :           0           0 bps
        Tail-dropped packets : Not Available
        Total-dropped packets:           0           0 pps
        Total-dropped bytes :           0           0 bps
0 bps
Queue: 4, Forwarding classes: no-loss
Queued:
    Packets           :           0           0 pps
    Bytes             :           0           0 bps
Transmitted:
    Packets           :           0           0 pps
    Bytes             :           0           0 bps
    Tail-dropped packets : Not Available
    Total-dropped packets:           0           0 pps
    Total-dropped bytes :           0           0 bps
Queue: 7, Forwarding classes: network-control
Queued:
    Packets           :           0           0 pps
    Bytes             :           0           0 bps
Transmitted:
    Packets           :           0           0 pps
    Bytes             :           0           0 bps
    Tail-dropped packets : Not Available
    Total-dropped packets:           0           0 pps
    Total-dropped bytes :           0           0 bps
Queue: 8, Forwarding classes: mcast
Queued:
    Packets           :           0           0 pps
    Bytes             :           0           0 bps
Transmitted:
    Packets           :           0           0 pps
    Bytes             :           0           0 bps
    Tail-dropped packets : Not Available
    Total-dropped packets:           0           0 pps
    Total-dropped bytes :           0           0 bps

```

#### show interfaces queue l2-statistics (lsq interface)

```

user@switch> show interfaces queue lsq-2/2/0.2 l2-statistics
Logical interface lsq-2/2/0.2 (Index 69) (SNMP ifIndex 1598)
Forwarding classes: 16 supported, 4 in use
Egress queues: 8 supported, 4 in use
Burst size: 0
Queue: 0, Forwarding classes: be
Queued:
    Packets           :           1           0 pps
    Bytes             :          1001           0 bps
Transmitted:
    Packets           :           5           0 pps
    Bytes             :          1062           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 1, Forwarding classes: ef
Queued:
    Packets           :           1           0 pps
    Bytes             :          1500           0 bps
Transmitted:
    Packets           :           6           0 pps
    Bytes             :          1573           0 bps

```

```
Tail-dropped packets :          0          0 pps
RED-dropped packets  :          0          0 pps
RED-dropped bytes    :          0          0 bps
Queue: 2, Forwarding classes: af
  Queued:
    Packets          :          1          0 pps
    Bytes            :         512          0 bps
  Transmitted:
    Packets          :          3          0 pps
    Bytes            :         549          0 bps
    Tail-dropped packets :          0          0 pps
    RED-dropped packets :          0          0 pps
    RED-dropped bytes  :          0          0 bps
Queue: 3, Forwarding classes: nc
  Queued:
    Packets          :          0          0 pps
    Bytes            :          0          0 bps
  Transmitted:
    Packets          :          0          0 pps
    Bytes            :          0          0 bps
    Tail-dropped packets :          0          0 pps
    RED-dropped packets :          0          0 pps
    RED-dropped bytes  :          0          0 bps
=====
```

## show interfaces routing

<b>Syntax</b>	show interfaces routing <brief   detail> <interface-name> <logical-system (all   <i>logical-system-name</i> )>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display the state of the router's interfaces. Use this command for performing router diagnostics only, when you are determining whether the routing protocols and the Junos OS differ about the state of an interface.
<b>Options</b>	<p><b>none</b>—Display standard information about the state of all router interfaces on all logical systems.</p> <p><b>brief   detail</b>—(Optional) Display the specified level of output.</p> <p><b>interface-name</b>—(Optional) Name of a specific interface.</p> <p><b>logical-system (all   <i>logical-system-name</i>)</b>—(Optional) Perform this operation on all logical systems or on a particular logical system.</p>
<b>Additional Information</b>	For information about how to configure routing protocols, see the Junos OS Routing Protocols Configuration Guide. For information about related operational mode commands for routing instances and protocols, see the Junos OS Operational Mode Commands.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces routing brief on page 110</a> <a href="#">show interfaces routing brief (TX Matrix Plus Router) on page 110</a> <a href="#">show interfaces routing detail on page 111</a> <a href="#">show interfaces routing detail (TX Matrix Plus Router) on page 111</a>
<b>Output Fields</b>	<a href="#">Table 20 on page 108</a> lists the output fields for the <b>show interfaces routing</b> command. Output fields are listed in the approximate order in which they appear.

**Table 20: show interfaces routing Output Fields**

Field Name	Field Description	Level of Output
<b>Interface</b>	Name of the physical interface.	none <b>brief</b>
<b>State</b>	State of the physical interface: <b>Up</b> or <b>Down</b> .	none <b>brief</b>
<b>Addresses</b>	Protocols and addresses configured on the interface.	none <b>brief</b>
<b>Index</b>	Interface index number, which reflects its initialization sequence.	<b>detail</b>

Table 20: show interfaces routing Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Refcount</b>	Number of references to the interface in the routing software.	<b>detail</b>
<b>State</b>	State ( <b>Up</b> or <b>Down</b> ) and type of interface.	<b>detail</b>
<b>Change</b>	Reflects one or more of the following recent changes to the interface: <ul style="list-style-type: none"> <li>• <b>Add</b>—The interface was just added.</li> <li>• <b>Address</b>—The interface's link-layer address has changed.</li> <li>• <b>Delete</b>—The interface is being deleted.</li> <li>• <b>Encapsulation</b>—The type of encapsulation on the interface has changed.</li> <li>• <b>Metric</b>—The interface's metric value has changed.</li> <li>• <b>MTU</b>—The interface's maximim transmission unit size has changed.</li> <li>• <b>UpDown</b>—The interface has made an up or down transition.</li> </ul>	<b>detail</b>
<b>Up/down transitions</b>	Number of times the interface has gone from <b>Down</b> to <b>Up</b> .	<b>detail</b>
<b>Link layer</b>	Describes the link layer of the interface.	<b>detail</b>
<b>Encapsulation</b>	Encapsulation on the interface.	<b>detail</b>
<b>Bandwidth</b>	Speed at which the interface is running.	<b>detail</b>
<b>Protocol address</b>	Information about the configuration of protocols on the interface: <ul style="list-style-type: none"> <li>• <b>Address</b>—Address configured on the interface for the protocol type.</li> <li>• <b>State</b>—State (<b>Up</b> or <b>down</b>) and type of interface.</li> <li>• <b>Change</b>—Reflects one or more of the following recent changes to the interface: <ul style="list-style-type: none"> <li>• <b>Add</b>—The interface was just added.</li> <li>• <b>Address</b>—The interface's address has changed.</li> <li>• <b>Broadcast</b>—The interface's broadcast address has changed.</li> <li>• <b>Delete</b>—The interface is being deleted.</li> <li>• <b>Netmask</b>—The interface's netmask has changed.</li> <li>• <b>UpDown</b>—The interface has made an up or down transition.</li> </ul> </li> <li>• <b>Preference</b>—Preference value for the route for this address.</li> <li>• <b>Metric</b>—Metric value on the interface for the protocol type.</li> <li>• <b>MTU</b>—Maximim transmission unit value of the interface.</li> <li>• <b>Local address</b>—On a point-to-point link, the address of the local side of the link. Not used for multicast links.</li> <li>• <b>Destination</b>—For a point-to-point link, the address of the remote side of the link. For multicast links, the network address.</li> </ul>	<b>detail</b>

## Sample Output

### show interfaces routing brief

```

user@host> show interfaces routing brief
Interface      State Addresses
so-5/0/3.0     Down  ISO    enabled
so-5/0/2.0     Up    MPLS   enabled
               ISO    enabled
               INET   192.168.2.120
               INET   enabled
so-5/0/1.0     Up    MPLS   enabled
               ISO    enabled
               INET   192.168.2.130
               INET   enabled
at-1/0/0.3     Up    CCC    enabled
at-1/0/0.2     Up    CCC    enabled
at-1/0/0.0     Up    ISO    enabled
               INET   192.168.90.10
               INET   enabled
lo0.0          Up    ISO    47.0005.80ff.f800.0000.0108.0001.1921.6800.5061.00
               ISO    enabled
               INET   127.0.0.1
fxp1.0         Up
fxp0.0         Up    INET   192.168.6.90

```

### show interfaces routing brief (TX Matrix Plus Router)

```

user@host> show interfaces routing brief
Interface      State Addresses
...
ge-23/0/4.0    Up    INET   2.9.1.1
               ISO    enabled
               MPLS   enabled
ge-23/0/3.0    Up    INET   2.8.1.1
               ISO    enabled
               MPLS   enabled
ge-23/0/2.0    Up    INET   2.7.1.1
               ISO    enabled
               MPLS   enabled
ge-23/0/1.0    Up    INET   2.6.1.1
               ISO    enabled
               MPLS   enabled
ge-23/0/0.0    Up    INET   2.5.1.1
               ISO    enabled
               MPLS   enabled
ge-31/0/7.599  Up    INET   2.14.10.93
ge-31/0/7.598  Up    INET   2.14.10.89
ge-31/0/7.597  Up    INET   2.14.10.85
ge-31/0/7.596  Up    INET   2.14.10.81
ge-31/0/7.595  Up    INET   2.14.10.77
ge-31/0/7.594  Up    INET   2.14.10.73
...
ixgbe1.0       Up    INET   10.34.0.4
               INET   162.0.0.4
               INET6   fe80::200:1ff:fe22:4
               INET6   fec0::a:22:0:4
ixgbe0.0       Up    INET   10.34.0.4
               INET   162.0.0.4
               INET6   fe80::200:ff:fe22:4
               INET6   fec0::a:22:0:4
em0.0          Up    INET   192.168.178.11

```



## show interfaces routing detail

```

user@host> show interfaces routing detail
so-5/0/3.0
  Index: 15, Refcount: 2, State: Up <Broadcast PointToPoint Multicast> Change:<>

  Metric: 0, Up/down transitions: 0, Full-duplex
  Link layer: HDLC serial line Encapsulation: PPP Bandwidth: 155Mbps
  ISO address (null)
    State: <Broadcast PointToPoint Multicast> Change: <>
    Preference: 0 (120 down), Metric: 0, MTU: 4470 bytes
so-5/0/2.0
  Index: 14, Refcount: 7, State: <Up Broadcast PointToPoint Multicast> Change:<>

  Metric: 0, Up/down transitions: 0, Full-duplex
  Link layer: HDLC serial line Encapsulation: PPP Bandwidth: 155Mbps
  MPLS address (null)
    State: <Up Broadcast PointToPoint Multicast> Change: <>
    Preference: 0 (120 down), Metric: 0, MTU: 4458 bytes
  ISO address (null)
    State: <Up Broadcast PointToPoint Multicast> Change: <>
    Preference: 0 (120 down), Metric: 0, MTU: 4470 bytes
  INET address 192.168.2.120
    State: <Up Broadcast PointToPoint Multicast Localup> Change: <>
    Preference: 0 (120 down), Metric: 0, MTU: 4470 bytes
    Local address: 192.168.2.120
    Destination: 192.168.2.110/32
  INET address (null)
    State: <Up Broadcast PointToPoint Multicast> Change: <>
    Preference: 0 (120 down), Metric: 0, MTU: 4470 bytes
...

```

## show interfaces routing detail (TX Matrix Plus Router)

```

user@host> show interfaces routing detail
ge-23/0/4.0
  Index: 77, Refcount: 5, State: <Up Broadcast Multicast> Change: <>
  0 metric, 0 up/down transitions, reth state 0, full-duplex
  Link layer: Ethernet Encapsulation: Ethernet Bandwidth: 1000Mbps
  Link address #0 0.1d.b5.14.da.2d
  INET address 2.9.1.1
    State: <Up Broadcast Multicast Localup> Change: <> Flags: <RT-Change>
    Preference 0, metric 0, MTU 1500 bytes
    Broadcast address 2.9.1.3
    Destination: 2.9.1.0/30
    System flags: <Is-Preferred Is-Primary>
  ISO address (null)
    State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
    Preference 0, metric 0, MTU 1497 bytes
    System flags: <>
  MPLS address (null)
    State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
    Preference 0, metric 0, MTU 1488 bytes
    System flags: <>
ge-23/0/3.0
  Index: 76, Refcount: 5, State: <Up Broadcast Multicast> Change: <>
  0 metric, 0 up/down transitions, reth state 0, full-duplex
  Link layer: Ethernet Encapsulation: Ethernet Bandwidth: 1000Mbps
  Link address #0 0.1d.b5.14.da.2c
  INET address 2.8.1.1
    State: <Up Broadcast Multicast Localup> Change: <> Flags: <RT-Change>
    Preference 0, metric 0, MTU 1500 bytes
    Broadcast address 2.8.1.3
    Destination: 2.8.1.0/30

```

```

    System flags: <Is-Preferred Is-Primary>
ISO address (null)
    State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
    Preference 0, metric 0, MTU 1497 bytes
    System flags: <>
MPLS address (null)
    State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
    Preference 0, metric 0, MTU 1488 bytes
    System flags: <>
ge-23/0/2.0
    Index: 75, Refcount: 5, State: <Up Broadcast Multicast> Change: <>
    0 metric, 0 up/down transitions, reth state 0, full-duplex
    Link layer: Ethernet Encapsulation: Ethernet Bandwidth: 1000Mbps
    Link address #0 0.1d.b5.14.da.2b
    INET address 2.7.1.1
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <RT-Change>
        Preference 0, metric 0, MTU 1500 bytes
        Broadcast address 2.7.1.3
        Destination: 2.7.1.0/30
        System flags: <Is-Preferred Is-Primary>
    ISO address (null)
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1497 bytes
        System flags: <>
    MPLS address (null)
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1488 bytes
        System flags: <>
ge-23/0/1.0
    Index: 74, Refcount: 5, State: <Up Broadcast Multicast> Change: <>
    0 metric, 0 up/down transitions, reth state 0, full-duplex
    Link layer: Ethernet Encapsulation: Ethernet Bandwidth: 1000Mbps
    Link address #0 0.1d.b5.14.da.2a
    INET address 2.6.1.1
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <RT-Change>
        Preference 0, metric 0, MTU 1500 bytes
        Broadcast address 2.6.1.3
    ...
ixgbe1.0
    Index: 5, Refcount: 5, State: <Up Broadcast Multicast> Change: <>
    0 metric, 0 up/down transitions, reth state 0, full-duplex
    Link layer: Ethernet Encapsulation: Ethernet Bandwidth: 1000Mbps
    Link address #0 2.0.1.22.0.4
    INET address 10.34.0.4
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Broadcast address 10.255.255.255
        Destination: 10.0.0.0/8
        System flags: <Is-Preferred>
    INET address 162.0.0.4
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Broadcast address 191.255.255.255
        Destination: 128.0.0.0/2
        System flags: <Primary Is-Preferred Is-Primary>
    INET6 address fe80::200:1ff:fe22:4
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Destination: fe80::/64
        System flags: <Is-Preferred>
    INET6 address fec0::a:22:0:4

```

```

    State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
    Preference 0, metric 0, MTU 1500 bytes
    Destination: fec0::/64
    System flags: <Is-Preferred Is-Primary>
ixgbe0.0
    Index: 4, Refcount: 5, State: <Up Broadcast Multicast> Change: <>
    0 metric, 0 up/down transitions, reth state 0, full-duplex
    Link layer: Ethernet Encapsulation: Ethernet Bandwidth: 1000Mbps
    Link address #0 2.0.0.22.0.4
    INET address 10.34.0.4
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Broadcast address 10.255.255.255
        Destination: 10.0.0.0/8
        System flags: <Is-Preferred>
    INET address 162.0.0.4
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Broadcast address 191.255.255.255
        Destination: 128.0.0.0/2
        System flags: <Primary Is-Default Is-Preferred Is-Primary>
    INET6 address fe80::200:ff:fe22:4
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Destination: fe80::/64
        System flags: <Is-Preferred>
    INET6 address fec0::a:22:0:4
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Destination: fec0::/64
        System flags: <Is-Default Is-Preferred Is-Primary>
em0.0
    Index: 3, Refcount: 2, State: <Up Broadcast Multicast> Change: <>
    0 metric, 0 up/down transitions, reth state 0, full-duplex
    Link layer: Ethernet Encapsulation: Ethernet Bandwidth: 100Mbps
    Link address #0 0.80.f9.26.0.c0
    INET address 192.168.178.11
        State: <Up Broadcast Multicast Localup> Change: <> Flags: <>
        Preference 0, metric 0, MTU 1500 bytes
        Broadcast address 192.168.178.127
        Destination: 192.168.178.0/25
        System flags: <Is-Preferred Is-Primary>

```

## show interfaces routing summary

<b>Syntax</b>	show interfaces routing summary <interface-name> <logical-system (all   logical-system-name)>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 12.1 for PTX Series Packet Transport Switches.
<b>Description</b>	Display a summary of the state of the router interfaces. Use this command for performing router diagnostics only, when you are determining whether the routing protocols and the Junos OS differ about the state of an interface.
<b>Options</b>	<b>none</b> —Display summary information about the state of all router interfaces on all logical systems.  <b>interface-name</b> —(Optional) Name of a specific interface.  <b>logical-system (all   logical-system-name)</b> —(Optional) Perform this operation on all logical systems or on a particular logical system.
<b>Additional Information</b>	For information about how to configure routing protocols, see the Junos OS Routing Protocols Configuration Guide. For information about related operational mode commands for routing instances and protocols, see the Junos OS Operational Mode Commands.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces routing summary on page 116</a> <a href="#">show interfaces routing summary (TX Matrix Plus Router) on page 116</a> <a href="#">show interfaces routing summary (PTX5000 Packet Transport Switches) on page 116</a>
<b>Output Fields</b>	<a href="#">Table 21 on page 114</a> lists the output fields for the <b>show interfaces routing summary</b> command. Output fields are listed in the approximate order in which they appear.

**Table 21: show interfaces routing summary Output Fields**

Field Name	Field Description
<b>n physical interfaces</b>	Number of routing interfaces and number of interfaces in the <b>up</b> state.
<b>n protocol protocol interfaces</b>	Type and number of routing protocols and number of related interfaces in the <b>up</b> state.
<b>Interface</b>	Logical interface name.
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.

Table 21: show interfaces routing summary Output Fields (*continued*)

Field Name	Field Description
<b>Metric</b>	Metric value for the interface.
<b>Trans</b>	Number of times the interface has transitioned from <b>Down</b> to <b>Up</b> .
<b>Status</b>	Interface status ( <b>Up</b> or <b>Down</b> ) and type.

## Sample Output

### show interfaces routing summary

```

user@host> show interfaces routing summary
14 physical interfaces (12 up)
  11 INET protocol addresses (11 up)
  6 ISO protocol addresses (4 up)
  3 MPLS protocol addresses (3 up)
  3 CCC protocol addresses (3 up)
Interface  Index    Metric  Trans. Status
so-5/0/3.0  15        0        0 Broadcast PointToPoint Multicast
so-5/0/2.0  14        0        0 Up Broadcast PointToPoint Multicast
so-5/0/1.0  13        0        5 Up Broadcast PointToPoint Multicast
so-5/0/0.0  12        0        2 Up Broadcast PointToPoint Multicast
so-1/2/0.0  11        0        0 Broadcast PointToPoint Multicast
so-1/1/0.0  10        0        5 Up Broadcast PointToPoint Multicast
at-1/0/0.6   9         0        0 Up Broadcast PointToPoint Multicast
at-1/0/0.5   8         0        0 Up Broadcast PointToPoint Multicast
at-1/0/0.4   7         0        0 Up Broadcast PointToPoint Multicast
at-1/0/0.3   6         0        0 Up Broadcast PointToPoint Multicast
at-1/0/0.2   5         0        0 Up Broadcast PointToPoint Multicast
at-1/0/0.0   4         0        0 Up Broadcast PointToPoint Multicast
lo0.0        3         0        0 Up Broadcast Loopback Multicast
fxp1.0       2         0        1 Up Broadcast Multicast
fxp0.0       1         0        0 Up Broadcast Multicast

```

### show interfaces routing summary (TX Matrix Plus Router)

```

user@host> show interfaces routing summary
9 physical interfaces (9 up)
  11 INET protocol addresses (11 up)
  6 MPLS protocol addresses (6 up)
  4 INET6 protocol addresses (4 up)

Interface          Index    Metric  Trans. Status
ge-23/0/8.0        73        0        0 Up Broadcast Multicast
ge-23/0/7.0        72        0        0 Up Broadcast Multicast
ge-23/0/6.0        71        0        0 Up Broadcast Multicast
ge-7/0/9.0         69        0        0 Up Broadcast Multicast
ge-15/0/9.0        70        0        0 Up Broadcast Multicast
xe-6/1/1.0         68        0        0 Up Broadcast Multicast
lo0.16385          66        0        0 Up Broadcast Loopback Multicast
lo0.16384          65        0        0 Up Broadcast Loopback Multicast
lo0.0              64        0        0 Up Broadcast Loopback Multicast
ixgbe1.0           5         0        0 Up Broadcast Multicast
ixgbe0.0           4         0        0 Up Broadcast Multicast
em0.0              3         0        0 Up Broadcast Multicast

```

### show interfaces routing summary

```

user@host> show interfaces routing summary
7 physical interfaces (68 up)
  7 INET protocol addresses (7 up)

```

(PTX5000 Packet  
Transport Switches)

2 CCC protocol addresses (2 up)  
4 INET6 protocol addresses (4 up)

Interface	Index	Metric	Trans. Status
lo0.16385	66	0	0 Up Broadcast Loopback Multicast
lo0.16384	64	0	0 Up Broadcast Loopback Multicast
lo0.0	65	0	0 Up Broadcast Loopback Multicast
ixgbe1.0	5	0	0 Up Broadcast Multicast
ixgbe0.0	4	0	0 Up Broadcast Multicast
et-5/0/5.32767	72	0	0 Up Broadcast Multicast
et-5/0/5.0	68	0	0 Up Broadcast Multicast
et-5/0/0.32767	67	0	0 Up Broadcast Multicast
et-5/0/0.0	71	0	0 Up Broadcast Multicast
em0.0	3	0	0 Up Broadcast Multicast

## show interfaces routing-instance

---

<b>Syntax</b>	show interfaces routing-instance ( <i>instance-name</i>   all)
<b>Release Information</b>	Command introduced in Junos OS Release 9.1.
<b>Description</b>	Display information about the interfaces configured for either a specific routing instance or for all of the routing instances.
<b>Options</b>	<p><b>all</b>—Display information about all of the interfaces configured for all of the routing instances on the router.</p> <p><b><i>instance-name</i></b>—Display information about the interfaces configured for the specified routing instance.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces routing-instance terse on page 119</a></p> <p><a href="#">show interfaces routing-instance all on page 119</a></p> <p><a href="#">show interfaces routing-instance extensive on page 119</a></p>
<b>Output Fields</b>	The output fields from the <b>show interfaces routing-instance</b> command are identical to those produced by the <b>show interfaces <i>interface-name</i></b> command. For a description of output fields, see the other chapters in this manual.



## Sample Output

```

show interfaces routing-instance terse
user@host> show interfaces routing-instance sample terse
Interface Admin Link Proto Local Remote
ge-0/0/0.0 up up inet 192.168.4.28/24

```

## Sample Output

```

show interfaces routing-instance all
user@host> show interfaces terse routing-instance all
Interface Admin Link Proto Local Remote Instance
at-0/0/1 up up inet 10.0.0.1/24
ge-0/0/0.0 up up inet 192.168.4.28/24 sample-a
at-0/1/0.0 up up inet6 fe80::a:0:0:4/64 sample-b
so-0/0/0.0 up up inet 10.0.0.1/32

```

```

show interfaces routing-instance extensive
user@host> show interfaces fe-0/1/3 routing-instance instance2 extensive
Logical interface fe-0/1/3.0 (Index 70) (SNMP ifIndex 53) (Generation 211)
Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
  Input bytes : 0
  Output bytes : 42
  Input packets: 0
  Output packets: 1
IPv6 transit statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:
  Input bytes : 0
  Output bytes : 42
  Input packets: 0
  Output packets: 1
Transit statistics:
  Input bytes : 0 0 bps
  Output bytes : 0 0 bps
  Input packets: 0 0 pps
  Output packets: 0 0 pps
IPv6 transit statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Protocol inet, MTU: 1500, Generation: 252, Route table: 4
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: 150.1.1/24, Local: 150.1.1.1, Broadcast: 150.1.1.255,
Generation: 263

```

## show interfaces snmp-index

---

<b>Syntax</b>	<code>show interfaces snmp-index <i>snmp-index</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display information for the interface with the specified SNMP index.
<b>Options</b>	This command has no options.
<b>Additional Information</b>	Output from both the <code>show interfaces <i>interface-name</i> detail</code> and the <code>show interfaces <i>interface-name</i> extensive</code> command includes all the information displayed in the output from the <code>show interfaces snmp-index</code> command.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces snmp-index on page 120</a>
<b>Output Fields</b>	The output fields from the <code>show interfaces snmp-index <i>snmp-index</i></code> command are identical to those produced by the <code>show interfaces <i>interface-name</i></code> command. For a description of output fields, see the other chapters in this manual.

## Sample Output

### show interfaces snmp-index

```
user@host> show interfaces snmp-index 33
Physical interface: so-2/1/1, Enabled, Physical link is Down
  Interface index: 149, SNMP ifIndex: 33
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SONET mode, Speed: 0C48,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running Down
  Interface flags: Hardware-Down Point-To-Point SNMP-Traps 16384
  Link flags     : Keepalives
  CoS queues    : 8 supported
  Last flapped  : 2005-06-15 11:45:57 PDT (05:38:43 ago)
  Input rate    : 0 bps (0 pps)
  Output rate   : 0 bps (0 pps)
  SONET alarms  : LOL, PLL, LOS
  SONET defects : LOL, PLL, LOF, LOS, SEF, AIS-L, AIS-P
```

## show interfaces source-class

<b>Syntax</b>	<code>show interfaces source-class</code> (all   <i>destination-class-name</i> <i>logical-interface-name</i> )
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. all option introduced in Junos OS Release 8.0.
<b>Description</b>	Display information about interfaces grouped by source class.
<b>Options</b>	<p><b>all</b>—Display information about all configured source classes.</p> <p><b>source-class-name</b>—Name of a logical grouping of prefixes that count packets having the source address matching those prefixes.</p> <p><b>interface-name</b>—Name of a logical interface.</p>
<b>Additional Information</b>	For interfaces that carry IPv4, IPv6, or Multiprotocol Label Switching (MPLS) traffic, you can maintain packet counts based on the entry and exit points for traffic passing through your network. Entry and exit points are identified by source and destination prefixes grouped into sets defined as source classes and destination classes. For more information, see the Junos® OS Network Interfaces.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces source-class all on page 122</a>
<b>Output Fields</b>	<a href="#">Table 22 on page 121</a> lists the output fields for the <b>show interfaces source-class</b> command. Output fields are listed in the approximate order in which they appear.

**Table 22: show interfaces source-class Output Fields**

Field Name	Field Description
<b>Logical interface</b>	Name of the logical interface.
<b>Source class</b>	Source class usage (SCU) counters per class for this interface.
<b>Packets</b>	Packets going to designated user-selected prefixes.
<b>Bytes</b>	Bytes going to designated user-selected prefixes.

## Sample Output

**show interfaces**  
**source-class all**

user@host> **show interfaces source-class all**

Logical interface .local..1

Logical interface .local..2

Logical interface fxp0.0

Logical interface fxp1.0

Logical interface lo0.16384

Logical interface lo0.16385

Logical interface lo0.0

Logical interface .local..3

Logical interface .local..4

Logical interface .local..5

Logical interface .local..6

Logical interface .local..7

Logical interface .local..8

Logical interface .local..9

Logical interface .local..10

Logical interface lo0.3

Logical interface pfh-0/0/0.16383

Logical interface fe-0/1/0.0

Logical interface fe-0/1/1.0

Protocol inet

Source class	Packets (packet-per-second)	Bytes (bits-per-second)
GOLD1	0	0
(	0)	0)
GOLD2	0	0
(	0)	0)
GOLD3	0	0
(	0)	0)
v4-src	0	0
(	0)	0)

Protocol inet6

Source class	Packets (packet-per-second)	Bytes (bits-per-second)
GOLD1	0	0
(	0)	0)
GOLD2	0	0
(	0)	0)

GOLD3	0	0
(	0) (	0)
v4-src	0	0
(	0) (	0)

Logical interface fe-0/1/2.0  
Description: CE1-to-PE2

Logical interface ge-0/3/0.0  
Description: CE1-to-PE1

Logical interface ge-0/3/2.0  
Description: CE2-to-PE1

Logical interface pc-0/3/0.16383

Logical interface lt-1/2/0.3  
Description: LS3->LS2

Logical interface lt-1/2/0.5  
Description: LS3->LS1

Logical interface sp-1/2/0.16383

## show interfaces statistics

---

<b>Syntax</b>	<code>show interfaces statistics <i>interface-name</i> &lt;detail&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 12.1 for PTX Series Packet Transport Switches. Command introduced in Junos OS Release 12.2 for ACX Series Routers.
<b>Description</b>	Display static interface statistics, such as errors.
<b>Options</b>	<i>interface-name</i> —Name of an interface.  <b>detail</b> —(Optional) Display detailed output.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">clear interfaces statistics on page 28</a></li></ul>
<b>List of Sample Output</b>	<a href="#">show interfaces statistics (Fast Ethernet) on page 125</a> <a href="#">show interfaces statistics (Gigabit Ethernet PIC—Egress) on page 125</a> <a href="#">show interfaces statistics detail (Aggregated Ethernet) on page 127</a> <a href="#">show interfaces statistics detail (Aggregated Ethernet—Ingress) on page 128</a> <a href="#">show interfaces statistics detail (Aggregated Ethernet—Egress) on page 130</a> <a href="#">show interfaces statistics (SONET/SDH) on page 132</a> <a href="#">show interfaces statistics (Aggregated SONET/SDH—Ingress) on page 133</a> <a href="#">show interfaces statistics (Aggregated SONET/SDH—Egress) on page 134</a> <a href="#">show interfaces statistics (PTX Series Packet Transport Switches) on page 135</a> <a href="#">show interfaces statistics (ACX Series routers) on page 136</a>
<b>Output Fields</b>	Output from both the <code>show interfaces <i>interface-name</i> detail</code> and the <code>show interfaces <i>interface-name</i> extensive</code> commands include all the information displayed in the output from the <code>show interfaces statistics</code> command. For more information, see the particular interface type in which you are interested. For information about destination class and source class statistics, see the “Destination Class Field” section and the “Source Class Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141. For information about the input errors and output errors, see Fast Ethernet and Gigabit Ethernet Counters.

## Sample Output

**show interfaces  
statistics  
(Fast Ethernet)**

```
user@host> show interfaces fe-1/3/1 statistics
Physical interface: fe-1/3/1, Enabled, Physical link is Up
Interface index: 144, SNMP ifIndex: 1042
Description: ford fe-1/3/1
Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
CoS queues     : 4 supported, 4 maximum usable queues
Current address: 00:90:69:93:04:dc, Hardware address: 00:90:69:93:04:dc
Last flapped   : 2006-04-18 03:08:59 PDT (00:01:24 ago)
Statistics last cleared: Never
Input rate      : 0 bps (0 pps)
Output rate     : 0 bps (0 pps)
Input errors: 0, Output errors: 0
Active alarms   : None
Active defects  : None
Logical interface fe-1/3/1.0 (Index 69) (SNMP ifIndex 50)
Flags: SNMP-Traps Encapsulation: ENET2
Protocol inet, MTU: 1500
  Flags: Is-Primary, DCU, SCU-in

      Destination class      Packets      Bytes
                             (packet-per-second) (bits-per-second)
      silver1                 0              0
      (                       0) (
      silver2                 0              0
      (                       0) (
      silver3                 0              0
      (                       0) (
Addresses, Flags: Is-Default Is-Preferred Is-Primary
  Destination: 10.27.245/24, Local: 10.27.245.2,
  Broadcast: 10.27.245.255
Protocol iso, MTU: 1497
  Flags: Is-Primary
```

**show interfaces  
statistics**

```
user@host> show interfaces ge-5/2/0 statistics detail
Physical interface: ge-5/2/0, Enabled, Physical link is Up
Interface index: 146, SNMP ifIndex: 519, Generation: 149
```

(Gigabit Ethernet  
PIC—Egress)

```

Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, BPDU Error: None,
MAC-REWRITE Error: None, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
Remote fault: Online
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : None
CoS queues     : 8 supported, 8 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:1d:b5:61:d9:74, Hardware address: 00:1d:b5:61:d9:74
Last flapped   : 2009-11-11 11:24:00 PST (09:23:08 ago)
Statistics last cleared: 2009-11-11 17:50:58 PST (02:56:10 ago)
Traffic statistics:
Input bytes   :          271524          0 bps
Output bytes  :        37769598        352 bps
Input packets :          3664          0 pps
Output packets:        885790          0 pps
IPv6 transit statistics:
Input bytes   :              0
Output bytes  :        16681118
Input packets :              0
Output packets:        362633
Multicast statistics:
IPv4 multicast statistics:
Input bytes   :        112048          0 bps
Output bytes  :       20779920          0 bps
Input packets :         1801          0 pps
Output packets:       519498          0 pps
IPv6 multicast statistics:
Input bytes   :        156500          0 bps
Output bytes  :       16681118          0 bps
Input packets :         1818          0 pps
Output packets:       362633          0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0, L2 channel errors: 0,
L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0,
Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort          882558          882558          0

1 expedited-fo          0              0              0

2 assured-forw          0              0              0

3 network-cont         3232          3232          0

Active alarms : None
Active defects : None

Logical interface ge-5/2/0.0 (Index 71) (SNMP ifIndex 573) (Generation 135)
Flags: SNMP-Traps 0x4000 Encapsulation: ENET2
Egress accounting overhead: 100
Ingress accounting overhead: 90
Traffic statistics:
Input bytes   :          271524

```



```

Output bytes :          37769598
Input packets:           3664
Output packets:         885790
IPv6 transit statistics:
  Input bytes :           0
  Output bytes :        16681118
  Input packets:           0
  Output packets:       362633
Local statistics:
  Input bytes :          271524
  Output bytes :        308560
  Input packets:          3664
  Output packets:        3659
Transit statistics:
  Input bytes :           0
  Output bytes :       37461038
  Input packets:           0
  Output packets:       882131
IPv6 transit statistics:
  Input bytes :           0
  Output bytes :       16681118
  Input packets:           0
  Output packets:       362633
Multicast statistics:
  IPv4 multicast statistics:
    Input bytes :         112048
    Output bytes :       20779920
    Input packets:         1801
    Output packets:       519498
  IPv6 multicast statistics:
    Input bytes :         156500
    Output bytes :       16681118
    Input packets:         1818
    Output packets:       362633
Protocol inet, MTU: 1500, Generation: 151, Route table: 0
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 40.40.40.0/30, Local: 40.40.40.2, Broadcast: 40.40.40.3,
Generation: 167
Protocol inet6, MTU: 1500, Generation: 152, Route table: 0
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: ::40.40.40.0/126, Local: ::40.40.40.2
Generation: 169
  Addresses, Flags: Is-Preferred
    Destination: fe80::/64, Local: fe80::21d:b5ff:fe61:d974
Protocol multiservice, MTU: Unlimited, Generation: 171
Generation: 153, Route table: 0
  Policer: Input: __default_arp_policer__

```

### show interfaces statistics detail (Aggregated Ethernet)

```

user@host> show interfaces ae0 detail
Physical interface: ae0, Enabled, Physical link is Up
Interface index: 186, SNMP ifIndex: 111, Generation: 187
Link-level type: Ethernet, MTU: 1514, Speed: 2000mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1,
Minimum bandwidth needed: 0
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Current address: 00:90:69:0b:2f:f0, Hardware address: 00:90:69:0b:2f:f0
Last flapped : Never
Statistics last cleared: 2006-12-23 03:04:16 PST (01:16:24 ago)
Traffic statistics:

```

```

Input bytes :                28544                0 bps
Output bytes :                39770                0 bps
Input packets:                508                  0 pps
Output packets:              509                  0 pps
Input bytes :                IPv6 28544
Output bytes :                IPv6 0
Input packets:              IPv6 508
Output packets:              IPv6 0
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
  Resource errors: 0

Logical interface ae0.0 (Index 67) (SNMP ifIndex 139) (Generation 145)
Flags: SNMP-Traps Encapsulation: ENET2
Statistics          Packets          pps          Bytes          bps
Bundle:
  Input :           508              0          28544          0
  Output:           509              0          35698          0
Link:
  ge-3/3/8.0
    Input :           508              0          28544          0
    Output:            0              0              0          0
  ge-3/3/9.0
    Input :            0              0              0          0
    Output:            0              0              0          0
Marker Statistics:  Marker Rx      Resp Tx      Unknown Rx      Illegal Rx
  ge-3/3/8.0          0          0          0          0
  ge-3/3/9.0          0          0          0          0
Egress queues: 8 supported, 8 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort                0                0                0
1 expedited-fo                0                0                0
2 assured-forw                0                0                0
3 network-cont                0                0                0

Protocol inet, MTU: 1500, Generation: 166, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 10.1.1/24, Local: 10.1.1.1, Broadcast: 10.1.1.255,
  Generation: 159
Protocol inet6, MTU: 1500, Generation: 163, Route table: 0
Flags: Is-Primary
Addresses, Flags: Is-Preferred
  Destination: fe80::/64, Local: fe80::206:5bff:fe05:c321,
  Broadcast: Unspecified, Generation: 161

```

## show interfaces statistics detail

```

user@host> show interfaces statistics detail ae0 | no-more
Physical interface: ae0, Enabled, Physical link is Up
Interface index: 128, SNMP ifIndex: 504, Generation: 278

```

(Aggregated  
Ethernet—Ingress)

```

Link-level type: Ethernet, MTU: 1514, Speed: 1Gbps, BPDU Error: None, MAC-REWRITE
Error: None, Loopback: Disabled,
Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1,
Minimum bandwidth needed: 0
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Current address: 00:1d:b5:61:db:f0, Hardware address: 00:1d:b5:61:db:f0
Last flapped : 2009-11-09 03:30:23 PST (00:01:28 ago)
Statistics last cleared: 2009-11-09 03:26:18 PST (00:05:33 ago)
Traffic statistics:
Input bytes :          544009602          54761856 bps
Output bytes :           3396           0 bps
Input packets:        11826292        148809 pps
Output packets:           42           0 pps
IPv6 transit statistics:
Input bytes :          350818604
Output bytes :           0
Input packets:        7626488
Output packets:           0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0
Ingress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort          0              0              0
1 expedited-fo         0              0              0
2 assured-forw         0              0              0
3 network-cont         0              0              0

Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort          21             21             0
1 expedited-fo         0              0              0
2 assured-forw         0              0              0
3 network-cont         451            451            0

Logical interface ae0.0 (Index 70) (SNMP ifIndex 574) (Generation 177)
Flags: SNMP-Traps 0x4000 Encapsulation: ENET2
Statistics      Packets      pps      Bytes      bps
Bundle:
Input :        11826292    148809    544009602    54761856
Output:         42         0         3396         0
Link:
ge-5/2/0.0
Input :        11826292    148809    544009602    54761856
Output:         42         0         3396         0
Marker Statistics:  Marker Rx      Resp Tx      Unknown Rx      Illegal Rx
ge-5/2/0.0          0          0          0          0
Protocol inet, MTU: 1500, Generation: 236, Route table: 0

```

```
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 30.30.30.0/30, Local: 30.30.30.2, Broadcast: 30.30.30.3,
Generation: 310
Protocol inet6, MTU: 1500, Generation: 237, Route table: 0
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: ::30.30.30.0/126, Local: ::30.30.30.2
Generation: 312
  Addresses, Flags: Is-Preferred
    Destination: fe80::/64, Local: fe80::21d:b5ff:fe61:dbf0
Protocol multiservice, MTU: Unlimited, Generation: 314
Generation: 238, Route table: 0
  Policer: Input: __default_arp_policer__
```

**show interfaces**  
**statistics detail**

```
user@host> show interfaces statistics detail ae0 | no-more
Physical interface: ae0, Enabled, Physical link is Up
Interface index: 128, SNMP ifIndex: 501, Generation: 319
```

(Aggregated  
Ethernet—Egress)

```

Link-level type: Ethernet, MTU: 1514, Speed: 1Gbps, BPDU Error: None, MAC-REWRITE
Error: None, Loopback: Disabled,
Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1,
Minimum bandwidth needed: 0
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Current address: 00:1f:12:c2:37:f0, Hardware address: 00:1f:12:c2:37:f0
Last flapped : 2009-11-09 03:30:24 PST (00:02:42 ago)
Statistics last cleared: 2009-11-09 03:26:42 PST (00:06:24 ago)
Traffic statistics:
Input bytes :                440                0 bps
Output bytes :            1047338120            54635848 bps
Input packets:                 7                0 pps
Output packets:          22768200          148466 pps
IPv6 transit statistics:
Input bytes :                288
Output bytes :            723202616
Input packets:                 4
Output packets:          15721796
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0
Ingress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort                0                0                0
1 expedited-fo                0                0                0
2 assured-forw                0                0                0
3 network-cont                0                0                0

Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort          201985796          201985796                0
1 expedited-fo                0                0                0
2 assured-forw                0                0                0
3 network-cont           65                65                0

Logical interface ae0.0 (Index 72) (SNMP ifIndex 505) (Generation 204)
Flags: SNMP-Traps 0x4000 Encapsulation: ENET2
Statistics      Packets      pps      Bytes      bps
Bundle:
Input :          7          0          440          0
Output:        22768200        148466        1047338120        54635848
Link:
ge-2/1/6.0
Input :          7          0          440          0
Output:        22768200        148466        1047338120        54635848
Marker Statistics:  Marker Rx      Resp Tx      Unknown Rx      Illegal Rx
ge-2/1/6.0          0          0          0          0
Protocol inet, MTU: 1500, Generation: 291, Route table: 0

```

```

    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 30.30.30.0/30, Local: 30.30.30.1, Broadcast: 30.30.30.3,
Generation: 420
    Protocol inet6, MTU: 1500, Generation: 292, Route table: 0
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: ::/26, Local: ::30.30.30.1
Generation: 422
    Addresses, Flags: Is-Preferred
      Destination: fe80::/64, Local: fe80::21f:12ff:fec2:37f0
    Protocol multiservice, MTU: Unlimited, Generation: 424
    Generation: 293, Route table: 0
    Policer: Input: __default_arp_policer__

```

### show interfaces statistics (SONET/SDH)

```

user@host> show interfaces statistics detail so-3/0/0 | no-more
Physical interface: so-3/0/0, Enabled, Physical link is Up
Interface index: 133, SNMP ifIndex: 538, Generation: 283
Link-level type: PPP, MTU: 4474, Clocking: Internal, SONET mode, Speed: OC192,
Loopback: None, FCS: 16, Payload scrambler: Enabled
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives
Hold-times     : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 13 (last seen 00:00:04 ago)
  Output: 14 (last sent 00:00:02 ago)
LCP state: Opened
NCP state: inet: Opened, inet6: Opened, iso: Not-configured, mp1s: Not-configured

CHAP state: Closed
PAP state: Closed
CoS queues   : 8 supported, 8 maximum usable queues
Last flapped : 2009-11-09 02:52:34 PST (01:12:39 ago)
Statistics last cleared: 2009-11-09 03:58:54 PST (00:06:19 ago)
Traffic statistics:
Input bytes   :          2559160294          54761720 bps
Output bytes  :           10640          48 bps
Input packets:          55633975          148809 pps
Output packets:           216           0 pps
IPv6 transit statistics:
Input bytes   :          647922328
Output bytes  :           0
Input packets:          14085269
Output packets:           0
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Bucket drops:
0, Policed discards: 0, L3 incompletes: 0,
  L2 channel errors: 0, L2 mismatch timeouts: 0, HS link CRC errors: 0, HS link
FIFO overflows: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0, HS link FIFO
underflows: 0, MTU errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:
  Queued packets  Transmitted packets  Dropped packets

  0 best-effort          4              4              0
  1 expedited-fo         0              0              0
  2 assured-forw         0              0              0

```

```

3 network-cont                213                213                0

```

```

SONET alarms   : None
SONET defects  : None

```

```

Logical interface so-3/0/0.0 (Index 72) (SNMP ifIndex 578) (Generation 182)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  Protocol inet, MTU: 4470, Generation: 244, Route table: 0
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 30.30.30.0/30, Local: 30.30.30.2, Broadcast: 30.30.30.3,
Generation: 322
    Protocol inet6, MTU: 4470, Generation: 245, Route table: 0
      Addresses, Flags: Is-Preferred Is-Primary
        Destination: ::30.30.30.0/126, Local: ::30.30.30.2
Generation: 324
      Addresses, Flags: Is-Preferred
        Destination: fe80::/64, Local: fe80::2a0:a5ff:fe61:9264
Generation: 326

```

#### show interfaces statistics (Aggregated SONET/SDH—Ingress)

```

user@host> show interfaces statistics detail as0 | no-more
Physical interface: as0, Enabled, Physical link is Up
  Interface index: 132, SNMP ifIndex: 534, Generation: 282
  Link-level type: PPP, MTU: 4474, Speed: OC192, Minimum links needed: 1, Minimum
bandwidth needed: 0
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Last flapped   : 2009-11-09 03:45:53 PST (00:09:38 ago)
  Statistics last cleared: 2009-11-09 03:48:17 PST (00:07:14 ago)
  Traffic statistics:
    Input bytes   :          2969786332          54761688 bps
    Output bytes  :           11601          0 bps
    Input packets :          64560636          148808 pps
    Output packets:           225          0 pps
  IPv6 transit statistics:
    Input bytes   :          2086013152
    Output bytes  :           0
    Input packets :          45348114
    Output packets:           0
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0
  Egress queues: 8 supported, 4 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort          3              3              0

    1 expedited-fo         0              0              0

    2 assured-forw         0              0              0

    3 network-cont        222            222            0

```

```

Logical interface as0.0 (Index 71) (SNMP ifIndex 576) (Generation 179)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  Statistics      Packets      pps      Bytes      bps

```

```

Bundle:
  Input :      64560550      148808      2969785300      54761688
  Output:      139          0          10344          0
Link:
  so-3/0/0.0
  Input :      64560550      148808      2969785300      54761688
  Output:      139          0          10344          0
Protocol inet, MTU: 4470, Generation: 240, Route table: 0
Addresses, Flags: Is-Preferred Is-Primary
Destination: 30.30.30.0/30, Local: 30.30.30.2, Broadcast: 30.30.30.3,
Generation: 316
Protocol inet6, MTU: 4470, Generation: 241, Route table: 0
Addresses, Flags: Is-Preferred Is-Primary
Destination: ::30.30.30.0/126, Local: ::30.30.30.2
Generation: 318
Addresses, Flags: Is-Preferred
Destination: fe80::/64, Local: fe80::2a0:a5ff:fe61:9264
Generation: 320

```

### show interfaces statistics (Aggregated SONET/SDH—Egress)

```

user@host> show interfaces statistics detail as0 | no-more
Physical interface: as0, Enabled, Physical link is Up
Interface index: 132, SNMP ifIndex: 565, Generation: 323
Link-level type: PPP, MTU: 4474, Speed: OC192, Minimum links needed: 1, Minimum
bandwidth needed: 0
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : Keepalives
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Last flapped   : 2009-11-09 03:43:37 PST (00:12:48 ago)
Statistics last cleared: 2009-11-09 03:48:54 PST (00:07:31 ago)
Traffic statistics:
Input bytes :      11198      392 bps
Output bytes :    3101452132    54783448 bps
Input packets:      234      0 pps
Output packets:    67422937    148868 pps
IPv6 transit statistics:
Input bytes :      5780
Output bytes :    2171015678
Input packets:      72
Output packets:    47195993
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort      67422830      67422830      0

1 expedited-fo      0      0      0

2 assured-forw      0      0      0

3 network-cont      90      90      0

Logical interface as0.0 (Index 71) (SNMP ifIndex 548) (Generation 206)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
Statistics      Packets      pps      Bytes      bps

```



```

Bundle:
  Input :          144          0          10118          392
  Output:        67422847        148868        3101450962        54783448
Link:
  so-0/1/0.0
  Input :          144          0          10118          392
  Output:        67422847        148868        3101450962        54783448
Protocol inet, MTU: 4470, Generation: 295, Route table: 0
  Addresses, Flags: Is-Preferred Is-Primary
  Destination: 30.30.30.0/30, Local: 30.30.30.1, Broadcast: 30.30.30.3,
Generation: 426
Protocol inet6, MTU: 4470, Generation: 296, Route table: 0
  Addresses, Flags: Is-Preferred Is-Primary
  Destination: ::/26, Local: ::30.30.30.1
Generation: 428
  Addresses, Flags: Is-Preferred
  Destination: fe80::/64, Local: fe80::2a0:a5ff:fe63:1d0a
Generation: 429

```

**show interfaces**  
**statistics (PTX Series)**

```

user@host> show interfaces statistics em0
Physical interface: em0, Enabled, Physical link is Up
Interface index: 8, SNMP ifIndex: 0

```

## Packet Transport Switches)

```

Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Speed: 1000Mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Current address: 00:80:f9:25:00:1b, Hardware address: 00:80:f9:25:00:1b
Last flapped   : Never
Statistics last cleared: Never
Input packets  : 212620
Output packets: 71
Input errors: 0, Output errors: 0

Logical interface em0.0 (Index 3) (SNMP ifIndex 0)
Flags: SNMP-Traps Encapsulation: ENET2
Input packets  : 212590
Output packets: 71
Protocol inet, MTU: 1500
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: 192.168.3/24, Local: 192.168.3.30,
Broadcast: 192.168.3.255

```

## show interfaces statistics (ACX Series routers)

```

user@host> show interfaces statistics ge-0/1/7
Physical interface: ge-0/1/7, Enabled, Physical link is Down
Interface index: 151, SNMP ifIndex: 524
Link-level type: Ethernet, Media type: Copper, MTU: 1514, Link-mode: Full-duplex,
Speed: 1000Mbps, BPDU Error: None, MAC-REWRITE Error: None, Loopback: Disabled,

Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
Remote fault: Online
Device flags   : Present Running Down
Interface flags: Hardware-Down SNMP-Traps Internal: 0x0
Link flags     : None
CoS queues     : 8 supported, 8 maximum usable queues
Current address: 84:18:88:c1:49:a3, Hardware address: 84:18:88:c1:49:a3
Last flapped   : 2012-05-11 04:25:28 PDT (2d 20:23 ago)
Statistics last cleared: 2012-05-13 23:07:23 PDT (01:41:25 ago)
Input rate     : 0 bps (0 pps)
Output rate    : 0 bps (0 pps)
Input errors: 0, Output errors: 0
Active alarms  : LINK
Active defects : LINK
Interface transmit statistics: Disabled

```

## show interfaces terse

<b>Syntax</b>	show interfaces terse
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Command introduced on PTX Series Packet Transport Switches for Junos OS Release 12.1.
<b>Description</b>	Display summary information about interfaces.
<b>Options</b>	This command has no options.
<b>Additional Information</b>	Interfaces are always displayed in numerical order, from the lowest to the highest FPC slot number. Within that slot, the lowest PIC slot is shown first. On an individual PIC, the lowest port number is always first.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Examples: Configuring Logical System Interfaces</li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces terse on page 138</a> <a href="#">show interfaces terse (TX Matrix Plus Router) on page 138</a> <a href="#">show interfaces terse (PTX Series Packet Transport Switches) on page 139</a>
<b>Output Fields</b>	Table 23 on page 137 lists the output fields for the <b>show interfaces terse</b> command. Output fields are listed in the approximate order in which they appear.

**Table 23: show interfaces terse Output Fields**

Field Name	Field Description
<b>Interface</b>	Interface name.
<b>Admin</b>	Whether the interface is turned on (up) or off (down).
<b>Link</b>	Link state: <b>up</b> or <b>down</b> .
<b>Proto</b>	Protocol family configured on the logical interface. A logical interface on a router that supports Ethernet OAM always shows the multiservice protocol.
<b>Local</b>	Local IP address of the logical interface.
<b>Remote</b>	Remote IP address of the logical interface.

## Sample Output

```

show interfaces terse user@host> show interfaces terse
Interface           Admin Link Proto  Local          Remote
t1-0/1/0:0          up   up
t1-0/1/0:0.0        up   up   inet   192.168.220.18/30
t1-0/1/0:1          up   up
t1-0/1/0:2          up   up
t1-0/1/0:3          up   up
at-1/0/0            up   up
at-1/0/1            up   up
dsc                 up   up
fxp0               up   up
fxp0.0             up   up   inet   192.168.71.249/21
fxp1               up   up
fxp1.0             up   up   inet   10.0.0.4/8
                    tnp   4
gre                up   up
ipip               up   up
lo0               up   up
lo0.0             up   up   inet   10.0.1.4        --> 0/0
                    127.0.0.1       --> 0/0
lo0.16385         up   up   inet
lsi               up   up
mtun              up   up

```

```

show interfaces terse user@host> show interfaces terse
(TX Matrix Plus
Router)
Interface           Admin Link Proto  Local          Remote
xe-0/0/0            up   up
xe-0/0/1            up   up
xe-0/0/2            up   up
xe-0/0/3            up   up
xe-6/0/0            up   up
xe-6/0/1            up   up
xe-6/0/2            up   up
xe-6/0/3            up   up
xe-6/1/0            up   up
xe-6/1/1            up   up
xe-6/1/2            up   up
xe-6/1/3            up   up
so-0/0/0            up   up
so-0/0/0.0          up   up   inet   1.1.1.1/30
ge-1/3/0.0          up   up   inet   --> 0/0
ge-7/0/0            up   up
ge-7/0/0.0          up   up   inet   2.15.1.1/30
ge-7/0/0.1          up   up   inet   2.15.1.5/30
ge-7/0/0.2          up   up   inet   2.15.1.9/30
ge-7/0/0.3          up   up   inet   2.15.1.13/30
ge-7/0/0.4          up   up   inet   2.15.1.17/30
ge-7/0/0.5          up   up   inet   2.15.1.21/30
...
em0                up   up
em0.0              up   up   inet   192.168.178.11/25
gre                up   up
ipip               up   up
ixgbe0             up   up

```

```

ixgbe0.0          up    up    inet    10.34.0.4/8
                  up    up    inet6   162.0.0.4/2
                  up    up    inet6   fe80::200:ff:fe22:4/64
                  up    up    inet6   fec0::a:22:0:4/64
                  up    up    tnp     0x22000004

ixgbe1            up    up
ixgbe1.0          up    up    inet    10.34.0.4/8
                  up    up    inet6   162.0.0.4/2
                  up    up    inet6   fe80::200:1ff:fe22:4/64
                  up    up    inet6   fec0::a:22:0:4/64
                  up    up    tnp     0x22000004

```

**show interfaces terse**  
(PTX Series Packet  
Transport Switches)

user@host> show interfaces em0 terse

Interface	Admin	Link	Proto	Local	Remote
em0	up	up			
em0.0	up	up	inet	192.168.3.30/24	



## CHAPTER 3

# Common Output Fields

- [Common Output Fields Description on page 141](#)

## Common Output Fields Description

---

This chapter explains the content of the output fields, which appear in the output of most **show interfaces** commands.

### Destination Class Field

For the logical interface, the **Destination class** field provides the names of destination class usage (DCU) counters per family and per class for a particular interface. The counters display packets and bytes arriving from designated user-selected prefixes. For example:

Destination class	Packets (packet-per-second)	Bytes (bits-per-second)
gold	1928095	161959980
bronze	( 889)	( 597762)
	0	0
silver	( 0)	( 0)
	0	0
	( 0)	( 0)

### Enabled Field

For the physical interface, the **Enabled** field provides information about the state of the interface, displaying one or more of the following values:

- **Administratively down, Physical link is Down**—The interface is turned off, and the physical link is inoperable and cannot pass packets even when it is enabled. To change the interface state to **Enabled**, use the following command:

```
user@host# set interfaces interface enable
```

Manually verify the connections to bring the physical link up.

- **Administratively down, Physical link is Up**—The interface is turned off, but the physical link is operational and can pass packets when it is enabled. To change the interface state to **Enabled**, use the following command:

```
user@host# set interfaces interface enable
```

- **Enabled, Physical link is Down**—The interface is turned on, but the physical link is inoperable and cannot pass packets. Manually verify the connections to bring the physical link up.
- **Enabled, Physical link is Up**—The interface is turned on, and the physical link is operational and can pass packets.

## Filters Field

For the logical interface, the **Filters** field provides the name of the firewall filters to be evaluated when packets are received or transmitted on the interface. The format is **Filters:** **Input:** *filter-name* and **Filters:** **Output:** *filter-name*. For example:

```
Filters: Input: sample-all
Filters: Output: cp-ftp
```

## Flags Fields

The following sections provide information about flags that are specific to interfaces:

- [Addresses, Flags Field on page 142](#)
- [Device Flags Field on page 143](#)
- [Family Flags Field on page 143](#)
- [Interface Flags Field on page 144](#)
- [Link Flags Field on page 145](#)
- [Logical Interface Flags Field on page 145](#)

---

### Addresses, Flags Field

The **Addresses, Flags** field provides information about the addresses configured for the protocol family on the logical interface and displays one or more of the following values:

- **Dest-route-down**—The routing process detected that the link was not operational and changed the interface routes to nonforwarding status
- **Is-Default**—The default address of the router used as the source address by SNMP, ping, traceroute, and other network utilities.
- **Is-Preferred**—The default local address for packets originating from the local router and sent to destinations on the subnet.
- **Is-Primary**—The default local address for broadcast and multicast packets originated locally and sent out the interface.
- **Preferred**—This address is a candidate to become the preferred address.
- **Primary**—This address is a candidate to become the primary address.



### Device Flags Field

---

The **Device flags** field provides information about the physical device and displays one or more of the following values:

- **Down**—Device has been administratively disabled.
- **Hear-Own-Xmit**—Device receives its own transmissions.
- **Link-Layer-Down**—The link-layer protocol has failed to connect with the remote endpoint.
- **Loopback**—Device is in physical loopback.
- **Loop-Detected**—The link layer has received frames that it sent, thereby detecting a physical loopback.
- **No-Carrier**—On media that support carrier recognition, no carrier is currently detected.
- **No-Multicast**—Device does not support multicast traffic.
- **Present**—Device is physically present and recognized.
- **Promiscuous**—Device is in promiscuous mode and recognizes frames addressed to all physical addresses on the media.
- **Quench**—Transmission on the device is quenched because the output buffer is overflowing.
- **Recv-All-Multicasts**—Device is in multicast promiscuous mode and therefore provides no multicast filtering.
- **Running**—Device is active and enabled.

### Family Flags Field

---

The **Family flags** field provides information about the protocol family on the logical interface and displays one or more of the following values:

- **DCU**—Destination class usage is enabled.
- **Dest-route-down**—The software detected that the link is down and has stopped forwarding the link's interface routes.
- **Down**—Protocol is inactive.
- **Is-Primary**—Interface is the primary one for the protocol.
- **Mac-Validate-Loose**—Interface is enabled with loose MAC address validation.
- **Mac-Validate-Strict**—Interface is enabled with strict MAC address validation.
- **Maximum labels**—Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.
- **MTU-Protocol-Adjusted**—The effective MTU is not the configured value in the software.
- **No-Redirects**—Protocol redirects are disabled.

- **Primary**—Interface can be considered for selection as the primary family address.
- **Protocol-Down**—Protocol failed to negotiate correctly.
- **SCU-in**—Interface is configured for source class usage input.
- **SCU-out**—Interface is configured for source class usage output.
- **send-bcast-packet-to-re**—Interface is configured to forward IPv4 broadcast packets to the Routing Engine.
- **targeted-broadcast**—Interface is configured to forward IPv4 broadcast packets to the LAN interface and the Routing Engine.
- **Unnumbered**—Protocol family is configured for unnumbered Ethernet. An unnumbered Ethernet interface borrows an IPv4 address from another interface, which is referred to as the donor interface.
- **Up**—Protocol is configured and operational.
- **uRPF**—Unicast Reverse Path Forwarding is enabled.

---

### Interface Flags Field

The **Interface flags** field provides information about the physical interface and displays one or more of the following values:

- **Admin-Test**—Interface is in test mode and some sanity checking, such as loop detection, is disabled.
- **Disabled**—Interface is administratively disabled.
- **Down**—A hardware failure has occurred.
- **Hardware-Down**—Interface is nonfunctional or incorrectly connected.
- **Link-Layer-Down**—Interface keepalives have indicated that the link is incomplete.
- **No-Multicast**—Interface does not support multicast traffic.
- **No-receive No-transmit**—Passive monitor mode is configured on the interface.
- **OAM-On-SVLAN**—(MX Series routers with MPC/MIC interfaces only) Interface is configured to propagate the Ethernet OAM state of a static, single-tagged service VLAN (S-VLAN) on a Gigabit Ethernet, 10-Gigabit Ethernet, or aggregated Ethernet interface to a dynamic or static double-tagged customer VLAN (C-VLAN) that has the same S-VLAN (outer) tag as the S-VLAN.
- **Point-To-Point**—Interface is point-to-point.
- **Pop all MPLS labels from packets of depth**—MPLS labels are removed as packets arrive on an interface that has the **pop-all-labels** statement configured. The depth value can be one of the following:
  - **1**—Takes effect for incoming packets with one label only.
  - **2**—Takes effect for incoming packets with two labels only.
  - **[ 1 2 ]**—Takes effect for incoming packets with either one or two labels.

- **Promiscuous**—Interface is in promiscuous mode and recognizes frames addressed to all physical addresses.
- **Recv-All-Multicasts**—Interface is in multicast promiscuous mode and provides no multicast filtering.
- **SNMP-Traps**—SNMP trap notifications are enabled.
- **Up**—Interface is enabled and operational.

---

### Link Flags Field

The **Link flags** field provides information about the physical link and displays one or more of the following values:

- **ACFC**—Address control field compression is configured. The Point-to-Point Protocol (PPP) session negotiates the ACFC option.
- **Give-Up**—Link protocol does not continue connection attempts after repeated failures.
- **Loose-LCP**—PPP does not use the Link Control Protocol (LCP) to indicate whether the link protocol is operational.
- **Loose-LMI**—Frame Relay does not use the Local Management Interface (LMI) to indicate whether the link protocol is operational.
- **Loose-NCP**—PPP does not use the Network Control Protocol (NCP) to indicate whether the device is operational.
- **No-Keepalives**—Link protocol keepalives are disabled.
- **PFC**—Protocol field compression is configured. The PPP session negotiates the PFC option.

---

### Logical Interface Flags Field

The **Logical interface flags** field provides information about the logical interface and displays one or more of the following values:

- **ACFC Encapsulation**—Address control field Compression (ACFC) encapsulation is enabled (negotiated successfully with a peer).
- **Device-down**—Device has been administratively disabled.
- **Disabled**—Interface is administratively disabled.
- **Down**—A hardware failure has occurred.
- **Clear-DF-Bit**—GRE tunnel or IPsec tunnel is configured to clear the Don't Fragment (DF) bit.
- **Hardware-Down**—Interface protocol initialization failed to complete successfully.
- **PFC**—Protocol field compression is enabled for the PPP session.
- **Point-To-Point**—Interface is point-to-point.

- **SNMP-Traps**—SNMP trap notifications are enabled.
- **Up**—Interface is enabled and operational.

## Label-Switched Interface Traffic Statistics Field

When you use the **vrf-table-label** statement to configure a VRF routing table, a label-switched interface (LSI) logical interface label is created and mapped to the VRF routing table.

Any routes present in a VRF routing table and configured with the **vrf-table-label** statement are advertised with the LSI logical interface label allocated for the VRF routing table. When packets for this VPN arrive on a core-facing interface, they are treated as if the enclosed IP packet arrived on the LSI interface and are then forwarded and filtered based on the correct table. For more information on the **vrf-table-label** statement, including a list of supported interfaces, see the *Junos VPNs Configuration Guide*.

If you configure the **family mpls** statement at the **[edit interfaces interface-name unit logical-unit-number]** hierarchy level and you also configure the **vrf-table-label** statement at the **[edit routing-instances routing-instance-name]** hierarchy level, the output for the **show interface interface-name extensive** command includes the following output fields about the LSI traffic statistics:

- **Input bytes**—Number of bytes entering the LSI and the current throughput rate in bits per second (bps).
- **Input packets**—Number of packets entering the LSI and the current throughput rate in packets per second (pps).



**NOTE:** If LSI interfaces are used with VPLS when **no-tunnel-services** is configured or L3VPN when **vrf-table-label** configuration is applied inside the routing-instance, the **Input packets** field associated with the core-facing interfaces may not display the correct value. Only the Input counter is affected because the LSI is used to receive traffic from the remote PEs. Traffic that arrives on an LSI interface might not be counted at both the Traffic Statistics and the Label-switched interface (LSI) traffic statistics levels.

This note applies to the following platforms:

- M Series routers with -E3 FPC model numbers or configured with an Enhanced CFEB (CFEB-E), and M120 routers
- MX Series routers with DPC or ADPC only

The following example shows the LSI traffic statistics that you might see as part of the output of the **show interface interface-name extensive** command:

Label-switched interface (LSI) traffic statistics:

Input bytes:	0	0 bps
Input packets:	0	0 pps

## Policer Field

For the logical interface, the **Policer** field provides the policers that are to be evaluated when packets are received or transmitted on the interface. The format is **Policer: Input: *type-fpc/picport-in-policer*, Output: *type-fpc/pic/port-out-policer***. For example:

**Policer: Input: at-1/2/0-in-policer, Output: at-2/4/0-out-policer**

## Protocol Field

For the logical interface, the **Protocol** field indicates the protocol family or families that are configured on the interface, displaying one or more of the following values:

- **aenet**—Aggregated Ethernet. Displayed on Fast Ethernet interfaces that are part of an aggregated Ethernet bundle.
- **ccc**—Circuit cross-connect (CCC). Configured on the logical interface of CCC physical interfaces.
- **inet**—IP version 4 (IPv4). Configured on the logical interface for IPv4 protocol traffic, including Open Shortest Path First (OSPF), Border Gateway Protocol (BGP), Internet Control Message Protocol (ICMP), and Internet Protocol Control Protocol (IPCP).
- **inet6**—IP version 6 (IPv6). Configured on the logical interface for IPv6 protocol traffic, including Routing Information Protocol for IPv6 (RIPng), Intermediate System-to-Intermediate System (IS-IS), and BGP.
- **iso**—International Organization for Standardization (ISO). Configured on the logical interface for IS-IS traffic.
- **mlfr-uni-nni**—Multilink Frame Relay (MLFR) FRF.16 user-to-network network-to-network (UNI NNI). Configured on the logical interface for link services bundling.
- **mlfr-end-to-end**—Multilink Frame Relay end-to-end. Configured on the logical interface for multilink bundling.
- **mlppp**—Multilink Point-to-Point Protocol (MLPPP). Configured on the logical interface for multilink bundling.
- **mpls**—Multiprotocol Label Switching (MPLS). Configured on the logical interface for participation in an MPLS path.
- **pppoe**—Point-to-Point Protocol over Ethernet (PPPoE). Configured on Ethernet interfaces enabled to support multiple protocol families.
- **tcc**—Translational cross-connect (TCC). Configured on the logical interface of TCC physical interfaces.
- **tnp**—Trivial Network Protocol (TNP). Used to communicate between the Routing Engine and the router's packet forwarding components. The Junos OS automatically configures this protocol family on the router's internal interfaces only.
- **vpls**—Virtual private LAN service (VPLS). Configured on the logical interface on which you configure VPLS.

## RPF Failures Field

For the logical interface, the **RPF Failures** field provides information about the amount of incoming traffic (in packets and bytes) that failed a unicast reverse path forwarding (RPF) check on a particular interface. The format is **RPF Failures: Packets: xx,Bytes: yy**. For example:

**RPF Failures: Packets: 0, Bytes:0**

## Source Class Field

For the logical interface, the **Source class** field provides the names of source class usage (SCU) counters per family and per class for a particular interface. The counters display packets and bytes arriving from designated user-selected prefixes. For example:

Source class	Packets (packet-per-second)	Bytes (bits-per-second)
gold	1928095	161959980
(	889)	( 597762)
bronze	0	0
(	0)	( 0)
silver	0	0
(	0)	( 0)

## PART 2

# Ethernet Interfaces

- [Ethernet Interface Operational Mode Commands on page 151](#)
- [VRRP Operational Mode Commands on page 425](#)





## CHAPTER 4

# Ethernet Interface Operational Mode Commands

Table 24 on page 151 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot aggregated Ethernet, Fast Ethernet, Gigabit Ethernet, and 10-Gigabit Ethernet interfaces. Commands are listed in alphabetical order.

**Table 24: Ethernet Interface Operational Mode Commands**

Task	Command
Clear dynamic VLAN interfaces.	<code>clear auto-configuration interfaces</code>
Clear a specified dynamic agent circuit identifier (ACI) interface set configured on the router. You can clear only those ACI interface sets that have no subscriber interface members.	<code>clear auto-configuration interfaces interface-set</code>
Clear Link Aggregation Control Protocol (LACP) statistics.	<code>clear lacp statistics</code>
Clear Link Aggregation Control Protocol (LACP) timeout entries.	<code>clear lacp timeouts</code>
Clear learned MAC addresses from the hardware and MAC database. Static MAC addresses are not cleared.	<code>clear interfaces mac-database</code>
Clear statistics that are collected for every MAC address, including policer statistics, on a given physical or logical interface.	<code>clear interfaces mac-database statistics</code>
Clear statistics that are collected for interface sets.	<code>clear interfaces interface-set statistics</code>
Clear the existing continuity measurement and restart counting the operational uptime.	<code>clear oam ethernet connectivity-fault-management continuity-measurement</code>
Clear ITU-T Y.1731 Ethernet frame delay measurement (ETH-DM) delay statistics and ETH-DM frame counts. (MX Series routers)	<code>clear oam ethernet connectivity-fault-management delay-statistics</code>

Table 24: Ethernet Interface Operational Mode Commands (*continued*)

Task	Command
Clear Operation, Administration, and Management (OAM) and connectivity fault management (CFM) linktrace database information.	<code>clear oam ethernet connectivity-fault-management linktrace path-database</code>
Clear all loss statistics maintained by CFM for a given maintenance domain and maintenance association.	<code>clear oam ethernet connectivity-fault-management loss-statistics</code>
Clear connectivity-fault-management policer statistics.	<code>clear oam ethernet connectivity-fault-management policer</code>
Clear all statistics maintained by CFM. (Routers that support IEEE 802.1ag OAM CFM)  In addition, for interfaces that support ITU-T Y.1731 Ethernet frame delay measurement (ETH-DM), also clear any ETH-DM statistics and frame counts for CFM maintenance association end points (MEPs).	<code>clear oam ethernet connectivity-fault-management statistics</code>
Clear Operation, Administration, and Management (OAM) link fault management state information and restart the link discovery process on Ethernet interfaces.	<code>clear oam ethernet link-fault-management state</code>
Clear Operation, Administration, and Management (OAM) statistics link fault management statistics for Ethernet interfaces.	<code>clear oam ethernet link-fault-management statistics</code>
Clear the statistics for all Ethernet ring protection groups or a specific Ethernet ring protection group.	<code>clear protection-group ethernet-ring statistics</code>
Check the reachability of a remote IEEE 802.1ag OAM maintenance association end point (MEP) or maintenance association intermediate point (MIP).	<code>ping ethernet</code>
Manually rebalance the subscribers on an aggregated Ethernet bundle with targeted distribution enabled.	<code>request interface rebalance (Aggregated Ethernet for Subscriber Management)</code>
Manually revert egress traffic from the designated backup link to the designated primary link of an aggregated Ethernet interface for which link protection is enabled, or manually switch egress traffic from the primary link to the backup link.	<code>request interface (revert   switchover) (Aggregated Ethernet Link Protection)</code>
Force LACP link switchover.	<code>request lacp link-switchover</code>
Clear the lockout, force switch, manual switch, exercise, and wait-to-restore states.	<code>request protection-group ethernet-aps clear</code>

Table 24: Ethernet Interface Operational Mode Commands (*continued*)

Task	Command
Test if APS is operating correctly.	<code>request protection-group ethernet-aps exercise</code>
Force traffic to switch from the active path to the alternate path.	<code>request protection-group ethernet-aps force-switch</code>
Lock the protection path, forcing the use of the working path.	<code>request protection-group ethernet-aps lockout</code>
Force traffic to switch from the active path to the alternate path.	<code>request protection-group ethernet-aps manual-switch</code>
Display status information about aggregated Fast Ethernet or Gigabit Ethernet router interfaces.	<code>show interfaces (Aggregated Ethernet)</code> <code>show interfaces (far-end-interval)</code>
Display status information about Fast Ethernet interfaces.	<code>show interfaces (Fast Ethernet)</code>
Display status information about the specified Gigabit Ethernet interface.	<code>show interfaces (Gigabit Ethernet)</code>
Display status information about 10-Gigabit Ethernet router interfaces.	<code>show interfaces (10-Gigabit Ethernet)</code>
Display IPv6 interface statistics for IPv6 traffic traversing through the IQ2 and IQ2E PICs on standalone T640 routers and on T640 routers in a TX Matrix or in a TXP Matrix.	<code>show interfaces extensive</code>
Display IPv6 interface statistics for IPv6 traffic traversing through the IQ2 PICs on M10i and M120 routers.	
Display IPv6 interface statistics for IPv6 traffic traversing through the IQ2E PICs on M10i, M120, and M320 routers.	
Display information about Gigabit Ethernet or 10-Gigabit Ethernet router interface sets.	<code>show interfaces interface-set (Ethernet Interface Set)</code>
Display information about Gigabit Ethernet or 10-Gigabit Ethernet router interface set queues.	<code>show interfaces interface-set queue</code>
Display the transceiver temperature, laser bias current, laser output power, receive optical power, and related alarms for 10-Gigabit Ethernet dense wavelength-division multiplexing (DWDM) interfaces.	<code>show interfaces diagnostics optics (Gigabit Ethernet, 10-Gigabit Ethernet, and 100 Gigabit Ethernet)</code>
Display information about integrated routing and bridging interfaces.	<code>show interfaces irb</code>


Table 24: Ethernet Interface Operational Mode Commands (*continued*)

Task	Command
Display status information about the distribution of subscribers on different links in an aggregated Ethernet bundle.	<code>show interfaces targeting</code> (Aggregated Ethernet for Subscriber Management)
Display Link Aggregation Control Protocol (LACP) information for aggregated, Fast Ethernet, or Gigabit Ethernet router interfaces.	<code>show lacp interfaces</code>
Display Link Aggregation Control Protocol (LACP) statistics.	<code>show lacp statistics</code>
Display Link Aggregation Control Protocol timeout entries.	<code>show lacp timeouts</code>
Display MAC address information for Gigabit Ethernet router interfaces.	<code>show interfaces mac-database</code> (Gigabit Ethernet)
Display information on a specified interface that is part of a multichassis link aggregation configuration.	<code>show interfaces mc-ae</code>
Display ETH-DM statistics for CFM MEPs. (MX Series routers, Ethernet DPCs).	<code>show oam ethernet</code> <code>connectivity-fault-management</code> <code>delay-statistics</code>
Display IEEE 802.1ag OAM connectivity fault management forwarding state information for Ethernet interfaces.	<code>show oam ethernet</code> <code>connectivity-fault-management</code> <code>forwarding-state</code>
Display OAM connectivity fault management information for Ethernet interfaces.  For interfaces that support ETH-DM, also display any ETH-DM frame counts when the <b>detail</b> or <b>extensive</b> option is included. In all other cases, ETH-DM frame counts are zero.	<code>show oam ethernet</code> <code>connectivity-fault-management</code> <code>interfaces</code>
Display OAM connectivity fault management linktrace path database information.	<code>show oam ethernet</code> <code>connectivity-fault-management</code> <code>linktrace path-database</code>
Display OAM connectivity fault management maintenance association end point (MEP) database information.  For interfaces that support ETH-DM, also display any ETH-DM frame counts. In all other cases, ETH-DM frame counts are zero.	<code>show oam ethernet</code> <code>connectivity-fault-management</code> <code>mep-database</code>
Display ETH-DM statistics and frame counts for CFM MEPs. (MX Series routers, Ethernet DPCs)	<code>show oam ethernet</code> <code>connectivity-fault-management</code> <code>mep-statistics</code>

Table 24: Ethernet Interface Operational Mode Commands (*continued*)

Task	Command
Display ETH-LM statistics for on-demand mode only.	<code>show oam ethernet connectivity-fault-management loss-statistics</code>
Display information about maintenance intermediate points (MIPs) for the Ethernet OAM 802.1ag standard for connectivity fault management (CFM).	<code>show oam ethernet connectivity-fault-management mip</code>
Display OAM connectivity fault management path database information for hosts configured with MEP.	<code>show oam ethernet connectivity-fault-management path-database</code>
Displays connectivity-fault-management policer statistics.	<code>show oam ethernet connectivity-fault-management policer</code>
Display OAM Ethernet Virtual Connection (EVC) information for hosts configured with Ethernet Local Management Interface (E-LMI). (MX series only)	<code>show oam ethernet evc</code>
Display OAM fault management statistics for Ethernet interfaces.	<code>show oam ethernet link-fault-management</code>
Display OAM Ethernet Local Management Interface status information for an LMI configured interface. (MX series only)	<code>show oam ethernet lmi</code>
Display OAM Ethernet Local Management Interface statistics for an LMI configured interface. (MX series only)	<code>show oam ethernet lmi statistics</code>
Display protection group Ethernet ring Automatic Protection Switching (APS).	<code>show protection-group ethernet-ring aps</code>
Display data channel information for all Ethernet ring protection groups or for a specific Ethernet ring protection group.	<code>show protection-group ethernet-ring data-channel</code>
Display protection group Ethernet ring interfaces.	<code>show protection-group ethernet-ring interface</code>
Display protection group Ethernet ring nodes.	<code>show protection-group ethernet-ring node-state</code>
Display protection group Ethernet ring statistics.	<code>show protection-group ethernet-ring statistics</code>
Display all data channel logical interfaces and the VLAN IDs controlled by a ring instance data channel.	<code>show protection-group ethernet-ring vlan</code>
Trace the path between two Ethernet OAM end points.	<code>traceroute ethernet</code>

## clear auto-configuration interfaces

<b>Syntax</b>	<code>clear auto-configuration interfaces <i>interface-name</i></code>
<b>Release Information</b>	Command introduced in Junos OS Release 9.5.
<b>Description</b>	Clear dynamically created VLAN interfaces.
	<div>  <p><b>NOTE:</b> For the clear command to be successful, no interface bindings (for example, DHCP server bindings) can exist on the dynamic interface.</p> </div>
<b>Options</b>	<i>interface-name</i> —Name of a physical or logical interface.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">clear auto-configuration interfaces (All Interfaces) on page 156</a> <a href="#">clear auto-configuration interfaces (Single Dynamically Created Interface) on page 156</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

clear  
auto-configuration  
interfaces (All  
Interfaces)

```
user@host> clear auto-configuration interfaces ge-1/0/0
```

```
10 interfaces removed from device ge-1/0/0
```

clear  
auto-configuration  
interfaces (Single  
Dynamically Created  
Interface)

```
user@host> clear auto-configuration interfaces ge-1/0/0.1073741824
```

```
Interface ge-1/0/0.1073741824 deleted
```

## clear auto-configuration interfaces interface-set

<b>Syntax</b>	clear auto-configuration interfaces interface-set <i>interface-set-name</i>
<b>Release Information</b>	Command introduced in Junos OS Release 12.2.
<b>Description</b>	<p>Clear a specified dynamic agent circuit identifier (ACI) interface set on the router. An ACI interface set is a logical collection of dynamic VLAN subscriber interfaces that originate at the same household or on the same access-loop port.</p> <p>You can clear only those ACI interface sets that have no active subscriber interface members. If the ACI interface set that you want to clear still has valid member interfaces, you must first remove these interfaces before issuing the <b>clear auto-configuration interfaces interface-set <i>interface-set-name</i></b> command.</p>
<b>Options</b>	<p><b><i>interface-set-name</i></b>—Name of the empty ACI interface set that you want to clear. Use the ACI interface set name generated by the router, such as aci-1003-ge-1/0/0.4001, and not the actual agent circuit identifier string found in the DHCP or PPPoE control packets. To view the names of the ACI interface sets configured on the router, you can issue the <b>show subscribers</b> command.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Clearing Agent Circuit Identifier Interface Sets</li> </ul>
<b>List of Sample Output</b>	<p><a href="#">clear auto-configuration interfaces interface-set on page 157</a></p> <p><a href="#">clear auto-configuration interfaces interface-set (Error Message for ACI Interface Set with Active Members) on page 157</a></p>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

```
clear
auto-configuration
interfaces
interface-set
```


```
user@host> clear auto-configuration interfaces interface-set aci-1003-ge-1/0/0.4001
Interface-set aci-1003-ge-1/0/0.4001 deleted
```

```
clear
auto-configuration
interfaces
interface-set (Error
Message for ACI
Interface Set with
Active Members)
```

```
user@host> clear auto-configuration interfaces interface-set aci-1005-ge-1/0/0.2800
error: Interface set aci-1005-ge-1/0/0.2800 has references.
```

## clear lacp statistics

---

Syntax	clear lacp statistics <interfaces <i>interface-name</i> >
Release Information	Command introduced in JUNOS Release 9.4.
Description	Clear Link Aggregation Control Protocol (LACP) statistics.
	<div> <b>NOTE:</b> This command does not clear LACP statistics displayed in the <code>show interfaces aenumber</code> extensive command.</div>
Options	<i>interfaces interface-name</i> —(Optional) Clear LACP interface statistics for all interfaces or for a specified interface
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"><li>• <a href="#">show lacp interfaces on page 321</a></li><li>• <a href="#">show lacp statistics on page 325</a></li></ul>
List of Sample Output	<a href="#">clear lacp statistics on page 158</a>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

`clear lacp statistics`      `user@host> clear lacp statistics`



## clear lacp timeouts

---

<b>Syntax</b>	clear lacp timeouts <interfaces <i>interface-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 12.1R4.
<b>Description</b>	Clear Link Aggregation Control Protocol (LACP) timeout entries.
<b>Options</b>	<b>interfaces <i>interface-name</i></b> —(Optional) Clear LACP timeout entries for the specified interface.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show lacp timeouts on page 327</a></li><li>• <a href="#">clear lacp statistics on page 158</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear lacp timeouts on page 159</a> <a href="#">clear lacp timeouts (aggregated Ethernet interface) on page 159</a> <a href="#">clear lacp timeouts (gigabit Ethernet interface) on page 159</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

clear lacp timeouts	user@host> clear lacp timeouts
clear lacp timeouts (aggregated Ethernet interface)	user@host> clear lacp timeouts interfaces ae0
clear lacp timeouts (gigabit Ethernet interface)	user@host > clear lacp timeouts interfaces ge-1/3/0

## clear interfaces mac-database

---

<b>Syntax</b>	<code>clear interfaces mac-database <i>interface-name</i></code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.3.
<b>Description</b>	For Gigabit Ethernet IQ2 interfaces, clear learned media access control (MAC) addresses from the hardware and MAC database. Static MAC addresses configured by the operator are not cleared.
<b>Options</b>	<i>interface-name</i> —Name of a physical or logical interface. When you clear a physical interface, all learned MAC addresses on all the logical interfaces under the physical interface are cleared.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">clear interfaces mac-database on page 160</a>
<b>Output Fields</b>	This command produces no output.

### Sample Output

<code>clear interfaces mac-database</code>	<code>user@host&gt; clear interfaces mac-database ge-0/0/0.0</code>
--	---

---

## clear interfaces mac-database statistics

---

<b>Syntax</b>	<code>clear interfaces mac-database statistics (<i>interface-name</i>  all)</code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.3.
<b>Description</b>	Clear statistics that are collected for every MAC address, including policer statistics, on a physical or logical interface or all interfaces.
<b>Options</b>	<code>(<i>interface-name</i>   all)</code> —Clear MAC database statistics for the specified physical or logical gigabit or 10-Gigabit Ethernet interface. Specify <b>all</b> to clear the MAC database statistics for all interfaces.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">clear interfaces mac-database statistics (Gigabit Ethernet) on page 161</a>
<b>Output Fields</b>	This command produces no output.

### Sample Output

`clear interfaces  
mac-database  
statistics (Gigabit  
Ethernet)`

```
user@host> clear interfaces mac-database statistics ge-0/1/0
```

## clear interfaces interface-set statistics

---

<b>Syntax</b>	clear interfaces interface-set statistics ( <i>interface-set-name</i>   all)
<b>Release Information</b>	Command introduced in Junos OS Release 8.5.
<b>Description</b>	Clear queue statistics for the specified interface set or all interface sets.
<b>Options</b>	( <i>interface-set-name</i>   all)—Clear queue statistics for the specified gigabit or 10-Gigabit Ethernet interface set. Specify <b>all</b> to clear queue statistics for all interface sets.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">clear interfaces interface-set statistics (Gigabit Ethernet) on page 162</a>
<b>Output Fields</b>	This command produces no output.

### Sample Output

<code>clear interfaces interface-set statistics (Gigabit Ethernet)</code>	<code>user@host&gt; clear interfaces interface-set statistics ge-2/2/0-0</code>
---	---

## clear oam ethernet connectivity-fault-management continuity-measurement

<b>Syntax</b>	clear oam ethernet connectivity-fault-management continuity-measurement maintenance-domain <i>md-name</i> maintenance-association <i>ma-name</i> <local-mep <i>local-mep-id</i> > <remote-mep <i>remote-mep-id</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 11.1.
<b>Description</b>	For all routers that support IEEE 802.1ag OAM connectivity fault management (CFM), clear the existing continuity measurement and restart counting the operational uptime (that is, the total time during which CCM adjacency is active for a particular remote MEP.).
<b>Options</b>	<p><b>maintenance-domain <i>md-name</i></b>—Name of an existing CFM maintenance domain.</p> <p><b>maintenance-association <i>ma-name</i></b>—Name of an existing CFM maintenance association.</p> <p><b>local-mep <i>local-mep-id</i></b>—(Optional) Display connectivity fault management information for the specified local MEP only.</p> <p><b>remote-mep <i>remote-mep-id</i></b>—(Optional) Display connectivity fault management information for the specified remote MEP only.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Managing Continuity Measurement Statistics</li> <li>Junos® OS Ethernet Interfaces</li> </ul>
<b>List of Sample Output</b>	<a href="#">clear oam ethernet connectivity-fault-management continuity-measurement on page 163</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

clear oam ethernet connectivity-fault-management continuity-measurement	<pre>user@host&gt; clear oam ethernet connectivity-fault-management continuity-measurement maintenance-domain md5 maintenance-association ma5 local-mep 100 remote-mep 102 Continuity measurement restarted.</pre>
---	--

## clear oam ethernet connectivity-fault-management delay-statistics

<b>Syntax</b>	<pre>clear oam ethernet connectivity-fault-management delay-statistics maintenance-association <i>maintenance-association-name</i> maintenance-domain <i>maintenance-domain-name</i> &lt;logical-system <i>logical-system-name</i>&gt; &lt;one-way&gt; &lt;two-way&gt;</pre>
<b>Release Information</b>	<p>Command introduced in Junos OS Release 9.6.</p> <p>Command introduced in Junos OS Release 11.4 for EX Series switches.</p>
<b>Description</b>	On MX Series routers and EX Series switches, clear ITU-T Y.1731 Ethernet frame delay measurement (ETH-DM) delay statistics and ETH-DM frame counts.
<b>Options</b>	<p><b><i>maintenance-association maintenance-association-name</i></b>—Clear ETH-DM delay statistics and ETH-DM frame counts for the specified maintenance association.</p> <p><b><i>maintenance-domain maintenance-domain-name</i></b>—Clear ETH-DM delay statistics and ETH-DM frame counts for the specified maintenance domain.</p> <p><b><i>logical-system logical-system-name</i></b>—(MX Series routers only) (Optional) Clear ETH-DM delay statistics and ETH-DM frame counts for the specified logical system.</p> <p><b><i>one-way</i></b>—(Optional) Clear one-way ETH-DM delay statistics and ETH-DM frame counts for the specified maintenance association, maintenance domain, or (on the routers only) logical system.</p> <p><b><i>two-way</i></b>—(Optional) Clear two-way ETH-DM delay statistics and ETH-DM frame counts for the specified maintenance association, maintenance domain, or (on the routers only) logical system.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">clear oam ethernet connectivity-fault-management statistics on page 168</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management delay-statistics on page 337</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management interfaces on page 345</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">clear oam ethernet connectivity-fault-management delay statistics on page 164</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

clear oam ethernet  
connectivity-fault-  
management delay  
statistics

```
user@switch> clear oam ethernet connectivity-fault-management delay-statistics
maintenance-domain md1 maintenance-association ma1
Delay statistics entries cleared
```

## clear oam ethernet connectivity-fault-management linktrace path-database

<b>Syntax</b>	<code>clear oam ethernet connectivity-fault-management linktrace path-database mac-address maintenance-association <i>ma-name</i> maintenance-domain <i>md-name</i></code>
<b>Release Information</b>	Command introduced in Junos OS Release 9.0.
<b>Description</b>	Clear all the linktrace entries and the relevant path information from the database for a particular remote host on M320, MX Series, T320, and T640 routers.
<b>Options</b>	<p><b>mac-address</b>—Clear connectivity fault management path database information for the specified MAC address of the remote host.</p> <p><b>maintenance-association <i>ma-name</i></b>—Clear connectivity fault management path database information for the specified maintenance association.</p> <p><b>maintenance-domain <i>md-name</i></b>—Clear connectivity fault management path database information for the specified maintenance domain.</p>
<b>Required Privilege Level</b>	view

### Sample Output

<pre>clear oam ethernet connectivity-fault- management linktrace path-database</pre>	<pre>user@host&gt; clear oam ethernet connectivity-fault-management linktrace path-database maintenance-domain md1 maintenance-association ma3 00058573e483 This command produces no output.</pre>
--	--

## clear oam ethernet connectivity-fault-management loss-statistics

---

<b>Syntax</b>	<b>clear oam ethernet connectivity-fault-management loss-statistics</b> <b>&lt;interface <i>ethernet-interface-name</i>&gt;</b> <b>&lt;level <i>md-level</i>&gt;</b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.1.
<b>Description</b>	<p>For all routers that support IEEE 802.1ag OAM connectivity fault management (CFM), clear all loss statistics maintained by CFM for a given maintenance domain and maintenance association.</p> <p>In addition, for Ethernet interfaces on MX Series routers, clear any ITU-T Y.1731 Ethernet frame loss measurement (ETH-LM) statistics.</p> <p>By default, the command clears ETH-LM statistics for CFM maintenance association end points (MEPs) attached to any interface on the router.</p>
<b>Options</b>	<p><b>interface <i>ethernet-interface-name</i></b>—(Optional) Clear ETH-LM statistics and ETH-LM frame counts only for MEPs attached to the specified Ethernet physical interface.</p> <p><b>level <i>md-level</i></b>—(Optional) Clear ETH-LM statistics and ETH-LM frame counts only for MEPs within CFM maintenance domains (MDs) of the specified level.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• Clearing ETH-LM Statistics</li><li>• Displaying ETH-LM Statistics</li><li>• Managing ETH-LM Statistics</li></ul>
<b>List of Sample Output</b>	<a href="#">clear oam ethernet connectivity-fault-management loss-statistics on page 166</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

<b>clear oam ethernet connectivity-fault-management loss-statistics</b>	<pre>user@host&gt; clear oam ethernet connectivity-fault-management loss-statistics Cleared loss measurements statistics of all CFM sessions</pre>
---	--



## clear oam ethernet connectivity-fault-management policer

<b>Syntax</b>	clear oam ethernet connectivity-fault-management policer maintenance-domain <i>md-name</i> maintenance-association <i>ma-name</i>
<b>Release Information</b>	Command introduced in Junos OS Release 10.0.
<b>Description</b>	On M7i and M10i with the Enhanced CFEB (CFEB-E), M320, M120, MX Series, T320, and T640 routers, clear connectivity-fault-management policer statistics.
<b>Options</b>	<p>The following options are supported:</p> <p><b>maintenance-domain <i>md-name</i></b>—Name of an existing CFM maintenance domain. If this option is not specified, policer statistics are cleared for all maintenance associations for all maintenance domains.</p> <p><b>maintenance-association <i>ma-name</i></b>—Name of an existing CFM maintenance association. If this option is not specified, policer statistics are cleared for all maintenance associations for given maintenance domain. This option cannot be specified without specifying maintenance-domain name.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show oam ethernet connectivity-fault-management policer on page 388</a></li> </ul>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### clear oam ethernet connectivity-fault-management policer

```
user@host> clear oam ethernet connectivity-fault-management policer
Policer statistics cleared
```

### clear oam ethernet connectivity-fault-management policer maintenance-domain *md-name* maintenance-association *ma-name*

```
user@host> clear oam ethernet connectivity-fault-management policer
maintenance-domain md5 maintenance-association ma5-1
Policer statistics cleared
```

## clear oam ethernet connectivity-fault-management statistics

<b>Syntax</b>	<b>clear oam ethernet connectivity-fault-management statistics</b> <code>&lt;interface ethernet-interface-name&gt;</code> <code>&lt;level md-level&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4. Support for ETH-DM statistics and frame counts added in Junos OS Release 9.5.
<b>Description</b>	For all routers that support IEEE 802.1ag OAM connectivity-fault management (CFM), clear all statistics maintained by CFM.  In addition, for Ethernet interfaces on Dense Port Concentrators (DPCs) in MX Series routers only, also clear any ITU-T Y.1731 Ethernet frame delay measurement (ETH-DM) statistics and ETH-DM frame counts.  By default, the command clears CFM statistics and ETH-DM statistics and frame counts for CFM maintenance association end points (MEPs) attached to any interface on the router.
<b>Options</b>	<b>ethernet-interface-name</b> —(Optional) Clear CFM statistics, ETH-DM statistics, and ETH-DM frame counts only for MEPs attached to the specified Ethernet physical interface.  <b>level</b> —(Optional) Clear CFM statistics, ETH-DM statistics, and ETH-DM frame counts only for MEPs within CFM maintenance domains (MDs) of the specified level.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show oam ethernet connectivity-fault-management delay-statistics on page 337</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management interfaces on page 345</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-database on page 357</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-statistics on page 367</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">clear oam ethernet connectivity-fault-management statistics on page 168</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

clear oam ethernet  
connectivity-fault-  
management statistics

```
user@host> clear oam ethernet connectivity-fault-management statistics
Cleared statistics of all CFM sessions
```

## clear oam ethernet link-fault-management state

<b>Syntax</b>	clear oam ethernet link-fault-management state < <i>interface-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	On all M Series, MX Series, ACX series, PTX Series, T320, and T640 routers, clear link fault management state information, restart the link discovery process, and reset OAM loopback state (if set previously) on Ethernet interfaces.
<b>Options</b>	<p><b>none</b>—Clear OAM link fault management state information, restart the link discovery process, and reset OAM loopback state (if set previously) on all Ethernet interfaces.</p> <p><b><i>interface-name</i></b>—(Optional) Clear OAM link fault management state information, restart the link discovery process, and reset OAM loopback state (if set previously) on the specified Ethernet interface only.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">clear oam ethernet link-fault-management state on page 169</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

clear oam ethernet link-fault-management state	<pre>user@host&gt; clear oam ethernet link-fault-management state ge-0/3/3 Cleared link-fault-management state for interface ge-0/3/3</pre>
--	---

## clear oam ethernet link-fault-management statistics

---

<b>Syntax</b>	clear oam ethernet link-fault-management < <i>interface-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 8.2.
<b>Description</b>	On M320, M120, MX Series, PTX Series, T320, and T640 routers, clear Operation, Administration, and Management (OAM) link fault management statistics or state information from Ethernet interfaces.
<b>Options</b>	<b>none</b> —Clear OAM link fault management statistics from all Ethernet interfaces.  <b><i>interface-name</i></b> —(Optional) Clear OAM link fault management statistics from the specified Ethernet interface only.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">clear oam ethernet link-fault-management statistics on page 170</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

<code>clear oam ethernet link-fault-management statistics</code>	<code>user@host&gt; clear oam ethernet link-fault-management statistics</code> Cleared link-fault-management statistics for all interfaces
--	---

## clear protection-group ethernet-ring statistics

<b>Syntax</b>	clear protection-group ethernet-ring statistics <group <i>name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 9.4.
<b>Description</b>	On MX Series routers, clear the statistics for all Ethernet ring protection groups or a specific Ethernet ring protection group.
<b>Options</b>	<b>group <i>name</i></b> —Clear the Ethernet ring protection statistics for the specified group.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">clear protection-group ethernet-ring statistics on page 171</a> <a href="#">clear protection-group ethernet-ring statistics on page 171</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

**clear protection-group ethernet-ring statistics** To clear all Ethernet ring protection group statistics for all protection groups, use the following command:

```
user@host> clear protection-group ethernet-ring statistics
Cleared protection-group statistics for all groups
```

### Sample Output

**clear protection-group ethernet-ring statistics** To clear Ethernet ring protection group statistics for the group *my\_prot\_group*, use the following command:

```
user@host> clear protection-group ethernet-ring statistics group my_prot_group
Cleared protection-group statistics for group my_prot_group
```

## ping ethernet

<b>Syntax</b>	ping ethernet <i>mac-address</i> maintenance-domain <i>md-name</i> maintenance-association <i>ma-name</i> <count <i>count</i> > < <i>host-mac-address</i> > <logical-system <i>logical-system-name</i> > <mep <i>identifier</i> > <size <i>bytes</i> > <wait <i>seconds</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 9.1. Support for multicast MAC addresses introduced in Junos OS Release 12.3R2.
<b>Description</b>	Check the reachability of a remote IEEE 802.1ag OAM maintenance association end point (MEP) or maintenance association intermediate point (MIP). Type Ctrl+c to interrupt a <b>ping ethernet</b> command.
<b>Options</b>	<p><b><i>mac-address</i></b>—Send loopback protocol messages to the MEP with the specified Ethernet MAC address.</p> <p><b>maintenance-association <i>ma-name</i></b>—Send loopback protocol messages to the MEP for the specified maintenance association.</p> <p><b>maintenance-domain <i>md-name</i></b>—Send loopback protocol messages to the MEP for the specified maintenance domain.</p> <p><b>count <i>count</i></b>—(Optional) Number of ping requests to send. The range of values is from 1 through 65,535. If the count is not specified 4 loopback messages are sent.</p> <p><b><i>host-mac-address</i></b>—(Optional) Unicast or multicast MAC address of the remote host in xx:xx:xx:xx:xx:xx format. For example, this can be a multicast MAC address in the 01:80:c2:00:00:3x format (where x = 0 through 7).</p> <p><b>logical-system <i>logical-system-name</i></b>—(Optional) Run the command for the specified logical system.</p> <p><b>mep <i>identifier</i></b>—(Optional) MEP identifier of the remote host. The default MEP identifier is 1. The range is 1 through 8191.</p> <p><b>size <i>bytes</i></b>—(Optional) The length, in bytes, of the data type, length, and value (TLV) sent in the loopback message. The range of values is from 1 through 1400. The default is 64 bytes.</p> <p><b>wait <i>seconds</i></b>—(Optional) Maximum wait time, in seconds, to send the next loopback message. The range of values is from 1 through 255. The default wait time is 1 second.</p>
<b>Required Privilege Level</b>	network
<b>List of Sample Output</b>	<a href="#">ping ethernet on page 173</a>

**Output Fields** Table 25 on page 173 lists the output fields for the **ping ethernet** command. Output fields are listed in the approximate order in which they appear.

**Table 25: ping ethernet Output Fields**

Field Name	Field Description
<b>PING to</b>	The MAC address of the remote MEP or MIP to which the request message packets are being sent.
<b>Interface</b>	The local Ethernet interface from which the request message packets are being sent.
<b>ping responses</b>	For each loopback message response received, display the number of TLV bytes, the MAC address of the remote MEP or MIP, and the sequence number.
<b>ping statistics</b>	Display totals for the following: <ul style="list-style-type: none"> <li>Request packets transmitted</li> <li>Response packets received</li> <li>Expected response packets not received</li> </ul>

## Sample Output

### ping ethernet

```
user@host> ping ethernet maintenance-domain md0 maintenance-association ma0
00:19:e2:b0:75:9c
  PING to 00:19:e2:b0:75:9c, Interface ge-1/1/1.0
    68 bytes from 00:19:e2:b0:75:9c: 1bm_seq=0
    68 bytes from 00:19:e2:b0:75:9c: 1bm_seq=1
    68 bytes from 00:19:e2:b0:75:9c: 1bm_seq=2
    68 bytes from 00:19:e2:b0:75:9c: 1bm_seq=3
    --- ping statistics ---
    4 packets transmitted, 4 packets received, 0% packet loss
```

## [request interface rebalance \(Aggregated Ethernet for Subscriber Management\)](#)

<b>Syntax</b>	<code>request interface rebalance interface <i>interface-name</i></code>
<b>Release Information</b>	Command introduced in Junos OS Release 11.2.
<b>Description</b>	Manually rebalance the subscribers on an aggregated Ethernet bundle with targeted distribution enabled.
<b>Options</b>	<i>interface-name</i> —Aggregated Ethernet logical interface number.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">request interface rebalance on page 174</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

<code>request interface rebalance</code>	<code>user@host &gt;request interface rebalance interface ae0</code>
--	--



## request interface (revert | switchover) (Aggregated Ethernet Link Protection)

**Syntax** request interface (revert | switchover) aex

**Release Information** Command introduced in Junos OS Release 8.3.

**Description** Manually revert egress traffic from the designated backup link to the designated primary link of an aggregated Ethernet interface for which link protection is enabled, or manually switch egress traffic from the primary link to the backup link. This traffic includes transit traffic and local traffic originated on the router itself.



**NOTE:** When link protection is enabled on an aggregated Ethernet interface, if the primary link fails, the router automatically routes egress traffic to the backup link. However, the router does not automatically route egress traffic back to the primary link when the primary link is subsequently reestablished. Instead, you manually control when to have traffic diverted back to the primary link by issuing the `request interface (revert | switchover) (Aggregated Ethernet Link Protection)` operational command and specifying the `revert` keyword.

On M Series and T Series routers, use the `request interface (revert | switchover) (Adaptive Services)` operational command to manually revert to the primary adaptive services interface or link services interface, or to switch from the primary to the secondary interface. For information about this command, see [request interface \(revert | switchover\) \(Adaptive Services\)](#).

**Options** `revert`—Restores egress traffic processing to the primary link.

`switchover`—Transfers egress traffic processing to the secondary (backup) link.

`aex`—Aggregated Ethernet logical interface number: 0 through 15.

**Required Privilege Level** view

**List of Sample Output** [request interface revert on page 175](#)


**Output Fields** When you enter this command, you are provided feedback on the status of your request.

### Sample Output

`request interface revert` user@host >request interface revert ae1

## request lacp link-switchover

---

<b>Syntax</b>	request lacp link-switchover aex
<b>Release Information</b>	Command introduced in Junos OS Release 9.3.
<b>Description</b>	Manually switch aggregated Ethernet active or standby LACP links.
	<div><p><b>NOTE:</b> Because this command overrides LACP priority calculations, we strongly recommend that you use this command only when the actor (in this case, the Juniper Networks router) is controlling the active or standby link and the partner (peer) is following. This scenario occurs when you configure only the actor for link protection.</p></div>
<b>Options</b>	aex—Aggregated Ethernet logical interface number: 0 through 15.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">request lacp link-switchover aeX on page 176</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request. To view the switchover, use the <b>show lacp interfaces</b> command.

### Sample Output

<code>request lacp link-switchover aeX</code>	<code>user@host &gt;request lacp link-switchover ae0ae0: Request succeeded</code>
---	---

## request protection-group ethernet-aps clear

---

<b>Syntax</b>	<b>request protection-group ethernet-aps clear</b> <b>maintenance-association <i>ma-name</i></b> <b>maintenance-domain <i>md-name</i></b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.2.
<b>Description</b>	On MX series routers, clears the lockout, force switch, manual switch, exercise, and wait-to-restore (WTR) states.
<b>Options</b>	<b>maintenance-association <i>ma-name</i></b> —Specifies an existing maintenance association from the set of configured maintenance associations.  <b>maintenance-domain <i>md-name</i></b> —Specifies an existing maintenance domain from the set of configured maintenance domains.
<b>Required Privilege Level</b>	maintenance

## request protection-group ethernet-aps exercise

---

<b>Syntax</b>	<b>request protection-group ethernet-aps exercise</b> <b>maintenance-association <i>ma-name</i></b> <b>maintenance-domain <i>md-name</i></b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.2.
<b>Description</b>	This command is used on MX series routers to test if APS is operating correctly, it does not interrupt regular APS operations.
<b>Options</b>	<b>maintenance-association <i>ma-name</i></b> —Specifies an existing maintenance association from the set of configured maintenance associations.  <b>maintenance-domain <i>md-name</i></b> —Specifies an existing maintenance domain from the set of configured maintenance domains.
<b>Required Privilege Level</b>	maintenance

## request protection-group ethernet-aps force-switch

---

<b>Syntax</b>	<b>request protection-group ethernet-aps force-switch</b> <b>maintenance-association <i>ma-name</i></b> <b>maintenance-domain <i>md-name</i></b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.2.
<b>Description</b>	On MX Series routers, forces traffic to switch from the active path to the alternate path. If the working path is the active path, traffic will be switched to the protection path. If the protection path is the active path, traffic will be switched to the protection path.
<b>Options</b>	<b>maintenance-association <i>ma-name</i></b> —Specifies an existing maintenance association from the set of configured maintenance associations.  <b>maintenance-domain <i>md-name</i></b> —Specifies an existing maintenance domain from the set of configured maintenance domains.
<b>Required Privilege Level</b>	maintenance

## request protection-group ethernet-aps lockdown

---

<b>Syntax</b>	<b>request protection-group ethernet-aps lockdown</b> <b>maintenance-association <i>ma-name</i></b> <b>maintenance-domain <i>md-name</i></b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.2.
<b>Description</b>	On MX Series routers, configures a lockdown of the protection path, forcing the use of the working path and locking out the protect path regardless of anything else.
<b>Options</b>	<b>maintenance-association <i>ma-name</i></b> —Specifies an existing maintenance association from the set of configured maintenance associations.  <b>maintenance-domain <i>md-name</i></b> —Specifies an existing maintenance domain from the set of configured maintenance domains.
<b>Required Privilege Level</b>	maintenance

## request protection-group ethernet-aps manual-switch

---

<b>Syntax</b>	<b>request protection-group ethernet-aps manual-switch</b> <b>maintenance-association <i>ma-name</i></b> <b>maintenance-domain <i>md-name</i></b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.2.
<b>Description</b>	On MX Series routers, forces traffic to switch from the active path to the alternate path, even in the absence of a failure on the working path. If the working path is the active path, traffic will be switched to the protection path. If the protection path is the active path, traffic will be switched to the protection path.
<b>Options</b>	<b>maintenance-association <i>ma-name</i></b> —Specifies an existing maintenance association from the set of configured maintenance associations.  <b>maintenance-domain <i>md-name</i></b> —Specifies an existing maintenance domain from the set of configured maintenance domains.
<b>Required Privilege Level</b>	maintenance

## show interfaces (Aggregated Ethernet)

<b>Syntax</b>	<pre>show interfaces ae <i>number</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p>
<b>Description</b>	(M Series, T Series, and MX Series routers and EX Series switches) Display status information about the specified aggregated Fast Ethernet or Gigabit Ethernet interface.
<b>Options</b>	<p><b>ae <i>number</i></b>—Display standard information about the specified aggregated Fast Ethernet or Gigabit Ethernet interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information about the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Aggregated Ethernet) on page 187</a></p> <p><a href="#">show interfaces brief (Aggregated Ethernet) on page 187</a></p> <p><a href="#">show interfaces detail (Aggregated Ethernet) on page 187</a></p> <p><a href="#">show interfaces extensive (Aggregated Ethernet) on page 188</a></p> <p><a href="#">show interfaces extensive (Aggregated Ethernet with VLAN Stacking) on page 189</a></p>
<b>Output Fields</b>	Table 26 on page 182 lists the output fields for the <b>show interfaces</b> (Aggregated Ethernet) command. Output fields are listed in the approximate order in which they appear.

Table 26: show interfaces (Aggregated Ethernet) Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
<b>Physical interface</b>	Name of the physical interface and state of the interface.	All levels
<b>Enabled</b>	State of the physical interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Index number of the physical interface, which reflects its initialization sequence.	All levels



Table 26: show interfaces (Aggregated Ethernet) Output Fields (*continued*)

Field Name	Field Description	Level of Output
SNMP ifIndex	SNMP index number for the physical interface.	detail extensive none
Generation	Unique number for use by Juniper Networks technical support only.	detail extensive
Link-level type	Encapsulation being used on the physical interface.	All levels
MTU	Maximum transmission unit size on the physical interface.	All levels
Speed	Speed at which the interface is running.	All levels
Loopback	Loopback status: <b>Enabled</b> or <b>Disabled</b> . If loopback is enabled, type of loopback: <b>Local</b> or <b>Remote</b> .	All levels
Source filtering	Source filtering status: <b>Enabled</b> or <b>Disabled</b> .	All levels
Flow control	Flow control status: <b>Enabled</b> or <b>Disabled</b> .	All levels
Minimum links needed	Number of child links that must be operational for the aggregate interface to be operational.	All levels
Device flags	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
Interface flags	Information about the interface. Possible values are described in the "Interfaces Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
Current address	Configured MAC address.	detail extensive
Hardware address	Hardware MAC address.	detail extensive
Last flapped	Date, time, and how long ago the interface went from down to up or from up to down. The format is <b>Last flapped: year-month-day hours:minutes:seconds timezone (hours:minutes:seconds ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	detail extensive
Input Rate	Input rate in bits per second (bps) and packets per second (pps).	None specified
Output Rate	Output rate in bps and pps.	None specified
Statistics last cleared	Time when the statistics for the interface were last set to zero.	detail extensive

Table 26: show interfaces (Aggregated Ethernet) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number of and rate at which bytes and packets are received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes and rate, in bps, at which bytes are received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes and rate, in bps, at which bytes are transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets and rate, in pps, at which packets are received on the interface.</li> <li>• <b>Output packets</b>—Number of packets and rate, in pps, at which packets are transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of incoming frame aborts and frame check sequence (FCS) errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's random early detection (RED) mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid FCS.</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or were not of interest. Usually, this field reports protocols that Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>detail extensive</b>
<b>Output errors</b>	<p>Output errors on the interface:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b> —Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), then the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>detail extensive</b>
<b>IPv6 transit statistics</b>	<p>Number of IPv6 transit bytes and packets received and transmitted on the physical interface if IPv6 statistics tracking is enabled.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 26: show interfaces (Aggregated Ethernet) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Queue counters</b>	CoS queue number and its associated user-configured forwarding class name. <ul style="list-style-type: none"> <li><b>Queued packets</b>—Number of queued packets.</li> <li><b>Transmitted packets</b>—Number of transmitted packets.</li> <li><b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface (which reflects its initialization sequence).	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP interface index number of the logical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>VLAN-Tag</b>	Tag Protocol Identifier (TPID) and VLAN identifier.	All levels
<b>Demux</b>	IP demultiplexing (demux) value that appears if this interface is used as the demux underlying interface. The output is one of the following: <ul style="list-style-type: none"> <li><b>Source Family Inet</b></li> <li><b>Destination Family Inet</b></li> </ul>	<b>detail extensive</b> none
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Statistics</b>	Information about the number of packets, packets per second, number of bytes, and bytes per second on this aggregate interface. <ul style="list-style-type: none"> <li><b>Bundle</b>—Information about input and output bundle rates.</li> <li><b>Link</b>—(<b>detail</b> and <b>extensive</b> only) Information about specific links in the aggregate, including link state and input and output rates.</li> <li><b>Marker Statistics</b>—(<b>detail</b> and <b>extensive</b> only) Information about 802.3ad marker protocol statistics on the specified links. <ul style="list-style-type: none"> <li><b>Marker Rx</b>—Number of valid marker protocol data units (PDUs) received on this aggregation port.</li> <li><b>Resp Tx</b>—Number of marker response PDUs transmitted on this aggregation port.</li> <li><b>Unknown Rx</b>—Number of frames received that either carry the slow protocols Ethernet type value (43B.4) but contain an unknown PDU, or are addressed to the slow protocols group MAC address (43B.3) but do not carry the slow protocols Ethernet type.</li> <li><b>Illegal Rx</b>—Number of frames received that carry the slow protocols Ethernet type value (43B.4) but contain a badly formed PDU or an illegal value of protocol subtype (43B.4).</li> </ul> </li> </ul>	<b>detail extensive</b> none

Table 26: show interfaces (Aggregated Ethernet) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<i>protocol-family</i>	Protocol family configured on the logical interface. Possible values are described in the "Protocol Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface. Possible values are described in the "Protocol Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive none</b>
<b>MTU</b>	Maximum transmission unit size on the logical interface.	<b>detail extensive none</b>
<b>Maximum labels</b>	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about protocol family flags. Possible values are described in the "Family Flags Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive none</b>
<b>Mac-Validate Failures</b>	Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface.	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about address flags. Possible values are described in the "Addresses Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces (Aggregated Ethernet)

```

user@host> show interfaces ae0
Physical interface: ae0, Enabled, Physical link is Up
  Interface index: 153, SNMP ifIndex: 59
  Link-level type: Ethernet, MTU: 1514, Speed: 300mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1
  Device flags   : Present Running
  Interface flags: SNMP-Traps 16384
  Current address: 00:05:85:8b:bf:f0, Hardware address: 00:05:85:8b:bf:f0
  Last flapped   : Never
  Input rate      : 0 bps (0 pps)
  Output rate     : 0 bps (0 pps)

Logical interface ae0.0 (Index 72) (SNMP ifIndex 60)
  Flags: SNMP-Traps 16384 Encapsulation: ENET2
  Statistics
  Bundle:
    Input :           0           0           0           0
    Output:           0           0           0           0
  Protocol inet, MTU: 1500
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.100.1/24, Local: 10.100.1.2, Broadcast: 10.100.1.255

```

### show interfaces brief (Aggregated Ethernet)

```

user@host> show interfaces ae0 brief
Physical interface: ae0, Enabled, Physical link is Up
  Link-level type: Ethernet, MTU: 1514, Speed: 300mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Disabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps 16384

Logical interface ae0.0
  Flags: SNMP-Traps 16384 Encapsulation: ENET2
  inet 10.100.1.2/24

```

### show interfaces detail (Aggregated Ethernet)

```

user@host> show interfaces ae0 detail
Physical interface: ae0, Enabled, Physical link is Up
  Interface index: 153, SNMP ifIndex: 59, Generation: 36
  Link-level type: Ethernet, MTU: 1514, Speed: 300mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1
  Device flags   : Present Running
  Interface flags: SNMP-Traps 16384
  Current address: 00:05:85:8b:bf:f0, Hardware address: 00:05:85:8b:bf:f0
  Last flapped   : Never
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :           0           0 bps
    Output bytes:           0           0 bps
    Input packets:          0           0 pps
    Output packets:         0           0 pps
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort           7375           7375           0
    1 expedited-fo           0           0           0
    2 assured-forw           0           0           0

```

3 network-cont	2268	2268	0
----------------	------	------	---

Logical interface ae0.0 (Index 72) (SNMP ifIndex 60) (Generation 18)

Flags: SNMP-Traps 16384 Encapsulation: ENET2

Statistics	Packets	pps	Bytes	bps
------------	---------	-----	-------	-----

Bundle:

Input :	0	0	0	0
Output:	0	0	0	0

Link:

fe-0/1/0.0

Input :	0	0	0	0
Output:	0	0	0	0

fe-0/1/2.0

Input :	0	0	0	0
Output:	0	0	0	0

fe-0/1/3.0

Input :	0	0	0	0
Output:	0	0	0	0

Marker Statistics:	Marker Rx	Resp Tx	Unknown Rx	Illegal Rx
--------------------	-----------	---------	------------	------------

fe-0/1/0.0	0	0	0	0
------------	---	---	---	---

fe-0/1/2.0	0	0	0	0
------------	---	---	---	---

fe-0/1/3.0	0	0	0	0
------------	---	---	---	---

Protocol inet, MTU: 1500, Generation: 37, Route table: 0

Flags: Is-Primary, Mac-Validate-Strict

Mac-Validate Failures: Packets: 0, Bytes: 0

Destination: 10.100.1/24, Local: 10.100.1.2, Broadcast: 10.100.1.255,

Generation: 49

### show interfaces extensive (Aggregated Ethernet)

user@host> show interfaces ae0 extensive

Physical interface: ae0, Enabled, Physical link is Up

Interface index: 153, SNMP ifIndex: 59, Generation: 36

Link-level type: Ethernet, MTU: 1514, Speed: 300mbps, Loopback: Disabled,

Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1

Device flags : Present Running

Interface flags: SNMP-Traps 16384

Current address: 00:05:85:8b:bf:f0, Hardware address: 00:05:85:8b:bf:f0

Last flapped : Never

Statistics last cleared: Never

Traffic statistics:

Input bytes :	60	0 bps
---------------	----	-------

Output bytes :	0	0 bps
----------------	---	-------

Input packets:	1	0 pps
----------------	---	-------

Output packets:	0	0 pps
-----------------	---	-------

Input errors:

Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,

Policed discards: 0, Resource errors: 0

Output errors:

Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,

Resource errors: 0

Queue counters:	Queued packets	Transmitted packets	Dropped packets
-----------------	----------------	---------------------	-----------------

0 best-effort	7375	7375	0
---------------	------	------	---

1 expedited-fo	0	0	0
----------------	---	---	---

2 assured-forw	0	0	0
----------------	---	---	---

3 network-cont	2268	2268	0
----------------	------	------	---

```

Logical interface ae0.0 (Index 72) (SNMP ifIndex 60) (Generation 18)
Flags: SNMP-Traps 16384 Encapsulation: ENET2
Statistics          Packets          pps          Bytes          bps
Bundle:
  Input :           1           0           60           0
  Output:           0           0           0           0
Link:
  fe-0/1/0.0
    Input :           0           0           0           0
    Output:           0           0           0           0
  fe-0/1/2.0
    Input :           0           0           0           0
    Output:           0           0           0           0
  fe-0/1/3.0
    Input :           1           0           60           0
    Output:           0           0           0           0
Marker Statistics:  Marker Rx      Resp Tx      Unknown Rx      Illegal Rx
fe-0/1/0.0          0          0          0          0
fe-0/1/2.0          0          0          0          0
fe-0/1/3.0          0          0          0          0
Protocol inet, MTU: 1500, Generation: 37, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 10.100.1/24, Local: 10.100.1.2, Broadcast: 10.100.1.255,
  Generation: 49

```

show interfaces  
extensive (Aggregated

```

user@host> show interfaces ae0 extensive
Physical interface: ae0, Enabled, Physical link is Up
Interface index: 155, SNMP ifIndex: 48, Generation: 186

```

Ethernet with VLAN  
Stacking)

```

Link-level type: 52, MTU: 1518, Speed: 2000mbps, Loopback: Disabled, Source
filtering: Disabled,
Flow control: Disabled, Minimum links needed: 1, Minimum bandwidth needed: 0
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Current address: 00:12:1e:19:3f:f0, Hardware address: 00:12:1e:19:3f:f0
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes :          2406875          40152 bps
Output bytes :        1124470          22056 bps
Input packets:           5307           5 pps
Output packets:         13295          21 pps
IPv6 transit statistics:
Input bytes :           0
Output bytes :           0
Input packets:           0
Output packets:          0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0
Ingress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort              0              859777              0
  1 expedited-fo             0              0              0
  2 assured-forw             0              0              0
  3 network-cont             0              0              0

Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort              0          1897615              0
  1 expedited-fo             0              0              0
  2 assured-forw             0              0              0
  3 network-cont             0          662505              0

Logical interface ae0.451 (Index 69) (SNMP ifIndex 167) (Generation 601)
Flags: SNMP-Traps VLAN-Tag [ 0x8100.451 ] Encapsulation: VLAN-VPLS
Statistics      Packets      pps      Bytes      bps
Bundle:
  Input :          289          0          25685          376
  Output:         1698          4          130375          3096
Link:
  ge-1/2/0.451
    Input :          289          0          25685          376
    Output:           0          0              0              0
  ge-1/2/1.451
    Input :           0          0              0              0
    Output:         1698          4          130375          3096
Marker Statistics:  Marker Rx      Resp Tx      Unknown Rx      Illegal Rx

```



```

ge-1/2/0.451          0          0          0          0
ge-1/2/1.451          0          0          0          0
Protocol vpls, MTU: 1518, Generation: 849, Route table: 3
Flags: Is-Primary

```

Logical interface ae0.452 (Index 70) (SNMP ifIndex 170) (Generation 602)

Flags: SNMP-Traps VLAN-Tag [ 0x8100.452 ] Encapsulation: VLAN-VPLS

Statistics	Packets	pps	Bytes	bps
------------	---------	-----	-------	-----

Bundle:

Input :	293	1	26003	1072
Output:	1694	3	130057	2400

Link:

ge-1/2/0.452				
Input :	293	1	26003	1072
Output:	1694	3	130057	2400

ge-1/2/1.452				
Input :	0	0	0	0
Output:	0	0	0	0

Marker Statistics:	Marker Rx	Resp Tx	Unknown Rx	Illegal Rx
--------------------	-----------	---------	------------	------------

ge-1/2/0.452	0	0	0	0
ge-1/2/1.452	0	0	0	0

Protocol vpls, MTU: 1518, Generation: 850, Route table: 3

Flags: None

...

## show interfaces (far-end-interval)

<b>Syntax</b>	<code>show interfaces far-end-interval <i>interface-fpc/pic/port</i></code>
<b>Release Information</b>	Command introduced in Junos OS Release 9.4.
<b>Description</b>	On channelized interfaces, display the far end interval data for the specified interface.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces far-end-interval coc12-5/2/0 on page 193</a> <a href="#">show interfaces far-end-interval coc1-5/2/1:1 on page 193</a>
<b>Output Fields</b>	<a href="#">Table 27 on page 192</a> lists the output fields for the <b>show interfaces far-end-interval</b> command. Output fields are listed in the approximate order in which they appear.

Table 27: show interfaces far-end-interval Output Fields

Field Name	Field Description
Physical interface	Interface FPC/PIC/port values.
SNMP ifIndex	SNMP interface index value.
ES-L/P	Error detection—Errored seconds.
SES-L/P	Error detection—Severely errored seconds.
UAS-L/P	Error detection—Unavailable seconds.

## Sample Output

```
show interfaces
far-end-interval
coc12-5/2/0
```

```
user@host> show interfaces far-end-interval coc12-5/2/0
Physical interface: coc12-5/2/0, SNMP ifIndex: 121
05:30-current:
  ES-L: 1, SES-L: 1, UAS-L: 0
05:15-05:30:
  ES-L: 0, SES-L: 0, UAS-L: 0
05:00-05:15:
  ES-L: 0, SES-L: 0, UAS-L: 0
04:45-05:00:
  ES-L: 0, SES-L: 0, UAS-L: 0
04:30-04:45:
  ES-L: 0, SES-L: 0, UAS-L: 0
04:15-04:30:
  ES-L: 0, SES-L: 0, UAS-L: 0
04:00-04:15:
...
```

```
show interfaces
far-end-interval
coc1-5/2/1:1
```

```
user@host> run show interfaces far-end-interval coc1-5/2/1:1
Physical interface: coc1-5/2/1:1, SNMP ifIndex: 342
05:30-current:
  ES-L: 1, SES-L: 1, UAS-L: 0, ES-P: 0, SES-P: 0, UAS-P: 0
05:15-05:30:
  ES-L: 0, SES-L: 0, UAS-L: 0, ES-P: 0, SES-P: 0, UAS-P: 0
05:00-05:15:
  ES-L: 0, SES-L: 0, UAS-L: 0, ES-P: 0, SES-P: 0, UAS-P: 0
04:45-05:00:
  ES-L: 0, SES-L: 0, UAS-L: 0, ES-P: 0, SES-P: 0, UAS-P: 0
04:30-04:45:
  ES-L: 0, SES-L: 0, UAS-L: 0, ES-P: 0, SES-P: 0, UAS-P: 0
04:15-04:30:
  ES-L: 0, SES-L: 0, UAS-L: 0, ES-P: 0, SES-P: 0, UAS-P: 0
04:00-04:15:
```

## show interfaces (Fast Ethernet)

<b>Syntax</b>	<pre>show interfaces <i>interface-type</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified Fast Ethernet interface.
<b>Options</b>	<p><b><i>interface-type</i></b>—On M Series and T Series routers, the interface type is <b><i>fe-fpc/pic/port</i></b>. On the J Series routers, the interface type is <b><i>fe-pim/O/port</i></b>.</p> <p><b><i>brief   detail   extensive   terse</i></b>—(Optional) Display the specified level of output.</p> <p><b><i>descriptions</i></b>—(Optional) Display interface description strings.</p> <p><b><i>media</i></b>—(Optional) Display media-specific information about network interfaces.</p> <p><b><i>snmp-index snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b><i>statistics</i></b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Fast Ethernet) on page 209</a></p> <p><a href="#">show interfaces brief (Fast Ethernet) on page 209</a></p> <p><a href="#">show interfaces detail (Fast Ethernet) on page 209</a></p> <p><a href="#">show interfaces extensive (Fast Ethernet) on page 210</a></p>
<b>Output Fields</b>	<p><a href="#">Table 28 on page 194</a> lists the output fields for the <b>show interfaces Fast Ethernet</b> command. Output fields are listed in the approximate order in which they appear.</p>

**Table 28: show interfaces Fast Ethernet Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the "Enabled Field" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Interface index</b>	Index number of the physical interface, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit size on the physical interface.	All levels
<b>Link-mode</b>	Type of link connection configured for the physical interface: <b>Full-duplex</b> or <b>Half-duplex</b>	<b>extensive</b>
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Loopback status: <b>Enabled</b> or <b>Disabled</b> . If loopback is enabled, type of loopback: <b>Local</b> or <b>Remote</b> .	All levels
<b>Source filtering</b>	Source filtering status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>LAN-PHY mode</b>	10-Gigabit Ethernet interface operating in Local Area Network Physical Layer Device (LAN PHY) mode. LAN PHY allows 10-Gigabit Ethernet wide area links to use existing Ethernet applications.	All levels
<b>WAN-PHY mode</b>	10-Gigabit Ethernet interface operating in Wide Area Network Physical Layer Device (WAN PHY) mode. WAN PHY allows 10-Gigabit Ethernet wide area links to use fiber-optic cables and other devices intended for SONET/SDH.	All levels
<b>Unidirectional</b>	Unidirectional link mode status for 10-Gigabit Ethernet interface: <b>Enabled</b> or <b>Disabled</b> for parent interface; <b>Rx-only</b> or <b>Tx-only</b> for child interfaces.	All levels
<b>Flow control</b>	Flow control status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>Auto-negotiation</b>	(Gigabit Ethernet interfaces) Autonegotiation status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>Remote-fault</b>	(Gigabit Ethernet interfaces) Remote fault status: <ul style="list-style-type: none"> <li>• <b>Online</b>—Autonegotiation is manually configured as online.</li> <li>• <b>Offline</b>—Autonegotiation is manually configured as offline.</li> </ul>	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Links Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Wavelength</b>	(10-Gigabit Ethernet dense wavelength-division multiplexing [DWDM] interfaces) Displays the configured wavelength, in nanometers (nm).	All levels

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Frequency</b>	(10-Gigabit Ethernet DWDM interfaces only) Displays the frequency associated with the configured wavelength, in terahertz (THz).	All levels
<b>CoS queues</b>	Number of CoS queues configured.	<b>detail extensive</b> none
<b>Schedulers</b>	(GigabitEthernet intelligent queuing 2 (IQ2) interfaces only) Number of CoS schedulers configured.	<b>extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b> none
<b>Hardware address</b>	Hardware MAC address.	<b>detail extensive</b> none
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second:timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive</b> none
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul> <p>Gigabit Ethernet and 10-Gigabit Ethernet IQ PICs count the overhead and CRC bytes.</p> <p>For Gigabit Ethernet IQ PICs, the input byte counts vary by interface type. For more information, see Table 31 under the <a href="#">show interfaces (10-Gigabit Ethernet)</a> command.</p>	<b>detail extensive</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded. L3 incomplete errors can be ignored by configuring the <b>ignore-l3-incompletes</b> statement.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the receive direction that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Collisions</b>—Number of Ethernet collisions. The Gigabit Ethernet PIC supports only full-duplex operation, so for Gigabit Ethernet PICs, this number should always remain 0. If it is nonzero, there is a software bug.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the send direction as reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters (Egress)</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Ingress queues</b>	Total number of ingress queues supported on the specified interface. Displayed on IQ2 interfaces.	<b>extensive</b>
<b>Queue counters (Ingress)</b>	<p>CoS queue number and its associated user-configured forwarding class name. Displayed on IQ2 interfaces.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>extensive</b>



Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Active alarms and Active defects</b>	<p>Ethernet-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. These fields can contain the value <b>None</b> or <b>Link</b>.</p> <ul style="list-style-type: none"> <li>• <b>None</b>—There are no active defects or alarms.</li> <li>• <b>Link</b>—Interface has lost its link state, which usually means that the cable is unplugged, the far-end system has been turned off, or the PIC is malfunctioning.</li> </ul>	<b>detail extensive none</b>
<b>OTN FEC statistics</b>	<p>The forward error correction (FEC) counters provide the following statistics:</p> <ul style="list-style-type: none"> <li>• <b>Corrected Errors</b>—The count of corrected errors in the last second.</li> <li>• <b>Corrected Error Ratio</b>—The corrected error ratio in the last 25 seconds. For example, 1e-7 is 1 error per 10 million bits.</li> </ul>	
<b>PCS statistics</b>	<p>(10-Gigabit Ethernet interfaces) Displays Physical Coding Sublayer (PCS) fault conditions from the WAN PHY or the LAN PHY device.</p> <ul style="list-style-type: none"> <li>• <b>Bit errors</b>—High bit error rate. Indicates the number of bit errors when the PCS receiver is operating in normal mode.</li> <li>• <b>Errored blocks</b>—Loss of block lock. The number of errored blocks when PCS receiver is operating in normal mode.</li> </ul>	<b>detail extensive</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
MAC statistics	<p>Receive and Transmit statistics reported by the PIC's MAC subsystem, including the following:</p> <ul style="list-style-type: none"> <li>• <b>Total octets</b> and <b>total packets</b>—Total number of octets and packets. For Gigabit Ethernet IQ PICs, the received octets count varies by interface type. For more information, see Table 31 under the <a href="#">show interfaces (10-Gigabit Ethernet)</a> command.</li> <li>• <b>Unicast packets</b>, <b>Broadcast packets</b>, and <b>Multicast packets</b>—Number of unicast, broadcast, and multicast packets.</li> <li>• <b>CRC/Align errors</b>—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error).</li> <li>• <b>FIFO error</b>—Number of FIFO errors that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC or a cable is probably malfunctioning.</li> <li>• <b>MAC control frames</b>—Number of MAC control frames.</li> <li>• <b>MAC pause frames</b>—Number of MAC control frames with <b>pause</b> operational code.</li> <li>• <b>Oversized frames</b>—Number of frames that exceed 1518 octets.</li> <li>• <b>Jabber frames</b>—Number of frames that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is from 20 ms to 150 ms.</li> <li>• <b>Fragment frames</b>—Total number of packets that were less than 64 octets in length (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. Fragment frames normally increment because both runts (which are normal occurrences caused by collisions) and noise hits are counted.</li> <li>• <b>VLAN tagged frames</b>—Number of frames that are VLAN tagged. The system uses the TPID of 0x8100 in the frame to determine whether a frame is tagged or not.</li> <li>• <b>Code violations</b>—Number of times an event caused the PHY to indicate "Data reception error" or "invalid data symbol error."</li> </ul>	extensive
OTN Received Overhead Bytes	APS/PCC0: 0x02, APS/PCC1: 0x11, APS/PCC2: 0x47, APS/PCC3: 0x58 Payload Type: 0x08	extensive
OTN Transmitted Overhead Bytes	APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00 Payload Type: 0x08	extensive

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Filter statistics</b>	<p><b>Receive</b> and <b>Transmit</b> statistics reported by the PIC's MAC address filter subsystem. The filtering is done by the content-addressable memory (CAM) on the PIC. The filter examines a packet's source and destination MAC addresses to determine whether the packet should enter the system or be rejected.</p> <ul style="list-style-type: none"> <li>• <b>Input packet count</b>—Number of packets received from the MAC hardware that the filter processed.</li> <li>• <b>Input packet rejects</b>—Number of packets that the filter rejected because of either the source MAC address or the destination MAC address.</li> <li>• <b>Input DA rejects</b>—Number of packets that the filter rejected because the destination MAC address of the packet is not on the accept list. It is normal for this value to increment. When it increments very quickly and no traffic is entering the router from the far-end system, either there is a bad ARP entry on the far-end system, or multicast routing is not on and the far-end system is sending many multicast packets to the local router (which the router is rejecting).</li> <li>• <b>Input SA rejects</b>—Number of packets that the filter rejected because the source MAC address of the packet is not on the accept list. The value in this field should increment only if source MAC address filtering has been enabled. If filtering is enabled, if the value increments quickly, and if the system is not receiving traffic that it should from the far-end system, it means that the user-configured source MAC addresses for this interface are incorrect.</li> <li>• <b>Output packet count</b>—Number of packets that the filter has given to the MAC hardware.</li> <li>• <b>Output packet pad count</b>—Number of packets the filter padded to the minimum Ethernet size (60 bytes) before giving the packet to the MAC hardware. Usually, padding is done only on small ARP packets, but some very small IP packets can also require padding. If this value increments rapidly, either the system is trying to find an ARP entry for a far-end system that does not exist or it is misconfigured.</li> <li>• <b>Output packet error count</b>—Number of packets with an indicated error that the filter was given to transmit. These packets are usually aged packets or are the result of a bandwidth problem on the FPC hardware. On a normal system, the value of this field should not increment.</li> <li>• <b>CAM destination filters, CAM source filters</b>—Number of entries in the CAM dedicated to destination and source MAC address filters. There can only be up to 64 source entries. If source filtering is disabled, which is the default, the values for these fields should be 0.</li> </ul>	<b>extensive</b>
<b>PMA PHY</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PHY Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>WIS section</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B1</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>LOL</b>—Loss of light</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>ES-S</b>—Errored seconds (section)</li> <li>• <b>SES-S</b>—Severely errored seconds (section)</li> <li>• <b>SEFS-S</b>—Severely errored framing seconds (section)</li> </ul>	<b>extensive</b>
<b>WIS line</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>REI-L</b>—Remote error indication (near-end line)</li> <li>• <b>RDI-L</b>—Remote defect indication (near-end line)</li> <li>• <b>AIS-L</b>—Alarm indication signal (near-end line)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>ES-L</b>—Errored seconds (near-end line)</li> <li>• <b>SES-L</b>—Severely errored seconds (near-end line)</li> <li>• <b>UAS-L</b>—Unavailable seconds (near-end line)</li> <li>• <b>ES-LFE</b>—Errored seconds (far-end line)</li> <li>• <b>SES-LFE</b>—Severely errored seconds (far-end line)</li> <li>• <b>UAS-LFE</b>—Unavailable seconds (far-end line)</li> </ul>	<b>extensive</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>WIS path</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B3</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>REI-P</b>—Remote error indication</li> <li>• <b>LOP-P</b>—Loss of pointer (path)</li> <li>• <b>AIS-P</b>—Path alarm indication signal</li> <li>• <b>RDI-P</b>—Path remote defect indication</li> <li>• <b>UNEQ-P</b>—Path unequipped</li> <li>• <b>PLM-P</b>—Path payload (signal) label mismatch</li> <li>• <b>ES-P</b>—Errored seconds (near-end STS path)</li> <li>• <b>SES-P</b>—Severely errored seconds (near-end STS path)</li> <li>• <b>UAS-P</b>—Unavailable seconds (near-end STS path)</li> <li>• <b>SES-PFE</b>—Severely errored seconds (far-end STS path)</li> <li>• <b>UAS-PFE</b>—Unavailable seconds (far-end STS path)</li> </ul>	<b>extensive</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
Autonegotiation information	<p>Information about link autonegotiation.</p> <ul style="list-style-type: none"> <li>• <b>Negotiation status:</b> <ul style="list-style-type: none"> <li>• <b>Incomplete</b>—Ethernet interface has the speed or link mode configured.</li> <li>• <b>No autonegotiation</b>—Remote Ethernet interface has the speed or link mode configured, or does not perform autonegotiation.</li> <li>• <b>Complete</b>—Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> </ul> </li> <li>• <b>Link partner status</b>—OK when Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> <li>• <b>Link partner:</b> <ul style="list-style-type: none"> <li>• <b>Link mode</b>—Depending on the capability of the attached Ethernet device, either <b>Full-duplex</b> or <b>Half-duplex</b>.</li> <li>• <b>Flow control</b>—Types of flow control supported by the remote Ethernet device. For Fast Ethernet interfaces, the type is <b>None</b>. For Gigabit Ethernet interfaces, types are <b>Symmetric</b> (link partner supports <b>PAUSE</b> on receive and transmit), <b>Asymmetric</b> (link partner supports <b>PAUSE</b> on transmit), and <b>Symmetric/Asymmetric</b> (link partner supports both <b>PAUSE</b> on receive and transmit or only <b>PAUSE</b> receive).</li> <li>• <b>Remote fault</b>—Remote fault information from the link partner—<b>Failure</b> indicates a receive link error. <b>OK</b> indicates that the link partner is receiving. <b>Negotiation error</b> indicates a negotiation error. <b>Offline</b> indicates that the link partner is going offline.</li> </ul> </li> <li>• <b>Local resolution</b>—Information from the link partner: <ul style="list-style-type: none"> <li>• <b>Flow control</b>—Types of flow control supported by the remote Ethernet device. For Gigabit Ethernet interfaces, types are <b>Symmetric</b> (link partner supports <b>PAUSE</b> on receive and transmit), <b>Asymmetric</b> (link partner supports <b>PAUSE</b> on transmit), and <b>Symmetric/Asymmetric</b> (link partner supports both <b>PAUSE</b> on receive and transmit or only <b>PAUSE</b> receive).</li> <li>• <b>Remote fault</b>—Remote fault information. <b>Link OK</b> (no error detected on receive), <b>Offline</b> (local interface is offline), and <b>Link Failure</b> (link error detected on receive).</li> </ul> </li> </ul>	extensive
Received path trace, Transmitted path trace	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits.</p>	extensive
Packet Forwarding Engine configuration	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> </ul>	extensive

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	<p>Information about the CoS queue for the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP interface index number for the logical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>VLAN-Tag</b>	<p>Rewrite profile applied to incoming or outgoing frames on the outer (<b>Out</b>) VLAN tag or for both the outer and inner (<b>In</b>) VLAN tags.</p> <ul style="list-style-type: none"> <li>• <b>push</b>—An outer VLAN tag is pushed in front of the existing VLAN tag.</li> <li>• <b>pop</b>—The outer VLAN tag of the incoming frame is removed.</li> <li>• <b>swap</b>—The outer VLAN tag of the incoming frame is overwritten with the user specified VLAN tag information.</li> <li>• <b>push</b>—An outer VLAN tag is pushed in front of the existing VLAN tag.</li> <li>• <b>push-push</b>—Two VLAN tags are pushed in from the incoming frame.</li> <li>• <b>swap-push</b>—The outer VLAN tag of the incoming frame is replaced by a user-specified VLAN tag value. A user-specified outer VLAN tag is pushed in front. The outer tag becomes an inner tag in the final frame.</li> <li>• <b>swap-swap</b>—Both the inner and the outer VLAN tags of the incoming frame are replaced by the user specified VLAN tag value.</li> <li>• <b>pop-swap</b>—The outer VLAN tag of the incoming frame is removed, and the inner VLAN tag of the incoming frame is replaced by the user-specified VLAN tag value. The inner tag becomes the outer tag in the final frame.</li> <li>• <b>pop-pop</b>—Both the outer and inner VLAN tags of the incoming frame are removed.</li> </ul>	<b>brief detail extensive</b> none
<b>Demux:</b>	<p>IP demultiplexing (demux) value that appears if this interface is used as the demux underlying interface. The output is one of the following:</p> <ul style="list-style-type: none"> <li>• Source Family Inet</li> <li>• Destination Family Inet</li> </ul>	<b>detail extensive</b> none
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Protocol</b>	Protocol family. Possible values are described in the “Protocol Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	<b>detail extensive</b> none
<b>MTU</b>	Maximum transmission unit size on the logical interface.	<b>detail extensive</b> none
<b>Maximum labels</b>	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	<b>detail extensive</b> none
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the specified interface set.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface set</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface set.</li> </ul>	<b>detail extensive</b>
<b>IPv6 transit statistics</b>	Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.	<b>extensive</b>
<b>Local statistics</b>	Number and rate of bytes and packets destined to the router.	<b>extensive</b>



Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Transit statistics</b>	Number and rate of bytes and packets transiting the switch.  <b>NOTE:</b> For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the <b>Output bytes</b> and <b>Output packets</b> interface counters. However, correct values display for both of these egress statistics when per-unit scheduling is enabled for the Gigabit Ethernet IQ2 physical interface, or when a single logical interface is actively using a shared scheduler.	<b>extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Route table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive none</b>
<b>Flags</b>	Information about protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Donor interface</b>	(Unnumbered Ethernet) Interface from which an unnumbered Ethernet interface borrows an IPv4 address.	<b>detail extensive none</b>
<b>Preferred source address</b>	(Unnumbered Ethernet) Secondary IPv4 address of the donor loopback interface that acts as the preferred source address for the unnumbered Ethernet interface.	<b>detail extensive none</b>
<b>Input Filters</b>	Names of any input filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parenthesis next to all interfaces.	<b>detail extensive</b>
<b>Output Filters</b>	Names of any output filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parenthesis next to all interfaces.	<b>detail extensive</b>
<b>Mac-Validate Failures</b>	Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface.	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Flags</b>	Information about address flag (possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interlace.	<b>detail extensive none</b>

Table 28: show interfaces Fast Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

---

## Sample Output

### show interfaces (Fast Ethernet)

```
user@host> show interfaces fe-0/0/0
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 22
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 4 supported, 4 maximum usable queues
  Current address: 00:05:85:02:38:00, Hardware address: 00:05:85:02:38:00
  Last flapped   : 2006-01-20 14:50:58 PST (2w4d 00:44 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  Active alarms  : None
  Active defects : None
Logical interface fe-0/0/0.0 (Index 66) (SNMP ifIndex 198)
  Flags: SNMP-Traps Encapsulation: ENET2
  Protocol inet, MTU: 1500
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.10.10/24, Local: 10.10.10.1, Broadcast: 10.10.10.255
```

### show interfaces brief (Fast Ethernet)

```
user@host> show interfaces fe-0/0/0 brief
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
Logical interface fe-0/0/0.0
  Flags: SNMP-Traps Encapsulation: ENET2
  inet 10.10.10.1/24
```

### show interfaces detail (Fast Ethernet)

```
user@host> show interfaces fe-0/0/0 detail
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 22, Generation: 5391
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 4 supported, 4 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:05:85:02:38:00, Hardware address: 00:05:85:02:38:00
  Last flapped   : 2006-01-20 14:50:58 PST (2w4d 00:45 ago)
  Statistics last cleared: Never
Traffic statistics:
  Input bytes   : 0          0 bps
  Output bytes  : 42         0 bps
  Input packets: 0          0 pps
  Output packets: 1         0 pps
Active alarms  : None
Active defects : None
Logical interface fe-0/0/0.0 (Index 66) (SNMP ifIndex 198) (Generation 67)
  Flags: SNMP-Traps Encapsulation: ENET2
  Protocol inet, MTU: 1500, Generation: 105, Route table: 0
    Flags: Is-Primary, Mac-Validate-Strict
    Mac-Validate Failures: Packets: 0, Bytes: 0
    Addresses, Flags: Is-Preferred Is-Primary
```

Destination: 10.10.10/24, Local: 10.10.10.1, Broadcast: 10.10.10.255,  
Generation: 136

**show interfaces  
extensive  
(Fast Ethernet)**

```

user@host> show interfaces fe-0/0/0 extensive
Physical interface: fe-0/0/0, Enabled, Physical link is Up
Interface index: 128, SNMP ifIndex: 22, Generation: 5391
Link-level type: Ethernet, MTU: 1514, Link-mode: Full-duplex, Speed:
100Mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
CoS queues     : 4 supported, 4 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:05:85:02:38:00, Hardware address: 00:05:85:02:38:00
Last flapped   : 2006-01-20 14:50:58 PST (2w4d 00:46 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   :                0                0 bps
Output bytes  :                42                0 bps
Input packets :                0                0 pps
Output packets:                1                0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 3, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Active alarms : None
Active defects : None
MAC statistics:
Total octets      Receive      Transmit
Total packets    0          64
Unicast packets  0          1
Broadcast packets 0          1
Multicast packets 0          0
CRC/Align errors 0          0
FIFO errors       0          0
MAC control frames 0          0
MAC pause frames  0          0
Oversized frames  0
Jabber frames     0
Fragment frames   0
VLAN tagged frames 0
Code violations    0
Filter statistics:
Input packet count      0
Input packet rejects    0
Input DA rejects        0
Input SA rejects        0
Output packet count     1
Output packet pad count 0
Output packet error count 0
CAM destination filters: 1, CAM source filters: 0
Autonegotiation information:
Negotiation status: Complete
Link partner:
Link partner: Full-duplex, Flow control: None, Remote fault: Ok
Local resolution:
Packet Forwarding Engine configuration:

```

```
Destination slot: 0
CoS information:
      Bandwidth      Buffer Priority  Limit
              %      bps    %      usec
0 best-effort      95    950000000  95         0    low  none
3 network-control   5     50000000   5         0    low  none
Logical interface fe-0/0/0.0 (Index 66) (SNMP ifIndex 198) (Generation 67)
Flags: SNMP-Traps Encapsulation: ENET2
Protocol inet, MTU: 1500, Generation: 105, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 10.10.10/24, Local: 10.10.10.1, Broadcast: 10.10.10.255,
  Generation: 136
```

## show interfaces (Gigabit Ethernet)

<b>Syntax</b>	<pre>show interfaces <i>ge-fpc/pic/port</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series, T Series, and MX Series routers only) Display status information about the specified Gigabit Ethernet interface.
<b>Options</b>	<p><b><i>ge-fpc/pic/port</i></b>—Display standard information about the specified Gigabit Ethernet interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Additional Information</b>	In a logical system, this command displays information only about the logical interfaces and not about the physical interfaces.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying and Managing Agent Circuit Identifier-Based Dynamic VLAN Configuration</li> </ul>
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Gigabit Ethernet) on page 228</a></p> <p><a href="#">show interfaces (Gigabit Ethernet on MX Series Routers) on page 228</a></p> <p><a href="#">show interfaces extensive (Gigabit Ethernet on MX Series Routers showing interface transmit statistics configuration) on page 228</a></p> <p><a href="#">show interfaces brief (Gigabit Ethernet) on page 230</a></p> <p><a href="#">show interfaces detail (Gigabit Ethernet) on page 230</a></p> <p><a href="#">show interfaces extensive (Gigabit Ethernet IQ2) on page 231</a></p> <p><a href="#">show interfaces (Gigabit Ethernet Unnumbered Interface) on page 234</a></p> <p><a href="#">show interfaces (ACI Interface Set Configured) on page 235</a></p>
<b>Output Fields</b>	<p><a href="#">Table 29 on page 213</a> describes the output fields for the <b>show interfaces</b> (Gigabit Ethernet) command. Output fields are listed in the approximate order in which they appear. For Gigabit Ethernet IQ and IQE PICs, the traffic and MAC statistics vary by interface type. For more information, see <a href="#">Table 30 on page 226</a>.</p>

Table 29: show interfaces Gigabit Ethernet Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Index number of the physical interface, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Loopback status: <b>Enabled</b> or <b>Disabled</b> . If loopback is enabled, type of loopback: <b>Local</b> or <b>Remote</b> .	All levels
<b>Source filtering</b>	Source filtering status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>LAN-PHY mode</b>	10-Gigabit Ethernet interface operating in Local Area Network Physical Layer Device (LAN PHY) mode. LAN PHY allows 10-Gigabit Ethernet wide area links to use existing Ethernet applications.	All levels
<b>WAN-PHY mode</b>	10-Gigabit Ethernet interface operating in Wide Area Network Physical Layer Device (WAN PHY) mode. WAN PHY allows 10-Gigabit Ethernet wide area links to use fiber-optic cables and other devices intended for SONET/SDH.	All levels
<b>Unidirectional</b>	Unidirectional link mode status for 10-Gigabit Ethernet interface: <b>Enabled</b> or <b>Disabled</b> for parent interface; <b>Rx-only</b> or <b>Tx-only</b> for child interfaces.	All levels
<b>Flow control</b>	Flow control status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>Auto-negotiation</b>	(Gigabit Ethernet interfaces) Autonegotiation status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>Remote-fault</b>	(Gigabit Ethernet interfaces) Remote fault status: <ul style="list-style-type: none"> <li>• <b>Online</b>—Autonegotiation is manually configured as online.</li> <li>• <b>Offline</b>—Autonegotiation is manually configured as offline.</li> </ul>	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Link flags</b>	Information about the link. Possible values are described in the “Links Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Wavelength</b>	(10-Gigabit Ethernet dense wavelength-division multiplexing [DWDM] interfaces) Displays the configured wavelength, in nanometers (nm).	All levels
<b>Frequency</b>	(10-Gigabit Ethernet DWDM interfaces only) Displays the frequency associated with the configured wavelength, in terahertz (THz).	All levels
<b>CoS queues</b>	Number of CoS queues configured.	<b>detail extensive</b> none
<b>Schedulers</b>	(Gigabit Ethernet intelligent queuing 2 [IQ2] interfaces only) Number of CoS schedulers configured.	<b>extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds (ms).	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b> none
<b>Hardware address</b>	Hardware MAC address.	<b>detail extensive</b> none
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second:timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive</b> none
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None
<b>Output Rate</b>	Output rate in bps and pps.	None
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li><b>Input bytes</b>—Number of bytes received on the interface</li> <li><b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li><b>Input packets</b>—Number of packets received on the interface.</li> <li><b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul> <p>Gigabit Ethernet and 10-Gigabit Ethernet IQ PICs count the overhead and CRC bytes.</p> <p>For Gigabit Ethernet IQ PICs, the input byte counts vary by interface type. For more information, see Table 31 under the <a href="#">show interfaces (10-Gigabit Ethernet)</a> command.</p>	<b>detail extensive</b>



Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded. L3 incomplete errors can be ignored by configuring the <b>ignore-l3-incompletes</b> statement.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the receive direction that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Collisions</b>—Number of Ethernet collisions. The Gigabit Ethernet PIC supports only full-duplex operation, so for Gigabit Ethernet PICs, this number should always remain 0. If it is nonzero, there is a software bug.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the send direction as reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters (Egress)</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Ingress queues</b>	Total number of ingress queues supported on the specified interface. Displayed on IQ2 interfaces.	<b>extensive</b>
<b>Queue counters (Ingress)</b>	<p>CoS queue number and its associated user-configured forwarding class name. Displayed on IQ2 interfaces.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>extensive</b>

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Active alarms and Active defects</b>	<p>Ethernet-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. These fields can contain the value <b>None</b> or <b>Link</b>.</p> <ul style="list-style-type: none"> <li>• <b>None</b>—There are no active defects or alarms.</li> <li>• <b>Link</b>—Interface has lost its link state, which usually means that the cable is unplugged, the far-end system has been turned off, or the PIC is malfunctioning.</li> </ul>	<b>detail extensive none</b>
Interface transmit statistics	<p>(On MX Series devices) Status of the <b>interface-transmit-statistics</b> configuration: Enabled or Disabled.</p> <ul style="list-style-type: none"> <li>• <b>Enabled</b>—When the <b>interface-transmit-statistics</b> statement is included in the configuration. If this is configured, the interface statistics show the actual transmitted load on the interface.</li> <li>• <b>Disabled</b>—When the <b>interface-transmit-statistics</b> statement is not included in the configuration. If this is not configured, the interface statistics show the offered load on the interface.</li> </ul>	<b>detail extensive</b>
<b>OTN FEC statistics</b>	<p>The forward error correction (FEC) counters provide the following statistics:</p> <ul style="list-style-type: none"> <li>• <b>Corrected Errors</b>—The count of corrected errors in the last second.</li> <li>• <b>Corrected Error Ratio</b>—The corrected error ratio in the last 25 seconds. For example, 1e-7 is 1 error per 10 million bits.</li> </ul>	<b>detail extensive</b>
<b>PCS statistics</b>	<p>(10-Gigabit Ethernet interfaces) Displays Physical Coding Sublayer (PCS) fault conditions from the WAN PHY or the LAN PHY device.</p> <ul style="list-style-type: none"> <li>• <b>Bit errors</b>—High bit error rate. Indicates the number of bit errors when the PCS receiver is operating in normal mode.</li> <li>• <b>Errored blocks</b>—Loss of block lock. The number of errored blocks when the PCS receiver is operating in normal mode.</li> </ul>	<b>detail extensive</b>

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
MAC statistics	<p>Receive and Transmit statistics reported by the PIC's MAC subsystem, including the following:</p> <ul style="list-style-type: none"> <li>• <b>Total octets</b> and <b>total packets</b>—Total number of octets and packets. For Gigabit Ethernet IQ PICs, the received octets count varies by interface type. For more information, see Table 31 under the <a href="#">show interfaces (10-Gigabit Ethernet)</a> command.</li> <li>• <b>Unicast packets</b>, <b>Broadcast packets</b>, and <b>Multicast packets</b>—Number of unicast, broadcast, and multicast packets.</li> <li>• <b>CRC/Align errors</b>—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error).</li> <li>• <b>FIFO error</b>—Number of FIFO errors that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC or a cable is probably malfunctioning.</li> <li>• <b>MAC control frames</b>—Number of MAC control frames.</li> <li>• <b>MAC pause frames</b>—Number of MAC control frames with <b>pause</b> operational code.</li> <li>• <b>Oversized frames</b>—There are two possible conditions regarding the number of oversized frames: <ul style="list-style-type: none"> <li>• Packet length exceeds 1518 octets, or</li> <li>• Packet length exceeds MRU</li> </ul> </li> <li>• <b>Jabber frames</b>—Number of frames that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is from 20 ms to 150 ms.</li> <li>• <b>Fragment frames</b>—Total number of packets that were less than 64 octets in length (excluding framing bits, but including FCS octets) and had either an FCS error or an alignment error. Fragment frames normally increment because both runts (which are normal occurrences caused by collisions) and noise hits are counted.</li> <li>• <b>VLAN tagged frames</b>—Number of frames that are VLAN tagged. The system uses the TPID of 0x8100 in the frame to determine whether a frame is tagged or not.</li> </ul> <p><b>NOTE:</b> The 20-port Gigabit Ethernet MIC (MIC-3D-20GE-SFP) does not have hardware counters for VLAN frames. Therefore, the <b>VLAN tagged frames</b> field displays 0 when the <b>show interfaces</b> command is executed on a 20-port Gigabit Ethernet MIC. In other words, the number of VLAN tagged frames cannot be determined for the 20-port Gigabit Ethernet MIC.</p> <ul style="list-style-type: none"> <li>• <b>Code violations</b>—Number of times an event caused the PHY to indicate "Data reception error" or "invalid data symbol error."</li> </ul>	extensive
OTN Received Overhead Bytes	APS/PCC0: 0x02, APS/PCC1: 0x11, APS/PCC2: 0x47, APS/PCC3: 0x58 Payload Type: 0x08	extensive
OTN Transmitted Overhead Bytes	APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00 Payload Type: 0x08	extensive

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Filter statistics</b>	<p><b>Receive</b> and <b>Transmit</b> statistics reported by the PIC's MAC address filter subsystem. The filtering is done by the content-addressable memory (CAM) on the PIC. The filter examines a packet's source and destination MAC addresses to determine whether the packet should enter the system or be rejected.</p> <ul style="list-style-type: none"> <li>• <b>Input packet count</b>—Number of packets received from the MAC hardware that the filter processed.</li> <li>• <b>Input packet rejects</b>—Number of packets that the filter rejected because of either the source MAC address or the destination MAC address.</li> <li>• <b>Input DA rejects</b>—Number of packets that the filter rejected because the destination MAC address of the packet is not on the accept list. It is normal for this value to increment. When it increments very quickly and no traffic is entering the router from the far-end system, either there is a bad ARP entry on the far-end system, or multicast routing is not on and the far-end system is sending many multicast packets to the local router (which the router is rejecting).</li> <li>• <b>Input SA rejects</b>—Number of packets that the filter rejected because the source MAC address of the packet is not on the accept list. The value in this field should increment only if source MAC address filtering has been enabled. If filtering is enabled, if the value increments quickly, and if the system is not receiving traffic that it should from the far-end system, it means that the user-configured source MAC addresses for this interface are incorrect.</li> <li>• <b>Output packet count</b>—Number of packets that the filter has given to the MAC hardware.</li> <li>• <b>Output packet pad count</b>—Number of packets the filter padded to the minimum Ethernet size (60 bytes) before giving the packet to the MAC hardware. Usually, padding is done only on small ARP packets, but some very small IP packets can also require padding. If this value increments rapidly, either the system is trying to find an ARP entry for a far-end system that does not exist or it is misconfigured.</li> <li>• <b>Output packet error count</b>—Number of packets with an indicated error that the filter was given to transmit. These packets are usually aged packets or are the result of a bandwidth problem on the FPC hardware. On a normal system, the value of this field should not increment.</li> <li>• <b>CAM destination filters, CAM source filters</b>—Number of entries in the CAM dedicated to destination and source MAC address filters. There can only be up to 64 source entries. If source filtering is disabled, which is the default, the values for these fields should be 0.</li> </ul>	<b>extensive</b>
<b>PMA PHY</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PHY Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>WIS section</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B1</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>LOL</b>—Loss of light</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>ES-S</b>—Errored seconds (section)</li> <li>• <b>SES-S</b>—Severely errored seconds (section)</li> <li>• <b>SEFS-S</b>—Severely errored framing seconds (section)</li> </ul>	<b>extensive</b>
<b>WIS line</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>REI-L</b>—Remote error indication (near-end line)</li> <li>• <b>RDI-L</b>—Remote defect indication (near-end line)</li> <li>• <b>AIS-L</b>—Alarm indication signal (near-end line)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>ES-L</b>—Errored seconds (near-end line)</li> <li>• <b>SES-L</b>—Severely errored seconds (near-end line)</li> <li>• <b>UAS-L</b>—Unavailable seconds (near-end line)</li> <li>• <b>ES-LFE</b>—Errored seconds (far-end line)</li> <li>• <b>SES-LFE</b>—Severely errored seconds (far-end line)</li> <li>• <b>UAS-LFE</b>—Unavailable seconds (far-end line)</li> </ul>	<b>extensive</b>

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>WIS path</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B3</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>REI-P</b>—Remote error indication</li> <li>• <b>LOP-P</b>—Loss of pointer (path)</li> <li>• <b>AIS-P</b>—Path alarm indication signal</li> <li>• <b>RDI-P</b>—Path remote defect indication</li> <li>• <b>UNEQ-P</b>—Path unequipped</li> <li>• <b>PLM-P</b>—Path payload (signal) label mismatch</li> <li>• <b>ES-P</b>—Errored seconds (near-end STS path)</li> <li>• <b>SES-P</b>—Severely errored seconds (near-end STS path)</li> <li>• <b>UAS-P</b>—Unavailable seconds (near-end STS path)</li> <li>• <b>SES-PFE</b>—Severely errored seconds (far-end STS path)</li> <li>• <b>UAS-PFE</b>—Unavailable seconds (far-end STS path)</li> </ul>	<b>extensive</b>

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
Autonegotiation information	<p>Information about link autonegotiation.</p> <ul style="list-style-type: none"> <li>• <b>Negotiation status:</b> <ul style="list-style-type: none"> <li>• <b>Incomplete</b>—Ethernet interface has the speed or link mode configured.</li> <li>• <b>No autonegotiation</b>—Remote Ethernet interface has the speed or link mode configured, or does not perform autonegotiation.</li> <li>• <b>Complete</b>—Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> </ul> </li> <li>• <b>Link partner status</b>—OK when Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> <li>• <b>Link partner</b>—Information from the remote Ethernet device: <ul style="list-style-type: none"> <li>• <b>Link mode</b>—Depending on the capability of the link partner, either <b>Full-duplex</b> or <b>Half-duplex</b>.</li> <li>• <b>Flow control</b>—Types of flow control supported by the link partner. For Gigabit Ethernet interfaces, types are <b>Symmetric</b> (link partner supports <b>PAUSE</b> on receive and transmit), <b>Asymmetric</b> (link partner supports <b>PAUSE</b> on transmit), <b>Symmetric/Asymmetric</b> (link partner supports <b>PAUSE</b> on receive and transmit or only <b>PAUSE</b> on transmit), and <b>None</b> (link partner does not support flow control).</li> <li>• <b>Remote fault</b>—Remote fault information from the link partner—<b>Failure</b> indicates a receive link error. <b>OK</b> indicates that the link partner is receiving. <b>Negotiation error</b> indicates a negotiation error. <b>Offline</b> indicates that the link partner is going offline.</li> </ul> </li> <li>• <b>Local resolution</b>—Information from the local Ethernet device: <ul style="list-style-type: none"> <li>• <b>Flow control</b>—Types of flow control supported by the local device. For Gigabit Ethernet interfaces, advertised capabilities are <b>Symmetric/Asymmetric</b> (local device supports <b>PAUSE</b> on receive and transmit or only <b>PAUSE</b> on receive) and <b>None</b> (local device does not support flow control). Depending on the result of the negotiation with the link partner, local resolution flow control type will display <b>Symmetric</b> (local device supports <b>PAUSE</b> on receive and transmit), <b>Asymmetric</b> (local device supports <b>PAUSE</b> on receive), and <b>None</b> (local device does not support flow control).</li> <li>• <b>Remote fault</b>—Remote fault information. <b>Link OK</b> (no error detected on receive), <b>Offline</b> (local interface is offline), and <b>Link Failure</b> (link error detected on receive).</li> </ul> </li> </ul>	extensive
Received path trace, Transmitted path trace	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits.</p>	extensive
Packet Forwarding Engine configuration	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> </ul>	extensive



Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	<p>Information about the CoS queue for the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP interface index number for the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>VLAN-Tag</b>	<p>Rewrite profile applied to incoming or outgoing frames on the outer (<b>Out</b>) VLAN tag or for both the outer and inner (<b>In</b>) VLAN tags.</p> <ul style="list-style-type: none"> <li>• <b>push</b>—An outer VLAN tag is pushed in front of the existing VLAN tag.</li> <li>• <b>pop</b>—The outer VLAN tag of the incoming frame is removed.</li> <li>• <b>swap</b>—The outer VLAN tag of the incoming frame is overwritten with the user-specified VLAN tag information.</li> <li>• <b>push</b>—An outer VLAN tag is pushed in front of the existing VLAN tag.</li> <li>• <b>push-push</b>—Two VLAN tags are pushed in from the incoming frame.</li> <li>• <b>swap-push</b>—The outer VLAN tag of the incoming frame is replaced by a user-specified VLAN tag value. A user-specified outer VLAN tag is pushed in front. The outer tag becomes an inner tag in the final frame.</li> <li>• <b>swap-swap</b>—Both the inner and the outer VLAN tags of the incoming frame are replaced by the user-specified VLAN tag value.</li> <li>• <b>pop-swap</b>—The outer VLAN tag of the incoming frame is removed, and the inner VLAN tag of the incoming frame is replaced by the user-specified VLAN tag value. The inner tag becomes the outer tag in the final frame.</li> <li>• <b>pop-pop</b>—Both the outer and inner VLAN tags of the incoming frame are removed.</li> </ul>	<b>brief detail extensive</b> none
<b>Demux</b>	<p>IP demultiplexing (demux) value that appears if this interface is used as the demux underlying interface. The output is one of the following:</p> <ul style="list-style-type: none"> <li>• Source Family Inet</li> <li>• Destination Family Inet</li> </ul>	<b>detail extensive</b> none
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>ACI VLAN: Dynamic Profile</b>	Name of the dynamic profile that defines the agent circuit identifier (ACI) interface set. If configured, the ACI interface set enables the underlying Ethernet interface to create dynamic VLAN subscriber interfaces based on ACI information.	<b>brief detail extensive</b> none
<b>Protocol</b>	Protocol family. Possible values are described in the “Protocol Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	<b>detail extensive</b> none
<b>MTU</b>	Maximum transmission unit size on the logical interface.	<b>detail extensive</b> none
<b>Dynamic Profile</b>	(MX Series routers with Trio MPCs only) Name of the dynamic profile that was used to create this interface configured with a Point-to-Point Protocol over Ethernet (PPPoE) family.	<b>detail extensive</b> none
<b>Service Name Table</b>	(MX Series routers with Trio MPCs only) Name of the service name table for the interface configured with a PPPoE family.	<b>detail extensive</b> none
<b>Max Sessions</b>	(MX Series routers with Trio MPCs only) Maximum number of PPPoE logical interfaces that can be activated on the underlying interface.	<b>detail extensive</b> none

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Duplicate Protection</b>	(MX Series routers with Trio MPCs only) State of PPPoE duplicate protection: <b>On</b> or <b>Off</b> . When duplicate protection is configured for the underlying interface, a dynamic PPPoE logical interface cannot be activated when an existing active logical interface is present for the same PPPoE client.	<b>detail extensive none</b>
<b>Maximum labels</b>	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	<b>detail extensive none</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the specified interface set. <ul style="list-style-type: none"> <li><b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface set</li> <li><b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface set.</li> </ul>	<b>detail extensive</b>
<b>IPv6 transit statistics</b>	Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.	<b>extensive</b>
<b>Local statistics</b>	Number and rate of bytes and packets destined to the router.	<b>extensive</b>
<b>Transit statistics</b>	Number and rate of bytes and packets transiting the switch.  <b>NOTE:</b> For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the <b>Output bytes</b> and <b>Output packets</b> interface counters. However, correct values display for both of these egress statistics when per-unit scheduling is enabled for the Gigabit Ethernet IQ2 physical interface, or when a single logical interface is actively using a shared scheduler.	<b>extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Route table in which the logical interface address is located. For example, <b>0</b> refers to the routing table inet.0.	<b>detail extensive none</b>
<b>Flags</b>	Information about protocol family flags. Possible values are described in the "Family Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	<b>detail extensive</b>
<b>Donor interface</b>	(Unnumbered Ethernet) Interface from which an unnumbered Ethernet interface borrows an IPv4 address.	<b>detail extensive none</b>
<b>Preferred source address</b>	(Unnumbered Ethernet) Secondary IPv4 address of the donor loopback interface that acts as the preferred source address for the unnumbered Ethernet interface.	<b>detail extensive none</b>
<b>Input Filters</b>	Names of any input filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parentheses next to all interfaces.	<b>detail extensive</b>

Table 29: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output Filters</b>	Names of any output filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parentheses next to all interfaces.	<b>detail extensive</b>
<b>Mac-Validate Failures</b>	Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface.	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>protocol-family</b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Flags</b>	Information about the address flag. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

Table 30: Gigabit Ethernet IQ PIC Traffic and MAC Statistics by Interface Type

Interface Type	Sample Command	Byte and Octet Counts Include	Comments
Inbound physical interface	<b>show interfaces ge-0/3/0 extensive</b>	<p>Traffic statistics:</p> <p>Input bytes: 496 bytes per packet, representing the Layer 2 packet</p> <p>MAC statistics:</p> <p>Received octets: 500 bytes per packet, representing the Layer 2 packet + 4 bytes</p>	The additional 4 bytes are for the CRC.
Inbound logical interface	<b>show interfaces ge-0/3/0.50 extensive</b>	<p>Traffic statistics:</p> <p>Input bytes: 478 bytes per packet, representing the Layer 3 packet</p>	

Table 30: Gigabit Ethernet IQ PIC Traffic and MAC Statistics by Interface Type (*continued*)

Interface Type	Sample Command	Byte and Octet Counts Include	Comments
Outbound physical interface	<b>show interfaces ge-0/0/0 extensive</b>	<p>Traffic statistics:</p> <p>Input bytes: 490 bytes per packet, representing the Layer 3 packet + 12 bytes</p> <p>MAC statistics:</p> <p>Received octets: 478 bytes per packet, representing the Layer 3 packet</p>	For input bytes, the additional 12 bytes include 6 bytes for the destination MAC address plus 4 bytes for VLAN plus 2 bytes for the Ethernet type.
Outbound logical interface	<b>show interfaces ge-0/0/0.50 extensive</b>	<p>Traffic statistics:</p> <p>Input bytes: 478 bytes per packet, representing the Layer 3 packet</p>	

## Sample Output

### show interfaces (Gigabit Ethernet)

```

user@host> show interfaces ge-3/0/2
Physical interface: ge-3/0/2, Enabled, Physical link is Up
  Interface index: 167, SNMP ifIndex: 35
  Link-level type: 52, MTU: 1522, Speed: 1000mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues    : 4 supported, 4 maximum usable queues
  Current address: 00:05:85:4a:e9:7c, Hardware address: 00:05:85:4a:e9:7c
  Last flapped  : 2006-08-10 17:25:10 PDT (00:01:08 ago)
  Input rate    : 0 bps (0 pps)
  Output rate   : 0 bps (0 pps)
  Ingress rate at Packet Forwarding Engine : 0 bps (0 pps)
  Ingress drop rate at Packet Forwarding Engine : 0 bps (0 pps)
  Active alarms : None
  Active defects : None

Logical interface ge-3/0/2.0 (Index 72) (SNMP ifIndex 69)
  Flags: SNMP-Traps 0x4000
  VLAN-Tag [ 0x8100.512 0x8100.513 ] In(pop-swap 0x8100.530) Out(swap-push
  0x8100.512 0x8100.513)
  Encapsulation: VLAN-CCC
  Input packets : 0
  Output packets: 0
  Protocol ccc, MTU: 1522
  Flags: Is-Primary

```

### show interfaces (Gigabit Ethernet on MX Series Routers)

```

user@host> show interfaces ge-2/2/2
Physical interface: ge-2/2/2, Enabled, Physical link is Up
  Interface index: 156, SNMP ifIndex: 188
  Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, MAC-REWRITE Error: None,
  Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues    : 8 supported, 4 maximum usable queues
  Schedulers     : 0
  Current address: 00:1f:12:b7:d7:c0, Hardware address: 00:1f:12:b7:d6:76
  Last flapped   : 2008-09-05 16:44:30 PDT (3d 01:04 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  Active alarms  : None
  Active defects : None

Logical interface ge-2/2/2.0 (Index 82) (SNMP ifIndex 219)
  Flags: SNMP-Traps 0x20000000 Encapsulation: Ethernet-Bridge
  Input packets : 0
  Output packets: 0
  Protocol aenet, AE bundle: ae0.0   Link Index: 4

```

### show interfaces extensive (Gigabit)

```

user@host> show interfaces ge-2/1/2 extensive | match "output|interface"
Physical interface: ge-2/1/2, Enabled, Physical link is Up
  Interface index: 151, SNMP ifIndex: 530, Generation: 154

```

Ethernet on MX Series  
Routers showing  
interface transmit

Interface flags: SNMP-Traps Internal: 0x4000  
Output bytes : 240614363944 772721536 bps  
Output packets: 3538446506 1420444 pps  
Direction : Output

**statistics  
configuration)**

Interface transmit statistics: Enabled

Logical interface ge-2/1/2.0 (Index 331) (SNMP ifIndex 955) (Generation 146)  
 Output bytes : 195560312716 522726272 bps  
 Output packets: 4251311146 1420451 pps

**show interfaces brief  
(Gigabit Ethernet)**

```
user@host> show interfaces ge-3/0/2 brief
Physical interface: ge-3/0/2, Enabled, Physical link is Up
Link-level type: 52, MTU: 1522, Speed: 1000mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
Remote fault: Online
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags : None

Logical interface ge-3/0/2.0
Flags: SNMP-Traps 0x4000
VLAN-Tag [ 0x8100.512 0x8100.513 ] In(pop-swap 0x8100.530) Out(swap-push
0x8100.512 0x8100.513)
Encapsulation: VLAN-CCC
ccc

Logical interface ge-3/0/2.32767
Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x0000.0 ] Encapsulation: ENET2
```

**show interfaces detail  
(Gigabit Ethernet)**

```
user@host> show interfaces ge-3/0/2 detail
Physical interface: ge-3/0/2, Enabled, Physical link is Up
Interface index: 167, SNMP ifIndex: 35, Generation: 177
Link-level type: 52, MTU: 1522, Speed: 1000mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
Remote fault: Online
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags : None
CoS queues : 4 supported, 4 maximum usable queues
Hold-times : Up 0 ms, Down 0 ms
Current address: 00:05:85:4a:e9:7c, Hardware address: 00:05:85:4a:e9:7c
Last flapped : 2006-08-09 17:17:00 PDT (01:31:33 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
Ingress traffic statistics at Packet Forwarding Engine:
Input bytes : 0 0 bps
Input packets: 0 0 pps
Drop bytes : 0 0 bps
Drop packets: 0 0 pps
Ingress queues: 4 supported, 4 in use
Queue counters: Queued packets Transmitted packets Dropped packets

0 best-effort 0 0 0
1 expedited-fo 0 0 0
2 assured-forw 0 0 0
3 network-cont 0 0 0
```



```

Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort              0              0              0
  1 expedited-fo             0              0              0
  2 assured-forw             0              0              0
  3 network-cont             0              0              0

Active alarms : None
Active defects : None

Logical interface ge-3/0/2.0 (Index 72) (SNMP ifIndex 69) (Generation 140)
  Flags: SNMP-Traps 0x4000
  VLAN-Tag [0x8100.512 0x8100.513 ] In(pop-swap 0x8100.530)
Out(swap-push 0x8100.512 0x8100.513)
  Encapsulation: VLAN-CCC
  Traffic statistics:
    Input bytes :              0
    Output bytes :              0
    Input packets:              0
    Output packets:              0
  Local statistics:
    Input bytes :              0
    Output bytes :              0
    Input packets:              0
    Output packets:              0
  Transit statistics:
    Input bytes :              0              0 bps
    Output bytes :              0              0 bps
    Input packets:              0              0 pps
    Output packets:              0              0 pps
  Protocol ccc, MTU: 1522, Generation: 149, Route table: 0
  Flags: Is-Primary

Logical interface ge-3/0/2.32767 (Index 71) (SNMP ifIndex 70)
(Generation 139)
  Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x0000.0 ] Encapsulation: ENET2
  Traffic statistics:
    Input bytes :              0
    Output bytes :              0
    Input packets:              0
    Output packets:              0
  Local statistics:
    Input bytes :              0
    Output bytes :              0
    Input packets:              0
    Output packets:              0
  Transit statistics:
    Input bytes :              0              0 bps
    Output bytes :              0              0 bps
    Input packets:              0              0 pps
    Output packets:              0              0 pps

```

**show interfaces  
extensive  
(Gigabit Ethernet IQ2)**

```

user@host> show interfaces ge-7/1/3 extensive
Physical interface: ge-7/1/3, Enabled, Physical link is Up
Interface index: 170, SNMP ifIndex: 70, Generation: 171
Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,

```

```

Remote fault: Online
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4004000
Link flags     : None
CoS queues     : 8 supported, 4 maximum usable queues
Schedulers     : 256
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:14:f6:30:5e:74, Hardware address: 00:14:f6:30:5e:74
Last flapped   : 2007-11-07 21:31:41 PST (02:03:33 ago)
Statistics last cleared: Never

Traffic statistics:
Input bytes   :          38910844056          7952 bps
Output bytes  :           7174605          8464 bps
Input packets :          418398473           11 pps
Output packets:           78903           12 pps

IPv6 transit statistics:
Input bytes   :              0
Output bytes  :              0
Input packets :              0
Output packets:              0

Ingress traffic statistics at Packet Forwarding Engine:
Input bytes   :          38910799145          7952 bps
Input packets :          418397956           11 pps
Drop bytes    :              0             0 bps
Drop packets  :              0             0 pps

Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
FIFO errors: 0, Resource errors: 0

Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Ingress queues: 4 supported, 4 in use
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	418390823	418390823	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	7133	7133	0

```

Egress queues: 4 supported, 4 in use
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	1031	1031	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	77872	77872	0

```

Active alarms : None
Active defects : None
MAC statistics:
Total octets      :          38910844056          7174605
Total packets     :          418398473           78903
Unicast packets   :          408021893366          1026

```

```

Broadcast packets          10          12
Multicast packets         418398217      77865
CRC/Align errors          0            0
FIFO errors                0            0
MAC control frames        0            0
MAC pause frames          0            0
Oversized frames          0
Jabber frames             0
Fragment frames           0
VLAN tagged frames        0
Code violations            0
OTN Received Overhead Bytes:
APS/PCC0: 0x02, APS/PCC1: 0x11, APS/PCC2: 0x47, APS/PCC3: 0x58
Payload Type: 0x08
OTN Transmitted Overhead Bytes:
APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00
Payload Type: 0x08
Filter statistics:
Input packet count        418398473
Input packet rejects      479
Input DA rejects          479
Input SA rejects          0
Output packet count       78903
Output packet pad count   0
Output packet error count 0
CAM destination filters: 0, CAM source filters: 0
Autonegotiation information:
Negotiation status: Complete
Link partner:
Link mode: Full-duplex, Flow control: Symmetric/Asymmetric,
Remote fault: OK
Local resolution:
Flow control: Symmetric, Remote fault: Link OK
Packet Forwarding Engine configuration:
Destination slot: 7
CoS information:
Direction : Output
CoS transmit queue      Bandwidth      Buffer      Priority      Limit
                        %          bps          %          usec
0 best-effort           95      950000000    95           0
low none
3 network-control       5       50000000     5           0
low none
Direction : Input
CoS transmit queue      Bandwidth      Buffer      Priority      Limit
                        %          bps          %          usec
0 best-effort           95      950000000    95           0
low none
3 network-control       5       50000000     5           0
low none

Logical interface ge-7/1/3.0 (Index 70) (SNMP ifIndex 85) (Generation 150)
Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
Input bytes :           812400
Output bytes :          1349206
Input packets:           9429
Output packets:          9449
IPv6 transit statistics:
Input bytes :            0
Output bytes :            0
Input packets:           0

```

```

    Output packets:                0
Local statistics:
  Input bytes  :                812400
  Output bytes :               1349206
  Input packets:                9429
  Output packets:               9449
Transit statistics:
  Input bytes  :                0      7440 bps
  Output bytes :                0      7888 bps
  Input packets:                0      10 pps
  Output packets:               0      11 pps
IPv6 transit statistics:
  Input bytes  :                0
  Output bytes :                0
  Input packets:                0
  Output packets:               0
Protocol inet, MTU: 1500, Generation: 169, Route table: 0
  Flags: Is-Primary, Mac-Validate-Strict
  Mac-Validate Failures: Packets: 0, Bytes: 0
  Addresses, Flags: Is-Preferred Is-Primary
  Input Filters: F1-ge-3/0/1.0-in, F3-ge-3/0/1.0-in
  Output Filters: F2-ge-3/0/1.0-out (53)
  Destination: 10.74.2/24, Local: 10.74.2.2, Broadcast: 10.74.2.255,
    Generation: 196
Protocol multiservice, MTU: Unlimited, Generation: 170, Route table: 0
  Flags: Is-Primary
  Policer: Input: __default_arp_policer__

```

**NOTE:** For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics displayed in the **show interfaces** command output might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the interface counters. For detailed information, see the description of the logical interface **Transit statistics** fields in [Table 29 on page 213](#).

#### show interfaces (Gigabit Ethernet)

```

user@host> show interfaces ge-3/2/0
Physical interface: ge-3/2/0, Enabled, Physical link is Up
  Interface index: 148, SNMP ifIndex: 50

```

**Unnumbered Interface)**

```

Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
Remote fault: Online
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : None
CoS queues    : 8 supported, 4 maximum usable queues
Current address: 00:14:f6:11:26:f8, Hardware address: 00:14:f6:11:26:f8
Last flapped   : 2006-10-27 04:42:23 PDT (08:01:52 ago)
Input rate     : 0 bps (0 pps)
Output rate    : 624 bps (1 pps)
Active alarms  : None
Active defects : None

```

```

Logical interface ge-3/2/0.0 (Index 67) (SNMP ifIndex 85)
  Flags: SNMP-Traps Encapsulation: ENET2
  Input packets : 0
  Output packets: 6
  Protocol inet, MTU: 1500
    Flags: Unnumbered
    Donor interface: lo0.0 (Index 64)
    Preferred source address: 22.22.22.22

```

**show interfaces (ACI Interface Set Configured)**

```

user@host> show interfaces ge-1/0/0.4001
Logical interface ge-1/0/0.4001 (Index 340) (SNMP ifIndex 548)
  Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.4001 ] Encapsulation: PPP-over-

Ethernet
ACI VLAN:
  Dynamic Profile: aci-vlan-set-profile
  PPPoE:
    Dynamic Profile: aci-vlan-pppoe-profile,
    Service Name Table: None,
    Max Sessions: 32000, Max Sessions VSA Ignore: Off,
    Duplicate Protection: On, Short Cycle Protection: Off,
    AC Name: nbc
  Input packets : 9
  Output packets: 8
  Protocol multiservice, MTU: Unlimited

```

## show interfaces (10-Gigabit Ethernet)

---

<b>Syntax</b>	<code>show interfaces <i>xe-fpc/pic/port</i></code> <code>&lt;brief   detail   extensive   terse&gt;</code> <code>&lt;descriptions&gt;</code> <code>&lt;media&gt;</code> <code>&lt;snmp-index <i>snmp-index</i>&gt;</code> <code>&lt;statistics&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.0.
<b>Description</b>	(M320, M120, MX Series, and T Series routers only) Display status information about the specified 10-Gigabit Ethernet interface.
<b>Options</b>	<p><code><i>xe-fpc/pic/port</i></code>—Display standard information about the specified 10-Gigabit Ethernet interface.</p> <p><code>brief   detail   extensive   terse</code>—(Optional) Display the specified level of output.</p> <p><code>descriptions</code>—(Optional) Display interface description strings.</p> <p><code>media</code>—(Optional) Display media-specific information about network interfaces.</p> <p><code>snmp-index <i>snmp-index</i></code>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><code>statistics</code>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces extensive (10-Gigabit Ethernet, LAN PHY Mode, IQ2) on page 251</a></p> <p><a href="#">show interfaces extensive (10-Gigabit Ethernet, WAN PHY Mode) on page 254</a></p> <p><a href="#">show interfaces extensive (10-Gigabit Ethernet, DWDM OTN PIC) on page 256</a></p> <p><a href="#">show interfaces extensive (10-Gigabit Ethernet, LAN PHY Mode, Unidirectional Mode) on page 259</a></p> <p><a href="#">show interfaces extensive (10-Gigabit Ethernet, LAN PHY Mode, Unidirectional Mode, Transmit-Only) on page 259</a></p> <p><a href="#">show interfaces extensive (10-Gigabit Ethernet, LAN PHY Mode, Unidirectional Mode, Receive-Only) on page 260</a></p>
<b>Output Fields</b>	See <a href="#">Table 31 on page 237</a> for the output fields for the <b>show interfaces</b> (10-Gigabit Ethernet) command.

Table 31: show interfaces Gigabit Ethernet Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Index number of the physical interface, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Loopback status: <b>Enabled</b> or <b>Disabled</b> . If loopback is enabled, type of loopback: <b>Local</b> or <b>Remote</b> .	All levels
<b>Source filtering</b>	Source filtering status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>LAN-PHY mode</b>	10-Gigabit Ethernet interface operating in Local Area Network Physical Layer Device (LAN PHY) mode. LAN PHY allows 10-Gigabit Ethernet wide area links to use existing Ethernet applications.	All levels
<b>WAN-PHY mode</b>	10-Gigabit Ethernet interface operating in Wide Area Network Physical Layer Device (WAN PHY) mode. WAN PHY allows 10-Gigabit Ethernet wide area links to use fiber-optic cables and other devices intended for SONET/SDH.	All levels
<b>Unidirectional</b>	Unidirectional link mode status for 10-Gigabit Ethernet interface: <b>Enabled</b> or <b>Disabled</b> for parent interface; <b>Rx-only</b> or <b>Tx-only</b> for child interfaces.	All levels
<b>Flow control</b>	Flow control status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>Auto-negotiation</b>	(Gigabit Ethernet interfaces) Autonegotiation status: <b>Enabled</b> or <b>Disabled</b> .	All levels
<b>Remote-fault</b>	(Gigabit Ethernet interfaces) Remote fault status: <ul style="list-style-type: none"> <li>• <b>Online</b>—Autonegotiation is manually configured as online.</li> <li>• <b>Offline</b>—Autonegotiation is manually configured as offline.</li> </ul>	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Link flags</b>	Information about the link. Possible values are described in the “Links Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Wavelength</b>	(10-Gigabit Ethernet dense wavelength-division multiplexing [DWDM] interfaces) Displays the configured wavelength, in nanometers (nm).	All levels
<b>Frequency</b>	(10-Gigabit Ethernet DWDM interfaces only) Displays the frequency associated with the configured wavelength, in terahertz (THz).	All levels
<b>CoS queues</b>	Number of CoS queues configured.	<b>detail extensive</b> none
<b>Schedulers</b>	(Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces only) Number of CoS schedulers configured.	<b>extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b> none
<b>Hardware address</b>	Hardware MAC address.	<b>detail extensive</b> none
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second:timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive</b> none
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul> <p>Gigabit Ethernet and 10-Gigabit Ethernet IQ PICs count the overhead and CRC bytes.</p> <p>For Gigabit Ethernet IQ PICs, the input byte counts vary by interface type. For more information, see <a href="#">Table 31 on page 237</a>.</p>	<b>detail extensive</b>



Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded. L3 incomplete errors can be ignored by configuring the <b>ignore-l3-incompletes</b> statement.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the receive direction that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Collisions</b>—Number of Ethernet collisions. The Gigabit Ethernet PIC supports only full-duplex operation, so for Gigabit Ethernet PICs, this number should always remain 0. If it is nonzero, there is a software bug.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the send direction as reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters (Egress)</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Ingress queues</b>	Total number of ingress queues supported on the specified interface. Displayed on IQ2 interfaces.	<b>extensive</b>
<b>Queue counters (Ingress)</b>	<p>CoS queue number and its associated user-configured forwarding class name. Displayed on IQ2 interfaces.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Active alarms and Active defects</b>	<p>Ethernet-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. These fields can contain the value <b>None</b> or <b>Link</b>.</p> <ul style="list-style-type: none"> <li>• <b>None</b>—There are no active defects or alarms.</li> <li>• <b>Link</b>—Interface has lost its link state, which usually means that the cable is unplugged, the far-end system has been turned off, or the PIC is malfunctioning.</li> </ul>	<b>detail extensive none</b>
<b>OTN alarms</b>	Active OTN alarms identified on the interface.	<b>detail extensive</b>
<b>OTN defects</b>	OTN defects received on the interface.	<b>detail extensive</b>
<b>OTN FEC Mode</b>	<p>The FECmode configured on the interface.</p> <ul style="list-style-type: none"> <li>• <b>efec</b>—Enhanced forward error correction (EFEC) is configured to detect and correct bit errors.</li> <li>• <b>gfec</b>—G.709 Forward error correction (GFEC) mode is configured to detect and correct bit errors.</li> <li>• <b>none</b>—FEC mode is not configured.</li> </ul>	<b>detail extensive</b>
<b>OTN Rate</b>	<p>OTN mode.</p> <ul style="list-style-type: none"> <li>• <b>fixed-stuff-bytes</b>—Fixed stuff bytes 11.0957 Gbps.</li> <li>• <b>no-fixed-stuff-bytes</b>—No fixed stuff bytes 11.0491 Gbps.</li> <li>• <b>pass-through</b>—Enable OTN passthrough mode.</li> <li>• <b>no-pass-through</b>—Do not enable OTN passthrough mode.</li> </ul>	<b>detail extensive</b>
<b>OTN Line Loopback</b>	Status of the line loopback, if configured for the DWDM OTN PIC. Its value can be: <b>enabled</b> or <b>disabled</b> .	<b>detail extensive</b>
<b>OTN FEC statistics</b>	<p>The forward error correction (FEC) counters for the DWDM OTN PIC.</p> <ul style="list-style-type: none"> <li>• <b>Corrected Errors</b>—The count of corrected errors in the last second.</li> <li>• <b>Corrected Error Ratio</b>—The corrected error ratio in the last 25 seconds. For example, 1e-7 is 1 error per 10 million bits.</li> </ul>	<b>detail extensive</b>
<b>OTN FEC alarms</b>	<p>OTN FEC excessive or degraded error alarms triggered on the interface.</p> <ul style="list-style-type: none"> <li>• <b>FEC Degrade</b>—OTU FEC Degrade defect.</li> <li>• <b>FEC Excessive</b>—OTU FEC Excessive Error defect.</li> </ul>	<b>detail extensive</b>
<b>OTN OC</b>	<p>OTN OC defects triggered on the interface.</p> <ul style="list-style-type: none"> <li>• <b>LOS</b>—OC Loss of Signal defect.</li> <li>• <b>LOF</b>—OC Loss of Frame defect.</li> <li>• <b>LOM</b>—OC Loss of Multiframe defect.</li> <li>• <b>Wavelength Lock</b>—OC Wavelength Lock defect.</li> </ul>	<b>detail extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>OTN OTU</b>	OTN OTU defects detected on the interface <ul style="list-style-type: none"> <li>• <b>AIS</b>—OTN AIS alarm.</li> <li>• <b>BDI</b>—OTN OTU BDI alarm.</li> <li>• <b>IAE</b>—OTN OTU IAE alarm.</li> <li>• <b>TTIM</b>—OTN OTU TTIM alarm.</li> <li>• <b>SF</b>—OTN ODU bit error rate fault alarm.</li> <li>• <b>SD</b>—OTN ODU bit error rate defect alarm.</li> <li>• <b>TCA-ES</b>—OTN ODU ES threshold alarm.</li> <li>• <b>TCA-SES</b>—OTN ODU SES threshold alarm.</li> <li>• <b>TCA-UAS</b>—OTN ODU UAS threshold alarm.</li> <li>• <b>TCA-BBE</b>—OTN ODU BBE threshold alarm.</li> <li>• <b>BIP</b>—OTN ODU BIP threshold alarm.</li> <li>• <b>BBE</b>—OTN OTU BBE threshold alarm.</li> <li>• <b>ES</b>—OTN OTU ES threshold alarm.</li> <li>• <b>SES</b>—OTN OTU SES threshold alarm.</li> <li>• <b>UAS</b>—OTN OTU UAS threshold alarm.</li> </ul>	<b>detail extensive</b>
<b>Received DAPI</b>	Destination Access Port Interface (DAPI) from which the packets were received.	<b>detail extensive</b>
<b>Received SAPI</b>	Source Access Port Interface (SAPI) from which the packets were received.	<b>detail extensive</b>
<b>Transmitted DAPI</b>	Destination Access Port Interface (DAPI) to which the packets were transmitted.	<b>detail extensive</b>
<b>Transmitted SAPI</b>	Source Access Port Interface (SAPI) to which the packets were transmitted.	<b>detail extensive</b>
<b>PCS statistics</b>	(10-Gigabit Ethernet interfaces) Displays Physical Coding Sublayer (PCS) fault conditions from the WAN PHY or the LAN PHY device. <ul style="list-style-type: none"> <li>• <b>Bit errors</b>—High bit error rate. Indicates the number of bit errors when the PCS receiver is operating in normal mode.</li> <li>• <b>Errored blocks</b>—Loss of block lock. The number of errored blocks when PCS receiver is operating in normal mode.</li> </ul>	<b>detail extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>MAC statistics</b>	<p>Receive and Transmit statistics reported by the PIC's MAC subsystem, including the following:</p> <ul style="list-style-type: none"> <li>• <b>Total octets</b> and <b>total packets</b>—Total number of octets and packets. For Gigabit Ethernet IQ PICs, the received octets count varies by interface type. For more information, see <a href="#">Table 32 on page 251</a></li> <li>• <b>Unicast packets</b>, <b>Broadcast packets</b>, and <b>Multicast packets</b>—Number of unicast, broadcast, and multicast packets.</li> <li>• <b>CRC/Align errors</b>—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error).</li> <li>• <b>FIFO error</b>—Number of FIFO errors that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC or a cable is probably malfunctioning.</li> <li>• <b>MAC control frames</b>—Number of MAC control frames.</li> <li>• <b>MAC pause frames</b>—Number of MAC control frames with <b>pause</b> operational code.</li> <li>• <b>Oversized frames</b>—Number of frames that exceed 1518 octets.</li> <li>• <b>Jabber frames</b>—Number of frames that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is from 20 ms to 150 ms.</li> <li>• <b>Fragment frames</b>—Total number of packets that were less than 64 octets in length (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. Fragment frames normally increment because both runts (which are normal occurrences caused by collisions) and noise hits are counted.</li> <li>• <b>VLAN tagged frames</b>—Number of frames that are VLAN tagged. The system uses the TPID of 0x8100 in the frame to determine whether a frame is tagged or not.</li> <li>• <b>Code violations</b>—Number of times an event caused the PHY to indicate "Data reception error" or "invalid data symbol error."</li> </ul>	<b>extensive</b>
<b>OTN Received Overhead Bytes</b>	APS/PCC0: 0x02, APS/PCC1: 0x11, APS/PCC2: 0x47, APS/PCC3: 0x58 Payload Type: 0x08	<b>extensive</b>
<b>OTN Transmitted Overhead Bytes</b>	APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00 Payload Type: 0x08	<b>extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Filter statistics</b>	<p><b>Receive</b> and <b>Transmit</b> statistics reported by the PIC's MAC address filter subsystem. The filtering is done by the content-addressable memory (CAM) on the PIC. The filter examines a packet's source and destination MAC addresses to determine whether the packet should enter the system or be rejected.</p> <ul style="list-style-type: none"> <li>• <b>Input packet count</b>—Number of packets received from the MAC hardware that the filter processed.</li> <li>• <b>Input packet rejects</b>—Number of packets that the filter rejected because of either the source MAC address or the destination MAC address.</li> <li>• <b>Input DA rejects</b>—Number of packets that the filter rejected because the destination MAC address of the packet is not on the accept list. It is normal for this value to increment. When it increments very quickly and no traffic is entering the router from the far-end system, either there is a bad ARP entry on the far-end system, or multicast routing is not on and the far-end system is sending many multicast packets to the local router (which the router is rejecting).</li> <li>• <b>Input SA rejects</b>—Number of packets that the filter rejected because the source MAC address of the packet is not on the accept list. The value in this field should increment only if source MAC address filtering has been enabled. If filtering is enabled, if the value increments quickly, and if the system is not receiving traffic that it should from the far-end system, it means that the user-configured source MAC addresses for this interface are incorrect.</li> <li>• <b>Output packet count</b>—Number of packets that the filter has given to the MAC hardware.</li> <li>• <b>Output packet pad count</b>—Number of packets the filter padded to the minimum Ethernet size (60 bytes) before giving the packet to the MAC hardware. Usually, padding is done only on small ARP packets, but some very small IP packets can also require padding. If this value increments rapidly, either the system is trying to find an ARP entry for a far-end system that does not exist or it is misconfigured.</li> <li>• <b>Output packet error count</b>—Number of packets with an indicated error that the filter was given to transmit. These packets are usually aged packets or are the result of a bandwidth problem on the FPC hardware. On a normal system, the value of this field should not increment.</li> <li>• <b>CAM destination filters, CAM source filters</b>—Number of entries in the CAM dedicated to destination and source MAC address filters. There can only be up to 64 source entries. If source filtering is disabled, which is the default, the values for these fields should be 0.</li> </ul>	<b>extensive</b>
<b>PMA PHY</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PHY Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>WIS section</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B1</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>LOL</b>—Loss of light</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>ES-S</b>—Errored seconds (section)</li> <li>• <b>SES-S</b>—Severely errored seconds (section)</li> <li>• <b>SEFS-S</b>—Severely errored framing seconds (section)</li> </ul>	<b>extensive</b>
<b>WIS line</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>REI-L</b>—Remote error indication (near-end line)</li> <li>• <b>RDI-L</b>—Remote defect indication (near-end line)</li> <li>• <b>AIS-L</b>—Alarm indication signal (near-end line)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>ES-L</b>—Errored seconds (near-end line)</li> <li>• <b>SES-L</b>—Severely errored seconds (near-end line)</li> <li>• <b>UAS-L</b>—Unavailable seconds (near-end line)</li> <li>• <b>ES-LFE</b>—Errored seconds (far-end line)</li> <li>• <b>SES-LFE</b>—Severely errored seconds (far-end line)</li> <li>• <b>UAS-LFE</b>—Unavailable seconds (far-end line)</li> </ul>	<b>extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>WIS path</b>	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. Any state other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B3</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>REI-P</b>—Remote error indication</li> <li>• <b>LOP-P</b>—Loss of pointer (path)</li> <li>• <b>AIS-P</b>—Path alarm indication signal</li> <li>• <b>RDI-P</b>—Path remote defect indication</li> <li>• <b>UNEQ-P</b>—Path unequipped</li> <li>• <b>PLM-P</b>—Path payload label mismatch</li> <li>• <b>ES-P</b>—Errored seconds (near-end STS path)</li> <li>• <b>SES-P</b>—Severely errored seconds (near-end STS path)</li> <li>• <b>UAS-P</b>—Unavailable seconds (near-end STS path)</li> <li>• <b>SES-PFE</b>—Severely errored seconds (far-end STS path)</li> <li>• <b>UAS-PFE</b>—Unavailable seconds (far-end STS path)</li> </ul>	<b>extensive</b>



Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
Autonegotiation information	<p>Information about link autonegotiation.</p> <ul style="list-style-type: none"> <li>• <b>Negotiation status:</b> <ul style="list-style-type: none"> <li>• <b>Incomplete</b>—Ethernet interface has the speed or link mode configured.</li> <li>• <b>No autonegotiation</b>—Remote Ethernet interface has the speed or link mode configured, or does not perform autonegotiation.</li> <li>• <b>Complete</b>—Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> </ul> </li> <li>• <b>Link partner status</b>—OK when Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> <li>• <b>Link partner:</b> <ul style="list-style-type: none"> <li>• <b>Link mode</b>—Depending on the capability of the attached Ethernet device, either <b>Full-duplex</b> or <b>Half-duplex</b>.</li> <li>• <b>Flow control</b>—Types of flow control supported by the remote Ethernet device. For Fast Ethernet interfaces, the type is <b>None</b>. For Gigabit Ethernet interfaces, types are <b>Symmetric</b> (link partner supports <b>PAUSE</b> on receive and transmit), <b>Asymmetric</b> (link partner supports <b>PAUSE</b> on transmit), and <b>Symmetric/Asymmetric</b> (link partner supports both <b>PAUSE</b> on receive and transmit or only <b>PAUSE</b> receive).</li> <li>• <b>Remote fault</b>—Remote fault information from the link partner—<b>Failure</b> indicates a receive link error. <b>OK</b> indicates that the link partner is receiving. <b>Negotiation error</b> indicates a negotiation error. <b>Offline</b> indicates that the link partner is going offline.</li> </ul> </li> <li>• <b>Local resolution</b>—Information from the link partner: <ul style="list-style-type: none"> <li>• <b>Flow control</b>—Types of flow control supported by the remote Ethernet device. For Gigabit Ethernet interfaces, types are <b>Symmetric</b> (link partner supports <b>PAUSE</b> on receive and transmit), <b>Asymmetric</b> (link partner supports <b>PAUSE</b> on transmit), and <b>Symmetric/Asymmetric</b> (link partner supports both <b>PAUSE</b> on receive and transmit or only <b>PAUSE</b> receive).</li> <li>• <b>Remote fault</b>—Remote fault information. <b>Link OK</b> (no error detected on receive), <b>Offline</b> (local interface is offline), and <b>Link Failure</b> (link error detected on receive).</li> </ul> </li> </ul>	extensive
Received path trace, Transmitted path trace	<p>(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits.</p>	extensive
Packet Forwarding Engine configuration	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> </ul>	extensive

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP interface index number for the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>VLAN-Tag</b>	<p>Rewrite profile applied to incoming or outgoing frames on the outer (<b>Out</b>) VLAN tag or for both the outer and inner (<b>In</b>) VLAN tags.</p> <ul style="list-style-type: none"> <li>• <b>push</b>—An outer VLAN tag is pushed in front of the existing VLAN tag.</li> <li>• <b>pop</b>—The outer VLAN tag of the incoming frame is removed.</li> <li>• <b>swap</b>—The outer VLAN tag of the incoming frame is overwritten with the user specified VLAN tag information.</li> <li>• <b>push</b>—An outer VLAN tag is pushed in front of the existing VLAN tag.</li> <li>• <b>push-push</b>—Two VLAN tags are pushed in from the incoming frame.</li> <li>• <b>swap-push</b>—The outer VLAN tag of the incoming frame is replaced by a user-specified VLAN tag value. A user-specified outer VLAN tag is pushed in front. The outer tag becomes an inner tag in the final frame.</li> <li>• <b>swap-swap</b>—Both the inner and the outer VLAN tags of the incoming frame are replaced by the user specified VLAN tag value.</li> <li>• <b>pop-swap</b>—The outer VLAN tag of the incoming frame is removed, and the inner VLAN tag of the incoming frame is replaced by the user-specified VLAN tag value. The inner tag becomes the outer tag in the final frame.</li> <li>• <b>pop-pop</b>—Both the outer and inner VLAN tags of the incoming frame are removed.</li> </ul>	<b>brief detail extensive none</b>
<b>Demux:</b>	<p>IP demultiplexing (demux) value that appears if this interface is used as the demux underlying interface. The output is one of the following:</p> <ul style="list-style-type: none"> <li>• Source Family Inet</li> <li>• Destination Family Inet</li> </ul>	<b>detail extensive none</b>
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Protocol</b>	Protocol family. Possible values are described in the “Protocol Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	<b>detail extensive none</b>
<b>MTU</b>	Maximum transmission unit size on the logical interface.	<b>detail extensive none</b>
<b>Maximum labels</b>	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	<b>detail extensive none</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the specified interface set.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface set</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface set.</li> </ul>	<b>detail extensive</b>
<b>IPv6 transit statistics</b>	Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.	<b>extensive</b>
<b>Local statistics</b>	Number and rate of bytes and packets destined to the router.	<b>extensive</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Transit statistics</b>	Number and rate of bytes and packets transiting the switch.  <b>NOTE:</b> For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the <b>Output bytes</b> and <b>Output packets</b> interface counters. However, correct values display for both of these egress statistics when per-unit scheduling is enabled for the Gigabit Ethernet IQ2 physical interface, or when a single logical interface is actively using a shared scheduler.	<b>extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Route table in which the logical interface address is located. For example, <b>0</b> refers to the routing table inet.0.	<b>detail extensive none</b>
<b>Flags</b>	Information about protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Donor interface</b>	(Unnumbered Ethernet) Interface from which an unnumbered Ethernet interface borrows an IPv4 address.	<b>detail extensive none</b>
<b>Preferred source address</b>	(Unnumbered Ethernet) Secondary IPv4 address of the donor loopback interface that acts as the preferred source address for the unnumbered Ethernet interface.	<b>detail extensive none</b>
<b>Input Filters</b>	Names of any input filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parenthesis next to all interfaces.	<b>detail extensive</b>
<b>Output Filters</b>	Names of any output filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parenthesis next to all interfaces.	<b>detail extensive</b>
<b>Mac-Validate Failures</b>	Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface.	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Flags</b>	Information about address flag (possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interlace.	<b>detail extensive none</b>

Table 31: show interfaces Gigabit Ethernet Output Fields (*continued*)

Field Name	Field Description	Level of Output
Generation	Unique number for use by Juniper Networks technical support only.	detail extensive

For Gigabit Ethernet IQ PICs, traffic and MAC statistics output varies. [Table 32 on page 251](#) describes the traffic and MAC statistics for two sample interfaces, each of which is sending traffic in packets of 500 bytes (including 478 bytes for the Layer 3 packet, 18 bytes for the Layer 2 VLAN traffic header, and 4 bytes for cyclic redundancy check [CRC] information). In [Table 32 on page 251](#), the **ge-0/3/0** interface is the inbound physical interface, and the **ge-0/0/0** interface is the outbound physical interface. On both interfaces, traffic is carried on logical unit .50 (VLAN 50).

Table 32: Gigabit Ethernet IQ PIC Traffic and MAC Statistics by Interface Type

Interface Type	Sample Command	Byte and Octet Counts Include	Comments
Inbound physical interface	<b>show interfaces ge-0/3/0 extensive</b>	Traffic statistics:  Input bytes: 496 bytes per packet, representing the Layer 2 packet  MAC statistics:  Received octets: 500 bytes per packet, representing the Layer 2 packet + 4 bytes	The additional 4 bytes are for the CRC.
Inbound logical interface	<b>show interfaces ge-0/3/0.50 extensive</b>	Traffic statistics:  Input bytes: 478 bytes per packet, representing the Layer 3 packet	
Outbound physical interface	<b>show interfaces ge-0/0/0 extensive</b>	Traffic statistics:  Input bytes: 490 bytes per packet, representing the Layer 3 packet + 12 bytes  MAC statistics:  Received octets: 478 bytes per packet, representing the Layer 3 packet	For input bytes, the additional 12 bytes includes 6 bytes for the destination MAC address + 4 bytes for VLAN + 2 bytes for the Ethernet type.
Outbound logical interface	<b>show interfaces ge-0/0/0.50 extensive</b>	Traffic statistics:  Input bytes: 478 bytes per packet, representing the Layer 3 packet	

## Sample Output

**show interfaces extensive**

```
user@host> show interfaces xe-5/0/0 extensive
Physical interface: xe-5/0/0, Enabled, Physical link is Up
Interface index: 177, SNMP ifIndex: 99, Generation: 178
```

**(10-Gigabit Ethernet,  
LAN PHY Mode, IQ2)**

```

Link-level type: Ethernet, MTU: 1518, LAN-PHY mode, Speed: 10Gbps, Loopback:
None, Source filtering: Enabled,
Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : None
CoS queues    : 8 supported, 4 maximum usable queues
Schedulers    : 1024
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:14:f6:b9:f1:f6, Hardware address: 00:14:f6:b9:f1:f6
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          6970332384          0 bps
Output bytes  :              0          0 bps
Input packets :          81050506          0 pps
Output packets:              0          0 pps
IPv6 transit statistics:
Input bytes   :              0
Output bytes  :              0
Input packets :              0
Output packets:              0
Ingress traffic statistics at Packet Forwarding Engine:
Input bytes   :          6970299398          0 bps
Input packets :          81049992          0 pps
Drop bytes    :              0          0 bps
Drop packets  :              0          0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0, L2 channel errors: 0,
L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0, HS link CRC errors: 0,
MTU errors: 0, Resource errors: 0
Ingress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

    0 best-effort          81049992          81049992          0

    1 expedited-fo              0              0          0

    2 assured-forw              0              0          0

    3 network-cont              0              0          0

Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

    0 best-effort              0              0          0

    1 expedited-fo              0              0          0

    2 assured-forw              0              0          0

    3 network-cont              0              0          0

Active alarms : None
Active defects : None
PCS statistics
  Bit errors           Seconds
                        0

```

```

    Errored blocks                0
MAC statistics:
    Total octets                  6970332384
    Total packets                 81050506
    Unicast packets               81050000
    Broadcast packets             506
    Multicast packets             0
    CRC/Align errors              0
    FIFO errors                   0
    MAC control frames            0
    MAC pause frames              0
    Oversized frames              0
    Jabber frames                  0
    Fragment frames               0
    VLAN tagged frames            0
    Code violations                0
Filter statistics:
    Input packet count            81050506
    Input packet rejects          506
    Input DA rejects              0
    Input SA rejects              0
    Output packet count           0
    Output packet pad count       0
    Output packet error count     0
    CAM destination filters: 0, CAM source filters: 0
Packet Forwarding Engine configuration:
    Destination slot: 5
CoS information:
    Direction : Output
    CoS transmit queue           Bandwidth      Buffer Priority Limit
                                %      bps      %      usec
    0 best-effort                95      950000000  95      0      low      none
    3 network-control            5       50000000   5       0      low      none

    Direction : Input
    CoS transmit queue           Bandwidth      Buffer Priority Limit
                                %      bps      %      usec
    0 best-effort                95      950000000  95      0      low      none
    3 network-control            5       50000000   5       0      low      none

Logical interface xe-5/0/0.0 (Index 71) (SNMP ifIndex 95) (Generation 195)
Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.100 ] Encapsulation: ENET2
Traffic statistics:
    Input bytes : 0
    Output bytes : 46
    Input packets: 0
    Output packets: 1
IPv6 transit statistics:
    Input bytes : 0
    Output bytes : 0
    Input packets: 0
    Output packets: 0
Local statistics:
    Input bytes : 0
    Output bytes : 46
    Input packets: 0
    Output packets: 1
Transit statistics:
    Input bytes : 0
    Output bytes : 0
    Input packets: 0
    Output packets: 0
    Input bytes : 0 bps
    Output bytes : 0 bps
    Input packets: 0 pps
    Output packets: 0 pps

```

```
Output packets:                0                0 pps
IPv6 transit statistics:
  Input bytes :                0
  Output bytes :               0
  Input packets:              0
  Output packets:             0
Protocol inet, MTU: 1500, Generation: 253, Route table: 0
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 192.1.1/24, Local: 192.1.1.1, Broadcast: 192.1.1.255,
Generation: 265
Protocol multiservice, MTU: Unlimited, Generation: 254, Route table: 0
  Flags: None
  Policer: Input: __default_arp_policer__
```

### **show interfaces extensive**

```
user@host> show interfaces xe-1/0/0 extensive
Physical interface: xe-1/0/0, Enabled, Physical link is Up
  Interface index: 141, SNMP ifIndex: 34, Generation: 47
```



(10-Gigabit Ethernet,  
WAN PHY Mode)

```

Link-level type: Ethernet, MTU: 1514, Speed: 10Gbps, Loopback: Disabled
WAN-PHY mode
Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps 16384
Link flags     : None
CoS queues    : 4 supported
Hold-times    : Up 0 ms, Down 0 ms
Current address: 00:05:85:a2:10:9d, Hardware address: 00:05:85:a2:10:9d
Last flapped   : 2005-07-07 11:22:34 PDT (3d 12:28 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes :                0                0 bps
Output bytes :                0                0 bps
Input packets:                0                0 pps
Output packets:                0                0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  HS Link CRC errors: 0, HS Link FIFO overflows: 0,
  Resource errors: 0
Output errors:
  Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0,
  Aged packets: 0, FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0,
  Resource errors: 0
Queue counters:      Queued packets  Transmitted packets  Dropped packets
0 best-effort        0                0                0
1 expedited-fo       0                0                0
2 assured-forw       0                0                0
3 network-cont       0                0                0
Active alarms : LOL, LOS, LBL
Active defects: LOL, LOS, LBL, SEF, AIS-L, AIS-P
PCS statistics      Seconds      Count
  Bit errors        0            0
  Errored blocks    0            0
MAC statistics:
Receive            Transmit
Total octets       0            0
Total packets      0            0
Unicast packets    0            0
Broadcast packets  0            0
Multicast packets  0            0
CRC/Align errors   0            0
FIFO errors        0            0
MAC control frames 0            0
MAC pause frames   0            0
Oversized frames   0
Jabber frames      0
Fragment frames    0
VLAN tagged frames 0
Code violations     0
Filter statistics:
Input packet count      0
Input packet rejects    0
Input DA rejects        0
Input SA rejects        0
Output packet count     0
Output packet pad count 0
Output packet error count 0
CAM destination filters: 0, CAM source filters: 0
PMA PHY:      Seconds      Count  State
  PLL lock    0            0  OK

```

```

PHY light          63159          1 Light Missing
WIS section:
  BIP-B1           0              0
  SEF              434430        434438 Defect Active
  LOS              434430        1 Defect Active
  LOF              434430        1 Defect Active
  ES-S             434430
  SES-S            434430
  SEFS-S           434430
WIS line:
  BIP-B2           0              0
  REI-L            0              0
  RDI-L            0              0 OK
  AIS-L            434430        1 Defect Active
  BERR-SF          0              0 OK
  BERR-SD          0              0 OK
  ES-L             434430
  SES-L            434430
  UAS-L            434420
  ES-LFE           0
  SES-LFE           0
  UAS-LFE           0
WIS path:
  BIP-B3           0              0
  REI-P            0              0
  LOP-P            0              0 OK
  AIS-P            434430        1 Defect Active
  RDI-P            0              0 OK
  UNEQ-P           0              0 OK
  PLM-P            0              0 OK
  ES-P             434430
  SES-P            434430
  UAS-P            434420
  ES-PFE           0
  SES-PFE           0
  UAS-PFE           0
Received path trace:
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
Transmitted path trace: orissa so-1/0/0
6f 72 69 73 73 61 20 73 6f 2d 31 2f 30 2f 30 00   orissa so-1/0/0.
Packet Forwarding Engine configuration:
  Destination slot: 1
CoS information:
  CoS transmit queue    %    Bandwidth    %    Buffer    Priority    Limit
                        %    bps           %    bytes
  0 best-effort         95    950000000  95     0        low       none
  3 network-control     5     50000000  5      0        low       none

```

### show interfaces extensive

```

user@host> show interfaces ge-7/0/0 extensive
Physical interface: ge-7/0/0, Enabled, Physical link is Down
Interface index: 143, SNMP ifIndex: 508, Generation: 208

```

(10-Gigabit Ethernet,  
DWDM OTN PIC)

```

Link-level type: Ethernet, MTU: 1514, Speed: 10Gbps, BPDU Error: None,
MAC-REWRITE Error: None, Loopback: Disabled, Source filtering: Disabled,
Flow control: Enabled
Device flags   : Present Running Down
Interface flags: Hardware-Down SNMP-Traps Internal: 0x4000
Link flags     : None
Wavelength    : 1550.12 nm, Frequency: 193.40 THz
CoS queues     : 8 supported, 8 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:05:85:70:2b:72, Hardware address: 00:05:85:70:2b:72
Last flapped   : 2011-04-20 15:48:54 PDT (18:39:49 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   : 0          0 bps
Output bytes  : 0          0 bps
Input packets : 0          0 pps
Output packets: 0          0 pps
IPv6 transit statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 2, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort        0          0          0

1 expedited-fo       0          0          0

2 assured-forw       0          0          0

3 network-cont
Queue number:        Mapped forwarding classes
0                    best-effort
1                    expedited-forwarding
2                    assured-forwarding
3                    network-control
Active alarms  : LINK
Active defects : LINK
MAC statistics:      Receive      Transmit
Total octets        0          0
Total packets       0          0
Unicast packets     0          0
Broadcast packets   0          0
Multicast packets   0          0
CRC/Align errors    0          0
FIFO errors         0          0
MAC control frames  0          0
MAC pause frames    0          0
Oversized frames    0
Jabber frames       0
Fragment frames     0
VLAN tagged frames  0
Code violations      0

```

```

Total octets                                0                0
Total packets                              0                0
Unicast packets                            0                0
Broadcast packets                          0                0
Multicast packets                          0                0
CRC/Align errors                           0                0
FIFO errors                                0                0
MAC control frames                          0                0
MAC pause frames                           0                0
Oversized frames                           0
Jabber frames                              0
Fragment frames                            0
VLAN tagged frames                         0
Code violations                             0
OTN alarms : None
OTN defects : None
OTN FEC Mode : GFEC
OTN Rate : Fixed Stuff Bytes 11.0957Gbps
OTN Line Loopback : Enabled
OTN FEC statistics :
    Corrected Errors                                0
    Corrected Error Ratio ( 0 sec average) 0e-0
OTN FEC alarms:
    Seconds      Count  State
    FEC Degrade   0      0  OK
    FEC Excessive 0      0  OK
OTN OC:
    Seconds      Count  State
    LOS           2      1  OK
    LOF          67164    2  Defect Active
    LOM          67164    71 Defect Active
    Wavelength Lock 0      0  OK
OTN OTU:
    AIS           0      0  OK
    BDI          65919    4814 Defect Active
    IAE          67158    1  Defect Active
    TTIM          7      1  OK
    SF           67164    2  Defect Active
    SD           67164    3  Defect Active
    TCA-ES        0      0  OK
    TCA-SES        0      0  OK
    TCA-UAS       80     40  OK
    TCA-BBE        0      0  OK
    BIP           0      0  OK
    BBE           0      0  OK
    ES            0      0  OK
    SES           0      0  OK
    UAS          587     0  OK
Received DAPI:
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
Received SAPI:
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
Transmitted DAPI:
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
Transmitted SAPI:
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
OTN Received Overhead Bytes:
    APS/PCC0: 0x02, APS/PCC1: 0x42, APS/PCC2: 0xa2, APS/PCC3: 0x48
    Payload Type: 0x03
OTN Transmitted Overhead Bytes:
    APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00
    Payload Type: 0x03
Filter statistics:

```

```

Input packet count          0
Input packet rejects        0
Input DA rejects            0
Input SA rejects            0
Output packet count         0
Output packet pad count     0
Output packet error count   0
CAM destination filters: 0, CAM source filters: 0
Packet Forwarding Engine configuration:
  Destination slot: 7
CoS information:
  Direction : Output
  CoS transmit queue      Bandwidth      Buffer Priority
Limit
    0 best-effort         95      9500000000    95      0      low
none
    3 network-control     5       500000000     5      0      low
none
...

```

**show interfaces  
extensive (10-Gigabit  
Ethernet, LAN PHY  
Mode, Unidirectional  
Mode)**

```

user@host> show interfaces xe-7/0/0 extensive
Physical interface: xe-7/0/0, Enabled, Physical link is Up
Interface index: 173, SNMP ifIndex: 212, Generation: 174
Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps,
Unidirectional: Enabled,
Loopback: None, Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
...

```

**show interfaces  
extensive (10-Gigabit  
Ethernet, LAN PHY)**

```

user@host> show interfaces xe-7/0/0-tx extensive
Physical interface: xe-7/0/0-tx, Enabled, Physical link is Up
Interface index: 176, SNMP ifIndex: 137, Generation: 177
Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps,

```

**Mode, Unidirectional  
Mode, Transmit-Only**

```

Unidirectional: Tx-Only
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags : None
CoS queues : 8 supported, 8 maximum usable queues
Hold-times : Up 0 ms, Down 0 ms
Current address: 00:05:85:73:e4:83, Hardware address: 00:05:85:73:e4:83
Last flapped : 2007-06-01 09:08:19 PDT (3d 02:31 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes : 0 0 bps
Output bytes : 322891152287160 9627472888 bps
Input packets: 0 0 pps
Output packets: 328809727380 1225492 pps

...

Filter statistics:
Output packet count 328810554250
Output packet pad count 0
Output packet error count 0

...

Logical interface xe-7/0/0-tx.0 (Index 73) (SNMP ifIndex 138) (Generation 139)

Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
Input bytes : 0
Output bytes : 322891152287160
Input packets: 0
Output packets: 328809727380
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Local statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 322891152287160 9627472888 bps
Input packets: 0 0 pps
Output packets: 328809727380 1225492 pps
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Protocol inet, MTU: 1500, Generation: 147, Route table: 0
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.11.12/24, Local: 10.11.12.13, Broadcast: 10.11.12.255,
Generation: 141
Protocol multiservice, MTU: Unlimited, Generation: 148, Route table: 0
Flags: None
Policer: Input: __default_arp_policer__

```

**show interfaces**

```

user@host> show interfaces xe-7/0/0-rx extensive
Physical interface: xe-7/0/0-rx, Enabled, Physical link is Up

```

extensive (10-Gigabit  
Ethernet, LAN PHY

Interface index: 174, SNMP ifIndex: 118, Generation: 175  
Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps,  
Unidirectional: Rx-Only

**Mode, Unidirectional  
Mode, Receive-Only)**

```

Device flags      : Present Running
Interface flags:  SNMP-Traps Internal: 0x4000
Link flags       : None
CoS queues       : 8 supported, 8 maximum usable queues
Hold-times       : Up 0 ms, Down 0 ms
Current address:  00:05:85:73:e4:83, Hardware address: 00:05:85:73:e4:83
Last flapped     : 2007-06-01 09:08:22 PDT (3d 02:31 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :      322857456303482      9627496104 bps
  Output bytes :              0          0 bps
  Input packets:      328775413751      1225495 pps
  Output packets:              0          0 pps

```

...

```

Filter statistics:
  Input packet count      328775015056
  Input packet rejects    1
  Input DA rejects        0

```

...

Logical interface xe-7/0/0-rx.0 (Index 72) (SNMP ifIndex 120) (Generation 138)

Flags: SNMP-Traps Encapsulation: ENET2

Traffic statistics:

```

  Input bytes :      322857456303482
  Output bytes :              0
  Input packets:      328775413751
  Output packets:              0

```

IPv6 transit statistics:

```

  Input bytes :              0
  Output bytes :              0
  Input packets:              0
  Output packets:              0

```

Local statistics:

```

  Input bytes :              0
  Output bytes :              0
  Input packets:              0
  Output packets:              0

```

Transit statistics:

```

  Input bytes :      322857456303482      9627496104 bps
  Output bytes :              0          0 bps
  Input packets:      328775413751      1225495 pps
  Output packets:              0          0 pps

```

IPv6 transit statistics:

```

  Input bytes :              0
  Output bytes :              0
  Input packets:              0
  Output packets:              0

```

Protocol inet, MTU: 1500, Generation: 145, Route table: 0

Addresses, Flags: Is-Preferred Is-Primary

Destination: 192.1.1/24, Local: 192.1.1.1, Broadcast: 192.1.1.255,

Generation: 139

Protocol multiservice, MTU: Unlimited, Generation: 146, Route table: 0

Flags: None

Policer: Input: \_\_default\_arp\_policer\_\_



## show interfaces extensive

**Syntax** show interfaces extensive

**Release Information** Command introduced before Junos OS Release 7.4.  
Command introduced in Junos OS Release 12.1 for PTX Series Packet Transport Switches.

**Description** Display extensive information about all interfaces configured on the router.



### NOTE:

- At some times, the cumulative byte counters displayed with the `show interfaces extensive` command on the 10-Gigabit Ethernet MPC with SFP+ is not always increasing and cumulative and does not give the correct results. There is a time lag in collecting these statistics, during which the display might decrease or go from a nonzero number to zero. Eventually, the counter will display the correct result.
- When the `show interfaces extensive` command is executed on a router with an MPC or a T4000 Type 5 FPC, the *Input packet rejects* counter of the *Filter statistics* field also displays statistics related to the following packet errors:
  - Invalid VLAN range
  - Tagged packet received on an untagged interface
- When the `show interfaces extensive` command is executed on an interface that is configured on a T4000 Type 5 FPC, the *IPv6 transit statistics* field displays:
  - Total statistics (sum of transit and local statistics) at the physical interface level
  - Transit statistics at the logical interface level
- When the `show interfaces extensive` command is executed on an aggregate interface in a T1600 Core Router, the *IPv6 Input bytes* is displayed for an aggregate interface. However, the *IPv6 Input bytes* is always zero on a member link of an aggregated bundle even when there are IPv6 transit traffic on the member link. This is because the logical interface index of the aggregate logical interface is updated but not the logical interface of the member links in the channel lookup table.

**Options** This command has no options.

**Required Privilege Level** view

**List of Sample Output** [show interfaces extensive \(Circuit Emulation\) on page 265](#)

[show interfaces extensive \(Fast Ethernet\) on page 265](#)  
[show interfaces extensive \(Gigabit Ethernet\) on page 267](#)  
[show interfaces extensive \(10-Gigabit Ethernet\) on page 267](#)  
[show interfaces extensive \(IQ2 and IQ2E\) on page 270](#)  
[show interfaces extensive \(100-Gigabit Ethernet\) on page 273](#)  
[show interfaces extensive \(PTX5000 Packet Transport Switch\) on page 274](#)  
[show interfaces extensive \(T4000 Routers with Type 5 FPCs\) on page 276](#)  
[show interfaces extensive \(T4000 Routers with 24-port 10-Gigabit Ethernet LAN/WAN PIC on Type 5 FPC\) on page 278](#)  
[show interfaces extensive \(Aggregated Ethernet\) on page 280](#)

**Output Fields** For more information, see the output fields table for the particular interface type in which you are interested. For information about destination class and source class statistics, see the “Destination Class Field” section and the “Source Class Field” section under [“Common Output Fields Description” on page 141](#). For sample output for specific interfaces, see the other topics in this collection.

## Sample Output

### show interfaces extensive (Circuit Emulation)

If a Circuit Emulation (CE) PIC is configured for SAToP pseudowire, then pseudowire statistics are displayed in the CE information section of the show interface extensive output. If SAToP pseudowire is not configured on the CE PIC, then all the CE information counters will be displayed as 0 (zero).

```
user@host> show interface tl-0/0/0 extensive
Physical interface :tl-0/0/0, Enabled, Physical Link : Up
  Interface index:61441
  Speed : 1.54 Mbps, Loopback: Disabled
  Operational state : Enabled, Encapsulation : Trans
  Encoding : b8zs, Framing : unframe, Build-out : 0-30
  Inversion : enable, Clock source : master
  Description :
  Traffic statistics:
  T1 media:      Seconds
  ES              1643
  SES            1643

  CE Info      Packets      Bytes
  CE Rx       : 2395529     306627712
  CE Tx       : 2396259     306721152
  CE Rx Drop: 0             0
  CE Tx Drop: 0             0

  CE Overrun  Events: 0
  CE Underrun Events: 0
```

## Sample Output

### show interfaces extensive (Fast Ethernet)

```
user@host> show interfaces fe-0/2/1 extensive
Physical interface: fe-0/2/0, Enabled, Physical link is Up
  Interface index: 129, SNMP ifIndex: 23, Generation: 130
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues   : 4 supported, 4 maximum usable queues
  Hold-times   : Up 0 ms, Down 0 ms
  Current address: 00:90:69:91:c4:3e, Hardware address: 00:90:69:91:c4:3e
  Last flapped : 2006-04-16 23:00:41 PDT (02:08:05 ago)
  Statistics last cleared: 2006-04-16 21:42:00 PDT (03:26:46 ago)
  Traffic statistics:
  Input bytes : 17539      152 bps
  Output bytes : 92968     224 bps
  Input packets: 348       0 pps
  Output packets: 1349     0 pps
  Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  FIFO errors: 0, Resource errors: 0
  Output errors:
  Carrier transitions: 3, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

  FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
  Egress queues: 4 supported, 4 in use
  Queue counters:      Queued packets  Transmitted packets      Dropped packets
```

0 best-effort	66	66	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	1283	1283	0

Active alarms : None

Active defects : None

MAC statistics:

	Receive	Transmit
Total octets	24721	105982
Total packets	348	1349
Unicast packets	347	430
Broadcast packets	1	37
Multicast packets	0	882
CRC/Align errors	0	0
FIFO errors	0	0
MAC control frames	0	0
MAC pause frames	0	0
Oversized frames	0	
Jabber frames	0	
Fragment frames	0	
VLAN tagged frames	0	
Code violations	0	

Filter statistics:

Input packet count	348	
Input packet rejects	0	
Input DA rejects	0	
Input SA rejects	0	
Output packet count		1349
Output packet pad count		0
Output packet error count		0
CAM destination filters: 3, CAM source filters: 0		

Autonegotiation information:

Negotiation status: Complete

Link partner:

Link mode: Full-duplex, Flow control: None, Remote fault: OK

Packet Forwarding Engine configuration:

Destination slot: 0

CoS information:

CoS transmit queue	Bandwidth	Buffer	Priority	Limit
	%	bps	%	usec
0 best-effort	95	95000000	95	0
3 network-control	5	5000000	5	0

Logical interface fe-0/2/0.0 (Index 66) (SNMP ifIndex 46) (Generation 133)

Flags: SNMP-Traps Encapsulation: ENET2

Protocol inet, MTU: 1500, Generation: 142, Route table: 0

Flags: DCU, SCU-out

Destination class	Packets (packet-per-second)	Bytes (bits-per-second)
silv1_new	0	0
(	0)	(
silv2_new	0	0
(	0)	(
silv_misc	0	0
(	0)	(
silver0	0	0
(	0)	(

```

silver2          0          0
(              0) (          0)
silver3          0          0
(              0) (          0)
silver4          0          0
(              0) (          0)
silver5          0          0
(              0) (          0)
silver6          0          0
(              0) (          0)
silver7          0          0
(              0) (          0)
silver9          0          0
(              0) (          0)

```

Source class	Packets (packet-per-second)	Bytes (bits-per-second)
gold1	0	0
(	0)	0)
gold2	16600	1062400
(	0)	0)
gold3	0	0
(	0)	0)

Addresses, Flags: Is-Preferred Is-Primary  
Destination: 12.1.1/24, Local: 12.1.1.1, Broadcast: 12.1.1.255,  
Generation: 150

## Sample Output

show interfaces  
extensive (Gigabit  
Ethernet)

user@host> show interfaces ge-5/0/0.0 extensive

```

Logical interface ge-5/0/0.0 (Index 71) (SNMP ifIndex 1930) (Generation 139)
Flags: SNMP-Traps 0x4000 Encapsulation: ENET2
Traffic statistics:
  Input bytes :          0
  Output bytes :         42
  Input packets:          0
  Output packets:         1
Local statistics:
  Input bytes :          0
  Output bytes :         42
  Input packets:          0
  Output packets:         1
Transit statistics:
  Input bytes :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:          0          0 pps
  Output packets:          0          0 pps
Output Filters: f-any
Protocol inet, MTU: 1500, Generation: 155, Route table: 0
  Output Filters: f-inet,
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.11.1/24, Local: 10.11.1.1, Broadcast: 10.11.1.255,
    Generation: 170
Protocol multiservice, MTU: Unlimited, Generation: 156, Route table: 0
  Flags: Is-Primary
  Policers: Input: __default_arp_policer__

```

## Sample Output

## show interfaces extensive (10-Gigabit Ethernet)

```

user@host> show interfaces xe-2/1/0 extensive

Physical interface: xe-2/1/0, Enabled, Physical link is Up
  Interface index: 258, SNMP ifIndex: 762, Generation: 2046
  Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, BPDU Error:
  None, Loopback: None, Source filtering: Disabled,
  Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues     : 8 supported, 8 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:1d:b5:f8:6d:eb, Hardware address: 00:1d:b5:f8:6d:eb
  Last flapped   : 2011-12-17 00:19:02 PST (07:36:37 ago)
  Statistics last cleared: 2011-12-17 07:55:24 PST (00:00:15 ago)
  Traffic statistics:
    Input bytes :          110000          0 bps
    Output bytes :           0          0 bps
    Input packets:           1000          0 pps
    Output packets:           0          0 pps
  IPv6 transit statistics:
    Input bytes :          110000
    Output bytes :           0
    Input packets:           1000
    Output packets:           0
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
  incompletes: 0, L2 channel errors: 0,
    L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
  FIFO errors: 0, HS link CRC errors: 0,
    MTU errors: 0, Resource errors: 0
  Egress queues: 8 supported, 4 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort          0              0              0
    1 expedited-fo        0              0              0
    2 assured-forw        0              0              0
    3 network-cont        0              0              0

  Queue number:      Mapped forwarding classes
    0                best-effort
    1                expedited-forwarding
    2                assured-forwarding
    3                network-control
  Active alarms : None
  Active defects : None
  PCS statistics
    Bit errors          0
    Errored blocks      0
  MAC statistics:
    Receive              Transmit
    Total octets        128000          0
    Total packets       1000          0
    Unicast packets     1000          0
    Broadcast packets   0          0
    Multicast packets   0          0
    CRC/Align errors    0          0

```

```

FIFO errors                                0                0
MAC control frames                        0                0
MAC pause frames                         0                0
Oversized frames                        0
Jabber frames                           0
Fragment frames                         0
VLAN tagged frames                      0
Code violations                          0
Filter statistics:
  Input packet count                     1000
  Input packet rejects                   0
  Input DA rejects                       0
  Input SA rejects                       0
  Output packet count                    0
  Output packet pad count                0
  Output packet error count              0
  CAM destination filters: 0, CAM source filters: 0
Packet Forwarding Engine configuration:
  Destination slot: 2
CoS information:
  Direction : Output
  CoS transmit queue                    Bandwidth          Buffer Priority
Limit
      0 best-effort                    95      95000000000    95      usec      low
none
      3 network-control                5      5000000000      5      0      low
none
Interface transmit statistics: Disabled

Logical interface xe-2/1/0.0 (Index 83) (SNMP ifIndex 1677) (Generation 10082)

Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2
Traffic statistics:
  Input bytes : 110000
  Output bytes : 0
  Input packets: 1000
  Output packets: 0
IPv6 transit statistics:
  Input bytes : 55000
  Output bytes : 0
  Input packets: 500
  Output packets: 0
Local statistics:
  Input bytes : 55000
  Output bytes : 0
  Input packets: 500
  Output packets: 0
Transit statistics:
  Input bytes : 55000
  Output bytes : 0
  Input packets: 500
  Output packets: 0
IPv6 transit statistics:
  Input bytes : 55000
  Output bytes : 0
  Input packets: 500
  Output packets: 0
Protocol inet6, MTU: 1500, Generation: 23739, Route table: 0
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 2001:1000:abcd:2312:1432:abcd:1234:0/112, Local:

```

```

2001:1000:abcd:2312:1432:abcd:1234:1234
  Generation: 506
  Addresses, Flags: Is-Preferred
    Destination: fe80::/64, Local: fe80::21d:b5ff:fe8:6deb
  Protocol multiservice, MTU: Unlimited, Generation: 508
  Generation: 23740, Route table: 0
  Policer: Input: __default_arp_policer__

```

## Sample Output

**show interfaces  
extensive (IQ2 and  
IQ2E)**

```

user@host> show interfaces ge-3/2/2 extensive
Physical interface: ge-3/2/2, Enabled, Physical link is Up
  Interface index: 156, SNMP ifIndex: 548, Generation: 159
  Link-level type: Ethernet, MTU: 1518, Speed: 1000mbps, BPDU Error: None,
MAC-REWRITE Error: None, Loopback: Disabled, Source filtering: Disabled,
Flow control: Enabled, Auto-negotiation: Enabled, Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues    : 8 supported, 8 maximum usable queues
  Schedulers    : 128
  Hold-times    : Up 0 ms, Down 0 ms
  Current address: 00:14:f6:12:86:fa, Hardware address: 00:14:f6:12:86:fa
  Last flapped  : 2010-03-17 04:03:11 PDT (00:45:30 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :          1716096          0 bps
    Output bytes  :          1716448          0 bps
    Input packets :           13407          0 pps
    Output packets:           13411          0 pps
  IPv6 total statistics:
    Input bytes   :          1716096
    Output bytes  :          1716096
    Input packets :           13407
    Output packets:           13407
  Ingress traffic statistics at Packet Forwarding Engine:
    Input bytes   :          1716096          0 bps
    Input packets :           13407          0 pps
    Drop bytes    :              0          0 bps
    Drop packets  :              0          0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
L3 incompletes: 0, L2 channel errors: 1, L2 mismatch timeouts: 0, FIFO errors:
0,
    Resource errors: 0
  Output errors:
    Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets:
0, FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
  Ingress queues: 8 supported, 4 in use
  Queue counters:      Queued packets  Transmitted packets      Dropped
packets
    0 best-effort          13407          13407
    0 1 expedited-fo              0              0
    0 2 assured-forw              0              0
    0 3 network-cont              0              0
    0
  Egress queues: 8 supported, 4 in use
  Queue counters:      Queued packets  Transmitted packets      Dropped
packets

```



```

0      0 best-effort          13407          13407
0      1 expedited-fo        0              0
0      2 assured-forw        0              0
0      3 network-cont        4              4
0
Active alarms : None
Active defects : None
MAC statistics:
                                Receive      Transmit
Total octets                  1716096    1716448
Total packets                  13407      13411
Unicast packets                13407      13407
Broadcast packets              0          0
Multicast packets              0          4
CRC/Align errors               0          0
FIFO errors                    0          0
MAC control frames             0          0
MAC pause frames               0          0
Oversized frames               0
Jabber frames                  0
Fragment frames                0
VLAN tagged frames             0
Code violations                0
Filter statistics:
Input packet count             13407
Input packet rejects           0
Input DA rejects               0
Input SA rejects               0
Output packet count            13411
Output packet pad count        0
Output packet error count      0
CAM destination filters: 0, CAM source filters: 0
Autonegotiation information:
Negotiation status: Complete
Link partner:
    Link mode: Full-duplex, Flow control: None, Remote fault: OK
Local resolution:
    Flow control: Symmetric, Remote fault: Link OK
Packet Forwarding Engine configuration:
Destination slot: 3
CoS information:
Direction : Output
CoS transmit queue            Bandwidth      Buffer Priority
Limit
    0 best-effort              %      bps      %      usec
    none                       95      950000000  95      0      low
    3 network-control          5      50000000    5      0      low
    none
Direction : Input
CoS transmit queue            Bandwidth      Buffer Priority
Limit
    0 best-effort              %      bps      %      usec
    none                       95      950000000  95      0      low
    3 network-control          5      50000000    5      0      low
    none

Logical interface ge-3/2/2.0 (Index 83) (SNMP ifIndex 6080) (Generation

```

148)

```

Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.100 ] Encapsulation: ENET2
Traffic statistics:
  Input bytes :          0
  Output bytes :         336
  Input packets:          0
  Output packets:         4
IPv6 total statistics:
  Input bytes :       1716096
  Output bytes :       1716096
  Input packets:      13407
  Output packets:     13407
Local statistics:
  Input bytes :          0
  Output bytes :         336
  Input packets:          0
  Output packets:         4
Transit statistics:
  Input bytes :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:         0          0 pps
  Output packets:         0          0 pps
IPv6 total statistics:
  Input bytes :       1716096
  Output bytes :       1716096
  Input packets:      13407
  Output packets:     13407
Protocol inet6, MTU: 1500, Generation: 159, Route table: 0
  Flags: Is-Primary
  Addresses, Flags: Is-Default Is-Primary
    Destination: Unspecified, Local: 2000::2
Generation: 146
  Addresses, Flags: Is-Preferred
    Destination: fe80::/64, Local: fe80::214:f600:6412:86fa
Protocol multiservice, MTU: Unlimited, Generation: 148
Generation: 160, Route table: 0
  Policer: Input: __default_arp_policer__

```

Logical interface ge-3/2/2.32767 (Index 84) (SNMP ifIndex 6081) (Generation

149)

```

Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x0000.0 ] Encapsulation: ENET2
Traffic statistics:
  Input bytes :          0
  Output bytes :          0
  Input packets:         0
  Output packets:         0
Local statistics:
  Input bytes :          0
  Output bytes :          0
  Input packets:         0
  Output packets:         0
Transit statistics:
  Input bytes :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:         0          0 pps
  Output packets:         0          0 pps
Protocol multiservice, MTU: Unlimited, Generation: 161, Route table: 0
  Flags: None
  Policer: Input: __default_arp_policer__

```

## Sample Output

**show interfaces  
extensive (100-Gigabit  
Ethernet)**

```

user@host> show interfaces et-0/0/0:0 extensive
Physical interface: et-0/0/0:0, Enabled, Physical link is Down
  Interface index: 156, SNMP ifIndex: 516, Generation: 163
  Link-level type: Ethernet, MTU: 9192, Speed: 50000mbps, BPDU Error: None,
MAC-REWRITE Error: None,
  Loopback: Disabled, Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running Down
  Interface flags: Hardware-Down SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues     : 8 supported, 8 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:aa:aa:aa:aa:00, Hardware address: 00:21:59:5c:48:00
  Last flapped   : 2010-01-07 16:36:49 PST (18:02:35 ago)
  Statistics last cleared: Never
Traffic statistics:
  Input bytes   :                0                0 bps
  Output bytes  :                0                0 bps
  Input packets :                0                0 pps
  Output packets:                0                0 pps
IPv6 transit statistics:
  Input bytes   :                0
  Output bytes  :                0
  Input packets :                0
  Output packets:                0
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0,
  L2 channel errors: 0, L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors:
0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0,
  HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 8 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 DEFAULT, NC-                0                0                0
  1 REALTIME                    0                0                0
  2 PRIVATE, NC-                0                0                0
  3 CONTROL                     1253             1253                0
  4 BC-H, CLASS_                0                0                0
  5 BC-M, CLASS_                0                0                0
  6 IA, CLASS_V_                0                0                0
  7 CLASS_S_OUTP                0                0                0

Queue      Mapped Forwarding Class
0          DEFAULT, NC-Q0
1          REALTIME
2          PRIVATE, NC-Q1
3          CONTROL
4          BC-H, CLASS-Q4
5          BC-M, CLASS-Q5

```

```

6      IA, CLASS_V_OUTPUT
7      CLASS_S_OUTPUT
Active alarms : None
Active defects : None
MAC statistics:
Total octets          Receive          Transmit
Total packets        0              0
Unicast packets      0              0
Broadcast packets    0              0
Multicast packets    0              0
CRC/Align errors     0              0
FIFO errors          0              0
MAC control frames   0              0
MAC pause frames     0              0
Oversized frames     0
Jabber frames        0
Fragment frames      0
VLAN tagged frames   0
Code violations       0
Packet Forwarding Engine configuration:
Destination slot: 0
CoS information:
Direction : Output
CoS transmit queue      Bandwidth          Buffer Priority Limit

                                %      bps      %      usec
0 best-effort           95    47500000000    95      0      low none
3 network-control       5     25000000000     5      0      low none

Logical interface et-0/0/0:0.0 (Index 68) (SNMP ifIndex 546) (Generation 161)
Flags: Deviet-Down SNMP-Traps Encapsulation: ENET2
Traffic statistics:
Input bytes :          0
Output bytes :          0
Input packets:         0
Output packets:        0
Local statistics:
Input bytes :          0
Output bytes :          0
Input packets:         0
Output packets:        0
Transit statistics:
Input bytes :          0          0 bps
Output bytes :          0          0 bps
Input packets:         0          0 pps
Output packets:        0          0 pps
Protocol inet, MTU: 9178, Generation: 220, Route table: 0
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 210.160.0/24, Local: 210.160.0.1, Broadcast: 210.160.0.255,
Generation: 192
Protocol mpls, MTU: 9166, Maximum labels: 3, Generation: 221, Route table: 0

Protocol multiservice, MTU: Unlimited, Generation: 222, Route table: 0
Policer: Input: __default_arp_policer

```

## Sample Output

### show interfaces

```

user@host> show interfaces et-7/0/0 extensive
Physical interface: et-7/0/0, Enabled, Physical link is Up

```

extensive (PTX5000  
Packet Transport  
Switch)

```

Interface index: 168, SNMP ifIndex: 501, Generation: 171
Link-level type: Ethernet, MTU: 1514, Speed: 10Gbps, BPDU Error: None,
MAC-REWRITE Error: None,
Loopback: Disabled, Source filtering: Disabled, Flow control: Enabled
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags : None
CoS queues : 8 supported, 8 maximum usable queues
Hold-times : Up 0 ms, Down 0 ms
Current address: 88:e0:f3:3b:de:43, Hardware address: 88:e0:f3:3b:de:43
Last flapped : 2012-01-18 11:48:24 PST (01:47:08 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes : 3583014 0 bps
Output bytes : 758050 0 bps
Input packets: 17740 0 pps
Output packets: 3418 0 pps
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0,
L2 channel errors: 0, L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors:
0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0,
HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters: Queued packets Transmitted packets Dropped packets

0 best-effort 252 252 0
1 expedited-fo 0 0 0
2 assured-forw 0 0 0
3 network-cont 6196 6196 0

Queue number: Mapped forwarding classes
0 best-effort
1 expedited-forwarding
2 assured-forwarding
3 network-control
Active alarms : None
Active defects : None
MAC statistics:
Total octets 4108825 1159686
Total packets 21166 6448
Unicast packets 14824 3255
Broadcast packets 3 0
Multicast packets 6339 3193
CRC/Align errors 0 0
FIFO errors 0 0
MAC control frames 0 0
MAC pause frames 0 0
Oversized frames 0
Jabber frames 0

```

```

Fragment frames                                0
VLAN tagged frames                            16091
Code violations                                0
Filter statistics:
  Input packet count                          9
  Input packet rejects                        9
  Input DA rejects                           9
  Input SA rejects                           0
  Output packet count                        0
  Output packet pad count                    0
  Output packet error count                  0
  CAM destination filters: 0, CAM source filters: 0
Autonegotiation information:
  Negotiation status: Incomplete
Packet Forwarding Engine configuration:
  Destination slot: 7
CoS information:
  Direction : Output
  CoS transmit queue      Bandwidth      Buffer Priority
Limit
      %      bps      %      usec      low
0 best-effort      95      9500000000      95      0
none
3 network-control      5      500000000      5      0
none
Interface transmit statistics: Disabled

```

## Sample Output

**show interfaces  
extensive (T4000)**

```

user@host> show interfaces xe-4/0/0 extensive
Physical interface: xe-4/0/0, Enabled, Physical link is Up
Interface index: 170, SNMP ifIndex: 859, Generation: 173

```

## Routers with Type 5 FPCs)

```

Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, Loopback:
None, Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : None
CoS queues    : 8 supported, 8 maximum usable queues
Hold-times    : Up 0 ms, Down 0 ms
Current address: 00:12:1e:37:53:f8, Hardware address: 00:12:1e:37:53:f8
Last flapped   : 2012-06-06 02:25:56 PDT (10:11:58 ago)
Statistics last cleared: 2012-06-06 12:36:59 PDT (00:00:55 ago)
Traffic statistics:
Input bytes   : 0                      0 bps
Output bytes  : 0                      0 bps
Input packets : 0                      0 pps
Output packets: 0                      0 pps
IPv6 transit statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0,
Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets  Dropped packets

0 best-effort        0                0                0
1 expedited-fo       0                0                0
2 assured-forw       0                0                0
3 network-cont       0                0                0

Queue number:      Mapped forwarding classes
0                  best-effort
1                  expedited-forwarding
2                  assured-forwarding
3                  network-control
Active alarms   : None
Active defects  : None
PCS statistics           Seconds
Bit errors         0
Errored blocks     0
MAC statistics:        Receive      Transmit
Total octets        0              0
Total packets       0              0
Unicast packets     0              0
Broadcast packets   0              0
Multicast packets   0              0
CRC/Align errors    0              0
FIFO errors         0              0
MAC control frames  0              0
MAC pause frames    0              0
Oversized frames    0
Jabber frames       0

```

```

    Fragment frames                                0
    VLAN tagged frames                             0
    Code violations                                0
  Filter statistics:
    Input packet count                             0
    Input packet rejects                           0
    Input DA rejects                               0
    Input SA rejects                               0
    Output packet count                            0
    Output packet pad count                        0
    Output packet error count                      0
    CAM destination filters: 0, CAM source filters: 0
  Packet Forwarding Engine configuration:
    Destination slot: 4
  CoS information:
    Direction : Output
    CoS transmit queue          Bandwidth          Buffer Priority
  Limit
    %          bps          %          usec
    0 best-effort          95          4750000000          95          0          low
  none
    3 network-control          5          250000000          5          0          low
  none
  Interface transmit statistics: Disabled

  Logical interface xe-4/0/0.0 (Index 93) (SNMP ifIndex 834) (Generation 158)
  Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2
  Traffic statistics:
    Input bytes : 0
    Output bytes : 0
    Input packets: 0
    Output packets: 0
  Local statistics:
    Input bytes : 0
    Output bytes : 0
    Input packets: 0
    Output packets: 0
  Transit statistics:
    Input bytes : 0 0 bps
    Output bytes : 0 0 bps
    Input packets: 0 0 pps
    Output packets: 0 0 pps
  Protocol inet, MTU: 1500, Generation: 192, Route table: 0
  Flags: Sendbcst-pkt-to-re
  Addresses, Flags: Is-Preferred Is-Primary
  Destination: 34.1.1/24, Local: 34.1.1.2, Broadcast: 34.1.1.255, Generation:
157
  Protocol multiservice, MTU: Unlimited, Generation: 193, Route table: 0
  Policer: Input: __default_arp_policer__

```

## Sample Output

show interfaces  
extensive (T4000  
Routers with 24-port  
10-Gigabit Ethernet

```

user@host> show interfaces xe-3/1/0 extensive
Physical interface: xe-3/1/0, Enabled, Physical link is Up
Interface index: 160, SNMP ifIndex: 1285, Generation: 163
Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, BPDU Error:
None, Loopback: None,

```



LAN/WAN PIC on Type  
5 FPC)

```

Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link flags     : None
CoS queues     : 8 supported, 8 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 2c:6b:f5:e1:cb:39, Hardware address: 2c:6b:f5:e1:cb:39
Last flapped   : 2012-05-09 07:15:54 UTC (03:39:52 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   : 0 0 bps
Output bytes  : 0 0 bps
Input packets : 0 0 pps
Output packets: 0 0 pps
IPv6 transit statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0, L3
incompletes: 0, L2 channel errors: 0,
L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,
FIFO errors: 0,
HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets  Dropped packets

0 best-effort        0                0                0
1 ay_q1              0                0                0
2 assured-forw       0                0                0
3 network-cont       0                0                0

Queue number:      Mapped forwarding classes
0                 best-effort
1                 ay_q1
2                 assured-forwarding
3                 network-control

Active alarms : None
Active defects : None
PCS statistics           Seconds
Bit errors            0
Errored blocks        0
MAC statistics:         Receive      Transmit
Total octets          0            0
Total packets         0            0
Unicast packets       0            0
Broadcast packets     0            0
Multicast packets     0            0
CRC/Align errors      0            0
FIFO errors           0            0
MAC control frames    0            0
MAC pause frames      0            0
Oversized frames      0
Jabber frames         0
Fragment frames       0

```

```

VLAN tagged frames          0
Code violations              0
Filter statistics:
  Input packet count        0
  Input packet rejects      0
  Input DA rejects          0
  Input SA rejects          0
  Output packet count       0
  Output packet pad count   0
  Output packet error count 0
  CAM destination filters: 0, CAM source filters: 0
Packet Forwarding Engine configuration:
  Destination slot: 3
CoS information:
  Direction : Output
  CoS transmit queue      Bandwidth      Buffer Priority  Limit

                                %      bps      %      usec
0 best-effort              95    9500000000    95      0      low    none
3 network-control          5     500000000     5      0      low    none

Preclassifier statistics:
Traffic Class      Received Packets  Transmitted Packets  Dropped Packets

network-control      0                0                0
best-effort          0                0                0
Interface transmit statistics: Disabled

```

## Sample Output

**show interfaces  
extensive (Aggregated  
Ethernet)**

```

user@host> show interfaces ae0 extensive
Physical interface: ae0, Enabled, Physical link is Up
Interface index: 199, SNMP ifIndex: 570, Generation: 202
Link-level type: Ethernet, MTU: 1514, Speed: 2Gbps, BPDU Error: None,
MAC-REWRITE Error: None, Loopback: Disabled, Source filtering: Disabled,
Flow control: Disabled, Minimum links needed: 1, Minimum bandwidth needed: 0
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Current address: 2c:6b:f5:d1:0f:c0, Hardware address: 2c:6b:f5:d1:0f:c0
Last flapped   : 2012-06-06 23:33:03 PDT (00:00:58 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes :          18532          1984 bps
Output bytes :           0           0 bps
Input packets:          158           2 pps
Output packets:           0           0 pps
IPv6 transit statistics:
Input bytes :           0
Output bytes :           0
Input packets:           0
Output packets:           0
Dropped traffic statistics due to STP State:
Input bytes :           0
Output bytes :           0
Input packets:           0
Output packets:           0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0,
Resource errors: 0

```

## Output errors:

Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:

0

Ingress queues: 8 supported, 4 in use

Queue counters:            Queued packets    Transmitted packets            Dropped packets

0 best-effort                            0                            0                            0

1 expedited-fo                            0                            0                            0

2 assured-forw                            0                            0                            0

3 network-cont                            0                            0                            0

Egress queues: 8 supported, 4 in use

Queue counters:            Queued packets    Transmitted packets            Dropped packets

0 best-effort                            57                            57                            0

1 expedited-fo                            0                            0                            0

2 assured-forw                            0                            0                            0

3 network-cont                            63605                            63605                            0

Queue number:            Mapped forwarding classes

0                            best-effort

1                            expedited-forwarding

2                            assured-forwarding

3                            network-control

Logical interface ae0.0 (Index 331) (SNMP ifIndex 583) (Generation 142)

Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2

Statistics            Packets            pps            Bytes            bps

Bundle:

Input :            149            2            17416            1984

Output:            0            0            0            0

Link:

ge-3/2/5.0

Input :            90            1            10100            992

Output:            0            0            0            0

ge-3/3/9.0

Input :            59            1            7316            992

Output:            0            0            0            0

LACP info:            Role            System            System            Port

Port    Port

priority            identifier    priority            number

key

ge-3/2/5.0    Actor            100    00:00:00:00:00:01            127            1

1    ge-3/2/5.0    Partner            127    00:24:dc:98:67:c0            127            1            1

ge-3/3/9.0    Actor            100    00:00:00:00:00:01            127            2

1    ge-3/3/9.0    Partner            127    00:24:dc:98:67:c0            127            2            1

LACP Statistics:            LACP Rx            LACP Tx            Unknown Rx            Illegal Rx

ge-3/2/5.0            38            137            0            0

ge-3/3/9.0            36            139            0            0

Marker Statistics:            Marker Rx            Resp Tx            Unknown Rx            Illegal Rx

ge-3/2/5.0            0            0            0            0

```

    ge-3/3/9.0          0          0          0          0
Protocol inet, MTU: 1500, Generation: 169, Route table: 0
  Flags: Sendbcst-pkt-to-re
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 1.1.1/24, Local: 1.1.1.2, Broadcast: 1.1.1.255, Generation:
153
Protocol multiservice, MTU: Unlimited, Generation: 170, Route table: 0
  Flags: Is-Primary
  Policer: Input: __default_arp_policer__

```

## show interfaces interface-set (Ethernet Interface Set)

<b>Syntax</b>	<code>show interfaces interface-set <i>interface-set-name</i></code> <detail   terse>
<b>Release Information</b>	Command introduced in Junos OS Release 8.5.
<b>Description</b>	<p>Display information about the specified gigabit or 10-Gigabit Ethernet interface set. Supported in MX Series routers with enhanced queuing DPCs or MPCs.</p> <p>You can also use the <b>show interfaces interface-set</b> command to display information about agent circuit identifier (ACI) interface sets configured on MX Series routers with MPCs/MICs.</p>
<b>Options</b>	<p><b>interface-set <i>interface-set-name</i></b>—Display information about the specified Gigabit Ethernet, 10-Gigabit Ethernet, or ACI interface set.</p> <p><b>detail   terse</b>—(Optional) Display the specified level of output.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying and Managing Agent Circuit Identifier-Based Dynamic VLAN Configuration</li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces interface-set terse on page 285</a> <a href="#">show interfaces interface-set detail on page 285</a> <a href="#">show interfaces interface-set (ACI Interface Set) on page 285</a>
<b>Output Fields</b>	Table 33 on page 283 describes the information for the <b>show interfaces interface-set</b> command.

Table 33: Ethernet show interfaces interface-set Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Interface set</b>	Name of the interface set or sets.	All levels
<b>Interface set index</b>	<p>Index number of the interface set. For ACI interface sets, the following fields are displayed:</p> <ul style="list-style-type: none"> <li><b>ACI VLAN</b>—ACI interface set that the router uses to create dynamic VLAN subscriber interfaces based on the agent circuit identifier value.</li> <li><b>PPPoE</b>—Dynamic PPPoE subscriber interface that the router creates using the ACI interface set.</li> </ul>	<b>detail none</b>
<b>Agent Circuit ID</b>	For ACI interface sets, string in DHCP or PPPoE control packets that uniquely identifies the subscriber's access node and the DSL line on the access node.	<b>detail none</b>
<b>Max Sessions</b>	For dynamic PPPoE subscriber interfaces, maximum number of PPPoE logical interfaces that that can be activated on the underlying interface.	<b>detail none</b>

Table 33: Ethernet show interfaces interface-set Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Max Sessions VSA Ignore</b>	For dynamic PPPoE subscriber interfaces, whether the router is configured to ignore (clear) the PPPoE maximum session value returned by RADIUS in the Max-Clients-Per-Interface Juniper Networks VSA [26-143] and restore the PPPoE maximum session value on the underlying interface to the value configured with the <b>max-sessions</b> statement: <b>Off</b> (default) or <b>On</b> .	<b>detail none</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the specified interface set.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes and number of bytes per second received and transmitted on the interface set</li> <li>• <b>Input packets, Output packets</b>—Number of packets and number of packets per second received and transmitted on the interface set.</li> </ul>	<b>detail</b>
<b>Egress queues supported</b>	Total number of egress queues supported on the specified interface set.	<b>detail</b>
<b>Egress queues in use</b>	Total number of egress queues used on the specified interface set.	<b>detail</b>
<b>Queue counters</b>	<b>Queued packets, Transmitted packets, and Dropped packets</b> statistics for the four forwarding classes.	<b>detail</b>
<b>Members</b>	List of all interface sets or, for ACI interface sets, list of all subscriber interfaces belonging to the specified ACI interface set.	<b>detail none</b>

## Sample Output

### show interfaces interface-set terse

```
user@host> show interfaces interface-set terse
Interface set:
  iflset-xe-11/3/0-0
  ge-1/0/1-0
  ge-1/0/1-2
```

### show interfaces interface-set detail

```
user@host> show interfaces interface-set iflset-xe-11/3/0-0 detail
Interface set: iflset-xe-11/3/0-0
Interface set index: 19
Traffic statistics:
  Output bytes :          751017840          401673504 bps
  Output packets:         11044380          738377 pps
Egress queues: 4 supported, 4 in use
Queue counters:
  Queued packets  Transmitted packets  Dropped packets
0 best-effort    211091327          11044380        199995746
1 expedited-fo      0                  0                0
2 assured-forw      0                  0                0
3 network-cont      0                  0                0
Members:
  xe-11/3/0.0
```

### show interfaces interface-set (ACI Interface Set)

```
user@host> show interfaces interface-set
Interface set: aci-1001-demux0.1073741826
Interface set index: 1
ACI VLAN:
  Agent Circuit ID: aci-ppp-dhcp-dvlan-60
PPPoE:
  Max Sessions: 3, Max Sessions VSA Ignore: Off
Members:
  pp0.1073741827
```

## show interfaces interface-set queue

<b>Syntax</b>	show interfaces interface-set queue <i>interface-set-name</i> <aggregate   remaining-traffic> <forwarding-class <i>class-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 8.5.
<b>Description</b>	Display information about the gigabit or 10-Gigabit Ethernet interface set queue. Supported in MX Series routers with enhanced queuing DPCs.
<b>Options</b>	<p><b><i>interface-set-name</i></b>—(Optional) Display information about the specified gigabit or 10-Gigabit Ethernet interface set. Wildcard values can be used in the interface set name.</p> <p><b>aggregate</b>—(Optional) Display the aggregated queuing statistics of all member logical interfaces for interface sets that have traffic-control profiles configured.</p> <p><b>both-ingress-egress</b>—(Optional) On Gigabit Ethernet Intelligent Queuing 2 (IQ2) PICs, display both ingress and egress queue statistics.</p> <p><b>egress</b>—(Optional) Display egress queue statistics.</p> <p><b>forwarding-class <i>class-name</i></b>—(Optional) Display queuing statistics for the specified forwarding class.</p> <p><b>ingress</b>—(Optional) On Gigabit Ethernet IQ2 PICs, display ingress queue statistics.</p> <p><b>remaining-traffic</b>—(Optional) Display the queuing statistics of all member logical interfaces for interface sets that do not have traffic-control profiles configured.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Example: Configuring E-LINE and E-LAN Services for a PBB Network on MX Series Routers</li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces interface-set queue (Gigabit Ethernet) on page 288</a> <a href="#">show interfaces interface-set queue both-ingress-egress (Enhanced DPC) on page 288</a> <a href="#">show interfaces interface-set queue egress (Enhanced DPC) on page 290</a> <a href="#">show interfaces interface-set queue forwarding-class (Gigabit Ethernet) on page 292</a> <a href="#">show interfaces interface-set queue (Enhanced DPC) on page 293</a> <a href="#">show interfaces interface-set queue remaining-traffic (Gigabit Ethernet) on page 294</a>
<b>Output Fields</b>	Table 34 on page 287 describes the information for the <b>show interfaces interface-set queue</b> command.



Table 34: Ethernet show interfaces interface-set queue Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Interface set</b>	Name of the interface set.	All levels
<b>Interface set index</b>	Index number of the interface set.	All levels
<b>Forwarding classes supported</b>	Total number of forwarding classes supported on the specified interface set.	All levels
<b>Forwarding classes in use</b>	Total number of forwarding classes used on the specified interface set.	All levels
<b>Egress queues supported</b>	Total number of egress queues supported on the specified interface set.	All levels
<b>Egress queues in use</b>	Total number of egress queues used on the specified interface set.	All levels
<b>Ingress queues supported</b>	Total number of ingress queues supported on the specified interface set.	All levels
<b>Ingress queues in use</b>	Total number of ingress queues used on the specified interface set.	All levels
<b>Queue</b>	Egress or ingress queue number for the statistics being displayed.	All levels
<b>Forwarding classes</b>	Forwarding class name for the statistics being displayed.	All levels
<b>Queued</b>	<b>Packet</b> and <b>Byte</b> statistics for the specified queue. <ul style="list-style-type: none"> <li><b>Packets</b>—Number of packets queued and input rate in packets per second.</li> <li><b>Bytes</b>—Number of bytes queued and input rate in bytes per second.</li> </ul>	All levels
<b>Transmitted</b>	<b>Packet</b> and <b>Byte</b> statistics for the specified forwarding class. <ul style="list-style-type: none"> <li><b>Packets</b>—Number of packets transmitted and transmit rate in packets per second.</li> <li><b>Bytes</b>—Number of bytes transmitted and transmit rate in bytes per second.</li> <li><b>Tail-dropped packets</b>—Number of packets tail dropped.</li> <li><b>RED-dropped packets</b>—Number of RED-dropped packets for the <b>low</b>, <b>medium-low</b>, <b>medium-high</b>, and <b>high</b> loss priorities.</li> <li><b>RED-dropped bytes</b>—Number of RED-dropped bytes for the <b>low</b>, <b>medium-low</b>, <b>medium-high</b>, and <b>high</b> loss priorities.</li> </ul>	All levels

## Sample Output

**show interfaces**  
**interface-set queue**  
**(Gigabit Ethernet)**

```
user@host> show interfaces interface-set queue ge-2/2/0-0
Interface set: ge-2/2/0-0
Interface set index: 3
Forwarding classes: 8 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets          :          3998482          1 pps
    Bytes            :        271896884        688 bps
  Transmitted:
    Packets          :          1077474          1 pps
    Bytes            :        73268340        688 bps
    Tail-dropped packets :          0          0 pps
    RED-dropped packets :          2921008          0 pps
      Low            :          2921008          0 pps
      Medium-low     :          0          0 pps
      Medium-high    :          0          0 pps
      High           :          0          0 pps
    RED-dropped bytes :        198628544          0 bps
      Low            :        198628544          0 bps
      Medium-low     :          0          0 bps
      Medium-high    :          0          0 bps
      High           :          0          0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets          :          0          0 pps
    Bytes            :          0          0 bps
  Transmitted:
    ...
```

**show interfaces**  
**interface-set queue**

```
user@host> show interfaces interface-set queue ge-2/2/0-0 both-ingress-egress
Interface set: ge-2/2/0-0
Interface set index: 3
```

**both-ingress-egress  
(Enhanced DPC)**

```

Forwarding classes: 16 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      185968478      473161 pps
    Bytes        :      10042313520    204441336 bps
  Transmitted:
    Packets      :      5441673        13780 pps
    Bytes        :      293850342      5952960 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      180526772  459372 pps
    RED-dropped bytes  :      9748446282 198451512 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
  Transmitted:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      0      0 pps
    RED-dropped bytes  :      0      0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :      522021472      473602 pps
    Bytes        :      28190332480    204599944 bps
  Transmitted:
    Packets      :      5791772        4055 pps
    Bytes        :      312755688      1751976 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      516227139  469546 pps
    RED-dropped bytes  :      27876265560 202843872 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
  Transmitted:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      0      0 pps
    RED-dropped bytes  :      0      0 bps
Forwarding classes: 16 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      5417304        13797 pps
    Bytes        :      368429508      7506096 bps
  Transmitted:
    Packets      :      5014996        12769 pps
    Bytes        :      341019728      6946560 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      402189      1028 pps
    Low          :      402189      1028 pps
    Medium-low   :      0      0 pps
    Medium-high  :      0      0 pps
    High         :      0      0 pps
    RED-dropped bytes  :      27348852    559536 bps
    Low          :      27348852    559536 bps
    Medium-low   :      0      0 bps
    Medium-high  :      0      0 bps

```

```

      High                :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
  Packets                :                0                0 pps
  Bytes                  :                0                0 bps
Transmitted:
  Packets                :                0                0 pps
  Bytes                  :                0                0 bps
  Tail-dropped packets :                0                0 pps
  RED-dropped packets  :                0                0 pps
    Low                  :                0                0 pps
    Medium-low          :                0                0 pps
    Medium-high         :                0                0 pps
    High                 :                0                0 pps
  RED-dropped bytes    :                0                0 bps
    Low                  :                0                0 bps
    Medium-low          :                0                0 bps
    Medium-high         :                0                0 bps
    High                 :                0                0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
  Packets                :          5770534          3963 pps
  Bytes                  :      396943252      2156144 bps
Transmitted:
  Packets                :          3945152          1457 pps
  Bytes                  :      268270336      792608 bps
  Tail-dropped packets :                0                0 pps
  RED-dropped packets  :          1815141          2506 pps
    Low                  :          1815141          2506 pps
    Medium-low          :                0                0 pps
    Medium-high         :                0                0 pps
    High                 :                0                0 pps
  RED-dropped bytes    :      123429524      1363536 bps
    Low                  :      123429524      1363536 bps
    Medium-low          :                0                0 bps
    Medium-high         :                0                0 bps
    High                 :                0                0 bps
Queue: 3, Forwarding classes: network-control
Queued:
  Packets                :                0                0 pps
  Bytes                  :                0                0 bps
Transmitted:
  Packets                :                0                0 pps
  Bytes                  :                0                0 bps
  Tail-dropped packets :                0                0 pps
  RED-dropped packets  :                0                0 pps
    Low                  :                0                0 pps
    Medium-low          :                0                0 pps
    Medium-high         :                0                0 pps
    High                 :                0                0 pps
  RED-dropped bytes    :                0                0 bps
    Low                  :                0                0 bps
    Medium-low          :                0                0 bps
    Medium-high         :                0                0 bps
    High                 :                0                0 bps

```

**show interfaces**  
**interface-set queue**

```

user@host> show interfaces interface-set queue ge-2/2/0-0 egress
Interface set: ge-2/2/0-0
Interface set index: 3

```

## egress (Enhanced DPC)

```

Forwarding classes: 16 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :          3958253          13822 pps
    Bytes        :          269217592        7519712 bps
  Transmitted:
    Packets      :          3665035          12729 pps
    Bytes        :          249222380        6924848 bps
    Tail-dropped packets :          0          0 pps
    RED-dropped packets :          293091        1093 pps
      Low        :          293091        1093 pps
      Medium-low :          0          0 pps
      Medium-high :          0          0 pps
      High       :          0          0 pps
    RED-dropped bytes :          19930188        594864 bps
      Low        :          19930188        594864 bps
      Medium-low :          0          0 bps
      Medium-high :          0          0 bps
      High       :          0          0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
  Transmitted:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
    Tail-dropped packets :          0          0 pps
    RED-dropped packets :          0          0 pps
      Low        :          0          0 pps
      Medium-low :          0          0 pps
      Medium-high :          0          0 pps
      High       :          0          0 pps
    RED-dropped bytes :          0          0 bps
      Low        :          0          0 bps
      Medium-low :          0          0 bps
      Medium-high :          0          0 bps
      High       :          0          0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :          5350989          3904 pps
    Bytes        :          368412924        2124048 bps
  Transmitted:
    Packets      :          3790469          1465 pps
    Bytes        :          257751892        796960 bps
    Tail-dropped packets :          0          0 pps
    RED-dropped packets :          1550282        2439 pps
      Low        :          1550282        2439 pps
      Medium-low :          0          0 pps
      Medium-high :          0          0 pps
      High       :          0          0 pps
    RED-dropped bytes :          105419176        1327088 bps
      Low        :          105419176        1327088 bps
      Medium-low :          0          0 bps
      Medium-high :          0          0 bps
      High       :          0          0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      :          0          0 pps
    Bytes        :          0          0 bps
  Transmitted:

```

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

**show interfaces**  
**interface-set queue**

```
user@host> show interfaces interface-set queue ge-2/2/0-0 forwarding-class best-effort
Interface set: ge-2/2/0-0
Interface set index: 3
```

**forwarding-class  
(Gigabit Ethernet)**

```

Forwarding classes: 8 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :          101857694          1420083 pps
    Bytes        :          6927234456         772532320 bps
  Transmitted:
    Packets      :          3984693           55500 pps
    Bytes        :         270959592          30192512 bps
    Tail-dropped packets :              0              0 pps
    RED-dropped packets :          97870952          1364583 pps
      Low        :          97870952          1364583 pps
      Medium-low :              0              0 pps
      Medium-high:              0              0 pps
      High       :              0              0 pps
    RED-dropped bytes :         6655225776         742339808 bps
      Low        :         6655225776         742339808 bps
      Medium-low :              0              0 bps
      Medium-high:              0              0 bps
      High       :              0              0 bps

```

**show interfaces  
interface-set queue  
(Enhanced DPC)**

```

user@host> show interfaces interface-set queue ge-2/2/0-0 ingress
Interface set: foo
  Interface set index: 3
Forwarding classes: 16 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :          149036817          473711 pps
    Bytes        :          8048003934         204642936 bps
  Transmitted:
    Packets      :          4360749           13891 pps
    Bytes        :         235480446          6000912 bps
    Tail-dropped packets :              0              0 pps
    RED-dropped packets :          144676035          459820 pps
    RED-dropped bytes :          7812506592         198642024 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :              0              0 pps
    Bytes        :              0              0 bps
  Transmitted:
    Packets      :              0              0 pps
    Bytes        :              0              0 bps
    Tail-dropped packets :              0              0 pps
    RED-dropped packets :              0              0 pps
    RED-dropped bytes :              0              0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :          485089207          473605 pps
    Bytes        :         26195987476         204597576 bps
  Transmitted:
    Packets      :          5480799           3959 pps
    Bytes        :         295963146          1710504 bps
    Tail-dropped packets :              0              0 pps
    RED-dropped packets :          479605853          469646 pps
    RED-dropped bytes :         25898716170         202887072 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      :              0              0 pps
    Bytes        :              0              0 bps
  Transmitted:

```

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
RED-dropped bytes	:	0	0 bps

**show interfaces  
interface-set queue  
remaining-traffic  
(Gigabit Ethernet)**

```
user@host> show interfaces interface-set queue ge-2/2/0-0 remaining-traffic
```

```
Interface set: ge-2/2/0-0
```

```
Interface set index: 12
```

```
Forwarding classes: 8 supported, 4 in use
```

```
Egress queues: 4 supported, 4 in use
```

```
Queue: 0, Forwarding classes: best-effort
```

```
Queued:
```


Packets	:	2201552	0 pps
Bytes	:	149705536	0 bps

```
Transmitted:
```

Packets	:	609765	0 pps
Bytes	:	41464020	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	1591787	0 pps
Low	:	1591787	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	108241516	0 bps
Low	:	108241516	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps



## show interfaces diagnostics optics (Gigabit Ethernet, 10-Gigabit Ethernet, and 100 Gigabit Ethernet)

<b>Syntax</b>	<code>show interfaces diagnostics optics <i>interface-name</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M120, M320, MX Series, T320, T640, and T1600 routers only) Display diagnostics data, warnings, and alarms for Gigabit Ethernet, 10-Gigabit Ethernet, and 100 Gigabit Ethernet interfaces.
<b>Options</b>	<i>interface-name</i> —Interface name: <i>ge-fpc/pic/port</i> or <i>xe-fpc/pic/port</i> .
<b>Additional Information</b>	<p>The transceivers are polled in 1-second intervals for diagnostics data, warnings, and alarms. The alarms do not cause the links to go down or the LEDs to change color, nor generate SNMP traps. Changes in alarm and warning status will generate system log messages.</p> <p>Thresholds that trigger a high alarm, low alarm, high warning, or low warning are set by the transceiver vendors. Generally, a high alarm or low alarm indicates that the optics module is not operating properly. This information can be used to diagnose why a device is not working.</p> <div style="margin-top: 20px;">  <p><b>NOTE:</b> Some transceivers do not support all optical diagnostics features described in the output fields.</p> <p>The <code>show interfaces diagnostics optics</code> command for optical interfaces does not report the decibel (dBm) value of the received signal if the received power is zero milliwatts (0.0000 mW).</p> </div>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces diagnostics optics (DWDM and DWDM OTN) on page 307</a> <a href="#">show interfaces diagnostics optics (Bidirectional SFP) on page 308</a> <a href="#">show interfaces diagnostics optics (SFP) on page 309</a> <a href="#">show interfaces diagnostics optics (SFP) on page 309</a> <a href="#">show interfaces diagnostics optics (XFP and CFP Optics) on page 310</a>
<b>Output Fields</b>	Table 35 on page 296 lists the output fields for the <code>show interfaces diagnostics optics</code> command for DWDM and DWDM OTN PICs. Output fields are listed in the approximate order in which they appear.

**Table 35: 10-Gigabit Ethernet DWDM and DWDM OTN PICs show interfaces diagnostics optics Output Fields**

Field Name	Field Description
<b>Physical interface</b>	Name of the physical interface.
<b>Laser bias current</b>	Magnitude of the laser bias power setting current, in milliamperes. The laser bias provides direct modulation of laser diodes and modulates currents.
<b>Laser output power</b>	Laser output power, in milliwatts (mW) and decibels, referenced to 1.0 mW (dBm). This is a software equivalent to the <b>LsPOWMON</b> pin in hardware.
<b>Receiver signal average optical power</b>	Average received optical power, in mW and dBm. This indicator is a software equivalent to the <b>RxPOWMON</b> pin in hardware. Average optical power is vendor-specific.
<b>Laser end-of-life alarm</b>	Laser end-of-life alarm: <b>On</b> or <b>Off</b> .
<b>Laser wavelength alarm</b>	Laser wavelength alarm: <b>On</b> or <b>Off</b> .
<b>Laser bias current alarm</b>	Laser bias current alarm: <b>On</b> or <b>Off</b> .
<b>Laser temperature alarm</b>	Laser temperature alarm: <b>On</b> or <b>Off</b> .
<b>Laser power alarm</b>	Laser power alarm: <b>On</b> or <b>Off</b> .
<b>Modulator temperature alarm</b>	Modulator temperature alarm: <b>On</b> or <b>Off</b> . Transceivers from some vendors do not support this field.
<b>Modulator bias alarm</b>	Modulator bias alarm: <b>On</b> or <b>Off</b> .
<b>Tx multiplexer FIFO error alarm</b>	Transmit multiplexer first in, first out (FIFO) error alarm: <b>On</b> or <b>Off</b> .
<b>Tx loss of PLL lock alarm</b>	Transmit loss of phase-locked loop (PLL) lock alarm: <b>On</b> or <b>Off</b> .
<b>Rx loss of average optical power alarm</b>	Receive loss of average optical power alarm: <b>On</b> or <b>Off</b> .
<b>Rx loss of AC power alarm</b>	Receive loss of AC power alarm: <b>On</b> or <b>Off</b> . Transceivers from some vendors do not support this field.
<b>Rx loss of PLL lock alarm</b>	Receive loss of phase-locked loop (PLL) lock alarm: <b>On</b> or <b>Off</b> .

[Table 36 on page 297](#) lists the output fields for the **show interfaces diagnostics optics** command when the router is operating with bidirectional SFP optics. Output fields are listed in the approximate order in which they appear.

Table 36: Gigabit Ethernet Bidirectional SFP Optics show interfaces diagnostics optics Output Fields

Field Name	Field Description
<b>Physical interface</b>	Name of the physical interface.
<b>Laser bias current</b>	Magnitude of the laser bias power setting current, in milliamperes. The laser bias provides direct modulation of laser diodes and modulates currents.
<b>Laser output power</b>	Laser output power, in milliwatts (mW) and decibels, referenced to 1.0 mW (dBm).
<b>Module temperature</b>	Temperature of the optics module, in Celsius and Fahrenheit.
<b>Module voltage</b>	Internally measured module voltage.
<b>Receiver signal average optical power</b>	Average received optical power, in mW and dBm.
<b>Laser bias current high alarm</b>	Laser bias power setting high alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser bias current low alarm</b>	Laser bias power setting low alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser bias current high warning</b>	Laser bias power setting high warning. Displays <b>on</b> or <b>off</b> .
<b>Laser bias current low warning</b>	Laser bias power setting low warning. Displays <b>on</b> or <b>off</b> .
<b>Laser output power high alarm</b>	Laser output power high alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser output power low alarm</b>	Laser output power low alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser output power high warning</b>	Laser output power high warning. Displays <b>on</b> or <b>off</b> .
<b>Laser output power low warning</b>	Laser output power low warning. Displays <b>on</b> or <b>off</b> .
<b>Module temperature high alarm</b>	Module temperature high alarm. Displays <b>on</b> or <b>off</b> .
<b>Module temperature low alarm</b>	Module temperature low alarm. Displays <b>on</b> or <b>off</b> .
<b>Module temperature high warning</b>	Module temperature high warning. Displays <b>on</b> or <b>off</b> .

Table 36: Gigabit Ethernet Bidirectional SFP Optics show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Module temperature low warning	Module temperature low warning. Displays <b>on</b> or <b>off</b> .
Module voltage high alarm	Module voltage high alarm. Displays <b>on</b> or <b>off</b> .
Module voltage low alarm	Module voltage low alarm. Displays <b>on</b> or <b>off</b> .
Module voltage high warning	Module voltage high warning. Displays <b>on</b> or <b>off</b> .
Module voltage low warning	Module voltage high warning. Displays <b>on</b> or <b>off</b> .
Laser rx power high alarm	Receive laser power high alarm. Displays <b>on</b> or <b>off</b> .
Laser rx power low alarm	Receive laser power low alarm. Displays <b>on</b> or <b>off</b> .
Laser rx power high warning	Receive laser power high warning. Displays <b>on</b> or <b>off</b> .
Laser rx power low warning	Receive laser power low warning. Displays <b>on</b> or <b>off</b> .
Laser bias current high alarm threshold	Vendor-specified threshold for the laser bias current high alarm: <b>70.000 mA</b> .
Laser bias current low alarm threshold	Vendor-specified threshold for the laser bias current low alarm: <b>0.0002 mA</b> .
Laser bias current high warning threshold	Vendor-specified threshold for the laser bias current high warning: <b>65.000 mA</b> .
Laser bias current low warning threshold	Vendor-specified threshold for the laser bias current low warning: <b>0.0002 mA</b> .
Laser output power high alarm threshold	Vendor-specified threshold for the laser output power high alarm: <b>1.0000 mW</b> or <b>0.00 dBm</b> .
Laser output power low alarm threshold	Vendor-specified threshold for the laser output power low alarm: <b>0.0560 mW</b> or <b>-12.52 dBm</b> .
Laser output power high warning threshold	Vendor-specified threshold for the laser output power high warning: <b>0.6300 mW</b> or <b>-2.01 dBm</b> .

Table 36: Gigabit Ethernet Bidirectional SFP Optics show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser output power low warning threshold	Vendor-specified threshold for the laser output power low warning: <b>0.0890 mW</b> or <b>-10.51 dBm</b> .
Module temperature high alarm threshold	Vendor-specified threshold for the module temperature high alarm: <b>100° C</b> or <b>212° F</b> .
Module temperature low alarm threshold	Vendor-specified threshold for the module temperature low alarm: <b>-50° C</b> or <b>-58° F</b> .
Module temperature high warning threshold	Vendor-specified threshold for the module temperature high warning: <b>95° C</b> or <b>203° F</b> .
Module temperature low warning threshold	Vendor-specified threshold for the module temperature low warning: <b>-48° C</b> or <b>-54° F</b> .
Module voltage high alarm threshold	Module voltage high alarm threshold: <b>3.700 v</b> .
Module voltage low alarm threshold	Module voltage low alarm threshold: <b>2.900 v</b> .
Module voltage high warning threshold	Module voltage high warning threshold: <b>3.7600 v</b> .
Module voltage low warning threshold	Module voltage low warning threshold: <b>3.000 v</b> .
Laser rx power high alarm threshold	Vendor-specified threshold for the laser Rx power high alarm: <b>1.9953 mW</b> or <b>3.00 dBm</b> .
Laser rx power low alarm threshold	Vendor-specified threshold for the laser Rx power low alarm: <b>0.0001 mW</b> or <b>-40.00 dBm</b> .
Laser rx power high warning threshold	Vendor-specified threshold for the laser Rx power high warning: <b>1.0000 mW</b> or <b>0.00 dBm</b> .
Laser rx power low warning threshold	Vendor-specified threshold for the laser Rx power low warning: <b>0.0010 mW</b> or <b>-30.00 dBm</b> .

[Table 37 on page 299](#) lists the output fields for the **show interfaces diagnostics optics** command for SFP transceivers. Output fields are listed in the approximate order in which they appear.

Table 37: Gigabit Ethernet SFP show interfaces diagnostics Output Fields

Field Name	Field Description
Physical interface	Name of the physical interface.

Table 37: Gigabit Ethernet SFP show interfaces diagnostics Output Fields (*continued*)

Field Name	Field Description
Laser bias current	Measured laser bias current in uA.
Laser output power	Measured laser output power in mW.
Module temperature	Internally measured module temperature.
Module voltage	Internally measured module voltage.
Laser rx power	Measured receive optical power in mW.
Laser bias current high alarm	Laser bias current high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser bias current low alarm	Laser bias current low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser output power high alarm	Laser output power high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser output power low alarm	Laser output power low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Module temp high alarm	Module temperature high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Module temp low alarm	Module temperature low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser rx power high alarm	Laser receive power high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser rx power low alarm	Laser receive power low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser bias current high warning	Laser bias current high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser bias current low warning	Laser bias current low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser output power high warning	Laser output power high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser output power low warning	Laser output power low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Module temperature high warning	Module temperature high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Module temperature low warning	Module temperature low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.

Table 37: Gigabit Ethernet SFP show interfaces diagnostics Output Fields (*continued*)

Field Name	Field Description
Laser rx power high warning	Laser receive power high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser rx power low warning	Laser receive power low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser bias current high alarm threshold	Laser bias current high alarm threshold. Alarm threshold ranges are vendor-specific.
Laser bias current low alarm threshold	Laser bias current low alarm threshold. Alarm threshold ranges are vendor-specific.
Laser bias current high warning threshold	Laser bias current high warning threshold. Warning ranges are vendor-specific.
Laser bias current low warning threshold	Laser bias current low warning threshold. Warning ranges are vendor-specific.
Laser output power high alarm threshold	Laser output power high alarm threshold. Alarm threshold ranges are vendor-specific.
Laser output power low alarm threshold	Laser output power low alarm threshold. Alarm threshold ranges are vendor-specific.
Laser output power high warning threshold	Laser output power high warning threshold. Warning ranges are vendor-specific.
Laser output power low warning threshold	Laser output power low warning threshold. Warning ranges are vendor-specific.
Module temperature high alarm threshold	Module temperature high alarm threshold. Alarm threshold ranges are vendor-specific.
Module temperature low alarm threshold	Module temperature low alarm threshold. Alarm threshold ranges are vendor-specific.
Module temperature high warning threshold	Module temperature high warning threshold. Warning ranges are vendor-specific.
Module temperature low warning threshold	Module temperature low warning threshold. Warning ranges are vendor-specific.
Module voltage high alarm threshold	Module voltage high alarm threshold. Alarm ranges are vendor-specific.
Module voltage low alarm threshold	Module voltage low alarm threshold. Alarm ranges are vendor-specific.

Table 37: Gigabit Ethernet SFP show interfaces diagnostics Output Fields (*continued*)

Field Name	Field Description
Module voltage high warning threshold	Module voltage high warning threshold. Warning ranges are vendor-specific.
Module voltage low warning threshold	Module voltage low warning threshold. Warning ranges are vendor-specific.
Laser rx power high alarm threshold	Laser receive power high alarm threshold. Alarm threshold ranges are vendor-specific.
Laser rx power low alarm threshold	Laser receive power low alarm threshold. Alarm threshold ranges are vendor-specific.
Laser rx power high warning threshold	Laser receive power high warning threshold. Warning threshold ranges are vendor-specific.
Laser rx power high low threshold	Laser receive power high warning threshold. Warning threshold ranges are vendor-specific.

Table 38 on page 302 lists the output fields for the **show interfaces diagnostics optics** command for 10-Gigabit Ethernet transceivers. Output fields are listed in the approximate order in which they appear.

Table 38: 10-Gigabit Ethernet Transceivers show interfaces diagnostics optics Output Fields

Field Name	Field Description
Physical interface	Name of the physical interface.
Laser bias current	Measured laser bias current in mA.
Laser output power	Measured laser output power in mW.
Module temperature	Internally measured module temperature.
Laser rx power	Measured receive optical power in mW.
Laser bias current high alarm	Laser bias current high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser bias current low alarm	Laser bias current low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser output power high alarm	Laser output power high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser output power low alarm	Laser output power low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.



Table 38: 10-Gigabit Ethernet Transceivers show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Module temp high alarm	Module temperature high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Module temp low alarm	Module temperature low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser rx power high alarm	Laser receive power high alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser rx power low alarm	Laser receive power low alarm: <b>On</b> or <b>Off</b> . Alarm ranges are vendor-specific.
Laser bias current high warning	Laser bias current high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser bias current low warning	Laser bias current low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser output power high warning	Laser output power high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser output power low warning	Laser output power low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Module temperature high warning	Module temperature high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Module temperature low warning	Module temperature low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser rx power high warning	Laser receive power high warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser rx power low warning	Laser receive power low warning: <b>On</b> or <b>Off</b> . Warning ranges are vendor-specific.
Laser bias current high alarm threshold	Laser bias current high alarm threshold. Alarm threshold ranges are vendor-specific.
Laser bias current low alarm threshold	Laser bias current low alarm threshold. Alarm threshold ranges are vendor-specific.
Laser output power high alarm threshold	Laser output power high alarm threshold. Alarm threshold ranges are vendor-specific.
Laser output power low alarm threshold	Laser output power low alarm threshold. Alarm threshold ranges are vendor-specific.

**Table 38: 10-Gigabit Ethernet Transceivers show interfaces diagnostics optics Output Fields (*continued*)**

Field Name	Field Description
Module temperature high alarm threshold	Module temperature high alarm threshold. Alarm threshold ranges are vendor-specific.
Module temperature low alarm threshold	Module temperature low alarm threshold. Alarm threshold ranges are vendor-specific.
Laser rx power high alarm threshold	Laser receive power high alarm threshold. Alarm threshold ranges are vendor-specific.
Laser rx power low alarm threshold	Laser receive power low alarm threshold. Alarm threshold ranges are vendor-specific.
Laser bias current high warning threshold	Laser bias current high warning threshold. Warning ranges are vendor-specific.
Laser bias current low warning threshold	Laser bias current low warning threshold. Warning ranges are vendor-specific.
Laser output power high warning threshold	Laser output power high warning threshold. Warning ranges are vendor-specific.
Laser output power low warning threshold	Laser output power low warning threshold. Warning ranges are vendor-specific.
Module temperature high warning threshold	Module temperature high warning threshold. Warning ranges are vendor-specific.
Module temperature low warning threshold	Module temperature low warning threshold. Warning ranges are vendor-specific.
Laser rx power high warning threshold	Laser receive power high warning threshold. Warning threshold ranges are vendor-specific.
Laser rx power low warning threshold	Laser receive power low warning threshold. Warning threshold ranges are vendor-specific.

[Table 39 on page 304](#) lists the output fields for the **show interfaces diagnostics optics** command for XFP transceivers. Output fields are listed in the approximate order in which they appear.

**Table 39: 10-Gigabit Ethernet XFP Transceivers show interfaces diagnostics optics Output Fields**

Field Name	Field Description
Physical interface	Name of the physical interface.

Table 39: 10-Gigabit Ethernet XFP Transceivers show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser bias current	Magnitude of the laser bias power setting current, in milliamperes. The laser bias provides direct modulation of laser diodes and modulates currents.
Laser output power	Laser output power, in milliwatts (mW) and decibels, referenced to 1.0 mW (dBm). This is a software equivalent to the <b>LsPOWMON</b> pin in hardware.
Module temperature	Temperature of the XFP optics module, in Celsius and Fahrenheit.
Laser rx power	Laser received optical power, in mW and dBm.
Laser bias current high alarm	Laser bias power setting high alarm. Displays <b>on</b> or <b>off</b> .
Laser bias current low alarm	Laser bias power setting low alarm. Displays <b>on</b> or <b>off</b> .
Laser bias current high warning	Laser bias power setting high warning. Displays <b>on</b> or <b>off</b> .
Laser bias current low warning	Laser bias power setting low warning. Displays <b>on</b> or <b>off</b> .
Laser output power high alarm	Laser output power high alarm. Displays <b>on</b> or <b>off</b> .
Laser output power low alarm	Laser output power low alarm. Displays <b>on</b> or <b>off</b> .
Laser output power high warning	Laser output power high warning. Displays <b>on</b> or <b>off</b> .
Laser output power low warning	Laser output power low warning. Displays <b>on</b> or <b>off</b> .
Module temperature high alarm	Module temperature high alarm. Displays <b>on</b> or <b>off</b> .
Module temperature low alarm	Module temperature low alarm. Displays <b>on</b> or <b>off</b> .
Module temperature high warning	Module temperature high warning. Displays <b>on</b> or <b>off</b> .
Module temperature low warning	Module temperature low warning. Displays <b>on</b> or <b>off</b> .
Laser rx power high alarm	Receive laser power high alarm. Displays <b>on</b> or <b>off</b> .

Table 39: 10-Gigabit Ethernet XFP Transceivers show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser rx power low alarm	Receive laser power low alarm. Displays <b>on</b> or <b>off</b> .
Laser rx power high warning	Receive laser power high warning. Displays <b>on</b> or <b>off</b> .
Laser rx power low warning	Receive laser power low warning. Displays <b>on</b> or <b>off</b> .
Module not ready alarm	Module not ready alarm. When <b>on</b> , indicates the module has an operational fault. Displays <b>on</b> or <b>off</b> .
Module power down alarm	Module power down alarm. When <b>on</b> , module is in a limited power mode, low for normal operation. Displays <b>on</b> or <b>off</b> .
Tx data not ready alarm	Any condition leading to invalid data on the transmit path. Displays <b>on</b> or <b>off</b> .
Tx not ready alarm	Any condition leading to invalid data on the transmit path. Displays <b>on</b> or <b>off</b> .
Tx laser fault alarm	Laser fault condition. Displays <b>on</b> or <b>off</b> .
Tx CDR loss of lock alarm	Transmit clock and data recovery (CDR) loss of lock. Loss of lock on the transmit side of the CDR. Displays <b>on</b> or <b>off</b> .
Rx not ready alarm	Any condition leading to invalid data on the receive path. Displays <b>on</b> or <b>off</b> .
Rx loss of signal alarm	Receive Loss of Signal alarm. When <b>on</b> , indicates insufficient optical input power to the module. Displays <b>on</b> or <b>off</b> .
Rx CDR loss of lock alarm	Receive CDR loss of lock. Loss of lock on the receive side of the CDR. Displays <b>on</b> or <b>off</b> .
Laser bias current high alarm threshold	Vendor-specified threshold for the laser bias current high alarm: <b>130.000 mA</b> .
Laser bias current low alarm threshold	Vendor-specified threshold for the laser bias current low alarm: <b>10.000 mA</b> .
Laser bias current high warning threshold	Vendor-specified threshold for the laser bias current high warning: <b>120.000 mA</b> .
Laser bias current low warning threshold	Vendor-specified threshold for the laser bias current low warning: <b>12.000 mA</b> .
Laser output power high alarm threshold	Vendor-specified threshold for the laser output power high alarm: <b>0.8910 mW</b> or <b>-0.50 dBm</b> .
Laser output power low alarm threshold	Vendor-specified threshold for the laser output power low alarm: <b>0.2230 mW</b> or <b>-6.52 dBm</b> .

Table 39: 10-Gigabit Ethernet XFP Transceivers show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser output power high warning threshold	Vendor-specified threshold for the laser output power high warning: <b>0.7940 mW</b> or <b>-100 dBm</b> .
Laser output power low warning threshold	Vendor-specified threshold for the laser output power low warning: <b>0.2510 mW</b> or <b>-600 dBm</b> .
Module temperature high alarm threshold	Vendor-specified threshold for the module temperature high alarm: <b>90° C</b> or <b>194° F</b> .
Module temperature low alarm threshold	Vendor-specified threshold for the module temperature low alarm: <b>-5° C</b> or <b>23° F</b> .
Module temperature high warning threshold	Vendor-specified threshold for the module temperature high warning: <b>85 ° C</b> or <b>185 ° F</b> .
Module temperature low warning threshold	Vendor-specified threshold for the module temperature low warning: <b>0° C</b> or <b>32° F</b> .
Laser rx power high alarm threshold	Vendor-specified threshold for the laser Rx power high alarm: <b>1.2589 mW</b> or <b>1.00 dBm</b> .
Laser rx power low alarm threshold	Vendor-specified threshold for the laser Rx power low alarm: <b>0.0323 mW</b> or <b>-14.91 dBm</b> .
Laser rx power high warning threshold	Vendor-specified threshold for the laser Rx power high warning: <b>1.1220 mW</b> or <b>0.50 dBm</b> .
Laser rx power low warning threshold	Vendor-specified threshold for the laser Rx power low warning: <b>0.0363 mW</b> or <b>-14.40 dBm</b> .

## Sample Output

### show interfaces diagnostics optics

```

user@host> show interfaces diagnostics optics ge-5/0/0
Physical interface: ge-5/0/0
Laser bias current           : 79.938 mA

```

**(DWDM and DWDM OTN)**

```

Laser output power           : 1.592 mW / 2.02 dBm
Receiver signal average optical power : 1.3854 mW / 1.42 dBm
Laser end-of-life alarm      : Off
Laser wavelength alarm       : Off
Laser bias current alarm     : Off
Laser temperature alarm      : Off
Laser power alarm            : Off
Modulator temperature alarm   : Off
Modulator bias alarm         : Off
Tx multiplexer FIFO error alarm : Off
Tx loss of PLL lock alarm    : Off
Rx loss of average optical power alarm: Off
Rx loss of AC power alarm    : Off
Rx loss of PLL lock alarm    : Off

```

**show interfaces  
diagnostics optics  
(Bidirectional SFP)**

```
user@host> show interfaces diagnostics optics ge-3/0/6
```

```

Physical interface: ge-3/0/6
  Laser bias current           : 13.356 mA
  Laser output power           : 0.2210 mW / -6.56 dBm
  Module temperature           : 36 degrees C / 96 degrees F
  Module voltage               : 3.2180 V
  Receiver signal average optical power : 0.2429 mW / -6.15 dBm
  Laser bias current high alarm : Off
  Laser bias current low alarm  : Off
  Laser bias current high warning : Off
  Laser bias current low warning : Off
  Laser output power high alarm : Off
  Laser output power low alarm  : Off
  Laser output power high warning : Off
  Laser output power low warning : Off
  Module temperature high alarm : Off
  Module temperature low alarm  : Off
  Module temperature high warning : Off
  Module temperature low warning : Off
  Module voltage high alarm     : Off
  Module voltage low alarm      : Off
  Module voltage high warning   : Off
  Module voltage low warning    : Off
  Laser rx power high alarm     : Off
  Laser rx power low alarm      : Off
  Laser rx power high warning   : Off
  Laser rx power low warning    : Off
  Laser bias current high alarm threshold : 70.000 mA
  Laser bias current low alarm threshold : 0.002 mA
  Laser bias current high warning threshold : 65.000 mA
  Laser bias current low warning threshold : 0.002 mA
  Laser output power high alarm threshold : 1.0000 mW / 0.00 dBm
  Laser output power low alarm threshold : 0.0560 mW / -12.52 dBm
  Laser output power high warning threshold : 0.6300 mW / -2.01 dBm
  Laser output power low warning threshold : 0.0890 mW / -10.51 dBm
  Module temperature high alarm threshold : 100 degrees C / 212 degrees F
  Module temperature low alarm threshold : -50 degrees C / -58 degrees F
  Module temperature high warning threshold : 95 degrees C / 203 degrees F
  Module temperature low warning threshold : -48 degrees C / -54 degrees F
  Module voltage high alarm threshold : 3.700 V
  Module voltage low alarm threshold : 2.900 V
  Module voltage high warning threshold : 3.600 V
  Module voltage low warning threshold : 3.000 V
  Laser rx power high alarm threshold : 1.9953 mW / 3.00 dBm
  Laser rx power low alarm threshold : 0.0001 mW / -40.00 dBm
  Laser rx power high warning threshold : 1.0000 mW / 0.00 dBm

```

Laser rx power low warning threshold : 0.0010 mW / -30.00 dBm

**show interfaces  
diagnostics optics  
(SFP)**

user@host> show interfaces diagnostics optics ge-0/3/0

Physical interface: ge-0/3/0

```

Laser bias current           : 23.408 mA
Laser output power          : 1.479 mW / 1.70 dBm
Module temperature          : 37 degrees C / 99 degrees F
Laser rx power              : 0.121 mW / -9.16 dBm
Laser bias current high alarm : Off
Laser bias current low alarm  : Off
Laser output power high alarm : Off
Laser output power low alarm  : Off
Module temperature high alarm : Off
Module temperature low alarm  : Off
Laser rx power high alarm     : Off
Laser rx power low alarm      : Off
Laser bias current high warning : Off
Laser bias current low warning : Off
Laser output power high warning : Off
Laser output power low warning : Off
Module temperature high warning : Off
Module temperature low warning : Off
Laser rx power high warning    : Off
Laser rx power low warning     : Off
Laser bias current high alarm threshold : 31.000 mA
Laser bias current low alarm threshold : 10.000 mA
Laser output power high alarm threshold : 6.000 mW / 7.78 dBm
Laser output power low alarm threshold : 0.100 mW / -10.00 dBm
Module temperature high alarm threshold : 85 degrees C / 185 degrees F
Module temperature low alarm threshold : 0 degrees C / 32 degrees F
Laser rx power high alarm threshold : 1.000 mW / 0.00 dBm
Laser rx power low alarm threshold : 0.001 mW / -30.00 dBm
Laser bias current high warning threshold : 28.000 mA
Laser bias current low warning threshold : 11.000 mA
Laser output power high warning threshold : 5.000 mW / 6.99 dBm
Laser output power low warning threshold : 0.500 mW / -3.01 dBm
Module temperature high warning threshold : 70 degrees C / 158 degrees F
Module temperature low warning threshold : 10 degrees C / 50 degrees F
Laser rx power high warning threshold : 0.501 mW / -3.00 dBm
Laser rx power low warning threshold : 0.001 mW / -28.86 dBm

```

**show interfaces  
diagnostics optics  
(SFP)**

user@host> show interfaces diagnostics optics ge-1/0/0

Physical interface: ge-1/0/0

```

Laser bias current           : 49.010 mA
Laser output power          : 1.263 mW / 1.01 dBm
Module temperature          : 17 degrees C / 62 degrees F

Module voltage              : 4.21 V
Laser rx power              : 0.060 mW / -12.21 dBm
Laser bias current high alarm : Off
Laser bias current low alarm  : Off
Laser output power high alarm : Off
Laser output power low alarm  : Off
Module temperature high alarm : Off
Module temperature low alarm  : Off
Module voltage high alarm     : Off
Module voltage low alarm      : Off
Laser rx power high alarm     : Off
Laser rx power low alarm      : Off
Laser bias current high warning : Off

```

```

Laser bias current low warning           : Off
Laser output power high warning          : Off
Laser output power low warning           : Off
Module temperature high warning          : Off
Module temperature low warning           : Off
Module voltage high warning              : Off
Module voltage low warning               : Off
Laser rx power high warning              : Off
Laser rx power low warning               : Off
Laser bias current high alarm threshold  : 70.000 mA
Laser bias current low alarm threshold   : 20.000 mA
Laser bias current high warning threshold : 65.000 mA
Laser bias current low warning threshold : 25.000 mA
Laser output power high alarm threshold  : 1.4120 mW / 1.50 dBm
Laser output power low alarm threshold   : 0.1990 mW / -7.01 dBm
Laser output power high warning threshold : 1.2580 mW / 1.00 dBm
Laser output power low warning threshold : 0.2230 mW / -6.52 dBm
Module temperature high alarm threshold  : 78 degrees C / 172 degrees F

Module temperature low alarm threshold    : 13 degrees C / 9 degrees F
Module temperature high warning threshold : 75 degrees C / 167 degrees F

Module temperature low warning threshold  : 10 degrees C / 14 degrees F

Module voltage high alarm threshold       : 5.71 V
Module voltage low alarm threshold        : 2.05 V
Module voltage high warning threshold     : 5.20 V
Module voltage low warning threshold      : 3.11 V
Laser rx power high alarm threshold       : 1.7783 mW / 2.50 dBm
Laser rx power low alarm threshold        : 0.0100 mW / -20.00 dBm
Laser rx power high warning threshold     : 1.5849 mW / 2.00 dBm
Laser rx power low warning threshold      : 0.0158 mW / -18.01 dBm

```

**show interfaces  
diagnostics optics  
(XFP and CFP Optics)**

user@host> show interfaces diagnostics optics xe-2/1/0

Physical interface: xe-2/1/0

```

Laser bias current           : 52.060 mA
Laser output power           : 0.5640 mW / -2.49 dBm
Module temperature            : 31 degrees C / 88 degrees F
Laser rx power                : 0.0844 mW / -10.74 dBm
Laser bias current high alarm : Off
Laser bias current low alarm  : Off
Laser bias current high warning : Off
Laser bias current low warning : Off
Laser output power high alarm  : Off
Laser output power low alarm   : Off
Laser output power high warning : Off
Laser output power low warning : Off
Module temperature high alarm  : Off
Module temperature low alarm   : Off
Module temperature high warning : Off
Module temperature low warning : Off
Laser rx power high alarm      : Off
Laser rx power low alarm       : Off
Laser rx power high warning    : Off
Laser rx power low warning     : Off
Module not ready alarm         : Off
Module power down alarm        : Off
Tx data not ready alarm        : Off
Tx not ready alarm             : Off
Tx laser fault alarm           : Off
Tx CDR loss of lock alarm      : Off

```



```
Rx not ready alarm           : Off
Rx loss of signal alarm      : Off
Rx CDR loss of lock alarm    : Off
Laser bias current high alarm threshold : 130.000 mA
Laser bias current low alarm threshold  : 10.000 mA
Laser bias current high warning threshold : 120.000 mA
Laser bias current low warning threshold : 12.000 mA
Laser output power high alarm threshold : 0.8910 mW / -0.50 dBm
Laser output power low alarm threshold  : 0.2230 mW / -6.52 dBm
Laser output power high warning threshold : 0.7940 mW / -1.00 dBm
Laser output power low warning threshold : 0.2510 mW / -6.00 dBm
Module temperature high alarm threshold : 90 degrees C / 194 degrees F
Module temperature low alarm threshold  : -5 degrees C / 23 degrees F
Module temperature high warning threshold : 85 degrees C / 185 degrees F
Module temperature low warning threshold : 0 degrees C / 32 degrees F
Laser rx power high alarm threshold     : 1.2589 mW / 1.00 dBm
Laser rx power low alarm threshold       : 0.0323 mW / -14.91 dBm
Laser rx power high warning threshold    : 1.1220 mW / 0.50 dBm
Laser rx power low warning threshold      : 0.0363 mW / -14.40 dBm
```

## show interfaces irb

<b>Syntax</b>	<pre>show interfaces irb &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	Display integrated routing and bridging interfaces information.
<b>Options</b>	<p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the interface with the specified SNMP index.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Additional Information</b>	Integrated routing and bridging (IRB) provides simultaneous support for Layer 2 bridging and Layer 3 IP routing on the same interface. IRB enables you to route local packets to another routed interface or to another bridging domain that has a Layer 3 protocol configured.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces irb extensive on page 317</a></p> <p><a href="#">show interfaces irb snmp-index on page 318</a></p>
<b>Output Fields</b>	<a href="#">Table 40 on page 312</a> lists the output fields for the <b>show interfaces irb</b> command. Output fields are listed in the approximate order in which they appear.

**Table 40: show interfaces irb Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the physical interface. Possible values are described in the "Enabled Field" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Proto</b>	Protocol configured on the interface.	<b>terse</b>
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>

Table 40: show interfaces irb Output Fields (*continued*)

Field Name	Field Description	Level of Output
SNMP ifIndex	SNMP index number for the physical interface.	detail extensive none
Type	Physical interface type.	detail extensive none
Link-level type	Encapsulation being used on the physical interface.	detail extensive brief none
MTU	MTU size on the physical interface.	detail extensive brief none
Clocking	Reference clock source: <b>Internal</b> or <b>External</b> . Always unspecified on IRB interfaces.	detail extensive brief
Speed	Speed at which the interface is running. Always unspecified on IRB interfaces.	detail extensive brief
Device flags	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	detail extensive brief none
Interface flags	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	detail extensive brief none
Link type	Physical interface link type: <b>full duplex</b> or <b>half duplex</b> .	detail extensive none
Link flags	Information about the link. Possible values are described in the "Links Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	detail extensive none
Physical Info	Physical interface information.	All levels
Hold-times	Current interface hold-time up and hold-time down, in milliseconds.	detail extensive
Current address	Configured MAC address.	detail extensive none
Hardware address	MAC address of the hardware.	detail extensive none
Alternate link address	Backup address of the link.	detail extensive
Last flapped	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hours:minutes:seconds timezone (hours:minutes:seconds ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	detail extensive none
Statistics last cleared	Time when the statistics for the interface were last set to zero.	detail extensive

Table 40: show interfaces irb Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>IPv6 transit statistics</b>	<p>Number of IPv6 transit bytes and packets received and transmitted on the physical interface if IPv6 statistics tracking is enabled.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>detail extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the DPC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>detail extensive</b>

---

#### Logical Interface

Table 40: show interfaces irb Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface (which reflects its initialization sequence).	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP interface index number of the logical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Encapsulation</b>	Encapsulation on the logical interface.	<b>detail extensive</b>
<b>Bandwidth</b>	Speed at which the interface is running.	<b>detail extensive</b>
<b>Routing Instance</b>	Routing instance IRB is configured under.	<b>detail extensive</b>
<b>Bridging Domain</b>	Bridging domain IRB is participating in.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the logical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>IPv6 transit statistics</b>	Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the local interface. Possible values are described in the “Protocol Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>MTU</b>	Maximum transmission unit size on the logical interface.	<b>detail extensive</b>

Table 40: show interfaces irb Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Maximum labels</b>	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive</b>
<b>Addresses, Flags</b>	Information about address flags. Possible values are described in the "Addresses Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive</b>
<b>Policer</b>	The policer that is to be evaluated when packets are received or transmitted on the interface.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive</b>

## Sample Output

**show interfaces irb  
extensive**

```

user@host> show interfaces irb extensive
Physical interface: irb, Enabled, Physical link is Up
  Interface index: 129, SNMP ifIndex: 23, Generation: 130
  Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: Unspecified
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 02:00:00:00:00:30, Hardware address: 02:00:00:00:00:30
  Alternate link address: Unspecified
  Last flapped   : Never
  Statistics last cleared: Never
Traffic statistics:
  Input bytes   : 0
  Output bytes  : 0
  Input packets : 0
  Output packets: 0
IPv6 transit statistics:
  Input bytes   : 0
  Output bytes  : 0
  Input packets : 0
  Output packets: 0
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0

Logical interface irb.0 (Index 68) (SNMP ifIndex 70) (Generation 143)
  Flags: Hardware-Down SNMP-Traps 0x4000 Encapsulation: ENET2
  Bandwidth: 1000mbps
  Routing Instance: customer_0 Bridging Domain: bd0
Traffic statistics:
  Input bytes   : 0
  Output bytes  : 0
  Input packets : 0
  Output packets: 0
IPv6 transit statistics:
  Input bytes   : 0
  Output bytes  : 0
  Input packets : 0
  Output packets: 0
Local statistics:
  Input bytes   : 0
  Output bytes  : 0
  Input packets : 0
  Output packets: 0
Transit statistics:
  Input bytes   : 0                0 bps
  Output bytes  : 0                0 bps
  Input packets : 0                0 pps
  Output packets: 0                0 pps
IPv6 transit statistics:
  Input bytes   : 0

```

```
Output bytes : 0
Input packets: 0
Output packets: 0
Protocol inet, MTU: 1500, Generation: 154, Route table: 0
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 10.51.1/24, Local: 10.51.1.2, Broadcast: 10.51.1.255,
Generation: 155
Protocol multiservice, MTU: 1500, Generation: 155, Route table: 0
Flags: Is-Primary
Policer: Input: __default_arp_policer
```

### **show interfaces irb snmp-index**

```
user@host> show interfaces snmp-index 25
Physical interface: irb, Enabled, Physical link is Up
Interface index: 128, SNMP ifIndex: 25
Type: Ethernet, Link-level type: Ethernet, MTU: 1514
Device flags : Present Running
Interface flags: SNMP-Traps
Link type : Full-Duplex
Link flags : None
Current address: 02:00:00:00:00:30, Hardware address: 02:00:00:00:00:30
Last flapped : Never
Input packets : 0
Output packets: 0

Logical interface irb.0 (Index 68) (SNMP ifIndex 70)
Flags: Hardware-Down SNMP-Traps 0x4000 Encapsulation: ENET2
Bandwidth: 1000mbps
Routing Instance: customer_0 Bridging Domain: bd0
Input packets : 0
Output packets: 0
Protocol inet, MTU: 1500
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 10.51.1/24, Local: 10.51.1.2, Broadcast: 10.51.1.255
Protocol multiservice, MTU: 1500
Flags: Is-Primary
```



## show interfaces targeting (Aggregated Ethernet for Subscriber Management)

<b>Syntax</b>	show interfaces targeting aex
<b>Release Information</b>	Command introduced in Junos OS Release 11.2.
<b>Description</b>	(MX Series routers only) Display status information about the distribution of subscribers on different links in an aggregated Ethernet bundle.
<b>Required Privilege Level</b>	view
<b>Output Fields</b>	Table 41 on page 319 lists the output fields for the <b>show interfaces targeting</b> command. Output fields are listed in the approximate order in which they appear.

Table 41: show interfaces targeting Output Fields

Field Name	Field Description	Level of Output
<b>Aggregated Ethernet Interface</b>		
<b>Aggregated interface</b>	Name of the aggregated Ethernet bundle.	All levels
<b>Redundancy mode</b>	Redundancy mechanism on the interface: <b>Link Level Redundancy</b> or <b>FPC Redundancy</b> .	All levels
<b>Total number of distributed interfaces</b>	Number of distributed links in the bundle.	All levels
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface and state of the interface.	All levels
<b>Link status</b>	Status of the link on the physical interface: <b>up</b> or <b>down</b> .	
<b>Number of primary distributions</b>	Number of subscribers distributed on primary links.	All levels
<b>Number of backup distributions</b>	Number of subscribers distributed on backup links.	All levels

## Sample Output

**show interfaces  
targeting ae0**

```
user@host> show interfaces targeting ae0
Aggregated interface: ae0
Redundancy mode: Link Level Redundancy
Total number of distributed interfaces: 3
Physical interface: ge-1/0/0, Link status: Up
Number of primary distributions: 200
Number of backup distributions: 200
Physical interface: ge-1/1/0, Link status: Up
Number of primary distributions: 200
Number of backup distributions: 199
Physical interface: ge-2/0/7, Link status: Up
Number of primary distributions: 200
Number of backup distributions: 200
Physical interface: ge-2/0/8, Link status: Up
Number of primary distributions: 199
Number of backup distributions: 200
```

## show lacp interfaces

**Syntax** `show lacp interfaces`  
`<interface-name>`

**Release Information** Command introduced in Junos OS Release 7.6.

**Description** Display Link Aggregation Control Protocol (LACP) information about the specified aggregated Ethernet, Fast Ethernet, or Gigabit Ethernet interface.

**Options** **none**—Display LACP information for all interfaces.

**interface-name**—(Optional) Display LACP information for the specified interface:

- Aggregated Ethernet—**aenumber**
- Fast Ethernet—**fe-fpc/pic/port**
- Gigabit Ethernet—**ge-fpc/pic/port**



**NOTE:** The `show lacp interfaces` command returns the following error message if your system is not configured in either active or passive LACP mode:

“Warning: lacp subsystem not running – not needed by configuration”

**Required Privilege Level** view

**List of Sample Output** [show lacp interfaces \(Aggregated Ethernet\) on page 324](#)  
[show lacp interfaces \(Gigabit Ethernet\) on page 324](#)

**Output Fields** [Table 42 on page 321](#) lists the output fields for the `show lacp interfaces` command. Output fields are listed in the approximate order in which they appear.

**Table 42: show lacp interfaces Output Fields**

Field Name	Field Description
Aggregated interface	Aggregated interface value.

Table 42: show lacp interfaces Output Fields (*continued*)

Field Name	Field Description
LACP State	<p>LACP state information for each aggregated interface:</p> <ul style="list-style-type: none"> <li>• <b>Role</b>—Role played by the interface. It can be one of the following: <ul style="list-style-type: none"> <li>• <b>Actor</b>—Local device participating in LACP negotiation.</li> <li>• <b>Partner</b>—Remote device participating in LACP negotiation.</li> </ul> </li> <li>• <b>Exp</b>—Expired state. <b>Yes</b> indicates the actor or partner is in an expired state. <b>No</b> indicates the actor or partner is not in an expired state.</li> <li>• <b>Def</b>—Default. <b>Yes</b> indicates that the actor's receive machine is using the default operational partner information, administratively configured for the partner. <b>No</b> indicates the operational partner information in use has been received in an LACP PDU.</li> <li>• <b>Dist</b>—Distribution of outgoing frames. <b>No</b> indicates distribution of outgoing frames on the link is currently disabled and is not expected to be enabled. Otherwise, the value is <b>Yes</b>.</li> <li>• <b>Col</b>—Collection of incoming frames. <b>Yes</b> indicates collection of incoming frames on the link is currently enabled and is not expected to be disabled. Otherwise, the value is <b>No</b>.</li> <li>• <b>Syn</b>—Synchronization. If the value is <b>Yes</b>, the link is considered synchronized. It has been allocated to the correct link aggregation group, the group has been associated with a compatible aggregator, and the identity of the link aggregation group is consistent with the system ID and operational key information transmitted. If the value is <b>No</b>, the link is not synchronized. It is currently not in the right aggregation.</li> <li>• <b>Aggr</b>—Ability of aggregation port to aggregate (<b>Yes</b>) or to operate only as an individual link (<b>No</b>).</li> <li>• <b>Timeout</b>—LACP timeout preference. Periodic transmissions of LACP PDUs occur at either a slow or fast transmission rate, depending upon the expressed LACP timeout preference (<b>Long Timeout</b> or <b>Short Timeout</b>).</li> <li>• <b>Activity</b>—Actor or partner's port activity. <b>Passive</b> indicates the port's preference for not transmitting LAC PDUs unless its partner's control value is <b>Active</b>. <b>Active</b> indicates the port's preference to participate in the protocol regardless of the partner's control value.</li> </ul>

Table 42: show lacp interfaces Output Fields (*continued*)

Field Name	Field Description
LACP Protocol	<p>LACP protocol information for each aggregated interface:</p> <ul style="list-style-type: none"> <li>Link state (active or standby) indicated in parentheses next to the interface when link protection is configured.</li> <li><b>Receive State</b>—One of the following values: <ul style="list-style-type: none"> <li><b>Current</b>—The state machine receives an LACP PDU and enters the <b>Current</b> state.</li> <li><b>Defaulted</b>—If no LACP PDU is received before the timer for the <b>Current</b> state expires a second time, the state machine enters the <b>Defaulted</b> state.</li> <li><b>Expired</b>—If no LACP PDU is received before the timer for the <b>Current</b> state expires once, the state machine enters the <b>Expired</b> state.</li> <li><b>Initialize</b>—When the physical connectivity of a link changes or a Begin event occurs, the state machine enters the <b>Initialize</b> state.</li> <li><b>LACP Disabled</b>—If the port is operating in half duplex, the operation of LACP is disabled on the port, forcing the state to <b>LACP Disabled</b>. This state is similar to the <b>Defaulted</b> state, except that the port is forced to operate as an individual port.</li> <li><b>Port Disabled</b>—If the port becomes inoperable and a Begin event has not occurred, the state machine enters the <b>Port Disabled</b> state.</li> </ul> </li> <li><b>Transmit State</b>—Transmit state of state machine. One of the following values: <ul style="list-style-type: none"> <li><b>Fast Periodic</b>—Periodic transmissions are enabled at a fast transmission rate.</li> <li><b>No Periodic</b>—Periodic transmissions are disabled.</li> <li><b>Periodic Timer</b>—Transitory state entered when the periodic timer expires.</li> <li><b>Slow Periodic</b>—Periodic transmissions are enabled at a slow transmission rate.</li> </ul> </li> <li><b>Mux State</b>—State of the multiplexer state machine for the aggregation port. The state is one of the following values: <ul style="list-style-type: none"> <li><b>Attached</b>—Multiplexer state machine initiates the process of attaching the port to the selected aggregator.</li> <li><b>Collecting—Yes</b> indicates that the receive function of this link is enabled with respect to its participation in an aggregation. Received frames are passed to the aggregator for collection. <b>No</b> indicates the receive function of this link is not enabled.</li> <li><b>Collecting Distributing</b>—Collecting and distributing states are merged together to form a combined state (coupled control). Because independent control is not possible, the coupled control state machine does not wait for the partner to signal that collection has started before enabling both collection and distribution.</li> <li><b>Detached</b>—Process of detaching the port from the aggregator is in progress.</li> <li><b>Distributing—Yes</b> indicates that the transmit function of this link is enabled with respect to its participation in an aggregation. Frames may be passed down from the aggregator's distribution function for transmission. <b>No</b> indicates the transmit function of this link is not enabled.</li> <li><b>Waiting</b>—Multiplexer state machine is in a holding process, awaiting an outcome.</li> </ul> </li> </ul>
LACP Statistics	<p>LACP statistics are returned when the <b>extensive</b> option is used and provides the following information:</p> <ul style="list-style-type: none"> <li><b>LACP Rx</b>—LACP received counter that increments for each normal hello.</li> <li><b>LACP Tx</b>—Number of LACP transmit packet errors logged.</li> <li><b>Unknown Rx</b>—Number of unrecognized packet errors logged.</li> <li><b>Illegal Rx</b>—Number of invalid packets received.</li> </ul>

## Sample Output

show lacp interfaces  
(Aggregated Ethernet)

user@host&gt; show lacp interfaces ae0 extensive

```

Aggregated interface: ae0
  LACP state:      Role  Exp  Def  Dist  Col  Syn  Aggr  Timeout  Activity
    ge-1/0/1      Actor  No   Yes  No   No   No   Yes    Fast    Active
    ge-1/0/1      Partner No   Yes  No   No   No   Yes    Fast    Passive
    ge-1/0/2      Actor  No   Yes  No   No   No   Yes    Fast    Active
    ge-1/0/2      Partner No   Yes  No   No   No   Yes    Fast    Passive

  LACP protocol:      Receive State      Transmit State      Mux State
    ge-1/0/1          CURRENT          Fast periodic      Collecting
distributing
    ge-1/0/2          CURRENT          Fast periodic      Collecting
distributing
    ge-1/0/1 (active)  CURRENT          Fast periodic      Collecting
distributing
    ge-1/0/2 (standby) CURRENT          Fast periodic      WAITING
  LACP Statistics:      LACP Rx      LACP Tx      Unknown Rx      Illegal Rx
    ge-1/0/1            0              0              0              0
    ge-1/0/2            0              0              0              0

```

show lacp interfaces  
(Gigabit Ethernet)

user@host&gt; show lacp interfaces ge-0/3/0

```

Aggregated interface: ae0
  LACP State:      Role  Exp  Def  Dist  Col  Syn  Aggr  Timeout  Activity
    ge-0/3/0      Actor  No   No   Yes  Yes  Yes  Yes    Fast    Active
    ge-0/3/0      Partner No   No   Yes  Yes  Yes  Yes    Fast    Active
  LACP Protocol:      Receive State      Transmit State      Mux State
    ge-0/3/0          Current          Fast periodic      Collecting distributing

```

## show lacp statistics

<b>Syntax</b>	<b>show lacp statistics interfaces</b> <b>&lt;interface-name&gt;</b>
<b>Release Information</b>	Command introduced in JUNOS Release 9.4
<b>Description</b>	Display Link Aggregation Control Protocol (LACP) statistics
<b>Options</b>	<b>interfaces</b> —Display LACP interface statistics.  <b>interface-name</b> —(Optional) Display LACP statistics for the specified interface.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show lacp interfaces on page 321</a></li> <li>• <a href="#">clear lacp statistics on page 158</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show lacp statistics on page 326</a>
<b>Output Fields</b>	<a href="#">Table 43 on page 325</a> lists the output fields for the <b>show lacp statistics</b> command. Output fields are listed in the approximate order in which they appear.

**Table 43: show lacp statistics Output Fields**

Field Name	Field Description
Aggregated interface	Name of aggregated interface.
LACP Statistics	LACP statistics information for each interface.
LACP Rx	LACP received counter that increments for each normal hello.
LACP Tx	LACP counter of transmitted packets..
Unknown Rx	Number of unrecognized packet errors logged.
Illegal Rx	Number of invalid packets received.

## Sample Output

**show lacp statistics**

user@host> **show lacp statistics interfaces ae0**

Aggregated interface: ae0

LACP Statistics:	LACP Rx	LACP Tx	Unknown Rx	Illegal Rx
ge-4/0/20	0	6	0	0
ge-2/0/24	0	6	0	0
ge-3/0/32	0	6	0	0
ge-3/0/35	0	6	0	0
ge-3/0/34	0	6	0	0
ge-3/0/33	145	179	0	0
ge-4/0/21	0	6	0	0
ge-2/0/25	0	6	0	0



## show lacp timeouts

<b>Syntax</b>	<code>show lacp timeouts</code> <code>&lt;interface-name&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 12.1R4
<b>Description</b>	Display Link Aggregation Control Protocol (LACP) timeout entries.
<b>Options</b>	<i>interface-name</i> —(Optional) Display LACP timeout information about the specified aggregated Ethernet, Ethernet, fast Ethernet, or gigabit Ethernet interface.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show lacp interfaces on page 321</a></li> <li>• <a href="#">show lacp statistics on page 325</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show lacp timeouts on page 329</a> <a href="#">show lacp timeouts (aggregated Ethernet interface) on page 329</a> <a href="#">show lacp timeouts (gigabit Ethernet Interface) on page 329</a>
<b>Output Fields</b>	<a href="#">Table 44 on page 327</a> lists the output fields for the <b>show lacp timeouts</b> command. Output fields are listed in the approximate order in which they appear.

**Table 44: show lacp timeouts Output Fields**

Field Name	Field Description
<b>Aggregated interface</b>	Name of aggregated Ethernet interface.
<b>LACP interfaces</b>	Name of logical Ethernet interface configured for LACP.

Table 44: show lacp timeouts Output Fields (*continued*)

Field Name	Field Description
<b>Current State</b>	<p>State of the aggregation port. The state is one of the following values:</p> <ul style="list-style-type: none"><li>• <b>Attached</b>—Multiplexer state machine initiates the process of attaching the port to the selected aggregator.</li><li>• <b>Collecting</b>—Yes indicates that the receive function of this link is enabled with respect to its participation in an aggregation. Received frames are passed to the aggregator for collection. No indicates the receive function of this link is not enabled.</li><li>• <b>Collecting Distributing</b>—Collecting and distributing states are merged together to form a combined state (coupled control). Because independent control is not possible, the coupled control state machine does not wait for the partner to signal that collection has started before enabling both collection and distribution.</li><li>• <b>Detached</b>—Process of detaching the port from the aggregator is in progress.</li><li>• <b>Distributing</b>—Yes indicates that the transmit function of this link is enabled with respect to its participation in an aggregation. Frames might be passed down from the aggregator's distribution function for transmission. No indicates the transmit function of this link is not enabled.</li><li>• <b>Waiting</b>—Multiplexer state machine is in a holding process, awaiting an outcome.</li></ul>
<b>Last timeout</b>	<ul style="list-style-type: none"><li>• Date and time that the logical Ethernet interface entry timed out and how much time has elapsed since timing out.</li><li>• (<i>interface-name</i> option) <b>Never</b> is displayed if the interface has not experienced a timeout.</li></ul>

## Sample Output

**show lacp timeouts**

```
user@host> show lacp timeouts
Aggregated interface: ae0
  LACP Interfaces  Current state      Last timeout
    ge-1/2/0       Detached           2012-09-05 05:14:00 UTC (00:00:05 ago)
    ge-1/3/0       Detached           2012-09-05 05:14:00 UTC (00:00:05 ago)
Aggregated interface: ae1
```

**show lacp timeouts  
(aggregated Ethernet  
interface)**

```
user@host > show lacp timeouts ae0
Aggregated interface: ae0
  LACP Interfaces  Current state      Last timeout
    ge-1/2/0       Collecting distributing Never
    ge-1/3/0       Collecting distributing Never
```

**show lacp timeouts  
(gigabit Ethernet  
Interface)**

```
user@host > show lacp timeouts ge-1/2/0
Aggregated interface: ae0
  LACP Interfaces  Current state      Last timeout
    ge-1/2/0       Collecting distributing Never
```

## show interfaces mac-database (Gigabit Ethernet)

<b>Syntax</b>	<code>show interfaces mac-database (ge-fpc/pic/port   ge-fpc/pic/port.n) &lt;mac-address mac-address&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Command introduced on PTX Series Packet Transport Switches for Junos OS Release 12.1.
<b>Description</b>	(M Series, T Series, MX Series routers, and PTX Series Packet Transport Switches only) Display media access control (MAC) address information for the specified Gigabit Ethernet interface.
<b>Options</b>	<p><b>ge-fpc/pic/port</b>—Display MAC addresses that have been learned on all logical interfaces on a particular physical interface.</p> <p><b>ge-fpc/pic/port.n</b>—Display MAC addresses that have been learned on a particular logical interface.</p> <p><b>mac-address mac-address</b>—(Optional) Display detailed MAC address statistics, including policer information.</p>
<b>Additional Information</b>	On IQ2 PIC interfaces, the default value for maximum retention of entries in the MAC address table has changed, for cases in which the table is not full. The new holding time is 12 hours. The previous retention time of 3 minutes is still in effect when the table is full.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces mac-database (All MAC Addresses on a Port) on page 332</a> <a href="#">show interfaces mac-database (All MAC Addresses on a Service) on page 333</a> <a href="#">show interfaces mac-database mac-address on page 334</a>
<b>Output Fields</b>	<a href="#">Table 45 on page 330</a> lists the output fields for the <b>show interfaces mac-database</b> command. Output fields are listed in the approximate order in which they appear.

**Table 45: show interfaces mac-database Output Fields**

Field Name	Field Description
<b>Physical Interface</b>	
<b>Physical interface</b>	Name of the physical interface.
<b>Enabled</b>	State of the physical interface. Possible values are described in the "Enabled Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.
<b>Description</b>	Description and name of the interface.

Table 45: show interfaces mac-database Output Fields (*continued*)

Field Name	Field Description
Link-level type	Encapsulation being used on the physical interface.
MTU	MTU size on the physical interface.
Speed	Speed at which the interface is running.
Loopback	Whether loopback is enabled and the type of loopback: <b>local</b> or <b>remote</b> .
Source filtering	Whether source filtering is configured.
Flow control	Whether flow control is enabled or disabled.
Device flags	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .
Interface flags	Information about the interface. Possible values are described in the “Links Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .
Link flags	Information about the link. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .
<b>Logical Interface</b>	
Logical interface	Name of the logical interface.
Index	Logical interface index number, which reflects its initialization sequence.
SNMP ifIndex	Logical interface SNMP interface index number.
Flags	Information about the logical interface (possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> ).
Encapsulation	Encapsulation on the logical interface.
MAC address, Input frames, Input bytes, Output frames, Output bytes	MAC address and corresponding number of input frames, input bytes, output frames, and output bytes.
Number of MAC addresses	Number of MAC addresses configured.

Table 45: show interfaces mac-database Output Fields (*continued*)

Field Name	Field Description
<b>Policer Statistics</b>	<p>(Displayed for <b>mac-address</b> option only) Display information about policers applied to a logical interface-MAC pair.</p> <ul style="list-style-type: none"> <li>• <b>Policer type</b>—Type of policer that is out of spec with respect to the configuration. It can be one or more of the following: <ul style="list-style-type: none"> <li>• <b>Input premium</b>—Number of high-priority rating out-of-spec frames or bytes received.</li> <li>• <b>Output premium</b>—Number of high-priority rating out-of-spec frames or bytes sent.</li> <li>• <b>Input aggregate</b>—Total number of out-of-spec frames or bytes received.</li> <li>• <b>Output aggregate</b>—Total number of out-of-spec frames or bytes sent.</li> </ul> </li> <li>• <b>Discarded Frames</b>—Number of discarded frames.</li> <li>• <b>Discarded Bytes</b>—Number of discarded bytes.</li> </ul>

### Sample Output

**show interfaces  
mac-database (All**

```
user@host> show interfaces mac-database xe-0/3/3
Physical interface: xe-0/3/3, Enabled, Physical link is Up
Interface index: 372, SNMP ifIndex: 788
```

**MAC Addresses on a Port)**

Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, Loopback: None, Source filtering: Disabled, Flow control: Enabled

Device flags : Present Running

Interface flags: SNMP-Traps Internal: 0x4000

Link flags : None

Logical interface xe-0/3/3.0 (Index 364) (SNMP ifIndex 829)

Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2

MAC address	Input frames	Input bytes	Output frames	Output bytes
00:00:00:00:00:00	1	56	0	0
00:00:c0:01:01:02	7023810	323095260	0	0
00:00:c0:01:01:03	7023810	323095260	0	0
00:00:c0:01:01:04	7023810	323095260	0	0
00:00:c0:01:01:05	7023810	323095260	0	0
00:00:c0:01:01:06	7023810	323095260	0	0
00:00:c0:01:01:07	7023810	323095260	0	0
00:00:c0:01:01:08	7023809	323095214	0	0
00:00:c0:01:01:09	7023809	323095214	0	0
00:00:c0:01:01:0a	7023809	323095214	0	0
00:00:c0:01:01:0b	7023809	323095214	0	0
00:00:c8:01:01:02	30424784	1399540064	37448598	1722635508
00:00:c8:01:01:03	30424784	1399540064	37448598	1722635508
00:00:c8:01:01:04	30424716	1399536936	37448523	1722632058
00:00:c8:01:01:05	30424789	1399540294	37448598	1722635508
00:00:c8:01:01:06	30424788	1399540248	37448597	1722635462
00:00:c8:01:01:07	30424783	1399540018	37448597	1722635462
00:00:c8:01:01:08	30424783	1399540018	37448596	1722635416
00:00:c8:01:01:09	8836796	406492616	8836795	406492570
00:00:c8:01:01:0a	30424712	1399536752	37448521	1722631966
00:00:c8:01:01:0b	30424715	1399536890	37448523	1722632058

Number of MAC addresses : 21

**show interfaces  
mac-database (All**

user@host> show interfaces mac-database xe-0/3/3

Logical interface xe-0/3/3.0 (Index 364) (SNMP ifIndex 829)

Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2

## MAC Addresses on a Service)

MAC address	Input frames	Input bytes	Output frames	Output bytes
00:00:00:00:00:00	1	56	0	0
00:00:c0:01:01:02	7023810	323095260	0	0
00:00:c0:01:01:03	7023810	323095260	0	0
00:00:c0:01:01:04	7023810	323095260	0	0
00:00:c0:01:01:05	7023810	323095260	0	0
00:00:c0:01:01:06	7023810	323095260	0	0
00:00:c0:01:01:07	7023810	323095260	0	0
00:00:c0:01:01:08	7023809	323095214	0	0
00:00:c0:01:01:09	7023809	323095214	0	0
00:00:c0:01:01:0a	7023809	323095214	0	0
00:00:c0:01:01:0b	7023809	323095214	0	0
00:00:c8:01:01:02	31016568	1426762128	38040381	1749857526
00:00:c8:01:01:03	31016568	1426762128	38040382	1749857572
00:00:c8:01:01:04	31016499	1426758954	38040306	1749854076
00:00:c8:01:01:05	31016573	1426762358	38040381	1749857526
00:00:c8:01:01:06	31016573	1426762358	38040381	1749857526
00:00:c8:01:01:07	31016567	1426762082	38040380	1749857480
00:00:c8:01:01:08	31016567	1426762082	38040379	1749857434
00:00:c8:01:01:09	9428580	433714680	9428580	433714680
00:00:c8:01:01:0a	31016496	1426758816	38040304	1749853984
00:00:c8:01:01:0b	31016498	1426758908	38040307	1749854122

show interfaces  
mac-database  
mac-address

```

user@host> show interfaces mac-database xe-0/3/3 mac-address 00:00:c8:01:01:09
Physical interface: xe-0/3/3, Enabled, Physical link is Up
  Interface index: 372, SNMP ifIndex: 788
  Link-level type: Ethernet, MTU: 1514, LAN-PHY mode, Speed: 10Gbps, Loopback:
None, Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None

Logical interface xe-0/3/3.0 (Index 364) (SNMP ifIndex 829)
  Flags: SNMP-Traps 0x4004000 Encapsulation: ENET2
  MAC address: 00:00:c8:01:01:09, Type: Configured,
    Input bytes   : 202324652
    Output bytes  : 202324560
    Input frames  : 4398362
    Output frames : 4398360
  Policer statistics:
    Policer type   Discarded frames   Discarded bytes
    Output aggregate      3992386           183649756

```



## show interfaces mc-ae

<b>Syntax</b>	<b>show interfaces mc-ae id <i>identifier</i> unit <i>number</i></b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.6.
<b>Description</b>	On MX Series routers with multi-chassis aggregated Ethernet ( <b>mc-aeX</b> ) interfaces, use this command to display information about the <b>mc-aeX</b> interfaces.
<b>Options</b>	<p><b>identifier</b>—(Optional) Name of the multichassis aggregated Ethernet interface.</p> <p><b>number</b>—(Optional) Specify the logical interface by unit number.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Configuring Multichassis Link Aggregation</li> </ul>
<b>List of Sample Output</b>	<p><a href="#">show interfaces mc-ae on page 336</a></p> <p><a href="#">show interfaces mc-ae (Active/Active Bridging and VRRP over IRB on MX Series Routers) on page 336</a></p>
<b>Output Fields</b>	Table 46 on page 335 lists the output fields for the <b>show interfaces mc-ae</b> command. Output fields are listed in the approximate order in which they appear.

**Table 46: show interfaces mc-ae Output Fields**

Output Field Name	Field Description
<b>Member Links</b>	Identifiers of the configured multichassis link aggregate interfaces configured interfaces.
<b>Local Status</b>	Status of the local link: <b>active</b> or <b>standby</b> .
<b>Peer Status</b>	Status of the peer link: <b>active</b> or <b>standby</b> .
<b>Peer State</b>	<p>Status of the local and peer links in an <b>active/active</b> bridge or VRRP over integrated routing and bridging (IRB) configuration on MX Series routers, including:</p> <p>Logical Interface—Aggregated Ethernet (AE) aggregate number and unit number.</p> <p>Topology Type—The bridge or VRRP topology type configured on the AE.</p> <p>Local State—Up or down state of the local device.</p> <p>Peer State—Up or down state of the peer device.</p> <p>Peer Ip/ICL-PL/State—Address, interface and state of the peer device.</p>

Table 46: show interfaces mc-ae Output Fields (*continued*)

Output Field Name	Field Description
Logical Interface	Identifier and unit of the mc-ae interface.
Core Facing Interface	Label: pseudowire interface or Ethernet interface.
ICL-PL	Label: pseudowire interface or Ethernet interface.

## Sample Output

```
show interfaces mc-ae user@host> show interfaces mc-ae ae0 unit 512
Member Links      : ae0
Local Status      : active
Peer Status       : active
Logical Interface  : ae0.512
Core Facing Interface : Label Ethernet Interface
ICL-PL            : Label Ethernet Interface
```

```
show interfaces mc-ae (Active/Active Bridging and VRRP over IRB on MX Series Routers) user@host# show interfaces mc-ae ge-0/0/0.0
Member Link           : ae0
Current State Machine's State: active
Local Status          : active
Local State           : up
Peer Status           : active
Peer State            : up
Logical Interface     : ae0.0
Topology Type         : bridge
Local State           : up
Peer State            : up
Peer Ip/ICL-PL/State  : 192.168.100.10 ge-0/0/0.0 up
```

## show oam ethernet connectivity-fault-management delay-statistics

<b>Syntax</b>	<pre>show oam ethernet connectivity-fault-management delay-statistics &lt;count <i>entry-count</i>&gt; &lt;local-mep <i>local-mep-id</i>&gt; maintenance-association <i>ma-name</i> maintenance-domain <i>md-name</i> &lt;remote-mep <i>remote-mep-id</i>&gt;</pre>
<b>Release Information</b>	<p>Command introduced in Junos OS Release 9.5.</p> <p>Command introduced in Junos OS Release 11.4 for EX Series switches.</p>
<b>Description</b>	<p>On MX Series routers with Ethernet interfaces on Dense Port Concentrators (DPCs), display ETH-DM delay statistics.</p> <p>On EX Series switches, display delay measurement results.</p>
<b>Options</b>	<p><b>count <i>entry-count</i></b>—(Optional) Number of entries to display from the statistics table. The range of values is 1 through 100. The default value is 100 entries.</p> <p><b>local-mep <i>local-mep-id</i></b>—(Optional) Numeric identifier of the local MEP. On MX Series routers, the range of values is 1 through 8192. On EX Series switches, the range of values is 1 through 8191.</p> <p><b>maintenance-association <i>ma-name</i></b>—Name of an existing CFM maintenance association.</p> <p><b>maintenance-domain <i>md-name</i></b>—Name of an existing connectivity fault management (CFM) maintenance domain.</p> <p><b>remote-mep <i>remote-mep-id</i></b>—(Optional) Numeric identifier of the remote MEP. On MX Series routers, the range of values is 1 through 8192. On EX Series switches, the range of values is 1 through 8191.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">clear oam ethernet connectivity-fault-management statistics on page 168</a></li> <li>• <a href="#">clear oam ethernet connectivity-fault-management delay-statistics on page 164</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management interfaces on page 345</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-database on page 357</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-statistics on page 367</a></li> </ul>
<b>List of Sample Output</b>	<p><a href="#">show oam ethernet connectivity-fault-management delay-statistics on page 339</a></p> <p><a href="#">show oam ethernet connectivity-fault-management delay-statistics remote-mep on page 339</a></p>
<b>Output Fields</b>	<p>Table 47 on page 338 lists the output fields for the <b>show oam ethernet connectivity-fault-management delay-statistics</b> command and the <b>show oam ethernet</b></p>

**connectivity-fault-management mep-statistics** command. Output fields are listed in the approximate order in which they appear.

**Table 47: show oam ethernet connectivity-fault-management delay-statistics and mep-statistics Output Fields**

Output Field Name	Field Description
MEP identifier	Maintenance association end point (MEP) numeric identifier.
MAC address	Unicast MAC address configured for the MEP.
Remote MEP count	Number of remote MEPs (unless you specify the <b>remote-mep</b> option).
Remote MEP identifier	Numeric identifier of the remote MEP.
Remote MAC address	Unicast MAC address of the remote MEP.
Index	Index number that corresponds to the ETH-DM entry in the CFM database.
One-way delay (usec)	For a one-way ETH-DM session, the frame delay time, in microseconds, measured at the receiver MEP.  For a detailed description of one-way Ethernet frame delay measurement, see the <i>ITU-T Y.1731 Ethernet Service OAM</i> topics in the Junos® OS Network Interfaces.
Two-way delay (usec)	For a two-way ETH-DM session, the frame delay time, in microseconds, measured at the initiator MEP.  For a detailed description of two-way Ethernet frame delay measurement, see the <i>ITU-T Y.1731 Ethernet Service OAM</i> topics in the Junos® OS Network Interfaces.
Average one-way delay	Average one-way frame delay for the statistics displayed.
Average one-way delay variation	Average one-way “frame jitter” for the statistics displayed.
Best-case one-way delay	Lowest one-way frame delay for the statistics displayed.
Worst-case one-way delay	Highest one-way frame delay for the statistics displayed.
Average two-way delay	Average two-way frame delay for the statistics displayed.
Average two-way delay variation	Average two-way “frame jitter” for the statistics displayed.
Best-case two-way delay	Lowest two-way frame delay for the statistics displayed.
Worst-case two-way delay	Highest two-way frame delay calculated in this session.

## Sample Output

**show oam ethernet  
connectivity-fault-  
management  
delay-statistics**

```
user@switch> show oam ethernet connectivity-fault-management delay-statistics
maintenance-domain md6 maintenance-association ma6
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
Remote MEP count: 2
Remote MEP identifier: 101
Remote MAC address: 00:05:85:73:39:4a
Delay measurement statistics:
Index  One-way delay  Two-way delay
      (usec)      (usec)
  1      259        519
  2      273        550
  3      287        571
  4      299        610
  5      313        650
Average one-way delay      : 286 usec
Average one-way delay variation: 62 usec
Best case one-way delay    : 259 usec
Worst case one-way delay   : 313 usec
Average two-way delay      : 580 usec
Average two-way delay variation: 26 usec
Best case two-way delay    : 519 usec
Worst case two-way delay   : 650 usec

Remote MEP identifier: 102
Remote MAC address: 00:04:55:63:39:5a
Delay measurement statistics:
Index  One-way delay  Two-way delay
      (usec)      (usec)
  1      29         58
  2      23         59
  3      27         56
  4      29         62
  5      33         68
Average one-way delay      : 28 usec
Average one-way delay variation: 3 usec
Best case one-way delay    : 23 usec
Worst case one-way delay   : 33 usec
Average two-way delay      : 60 usec
Average two-way delay variation: 3 usec
Best case two-way delay    : 56 usec
Worst case two-way delay   : 68 usec
```

**show oam ethernet  
connectivity-fault-  
management  
delay-statistics  
remote-mep**

```
user@switch> show oam ethernet connectivity-fault-management delay-statistics
maintenance-domain md6 maintenance-association ma6 remote-mep 101
MEP identifier: 100, MAC address: 00:05:85:73:7b:39

Remote MEP identifier: 101
Remote MAC address: 00:05:85:73:39:4a
Delay measurement statistics:
Index  One-way delay  Two-way delay
      (usec)      (usec)
  1      259        519
  2      273        550
  3      287        571
  4      299        610
  5      313        650
Average one-way delay      : 286 usec
```

```
Average one-way delay variation: 62 usec
Best case one-way delay          : 259 usec
Worst case one-way delay         : 313 usec
Average two-way delay            : 580 usec
Average two-way delay variation: 26 usec
Best case two-way delay          : 519 usec
Worst case two-way delay         : 650 usec
```

## show oam ethernet connectivity-fault-management forwarding-state

<b>Syntax</b>	<b>show oam ethernet connectivity-fault-management forwarding-state</b> <b>interface</b> <i>interface-name</i>   <b>instance</b> <i>instance-name</i> <brief   detail   extensive>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	On M7i and M10i with the Enhanced CFEB (CFEB-E), M320, MX Series, T320, and T640 routers, display IEEE 802.1ag Operation, Administration, and Management (OAM) connectivity fault management forwarding state information for Ethernet interfaces.
<b>Options</b>	<p><b>interface</b> <i>interface-name</i>—Display forwarding state information for the specified Ethernet interface only.</p> <p><b>instance</b> <i>instance-name</i>—Display forwarding state information for the specified forwarding instance only.</p> <p><b>brief   detail   extensive</b>—(Optional) Display the specified level of output.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show oam ethernet connectivity-fault-management forwarding-state instance on page 343</a></p> <p><a href="#">show oam ethernet connectivity-fault-management forwarding-state interface on page 343</a></p> <p><a href="#">show oam ethernet connectivity-fault-management forwarding-state interface detail on page 343</a></p> <p><a href="#">show oam ethernet connectivity-fault-management forwarding-state interfaceinterface-name on page 344</a></p>
<b>Output Fields</b>	Table 48 on page 341 lists the output fields for the <b>show oam ethernet connectivity-fault-management forwarding-state</b> command. Output fields are listed in the approximate order in which they appear.

**Table 48: show oam ethernet connectivity-fault-management forwarding-state Output Fields**

Field Name	Field Description	Level of Output
<b>Interface name</b>	Interface identifier.	All levels
<b>Link (Status)</b>	Local link status.	All levels
<b>Filter action</b>	Filter action for messages at the level.	All levels
<b>Next hop type</b>	Next-hop type.	All levels
<b>Next index</b>	Next-hop index number.	brief
<b>Level</b>	Maintenance domain (MD) level.	detail

**Table 48: show oam ethernet connectivity-fault-management forwarding-state Output Fields (*continued*)**

Field Name	Field Description	Level of Output
<b>Direction</b>	MEP direction configured.	none
<b>Instance name</b>	Forwarding instance name.	All levels
<b>CEs</b>	Number of customer edge (CE) interfaces.	All levels
<b>VEs</b>	Number of VPN endpoint (VE) interfaces.	All levels



## Sample Output

**show oam ethernet  
connectivity-fault-  
management  
forwarding-  
state instance**

```
user@host> show oam ethernet connectivity-fault-management forwarding-state instance
Instance name: __+bd1__
CEs: 3
VEs: 0
Maintenance domain forwarding state:
```

Level	Direction	Filter action	Nexthop type	Nexthop index
0		Drop	none	
1		Drop	none	
2		Drop	none	
3		Drop	none	
4		Drop	none	
5		Drop	none	
6		Drop	none	
7		Drop	none	

**show oam ethernet  
connectivity-fault-  
management  
forwarding-  
state interface**

```
user@host> show oam ethernet connectivity-fault-management forwarding-state interface
Interface name: ge-3/0/0.0
Instance name: __+bd1__
Maintenance domain forwarding state:
```

Level	Direction	Filter action	Nexthop type	Nexthop index
0		Drop	none	
1		Drop	none	
2		Drop	none	
3		Drop	none	
4		Drop	none	
5		Drop	none	
6		Drop	none	
7	down	Receive	none	

```
Interface name: xe-0/0/0.0
Instance name: __+bd1__
Maintenance domain forwarding state:
```

Level	Direction	Filter action	Nexthop type	Nexthop index
0		Drop	none	
1		Drop	none	
2		Drop	none	
3		Drop	none	
4		Drop	none	
5		Drop	none	
6		Drop	none	
7	down	Receive	none	

**show oam ethernet  
connectivity-fault-  
management  
forwarding-  
state interface detail**

```
user@host> show oam ethernet connectivity-fault-management forwarding-state interface
detail
Interface name: ge-3/0/0.0
Instance name: __+bd1__

Level: 0
Filter action: Drop
Nexthop type: none
```

```

Level: 1
Filter action: Drop
Nexthop type: none

Level: 2
Filter action: Drop
Nexthop type: none

Level: 3
Filter action: Drop
Nexthop type: none

Level: 4
Filter action: Drop
Nexthop type: none

Level: 5
Filter action: Drop
Nexthop type: none

Level: 6
Filter action: Drop
Nexthop type: none

Level: 7
Direction: down
Filter action: Receive
Nexthop type: none

Interface name: xe-0/0/0.0
Instance name: __+bd1__

Level: 0
Filter action: Drop
Nexthop type: none

Level: 1
Filter action: Drop
Nexthop type: none

...

```

**show oam ethernet  
connectivity-fault-  
management  
forwarding-  
state interface  
interface-name**

```

user@host> show oam ethernet connectivity-fault-management forwarding-state interface
interface-name ge-3/0/0/0.0
Interface name: ge-3/0/0.0
Instance name: __+bd1__
Maintenance domain forwarding state:

```

Level	Direction	Filter action	Nexthop type	Nexthop index
0		Drop	none	
1		Drop	none	
2		Drop	none	
3		Drop	none	
4		Drop	none	
5		Drop	none	
6		Drop	none	
7	down	Receive	none	

## show oam ethernet connectivity-fault-management interfaces

<b>Syntax</b>	<pre>show oam ethernet connectivity-fault-management interfaces &lt;ethernet-interface-name&gt; &lt;level md-level&gt; &lt;brief   detail   extensive&gt;</pre>
<b>Release Information</b>	<p>Command introduced in Junos OS Release 8.4.</p> <p>Support for ITU-T Y.1731 frame delay measurement added in Junos OS Release 9.5.</p>
<b>Description</b>	<p>On M7i and M10i routers with Enhanced CFEB (CFEB-E), and on M320, MX Series, ACX Series, T320, and T640 routers, display IEEE 802.1ag Operation, Administration, and Management (OAM) connectivity fault management (CFM) database information for Ethernet interfaces.</p> <p>In addition, for Ethernet interfaces on MX Series routers, also display any ITU-T Y.1731 frame delay measurement (ETH-DM) frame counts when <b>detail</b> or <b>extensive</b> mode is specified.</p>
<b>Options</b>	<p><b>brief   detail   extensive</b>—(Optional) Specified level of output.</p> <p><b>ethernet-interface-name</b>—(Optional) CFM information only for CFM entities attached to the specified Ethernet interface.</p> <p><b>level md-level</b>—(Optional) CFM information for CFM identities enclosed within a maintenance domain of the specified level.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">clear oam ethernet connectivity-fault-management statistics on page 168</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management delay-statistics on page 337</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-database on page 357</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-statistics on page 367</a></li> </ul>
<b>List of Sample Output</b>	<p><a href="#">show oam ethernet connectivity-fault-management interfaces on page 350</a></p> <p><a href="#">show oam ethernet connectivity-fault-management interfaces detail on page 350</a></p> <p><a href="#">show oam ethernet connectivity-fault-management interfaces detail (One-Way ETH-DM) on page 351</a></p> <p><a href="#">show oam ethernet connectivity-fault-management interfaces detail (Connection Protection TLV Configured) on page 351</a></p> <p><a href="#">show oam ethernet connectivity-fault-management interfaces extensive on page 353</a></p> <p><a href="#">show oam ethernet connectivity-fault-management interfaces level on page 353</a></p> <p><a href="#">show oam ethernet connectivity-fault-management interfaces (trunk ports) on page 353</a></p>
<b>Output Fields</b>	<p>Table 49 on page 346 lists the output fields for the <b>show oam ethernet connectivity-fault-management interfaces</b> command. Output fields are listed in the approximate order in which they appear.</p>

Table 49: show oam ethernet connectivity-fault-management interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Interface</b>	Interface identifier.	All levels
<b>Interface status</b>	Local interface status.	All levels
<b>Link status</b>	Local link status. <b>Up</b> , <b>down</b> , or <b>oam-down</b> .	All levels
<b>Maintenance domain name</b>	Maintenance domain name.	<b>detail extensive</b>
<b>Format (Maintenance domain)</b>	Maintenance domain name format configured.	<b>detail extensive</b>
<b>Level</b>	Maintenance domain level configured.	All levels
<b>Maintenance association name</b>	Maintenance association name.	<b>detail extensive</b>
<b>Format (Maintenance association)</b>	Maintenance association name format configured.	<b>detail extensive</b>
<b>Continuity-check status</b>	Continuity-check status.	<b>detail extensive</b>
<b>Interval</b>	Continuity-check message interval.	<b>detail extensive</b>
<b>Loss-threshold</b>	Lost continuity-check message threshold.	<b>detail extensive</b>
<b>Interface status TLV</b>	Status of the interface status TLV, if configured on the MEP interface: <b>none</b> , <b>up</b> , <b>down</b> , <b>testing</b> , <b>unknown</b> , <b>dormant</b> , <b>notPresent</b> , <b>lowerLayerDown</b>	<b>detail extensive</b>
<b>Port status TLV</b>	Status of the port status TLV, if configured on the MEP interface: <b>none</b> , <b>no</b> , <b>yes</b>	<b>detail extensive</b>
<b>Connection Protection TLV</b>	Status of the connection protection TLV if configured on the MEP interface: <b>no</b> , <b>yes</b>  If <b>yes</b> , then the transmitted connection protection TLV is decoded and the following three fields are displayed: <b>Prefer me</b> , <b>Protection in use</b> , <b>FRR Flag</b>	<b>detail extensive</b>
<b>Prefer me</b>	If set to <b>yes</b> , the path through which CCM was transmitted is preferred (unless the path fails). It is used for signaling a manual-switch command to the remote side.  Its value can be <b>yes</b> or <b>no</b> .	<b>detail extensive</b>
<b>Protection in use</b>	Used for protection decision coordination. Its value is set to <b>yes</b> if the endpoint transmitting the CCM is currently transmitting the user traffic to protection path.  Its value can be <b>yes</b> or <b>no</b> .	<b>detail extensive</b>

**Table 49: show oam ethernet connectivity-fault-management interfaces Output Fields (*continued*)**

Field Name	Field Description	Level of Output
<b>FRR Flag</b>	LSR/LER forwarding the CCM Frame into a bypass tunnel is set.  Its value can be <b>yes</b> or <b>no</b> .	<b>detail extensive</b>
<b>MEP identifier</b>	Maintenance association end point (MEP) identifier.	All levels
<b>Neighbors</b>	Number of MEP neighbors.	All levels
<b>Direction</b>	MEP direction configured.	<b>detail extensive</b>
<b>MAC address</b>	MAC address configured for the MEP.	<b>detail extensive</b>
<b>MEP status</b>	Indicates the status of the connectivity fault management (CFM) protocol running on the MEP: <b>Running</b> , <b>inactive</b> , <b>disabled</b> , or <b>unsupported</b> .	<b>detail extensive</b>
<b>Remote MEP not receiving CCM</b>	Whether the remote MEP is not receiving connectivity check messages (CCMs).	<b>detail extensive</b>
<b>Erroneous CCM received</b>	Whether erroneous CCMs have been received.	<b>detail extensive</b>
<b>Cross-connect CCM received</b>	Whether cross-connect CCMs have been received.	<b>detail extensive</b>
<b>RDI sent by some MEP</b>	Whether the remote defect indication (RDI) bit is set in messages that have been received. The absence of the RDI bit in a CCM indicates that the transmitting MEP is receiving CCMs from all configured MEPs.	<b>detail extensive</b>
<b>CCMs sent</b>	Number of CCMs transmitted.	<b>detail extensive</b>
<b>CCMs received out of sequence</b>	Number of CCMs received out of sequence.	<b>detail extensive</b>
<b>LBMs sent</b>	Number of loopback request messages (LBMs) sent.	<b>detail extensive</b>
<b>Valid in-order LBRs received</b>	Number of loopback response messages (LBRs) received that were valid messages and in sequence.	<b>detail extensive</b>
<b>Valid out-of-order LBRs received</b>	Number of LBRs received that were valid messages and not in sequence.	<b>detail extensive</b>
<b>LBRs received with corrupted data</b>	Number of LBRs received that were corrupted.	<b>detail extensive</b>
<b>LBRs sent</b>	Number of LBRs transmitted.	<b>detail extensive</b>
<b>LTMs sent</b>	Linktrace messages (LTMs) transmitted.	<b>detail extensive</b>

**Table 49: show oam ethernet connectivity-fault-management interfaces Output Fields (*continued*)**

Field Name	Field Description	Level of Output
<b>LTMIs received</b>	Linktrace messages received.	<b>detail extensive</b>
<b>LTRs sent</b>	Linktrace responses (LTRs) transmitted.	<b>detail extensive</b>
<b>LTRs received</b>	Linktrace responses received.	<b>detail extensive</b>
<b>Sequence number of next LTM request</b>	Sequence number of next LTM request to be transmitted.	<b>detail extensive</b>
<b>1DMs sent</b>	<p>If the interface is attached to an initiator MEP for a one-way ETH-DM session: Number of one-way delay measurement (1DM) PDU frames sent to the peer MEP in this session.</p> <p>For all other cases, this field displays 0.</p>	<b>detail extensive</b>
<b>Valid 1DMs received</b>	<p>If the interface is attached to a receiver MEP for a one-way ETH-DM session: Number of valid 1DM frames received.</p> <p>For all other cases, this field displays 0.</p>	<b>detail extensive</b>
<b>Invalid 1DMs received</b>	<p>If the interface is attached to a receiver MEP for a one-way ETH-DM session: Number of invalid 1DM frames received.</p> <p>For all other cases, this field displays 0.</p>	<b>detail extensive</b>
<b>Out of sync 1DMs received</b>	<p>If the interface is attached to a receiver MEP for a one-way ETH-DM session: Number of out-of-sync one-way delay measurement request packets received.</p>	<b>detail extensive</b>
<b>DMMs sent</b>	<p>If the interface is attached to an initiator MEP for a two-way ETH-DM session: Number of Delay Measurement Message (DMM) PDU frames sent to the peer MEP in this session.</p> <p>For all other cases, this field displays 0.</p>	<b>detail extensive</b>
<b>Valid DMMs received</b>	<p>If the interface is attached to an initiator MEP for a two-way ETH-DM session: Number of valid two-way delay measurement request packets received.</p>	<b>detail extensive</b>
<b>Invalid DMMs received</b>	<p>If the interface is attached to an initiator MEP for a two-way ETH-DM session: Number of invalid two-way delay measurement request packets received.</p>	<b>detail extensive</b>
<b>DMRs sent</b>	<p>If the interface is attached to a responder MEP for a two-way ETH-DM session: Number of delay measurement reply (DMR) frames sent.</p> <p>For all other cases, this field displays 0.</p>	<b>detail extensive</b>
<b>Valid DMRs received</b>	<p>If the interface is attached to an initiator MEP for a two-way ETH-DM session: Number of valid DMRs received.</p> <p>For all other cases, this field displays 0.</p>	<b>detail extensive</b>

**Table 49: show oam ethernet connectivity-fault-management interfaces Output Fields (*continued*)**

Field Name	Field Description	Level of Output
<b>Invalid DMRs received</b>	If the interface is attached to an initiator MEP for a two-way ETH-DM session: Number of invalid DMRs received.  For all other cases, this field displays 0.	<b>detail extensive</b>
<b>LMM sent</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of loss measurement message (LMM) PDU frames sent to the peer MEP in this session.	<b>detail extensive</b>
<b>Valid LMM received</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of valid loss measurement request packets received.	<b>detail extensive</b>
<b>Invalid LMM received</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of invalid loss measurement request packets received.	<b>detail extensive</b>
<b>LMR sent</b>	If the interface is attached to a responder MEP for a ETH-LM session: Number of loss measurement reply (LMR) frames sent.	<b>detail extensive</b>
<b>Valid LMR received</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of valid LMR frames received.	<b>detail extensive</b>
<b>Invalid LMR received</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of invalid LMR frames received.	<b>detail extensive</b>
<b>Remote MEP count</b>	Number of remote MEPs.	<b>extensive</b>
<b>Identifier (remote MEP)</b>	MEP identifier of the remote MEP.	<b>extensive</b>
<b>MAC address (remote MEP)</b>	MAC address of the remote MEP.	<b>extensive</b>
<b>State (remote MEP)</b>	State of the remote MEP.	<b>extensive</b>
<b>Interface (remote MEP)</b>	Interface of the remote MEP.	<b>extensive</b>

## Sample Output

**show oam ethernet  
connectivity-fault-  
management  
interfaces**

```
user@host> show oam ethernet connectivity-fault-management interfaces
Interface      Link      Status      Level      MEP
               Identifier Neighbors
ge-1/1/0.0     Up        Active      0          2          1
ge-1/1/0.1     Up        Active      0          2          1
ge-1/1/0.10    Up        Active      0          2          1
ge-1/1/0.100   Up        Active      0          2          1
ge-1/1/0.101   Up        Active      0          2          1
ge-1/1/0.102   Up        Active      0          2          1
ge-1/1/0.103   Up        Active      0          2          1
ge-1/1/0.104   Up        Active      0          2          1
ge-1/1/0.105   Up        Active      0          2          1
ge-1/1/0.106   Up        Active      0          2          1
```

...

**show oam ethernet  
connectivity-fault-  
management  
interfaces detail**

```
user@host> show oam ethernet connectivity-fault-management interfaces detail
Interface name: ge-5/2/9.0, Interface status: Active, Link status: Up
Maintenance domain name: md0, Format: string, Level: 5
Maintenance association name: ma1, Format: string
Continuity-check status: enabled, Interval: 100ms, Loss-threshold: 3 frames
MEP identifier: 1, Direction: down, MAC address: 00:90:69:0b:4b:94
MEP status: running
Defects:
  Remote MEP not receiving CCM          : no
  Erroneous CCM received                 : yes
  Cross-connect CCM received            : no
  RDI sent by some MEP                  : yes
Statistics:
  CCMs sent                             : 76
  CCMs received out of sequence          : 0
  LBMs sent                             : 0
  Valid in-order LBRs received           : 0
  Valid out-of-order LBRs received       : 0
  LBRs received with corrupted data      : 0
  LBRs sent                             : 0
  LTMs sent                             : 0
  LTMs received                         : 0
  LTRs sent                             : 0
  LTRs received                         : 0
  Sequence number of next LTM request    : 0
  1DMs sent                             : 0
  Valid 1DMs received                   : 0
  Invalid 1DMs received                  : 0
  DMMs sent                             : 0
  DMRs sent                             : 0
  Valid DMRs received                   : 0
  Invalid DMRs received                  : 0
  LMM sent                              : 10
  Valid LMM received                    : 20
  Invalid LMM received                   : 0
  LMR sent                              : 20
  Valid LMR received                    : 10
  Invalid LMR received                   : 0
Remote MEP count: 2
Identifier      MAC address      State      Interface
2001           00:90:69:0b:7f:71    ok         ge-5/2/9.0
```



4001 00:90:69:0b:09:c5 ok ge-5/2/9.0

**show oam ethernet  
connectivity-fault-  
management  
interfaces detail  
(One-Way ETH-DM)**

```
user@host show oam ethernet connectivity-fault-management interfaces detail
Interface name: ge-0/2/5.0, Interface status: Active, Link status: Up
Maintenance domain name: md6, Format: string, Level: 6
Maintenance association name: ma6, Format: string
Continuity-check status: enabled, Interval: 100ms, Loss-threshold: 3 frames
MEP identifier: 101, Direction: down, MAC address: 00:90:69:0a:48:57
MEP status: running
Defects:
  Remote MEP not receiving CCM                : no
  Erroneous CCM received                      : no
  Cross-connect CCM received                  : no
  RDI sent by some MEP                       : no
Statistics:
  CCMs sent                                  : 1590
  CCMs received out of sequence              : 0
  LBMs sent                                  : 0
  Valid in-order LBRs received               : 0
  Valid out-of-order LBRs received           : 0
  LBRs received with corrupted data          : 0
  LBRs sent                                  : 0
  LTMs sent                                  : 0
  LTMs received                              : 0
  LTRs sent                                  : 0
  LTRs received                              : 0
  Sequence number of next LTM request        : 0
  1DMs sent                                  : 10
  Valid 1DMs received                       : 0
  Invalid 1DMs received                     : 0
  DMMs sent                                  : 0
  DMRs sent                                  : 0
  Valid DMRs received                      : 0
  Invalid DMRs received                    : 0
Remote MEP count: 1
  Identifier  MAC address      State  Interface
  201        00:90:69:0a:43:94 ok     ge-0/2/5.0
```

**show oam ethernet  
connectivity-fault-  
management  
interfaces detail  
(Connection  
Protection TLV  
Configured)**

```
user@host show oam ethernet connectivity-fault-management interfaces detail
Interface name: xe-6/2/0.0 , Interface status: Active, Link status: Up
Maintenance domain name: md6, Format: string, Level: 6
Maintenance association name: ma6, Format: string
Continuity-check status: enabled, Interval: 1s, Loss-threshold: 3 frames
Interface status TLV: none, Port status TLV: none
Connection Protection TLV: yes
  Prefer me: no, Protection in use: no, FRR Flag: no
MEP identifier: 1, Direction: down, MAC address: 00:19:e2:b1:14:30
MEP status: running
Defects:
  Remote MEP not receiving CCM                : no
  Erroneous CCM received                      : no
  Cross-connect CCM received                  : no
  RDI sent by some MEP                       : no
  Some remote MEP's MAC in error state        : no
Statistics:
  CCMs sent                                  : 225
  CCMs received out of sequence              : 0
  LBMs sent                                  : 0
  Valid in-order LBRs received               : 0
```

```

Valid out-of-order LBRs received           : 0
LBRs received with corrupted data          : 0
LBRs sent                                  : 0
LTMs sent                                  : 0
LTMs received                              : 0
LTRs sent                                  : 0
LTRs received                              : 0
Sequence number of next LTM request        : 0
1DMs sent                                  : 0
Valid 1DMs received                        : 0
Invalid 1DMs received                      : 0
Out of sync 1DMs received                  : 0
DMMs sent                                  : 0
Valid DMMs received                       : 0
Invalid DMMs received                     : 0
DMRs sent                                  : 0
Valid DMRs received                       : 0
Invalid DMRs received                     : 0
LMMs sent                                  : 0
Valid LMMs received                       : 0
Invalid LMMs received                     : 0
LMRs sent                                  : 0
Valid LMRs received                       : 0
Invalid LMRs received                     : 0
Remote MEP count: 1
  Identifier  MAC address  State  Interface
    2        00:90:69:7f:e4:30

```

**show oam ethernet  
connectivity-fault-  
management  
interfaces  
extensive**

```

user@host> show oam ethernet connectivity-fault-management interfaces extensive
Interface name: ge-5/2/9.0, Interface status: Active, Link status: Up
Maintenance domain name: md0, Format: string, Level: 5
Maintenance association name: ma1, Format: string
Continuity-check status: enabled, Interval: 100ms, Loss-threshold: 3 frames
Interface status TLV: none, Port status TLV: none
Connection Protection TLV: no
MEP identifier: 1, Direction: down, MAC address: 00:90:69:0b:4b:94
MEP status: running
Defects:
  Remote MEP not receiving CCM                : no
  Erroneous CCM received                      : yes
  Cross-connect CCM received                  : no
  RDI sent by some MEP                       : yes
Statistics:
  CCMs sent                                  : 76
  CCMs received out of sequence              : 0
  LBMs sent                                  : 0
  Valid in-order LBRs received               : 0
  Valid out-of-order LBRs received          : 0
  LBRs received with corrupted data         : 0
  LBRs sent                                  : 0
  LTMs sent                                  : 0
  LTMs received                             : 0
  LTRs sent                                  : 0
  LTRs received                             : 0
  Sequence number of next LTM request       : 0
  1DMs sent                                  : 0
  Valid 1DMs received                       : 0
  Invalid 1DMs received                     : 0
  DMMs sent                                  : 0
  DMRs sent                                  : 0
  Valid DMRs received                      : 0
  Invalid DMRs received                    : 0
Remote MEP count: 2
Identifier  MAC address      State  Interface
2001      00:90:69:0b:7f:71  ok    ge-5/2/9.0
4001      00:90:69:0b:09:c5  ok    ge-5/2/9.0

```

**show oam ethernet  
connectivity-fault-  
management  
interfaces level**

```

user@host> show oam ethernet connectivity-fault-management interfaces level 7
Interface  Link      Status      Level  MEP      Neighbors
Identifier
ge-3/0/0.0  Up        Active      7      201      0
xe-0/0/0.0  Up        Active      7      203      1

```

**show oam ethernet  
connectivity-fault-  
management  
interfaces (trunk  
ports)**

```

user@host> show oam ethernet connectivity-fault-management interfaces

Interface                Link      Status      Level  MEP      Neighbors
Identifier
ge-4/0/1.0, v1an 100     Up        Active      5      100      0
ge-10/3/10.4091, v1an 4091 Down      Inactive    4      400      0
ge-4/0/0.0               Up        Active      6      200      0

user@host> show oam ethernet connectivity-fault-management interfaces ge-4/0/0.0

Interface                Link      Status      Level  MEP      Neighbors
Identifier

```

ge-4/0/0.0	Up	Active	6	200	0
------------	----	--------	---	-----	---

user@host> show oam ethernet connectivity-fault-management interfaces ge-4/0/1.0 vlan 100

Interface	Link	Status	Level	MEP Identifier	Neighbors
ge-4/0/1.0, vlan 100	Up	Active	5	100	0

user@host> show oam ethernet connectivity-fault-management interfaces ge-10/3/10.4091  
vlan 4091

Interface	Link	Status	Level	MEP Identifier	Neighbors
ge-10/3/10.4091, vlan 4091	Down	Inactive	4	400	0

## show oam ethernet connectivity-fault-management linktrace path-database

<b>Syntax</b>	<b>show oam ethernet connectivity-fault-management linktrace path-database mac-address maintenance-association <i>ma-name</i> maintenance-domain <i>md-name</i></b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.0.
<b>Description</b>	On M320, MX Series, T320, and T640 routers, display IEEE 802.1ag Operation, Administration, and Management (OAM) connectivity fault management maintenance linktrace database information.
<b>Options</b>	<p><b>mac-address</b>—Display connectivity fault management path database information for the specified MAC address of the remote host.</p> <p><b>maintenance-association <i>ma-name</i></b>—Display connectivity fault management path database information for the specified maintenance association.</p> <p><b>maintenance-domain <i>md-name</i></b>—Display connectivity fault management path database information for the specified maintenance domain.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show oam ethernet connectivity-fault-management linktrace path-database on page 356</a></p> <p><a href="#">show oam ethernet connectivity-fault-management linktrace path-database (Two traceroute Commands) on page 356</a></p>
<b>Output Fields</b>	Table 50 on page 355 lists the output fields for the <b>show oam ethernet connectivity-fault-management linktrace path-database</b> command. Output fields are listed in the approximate order in which they appear.

**Table 50: show oam ethernet connectivity-fault-management linktrace path-database Output Fields**

Field Name	Field Description
<b>Linktrace to</b>	MAC address of the 802.1ag node to which the linktrace message is targeted.
<b>Interface</b>	Interface used by the local MEP to send the linktrace message (LTM).
<b>Maintenance Domain</b>	Maintenance domain identifier specified in the traceroute command.
<b>Maintenance Association</b>	Maintenance association identifier specified in the traceroute command.
<b>Level</b>	Maintenance domain level configured for the maintenance domain.
<b>Local Mep</b>	MEP identifier of the local MEP originating the linktrace.
<b>Hop</b>	Sequential hop count of the linktrace path.

Table 50: show oam ethernet connectivity-fault-management linktrace path-database Output Fields (*continued*)

Field Name	Field Description
TTL	Number of hops remaining in the linktrace message (LTM). The time to live (TTL) is decremented at each hop.
Source MAC address	MAC address of the 802.1ag maintenance intermediate point (MIP) that is forwarding the LTM.
Next hop MAC address	MAC address of the 802.1ag node that is the next hop in the LTM path.
Transaction Identifier	4-byte identifier maintained by the MEP. Each LTM uses a transaction identifier. The transaction identifier is maintained globally across all maintenance domains. Use the transaction identifier to match an incoming linktrace responses (LTR), with a previously sent LTM.

## Sample Output

**show oam ethernet connectivity-fault-management linktrace path-database**

```
user@host> show oam ethernet connectivity-fault-management linktrace path-database
maintenance-domain MD1 maintenance-association MA1 00:01:02:03:04:05
Linktrace to 00:01:02:03:04:05, Interface : ge-5/0/0.0
Maintenance Domain: MD1, Level: 7
Maintenance Association: MA1, Local Mep: 1
```

Hop	TTL	Source MAC address	Next hop MAC address
Transaction Identifier:100001			
1	63	00:00:aa:aa:aa:aa	00:00:bb:bb:bb:bb
2	62	00:00:bb:bb:bb:bb	00:00:cc:cc:cc:cc
3	61	00:00:cc:cc:cc:cc	00:01:02:03:04:05
4	60	00:01:02:03:04:05	00:00:00:00:00:00

**show oam ethernet connectivity-fault-management linktrace path-database (Two traceroute Commands)**

```
user@host> show oam ethernet connectivity-fault-management linktrace path-database
maintenance-domain MD2 maintenance-association MA2 00:06:07:08:09:0A
Linktrace to 00:06:07:08:09:0A, Interface : ge-5/0/1.0
Maintenance Domain: MD2, Level: 6
Maintenance Association: MA2, Local Mep: 10
```

Hop	TTL	Source MAC address	Next hop MAC address
Transaction Identifier:100002			
1	63	00:00:aa:aa:aa:aa	00:00:bb:bb:bb:bb
2	62	00:00:bb:bb:bb:bb	00:00:cc:cc:cc:cc
3	61	00:00:cc:cc:cc:cc	00:06:07:08:09:0A
4	60	00:06:07:08:09:0A	00:00:00:00:00:00
Transaction Identifier:100003			
1	63	00:00:aa:aa:aa:aa	00:00:bb:bb:bb:bb
2	62	00:00:bb:bb:bb:bb	00:00:cc:cc:cc:cc
3	61	00:00:cc:cc:cc:cc	00:06:07:08:09:0A
4	60	00:06:07:08:09:0A	00:00:00:00:00:00

## show oam ethernet connectivity-fault-management mep-database

<b>Syntax</b>	<pre>show oam ethernet connectivity-fault-management mep-database maintenance-domain <i>domain-name</i> maintenance-association <i>ma-name</i> &lt;local-mep <i>local-mep-id</i>&gt; &lt;remote-mep <i>remote-mep-id</i>&gt;</pre>
<b>Release Information</b>	<p>Command introduced in Junos OS Release 8.4.</p> <p>Support for ITU-T Y.1731 frame delay measurement added in Junos OS Release 9.5.</p>
<b>Description</b>	<p>On M7i and M10i routers with Enhanced CFEB (CFEB-E), and on M320, M120, MX Series, ACX Series, T320, and T640 routers, display IEEE 802.1ag Operation, Administration, and Management (OAM) connectivity fault management (CFM) database information for CFM maintenance association end points (MEPs) in a CFM session.</p> <p>In addition, on M120, M320, and MX series routers, also display port status TLV, interface status TLV, and action profile information.</p> <p>In addition, for Ethernet interfaces on MX Series routers, also display any ITU-T Y.1731 frame delay measurement (ETH-DM) frame counts.</p>
<b>Options</b>	<p><b>maintenance-association <i>ma-name</i></b>—Name of the maintenance association.</p> <p><b>maintenance-domain <i>domain-name</i></b>—Name of the maintenance domain.</p> <p><b><i>local-mep-id</i></b>—(Optional) Numeric identifier of local MEP.</p> <p><b><i>remote-mep-id</i></b>—(Optional) Numeric identifier of the remote MEP.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">clear oam ethernet connectivity-fault-management statistics on page 168</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management delay-statistics on page 337</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management interfaces on page 345</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-statistics on page 367</a></li> </ul>
<b>List of Sample Output</b>	<p><a href="#">show oam ethernet connectivity-fault-management mep-database on page 363</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-database (One-Way ETH-DM) on page 363</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-database local-mep remote-mep on page 364</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-database remote-mep (Action Profile Event) on page 364</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-database (Connection Protection TLV Configured) on page 364</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-database on page 365</a></p>

[show oam ethernet connectivity-fault-management mep-database \(enhanced continuity measurement\) on page 366](#)

**Output Fields** [Table 51 on page 358](#) lists the output fields for the **show oam ethernet connectivity-fault-management mep-database** command. Output fields are listed in the approximate order in which they appear.

**Table 51: show oam ethernet connectivity-fault-management mep-database Output Fields**

Field Name	Field Description
Maintenance domain name	Maintenance domain name.
Format (Maintenance domain)	Maintenance domain name format configured.
Level	Maintenance domain level configured.
Maintenance association name	Maintenance association name.
Format (Maintenance association)	Maintenance association name format configured.
Continuity-check status	Continuity-check status.
Interval	Continuity-check message interval.
Loss-threshold	Lost continuity-check message threshold.
Connection Protection TLV	Status of the connection protection TLV, if configured on the MEP interface: <b>no</b> , <b>yes</b>  If <b>yes</b> , then the transmitted connection protection TLV is decoded and the following three fields are displayed: <b>Prefer me</b> , <b>Protection in use</b> , <b>FRR Flag</b>
Prefer me	If set to <b>yes</b> , the path through which CCM was transmitted is preferred (unless the path fails). It is used for signaling a manual-switch command to remote side.  Its value can be <b>yes</b> or <b>no</b> .
Protection in use	Used for protection decision coordination. Its value is set to <b>yes</b> if the endpoint transmitting the CCM is currently transmitting the user traffic to protection path.  Its value can be <b>yes</b> or <b>no</b> .
FRR Flag	LSR/LER forwarding the CCM Frame into a bypass tunnel is set.  Its value can be <b>yes</b> or <b>no</b> .
MEP identifier	Maintenance association end point (MEP) identifier.
Direction	MEP direction configured.



**Table 51: show oam ethernet connectivity-fault-management mep-database Output Fields (*continued*)**

Field Name	Field Description
<b>MAC address</b>	MAC address configured for the MEP.
<b>Auto-discovery</b>	Whether automatic discovery is enabled or disabled.
<b>Priority</b>	Priority used for CCMs and linktrace messages transmitted by the MEP.
<b>Interface name</b>	Interface identifier.
<b>Interface status</b>	Local interface status.
<b>Link status</b>	Local link status.
<b>Remote MEP not receiving CCM</b>	Whether the remote MEP is not receiving CCMs.
<b>Erroneous CCM received</b>	Whether erroneous CCMs have been received.
<b>Cross-connect CCM received</b>	Whether cross-connect CCMs have been received.
<b>RDI sent by some MEP</b>	Whether the remote defect indication (RDI) bit is set in messages that have been received. The absence of the RDI bit in a CCM indicates that the transmitting MEP is receiving CCMs from all configured MEPs.
<b>CCMs sent</b>	Number of CCMs transmitted.
<b>CCMs received out of sequence</b>	Number of CCMs received out of sequence.
<b>LBMs sent</b>	Number of loopback messages (LBMs) sent.
<b>Valid in-order LBRs received</b>	Number of loopback response messages (LBRs) received that were valid messages and in sequence.
<b>1DMs sent</b>	If the MEP is an initiator for a one-way ETH-DM session: Number of one-way delay measurement (1DM) PDU frames sent to the peer MEP in this session.  For all other cases, this field displays 0.
<b>Valid 1DMs received</b>	If the MEP is a receiver for a one-way ETH-DM session: Number of valid 1DM frames received.  For all other cases, this field displays 0.
<b>Invalid 1DMs received</b>	If the MEP is a receiver for a one-way ETH-DM session: Number of invalid 1DM frames received.  For all other cases, this field displays 0.

Table 51: show oam ethernet connectivity-fault-management mep-database Output Fields (*continued*)

Field Name	Field Description
<b>Out of sync 1DMs received</b>	If the MEP is a receiver for a one-way ETH-DM session: Number of out-of-sync one-way delay measurement request packets received.
<b>DMMs sent</b>	If the MEP is an initiator for a two-way ETH-DM session: Number of Delay Measurement Message (DMM) PDU frames sent to the peer MEP in this session.  For all other cases, this field displays 0.
<b>Valid DMMs received</b>	If the MEP is an initiator for a two-way ETH-DM session: Number of valid two-way delay measurement packets received.
<b>Invalid DMMs received</b>	If the MEP is an initiator for a two-way ETH-DM session: Number of invalid two-way delay measurement packets received.
<b>DMRs sent</b>	If the MEP is a responder for a ETH-DM session: Number of Delay Measurement Reply (DMR) frames sent.  For all other cases, this field displays 0.
<b>Valid DMRs received</b>	If the MEP is an initiator for a two-way ETH-DM session: Number of valid DMRs received.  For all other cases, this field displays 0.
<b>Invalid DMRs received</b>	If the MEP is an initiator for a two-way ETH-DM session: Number of invalid DMRs received.  For all other cases, this field displays 0.
<b>Valid out-of-order LBRs received</b>	Number of LBRs received that were valid messages and not in sequence.
<b>LBRs received with corrupted data</b>	Number of LBRs received that were corrupted.
<b>LBRs sent</b>	Number of LBRs transmitted.
<b>LTMs sent</b>	Linktrace messages (LTMs) transmitted.
<b>LTMs received</b>	Linktrace messages received.
<b>LTRs sent</b>	Linktrace responses (LTRs) transmitted.
<b>LTRs received</b>	Linktrace responses received.
<b>Sequence number of next LTM request</b>	Sequence number of the next linktrace message request to be transmitted.
<b>LMM sent</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of loss measurement message (LMM) PDU frames sent to the peer MEP in this session.

**Table 51: show oam ethernet connectivity-fault-management mep-database Output Fields (*continued*)**

Field Name	Field Description
<b>Valid LMM received</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of valid loss measurement request packets received.
<b>Invalid LMM received</b>	If the interface is attached to an initiator MEP for a ETH LM session: Number of invalid loss measurement request packets received.
<b>LMR sent</b>	If the interface is attached to a responder MEP for a ETH-LM session: Number of loss measurement reply (LMR) frames sent.
<b>Valid LMR received</b>	If the interface is attached to an initiator MEP for a ETH LM session: Number of valid LMR frames received.
<b>Invalid LMR received</b>	If the interface is attached to an initiator MEP for a ETH-LM session: Number of invalid LMR frames received.
<b>Remote MEP identifier</b>	MEP identifier of the remote MEP.
<b>State (remote MEP)</b>	State of the remote MEP: <b>idle</b> , <b>start</b> , <b>ok</b> , or <b>failed</b> .
<b>MAC address</b>	MAC address of the remote MEP.
<b>Type</b>	Whether the remote MEP MAC address was learned using automatic discovery or configured.
<b>Interface</b>	Interface of the remote MEP. A seven-digit number is appended if CFM is configured to run on a routing instance of type VPLS.
<b>Last flapped</b>	Date, time, and how long ago the remote MEP interface went from down to up. The format is <b>Last flapped: year-month-day hours:minutes:seconds timezone (hours:minutes:seconds ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .
<b>Remote defect indication</b>	Whether the remote defect indication (RDI) bit is set in messages that have been received or transmitted.
<b>Port status TLV</b>	<ul style="list-style-type: none"> <li>In the Maintenance domain section, displays the last transmitted port status TLV value.</li> <li>In the Remote MEP section, displays the last value of port status TLV received from the remote MEP.</li> </ul> <p>In the Action profile section, displays, the last occurred event <b>port-status-tlv blocked</b> event. This event occurred due to the reception of <b>blocked</b> value in the port status TLV from remote MEP.</p>
<b>Interface status TLV</b>	<ul style="list-style-type: none"> <li>In the Maintenance domain section, displays the last transmitted interface status TLV value.</li> <li>In the Remote MEP section, displays the last value of interface status TLV received from the remote MEP.</li> </ul> <p>In the Action profile section, if displays, the last occurred event interface-status-tlv event ( either <b>lower-layer-down</b> or <b>down</b>). This event occurred due to the reception of either lower or <b>down</b> value in the interface status TLV from remote MEP.</p>
<b>Action profile</b>	Name of the action profile occurrence associated with a remote MEP.

**Table 51: show oam ethernet connectivity-fault-management mep-database Output Fields (*continued*)**

Field Name	Field Description
<b>Last event</b>	When an action profile occurs, displays the last event that triggered it.
<b>Last event cleared</b>	When all the configured and occurred events (under action profile) are cleared, then the action taken gets reverted (such as down interface is made up) and the corresponding time is noted and displayed.
<b>Action</b>	Action taken and the corresponding time of the action occurrence.

---

## Sample Output

**show oam ethernet  
connectivity-fault-  
management  
mep-database**

```
user@host> show oam ethernet connectivity-fault-management mep-database
maintenance-domain vpls-vlan2000 maintenance-association vpls-vlan200
Maintenance domain name: vpls-vlan2000, Format: string, Level: 5
Maintenance association name: vpls-vlan200, Format: string
Continuity-check status: enabled, Interval: 100ms, Loss-threshold: 3 frames
MEP identifier: 200, Direction: up, MAC address: 00:19:e2:b0:74:01
Auto-discovery: enabled, Priority: 0
Interface status TLV: none, Port status TLV: none
Connection Protection TLV: no Interface name: ge-0/0/1.0, Interface status:
Active, Link status: Up
Defects:
  Remote MEP not receiving CCM                : no
  Erroneous CCM received                      : no
  Cross-connect CCM received                  : no
  RDI sent by some MEP                       : no
Statistics:
  CCMs sent                                  : 1476
  CCMs received out of sequence              : 0
  LBMs sent                                  : 85
  Valid in-order LBRs received                : 78
  Valid out-of-order LBRs received           : 0
  LBRs received with corrupted data          : 0
  LBRs sent                                  : 0
  LTMs sent                                  : 1
  LTMs received                              : 0
  LTRs sent                                  : 0
  LTRs received                              : 1
  Sequence number of next LTM request        : 1
  1DMs sent                                  : 0
  Valid 1DMs received                        : 0
  Invalid 1DMs received                      : 0
  DMMs sent                                  : 0
  DMRs sent                                  : 0
  Valid DMRs received                        : 0
  Invalid DMRs received                      : 0
Remote MEP count: 1
Identifier  MAC address      State  Interface
100        00:19:e2:b2:81:4b  ok    vt-0/1/10.1049088
```

**show oam ethernet  
connectivity-fault-  
management  
mep-database  
(One-Way ETH-DM)**

```
user@host> show oam ethernet connectivity-fault-management mep-database
maintenance-domain md6 maintenance-domain ma6
Maintenance domain name: md6, Format: string, Level: 6
Maintenance association name: ma6, Format: string
Continuity-check status: enabled, Interval: 100ms, Loss-threshold: 3 frames
MEP identifier: 101, Direction: down, MAC address: 00:90:69:0a:48:57
Auto-discovery: enabled, Priority: 0
Interface name: ge-0/2/5.0, Interface status: Active, Link status: Up
Defects:
  Remote MEP not receiving CCM                : no
  Erroneous CCM received                      : no
  Cross-connect CCM received                  : no
  RDI sent by some MEP                       : no
Statistics:
  CCMs sent                                  : 1590
  CCMs received out of sequence              : 0
  LBMs sent                                  : 0
  Valid in-order LBRs received                : 0
```

```

Valid out-of-order LBRs received          : 0
LBRs received with corrupted data        : 0
LBRs sent                                : 0
LTMs sent                                : 0
LTMs received                             : 0
LTRs sent                                : 0
LTRs received                             : 0
Sequence number of next LTM request      : 0
1DMs sent                                 : 10
Valid 1DMs received                       : 0
Invalid 1DMs received                     : 0
DMMs sent                                 : 0
DMRs sent                                 : 0
Valid DMRs received                       : 0
Invalid DMRs received                     : 0
Remote MEP count: 1
Identifier  MAC address  State  Interface
  201      00:90:69:0a:43:94    ok    ge-0/2/5.0

```

**show oam ethernet  
connectivity-fault-  
management  
mep-database  
local-mep remote-mep**

```

user@host> show oam ethernet connectivity-fault-management mep-database
maintenance-domain vpls-vlan2000 maintenance-association vpls-vlan200 local-mep 200
remote-mep 100

```

```

Maintenance domain name: vpls-vlan2000, Format: string, Level: 5
Maintenance association name: vpls-vlan200, Format: string
Continuity-check status: enabled, Interval: 100ms, Loss-threshold: 3 frames
MEP identifier: 200, Direction: up, MAC address: 00:19:e2:b0:74:01
Auto-discovery: enabled, Priority: 0
Interface name: ge-0/0/1.0, Interface status: Active, Link status: Up

```

```

Remote MEP identifier: 100, State: ok
MAC address: 00:19:e2:b2:81:4b, Type: Learned
Interface: vt-0/1/10.1049088
Last flapped: Never
Remote defect indication: false
Port status TLV: none
Interface status TLV: none

```

**show oam ethernet  
connectivity-fault-  
management  
mep-database  
remote-mep  
(Action Profile Event)**

```

user@host> show oam ethernet connectivity-fault-management mep-database
maintenance-domain md5 maintenance-association ma5 remote-mep 200
Maintenance domain name: md5, Format: string, Level: 5
Maintenance association name: ma5, Format: string
Continuity-check status: enabled, Interval: 1s, Loss-threshold: 3 frames
MEP identifier: 100, Direction: down, MAC address: 00:05:85:73:e8:ad
Auto-discovery: enabled, Priority: 0
Interface status TLV: none, Port status TLV: none
Interface name: ge-1/0/8.0, Interface status: Active, Link status: Up

```

```

Remote MEP identifier: 200, State: ok
MAC address: 00:05:85:73:96:1f, Type: Configured
Interface: ge-1/0/8.0
Last flapped: Never
Remote defect indication: false
Port status TLV: none
Interface status TLV: lower-layer-down
Action profile: juniper
  Last event: Interface-status-tlv lower-layer-down
  Action: Interface-down, Time: 2009-03-27 14:25:10 PDT (00:00:02 ago)

```

```

user@host> show oam ethernet connectivity-fault-management mep-database

```

show oam ethernet  
connectivity-fault-  
management  
mep-database  
(Connection  
Protection TLV  
Configured)

#### **maintenance-domain md5 maintenance-association ma5**

If connection-protection is not enabled on down MEPs, but connection-protection TLV is used, MX always sets the protection-in-use flag in connection-protection tlv, while CCMs are sent out. During reversion, this is an indicator to the receiver that protect-path is in use, otherwise the peer (receiver) assumes working is active and reversion does not work as expected. Setting this bit does not affect protection-switching/traffic-loss.

```
Maintenance domain name: md5, Format: string, Level: 5
Maintenance association name: ma5, Format: string
Continuity-check status: enabled, Interval: 1s, Loss-threshold: 3 frames
MEP identifier: 1, Direction: down, MAC address: 00:19:e2:b1:14:30
Auto-discovery: enabled, Priority: 0
Interface status TLV: none, Port status TLV: none
Connection Protection TLV: yes
  Prefer me: no, Protection in use: no, FRR Flag: no
Interface name: xe-6/2/0.0, Interface status: Active, Link status: Up
Defects:
  Remote MEP not receiving CCM                : no
  Erroneous CCM received                      : no
  Cross-connect CCM received                  : no
  RDI sent by some MEP                       : no
  Some remote MEP's MAC in error state        : no
Statistics:
  CCMs sent                                  : 251
  CCMs received out of sequence              : 0
  LBMs sent                                  : 0
  Valid in-order LBRs received               : 0
  Valid out-of-order LBRs received           : 0
  LBRs received with corrupted data          : 0
  LBRs sent                                  : 0
  LTMs sent                                  : 0
  LTMs received                             : 0
  LTRs sent                                  : 0
  LTRs received                             : 0
  Sequence number of next LTM request        : 0
  1DMs sent                                  : 0
  Valid 1DMs received                       : 0
  Invalid 1DMs received                     : 0
  Out of sync 1DMs received                 : 0
  DMMs sent                                  : 0
  Valid DMMs received                      : 0
  Invalid DMMs received                    : 0
  DMRs sent                                  : 0
  Valid DMRs received                     : 0
  Invalid DMRs received                    : 0
  LMMs sent                                  : 0
  Valid LMMs received                      : 0
  Invalid LMMs received                    : 0
  LMRs sent                                  : 0
  Valid LMRs received                     : 0
  Invalid LMRs received                    : 0
Remote MEP count: 1
Identifier    MAC address    State    Interface
  2          00:90:69:7f:e4:30
```

show oam ethernet  
connectivity-fault-  
management  
mep-database

#### **user@host> show oam ethernet connectivity-fault-management mep-database maintenance-domain md5 maintenance-association ma5**

```
Maintenance association name: ma1, Format: string
Continuity-check status: enabled, Interval: 1s, Loss-threshold: 3 frames
MEP identifier: 1, Direction: down, MAC address: 00:14:f6:b6:01:fe
```

Auto-discovery: enabled, Priority: 0  
 Interface name: ge-1/0/0.0, Interface status: Active, Link status: Up

Defects:

Remote MEP not receiving CCM : no  
 Erroneous CCM received : no  
 Cross-connect CCM received : no  
 RDI sent by some MEP : no

Statistics:

CCMs sent : 328703  
 CCMs received out of sequence : 0  
 LBMs sent : 85  
 Valid in-order LBRs received : 78  
 Valid out-of-order LBRs received : 0  
 LBRs received with corrupted data : 0  
 LBRs sent : 0  
 LTMs sent : 0  
 LTMs received : 0  
 LTRs sent : 0  
 LTRs received : 0  
 Sequence number of next LTM request : 0  
 1DMs sent : 10  
 Valid 1DMs received : 10  
 Invalid 1DMs received : 0  
 DMMs sent : 20  
 DMRs sent : 0  
 Valid DMRs received : 10  
 Invalid DMRs received : 0  
 LMM sent : 10  
 Valid LMM received : 20  
 Invalid LMM received : 0  
 LMR sent : 20  
 Valid LMR received : 10  
 Invalid LMR received : 0  
 Remote MEP count : 1

Identifier	MAC address	State	Interface
2	00:12:1e:fb:ea:7d	ok	ge-1/0/0.0

**show oam ethernet  
 connectivity-fault-  
 management  
 mep-database  
 (enhanced continuity  
 measurement)**

```
user@host> show oam ethernet connectivity-fault-management mep-database
maintenance-domain md5 maintenance-association ma5 local-mep 2001 remote-mep 1001
Maintenance domain name: md5, Format: string, Level: 5
Maintenance association name: ma5, Format: string
Continuity-check status: enabled, Interval: 100ms, Loss-threshold: 3 frames
MEP identifier: 2001, Direction: down, MAC address: 00:19:e2:b2:81:4a
Auto-discovery: enabled, Priority: 0
Interface status TLV: up, Port status TLV: up
Interface name: ge-2/0/0.0, Interface status: Active, Link status: Up
```

```
Remote MEP identifier: 1001, State: ok
MAC address : 00:19:e2:b0:74:00, Type: Learned
Interface : ge-2/0/0.0
Last flapped : Never
+ Continuity : 91%, Admin-enable duration: 2100sec, Oper-down duration: 100sec
Remote defect indication: false
Port status TLV: none
Interface status TLV: none
```



## show oam ethernet connectivity-fault-management mep-statistics

<b>Syntax</b>	<pre>show oam ethernet connectivity-fault-management mep-statistics maintenance-domain <i>md-name</i> maintenance-association <i>ma-name</i> &lt;mep <i>mep-id</i>&gt; &lt;remote-mep <i>remote-mep-id</i>&gt; &lt;count <i>entry-count</i>&gt;</pre>
<b>Release Information</b>	<p>Command introduced in Junos OS Release 9.5.</p> <p>Command introduced in Junos OS Release 11.4 for EX Series switches.</p>
<b>Description</b>	On MX Series and ACX Series routers and EX Series switches with Ethernet interfaces, display ETH-DM statistics and ETH-DM frame counts.
<b>Options</b>	<p><b>maintenance-domain <i>md-name</i></b>—Name of an existing CFM maintenance domain.</p> <p><b>maintenance-association <i>ma-name</i></b>—Name of an existing CFM maintenance association.</p> <p><b>mep <i>mep-id</i></b>—(Optional) Numeric identifier of the local MEP. The range of values is 1 through 8192. On EX Series switches, the range of values is 1 through 8191.</p> <p><b>remote-mep <i>remote-mep-id</i></b>—(Optional) Numeric identifier of the remote MEP. The range of values is 1 through 8192. On EX Series switches, the range of values is 1 through 8191.</p> <p><b>count <i>entry-count</i></b>—(Optional) Number of entries to display from the statistics table. The range of values is 1 through 100. The default value is 100 entries.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">clear oam ethernet connectivity-fault-management statistics on page 168</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management delay-statistics on page 337</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management interfaces on page 345</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-database on page 357</a></li> </ul>
<b>List of Sample Output</b>	<p><a href="#">show oam ethernet connectivity-fault-management mep-statistics (CIR counters only) on page 369</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-statistics (CIR and EIR counters enabled) on page 370</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-statistics remote-mep (CIR counters only) on page 372</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-statistics remote-mep (CIR and EIR counters enabled) on page 374</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-statistics on page 376</a></p> <p><a href="#">show oam ethernet connectivity-fault-management mep-statistics remote-mep on page 377</a></p>

**Output Fields** Table 52 on page 368 lists the output fields for the **show oam ethernet connectivity-fault-management mep-statistics** command. Output fields are listed in the approximate order in which they appear.

**Table 52: show oam ethernet connectivity-fault-management delay-statistics and mep-statistics Output Fields**

Output Field Name	Field Description
MEP identifier	Maintenance association end point (MEP) numeric identifier.
MAC address	Unicast MAC address configured for the MEP.
Remote MEP count	Number of remote MEPs (unless you specify the <b>remote-mep</b> option).
Remote MEP identifier	Numeric identifier of the remote MEP.
Remote MAC address	Unicast MAC address of the remote MEP.
Index	Index number that corresponds to the ETH-DM entry in the CFM database.
One-way delay (usec)	For a one-way ETH-DM session, the frame delay time, in microseconds, measured at the receiver MEP.  For a detailed description of one-way Ethernet frame delay measurement, see the <i>ITU-T Y.1731 Ethernet Service OAM</i> topics in the Junos® OS Network Interfaces.
Two-way delay (usec)	For a two-way ETH-DM session, the frame delay time, in microseconds, measured at the initiator MEP.  For a detailed description of two-way Ethernet frame delay measurement, see the <i>ITU-T Y.1731 Ethernet Service OAM</i> topics in the Junos® OS Network Interfaces.
Average one-way delay	Average one-way frame delay for the statistics displayed.
Average one-way delay variation	Average one-way “frame jitter” for the statistics displayed.
Best-case one-way delay	Lowest one-way frame delay for the statistics displayed.
Worst-case one-way delay	Highest one-way frame delay for the statistics displayed.
Average two-way delay	Average two-way frame delay for the statistics displayed.
Average two-way delay variation	Average two-way “frame jitter” for the statistics displayed.
Best-case two-way delay	Lowest two-way frame delay for the statistics displayed.
Worst-case two-way delay	Highest two-way frame delay calculated in this session.

## Sample Output

show oam ethernet  
connectivity-fault-  
management  
mep-statistics (CIR  
counters only)

```
user@host> show oam ethernet connectivity-fault-management mep-statistics
maintenance-domain md1 maintenance-association ma-1 local-mep 3 remote-mep 103 count 3
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
Remote MEP count                : 1
CCMs sent                       : 6550
CCMs received out of sequence   : 0
LBMs sent                       : 0
Valid in-order LBRs received    : 0
Valid out-of-order LBRs received : 0
LBRs received with corrupted data : 0
LBRs sent                       : 0
LTMs sent                       : 0
LTMs received                   : 0
LTRs sent                       : 0
LTRs received                   : 0
Sequence number of next LTM request : 0
1DMs sent                       : 5
Valid 1DMs received             : 0
Invalid 1DMs received           : 0
DMMs sent                       : 5
DMRs sent                       : 0
Valid DMRs received             : 5
Invalid DMRs received           : 0
LMM sent                       : 5
Valid LMM received              : 5
Invalid LMM received            : 0
LMR sent                       : 0
Valid LMR received              : 5
Invalid LMR received            : 0
Remote MEP identifier           : 101
Remote MAC address              : 00:05:85:73:39:4a
```

### Delay measurement statistics:

Index	One-way delay (usec)	Two-way delay (usec)
1	259	519
2	273	550
3	287	571
4	299	610
5	313	650

```
Average one-way delay          : 286 usec
Average one-way delay variation : 62 usec
Best case one-way delay        : 259 usec
Average two-way delay          : 580 usec
Average two-way delay variation : 26 usec
Best case two-way delay        : 519 usec
Worst case two-way delay       : 650 usec
```

### Loss measurement statistics:

Index	Near-end Frame loss (CIR)	Far-end Frame loss (CIR)	Near-end Frame loss (EIR)	Far-end Frame loss (EIR)
1	9	9		
2	3	5		
3	7	5		
4	9	6		
5	3	6		

```
Average near-end loss (CIR)           : 6.2
Average near-end loss ratio (CIR)      : 6.2%
Average far-end loss (CIR)            : 6.2
Average far-end loss ratio (CIR)       : 6.2%
Near-end best case loss (CIR)          : 3
Near-end best case loss ratio (CIR)    : 3%
Near-end worst case loss (CIR)         : 9
Near-end worst case loss ratio (CIR)   : 9%
Far-end best case loss (CIR)           : 5
Far-end best case loss ratio (CIR)     : 5%
Far-end worst case loss (CIR)          : 9
Far-end worst case loss ratio (CIR)    : 9%
```

**show oam ethernet  
connectivity-fault-  
management  
mep-statistics (CIR**

```
user@host> show oam ethernet connectivity-fault-management mep-statistics
maintenance-domain mdl maintenance-association ma-1 local-mep 3 remote-mep 103 count 3
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
Remote MEP count           : 1
CCMs sent                  : 6550
```

and EIR counters  
enabled)

```
CCMs received out of sequence      : 0
LBMs sent                          : 0
Valid in-order LBRs received       : 0
Valid out-of-order LBRs received  : 0
LBRs received with corrupted data  : 0
LBRs sent                         : 0
LTMs sent                         : 0
LTMs received                     : 0
LTRs sent                         : 0
LTRs received                     : 0
Sequence number of next LTM request : 0
1DMs sent                         : 5
Valid 1DMs received               : 0
Invalid 1DMs received             : 0
DMMs sent                        : 5
DMRs sent                        : 0
Valid DMRs received               : 5
Invalid DMRs received             : 0
LMM sent                         : 5
Valid LMM received                : 5
Invalid LMM received              : 0
LMR sent                         : 0
Valid LMR received                : 5
Invalid LMR received              : 0
Remote MEP identifier              : 101
Remote MAC address                 : 00:05:85:73:39:4a
```

#### Delay measurement statistics:

Index	One-way delay (usec)	Two-way delay (usec)
1	259	519
2	273	550
3	287	571
4	299	610
5	313	650

```
Average one-way delay              : 286 usec
Average one-way delay variation     : 62 usec
Best case one-way delay             : 259 usec
Average two-way delay               : 580 usec
Average two-way delay variation     : 26 usec
Best case two-way delay             : 519 usec
Worst case two-way delay            : 650 usec
```

#### Loss measurement statistics:

Index	Near-end Frame loss (CIR)	Far-end Frame loss (CIR)	Near-end Frame loss (EIR)	Far-end Frame loss (EIR)
1	9	9	2	4
2	3	5	4	6
3	7	5	0	2
4	9	6	8	2
5	3	6	6	4

```
Average near-end loss (CIR)        : 6.2
Average near-end loss ratio (CIR)   : 6.2%
Average far-end loss (CIR)          : 6.2
Average far-end loss ratio (CIR)    : 6.2%
Near-end best case loss (CIR)       : 3
Near-end best case loss ratio (CIR) : 3%
Near-end worst case loss (CIR)      : 9
```

Near-end worst case loss ratio (CIR)	: 9%
Far-end best case loss (CIR)	: 5
Far-end best case loss ratio (CIR)	: 5%
Far-end worst case loss (CIR)	: 9
Far-end worst case loss ratio (CIR)	: 9%
Average near-end loss (EIR)	: 4
Average near-end loss ratio (EIR)	: 4%
Average far-end loss (EIR)	: 3.4
Average far-end loss ratio (EIR)	: 3.4%
Near-end best case loss (EIR)	: 0
Near-end best case loss ratio (EIR)	: 0%
Near-end worst case loss (EIR)	: 8
Near-end worst case loss ratio (EIR)	: 8%
Far-end best case loss (EIR)	: 2
Far-end best case loss ratio (EIR)	: 2%
Far-end worst case loss (EIR)	: 6
Far-end worst case loss ratio (EIR)	: 6%

**show oam ethernet  
connectivity-fault-  
management  
mep-statistics**

```
user@host> show oam ethernet connectivity-fault-management mep-statistics
maintenance-domain md1 maintenance-association ma-1 local-mep 3 remote-mep 103 count 3
remote-mep 101
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
CCMs sent : 7762
```

remote-mep (CIR  
counters only)

```

CCMs received out of sequence      : 0
LBMs sent                          : 0
Valid in-order LBRs received       : 0
Valid out-of-order LBRs received   : 0
LBRs received with corrupted data  : 0
LBRs sent                          : 0
LTMs sent                          : 0
LTMs received                      : 0
LTRs sent                          : 0
LTRs received                      : 0
Sequence number of next LTM request : 0
1DMs sent                          : 5
Valid 1DMs received                : 0
Invalid 1DMs received              : 0
DMMs sent                          : 5
DMRs sent                          : 0
Valid DMRs received                : 5
Invalid DMRs received              : 0
LMM sent                           : 5
Valid LMM received                 : 5
Invalid LMM received               : 0
LMR sent                           : 0
Valid LMR received                 : 5
Invalid LMR received               : 0
Remote MEP identifier               : 101
Remote MAC address                  : 00:05:85:73:39:4a

```

## Delay measurement statistics:

Index	One-way delay (usec)	Two-way delay (usec)
1	259	519
2	273	550
3	287	571
4	299	610
5	313	650

```

Average one-way delay              : 286 usec
Average one-way delay variation    : 62 usec
Best case one-way delay            : 259 usec
Average two-way delay              : 580 usec
Average two-way delay variation    : 26 usec
Best case two-way delay            : 519 usec
Worst case two-way delay           : 650 usec

```

## Loss measurement statistics:

Index	Near-end Frame loss (CIR)	Far-end Frame loss (CIR)	Near-end Frame loss (EIR)	Far-end Frame loss (EIR)
1	9	9		
2	3	5		
3	7	5		
4	9	6		
5	3	6		

```

Average near-end loss (CIR)        : 6.2
Average near-end loss ratio (CIR)  : 6.2%
Average far-end loss (CIR)         : 6.2
Average far-end loss ratio (CIR)   : 6.2%
Near-end best case loss (CIR)      : 3
Near-end best case loss ratio (CIR): 3%
Near-end worst case loss (CIR)     : 9
Near-end worst case loss ratio (CIR): 9%

```

Far-end best case loss (CIR)	: 5
Far-end best case loss ratio (CIR)	: 5%
Far-end worst case loss (CIR)	: 9
Far-end worst case loss ratio (CIR)	: 9%
Average near-end loss (EIR)	: 4
Average near-end loss ratio (EIR)	: 4%
Average far-end loss (EIR)	: 3.4
Average far-end loss ratio (EIR)	: 3.4%
Near-end best case loss (EIR)	: 0
Near-end best case loss ratio (EIR)	: 0%
Near-end worst case loss (EIR)	: 8
Near-end worst case loss ratio (EIR)	: 8%
Far-end best case loss (EIR)	: 2
Far-end best case loss ratio (EIR)	: 2%
Far-end worst case loss (EIR)	: 6
Far-end worst case loss ratio (EIR)	: 6%

**show oam ethernet  
connectivity-fault-  
management  
mep-statistics**

```
user@host> show oam ethernet connectivity-fault-management mep-statistics
maintenance-domain mdl maintenance-association ma-1 local-mep 3 remote-mep 103 count 3
remote-mep 101
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
CCMs sent :7762
```



## remote-mep (CIR and EIR counters enabled)

```

CCMs received out of sequence      : 0
LBMs sent                          : 0
Valid in-order LBRs received       : 0
Valid out-of-order LBRs received   : 0
LBRs received with corrupted data  : 0
LBRs sent                          : 0
LTMs sent                          : 0
LTMs received                      : 0
LTRs sent                          : 0
LTRs received                      : 0
Sequence number of next LTM request : 0
1DMs sent                          : 5
Valid 1DMs received                : 0
Invalid 1DMs received              : 0
DMMs sent                          : 5
DMRs sent                          : 0
Valid DMRs received                : 5
Invalid DMRs received              : 0
LMM sent                           : 5
Valid LMM received                 : 5
Invalid LMM received               : 0
LMR sent                           : 0
Valid LMR received                 : 5
Invalid LMR received               : 0
Remote MEP identifier               : 101
Remote MAC address                  : 00:05:85:73:39:4a

```

## Delay measurement statistics:

Index	One-way delay (usec)	Two-way delay (usec)
1	259	519
2	273	550
3	287	571
4	299	610
5	313	650

```

Average one-way delay              : 286 usec
Average one-way delay variation     : 62 usec
Best case one-way delay             : 259 usec
Average two-way delay               : 580 usec
Average two-way delay variation     : 26 usec
Best case two-way delay             : 519 usec
Worst case two-way delay            : 650 usec

```

## Loss measurement statistics:

Index	Near-end Frame loss (CIR)	Far-end Frame loss (CIR)	Near-end Frame loss (EIR)	Far-end Frame loss (EIR)
1	10	8	5	12
2	12	7	6	16
3	7	5	0	2
4	9	6	8	2
5	3	6	6	4

```

Average near-end loss (CIR)        : 6.2
Average near-end loss ratio (CIR)  : 6.2%
Average far-end loss (CIR)         : 6.2
Average far-end loss ratio (CIR)   : 6.2%
Near-end best case loss (CIR)      : 3
Near-end best case loss ratio (CIR): 3%
Near-end worst case loss (CIR)     : 9

```

```

Near-end worst case loss ratio (CIR) : 9%
Far-end best case loss (CIR) : 5
Far-end best case loss ratio (CIR) : 5%
Far-end worst case loss (CIR) : 9
Far-end worst case loss ratio (CIR) : 9%
Average near-end loss (EIR) : 4
Average near-end loss ratio (EIR) : 4%
Average far-end loss (EIR) : 3.4
Average far-end loss ratio (EIR) : 3.4%
Near-end best case loss (EIR) : 0
Near-end best case loss ratio (EIR) : 0%
Near-end worst case loss (EIR) : 8
Near-end worst case loss ratio (EIR) : 8%
Far-end best case loss (EIR) : 2
Far-end best case loss ratio (EIR) : 2%
Far-end worst case loss (EIR) : 6
Far-end worst case loss ratio (EIR) : 6%

```

#### show oam ethernet connectivity-fault- management mep-statistics

```

user@host> show oam ethernet connectivity-fault-management mep-statistics
maintenance-domain md1 maintenance-association ma-1

```

```
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
```

```
Remote MEP count: 1
```

```

CCMs sent : 6550
CCMs received out of sequence : 0
LBMs sent : 0
Valid in-order LBRs received : 0
Valid out-of-order LBRs received : 0
LBRs received with corrupted data : 0
LBRs sent : 0
LTMs sent : 0
LTMs received : 0
LTRs sent : 0
LTRs received : 0
Sequence number of next LTM request : 0
IDMs sent : 5
Valid IDMs received : 0
Invalid IDMs received : 0
DMMs sent : 5
DMRs sent : 0
Valid DMRs received : 5
Invalid DMRs received : 0

```

```
Remote MEP identifier: 101
```

```
Remote MAC address: 00:05:85:73:39:4a
```

```
Delay measurement statistics:
```

Index	One-way delay (usec)	Two-way delay (usec)
1	259	519
2	273	550
3	287	571
4	299	610
5	313	650

```

Average one-way delay : 286 usec
Average one-way delay variation: 62 usec
Best case one-way delay : 259 usec
Worst case one-way delay : 313 usec
Average two-way delay : 580 usec
Average two-way delay variation: 26 usec
Best case two-way delay : 519 usec
Worst case two-way delay : 650 usec

```

```
show oam ethernet
connectivity-fault-
management
mep-statistics
remote-mep
```

```
user@host> show oam ethernet connectivity-fault-management mep-statistics
maintenance-domain md1 maintenance-association ma1 remote-mep 101
```

```
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
CCMs sent : 7762
CCMs received out of sequence : 0
LBMs sent : 0
Valid in-order LBRs received : 0
Valid out-of-order LBRs received : 0
LBRs received with corrupted data : 0
LBRs sent : 0
LTMs sent : 0
LTMs received : 0
LTRs sent : 0
LTRs received : 0
Sequence number of next LTM request : 0
1DMs sent : 5
Valid 1DMs received : 0
Invalid 1DMs received : 0
DMMs sent : 5
DMRs sent : 0
Valid DMRs received : 5
Invalid DMRs received : 0
```

```
Remote MEP identifier: 101
```

```
Remote MAC address: 00:05:85:73:39:4a
```

```
Delay measurement statistics:
```

Index	One-way delay (usec)	Two-way delay (usec)
1	259	519
2	273	550
3	287	571
4	299	610
5	313	650

```
Average one-way delay : 286 usec
Average one-way delay variation: 62 usec
Best case one-way delay : 259 usec
Worst case one-way delay : 313 usec
Average two-way delay : 580 usec
Average two-way delay variation: 26 usec
Best case two-way delay : 519 usec
Worst case two-way delay : 650 usec
```

## show oam ethernet connectivity-fault-management loss-statistics

<b>Syntax</b>	<pre>show oam ethernet connectivity-fault-management loss-statistics maintenance-domain <i>md-name</i> maintenance-association <i>ma-name</i> &lt;count <i>entry-count</i>&gt; &lt;local-mep <i>local-mep-id</i>&gt; &lt;remote-mep <i>remote-mep-id</i>&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 11.1.
<b>Description</b>	On MX Series and ACX series routers with Ethernet interfaces, display ETH-LM statistics for on-demand mode only.
<b>Options</b>	<p><b>maintenance-domain <i>md-name</i></b>—Name of an existing CFM maintenance domain.</p> <p><b>maintenance-association <i>ma-name</i></b>—Name of an existing CFM maintenance association.</p> <p><b>count <i>entry-count</i></b>—(Optional) Number of entries to display from the statistics table. The range of values is from 1 through 100. The default value is 100.</p> <p><b>local-mep <i>local-mep-id</i></b>—(Optional) Numeric identifier of the local MEP. The range of values is from 1 through 8191.</p> <p><b>remote-mep <i>remote-mep-id</i></b>—(Optional) Numeric identifier of the remote MEP. The range of values is from 1 through 8191.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li><a href="#">show oam ethernet connectivity-fault-management mep-statistics on page 367</a></li> </ul>
<b>List of Sample Output</b>	<p><a href="#">show oam ethernet connectivity-fault-management loss-statistics (with only CIR frames) on page 381</a></p> <p><a href="#">show oam ethernet connectivity-fault-management loss-statistics (with CIR and EIR frames) on page 381</a></p> <p><a href="#">show oam ethernet connectivity-fault-management loss-statistics remote-mep (with CIR frames) on page 382</a></p> <p><a href="#">show oam ethernet connectivity-fault-management loss-statistics remote-mep (with CIR and EIR frames) on page 382</a></p>
<b>Output Fields</b>	Table 53 on page 378 lists the output fields for the <b>show oam ethernet connectivity-fault-management loss-statistics</b> command. Output fields are listed in the approximate order in which they appear.

Table 53: show oam ethernet connectivity-fault-management loss-statistics Output Fields

Output Field Name	Field Description
MEP identifier	Maintenance association end point (MEP) numeric identifier.

**Table 53: show oam ethernet connectivity-fault-management loss-statistics Output Fields (*continued*)**

Output Field Name	Field Description
MAC address	Unicast MAC address configured for the MEP.
Remote MEP count	Number of remote MEPs (unless you specify the <b>remote-mep</b> option).
Remote MEP identifier	Numeric identifier of the remote MEP.
Remote MAC address	Unicast MAC address of the remote MEP.
Index	Index number that corresponds to the ETH-LM entry in the CFM database.
Near-end frame loss	Count of frame loss associated with ingress data frames.
Far-end frame loss	Count of frame loss associated with egress data frames.
Near-end loss ratio	Ratio, expressed as a percentage, of the number of service frames not delivered divided by the total number of service frames during time interval T at the ingress interface.
Far-end loss ratio	Ratio, expressed as a percentage, of the number of service frames not delivered divided by the total number of service frames during time interval T at the egress interface.
Average near-end frame loss	Average frame loss measured in this session associated with ingress data frames.
Average near-end loss ratio	Average frame loss ratio measured in this session associated with ingress data frames.
Average far-end frame loss	Average frame loss measured in this session associated with egress data frames.
Average far-end loss ratio	Average frame loss ratio measured in this session associated with egress data frames.
Near-end best case loss	Lowest frame loss measured in this session associated with ingress data frames.
Near-end best case loss ratio	Lowest frame loss ratio measured in this session associated with ingress data frames.
Near-end worst case loss	Highest frame loss measured in this session associated with ingress data frames.
Near-end worst case loss ratio	Highest frame loss ratio measured in this session associated with ingress data frames.
Far-end best case frame loss	Lowest frame loss measured in this session associated with egress data frames.
Far-end best case loss ratio	Lowest frame loss ratio measured in this session associated with egress data frames.

**Table 53: show oam ethernet connectivity-fault-management loss-statistics Output Fields (*continued*)**

Output Field Name	Field Description
<b>Far-end worst case loss</b>	Highest frame loss measured in this session associated with egress data frames.
<b>Far-end worst case loss ratio</b>	Highest frame loss ratio measured in this session associated with egress data frames.

## Sample Output

**show oam ethernet  
connectivity-fault-  
management  
loss-statistics (with  
only CIR frames)**

```
user@host> show oam ethernet connectivity-fault-management loss-statistics
maintenance-domain md6 maintenance-association ma6
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
Remote MEP count      : 1

Remote MEP identifier  : 101
Remote MAC address    : 00:05:85:73:39:4a

Loss measurement statistics:
Index  Near-end    Far-end      Near-end     Far-end
      Frame loss Frame loss   Frame loss   Frame loss
            (CIR)      (CIR)        (EIR)        (EIR)
  1         9         9
  2         3         5
  3         7         7
  4         9         1
  5         3         6
Average near-end loss (CIR)      : 6.2
Average near-end loss ratio (CIR) : 6.2%
Average far-end loss (CIR)       : 5.6
Average far-end loss ratio (CIR) : 5.6%
Near-end best case loss (CIR)    : 3
Near-end best case loss ratio (CIR) : 3%
Near-end worst case loss (CIR)   : 9
Near-end worst case loss ratio (CIR) : 9%
Far-end best case loss (CIR)     : 1
Far-end best case loss ratio (CIR) : 1%
Far-end worst case loss (CIR)    : 9
Far-end worst case loss ratio (CIR) : 9%
```

**show oam ethernet  
connectivity-fault-  
management  
loss-statistics (with  
CIR and EIR frames)**

```
user@host> show oam ethernet connectivity-fault-management loss-statistics
maintenance-domain md6 maintenance-association ma6 remote-mep 101
MEP identifier: 100, MAC address: 00:05:85:73:7b:39
Remote MEP count      : 1
Remote MEP identifier  : 101
Remote MAC address    : 00:05:85:73:39:4a

Loss measurement statistics:
Index  Near-end    Far-end      Near-end     Far-end
      Frame loss Frame loss   Frame loss   Frame loss
            (CIR)      (CIR)        (EIR)        (EIR)
  1         9         9         8         10
  2         3         5         4         16
  3         7         7        10         8
  4         9         1        12        20
  5         3         6         6        18
Average near-end loss (CIR)      : 6.2
Average near-end loss ratio (CIR) : 6.2%
Average far-end loss (CIR)       : 5.6
Average far-end loss ratio (CIR) : 5.6%
Near-end best case loss (CIR)    : 3
Near-end best case loss ratio (CIR) : 3%
Near-end worst case loss (CIR)   : 9
Near-end worst case loss ratio (CIR) : 9%
Far-end best case loss (CIR)     : 1
Far-end best case loss ratio (CIR) : 1%
Far-end worst case loss (CIR)    : 9
```

```

Far-end worst case loss ratio (CIR) : 9%
Average near-end loss (EIR) : 8
Average near-end loss ratio (EIR) : 8%
Average far-end loss (EIR) : 14.4
Average far-end loss ratio (EIR) : 14.4%
Near-end best case loss (EIR) : 4
Near-end best case loss ratio (EIR) : 4%
Near-end worst case loss (EIR) : 12
Near-end worst case loss ratio (EIR) : 12%
Far-end best case loss (EIR) : 8
Far-end best case loss ratio (EIR) : 8%
Far-end worst case loss (EIR) : 20
Far-end worst case loss ratio (EIR) : 20%

```

**show oam ethernet  
connectivity-fault-  
management  
loss-statistics  
remote-mep (with CIR  
frames)**

```

user@host> show oam ethernet connectivity-fault-management loss-statistics
maintenance-domain md6 maintenance-association ma6 remote-mep 102
Remote MEP identifier: 102
Remote MAC address: 00:05:85:73:39:4a

```

```

Loss measurement statistics:
Index      Near-end      Far-end      Near-end      Far-end
           Frame loss   Frame loss   Frame loss   Frame loss
           (CIR)      (CIR)      (EIR)        (EIR)
-----
1           5           9
2           7          100
3           8           1
4           9           6
5           1           5

Average near-end loss (CIR) : 6
Average near-end loss ratio (CIR) : 6%
Average far-end loss (CIR) : 24.2
Average far-end loss ratio (CIR) : 24.2%
Near-end best case loss (CIR) : 1
Near-end best case loss ratio (CIR) : 1%
Near-end worst case loss (CIR) : 9
Near-end worst case loss ratio (CIR) : 9%
Far-end best case loss (CIR) : 1
Far-end best case loss ratio (CIR) : 1%
Far-end worst case loss (CIR) : 100
Far-end worst case loss ratio (CIR) : 100%

```

**show oam ethernet  
connectivity-fault-  
management  
loss-statistics**

```

user@host> show oam ethernet connectivity-fault-management loss-statistics
maintenance-domain md6 maintenance-association ma6 remote-mep 102

Remote MEP identifier : 102
Remote MAC address : 00:05:85:73:39:4a

```



remote-mep (with CIR  
and EIR frames)

## Loss measurement statistics:

Index	Near-end Frame loss (CIR)	Far-end Frame loss (CIR)	Near-end Frame loss (EIR)	Far-end Frame loss (EIR)
1	5	9	2	4
2	7	100	4	6
3	8	1	0	8
4	9	6	6	4
5	1	5	8	4

```

Average near-end loss (CIR)           : 6
Average near-end loss ratio (CIR)      : 6%
Average far-end loss (CIR)            : 24.2
Average far-end loss ratio (CIR)       : 24.2%
Near-end best case loss (CIR)          : 1
Near-end best case loss ratio (CIR)    : 1%
Near-end worst case loss (CIR)         : 9
Near-end worst case loss ratio (CIR)   : 9%
Far-end best case loss (CIR)           : 1
Far-end best case loss ratio (CIR)     : 1%
Far-end worst case loss (CIR)          : 100
Far-end worst case loss ratio (CIR)    : 100%
Average near-end loss (EIR)           : 4
Average near-end loss ratio (EIR)      : 4%
Average far-end loss (EIR)            : 5.2
Average far-end loss ratio (EIR)       : 5.2%
Near-end best case loss (EIR)          : 0
Near-end best case loss ratio (EIR)    : 0%
Near-end worst case loss (EIR)         : 8
Near-end worst case loss ratio (EIR)   : 8%
Far-end best case loss (EIR)           : 4
Far-end best case loss ratio (EIR)     : 4%
Far-end worst case loss (EIR)          : 8
Far-end worst case loss ratio (EIR)    : 8%

```

## show oam ethernet connectivity-fault-management mip

<b>Syntax</b>	<pre>show oam ethernet connectivity-fault-management mip &lt;bridge-domain <i>bridge-domain-name</i>&gt; &lt;instance-name <i>routing-instance-name</i>&gt; &lt;interface-name <i>logical-interface-name</i>&gt; &lt;logical-system <i>logical-system-name</i>&gt; &lt;vlan <i>vlan-identifier</i>&gt;</pre>
<b>Release Information</b>	<p>Command introduced in Junos OS Release 9.4.</p> <p><b>vlan</b> option introduced in Junos OS Release 9.6.</p>
<b>Description</b>	On MX Series routers, display information about maintenance intermediate points (MIPs) for the Ethernet OAM 802.1ag standard for connectivity fault management (CFM).
<b>Options</b>	<p><b>none</b>—Display MIP information for all instances.</p> <p><b>bridge-domain <i>bridge-domain-name</i></b>—(Optional) Display MIP information for the specified bridge domain.</p> <p><b>instance-name <i>routing-instance-name</i></b>—(Optional) Display MIP information for the specified routing instance.</p> <p><b>interface-name <i>logical-interface-name</i></b>—(Optional) Display MIP information for the specified logical interface.</p> <p><b>logical-system <i>logical-system-name</i></b>—(Optional) Display MIP information for the specified logical system.</p> <p><b>vlan <i>vlan-identifier</i></b>—(Optional) Display MIP information for the specified VLAN.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-database on page 357</a></li> <li>• <a href="#">show oam ethernet connectivity-fault-management mep-statistics on page 367</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show oam ethernet connectivity-fault-management mip on page 385</a>
<b>Output Fields</b>	Table 54 on page 384 lists the output fields for the <b>show oam ethernet connectivity-fault-management mip</b> command. Output fields are listed in the approximate order in which they appear.

Table 54: show oam ethernet connectivity-fault-management mip Output Fields

Field Name	Field Description
MIP information for instance	Header for MIP information for the MIP name.
instance	Name of each instance associated with the MIP and the VLAN identifier associated with each instance.

Table 54: show oam ethernet connectivity-fault-management mip Output Fields (*continued*)

Field Name	Field Description
<b>maintenance-domain mhf</b>	Display status of MIP half function for the maintenance domain: <b>explicit</b> , <b>unspecified</b> , or <b>default</b> .
<b>maintenance-association</b>	Display status of MIP half function for the maintenance association: <b>explicit</b> , <b>unspecified</b> , or <b>default</b> .
<b>default maintenance-domain</b>	Display status of MIP half function for the default maintenance domain: <b>explicit</b> , <b>unspecified</b> , or <b>default</b> .
<b>Interface</b>	Name of logical interface.
<b>Level</b>	Number used to identify the maintenance domain to which the CFM message from this interface belongs.

## Sample Output

### show oam ethernet connectivity-fault-management mip

```

user@host> show oam ethernet connectivity-fault-management mip
MIP information for instance pbn-1-for-eline eline-svlans-vlan-1200
  maintenance-domain mhf      : unspecified
  maintenance-association mhf  : unspecified
  default maintenance-domain mhf : default

  Interface      Level
  pip0.0         3
  ge-1/0/0.2     3

MIP information for instance pbn-1-for-eline eline-svlans-vlan-2100
  maintenance-domain mhf      : unspecified
  maintenance-association mhf  : unspecified
  default maintenance-domain mhf : default

  Interface      Level
  pip0.0         3
  ge-1/0/0.1     3

```

## show oam ethernet connectivity-fault-management path-database

<b>Syntax</b>	show oam ethernet connectivity-fault-management path-database <host-mac-address> <maintenance-association <i>ma-name</i> > <maintenance-domain <i>domain-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	On M7i and M10i with Enhanced CFEB (CFEB-E), M320, MX Series, ACX Series, T320, and T640 routers, display IEEE 802.lag Operation, Administration, and Management (OAM) connectivity fault management path database information for a host configured with an MEP.
<b>Options</b>	<p><b>host-mac-address</b>—(Optional) Display connectivity fault management path database information for a specified Ethernet host.</p> <p><b>maintenance-association <i>ma-name</i></b>—(Optional) Display connectivity fault management path database information for the specified maintenance association.</p> <p><b>maintenance-domain <i>domain-name</i></b>—(Optional) Display connectivity fault management path database information for the specified maintenance domain.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show oam ethernet connectivity-fault-management path-database on page 387</a>
<b>Output Fields</b>	<a href="#">Table 55 on page 386</a> lists the output fields for the <b>show oam ethernet connectivity-fault-management path-database</b> command. Output fields are listed in the approximate order in which they appear.

**Table 55: show oam ethernet connectivity-fault-management path-database Output Fields**

Field Name	Field Description
Linktrace to	MAC address of the remote MEPs in the path.
Interface	Interface identifier.
Maintenance domain name	Maintenance domain name.
Format (Maintenance domain)	Maintenance domain name format configured.
Level	Maintenance domain level configured.
Maintenance association name	Maintenance association name.

Table 55: show oam ethernet connectivity-fault-management path-database Output Fields (*continued*)

Field Name	Field Description
Local Mep	Local MEP identifier.

## Sample Output

**show oam ethernet  
connectivity-fault-  
management  
path-database**

```
user@host> show oam ethernet connectivity-fault-management path-database
maintenance-domain md1 maintenance-association ma1 00:05:85:79:39:ef
Linktrace to 00:05:85:79:39:ef, Interface : ge-3/0/0
    Maintenance Domain: md1, Level: 7
    Maintenance Association: ma1, Local Mep: 201
```

## show oam ethernet connectivity-fault-management policer

<b>Syntax</b>	<b>show oam ethernet connectivity-fault-management policer</b> <maintenance-domain <i>md-name</i> > <maintenance-association <i>ma-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 10.0.
<b>Description</b>	On M120, M320, MX Series, T320, and T640 routers displays connectivity-fault-management policer statistics.
<b>Options</b>	<p>This command has the following options:</p> <p><b>maintenance-domain <i>md-name</i></b>—Name of an existing CFM maintenance domain. If this option is not specified, policer statistics are displayed for all maintenance associations for all maintenance domains.</p> <p><b>maintenance-association <i>ma-name</i></b>—Name of an existing CFM maintenance association. If this option is not specified, policer statistics are displayed for all maintenance associations for given maintenance domain. This option cannot be specified without specifying maintenance-domain name.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">clear oam ethernet connectivity-fault-management policer on page 167</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show oam ethernet connectivity-fault-management policer on page 390</a> <a href="#">show oam ethernet connectivity-fault-management policer maintenance-domain <i>md-name</i> on page 390</a> <a href="#">show oam ethernet connectivity-fault-management policer maintenance-domain <i>md-name</i> maintenance-association <i>ma-name</i> on page 390</a>
<b>Output Fields</b>	Table 56 on page 388 lists the output fields for the <b>show oam ethernet connectivity-fault-management policer</b> command. Output fields are listed in the approximate order in which they appear.

**Table 56: show oam ethernet connectivity-fault-management policer Output Fields**

Field Name	Field Description
<b>Legend for Policer</b>	<p>Describes the symbols used under the <b>Scope</b> and <b>Type</b> headings:</p> <ul style="list-style-type: none"> <li>• G - Global scope</li> <li>• S - Service scope</li> <li>• cc - Continuity check (Type)</li> </ul>
<b>Maintenance Domain</b>	Displays the maintenance domain name.
<b>Level</b>	Displays the maintenance domain level configured.

Table 56: show oam ethernet connectivity-fault-management policer Output Fields (*continued*)

Field Name	Field Description
<b>Maintenance association</b>	Displays the maintenance association name.
<b>Policer</b>	Displays the policer name.
<b>Type</b>	Policer type. Value <b>cc</b> means this policer is used only to police continuity check CFM messages. Value <b>other</b> means this policer is used only to police non-continuity check CFM messages. Value <b>all</b> means this policer is used to police all CFM messages.
<b>Scope</b>	Policer scope. Displays whether the <i>global</i> (G) policer configuration is applicable or the session (S) specific policer config is applicable.
<b>Drop count</b>	Displays the number of packets dropped by the indicated policer.

## Sample Output

**show oam ethernet  
connectivity-fault  
-management  
policer**

Displays the policer information for all maintenance associations and their maintenance domains.

```
show oam ethernet connectivity-fault-management policer
Legend for Policer
G - Global scope
S - Service scope
cc - Continuity check

Maintenance Domain: md1 Level: 1
Maintenance association Policer      Type      Scope Drop count
ma1                     cfm-policer1 all      G          300
ma1-2                   cfm-policer1 cc       S          259
ma1-2                   cfm-policer1 other    G          300
Maintenance Domain: md2 Level: 2
Maintenance association Policer      Type      Scope Drop count
ma2                     cfm-policer1 cc       G          300
ma2                     cfm-policer2 other    S          223
```

**show oam ethernet  
connectivity-fault  
-management  
policer  
maintenance-domain  
md-name**

Displays the policer information for the specified maintenance domain and its maintenance associations.

```
show oam ethernet connectivity-fault-management policer maintenance-domain md1
Legend for Policer
G - Global scope
S - Service scope
cc - Continuity check

Maintenance Domain: md1 Level: 1
Maintenance association Policer      Type      Scope Drop count
ma1                     cfm-policer1 all      G          300
ma1-2                   cfm-policer1 cc       S          259
ma1-2                   cfm-policer1 other    G          300
```

**show oam ethernet  
connectivity-fault  
-management  
policer  
maintenance-domain  
md-name  
maintenance-association  
ma-name**

Displays the policer information for the specified **maintenance-domain *md-name*** and **maintenance-association *ma-name***.

```
show oam ethernet connectivity-fault-management policer maintenance-domain md5
maintenance-association ma5
Legend for Policer
G - Global scope
S - Service scope
cc - Continuity check

Maintenance Domain: md5 Level: 5
Maintenance association Policer      Type      Scope Drop count
ma5                     cfm-policer cc       S          187
ma5                     cfm-policer-2 other    S          234
```



## show oam ethernet evc

<b>Syntax</b>	<b>show oam ethernet evc &lt;evc-id&gt;</b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.5.
<b>Description</b>	On MX Series routers with OAM Ethernet Virtual Connection (EVC) configurations, displays the EVC configuration and status information.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	View
<b>Output Fields</b>	<a href="#">Table 57 on page 391</a> lists the output fields for the <b>show oam ethernet evc</b> command. Output fields are listed in the approximate order in which they appear.

**Table 57: show oam ethernet evc Output Fields**

Field Name	Field Description
<b>EVC identifier</b>	Header for the EVC information showing the EVC name, configuration, and active/inactive status.
<b>UNI count</b>	Number of configured and active UNIs.
<b>Protocol</b>	Protocol configured between the UNIs.
<b>Local UNIs</b>	Heading for the list of local UNIs
<b>UNI Identifier</b>	Name of the UNI.
<b>Interface</b>	Interface type-dpc/pic/port.unit-number.
<b>Status</b>	Status operational or not operational.

## Sample Output

```

show oam ethernet evc  user@host> show oam ethernet evc
                        EVC identifier: evc1, Point-to-Point, Active
                        UNI count: Configured(2), Active(2)
                        Protocol: cfm, Management domain: md, Management association: ma
                        Local UNIs:
                          UNI Identifier      Interface      Status
                          uni1                 ge-1/1/1      Operational
                          uni2                 ge-1/1/1      Not Operational

```

## show oam ethernet fnp interface

<b>Syntax</b>	<b>show oam ethernet fnp interface</b> <i>&lt;ethernet-interface-name&gt;</i> <i>&lt;routing-instance routing-instance-name&gt;</i>
<b>Release Information</b>	Command introduced in Junos OS Release 11.4.
<b>Description</b>	On MX Series routers with Gigabit Ethernet, Fast Ethernet, or aggregated Ethernet PICs, displays OAM Ethernet Failure Notification Protocol (FNP) information for Ethernet interfaces.
<b>Options</b>	<i>interface-name</i> —(Optional) Display Ethernet FNP information for the specified Ethernet interface only.  <i>routing-instance-name</i> —(Optional) Display FNP for the specified routing instance.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show oam ethernet fnp interface on page 392</a>
<b>Output Fields</b>	<a href="#">Table 58 on page 392</a> lists the output fields for the <b>show oam ethernet fnp interface</b> command. Output fields are listed in the approximate order in which they appear.

**Table 58: show oam ethernet fnp interface Output Fields**

Field Name	Field Description
<b>Interface</b>	Name of the interface for the displayed information.
<b>VLAN</b>	Name of the VLAN.
<b>State</b>	Displays state of the interface.
<b>FNP Message Interface</b>	Displays the message interface type.
<b>FNP Message Source MAC</b>	Displays the source MAC address.

## Sample Output

```

show oam ethernet fnp interface
user@host> show oam ethernet fnp interface
The FNP controlled interfaces are:
Interface    VLAN    State    FNP message    FNP message
Interface    Source MAC
ge-0/0/0.30  30      down    1si.1054976    a0:aa:aa:aa:aa:aa
ge-0/0/0.20  20      down    1si.1054976    a0:aa:aa:aa:aa:aa

```

## show oam ethernet fnp messages

<b>Syntax</b>	<b>show oam ethernet fnp messages</b> <b>&lt;interface <i>interface-name</i>&gt;</b> <b>&lt;routing instance <i>routing-instance-name</i>&gt;</b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.4
<b>Description</b>	On MX Series routers with Gigabit Ethernet, Fast Ethernet, or aggregated Ethernet PICs, displays OAM Ethernet Failure Notification Protocol (FNP) messages.
<b>Options</b>	<b><i>interface-name</i></b> —(Optional) Display Ethernet FNP messages for the specified Ethernet interface only.  <b><i>routing-instance-name</i></b> —(Optional) Display FNP messages for the specified routing instance.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show oam ethernet fnp messages on page 394</a>
<b>Output Fields</b>	<a href="#">Table 59 on page 393</a> lists the output fields for the <b>show oam ethernet fnp messages</b> command. Output fields are listed in the approximate order in which they appear.

**Table 59: show oam ethernet fnp messages Output Fields**

Field Name	Field Description
Message from source MAC address	The source MAC address of the message.
Originating port number	Port number of the original message.
Time since last message	Elapsed time in hours, minutes, and seconds since the last message was received.
Time since last message update	Elapsed time in hours, minutes, and seconds since the last message was updated.
Total messages received	Number of messages received.
Domain ID	Domain ID of the message.
STP Root ID	The spanning tree Root ID of the message.
Trigger Reason	The reason why the message was triggered.
Effectuated VLANs	Number of VLANs that are affected.
Disabled interfaces	Name of the interfaces that are disabled.

## Sample Output

```
show oam ethernet fnp messages user@host> show oam ethernet fnp messages
Active FNP messages on interface lsi.1054465
Message source MAC: a0:aa:aa:aa:aa:aa
Originating port number: 141077
Time since last message: 00:00:00
Time since last message update: 00:00:00
Total messages received: 1
Domain ID: 0
STP Root ID: 0.f0:ff:ff:ff:ff:ff
Trigger reason: todo
Effectuated VLANs: 10
Disabled interfaces:
  Interface VLAN
  ge-0/0/0.10 10
```

## show oam ethernet fnp status

<b>Syntax</b>	<b>show oam ethernet fnp status</b> <b>&lt;interface <i>interface-name</i>&gt;</b> <b>&lt;routing instance <i>routing-instance-name</i>&gt;</b>
<b>Release Information</b>	Command introduced in Junos OS Release 11.4
<b>Description</b>	On MX Series routers with Gigabit Ethernet, Fast Ethernet, or aggregated Ethernet PICs, displays OAM Ethernet Failure Notification Protocol (FNP) status.
<b>Options</b>	<b><i>interface-name</i></b> —(Optional) Display Ethernet FNP information for the specified Ethernet interface only.  <b><i>routing-instance-name</i></b> —(Optional) Display FNP for the specified routing instance.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show oam ethernet fnp status on page 396</a>
<b>Output Fields</b>	<a href="#">Table 60 on page 395</a> lists the output fields for the <b>show oam ethernet fnp status</b> command. Output fields are listed in the approximate order in which they appear.

**Table 60: show oam ethernet fnp status Output Fields**

Field Name	Field Description
<b>FNP interval</b>	The time interval between messages.
<b>Loss threshold</b>	The number of messages that can be lost before FNP is marked as down.
<b>FNP enabled interfaces</b>	Displays interfaces that are enabled.
<b>Interface</b>	The name of the interface.
<b>Domain ID</b>	Domain ID of the message.
<b>STP Root ID</b>	The spanning tree Root ID of the message.
<b>FNP Messages</b>	The total number of messages received.

## Sample Output

```
show oam ethernet fnp status      user@host> show oam ethernet status
FNP interval:
Loss threshold
FNP enabled interfaces
Interface      Domain ID      STP Root ID      FNP Messages
ge-0/0/0.1278      100      0.f0:ff:ff:ff:ff:ff      0
```

## show oam ethernet link-fault-management

<b>Syntax</b>	show oam ethernet link-fault-management <brief   detail> <interface-name>
<b>Release Information</b>	Command introduced in Junos OS Release 8.2.
<b>Description</b>	On M320, M120, MX Series, T320, and T640 routers, display Operation, Administration, and Management (OAM) link fault management information for Ethernet interfaces.
<b>Options</b>	<b>brief   detail</b> —(Optional) Display the specified level of output.  <b>interface-name</b> —(Optional) Display link fault management information for the specified Ethernet interface only.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show oam ethernet link-fault-management brief on page 402</a> <a href="#">show oam ethernet link-fault-management detail on page 402</a>
<b>Output Fields</b>	<a href="#">Table 61 on page 397</a> lists the output fields for the <b>show oam ethernet link-fault-management</b> command. Output fields are listed in the approximate order in which they appear.

**Table 61: show oam ethernet link-fault-management Output Fields**

Field Name	Field Description	Level of Output
<b>Status</b>	Indicates the status of the established link.  <ul style="list-style-type: none"> <li>• <b>Fail</b>—A link fault condition exists.</li> <li>• <b>Running</b>—A link fault condition does not exist.</li> </ul>	All levels
<b>Discovery state</b>	State of the discovery mechanism:  <ul style="list-style-type: none"> <li>• <b>Passive Wait</b></li> <li>• <b>Send Any</b></li> <li>• <b>Send Local Remote</b></li> <li>• <b>Send Local Remote Ok</b></li> <li>• <b>Fault</b></li> </ul>	All levels
<b>Peer address</b>	Address of the OAM peer.	All levels

Table 61: show oam ethernet link-fault-management Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Flags</b>	<p>Information about the interface. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a>.</p> <ul style="list-style-type: none"> <li>• <b>Remote-Stable</b>—Indicates remote OAM client acknowledgment of and satisfaction with local OAM state information. <b>False</b> indicates that remote DTE either has not seen or is unsatisfied with local state information. <b>True</b> indicates that remote DTE has seen and is satisfied with local state information.</li> <li>• <b>Local-Stable</b>—Indicates local OAM client acknowledgment of and satisfaction with remote OAM state information. <b>False</b> indicates that local DTE either has not seen or is unsatisfied with remote state information. <b>True</b> indicates that local DTE has seen and is satisfied with remote state information.</li> <li>• <b>Remote-State-Valid</b>—Indicates the OAM client has received remote state information found within Local Information TLVs of received Information OAM PDUs. <b>False</b> indicates that OAM client has not seen remote state information. <b>True</b> indicates that the OAM client has seen remote state information.</li> </ul>	All levels
<b>Remote loopback status</b>	Indicates the remote loopback status. An OAM entity can put its remote peer into loopback mode using the Loopback control OAM PDU. In loopback mode, every frame received is transmitted back on the same port (except for OAM PDUs, which are needed to maintain the OAM session).	All levels
<b>Remote entity information</b>	<p>Remote entity information.</p> <ul style="list-style-type: none"> <li>• <b>Remote MUX action</b>—Indicates the state of the multiplexer functions of the OAM sublayer. Device is forwarding non-OAM PDUs to the lower sublayer or discarding non-OAM PDUs.</li> <li>• <b>Remote parser action</b>—Indicates the state of the parser function of the OAM sublayer. Device is forwarding non-OAM PDUs to higher sublayer, looping back non-OAM PDUs to the lower sublayer, or discarding non-OAM PDUs.</li> <li>• <b>Discovery mode</b>—Indicates whether discovery mode is active or inactive.</li> <li>• <b>Unidirectional mode</b>—Indicates the ability to operate a link in a unidirectional mode for diagnostic purposes.</li> <li>• <b>Remote loopback mode</b>—Indicates whether remote loopback is supported or unsupported.</li> <li>• <b>Link events</b>—Indicates whether interpreting link events is supported or unsupported on the remote peer.</li> <li>• <b>Variable requests</b>—Indicates whether variable requests are supported. The Variable Request OAM PDU, is used to request one or more MIB variables from the remote peer.</li> </ul>	All levels
<b>OAM Receive Statistics</b>		
<b>Information</b>	The total number of information PDUs received.	<b>detail</b>
<b>Event</b>	The total number of loopback control PDUs received.	<b>detail</b>
<b>Variable request</b>	The total number of variable request PDUs received.	<b>detail</b>
<b>Variable response</b>	The total number of variable response PDUs received.	<b>detail</b>



Table 61: show oam ethernet link-fault-management Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Loopback control</b>	The total number of loopback control PDUs received.	<b>detail</b>
<b>Organization specific</b>	The total number of vendor organization specific PDUs received.	<b>detail</b>
<b>OAM Transmit Statistics</b>		
<b>Information</b>	The total number of information PDUs transmitted.	<b>detail</b>
<b>Event</b>	The total number of event notification PDUs transmitted.	<b>detail</b>
<b>Variable request</b>	The total number of variable request PDUs transmitted.	<b>detail</b>
<b>Variable response</b>	The total number of variable response PDUs transmitted.	<b>detail</b>
<b>Loopback control</b>	The total number of loopback control PDUs transmitted.	<b>detail</b>
<b>Organization specific</b>	The total number of vendor organization specific PDUs transmitted.	<b>detail</b>
<b>OAM Received Symbol Error Event information</b>		
<b>Events</b>	The number of symbol error event TLVs that have been received since the OAM sublayer was reset.	<b>detail</b>
<b>Window</b>	The symbol error event window in the received PDU.  The protocol default value is the number of symbols that can be received in one second on the underlying physical layer.	<b>detail</b>
<b>Threshold</b>	The number of errored symbols in the period required for the event to be generated.	<b>detail</b>
<b>Errors in period</b>	The number of symbol errors in the period reported in the received event PDU.	<b>detail</b>
<b>Total errors</b>	The number of errored symbols that have been reported in received event TLVs since the OAM sublayer was reset.  Symbol errors are coding symbol errors.	<b>detail</b>
<b>OAM Received Frame Error Event Information</b>		
<b>Events</b>	The number of errored frame event TLVs that have been received since the OAM sublayer was reset.	<b>detail</b>
<b>Window</b>	The duration of the window in terms of the number of 100 ms period intervals.	<b>detail</b>
<b>Threshold</b>	The number of detected errored frames required for the event to be generated.	<b>detail</b>
<b>Errors in period</b>	The number of detected errored frames in the period.	<b>detail</b>

Table 61: show oam ethernet link-fault-management Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Total errors</b>	The number of errored frames that have been reported in received event TLVs since the OAM sublayer was reset.  A frame error is any frame error on the underlying physical layer.	<b>detail</b>
<b>OAM Received Frame Period Error Event Information</b>		
<b>Events</b>	The number of frame seconds errors event TLVs that have been received since the OAM sublayer was reset.	<b>detail</b>
<b>Window</b>	The duration of the frame seconds window.	<b>detail</b>
<b>Threshold</b>	The number of frame seconds errors in the period.	<b>detail</b>
<b>Errors in period</b>	The number of frame seconds errors in the period.	<b>detail</b>
<b>Total errors</b>	The number of frame seconds errors that have been reported in received event TLVs since the OAM sublayer was reset.	<b>detail</b>
<b>OAM Transmitted Symbol Error Event Information</b>		
<b>Events</b>	The number of symbol error event TLVs that have been transmitted since the OAM sublayer was reset.	<b>detail</b>
<b>Window</b>	The symbol error event window in the transmitted PDU.	<b>detail</b>
<b>Threshold</b>	The number of errored symbols in the period required for the event to be generated.	<b>detail</b>
<b>Errors in period</b>	The number of symbol errors in the period reported in the transmitted event PDU.	<b>detail</b>
<b>Total errors</b>	The number of errored symbols reported in event TLVs that have been transmitted since the OAM sublayer was reset.	<b>detail</b>
<b>OAM Current Symbol Error Event Information</b>		
<b>Events</b>	The number of symbol error TLVs that have been generated regardless of whether the threshold for sending event TLVs has been crossed.	<b>detail</b>
<b>Window</b>	The symbol error event window in the transmitted PDU.	<b>detail</b>
<b>Threshold</b>	The number of errored symbols in the period required for the event to be generated.	<b>detail</b>
<b>Errors in period</b>	The total number of symbol errors in the period reported.	<b>detail</b>
<b>Total errors</b>	The number of errored symbols reported in event TLVs that have been generated regardless of whether the threshold for sending event TLVs has been crossed.	<b>detail</b>
<b>OAM Transmitted Frame Error Event Information</b>		

Table 61: show oam ethernet link-fault-management Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Events</b>	The number of errored frame event TLVs that have been transmitted since the OAM sublayer was reset.	<b>detail</b>
<b>Window</b>	The duration of the window in terms of the number of 100 ms period intervals.	<b>detail</b>
<b>Threshold</b>	The number of detected errored frames required for the event to be generated.	<b>detail</b>
<b>Errors in period</b>	The number of detected errored frames in the period.	<b>detail</b>
<b>Total errors</b>	The number of errored frames that have been detected since the OAM sublayer was reset.	<b>detail</b>
<b>OAM Current Frame Error Event Information</b>		
<b>Events</b>	The number of errored frame event TLVs that have been generated regardless of whether the threshold for sending event TLVs has been crossed.	<b>detail</b>
<b>Window</b>	The duration of the window in terms of the number of 100 ms period intervals.	<b>detail</b>
<b>Threshold</b>	The number of detected errored frames required for the event to be generated.	<b>detail</b>
<b>Errors in period</b>	The number of errored frames in the period.	<b>detail</b>
<b>Total errors</b>	The number of errored frames detected regardless of whether the threshold for transmitting event TLVs has been crossed.	<b>detail</b>

## Sample Output

**show oam ethernet  
link-fault-management  
brief**

```
user@host> show oam ethernet link-fault-management brief
Interface: ge-3/1/3
Status: Running, Discovery state: Send Any
Peer address: 00:90:69:72:2c:83
Flags:Remote-Stable Remote-State-Valid Local-Stable 0x50
Remote loopback status: Disabled on local port, Enabled on peer port
Remote entity information:
  Remote MUX action: discarding, Remote parser action: loopback
  Discovery mode: active, Unidirectional mode: unsupported
  Remote loopback mode: supported, Link events: supported
  Variable requests: unsupported
```

**show oam ethernet  
link-fault-management  
detail**

```
user@host> show oam ethernet link-fault-management detail
Interface: ge-6/1/0
Status: Running, Discovery state: Send Any
Peer address: 00:90:69:0a:07:14
Flags:Remote-Stable Remote-State-Valid Local-Stable 0x50
OAM receive statistics:
  Information: 186365, Event: 0, Variable request: 0, Variable response: 0
  Loopback control: 0, Organization specific: 0
OAM transmit statistics:
  Information: 186347, Event: 0, Variable request: 0, Variable response: 0
  Loopback control: 0, Organization specific: 0
OAM received symbol error event information:
  Events: 0, Window: 0, Threshold: 0
  Errors in period: 0, Total errors: 0
OAM received frame error event information:
  Events: 0, Window: 0, Threshold: 0
  Errors in period: 0, Total errors: 0
OAM received frame period error event information:
  Events: 0, Window: 0, Threshold: 0
  Errors in period: 0, Total errors: 0
OAM transmitted symbol error event information:
  Events: 0, Window: 0, Threshold: 1
  Errors in period: 0, Total errors: 0
OAM current symbol error event information:
  Events: 0, Window: 0, Threshold: 1
  Errors in period: 0, Total errors: 0
OAM transmitted frame error event information:
  Events: 0, Window: 0, Threshold: 1
  Errors in period: 0, Total errors: 0
OAM current frame error event information:
  Events: 0, Window: 0, Threshold: 1
  Errors in period: 0, Total errors: 0
Remote entity information:
  Remote MUX action: forwarding, Remote parser action: forwarding
  Discovery mode: active, Unidirectional mode: unsupported
  Remote loopback mode: supported, Link events: supported
  Variable requests: unsupported
```

## show oam ethernet lmi

<b>Syntax</b>	<b>show oam ethernet lmi (interface &lt;interface-name&gt;)</b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.5.
<b>Description</b>	On MX Series routers with Gigabit Ethernet, Fast Ethernet, or aggregated Ethernet, and OAM Ethernet Local Management Interface (LMI) configuration, display the LMI information for the configured interfaces or optionally for a specified interface.
<b>Options</b>	<b>interface</b> —(Optional) Display LMI information for a specified interface. <b>interface-name</b> —(Optional) Display Ethernet LMI information for the specified interface only.
<b>Required Privilege Level</b>	View
<b>Output Fields</b>	Table 62 on page 403 lists the output fields for the <b>show oam ethernet lmi</b> command. Output fields are listed in the approximate order in which they appear.

**Table 62: show oam ethernet lmi Output Fields**

Field Name	Field Description
Physical Interface	Header for the EVC information showing the Ethernet virtual circuit (EVC) name, configuration, and active/inactive status.
UNI Identifier	Name of the UNI.
EVC map type	EVC configuration.
Polling verification timer	Polling verification timer status.
E-LMI state	Operational status of the E-LMI configuration in the interfaces or specified interface.
Priority/Untagged VLAN ID	To be provided.
Default EVC	The EVC set as the default EVC.
Associated EVCs	Heading for the list of configured EVCs.
EVC Identifier	EVC name.
Reference ID	To be provided.
Status	Status active or not active.
CE VLAN IDs	Customer edge VLAN ID numbers.

## Sample Output

```
show oam ethernet lmi interface
user@host> show oam ethernet lmi interface ge-1/1/1
Physical interface: ge-1/1/1, Physical link is Up
UNI identifier: uni-ce1, EVC map type: Bundling
Polling verification timer: Enabled, E-LMI state: Operational
Priority/Untagged VLAN ID: 20, Default EVC: evc1
Associated EVCs:
  EVC      Reference      Status      CE VLAN IDs
  Identifier ID
  evc1      1      Active (New)      1-2048
  evc2      2      Not Active      2049-4096
```

## show oam ethernet lmi statistics

<b>Syntax</b>	<b>show oam ethernet lmi statistics</b> <interface <i>interface-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 9.5.
<b>Description</b>	On MX Series routers with Gigabit Ethernet, Fast Ethernet, or aggregated Ethernet PICs, displays OAM Ethernet Local Management Interface (LMI) statistics.
<b>Options</b>	<p><b>interface</b>—(Optional) Display LMI statistics for a specified interface.</p> <p><b>interface-name</b>—(Optional) Display Ethernet LMI information for the specified Ethernet interface only.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show oam ethernet lmi statistics on page 406</a>
<b>Output Fields</b>	<a href="#">Table 63 on page 405</a> lists the output fields for the <b>show oam ethernet lmi statistics</b> command. Output fields are listed in the approximate order in which they appear.

**Table 63: show oam ethernet lmi statistics Output Fields**

Field Name	Field Description
Physical interface	Name of the interface for the displayed statistics.
Reliability errors	Number of E-LMI reliability errors logged.
Protocol errors	Number of E-LMI protocol errors.
Status check received	Number of E-LMI status check receive errors.
Status check sent	Number of E-LMI status check sent errors.
Full status received	Number of E-LMI full status receive errors.
Full status sent	Number of E-LMI full status sent errors.
Full status continued received	Number of E-LMI status continued received errors.
Full status continued sent	Number of E-LMI full status continued sent errors.
Asynchronous status sent	Number of E-LMI asynchronous status sent errors.

## Sample Output

```
show oam ethernet lmi statistics
statistics
user@host> show oam ethernet lmi statistics interface ge-1/1/1
Physical interface: ge-1/1/1
  Reliability errors                4  Protocol errors
  0
  Status check received            0  Status check sent
  0
  Full status received            694  Full status sent
694
  Full status continued received    0  Full status continued sent
  0
  Asynchronous status sent         0
```



## show protection-group ethernet-ring aps

<b>Syntax</b>	<b>show protection-group ethernet-ring aps</b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.4. Command introduced in Junos OS Release 12.1 for EX Series switches.
<b>Description</b>	Display the status of the Automatic Protection Switching (APS) and Ring APS (RAPS) messages on an Ethernet ring.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show protection-group ethernet-ring data-channel on page 409</a></li> <li>• <a href="#">show protection-group ethernet-ring interface on page 411</a></li> <li>• <a href="#">show protection-group ethernet-ring node-state on page 414</a></li> <li>• <a href="#">show protection-group ethernet-ring statistics on page 417</a></li> <li>• <a href="#">show protection-group ethernet-ring vlan on page 420</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show protection-group ethernet-ring aps (EX Switches) on page 408</a> <a href="#">show protection-group ethernet-ring aps (Owner Node, Normal Operation on MX Routers) on page 408</a> <a href="#">show protection-group ethernet-ring aps (Ring Node, Normal Operation on MX Routers) on page 408</a> <a href="#">show protection-group ethernet-ring aps (Owner Node, Failure Condition on MX Routers) on page 408</a> <a href="#">show protection-group ethernet-ring aps (Ring Node, Failure Condition on MX Routers) on page 408</a>
<b>Output Fields</b>	<a href="#">Table 64 on page 407</a> lists the output fields for the <b>show protection-group ethernet-ring aps</b> command. Output fields are listed in the approximate order in which they appear.

**Table 64: show protection-group ethernet-ring aps Output Fields**

Field Name	Field Description
<b>Ethernet Ring Name</b>	Name configured for the Ethernet ring.
<b>Request/State</b>	Status of the Ethernet ring RAPS messages. <ul style="list-style-type: none"> <li>• <b>NR</b>—Indicates there is no request for APS on the ring.</li> <li>• <b>SF</b>—Indicates there is a signal failure on the ring.</li> </ul>
<b>No Flush</b>	State of the ring flushing: <b>No</b> (normal) or <b>Yes</b> (failure).
<b>Ring Protection Link Blocked</b>	Blocking on the ring protection link: <b>Yes</b> or <b>No</b> .

Table 64: show protection-group ethernet-ring aps Output Fields (*continued*)

Field Name	Field Description
Originator	Whether this node is the ring originator: <b>Yes</b> or <b>No</b> .
Remote Node ID	Identifier (in MAC address format) of the remote node.

## Sample Output

show protection-group  
ethernet-ring aps (EX  
Switches)

```
user@switch>> show protection-group ethernet-ring aps
Ring Name      Request/state No Flush  RPL Blocked Originator Remote Node ID
erp1           NR           no        yes        no          00:1F:12:30:B8:81
```

## Sample Output

show protection-group  
ethernet-ring aps  
(Owner Node, Normal  
Operation on MX  
Routers)

```
user@host> show protection-group ethernet-ring aps
Ethernet Ring Name Request/state No Flush Ring Protection Link Blocked
pg101              NR           No        Yes

Originator Remote Node ID
Yes
```

show protection-group  
ethernet-ringaps (Ring  
Node, Normal  
Operation on MX  
Routers)

```
user@host> show protection-group ethernet-ring aps
Ethernet Ring Name Request/state No Flush Ring Protection Link Blocked
pg102              NR           No        Yes

Originator Remote Node ID
No          00:01:01:00:00:01
```

show protection-group  
ethernet-ring aps  
(Owner Node, Failure  
Condition on MX  
Routers)

```
user@host> show protection-group ethernet-ring aps
Ethernet Ring Name Request/state No Flush Ring Protection Link Blocked
pg101              SF           No        No

Originator Remote Node ID
No          00:01:02:00:00:01
```

show protection-group  
ethernet-ringaps (Ring  
Node, Failure Condition  
on MX Routers)

```
user@host> show protection-group ethernet-ring aps
Ethernet Ring Name Request/state No Flush Ring Protection Link Blocked
pg102              SF           No        Yes

Originator Remote Node ID
Yes         00:00:00:00:00:00
```

## show protection-group ethernet-ring data-channel

<b>Syntax</b>	show protection-group ethernet-ring data-channel <brief   detail> <group-name <i>group-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 10.2.
<b>Description</b>	On MX Series routers, display data channel information for all Ethernet ring protection groups or for a specific Ethernet ring protection group.
<b>Options</b>	<b>brief   detail</b> —(Optional) Display the specified level of output.  <b>group-name</b> —(Optional) Protection group for which to display statistics. If you omit this optional field, all protection group statistics for configured groups will be displayed.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show protection-group ethernet-ring aps on page 407</a></li> <li>• <a href="#">show protection-group ethernet-ring interface on page 411</a></li> <li>• <a href="#">show protection-group ethernet-ring node-state on page 414</a></li> <li>• <a href="#">show protection-group ethernet-ring statistics on page 417</a></li> <li>• <a href="#">show protection-group ethernet-ring vlan on page 420</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show protection-group ethernet-ring data-channel on page 410</a>
<b>Output Fields</b>	<a href="#">Table 65 on page 409</a> lists the output fields for the <b>show protection-group ethernet-ring data-channel</b> command. Output fields are listed in the approximate order in which they appear.

**Table 65: show protection-group ethernet-ring data-channel Output Fields**

Field Name	Field Description
<b>Interface</b>	Name of the interface configured for the Ethernet ring.
<b>STP index</b>	The Spanning Tree Protocol (STP) index number used by each interface in an Ethernet ring. The STP index controls the forwarding behavior for a set of VLANs on a data channel on an Ethernet ring port. For multiple Ethernet ring instances on a physical ring port, there are multiple STP index numbers. Different ring instances will have different STP index numbers and may have different forwarding behavior.
<b>Forward State</b>	Forwarding state on the Ethernet ring. <ul style="list-style-type: none"> <li>• <b>fowarding</b>—Indicates packets are being forwarded.</li> <li>• <b>discarding</b>—Indicates packets are being discarded.</li> </ul>

## Sample Output

```
show protection-group ethernet-ring data-channel
user@host> show protection-group ethernet-ring data-channel
Ethernet ring data channel information for protection group pg301
Interface    STP index    Forward State
ge-1/0/3     71           forwarding
ge-1/0/4     82           forwarding

Ethernet ring data channel information for protection group pg302
Interface    STP index    Forward State
ge-1/0/3     52           forwarding
ge-1/0/4     91           forwarding
```

## show protection-group ethernet-ring interface

<b>Syntax</b>	<b>show protection-group ethernet-ring interface</b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.4.
<b>Description</b>	Displays the status of the Automatic Protection Switching (APS) interfaces on an Ethernet ring.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show protection-group ethernet-ring data-channel on page 409</a></li> <li>• <a href="#">show protection-group ethernet-ring aps on page 407</a></li> <li>• <a href="#">show protection-group ethernet-ring node-state on page 414</a></li> <li>• <a href="#">show protection-group ethernet-ring statistics on page 417</a></li> <li>• <a href="#">show protection-group ethernet-ring vlan on page 420</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show protection-group ethernet-ring interface (EX Series Switch Owner Node) on page 412</a> <a href="#">show protection-group ethernet-ring interface (Owner Node MX Series Router ) on page 412</a> <a href="#">show protection-group ethernet-ring interface (EX Series Switch Ring Node) on page 412</a> <a href="#">show protection-group ethernet-ring interface (MX Series Router Ring Node) on page 412</a>
<b>Output Fields</b>	Table 66 on page 411 lists the output fields for both the EX Series switch and the MX Series router <b>show protection-group ethernet-ring interface</b> commands. Output fields are listed in the approximate order in which they appear.

**Table 66: MX Series Routers show protection-group ethernet-ring interface Output Fields**

Field Name	Field Description
Ethernet ring port parameters for protection group <i>group-name</i>	Output is organized by configured protection group.
Interface	Physical interfaces configured for the Ethernet ring.
Control Channel	(MX Series router only) Logical unit configured on the physical interface. <ul style="list-style-type: none"> <li>• <b>NR</b>—Indicates there is no request for APS on the ring.</li> <li>• <b>SF</b>—Indicates there is a signal failure on the ring.</li> </ul>
Forward State	State of the ring forwarding on the interface: <b>discarding</b> or <b>forwarding</b> .

Table 66: MX Series Routers show protection-group ethernet-ring interface Output Fields (*continued*)

Field Name	Field Description
Ring Protection Link End	Whether this interface is the end of the ring: <b>Yes</b> or <b>No</b> .
Signal Failure	Whether there a signal failure exists on the link: <b>Clear</b> or <b>Set</b> .
Admin State	State of the interface: For EX switches, <b>ready</b> , <b>ifl ready</b> , or <b>waiting</b> . For MX routers, <b>IFF ready</b> or <b>IFF disabled</b> .

## Sample Output

**show protection-group ethernet-ring interface**  
(EX Series Switch Owner Node)

```
user@host> show protection-group ethernet-ring interface
Ethernet ring port parameters for protection group pg101

Interface      Forward State  RPL End  Signal Failure  Admin State
ge-0/0/3.0     discarding    Yes      Clear          ready
ge-0/0/9.0     forwarding    No       Clear          ready
```

**show protection-group ethernet-ring interface**  
(Owner Node MX Series Router )

```
user@host> show protection-group ethernet-ring interface
Ethernet ring port parameters for protection group pg101

Interface      Control Channel Forward State  Ring Protection Link End
ge-1/0/1       ge-1/0/1.1     discarding    Yes
ge-1/2/4       ge-1/2/4.1     forwarding    No

Signal Failure  Admin State
Clear          IFF ready
Clear          IFF ready
```

**show protection-group ethernet-ring interface**  
(EX Series Switch Ring Node)

```
user@host> show protection-group ethernet-ring interface
Ethernet ring port parameters for protection group pg102

Ethernet ring port parameters for protection group pg101

Interface      Forward State  RPL End  Signal Failure  Admin State
ge-0/0/3.0     discarding    Yes      Clear          ready
ge-0/0/9.0     forwarding    No       Clear          ready
```

**show protection-group ethernet-ring interface**

```
user@host> show protection-group ethernet-ring interface
Ethernet ring port parameters for protection group pg102
```

(MX Series Router Ring Node)

Interface	Control Channel	Forward State	Ring Protection Link End
ge-1/2/1	ge-1/2/1.1	forwarding	No
ge-1/0/2	ge-1/0/2.1	forwarding	No

Signal Failure	Admin State
Clear	IFF ready
Clear	IFF ready

## show protection-group ethernet-ring node-state

<b>Syntax</b>	<b>show protection-group ethernet-ring node-state</b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.4. Command introduced in Junos OS Release 12.1 for EX Series switches.
<b>Description</b>	Display the status of the Automatic Protection Switching (APS) nodes on an Ethernet ring.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show protection-group ethernet-ring data-channel on page 409</a></li> <li>• <a href="#">show protection-group ethernet-ring aps on page 407</a></li> <li>• <a href="#">show protection-group ethernet-ring interface on page 411</a></li> <li>• <a href="#">show protection-group ethernet-ring statistics on page 417</a></li> <li>• <a href="#">show protection-group ethernet-ring vlan on page 420</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show protection-group ethernet-ring node-state (EX Series Switch) on page 415</a> <a href="#">show protection-group ethernet-ring node-state (Owner Node, Normal Operation on MX Series Router) on page 415</a> <a href="#">show protection-group ethernet-ring node-state (Ring Node, Normal Operation on MX Series Router) on page 415</a> <a href="#">show protection-group ethernet-ring node-state (Owner Node, Failure Condition on MX Series Router) on page 415</a> <a href="#">show protection-group ethernet-ring node-state (Ring Node, Failure Condition on MX Series Router) on page 415</a>
<b>Output Fields</b>	<a href="#">Table 67 on page 414</a> lists the output fields for the <b>show protection-group ethernet-ring node-state</b> command. Output fields are listed in the approximate order in which they appear.

**Table 67: show protection-group ethernet-ring node-state Output Fields**

Field Name	Field Description
<b>Ring Name</b>	Name configured for the Ethernet ring.
<b>APS State</b>	State of the Ethernet ring APS. <ul style="list-style-type: none"> <li>• <b>idle</b>—Indicates there is no APS on the ring.</li> <li>• <b>protected</b>—Indicates there is a protection switch on the ring.</li> </ul>



Table 67: show protection-group ethernet-ring node-state Output Fields (*continued*)

Field Name	Field Description
Event	Events on the ring. <ul style="list-style-type: none"> <li>• <b>NR-RB</b>—Indicates there is no APS request and the ring link is blocked on the ring owner node.</li> <li>• <b>NR</b>—Indicates there is no APS request on the ring non-owner nodes.</li> <li>• <b>SF</b>—Indicates there is signal failure on a node link.</li> </ul>
Ring Protection Link Owner	Whether this node is the ring owner: <b>Yes</b> or <b>No</b> .
Restore Timer (WTR Timer)	Restoration timer: <b>Enabled</b> or <b>Disabled</b> .
Guard Timer	Guard timer: <b>Enabled</b> or <b>Disabled</b> .
Operational State	State of the node: <b>Operational</b> or <b>Non-operational</b> .

## Sample Output

```
show protection-group ethernet-ring node-state (EX Series Switch)
user@switch> show protection-group ethernet-ring node-state
Ring Name APS State Event RPL Owner WTR Timer Guard Timer Op State
erp1 idle NR-RB yes disabled disabled operational
```

```
show protection-group ethernet-ring node-state (Owner Node, Normal Operation on MX Series Router)
user@host> show protection-group ethernet-ring node-state
Ethernet ring APS State Event Ring Protection Link Owner
pg101 idle NR-RB Yes

Restore Timer Quard Timer Operation state
disabled disabled operational
```

```
show protection-group ethernet-ring node-state (Ring Node, Normal Operation on MX Series Router)
user@host> show protection-group ethernet-ring node-state
Ethernet ring APS State Event Ring Protection Link Owner
pg102 idle NR-RB No

Restore Timer Quard Timer Operation state
disabled disabled operational
```

```
show protection-group ethernet-ring node-state (Owner Node, Failure Condition on MX Series Router)
user@host> show protection-group ethernet-ring node-state
Ethernet ring APS State Event Ring Protection Link Owner
pg101 protected SF Yes

Restore Timer Quard Timer Operation state
disabled disabled operational
```

```
show protection-group ethernet-ring
user@host> show protection-group ethernet-ring node-state
Ethernet ring APS State Event Ring Protection Link Owner
pg102 idle NR-RB No
```

node-state (Ring Node,  
Failure Condition on  
MX Series Router)

Restore Timer	Quard Timer	Operation state
disabled	disabled	operational

## show protection-group ethernet-ring statistics

<b>Syntax</b>	<b>show protection-group ethernet-ring statistics</b> <group-name <i>group-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 9.4. Command introduced in Junos OS Release 12.1 for EX Series switches.
<b>Description</b>	Display statistics regarding Automatic Protection Switching (APS) protection groups on an Ethernet ring.
<b>Options</b>	<b>group-name</b> —Protection group for which to display statistics. In you omit this optional field, all protection group statistics for configured groups will be displayed.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show protection-group ethernet-ring data-channel on page 409</a></li> <li>• <a href="#">show protection-group ethernet-ring aps on page 407</a></li> <li>• <a href="#">show protection-group ethernet-ring node-state on page 414</a></li> <li>• <a href="#">show protection-group ethernet-ring interface on page 411</a></li> <li>• <a href="#">show protection-group ethernet-ring vlan on page 420</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show protection-group ethernet-ring statistics (EX Switch) on page 418</a> <a href="#">show protection-group ethernet-ring statistics (Owner Node, Normal Operation on MX Router) on page 418</a> <a href="#">show protection-group ethernet-ring statistics (Ring Node, Normal Operation on MX Router) on page 418</a> <a href="#">show protection-group ethernet-ring statistics (Owner Node, Failure Condition on MX Router) on page 418</a> <a href="#">show protection-group ethernet-ring statistics (Ring Node, Failure Condition on MX Router) on page 418</a>
<b>Output Fields</b>	<a href="#">Table 68 on page 417</a> lists the output fields for the <b>show protection-group ethernet-ring statistics</b> command. Output fields are listed in the approximate order in which they appear.

**Table 68: show protection-group ethernet-ring statistics Output Fields**

Field Name	Field Description
<b>Ethernet Ring Statistics for PG</b>	Name of the protection group for which statistics are displayed.
<b>RAPS sent</b>	Number of Ring Automatic Protection Switching (RAPS) messages sent. (On MX Series switches only)
<b>RAPS received</b>	Number of RAPS messages received. (On MX Series switches only)

Table 68: show protection-group ethernet-ring statistics Output Fields (*continued*)

Field Name	Field Description
<b>Local SF</b>	Number of times a signal failure (SF) has occurred locally.
<b>Remote SF</b>	Number of times a signal failure (SF) has occurred anywhere else on the ring.
<b>NR event</b>	Number of times a No Request (NR) event has occurred on the ring.
<b>NR-RB event</b>	Number of times a No Request, Ring Blocked (NR-RB) event has occurred on the ring.

## Sample Output

**show protection-group  
ethernet-ring statistics  
(EX Switch)**

```
user@switch> show protection-group ethernet-ring statistics
Ring Name Local SF Remote SF NR Event NR-RB Event
erp1      2      1      2      3
```

**show protection-group  
ethernet-ring statistics  
(Owner Node, Normal  
Operation on MX  
Router)**

```
user@host> show protection-group ethernet-ring statistics group-name pg101
Ethernet Ring statistics for PG pg101
RAPS sent : 1
RAPS received : 0
Local SF happened: : 0
Remote SF happened: : 0
NR event happened: : 0
NR-RB event happened: : 1
```

**show protection-group  
ethernet-ring statistics  
(Ring Node, Normal  
Operation on MX  
Router)**

```
user@host> show protection-group ethernet-ring statistics group-name pg102
Ethernet Ring statistics for PG pg102
RAPS sent : 0
RAPS received : 1
Local SF happened: : 0
Remote SF happened: : 0
NR event happened: : 0
NR-RB event happened: : 1
```

**show protection-group  
ethernet-ring statistics  
(Owner Node, Failure  
Condition on MX  
Router)**

```
user@host> show protection-group ethernet-ring statistics group-name pg101
Ethernet Ring statistics for PG pg101
RAPS sent : 1
RAPS received : 1
Local SF happened: : 0
Remote SF happened: : 1
NR event happened: : 0
NR-RB event happened: : 1
```

**show protection-group  
ethernet-ring statistics  
(Ring Node, Failure**

```
user@host> show protection-group ethernet-ring statistics group-name pg102
Ethernet Ring statistics for PG pg102
RAPS sent : 1
RAPS received : 1
```

Condition on MX Router)	Local SF happened:	: 1
	Remote SF happened:	: 0
	NR event happened:	: 0
	NR-RB event happened:	: 1

## show protection-group ethernet-ring vlan

<b>Syntax</b>	show protection-group ethernet-ring vlan <brief   detail> <group-name <i>group-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 10.2.
<b>Description</b>	On MX Series routers, display all data channel logical interfaces and the VLAN IDs controlled by a ring instance data channel.
<b>Options</b>	<b>brief   detail</b> —(Optional) Display the specified level of output.  <b>group-name</b> —(Optional) Protection group for which to display statistics. In you omit this optional field, all protection group statistics for configured groups will be displayed.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show protection-group ethernet-ring aps on page 407</a></li> <li>• <a href="#">show protection-group ethernet-ring data-channel on page 409</a></li> <li>• <a href="#">show protection-group ethernet-ring interface on page 411</a></li> <li>• <a href="#">show protection-group ethernet-ring node-state on page 414</a></li> <li>• <a href="#">show protection-group ethernet-ring statistics on page 417</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show protection-group ethernet-ring vlan on page 421</a> <a href="#">show protection-group ethernet-ring vlan brief on page 421</a> <a href="#">show protection-group ethernet-ring vlan detail on page 421</a> <a href="#">show protection-group ethernet-ring vlan group-name vkm01 on page 421</a>
<b>Output Fields</b>	Table 69 on page 420 lists the output fields for the <b>show protection-group ethernet-ring vlan</b> command. Output fields are listed in the approximate order in which they appear.

Table 69: show protection-group ethernet-ring vlan Output Fields

Field Name	Field Description
<b>Interface</b>	Name of the interface configured for the Ethernet protection ring.
<b>Vlan</b>	Name of the VLAN associated with the interface configured for the Ethernet protection ring.
<b>STP Index</b>	The Spanning Tree Protocol (STP) index number used by each interface in an Ethernet ring. The STP index controls the forwarding behavior for a set of VLANs on a data channel on an Ethernet ring port. For multiple Ethernet ring instances on a physical ring port, there are multiple STP index numbers. Different ring instances will have different STP index numbers and may have different forwarding behavior.

**Table 69: show protection-group ethernet-ring vlan Output Fields (continued)**

Field Name	Field Description
Bridge Domain	Name of the bridge domain that is associated with the VLAN configured for the Ethernet protection ring.

## Sample Output

### show protection-group ethernet-ring vlan

```
user@host> show protection-group ethernet-ring vlan
Ethernet ring IFBD parameters for protection group vkm01
```

Interface	Vlan	STP Index	Bridge Domain
ge-2/0/8	100	130	default-switch/bd100
ge-2/0/4	100	126	default-switch/bd100

### show protection-group ethernet-ring vlan brief

```
user@host> show protection-group ethernet-ring vlan brief
Ethernet ring IFBD parameters for protection group vkm01
```

Interface	Vlan	STP Index	Bridge Domain
ge-2/0/8	100	130	default-switch/bd100
ge-2/0/4	100	126	default-switch/bd100

### show protection-group ethernet-ring vlan detail

```
user@host> show protection-group ethernet-ring vlan detail
Ethernet ring IFBD parameters for protection group vkm01
```

```
Interface name      : ge-2/0/8
Vlan                : 100
STP index           : 130
Bridge Domain       : default-switch/bd100
Interface name      : ge-2/0/4
Vlan                : 100
STP index           : 126
Bridge Domain       : default-switch/bd100
```

### show protection-group ethernet-ring vlan group-name vkm01

```
user@host> show protection-group ethernet-ring vlan vkm01
Ethernet ring IFBD parameters for protection group vkm01
```

Interface	Vlan	STP Index	Bridge Domain
ge-2/0/8	100	130	default-switch/bd100
ge-2/0/4	100	126	default-switch/bd100

## traceroute ethernet

<b>Syntax</b>	<b>traceroute ethernet</b> ( <i>mac-address</i>   <i>mep-id</i> ) <b>maintenance-association</b> <i>ma-name</i> <b>maintenance-domain</b> <i>md-name</i> <b>ttl</b> <i>value</i> <b>&lt;wait seconds&gt;</b>
<b>Release Information</b>	Command introduced in Junos OS Release 9.0. <b>mep-id</b> option introduced in Junos OS Release 9.1.
<b>Description</b>	Triggers the linktrace protocol to trace the route between two maintenance points. The result of the traceroute protocol is stored in the path database. To display the path database, use the <b>show oam ethernet connectivity-fault-management path-database</b> command.  Before using the traceroute command, you can verify the remote MEP's MAC address using the <b>show oam ethernet connectivity-fault-management path-database</b> command.
<b>Options</b>	<b>mac-address</b> —Destination unicast MAC address of the remote maintenance point.  <b>mep-id</b> —MEP identifier of the remote maintenance point. The range of values is 1 through 8191.  <b>maintenance-association</b> <i>ma-name</i> —Specifies an existing maintenance association from the set of configured maintenance associations.  <b>maintenance-domain</b> <i>md-name</i> —Specifies an existing maintenance domain from the set of configured maintenance domains.  <b>ttl</b> <i>value</i> —Number of hops to use in the linktrace request. The range is 1 to 255 hops. The default is 4.  <b>wait</b> <i>seconds</i> —(Optional) Maximum time to wait for a response to the traceroute request. The range is 1 to 255 seconds. The default is 5.
<b>Required Privilege Level</b>	network
<b>List of Sample Output</b>	<a href="#">traceroute ethernet on page 423</a>
<b>Output Fields</b>	<a href="#">Table 70 on page 422</a> lists the output fields for the <b>traceroute ethernet</b> command. Output fields are listed in the approximate order in which they appear.

**Table 70: traceroute ethernet Output Fields**

Field Name	Field Description
Linktrace to	MAC address of the destination maintenance point.
Interface	Local interface used to send the linktrace message (LTM).



Table 70: traceroute ethernet Output Fields (*continued*)

Field Name	Field Description
<b>Maintenance Domain</b>	Maintenance domain specified in the traceroute command.
<b>Level</b>	Maintenance domain level configured.
<b>Maintenance Association</b>	Maintenance association specified in the traceroute command.
<b>Local Mep</b>	The local maintenance end point identifier.
<b>Transaction Identifier</b>	4-byte identifier maintained by the MEP. Each LTM uses a transaction identifier. The transaction identifier is maintained globally across all Maintenance Domains. Use the transaction identifier to match an incoming linktrace response (LTR), with a previously sent LTM.
<b>Hop</b>	Sequential hop count of the linktrace path.
<b>TTL</b>	Number of hops remaining in the linktrace message. The time to live (TTL) is decremented at each hop.
<b>Source MAC address</b>	MAC address of the 802.1ag maintenance point that is sending the linktrace message.
<b>Next-hop MAC address</b>	MAC address of the 802.1ag node that is the next hop in the LTM path.

## Sample Output

### traceroute ethernet

```
user@host> traceroute ethernet maintenance-domain md1 maintenance-association ma1
00:90:69:7e:01:ff
```

```
Linktrace to 00:01:02:03:04:05, Interface : ge-5/0/0.0
```

```
  Maintenance Domain: MD1, Level: 7
```

```
  Maintenance Association: MA1, Local Mep: 1
```

Hop	TTL	Source MAC address	Next hop MAC address
Transaction Identifier:100001			
1	63	00:00:aa:aa:aa:aa	00:00:bb:bb:bb:bb
2	62	00:00:bb:bb:bb:bb	00:00:cc:cc:cc:cc
3	61	00:00:cc:cc:cc:cc	00:01:02:03:04:05
4	60	00:01:02:03:04:05	00:00:00:00:00:00



## CHAPTER 5

# VRRP Operational Mode Commands

Table 71 on page 425 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot Virtual Router Redundancy Protocol (VRRP) on Ethernet, Fast Ethernet, Gigabit Ethernet, 10-Gigabit Ethernet, and logical tunnel interfaces. Commands are listed in alphabetical order.

**Table 71: VRRP Operational Mode Commands**

Task	Command
Clear (set to zero) VRRP groups.	<code>clear vrrp</code>
Display VRRP groups.	<code>show vrrp</code>

## clear vrrp

---

<b>Syntax</b>	clear vrrp (all   interface <i>interface-name</i> )
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Set Virtual Router Redundancy Protocol (VRRP) interface statistics to zero.
<b>Options</b>	<p><b>all</b>—Clear statistics on all interfaces.</p> <p><b>interface <i>interface-name</i></b>—Clear statistics on the specified interface only.</p>
<b>Required Privilege Level</b>	clear
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show vrrp on page 427</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear vrrp all on page 426</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

**clear vrrp all**                      user@host> clear vrrp all

## show vrrp

<b>Syntax</b>	<pre>show vrrp &lt;brief   detail   extensive   summary&gt; &lt;interface <i>interface-name</i> &lt;group number&gt;&gt; &lt;logical-system (<i>logical-system-name</i>   all)&gt; &lt;track &lt;interfaces&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about Virtual Router Redundancy Protocol (VRRP) groups.
<b>Options</b>	<p><b>none</b>—(Same as brief) Display brief status information about all VRRP interfaces.</p> <p><b>brief   detail   extensive   summary</b>—(Optional) Display the specified level of output.</p> <p><b>interface <i>interface-name</i> &lt;group number&gt;</b>—(Optional) Display information and status about the specified VRRP interface, and, optionally, group number.</p> <p><b>logical-system (all   <i>logical-system-name</i>)</b>—(Optional) Perform this operation on all logical systems or on a particular logical system.</p> <p><b>track &lt;interfaces&gt;</b>—(Optional) Display information and status about VRRP track interfaces.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">clear vrrp on page 426</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show vrrp on page 433</a> <a href="#">show vrrp brief on page 433</a> <a href="#">show vrrp detail (IPv6) on page 433</a> <a href="#">show vrrp detail (Route Track) on page 433</a> <a href="#">show vrrp interface on page 434</a> <a href="#">show vrrp summary on page 434</a> <a href="#">show vrrp track detail on page 434</a> <a href="#">show vrrp track summary on page 435</a> <a href="#">show vrrp extensive on page 435</a>
<b>Output Fields</b>	<a href="#">Table 72 on page 427</a> lists the output fields for the <b>show vrrp</b> command. Output fields are listed in the approximate order in which they appear

**Table 72: show vrrp Output Fields**

Field Name	Field Description	Level of Output
Interface	Name of the logical interface.	brief extensive none summary
Interface index	Physical interface index number, which reflects its initialization sequence.	extensive

Table 72: show vrrp Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Groups</b>	Total number of VRRP groups configured on the interface.	<b>extensive</b>
<b>Active</b>	Total number of VRRP groups that are active (that is, whose interface state is either up or down).	<b>extensive</b>
<b>Interface VRRP PDU statistics</b>	Nonerrored statistics for the logical interface: <ul style="list-style-type: none"> <li>• <b>Advertisement sent</b>—Number of VRRP advertisement protocol data units (PDUs) that the interface has transmitted.</li> <li>• <b>Advertisement received</b>—Number of VRRP advertisement PDUs received by the interface.</li> <li>• <b>Packets received</b>—Number of VRRP packets received for VRRP groups on the interface.</li> <li>• <b>No group match received</b>—Number of VRRP packets received for VRRP groups that do not exist on the interface.</li> </ul>	<b>extensive</b>
<b>Interface VRRP PDU error statistics</b>	Errored statistics for the logical interface: <ul style="list-style-type: none"> <li>• <b>Invalid IPAH next type received</b>—Number of packets received that use the IP Authentication Header protocol (IPAH) and that do not encapsulate VRRP packets.</li> <li>• <b>Invalid VRRP ttl value received</b>—Number of packets received whose IP time-to-live (TTL) value is not 255.</li> <li>• <b>Invalid VRRP version received</b>—Number of packets received whose VRRP version is not 2.</li> <li>• <b>Invalid VRRP pdu type received</b>—Number of packets received whose VRRP PDU type is not 1.</li> <li>• <b>Invalid VRRP authentication type received</b>—Number of packets received whose VRRP authentication is not none, simple, or md5.</li> <li>• <b>Invalid VRRP IP count received</b>—Number of packets received whose VRRP IP count exceeds 8.</li> <li>• <b>Invalid VRRP checksum received</b>—Number of packets received whose VRRP checksum does not match the calculated one.</li> </ul>	<b>extensive</b>
<b>Physical interface</b>	Name of the physical interface.	<b>detail extensive</b>
<b>Unit</b>	Logical unit number.	All levels
<b>Address</b>	Address of the physical interface.	<b>brief detail extensive</b> none
<b>Index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b>
<b>VRRP-Traps</b>	Status of VRRP traps: <b>Enabled</b> or <b>Disabled</b> .	<b>detail extensive</b>
<b>VRRP-Version</b>	VRRP version: <b>2</b> or <b>3</b> .	<b>detail extensive</b>

Table 72: show vrrp Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Type and Address</b>	Identifier for the address and the address itself: <ul style="list-style-type: none"> <li>• <b>lcl</b>—Configured local interface address.</li> <li>• <b>mas</b>—Address of the master virtual router. This address is displayed only when the local interface is acting as a backup router.</li> <li>• <b>vip</b>—Configured virtual IP addresses.</li> </ul>	<b>brief none summary</b>
<b>Interface state or Int state</b>	State of the physical interface: <ul style="list-style-type: none"> <li>• <b>down</b>—The device is present and the link is unavailable.</li> <li>• <b>not present</b>—The interface is configured, but no physical device is present.</li> <li>• <b>unknown</b>—The VRRP process has not had time to query the kernel about the state of the interface.</li> <li>• <b>up</b>—The device is present and the link is established.</li> </ul>	<b>brief extensive none summary</b>
<b>Group</b>	VRRP group number.	<b>brief extensive none summary</b>
<b>State</b>	VRRP state: <ul style="list-style-type: none"> <li>• <b>backup</b>—The interface is acting as the backup router interface.</li> <li>• <b>bringup</b>—VRRP is just starting and the physical device is not yet present.</li> <li>• <b>idle</b>—VRRP is configured on the interface and is disabled. This can occur when VRRP is first enabled on an interface whose link is established.</li> <li>• <b>initializing</b>—VRRP is initializing.</li> <li>• <b>master</b>—The interface is acting as the master router interface.</li> <li>• <b>transition</b>—The interface is changing between being the backup and being the master router.</li> </ul>	<b>extensive</b>
<b>Priority</b>	Configured VRRP priority for the interface.	<b>detail extensive</b>
<b>Advertisement interval</b>	Configured VRRP advertisement interval.	<b>detail extensive</b>
<b>Authentication type</b>	Configured VRRP authentication type: <b>none</b> , <b>simple</b> , or <b>md5</b> .	<b>detail extensive</b>
<b>Preempt</b>	Whether preemption is allowed on the interface: <b>yes</b> or <b>no</b> .	<b>detail extensive</b>
<b>Accept-data mode</b>	Whether the interface is configured to accept packets destined for the virtual IP address: <b>yes</b> or <b>no</b> .	<b>detail extensive</b>
<b>VIP count</b>	Number of virtual IP addresses that have been configured on the interface.	<b>detail extensive</b>
<b>VIP</b>	List of virtual IP addresses configured on the interface.	<b>detail extensive</b>
<b>Advertisement timer</b>	How long, in seconds, until the advertisement timer expires.	<b>detail extensive</b>

Table 72: show vrrp Output Fields (*continued*)

Field Name	Field Description	Level of Output
Master router	IP address of the interface that is acting as the master. If the VRRP interface is down, the output is <b>N/A</b> .	detail extensive
Virtual router uptime	How long, in seconds, that the virtual router has been up.	detail extensive
Master router uptime	How long, in seconds, that the master route has been up.	detail extensive
Virtual MAC	MAC address associated with the virtual IP address.	detail extensive
Tracking	Whether tracking is <b>enabled</b> or <b>disabled</b> .	detail extensive
Current priority	Current operational priority for being the VRRP master.	detail extensive
Configured priority	Configured base priority for being the VRRP master.	detail extensive
Priority hold-time	Minimum time interval, in seconds, between successive changes to the current priority. <b>Disabled</b> indicates no minimum interval.	detail extensive
Remaining-time	( <b>track</b> option only) Displays the time remaining in the priority hold-time interval.	detail
Interface tracking	Whether interface tracking is enabled or disabled. When enabled, the output also displays the number of tracked interfaces.	detail extensive
Interface/Tracked interface	Name of the tracked interface.	detail extensive
Int state/Interface state	Current operational state of the tracked interface: <b>up</b> or <b>down</b> .	detail extensive
Int speed/Speed	Current operational speed, in bits per second, of the tracked interface.	detail extensive
Incurred priority cost	Operational priority cost incurred due to the state and speed of this tracked interface. This cost is applied to the configured priority to obtain the current priority.	detail extensive
Threshold	Speed below which the corresponding priority cost is incurred. In other words, when the speed of the interface drops below the threshold speed, the corresponding priority cost is incurred.  An entry of <b>down</b> means that the corresponding priority cost is incurred when the interface is down.	detail extensive
Route tracking	Whether route tracking is enabled or disabled. When enabled, the output also displays the number of tracked routes.	detail extensive
Route count	The number of routes being tracked.	detail extensive



Table 72: show vrrp Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Route</b>	The IP address of the route being tracked.	<b>detail extensive</b>
<b>VRF name</b>	The VPN routing and forwarding (VRF) routing instance that the tracked route is in.	<b>detail extensive</b>
<b>Route state</b>	The state of the route being tracked: <b>up</b> , <b>down</b> , or <b>unknown</b> .	<b>detail extensive</b>
<b>Priority cost</b>	Configured priority cost. This value is incurred when the interface speed drops below the corresponding threshold or when the tracked route goes down.	<b>detail extensive</b>
<b>Active</b>	Whether the threshold is active (*). If the threshold is active, the corresponding priority cost is incurred.	<b>detail extensive</b>
<b>Group VRRP PDU statistics</b>	Number of VRRP advertisements sent and received by the group.	<b>extensive</b>
<b>Group VRRP PDU error statistics</b>	Errored statistics for the VRRP group: <ul style="list-style-type: none"> <li>• <b>Bad authentication type received</b>—Number of VRRP PDUs received with an invalid authentication type. The received authentication can be <b>none</b>, <b>simple</b>, or <b>md5</b> and must be the same for all routers in the VRRP group.</li> <li>• <b>Bad password received</b>—Number of VRRP PDUs received with an invalid key (password). The password for simple authentication must be the same for all routers in the VRRP group.</li> <li>• <b>Bad MD5 digest received</b>—Number of VRRP PDUs received for which the MD5 digest computed from the VRRP PDU differs from the digest expected by the VRRP instance configured on the router.</li> <li>• <b>Bad advertisement timer received</b>—Number of VRRP PDUs received with an advertisement time interval that is inconsistent with the one in use among the routers in the VRRP group.</li> <li>• <b>Bad VIP count received</b>—Number of VRRP PDUs whose virtual IP address counts differ from the count that has been configured on the VRRP instance.</li> <li>• <b>Bad VIPADDR received</b>—Number of VRRP PDUs whose virtual IP addresses differ from the list of virtual IP addresses configured on the VRRP instance.</li> </ul>	<b>extensive</b>
<b>Group state transition statistics</b>	State transition statistics for the VRRP group: <ul style="list-style-type: none"> <li>• <b>Idle to master transitions</b>—Number of times that the VRRP instance transitioned from the idle state to the master state.</li> <li>• <b>Idle to backup transitions</b>—Number of times that the VRRP instance transitioned from the idle state to the backup state.</li> <li>• <b>Backup to master transitions</b>—Number of times that the VRRP instance transitioned from the backup state to the master state.</li> <li>• <b>Master to backup transitions</b>—Number of times that the VRRP instance transitioned from the master state to the backup state.</li> </ul>	<b>extensive</b>

Table 72: show vrrp Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>VR state</b>	<p>VRRP information:</p> <ul style="list-style-type: none"><li>• <b>backup</b>—The interface is acting as the backup router interface.</li><li>• <b>bringup</b>—VRRP is just starting, and the physical device is not yet present.</li><li>• <b>idle</b>—VRRP is configured on the interface and is disabled. This can occur when VRRP is first enabled on an interface whose link is established.</li><li>• <b>initializing</b>—VRRP is initializing.</li><li>• <b>master</b>—The interface is acting as the master router interface.</li><li>• <b>transition</b>—The interface is changing between being the backup and being the master router.</li></ul>	<b>brief none summary</b>
<b>Timer</b>	<p>VRRP timer information:</p> <ul style="list-style-type: none"><li>• <b>A</b>—How long, in seconds, until the advertisement timer expires.</li><li>• <b>D</b>—How long, in seconds, until the Master is Dead timer expires.</li></ul>	<b>brief none</b>

## Sample Output

### show vrrp

```
user@host> show vrrp
Interface      State      Group  VR state  Timer  Type  Address
fe-0/0/0.121   up         1      master    A 1.052 1c1  fec0::12:1:1:1
                                     vip  fe80::12:1:1:99
                                     vip  fec0::12:1:1:99
fe-0/0/2.131   up         1      master    A 0.364 1c1  fec0::13:1:1:1
                                     vip  fe80::13:1:1:99
                                     vip  fec0::13:1:1:99
```

### show vrrp brief

The output for the **show vrrp brief** command is identical to that for the **show vrrp** command. For sample output, see [show vrrp on page 433](#)

### show vrrp detail (IPv6)

```
user@host> show vrrp detail
Physical interface: fe-0/0/0, Unit: 121, Vlan-id: 212, Address: fec0::12:1:1:1/120

Index: 67, SNMP ifIndex: 45, VRRP-Traps: enabled
Interface state: up, Group: 1, State: master
Priority: 200, Advertisement interval: 1, Authentication type: none
Preempt: yes, Accept-data mode: no, VIP count: 2, VIP: fe80::12:1:1:99,
fec0::12:1:1:99
Advertisement timer: 1.121s, Master router: fe80::12:1:1:1
Virtual router uptime: 00:03:47, Master router uptime: 00:03:41
Virtual MAC: 00:00:5e:00:02:01
Tracking: disabled

Physical interface: fe-0/0/2, Unit: 131, Vlan-id: 213, Address: fec0::13:1:1:1/120

Index: 69, SNMP ifIndex: 47, VRRP-Traps: enabled
Interface state: up, Group: 1, State: master
Priority: 200, Advertisement interval: 1, Authentication type: none
Preempt: yes, Accept-data mode: no, VIP count: 2, VIP: fe80::13:1:1:99,
fec0::13:1:1:99
Advertisement timer: 0.327s, Master router: fe80::13:1:1:1
Virtual router uptime: 00:03:47, Master router uptime: 00:03:41
Virtual MAC: 00:00:5e:00:02:01
Tracking: disabled
```

### show vrrp detail (Route Track)

```
user@host> show vrrp detail
Physical interface: ge-1/2/0, Unit: 0, Address: 30.30.30.30/24
Index: 67, SNMP ifIndex: 379, VRRP-Traps: enabled, VRRP-Version: 2
Interface state: up, Group: 100, State: master
Priority: 150, Advertisement interval: 1, Authentication type: none
Preempt: yes, Accept-data mode: no, VIP count: 1, VIP: 30.30.30.100
Advertisement timer: 1.218s, Master router: 30.30.30.30
Virtual router uptime: 00:04:28, Master router uptime: 00:00:13
Virtual MAC: 00:00:5e:00:01:64
Tracking: enabled
  Current priority: 150, Configured priority: 150
  Priority hold-time: disabled
  Interface tracking: disabled
  Route tracking: enabled, Route count: 1
```

Route	VRF name	Route state	Priority cost
192.168.40.0/22	default	up	30

**show vrrp interface**

```

user@host> show vrrp interface
Interface: fe-0/0/0.121, Interface index: 67, Groups: 1, Active : 1
  Interface VRRP PDU statistics
    Advertisement sent           : 205
    Advertisement received       : 0
    Packets received             : 0
    No group match received      : 0
  Interface VRRP PDU error statistics
    Invalid IPAH next type received : 0
    Invalid VRRP TTL value received : 0
    Invalid VRRP version received  : 0
    Invalid VRRP PDU type received : 0
    Invalid VRRP authentication type received: 0
    Invalid VRRP IP count received : 0
    Invalid VRRP checksum received : 0

Physical interface: fe-0/0/0, Unit: 121, Vlan-id: 212, Address: fec0::12:1:1:1/120

Index: 67, SNMP ifIndex: 45, VRRP-Traps: enabled
Interface state: up, Group: 1, State: master
Priority: 200, Advertisement interval: 1, Authentication type: none
Preempt: yes, Accept-data mode: no, VIP count: 2, VIP: fe80::12:1:1:99,
fec0::12:1:1:99
Advertisement timer: 0.789s, Master router: fe80::12:1:1:1
Virtual router uptime: 00:04:26, Master router uptime: 00:04:20
Virtual MAC: 00:00:5e:00:02:01
Tracking: disabled
Group VRRP PDU statistics
  Advertisement sent           : 205
  Advertisement received       : 0
Group VRRP PDU error statistics
  Bad authentication type received: 0
  Bad password received           : 0
  Bad MD5 digest received         : 0
  Bad advertisement timer received: 0
  Bad VIP count received          : 0
  Bad VIPADDR received           : 0
Group state transition statistics
  Idle to master transitions      : 0
  Idle to backup transitions      : 1
  Backup to master transitions    : 1
  Master to backup transitions    : 0

```

**show vrrp summary**

```

user@host> show vrrp summary
Interface  State      Group  VR state  Type  Address
ge-4/2/0.0  up         1    backup   1cl   10.57.0.2
vip        10.57.0.100

```

**show vrrp track detail**

```

user@host> show vrrp track detail
Tracked interface: ae1.211
State: up, Speed: 400m
Incurred priority cost: 0
Threshold  Priority cost  Active
400m       10
300m       60
200m       110

```

```

100m      160
down      190
Tracking VRRP interface: ae0.210, Group: 1
  VR State: master
  Current priority: 200, Configured priority: 200
  Priority hold-time: disabled,    Remaining-time: 50.351

```

### show vrrp track summary

```

user@host> show vrrp track summary
Track if    State    Speed    VRRP if    Group    VR State    Current priority
ae1.211     up      400m     ae0.210     1        master      200

```

### show vrrp extensive

```

user@host> show vrrp extensive
Interface: ge-2/0/0.0, Interface index :65539, Groups: 1, Active :1
  Interface VRRP PDU statistics
    Advertisement sent                :0
    Advertisement received             :0
    Packets received                   :0
    No group match received            :0
  Interface VRRP PDU error statistics
    Invalid IPAH next type received    :0
    Invalid VRRP TTL value received    :0
    Invalid VRRP version received      :0
    Invalid VRRP PDU type received     :0
    Invalid VRRP authentication type received:0
    Invalid VRRP IP count received     :0
    Invalid VRRP checksum received     :0

Physical interface: ge-2/0/0, Unit: 0, Address: 10.10.10.1/24
Index: 65539, SNMP ifIndex: 648, VRRP-Traps: enabled, VRRP-Version: 3
Interface state: up, Group: 1, State: backup, VRRP Mode: Active
Priority: 100, Advertisement interval: 1, Authentication type: none
Advertisement threshold: 3, Computed send rate: 0
Preempt: yes, Accept-data mode: no, VIP count: 1, VIP: 10.10.10.2
Dead timer: 3.078s, Master priority: 0, Master router: 10.10.10.1
Virtual router uptime: 00:00:04
Tracking: disabled
Group VRRP PDU statistics
  Advertisement sent                  :0
  Advertisement received               :0
Group VRRP PDU error statistics
  Bad authentication Type received    :0
  Bad password received                :0
  Bad MD5 digest received             :0
  Bad advertisement timer received    :0
  Bad VIP count received               :0
  Bad VIPADDR received                :0
Group state transition statistics
  Idle to master transitions           :0
  Idle to backup transitions           :1
  Backup to master transitions         :0
  Master to backup transitions         :0

```



## PART 3

# Digital Transmission Interfaces

- [Digital Transmission Interface Operational Mode Commands on page 439](#)





## CHAPTER 6

# Digital Transmission Interface Operational Mode Commands

Table 73 on page 439 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot digital transmission interfaces (T1, E1, T3, and E3). Commands are listed in alphabetical order.

**Table 73: Digital Transmission Interface Operational Mode Commands**

Task	Command
Display status information about T1 or E1 interfaces.	<a href="#">show interfaces (T1, E1, or DS)</a>
Display status information about T3 or E3 interfaces.	<a href="#">show interfaces (T3 or E3)</a>



**NOTE:** Because the output for the E1 and T1 interfaces is almost identical, the command and output are explained once, with notations included for any differences. The same is true for the E3 and T3 interfaces.

## show interfaces (T1, E1, or DS)

<b>Syntax</b>	<pre>show interfaces <i>interface-type</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified T1, E1, or DS interface.
<b>Options</b>	<p><b><i>interface-type</i></b>—On ACX Series, M Series, MX Series, and T Series routers, the T1 interface type is <b>t1-<i>fpc/pic/port</i></b>, whereas the E1 interface type is <b>e1-<i>fpc/pic/port</i></b>, and DS interface type is <b>ds-<i>fpc/pic/port:channel</i></b>. On the J Series routers, the T1 interface type is <b>t1-<i>pim/O/port</i></b>, whereas the E1 interface type is <b>e1-<i>pim/O/port</i></b>.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Understanding Interfaces on ACX Series Universal Access Routers</li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces (T1, IMA Link) on page 453</a> <a href="#">show interfaces (T1, PPP) on page 453</a> <a href="#">show interfaces detail (T1, PPP) on page 454</a> <a href="#">show interfaces extensive (T1 CRC Errors) on page 454</a> <a href="#">show interfaces extensive (T1, PPP) on page 455</a> <a href="#">show interfaces (E1, Frame Relay) on page 456</a> <a href="#">show interfaces detail (E1, Frame Relay) on page 457</a> <a href="#">show interfaces extensive (E1, Frame Relay) on page 458</a> <a href="#">show interfaces (E1, IMA Link) on page 460</a> <a href="#">show interfaces extensive (T1, TDM-CCC-SATOP) on page 461</a> <a href="#">show interfaces extensive (DS, TDM-CCC-CESoPSN) on page 463</a>
<b>Output Fields</b>	<p><a href="#">Table 74 on page 441</a> lists the output fields for the <b>show interfaces</b> (T1 or E1) command. Output fields are listed in the approximate order in which they appear.</p>

Table 74: T1 or E1 show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source: <b>Internal</b> or <b>External</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>FCS</b>	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16</b> bits.	All levels
<b>Framing</b>	Physical layer framing format used for the E1 interface on the link: <b>G704</b> , <b>G704-NO-CRC4</b> , or <b>Unframed</b> . The default is <b>G704</b> .  Physical layer framing format used for the T1 interface on the link: <b>SF</b> and <b>ESF</b> . The default is <b>ESF</b> .	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>IMA Link alarms</b>	Current active IMA link alarms, including the following: <ul style="list-style-type: none"> <li>• LIF</li> <li>• LODS</li> <li>• RFI-IMA</li> <li>• Tx-Mis-Connected</li> <li>• Tx-Unusable-FE</li> <li>• Rx-Unusable-FE</li> <li>• Link Fault</li> </ul>	<b>detail extensive none</b>
<b>IMA Link defects</b>	Current active IMA link defects, including the following: <ul style="list-style-type: none"> <li>• LIF</li> <li>• LODS</li> <li>• RFI-IMA</li> <li>• Tx-Mis-Connected</li> <li>• Tx-Unusable-FE</li> <li>• Rx-Unusable-FE</li> <li>• Link Fault</li> </ul>	<b>detail extensive none</b>
<b>IMA Link state</b>	Current active IMA link status, including the following: <ul style="list-style-type: none"> <li>• <b>Line:</b> synchronized or not synchronized</li> <li>• <b>Near end:</b>—Status of near-end receive and transmit links <ul style="list-style-type: none"> <li>• <b>Rx:</b> Usable or Unusable</li> <li>• <b>Tx:</b> Usable or Unusable</li> </ul> </li> <li>• <b>Far end:</b>—Status of far-end receive and transmit links <ul style="list-style-type: none"> <li>• <b>Rx:</b> Usable or Unusable</li> <li>• <b>Tx:</b> Usable or Unusable</li> </ul> </li> </ul>	<b>detail extensive none</b>

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
IMA link media	<p>IMA Link Media Status, which provides the seconds and count state for the following link media parameters:</p> <ul style="list-style-type: none"> <li>• LIF</li> <li>• LODS</li> <li>• Err-ICP</li> <li>• IV</li> <li>• Rx-FC</li> <li>• Tx-FC</li> <li>• FE-Defects</li> <li>• FE-Rx-FC</li> <li>• FE-Tx-FC</li> <li>• Rx-ICP</li> <li>• Rx-Stuff</li> <li>• Tx-ICP</li> <li>• Tx-Stuff</li> <li>• Rx-SES</li> <li>• Rx-UAS</li> <li>• Rx-UUS</li> <li>• Tx-UUS</li> <li>• FE-Rx-SES</li> <li>• FE-Rx-UAS</li> <li>• FE-Rx-UUS</li> <li>• FE-Tx-UUS</li> </ul>	detail extensive none
Keepalive settings	<p>(PPP and HDLC) Configured settings for keepalives.</p> <ul style="list-style-type: none"> <li>• <b>interval seconds</b>—The time in seconds between successive keepalive requests. The range is 10 seconds through 32,767 seconds, with a default of 10 seconds.</li> <li>• <b>down-count number</b>—The number of keepalive packets a destination must fail to receive before the network takes a link down. The range is 1 through 255, with a default of 3.</li> <li>• <b>up-count number</b>—The number of keepalive packets a destination must receive to change a link's status from down to up. The range is 1 through 255, with a default of 1.</li> </ul>	detail extensive none
Keepalive statistics	<p>(PPP and HDLC) Information about keepalive packets. (When no level of output is specified, the word <b>statistics</b> is not part of the field name and the <b>last seen</b> text is not displayed.)</p> <ul style="list-style-type: none"> <li>• <b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li>• (last seen 00:00:00 ago)—Time since the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li>• <b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li>• (last seen 00:00:00 ago)—Time since the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul>	detail extensive none

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>LMI settings</b>	<p>(Frame Relay) Settings for Local Management Interface (LMI) which can be either ANSI LMI settings or ITU LMI settings. ANSI LMI settings is the default. The format is <b>(ANSI or ITU) LMI settings: value, value... xx</b> seconds, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li>• <b>n391dte</b>—DTE full status polling interval (1–255)</li> <li>• <b>n392dce</b>—DCE error threshold (1–10)</li> <li>• <b>n392dte</b>—DTE error threshold (1–10)</li> <li>• <b>n393dce</b>—DCE monitored event count (1–10)</li> <li>• <b>n393dte</b>—DTE monitored event count (1–10)</li> <li>• <b>t391dte</b>—DTE polling timer (5–30 seconds)</li> <li>• <b>t392dce</b>—DCE polling verification timer (5–30 seconds)</li> </ul>	<b>detail extensive</b> none
<b>LMI</b>	<p>(Frame Relay) Local Management Interface (LMI) packet statistics:</p> <ul style="list-style-type: none"> <li>• <b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: nn (last seen hh:mm:ss ago)</b>.</li> <li>• <b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: nn (last sent hh:mm:ss ago)</b>.</li> </ul>	<b>detail extensive</b> none
<b>DTE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the data terminal equipment (DTE) to the data communications equipment (DCE):</p> <ul style="list-style-type: none"> <li>• <b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li>• <b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li>• <b>Enquiry responses received</b>—Number of enquiry responses received by the DTE from the DCE.</li> <li>• <b>Full enquiry responses received</b>—Number of full enquiry responses sent from the DTE to the DCE.</li> </ul>	<b>detail extensive</b> none
<b>DCE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the DCE to the DTE:</p> <ul style="list-style-type: none"> <li>• <b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li>• <b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li>• <b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li>• <b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	<b>detail extensive</b> none

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Common statistics</b>	(Frame Relay) Statistics about messages sent between the DTE and the DCE: <ul style="list-style-type: none"> <li>• <b>Unknown messages received</b>—Number of received packets that do not fall into any category.</li> <li>• <b>Asynchronous updates received</b>—Number of link status peer changes received.</li> <li>• <b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li>• <b>Keepalive responses timedout</b>—Number of keepalive responses that timed out when no Local Management Interface (LMI) packet was reported for <b>n392dte</b> or <b>n393dce</b> intervals. (See <b>LMI settings</b>.)</li> </ul>	<b>detail extensive none</b>
<b>Nonmatching DCE-end DLCIs</b>	(Frame Relay. Displayed only from the DTE.) Number of DLCIs configured from the DCE.	<b>detail extensive none</b>
<b>LCP state</b>	(PPP) Link Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not configured</b>—LCP is not configured on the interface.</li> <li>• <b>Opened</b>—LCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>NCP state</b>	(PPP) Network Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>CHAP state</b>	(PPP) State of the Challenge Handshake Authentication Protocol (CHAP) during its transaction. <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response is not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the Success state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Down</b>—CHAP authentication is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Opened</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS Queues</b>	Number of CoS queues configured.	<b>detail extensive none</b>
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>SRAM errors</b>—Number of hardware errors that occurred in the static RAM (SRAM) on the PIC or PIM. If the value of this field increments, the PIC or PIM is malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>



Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>DS1 alarms</b> <b>DS1 defects</b>	<p>E1 media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. The following lists all possible alarms and defects. For complete explanations of most of these alarms and defects, see <i>Belcore Telcordia GR-499-CORE</i>.</p> <ul style="list-style-type: none"> <li>• <b>AIS</b>—Alarm indication signal.</li> <li>• <b>LOF</b>—Loss of frame.</li> <li>• <b>LOS</b>—Loss of signal.</li> <li>• <b>YLW</b>—Yellow alarm. Indicates errors at the remote site receiver.</li> </ul>	<b>detail extensive none</b>

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
T1 media or E1 media	<p>Counts of T1 or E1 media-specific errors.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem. The T1 or E1 media-specific error types are:</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>BEE</b>—Bit error</li> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> <li>• <b>CRC Major</b>—Cyclic redundancy check major alarm threshold exceeded</li> <li>• <b>CRC Minor</b>—Cyclic redundancy check minor alarm threshold exceeded</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>PCV</b>—Pulse code violation</li> <li>• <b>CS</b>—Carrier state</li> <li>• <b>CRC</b>—Cyclic redundancy check</li> <li>• <b>FEBE</b>—Far-end block error (E1 only)</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>ES</b>—Errored seconds</li> <li>• <b>BES</b>—Bursty errored seconds</li> <li>• <b>SES</b>—Severely errored seconds</li> <li>• <b>SEFS</b>—Severely errored framing seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> </ul>	extensive
SAToP Configuration	<p>Information about the SAToP configuration.</p> <ul style="list-style-type: none"> <li>• <b>payload-size</b>—Configure the payload size, in bytes (from 32 through 1024 bytes).</li> <li>• <b>idle-pattern</b>—An 8-bit hexadecimal pattern to replace TDM data in a lost packet (from 0 through 255).</li> <li>• <b>jitter-buffer-packets</b>—Number of packets in the jitter buffer (from 1 through 64 packets).</li> <li>• <b>jitter-buffer-latency</b>—Time delay in the jitter buffer (from 1 through 1000 milliseconds).</li> <li>• <b>excessive-packet-loss-rate</b>—Set packet loss options. The options are <b>groups</b>, <b>sample-period</b>, and <b>threshold</b>.</li> <li>• <b>sample-period</b>—Time required to calculate excessive packet loss rate (from 1000 through 65,535 milliseconds).</li> <li>• <b>threshold</b>—Percentile designating the threshold of excessive packet loss rate (1–100 percent).</li> </ul>	extensive

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CESoPSN Configuration</b>	<p>Information about the CESoPSN configuration.</p> <ul style="list-style-type: none"> <li>• <b>packetization-latency</b>—Time required to create packets (from 1000 through 8000 microseconds).</li> <li>• <b>idle-pattern</b>—An 8-bit hexadecimal pattern to replace TDM data in a lost packet (from 0 through 255).</li> <li>• <b>jitter-buffer-packets</b>—Number of packets in the jitter buffer (from 1 through 64 packets).</li> <li>• <b>jitter-buffer-latency</b>—Time delay in the jitter buffer (from 1 through 1000 milliseconds).</li> <li>• <b>excessive-packet-loss-rate</b>—Set packet loss options. The options are <b>sample-period</b> and <b>threshold</b>.</li> <li>• <b>sample-period</b>—Time required to calculate excessive packet loss rate (from 1000 through 65,535 milliseconds).</li> <li>• <b>threshold</b>—Percentile designating the threshold of excessive packet loss rate (1–100 percent).</li> </ul>	<b>extensive</b>
<b>HDLC configuration</b>	<p>Information about the HDLC configuration.</p> <ul style="list-style-type: none"> <li>• <b>Policing bucket</b>—Configured state of the receiving policer.</li> <li>• <b>Shaping bucket</b>—Configured state of the transmitting shaper.</li> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> <li>• <b>Timeslots</b>—Time slots configured on the interface.</li> <li>• <b>Buildout</b>—(T1 only) Buildout setting: 0-132, 133-265, 266-398, 399-531, or 532-655 feet.</li> <li>• <b>Timeslots</b>—Configured time slots for the interface.</li> <li>• <b>Byte encoding</b>—(T1 only) Byte encoding used: <b>Nx64K</b> or <b>Nx56K</b>.</li> <li>• <b>Line encoding</b>—Line encoding used. For T1, the value can be <b>B8ZS</b> or <b>AMI</b>. For E1, the value is <b>HDB3</b>.</li> <li>• <b>Data inversion</b>—HDLC data inversion setting: <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Idle cycle flag</b>—Idle cycle flags.</li> <li>• <b>Start end flag</b>—Start and end flag.</li> </ul>	<b>extensive</b>
<b>DS1 BERT configuration</b>	<p>BERT (bit error rate test) checks the quality of the line. This output appears only when a BERT is run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>BERT time period</b>—Configured total time period that the BERT is to run.</li> <li>• <b>Elapsed</b>—Actual time elapsed since the start of the BERT (in seconds).</li> <li>• <b>Induced error rate</b>—Configured rate at which the bit errors are induced in the BERT pattern.</li> <li>• <b>Algorithm</b>—Type of algorithm selected for the BERT.</li> </ul>	<b>detail extensive none</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	(Frame Relay) Number and rate of bytes and packets received and transmitted on the logical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	(Frame Relay) Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes a while (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Transit statistics</b>	(Frame Relay) Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. This counter normally stabilizes in less than 1 second.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mlfr</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b>Multilink bundle</b>	Interface name for the multilink bundle, if configured.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive none</b>
<b>DLCI</b>	<p>(Frame Relay) DLCI number of the logical interface. The following DLCI information is displayed: <b>Flags</b>, <b>Total down time</b>, <b>Last down</b>, and <b>Traffic statistics</b> or (<b>Input packets</b>, <b>Output packets</b>). <b>Flags</b> can be one or more of the following:</p> <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when the link is active, but no information is received from the DCE.</li> <li>• <b>DCE-Unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the corresponding DLCI in the DCE is configured.</li> <li>• <b>DCE-configured</b>—Displayed when the command is issued from the DTE.</li> </ul>	<b>detail extensive none</b>
<b>DLCI statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	<b>detail extensive none</b>

Table 74: T1 or E1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CE Info</b>	<p>Information related to the circuit emulation statistics.</p> <ul style="list-style-type: none"> <li>• <b>CE Tx</b>—Number of transmitted packets and bytes (TDM to PSN flow).</li> <li>• <b>CE Rx</b>—Number of received packets and bytes and forward bytes (PSN to TDM flow).</li> <li>• <b>CE Rx Forwarded</b>—Number of forwarded bytes.</li> <li>• <b>CE Strayed</b>—Number of stray packets.</li> <li>• <b>CE Lost</b>—Number of lost packets.</li> <li>• <b>CE Malformed</b>—Number of malformed packets</li> <li>• <b>CE Misinserted</b>—Number of misinserted packets.</li> <li>• <b>CE AIS dropped</b>—Number of dropped bytes due to buffer overrun (PSN to TDM).</li> <li>• <b>CE Dropped</b>—Number of dropped packets during resynchronization</li> <li>• <b>CE Overrun Events</b>—Number of overrun events.</li> <li>• <b>CE Underrun Events</b>—Number of underrun events.</li> </ul>	<b>extensive</b>

## Sample Output

show interfaces (T1,  
IMA Link)

```
user@host> show interfaces t1-1/0/0
IMA Link alarms      : None
IMA Link defects     : LIF, LODS
IMA Link state:
  Line       : Not synchronized
  Near end   : Rx: Unusable, Tx: Usable
  Far end    : Rx: Unusable, Tx: Usable
IMA link media:      Seconds      Count  State
LIF                  0            0      OK
LODS                  0            0      OK
Err-ICP              0            0      OK
IV                   0            0      OK
Rx-FC                 0            0      OK
Tx-FC                 0            0      OK
FE-Defects           0            0
FE-Rx-FC             0            0
FE-Tx-FC             0            0
Rx-ICP               0            0
Rx-Stuff             0            0
Tx-ICP               11           11
Tx-Stuff             0            0
Rx-SES                0
Rx-UAS                0
Rx-UUS                1
Tx-UUS                0
FE-Rx-SES             0
FE-Rx-UAS             0
FE-Rx-UUS             0
FE-Tx-UUS             0
```

show interfaces  
(T1, PPP)

```
user@host> show interfaces t1-1/1/0
Physical interface: t1-1/1/0, Enabled, Physical link is Up
Interface index: 149, SNMP ifIndex: 45
Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: T1,
Loopback: None, FCS: 16, Framing: ESF
Device flags      : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags        : Keepalives
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive: Input: 0 (never), Output: 0 (never)
LCP state: Opened
NCP state: Opened
CHAP state: Opened
CoS queues        : 4 supported, 4 in use
Last flapped      : 2005-12-05 08:43:06 PST (02:13:35 ago)
Input rate        : 0 bps (0 pps)
Output rate       : 72 bps (0 pps)
DS1 alarms        : None
DS1 defects       : None

Logical interface t1-1/1/0.0 (Index 66) (SNMP ifIndex 51)
Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP
Protocol inet, MTU: 1500
Flags: Protocol-Down
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255
```

**show interfaces detail  
(T1, PPP)**

```

user@host> show interfaces t1-1/1/0 detail
Physical interface: t1-1/1/0, Enabled, Physical link is Up
  Interface index: 149, SNMP ifIndex: 45, Generation: 32
  Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: T1,
  Loopback: None, FCS: 16, Framing: ESF
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Hold-times     : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 0 (last seen: never)
    Output: 0 (last sent: never)
  LCP state: Opened
  NCP state: Opened
  CHAP state: Opened
  CoS queues   : 4 supported, 4 in use
  Last flapped : 2005-12-05 08:43:06 PST (02:13:52 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :               798                0 bps
    Input packets :                0                0 pps
    Output packets:               42                0 pps
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort           0                0                0
    1 expedited-fo         0                0                0
    2 assured-forw         0                0                0
    3 network-cont        40                40                0

  DS1  alarms   : None
  DS1  defects  : None
  DS1 BERT configuration:
    BERT time period: 10 seconds, Elapsed: 0 seconds
    Induced Error rate: 10e-0, Algorithm: 2^15 - 1
  Logical interface t1-1/1/0.0 (Index 66) (SNMP ifIndex 51) (Generation 5)
  Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP
  Protocol inet, MTU: 1500, Generation: 14, Route table: 0
  Flags: Protocol-Down
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255,
    Generation: 18

```

**show interfaces  
extensive (T1 CRC  
Errors)**

```

user@host> show interfaces t1-3/2/0:1:1 extensive
Physical interface: t1-3/2/0:1:1, Enabled, Physical link is Down
  Interface index: 179, SNMP ifIndex: 79, Generation: 180
  :
  :
  DS1  alarms   : AIS, LOF, CRC Major, CRC Minor
  DS1  defects  : AIS, LOF, CRC Major, CRC Minor
  T1  media:      Seconds      Count  State
    SEF              1          1  OK
    BEE              1          1  OK
    AIS            1128          1  Defect Active
    LOF            1128          1  Defect Active
    LOS              0          0  OK

```



```

YELLOW                0                0 OK
CRC Major              154              1 Defect Active
CRC Minor              154              1 Defect Active
BPV                    0                0
EXZ                    0                0
LCV                    0                0
PCV                    0                0
CS                     0                0
CRC                    154              15400
...

```

### show interfaces extensive (T1, PPP)

```

user@host> show interfaces t1-1/1/0 extensive
Physical interface: t1-1/1/0, Enabled, Physical link is Up
Interface index: 149, SNMP ifIndex: 45, Generation: 32
Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: T1,
Loopback: None, FCS: 16, Framing: ESF
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives
Hold-times    : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 0 (last seen: never)
  Output: 0 (last sent: never)
LCP state: Down
NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
mpls: Not-configured
CHAP state: Closed
CoS queues   : 4 supported, 4 in use
Last flapped : 2005-12-05 08:43:06 PST (02:13:54 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :                0                0 bps
  Output bytes:                817              72 bps
  Input packets:                0                0 pps
  Output packets:              43                0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Policed discards: 0,
  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  HS link CRC errors: 0, SRAM errors: 0, Resource errors: 0
Output errors:
  Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,
  Resource errors: 0
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort                0                0                0
  1 expedited-fo                0                0                0
  2 assured-forw                0                0                0
  3 network-cont              42              42                0

DS1  alarms   : None
DS1  defects  : None
T1 media:      Seconds      Count  State
  SEF                1        1  OK
  BEE                0        0  OK
  AIS                0        0  OK
  LOF                1        1  OK

```

```

LOS                0                0 OK
YELLOW             1                1 OK
BPV                1                1
EXZ                1                1
LCV                1                65535
PCV                1                1023
CS                 0                0
LES                1
ES                 1
SES                1
SEFS               1
BES                0
UAS                0

```

#### HDLC configuration:

```

Policing bucket: Disabled
Shaping bucket : Disabled
Giant threshold: 1514, Runt threshold: 3
Timeslots       : All active
Line encoding: B8ZS
Buildout        : 0 to 132 feet
Byte encoding: Nx64K, Data inversion: Disabled, Idle cycle flag: flags,
Start end flag: shared

```

#### DS1 BERT configuration:

```

BERT time period: 10 seconds, Elapsed: 0 seconds
Induced Error rate: 10e-0, Algorithm: 2^15 - 1

```

#### Packet Forwarding Engine configuration:

```

Destination slot: 1, PLP byte: 1 (0x00)

```

#### CoS information:

CoS transmit queue	%	Bandwidth bps	%	Buffer usec	Priority	Limit
0 best-effort	95	1459200	95	0	low	none
3 network-control	5	76800	5	0	low	none

#### Logical interface tl-1/1/0.0 (Index 66) (SNMP ifIndex 51) (Generation 5)

```

Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP
Protocol inet, MTU: 1500, Generation: 14, Route table: 0
Flags: Protocol-Down
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255,
Generation: 18

```

### show interfaces (E1, Frame Relay)

```
user@host> show interfaces e1-3/0/0
```

```

Physical interface: e1-3/0/0, Enabled, Physical link is Up
Interface index: 146, SNMP ifIndex: 37
Link-level type: Frame-Relay, MTU: 1504, Clocking: Internal, Speed: E1,
Loopback: None, FCS: 16, Framing: G704
Device flags   : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps 16384
Link flags     : Keepalives DTE
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI: Input: 0 (never), Output: 11 (00:00:05 ago)
DTE statistics:
  Enquiries sent           : 10
  Full enquiries sent      : 1
  Enquiry responses received : 0
  Full enquiry responses received : 0
DCE statistics:
  Enquiries received       : 0
  Full enquiries received  : 0
  Enquiry responses sent   : 0
  Full enquiry responses sent : 0

```

```

Common statistics:
  Unknown messages received      : 0
  Asynchronous updates received  : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout    : 1
CoS queues      : 8 supported
Last flapped    : 2005-11-30 14:50:34 PST (4d 20:33 ago)
Input rate      : 0 bps (0 pps)
Output rate     : 0 bps (0 pps)
DS1 alarms     : None
DS1 defects    : None
Logical interface e1-3/0/0.0 (Index 72) (SNMP ifIndex 32)
  Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
Input packets : 0
Output packets: 0
  Protocol inet, MTU: 1500
  Flags: None
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
  Destination: 10.1.3/24, Local: 10.1.3.1, Broadcast: 10.1.3.255
  DLCI 100
  Flags: Down, DCE-Unconfigured
  Total down time: 00:01:13 sec, Last down: 00:01:13 ago
  Input packets : 0
  Output packets: 0
DLCI statistics:
  Active DLCI :0 Inactive DLCI :1

```

#### show interfaces detail (E1, Frame Relay)

```

user@host> show interfaces e1-3/0/0 detail
Physical interface: e1-3/0/0, Enabled, Physical link is Up
Interface index: 146, SNMP ifIndex: 37, Generation: 69
Link-level type: Frame-Relay, MTU: 1504, Clocking: Internal, Speed: E1,
Loopback: None, FCS: 16, Framing: G704
Device flags : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps 16384
Link flags : Keepalives DTE
Hold-times : Up 0 ms, Down 0 ms
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI statistics:
  Input : 0 (last seen: never)
  Output: 12 (last sent 00:00:02 ago)
DTE statistics:
  Enquiries sent : 10
  Full enquiries sent : 2
  Enquiry responses received : 0
  Full enquiry responses received : 0
DCE statistics:
  Enquiries received : 0
  Full enquiries received : 0
  Enquiry responses sent : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout : 1
CoS queues : 8 supported
Last flapped : 2005-11-30 14:50:34 PST (4d 20:33 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes : 0 0 bps
  Output bytes : 225 56 bps

```

```

Input packets:          0          0 pps
Output packets:         15          0 pps
Queue counters:         Queued packets  Transmitted packets  Dropped packets

  0 limited              0              0              0
  1 expedited-fo         0              0              0
  2 real-plus            0              0              0
  3 network-cont         15             15             0

DS1  alarms   : None
DS1  defects  : None
DS1  BERT configuration:
      BERT time period: 10 seconds, Elapsed: 0 seconds
      Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Logical interface e1-3/0/0.0 (Index 72) (SNMP ifIndex 32) (Generation 26)
Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
Traffic statistics:
  Input bytes  :          0
  Output bytes :          0
  Input packets:          0
  Output packets:         0
Local statistics:
  Input bytes  :          0
  Output bytes :          0
  Input packets:          0
  Output packets:         0
Transit statistics:
  Input bytes  :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:          0          0 pps
  Output packets:         0          0 pps
Protocol inet, MTU: 1500, Generation: 32, Route table: 0
  Flags: None
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 10.1.3/24, Local: 10.1.3.1, Broadcast: 10.1.3.255,
    Generation: 42
  DLCI 100
    Flags: Down, DCE-Unconfigured
    Total down time: 00:01:18 sec, Last down: 00:01:18 ago
    Traffic statistics:
      Input bytes  :          0
      Output bytes :          0
      Input packets:          0
      Output packets:         0
  DLCI statistics:
    Active DLCI :0 Inactive DLCI :1

```

### show interfaces extensive (E1, Frame Relay)

```

user@host> show interfaces e1-3/0/0 extensive
Physical interface: e1-3/0/0, Enabled, Physical link is Up
Interface index: 146, SNMP ifIndex: 37, Generation: 69
Link-level type: Frame-Relay, MTU: 1504, Clocking: Internal, Speed: E1,
Loopback: None, FCS: 16, Framing: G704
Device flags   : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps 16384
Link flags     : Keepalives DTE
Hold-times     : Up 0 ms, Down 0 ms
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI statistics:

```

```

Input : 0 (last seen: never)
Output: 12 (last sent 00:00:05 ago)
DTE statistics:
  Enquiries sent           : 10
  Full enquiries sent      : 2
  Enquiry responses received : 0
  Full enquiry responses received : 0
DCE statistics:
  Enquiries received       : 0
  Full enquiries received  : 0
  Enquiry responses sent   : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout : 1
CoS queues : 8 supported
Last flapped : 2005-11-30 14:50:34 PST (4d 20:33 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes : 0 0 bps
  Output bytes : 225 0 bps
  Input packets: 0 0 pps
  Output packets: 15 0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Policed discards: 0,
  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  HS link CRC errors: 0, SRAM errors: 0, Resource errors: 0
Output errors:
  Carrier transitions: 17, Errors: 0, Drops: 0, Aged packets: 0,
  MTU errors: 0, Resource errors: 0
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 limited	0	0	0
1 expedited-fo	0	0	0
2 real-plus	0	0	0
3 network-cont	15	15	0

```

DS1 alarms : None
DS1 defects : None
E1 media:

```

	Seconds	Count	State
SEF	0	0	OK
BEE	5	5	OK
AIS	0	0	OK
LOF	245	15	OK
LOS	245	4	OK
YELLOW	0	11	OK
BPV	0	0	
EXZ	9	9	
LCV	0	0	
PCV	0	0	
CS	0	0	
FEBE	0	0	
LES	0		
ES	0		
SES	0		
SEFS	0		

```

    BES                                0
    UAS                                271
    HDLC configuration:
      Policing bucket: Disabled
      Shaping bucket : Disabled
      Giant threshold: 1506, Runt threshold: 0
      Timeslots      : All active
      Line encoding: HDB3, Data inversion: Disabled, Idle cycle flag: flags,
      Start end flag: shared
    DS1 BERT configuration:
      BERT time period: 10 seconds, Elapsed: 0 seconds
      Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
    Packet Forwarding Engine configuration:
      Destination slot: 3, PLP byte: 1 (0x00)
    CoS information:
      CoS transmit queue      Bandwidth      Buffer      Priority      Limit
                               %             bps        %          usec
    0 limited                  95       1945600   95          0        low    none
    3 network-control          5        102400    5           0        low    none
    Logical interface e1-3/0/0.0 (Index 72) (SNMP ifIndex 32) (Generation 26)
    Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
    Traffic statistics:
      Input bytes : 0
      Output bytes : 0
      Input packets: 0
      Output packets: 0
    Local statistics:
      Input bytes : 0
      Output bytes : 0
      Input packets: 0
      Output packets: 0
    Transit statistics:
      Input bytes : 0
      Output bytes : 0
      Input packets: 0
      Output packets: 0
    Protocol inet, MTU: 1500, Generation: 32, Route table: 0
    Flags: None
    Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
      Destination: 10.1.3/24, Local: 10.1.3.1, Broadcast: 10.1.3.255,
      Generation: 42
    DLCI 100
    Flags: Down, DCE-Unconfigured
    Total down time: 00:01:21 sec, Last down: 00:01:21 ago
    Traffic statistics:
      Input bytes : 0
      Output bytes : 0
      Input packets: 0
      Output packets: 0
    DLCI statistics:
      Active DLCI :0 Inactive DLCI :1

```

#### show interfaces (E1, IMA Link)

```

user@host> show interfaces e1-1/0/0
IMA Link alarms : None
IMA Link defects : LIF, LODS
IMA Link state:
  Line : Not synchronized
  Near end : Rx: Unusable, Tx: Usable
  Far end : Rx: Unusable, Tx: Usable
IMA link media:      Seconds      Count  State
LIF                                0

```

```

LODS                                0
Err-ICP                            0
IV                                  0
Rx-FC                               0
Tx-FC                               0
FE-Defects                          0
FE-Rx-FC                            0
FE-Tx-FC                            0
Rx-ICP                              0
Rx-Stuff                             0
Tx-ICP                              11
Tx-Stuff                             0
Rx-SES                               0
Rx-UAS                               0
Rx-UUS                               1
Tx-UUS                               0
FE-Rx-SES                           0
FE-Rx-UAS                           0
FE-Rx-UUS                           0
FE-Tx-UUS                           0

```

#### show interfaces extensive (T1, TDM-CCC-SATOP)

```

user@host>show interfaces t1-1/0/0:1:1 extensive
Physical interface: t1-1/0/0:1:1, Enabled, Physical link is Down
  Interface index: 153, SNMP ifIndex: 579, Generation: 817
  Link-level type: TDM-CCC-SATOP, MTU: 1504, Clocking: Internal, Speed: T1,
  Loopback: None, FCS: 16, Framing: ESF,
  Parent: coc1-1/0/0:1 Interface index 152
  Device flags   : Present Running Down
  Interface flags: Hardware-Down Point-To-Point SNMP-Traps Internal: 0x0
  Link flags     : None
  Hold-times    : Up 0 ms, Down 0 ms
  CoS queues    : 8 supported, 8 maximum usable queues
  Last flapped  : 2012-10-28 02:12:40 PDT (22:32:13 ago)
  Statistics last cleared: 2012-10-29 00:44:52 PDT (00:00:01 ago)
  Egress queues: 8 supported, 4 in use
  Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	0	0	0

```

  Queue number:      Mapped forwarding classes
    0                best-effort
    1                expedited-forwarding
    2                assured-forwarding
    3                network-control
  DS1  alarms       : None
  DS1  defects      : None
  T1  media:
    Seconds      Count  State
    SEF          0      0 OK
    BEE          0      0 OK
    AIS          0      0 OK
    LOF          0      0 OK
    LOS          0      0 OK
    YELLOW       0      0 OK
    CRC Major    0      0 OK
    CRC Minor    0      0 OK

```

```

BPV                                0            0
EXZ                                0            0
LCV                                0            0
PCV                                0            0
CS                                 0            0
CRC                                0            0
LES                                0
ES                                 0
SES                                0
SEFS                               0
BES                                0
UAS                                0
SAToP configuration:
  Payload size: 192
  Idle pattern: 0xFF
  Octet aligned: Disabled
  Jitter buffer: packets: 8, latency: 7 ms, auto adjust: Disabled
  Excessive packet loss rate: sample period: 10000 ms, threshold: 30%
DS1 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Induced Error rate: 0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
SONET alarms : None
SONET defects : AIS-V, RDI-V
SONET vt:
  BIP-BIP2                          0            0
  REI-V                             0            0
  LOP-V                             0            0 OK
  AIS-V                             2            0 Defect Active
  RDI-V                             2            0 Defect Active
  UNEQ-V                            0            0 OK
  PLM-V                             0            0 OK
  ES-V                              0
  SES-V                              0
  UAS-V                             2
  ES-VFE                            0
  SES-VFE                           0
  UAS-VFE                           0
Received SONET overhead:
V5 : 0x07
V5(cmp) : 0x02
Transmitted SONET overhead:
V5 : 0x02
Packet Forwarding Engine configuration:
  Destination slot: 1
CoS information:
  Direction : Output
  CoS transmit queue
Limit      Bandwidth      Buffer Priority
           %      bps      %      usec
0 best-effort 95      1459200 95      0      low
none
3 network-control 5      76800 5      0      low
none

Logical interface t1-1/0/0:1:1.0 (Index 69) (SNMP ifIndex 580) (Generation 525)

Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: TDM-CCC-SATOP
CE info      Packets      Bytes Count
CE Tx        1005      192960
CE Rx        1004      192768
CE Rx Forwarded      0

```



```

CE Strayed          0
CE Lost             0
CE Malformed        0
CE Misinserted      0
CE AIS dropped       0
CE Dropped          1005      192960
CE Overrun Events    0
CE Underrun Events   0
Protocol ccc, MTU: 1504, Generation: 814, Route table: 0
Flags: Is-Primary

```

**show interfaces  
extensive (DS,  
TDM-CCC-CESoPSN)**

```

user@host>show interfaces ds-1/0/0:1:1 extensive
Physical interface: ds-1/0/0:1:1, Enabled, Physical link is Down
Interface index: 154, SNMP ifIndex: 597, Generation: 819
Link-level type: TDM-CCC-CESoPSN, MTU: 1504, Speed: 1536kbps, Loopback: None,
FCS: 16, Parent: ct1-1/0/0:1:1 Interface index 153
Device flags      : Present Running Down
Interface flags: Hardware-Down Point-To-Point SNMP-Traps Internal: 0x0
Link flags       : None
Hold-times       : Up 0 ms, Down 0 ms
CoS queues       : 8 supported, 8 maximum usable queues
Last flapped     : 2012-10-29 00:49:03 PDT (00:00:35 ago)
Statistics last cleared: Never
Egress queues: 8 supported, 4 in use
Queue counters:   Queued packets  Transmitted packets      Dropped packets

  0 best-effort          0              0              0
  1 expedited-fo         0              0              0
  2 assured-forw         0              0              0
  3 network-cont         0              0              0

Queue number:      Mapped forwarding classes
0                  best-effort
1                  expedited-forwarding
2                  assured-forwarding
3                  network-control

CESoPSN configuration:
Packetization latency: 1000 us
Idle pattern: 0xFF
Jitter buffer: packets: 8, latency: 8 ms, auto adjust: Disabled
Excessive packet loss rate: sample period: 10000 ms, threshold: 30%
DSO BERT configuration:
BERT time period: 10 seconds, Elapsed: 0 seconds
Induced Error rate: 0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
Destination slot: 1
CoS information:
Direction : Output
CoS transmit queue      Bandwidth      Buffer Priority
Limit                  %      bps      %      usec      low
  0 best-effort          95      1459200  95      0      low
none
  3 network-control      5       76800   5       0      low
none

Logical interface ds-1/0/0:1:1:1.0 (Index 69) (SNMP ifIndex 598) (Generation 549)

```

```

    Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: TDM-CCC-CESoPSN
CE info          Packets      Bytes  Count
CE Tx            0            0
CE Rx           35712        6856704
CE Rx Forwarded          0
CE Strayed            0
CE Lost              0
CE Malformed         0
CE Misinserted       0
CE AIS dropped       0
CE Dropped           0            0
CE Overrun Events                0
CE Underrun Events                1
Protocol ccc, MTU: 1504, Generation: 857, Route table: 0
  Flags: Is-Primary

```

## show interfaces (T3 or E3)

<b>Syntax</b>	show interfaces <i>interface-type</i> <brief   detail   extensive   terse> <descriptions> <media> <snmp-index <i>snmp-index</i> > <statistics>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified T3 or E3 interface.
<b>Options</b>	<p><i>interface-type</i>—On M Series and T Series routers, the T3 interface type is <b>t3-fpc/pic/port</b>, whereas the E3 interface type is <b>e3-fpc/pic/port</b>. On the J Series routers, the T3 interface type is <b>t3-pim/0/port</b>, whereas the E3 interface type is <b>e3-pim/0/port</b>.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces (T3, PPP) on page 475</a> <a href="#">show interfaces detail (T3, PPP) on page 475</a> <a href="#">show interfaces extensive (T3, PPP) on page 476</a> <a href="#">show interfaces (E3, Frame Relay) on page 477</a> <a href="#">show interfaces detail (E3, Frame Relay) on page 478</a> <a href="#">show interfaces extensive (E3, Frame Relay) on page 480</a>
<b>Output Fields</b>	<a href="#">Table 75 on page 465</a> lists the output fields for the <b>show interfaces</b> (T3 or E3) command. Output fields are listed in the approximate order in which they appear.

Table 75: T3 or E3 show interfaces Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive</b> none

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source. It can be <b>Internal</b> or <b>External</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>FCS</b>	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16</b> bits.	All levels
<b>Mode</b>	(T3 only) Whether C-bit parity mode or M13 mode is enabled.	All levels
<b>Long buildout</b>	(T3 only) Buildout setting: less than 255 feet (68 meters) or greater than 255 feet and shorter than 450 feet (137 meters).	All levels
<b>Framing</b>	(E3 only) Physical layer framing format used on the link. It can be <b>G751</b> or <b>Unframed</b> . The default is <b>G751</b> .	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Keepalive settings</b>	(PPP and HDLC) Configured settings for keepalives. <ul style="list-style-type: none"> <li><b>interval seconds</b>—Time in seconds between successive keepalive requests. The range is <b>10</b> seconds through <b>32,767</b> seconds, with a default of <b>10</b> seconds.</li> <li><b>down-count number</b>—Number of keepalive packets a destination must fail to receive before the network takes a link down. The range is <b>1</b> through <b>255</b>, with a default of <b>3</b>.</li> <li><b>up-count number</b>—Number of keepalive packets a destination must receive to change a link's status from down to up. The range is <b>1</b> through <b>255</b>, with a default of <b>1</b>.</li> </ul>	<b>detail extensive none</b>

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Keepalive statistics or Keepalive	<p>(PPP and HDLC) Information about keepalive packets.</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li><b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul>	detail extensive none
LMI settings	<p>(Frame Relay) Local Management Interface (LMI) settings (ANSI or ITU). ANSI LMI settings is the default. The format is <b>LMI settings: value, value... xx</b> seconds, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li><b>n391dte</b>—DTE full status polling interval (1–255)</li> <li><b>n392dce</b>—DCE error threshold (1–10)</li> <li><b>n392dte</b>—DTE error threshold (1–10)</li> <li><b>n393dce</b>—DCE monitored event count (1–10)</li> <li><b>n393dte</b>—DTE monitored event count (1–10)</li> <li><b>t391dte</b>—DTE polling timer (5–30 seconds)</li> <li><b>t392dce</b>—DCE polling verification timer (5–30 seconds)</li> </ul>	detail extensive none
LMI	<p>(Frame Relay) LMI statistics:</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: nn (last seen hh:mm:ss ago)</b>.</li> <li><b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: nn (last sent hh:mm:ss ago)</b>.</li> </ul>	detail extensive none
DTE statistics	<p>(Frame Relay) Statistics about messages transmitted from the data terminal equipment (DTE) to the data communications equipment (DCE):</p> <ul style="list-style-type: none"> <li><b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li><b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li><b>Enquiry responses received</b>—Number of enquiry responses received by the DTE from the DCE.</li> <li><b>Full enquiry responses received</b>—Number of full enquiry responses sent from the DTE to the DCE.</li> </ul>	detail extensive none
DCE statistics	<p>(Frame Relay) Statistics about messages transmitted from the DCE to the DTE:</p> <ul style="list-style-type: none"> <li><b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li><b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li><b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li><b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	detail extensive none

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Common statistics</b>	(Frame Relay) Statistics about messages sent between the DTE and the DCE: <ul style="list-style-type: none"> <li><b>Unknown messages received</b>—Number of received packets that do not fall into any category.</li> <li><b>Asynchronous updates received</b>—Number of link status peer changes received.</li> <li><b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li><b>Keepalive responses timedout</b>—Number of keepalive responses that timed out when no LMI packet was reported for <b>n392dte</b> or <b>n393dce</b> intervals. (See <b>LMI settings</b>.)</li> </ul>	<b>detail extensive none</b>
<b>Nonmatching DCE-end DLCIs</b>	(Frame Relay. Displayed only from the DTE.) Number of DLCIs configured from the DCE.	<b>detail extensive none</b>
<b>LCP state</b>	(PPP) Link Control Protocol state. <ul style="list-style-type: none"> <li><b>Conf-ack-received</b>—Acknowledgement was received.</li> <li><b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li><b>Conf-req-sent</b>—Request was sent.</li> <li><b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li><b>Opened</b>—LCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>NCP state</b>	(PPP) Network Control Protocol state. <ul style="list-style-type: none"> <li><b>Conf-ack-received</b>—Acknowledgement was received.</li> <li><b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li><b>Conf-req-sent</b>—Request was sent.</li> <li><b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li><b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>CHAP state</b>	(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction. <ul style="list-style-type: none"> <li><b>Chap-Resp-received</b>—Response received for the challenge sent, but CHAP not yet moved into the Success state. (Most likely with RADIUS authentication.)</li> <li><b>Chap-Resp-sent</b>—Response sent for the challenge received.</li> <li><b>Chap-Chal-sent</b>—Challenge sent.</li> <li><b>Chap-Chal-received</b>—Challenge received but response not yet sent.</li> <li><b>Down</b>—CHAP authentication is incomplete (not yet completed or has failed).</li> <li><b>Not-configured</b>—CHAP is not configured on the interface.</li> <li><b>Opened</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (year-month-day hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>CoS queues</b>	Number of CoS queues configured.	<b>detail extensive none</b>

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets received on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—(T3 only) Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—(T3 only) Number of frames received that are larger than the giant threshold.</li> <li>• <b>Bucket Drops</b>—Drops resulting from the traffic load exceeding the interface transmit/receive leaky bucket configuration. The default is <b>off</b>.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>SRAM errors</b>—Number of hardware errors that occurred in the static RAM (SRAM) on the PIC or PIM. If the value of this field increments, the PIC or PIM is malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Active alarms</b> <b>Active defects</b>	<p>E3 media-specific defects that can render the interface unable to pass packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface.</p> <ul style="list-style-type: none"> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>FERF</b>—Far-end receive failures</li> <li>• <b>IDLE</b>—Idle code detected</li> <li>• <b>LCD</b>—Loss of cell delineation</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>PLL</b>—Phase-locked loop</li> <li>• <b>YLW</b>—Remote defect indication</li> </ul>	<b>detail extensive none</b>



Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DS3 media or E3 media</b>	<p>Counts of DS3 (T3) or E3 media-specific errors.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than OK indicates a problem.</li> </ul> <p>The DS3 or E3 media-specific error types can be:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop out of lock</li> <li>• <b>Reframing</b>—Frame alignment recovery time</li> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>IDLE</b>—Idle code detected</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>PCV</b>—(DS3 only) Pulse code violation</li> <li>• <b>CCV</b>—(DS3 only) C-bit coding violation</li> <li>• <b>FEBE</b>—(DS3 only) Far-end block error</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>PES</b>—(DS3 only) P-bit errored seconds</li> <li>• <b>PSSES</b>—(DS3 only) P-bit errored seconds (section)</li> <li>• <b>CES</b>—(DS3 only) C-bit errored seconds</li> <li>• <b>CSES</b>—(DS3 only) C-bit severely errored seconds</li> <li>• <b>SEFS</b>—Severely errored framing seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> </ul>	<b>extensive</b>
<b>HDLC configuration</b>	<p>Information about the HDLC configuration.</p> <ul style="list-style-type: none"> <li>• <b>Policing bucket</b>—Configured state of the receiving policer.</li> <li>• <b>Shaping bucket</b>—Configured state of the transmitting shaper.</li> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> <li>• <b>Idle cycle flag</b>—Idle cycle flags.</li> <li>• <b>Start end flag</b>—Start and end flag.</li> </ul>	<b>extensive</b>

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DSU configuration</b>	<p>Information about the DSU configuration. The last three lines (<b>Bit count</b>, <b>Error bit count</b>, and <b>LOS information</b>) are displayed only if a BERT has ever been run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>Compatibility mod</b>—CSU/DSU compatibility mode: <b>None</b>, <b>Larscom</b>, <b>Kentrox</b>, or <b>Digital-Link</b>.</li> <li>• <b>Scrambling</b>—Payload scrambling: <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Subrate</b>—Configured subrate setting. Applies only when <b>Digital-Link</b> compatibility mode is used. The subrate can be <b>Disabled</b> or display units in Kbps.</li> <li>• <b>FEAC loopbac</b>—(T3) Whether a far-end alarm and control (FEAC) loopback is <b>Active</b> or <b>Inactive</b>. This feature is used to send alarm or status information from the far-end terminal back to the near-end terminal and to initiate T3 loopbacks at the far-end terminal from the near-end terminal.</li> <li>• <b>Response</b>—Whether the FEAC signal is <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Count</b>—Number of FEAC loopbacks.</li> </ul>	<b>extensive</b>
<b>DS3 (or E3) BERT configuration</b>	<p>BERT (bit error rate test) checks the quality of the line. This output appears only when a BERT is run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>BERT time period</b>—Configured total time period that the BERT is to run.</li> <li>• <b>Elapsed</b>—Actual time elapsed since the start of the BERT (in seconds).</li> <li>• <b>Induced error rate</b>—Configured rate at which the bit errors are induced in the BERT pattern.</li> <li>• <b>Algorithm</b>—Type of algorithm selected for the BERT.</li> </ul>	<b>detail extensive none</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>
<b>CoS information</b>	<p>Information about the CoS queue for the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>

---

**Logical Interface**


---

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Logical interface</b>	Name of the logical interface.	<b>detail extensive none</b>
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>extensive</b>
<b>Flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Encapsulation</b>	Encapsulation on the logical interface.	<b>detail extensive none</b>
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	<p>(Frame Relay) Number and rate of bytes and packets received and transmitted on the logical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	(Frame Relay) Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	(Frame Relay) Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. This counter normally stabilizes in less than 1 second.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mlfr</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b>Multilink bundle</b>	(Multilink) Interface name for the multilink bundle.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>

Table 75: T3 or E3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive none</b>
<b>DLCI</b>	<p>(Frame Relay) DLCI number of the logical interface. The following DLCI information is displayed: <b>Flags</b>, <b>Total down time</b>, <b>Last down</b>, and <b>Traffic statistics</b> (or <b>Input packets</b>, <b>Output packets</b>). <b>Flags</b> is one or more of the following:</p> <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when the link is active, but no information is received from the DCE.</li> <li>• <b>DCE Unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the corresponding DLCI in the DCE is configured.</li> <li>• <b>DCE-configured</b>—Displayed when the command is issued from the DTE.</li> </ul>	<b>detail extensive none</b>
<b>DLCI statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	<b>detail extensive none</b>

## Sample Output

### show interfaces (T3, PPP)

```

user@host> show interfaces t3-0/2/0
Physical interface: t3-0/2/0, Enabled, Physical link is Up
  Interface index: 139, SNMP ifIndex: 35
  Link-level type: PPP, MTU: 4474, Clocking: Internal, Speed: T3,
  Loopback: None, FCS: 16, Mode: C/Bit parity,
  Long buildout: Shorter than 255 feet
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 0 (never), Output: 0 (never)
  LCP state: Down
  NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Closed
  CoS queues     : 4 supported, 4 in use
  Last flapped   : 2005-12-05 08:43:06 PST (02:18:40 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 72 bps (0 pps)
  Active alarms  : None
  Active defects : None
  DS3 BERT configuration:
    BERT time period: 10 seconds, Elapsed: 0 seconds
    Algorithm: 2^15 - 1, 0.151, Pseudorandom (9), Induced error rate: 10e-0

Logical interface t3-0/2/0.0 (Index 66) (SNMP ifIndex 54)
  Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP
  Protocol inet, MTU: 4470
  Flags: Protocol-Down
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255

```

### show interfaces detail (T3, PPP)

```

user@host> show interfaces t3-0/2/0 detail
Physical interface: t3-0/2/0, Enabled, Physical link is Up
  Interface index: 139, SNMP ifIndex: 35, Generation: 22
  Link-level type: PPP, MTU: 4474, Clocking: Internal, Speed: T3,
  Loopback: None, FCS: 16, Mode: C/Bit parity,
  Long buildout: Shorter than 255 feet
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Hold-times     : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 0 (last seen: never)
    Output: 0 (last sent: never)
  LCP state: Down
  NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Closed
  CoS queues     : 4 supported, 4 in use
  Last flapped   : 2005-12-05 08:43:06 PST (02:18:45 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   : 0 0 bps
    Output bytes  : 152 0 bps
    Input packets : 0 0 pps

```

Output packets:	8	0 pps
Queue counters:	Queued packets	Transmitted packets      Dropped packets
0 best-effort	0	0
1 expedited-fo	0	0
2 assured-forw	0	0
3 network-cont	6	6

Active alarms : None  
Active defects : None  
DS3 BERT configuration:  
BERT time period: 10 seconds, Elapsed: 0 seconds  
Algorithm: 2^15 - 1, 0.151, Pseudorandom (9), Induced error rate: 10e-0

Logical interface t3-0/2/0.0 (Index 66) (SNMP ifIndex 54) (Generation 8)  
Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP  
Protocol inet, MTU: 4470, Generation: 17, Route table: 0  
Flags: Protocol-Down  
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary  
Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255,  
Generation: 24

#### show interfaces extensive (T3, PPP)

```
user@host> show interfaces t3-0/2/0 extensive
Physical interface: t3-0/2/0, Enabled, Physical link is Up
Interface index: 139, SNMP ifIndex: 35, Generation: 22
Link-level type: PPP, MTU: 4474, Clocking: Internal, Speed: T3,
Loopback: None, FCS: 16, Mode: C/Bit parity,
Long buildout: Shorter than 255 feet
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives
Hold-times     : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 0 (last seen: never)
  Output: 0 (last sent: never)
LCP state: Down
NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
mpls: Not-configured
CHAP state: Closed
CoS queues   : 4 supported, 4 in use
Last flapped : 2005-12-05 08:43:06 PST (02:18:47 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes :          0          0 bps
Output bytes :        171         72 bps
Input packets:          0          0 pps
Output packets:         9          0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Bucket drops: 0, Policed discards: 0, L3 incompletes: 0,
L2 channel errors: 0, L2 mismatch timeouts: 0, HS link CRC errors: 0,
SRAM errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,

Resource errors: 0
Queue counters:      Queued packets  Transmitted packets      Dropped packets
```

0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	7	7	0

Active alarms : None

Active defects : None

DS3 media:	Seconds	Count	State
PLL Lock	0	0	OK
Reframing	0	0	OK
AIS	0	0	OK
LOF	0	0	OK
LOS	0	0	OK
IDLE	0	0	OK
YELLOW	0	0	OK
BPV	0	0	
EXZ	0	0	
LCV	1	4	
PCV	0	0	
CCV	0	0	
FEBE	1	11	
LES	1		
PES	0		
PSES	0		
CES	0		
CSES	0		
SEFS	0		
UAS	0		

HDLC configuration:

Policing bucket: Disabled

Shaping bucket : Disabled

Giant threshold: 4484, Runt threshold: 3

Idle cycle flag: flags, Start end flag: shared

DSU configuration:

Compatibility mode: None, Scrambling: Disabled, Subrate: Disabled

FEAC loopback: Inactive, Response: Disabled, Count: 0

DS3 BERT configuration:

BERT time period: 10 seconds, Elapsed: 0 seconds

Algorithm:  $2^{15} - 1$ , 0.151, Pseudorandom (9), Induced error rate: 10e-0

Packet Forwarding Engine configuration:

Destination slot: 0, PLP byte: 1 (0x00)

CoS information:

CoS transmit queue	%	Bandwidth bps	%	Buffer usec	Priority	Limit
0 best-effort	95	42499200	95	0	low	none
3 network-control	5	2236800	5	0	low	none

Logical interface t3-0/2/0.0 (Index 66) (SNMP ifIndex 54) (Generation 8)

Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP

Protocol inet, MTU: 4470, Generation: 17, Route table: 0

Flags: Protocol-Down

Addresses, Flags: Dest-route-down Is-Preferred Is-Primary

Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255,

Generation: 24

**show interfaces**

user@host> **show interfaces e3-1/2/0**

Physical interface: e3-1/2/0, Enabled, Physical link is Up

**(E3, Frame Relay)**

```

Interface index: 153, SNMP ifIndex: 49
Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, Speed: E3,
Loopback: None, FCS: 16, Framing: G751
Device flags   : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives DTE
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI: Input: 0 (never), Output: 4 (00:00:06 ago)
DTE statistics:
  Enquiries sent           : 4
  Full enquiries sent      : 0
  Enquiry responses received : 0
  Full enquiry responses received : 0
DCE statistics:
  Enquiries received       : 0
  Full enquiries received  : 0
  Enquiry responses sent   : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout : 1
CoS queues   : 4 supported, 4 in use
Last flapped : 2005-12-05 08:46:14 PST (02:27:17 ago)
Input rate   : 0 bps (0 pps)
Output rate  : 0 bps (0 pps)
Active alarms : None
Active defects : None

Logical interface e3-1/2/0.0 (Index 66) (SNMP ifIndex 57)
  Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
Input packets : 0
Output packets: 0
  Protocol inet, MTU: 4470
  Flags: None
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255
  DLCI 100
    Flags: Down, DCE-Unconfigured
    Total down time: 00:00:06 sec, Last down: 00:00:06 ago
    Input packets : 0
    Output packets: 0
  DLCI statistics:
    Active DLCI :0 Inactive DLCI :1

```

**show interfaces detail  
(E3, Frame Relay)**

```

user@host> show interfaces e3-1/2/0 detail
Physical interface: e3-1/2/0, Enabled, Physical link is Up
Interface index: 153, SNMP ifIndex: 49, Generation: 36
Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, Speed: E3,
Loopback: None, FCS: 16, Framing: G751
Device flags   : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives DTE
Hold-times     : Up 0 ms, Down 0 ms
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI statistics:
  Input : 0 (last seen: never)
  Output: 5 (last sent 00:00:07 ago)
DTE statistics:
  Enquiries sent           : 5

```



```

Full enquiries sent           : 0
Enquiry responses received    : 0
Full enquiry responses received : 0
DCE statistics:
  Enquiries received          : 0
  Full enquiries received     : 0
  Enquiry responses sent      : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received   : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout : 1
CoS queues      : 4 supported, 4 in use
Last flapped   : 2005-12-05 08:46:14 PST (02:27:27 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :           0          0 bps
  Output bytes :          806          0 bps
  Input packets:           0          0 pps
  Output packets:          44          0 pps
Queue counters:      Queued packets  Transmitted packets  Dropped packets

  0 best-effort           0              0              0
  1 expedited-fo          0              0              0
  2 assured-forw          0              0              0
  3 network-cont         43             43              0

Active alarms : None
Active defects : None

Logical interface e3-1/2/0.0 (Index 66) (SNMP ifIndex 57) (Generation 15)
Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
Traffic statistics:
  Input bytes :           0
  Output bytes :           0
  Input packets:           0
  Output packets:           0
Local statistics:
  Input bytes :           0
  Output bytes :           0
  Input packets:           0
  Output packets:           0
Transit statistics:
  Input bytes :           0          0 bps
  Output bytes :           0          0 bps
  Input packets:           0          0 pps
  Output packets:           0          0 pps
Protocol inet, MTU: 4470, Generation: 24, Route table: 0
  Flags: None
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255,
    Generation: 38
  DLCI 100
  Flags: Down, DCE-Unconfigured
  Total down time: 00:00:16 sec, Last down: 00:00:16 ago
  Traffic statistics:
    Input bytes :           0

```

```

        Output bytes :          0
        Input packets:          0
        Output packets:         0
DLCI statistics:
    Active DLCI :0 Inactive DLCI :1

```

### show interfaces extensive (E3, Frame Relay)

```

user@host> show interfaces e3-1/2/0 extensive
Physical interface: e3-1/2/0, Enabled, Physical link is Up
  Interface index: 153, SNMP ifIndex: 49, Generation: 36
  Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, Speed: E3,
  Loopback: None, FCS: 16, Framing: G751
  Device flags : Present Running
  Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags : Keepalives DTE
  Hold-times : Up 0 ms, Down 0 ms
  ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
  LMI statistics:
    Input : 0 (last seen: never)
    Output: 6 (last sent 00:00:02 ago)
  DTE statistics:
    Enquiries sent : 5
    Full enquiries sent : 1
    Enquiry responses received : 0
    Full enquiry responses received : 0
  DCE statistics:
    Enquiries received : 0
    Full enquiries received : 0
    Enquiry responses sent : 0
    Full enquiry responses sent : 0
  Common statistics:
    Unknown messages received : 0
    Asynchronous updates received : 0
    Out-of-sequence packets received : 0
    Keepalive responses timeout : 1
  CoS queues : 4 supported, 4 in use
  Last flapped : 2005-12-05 08:46:14 PST (02:27:30 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :          0          0 bps
    Output bytes :        821          56 bps
    Input packets:          0          0 pps
    Output packets:        45          0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 21118, Bucket drops: 0,
    Policed discards: 0, L3 incompletes: 0, L2 channel errors: 0,
    L2 mismatch timeouts: 0, HS link CRC errors: 0, SRAM errors: 0,
    Resource errors: 0
  Output errors:
    Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,
    Resource errors: 0
  Queue counters:

```

Queue counters:	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	44	44	0

```

Active alarms : None
Active defects : None
E3 media:
Seconds      Count  State
PLL Lock      0        0 OK
Reframing    187        1 OK
AIS           0        0 OK
LOF          187        1 OK
LOS          187        1 OK
IDLE         0        0 OK
YELLOW       0        0 OK
BPV          0        0
EXZ          0        0
LCV          188    12303167
LES          188
SEFS         187
UAS          195
DSU configuration:
  Compatibility mode: None, Scrambling: Disabled
E3 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Algorithm: 2^15 - 1, 0.151, Pseudorandom (9), Induced Error rate: 10e-0
Packet Forwarding Engine configuration:
  Destination slot: 1, PLP byte: 1 (0x00)
CoS information:
CoS transmit queue      Bandwidth      Buffer  Priority  Limit
                        %      bps      %      usec
0 best-effort          95    32649600  95        0      low  none
3 network-control      5     1718400   5        0      low  none

Logical interface e3-1/2/0.0 (Index 66) (SNMP ifIndex 57) (Generation 15)
Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Local statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
Protocol inet, MTU: 4470, Generation: 24, Route table: 0
Flags: None
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255,
Generation: 38
DLCI 100
Flags: Down, DCE-Unconfigured
Total down time: 00:00:19 sec, Last down: 00:00:19 ago
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
DLCI statistics:
Active DLCI :0 Inactive DLCI :1

```



## PART 4

# IP Demux Interfaces

- [IP Demux Interface Operational Mode Commands on page 485](#)



## CHAPTER 7

# IP Demux Interface Operational Mode Commands

Table 76 on page 485 summarizes the command-line interface (CLI) command that you can use to monitor and troubleshoot MPLS pseudowire subscriber interfaces.

**Table 76: MPLS Pseudowire Subscriber Interfaces Operational Mode Commands**

Task	Command
Display MPLS pseudowire subscriber interface information.	show interfaces ps0 (Pseudowire Subscriber Interfaces)

## show interfaces demux0 (Demux Interfaces)

<b>Syntax</b>	<code>show interfaces demux0.logical-interface-number</code> <code>&lt;brief   detail   extensive   terse&gt;</code> <code>&lt;descriptions&gt;</code> <code>&lt;media&gt;</code> <code>&lt;snmp-index snmp-index&gt;</code> <code>&lt;statistics&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 9.0.
<b>Description</b>	(MX Series and M Series routers only) Display status information about the specified demux interface.
<b>Options</b>	<p><b>none</b>—Display standard information about the specified demux interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying and Managing Agent Circuit Identifier-Based Dynamic VLAN Configuration</li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces (Demux) on page 493</a> <a href="#">show interfaces (PPPoE over Aggregated Ethernet) on page 494</a> <a href="#">show interfaces extensive (Targeted Distribution for Aggregated Ethernet Links) on page 494</a> <a href="#">show interfaces demux0 (ACI Interface Set Configured) on page 495</a>
<b>Output Fields</b>	Table 77 on page 486 lists the output fields for the <b>show interfaces</b> (demux interfaces) command. Output fields are listed in the approximate order in which they appear.

Table 77: Demux show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	brief detail extensive none
<b>Interface index</b>	Index number of the physical interface, which reflects its initialization sequence.	brief detail extensive none



Table 77: Demux show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	brief detail extensive none
<b>Physical link</b>	Status of the physical link ( <b>Up</b> or <b>Down</b> ).	detail extensive none
<b>Admin</b>	Administrative state of the interface ( <b>Up</b> or <b>Down</b> ).	terse
<b>Interface index</b>	Index number of the physical interface, which reflects its initialization sequence.	detail extensive none
<b>Link</b>	Status of the physical link ( <b>Up</b> or <b>Down</b> ).	terse
<b>Targeting summary</b>	Status of aggregated Ethernet links that are configured with targeted distribution ( <b>primary</b> or <b>backup</b> )	extensive
<b>Bandwidth</b>	Bandwidth allocated to the aggregated Ethernet links that are configured with targeted distribution.	extensive
<b>Proto</b>	Protocol family configured on the interface.	terse
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	detail extensive none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	detail extensive
<b>Type</b>	Type of interface. <b>Software-Pseudo</b> indicates a standard software interface with no associated hardware device.	brief detail extensive none
<b>Link-level type</b>	Encapsulation being used on the physical interface.	brief detail extensive
<b>MTU</b>	Maximum transmission unit size on the physical interface.	brief detail extensive
<b>Clocking</b>	Reference clock source: <b>Internal</b> (1) or <b>External</b> (2).	brief detail extensive
<b>Speed</b>	Speed at which the interface is running.	brief detail extensive
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	brief detail extensive none
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	brief detail extensive none
<b>Link type</b>	Data transmission type.	detail extensive none
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	detail extensive none
<b>Physical info</b>	Information about the physical interface.	detail extensive
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	detail extensive

Table 77: Demux show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Current address	Configured MAC address.	detail extensive
Hardware address	Hardware MAC address.	detail extensive
Alternate link address	Backup address of the link.	detail extensive
Last flapped	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second:timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	detail extensive none
Statistics last cleared	Time when the statistics for the interface were last set to zero.	detail extensive
Traffic statistics	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> <li>• <b>IPv6 transit statistics</b>—Number of IPv6 transit bytes and packets received and transmitted on the physical interface if IPv6 statistics tracking is enabled.</li> </ul> <p><b>NOTE:</b> These fields include dropped traffic and exception traffic, as those fields are not separately defined.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	detail extensive
Input errors	<p>Input errors on the interface whose definitions are as follows:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant packet threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	extensive
Input Rate	Input rate in bits per second (bps) and packets per second (pps).	none

Table 77: Demux show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious: <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output Rate</b>	Output rate in bps and pps.	none
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	<b>brief detail extensive</b> none
<b>Index</b>	Index number of the logical interface, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP interface index number for the logical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>brief detail extensive</b> none
<b>Encapsulation</b>	Encapsulation on the logical interface.	<b>brief extensive</b> none
<b>ACI VLAN: Dynamic Profile</b>	Name of the dynamic profile that defines the agent circuit identifier (ACI) interface set. If configured, the ACI interface set enables the underlying demux interface to create dynamic VLAN subscriber interfaces based on ACI information.	<b>brief detail extensive</b> none
<b>Demux</b>	Specific IP demultiplexing (demux) values: <ul style="list-style-type: none"> <li>• <b>Underlying interface</b>—The underlying interface that the demux interface uses.</li> <li>• <b>Index</b>—Index number of the logical interface.</li> <li>• <b>Family</b>—Protocol family configured on the logical interface.</li> <li>• <b>Source prefixes, total</b>—Total number of source prefixes for the underlying interface.</li> <li>• <b>Destination prefixes, total</b>—Total number of destination prefixes for the underlying interface.</li> <li>• <b>Prefix—in</b>et family prefix.</li> </ul>	<b>detail extensive</b> none

Table 77: Demux show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<i>protocol-family</i>	Protocol family configured on the logical interface.	<b>brief</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the specified interface set.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface set.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface set.</li> <li>• <b>IPv6 transit statistics</b>—Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.</li> </ul> <p><b>NOTE:</b> The packet and byte counts in these fields include traffic that is dropped and does not leave the router.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	<p>Number of transit bytes and packets received and transmitted on the local interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Transit statistics</b>	<p>Number and rate of bytes and packets transiting the switch.</p> <p><b>NOTE:</b> The packet and byte counts in these fields include traffic that is dropped and does not leave the router.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>IPv6 Transit statistics</b>	<p>Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.</p> <p><b>NOTE:</b> The packet and byte counts in these fields include traffic that is dropped and does not leave the router.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input packets</b>	Number of packets received on the interface.	<b>none</b>

Table 77: Demux show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output packets</b>	Number of packets transmitted on the interface.	none
<b>Protocol</b>	Protocol family. Possible values are described in the "Protocol Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	detail extensive none
<b>MTU</b>	Maximum transmission unit size on the logical interface.	detail extensive none
<b>Maximum labels</b>	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	detail extensive none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	detail extensive
<b>Route table</b>	Route table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	detail extensive
<b>Flags</b>	Information about protocol family flags. Possible values are described in the "Family Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	detail extensive none
<b>Mac-Validate Failures</b>	Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface.	detail extensive none
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the "Addresses Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	detail extensive none
<b>Destination</b>	IP address of the remote side of the connection.	detail extensive statistics none
<b>Local</b>	IP address of the logical interface.	detail extensive terse none
<b>Remote</b>	IP address of the remote interface.	terse
<b>Broadcast</b>	Broadcast address of the logical interface.	detail extensive none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	detail extensive
<b>Link</b>	Name of the physical interfaces for member links in an aggregated Ethernet bundle for a PPPoE over aggregated Ethernet configuration. PPPoE traffic goes out on these interfaces.	detail extensive none
<b>Dynamic-profile</b>	Name of the PPPoE dynamic profile assigned to the underlying interface.	detail extensive none
<b>Service Name Table</b>	Name of the PPPoE service name table assigned to the PPPoE underlying interface.	detail extensive none
<b>Max Sessions</b>	Maximum number of dynamic PPPoE logical interfaces that the router can activate on the underlying interface.	detail extensive none

Table 77: Demux show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Duplicate Protection</b>	State of duplicate protection: <b>On</b> or <b>Off</b> . Duplicate protection prevents the activation of another dynamic PPPoE logical interface on the same underlying interface when a dynamic PPPoE logical interface for a client with the same MAC address is already active on that interface.	<b>detail extensive none</b>
<b>AC Name</b>	Name of the access concentrator.	<b>detail extensive none</b>

## Sample Output

### show interfaces (Demux)

```

user@host> show interfaces demux0
Physical interface: demux0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 79, Generation: 129
  Type: Software-Pseudo, Link-level type: Unspecified, MTU: 9192, Clocking: 1,
  Speed: Unspecified
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : Never
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
  IPv6 transit statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
    Resource errors: 0

Logical interface demux0.0 (Index 87) (SNMP ifIndex 84) (Generation 312)
  Flags: SNMP-Traps 0x4000 Encapsulation: ENET2
  Demux:
    Underlying interface: ge-2/0/1.0 (Index 74)
    Family Inet Source prefixes, total 1
    Prefix: 1.1.1/24
    Traffic statistics:
      Input bytes   :                0
      Output bytes  :             1554
      Input packets :                0
      Output packets:             37
    IPv6 transit statistics:
      Input bytes   :                0
      Output bytes  :                0
      Input packets :                0
      Output packets:                0
    Local statistics:
      Input bytes   :                0
      Output bytes  :             1554
      Input packets :                0
      Output packets:             37
    Transit statistics:
      Input bytes   :                0                0 bps
      Output bytes  :                0                0 bps
      Input packets :                0                0 pps
      Output packets:                0                0 pps

```

```
IPv6 transit statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Protocol inet, MTU: 1500, Generation: 395, Route table: 0
  Flags: Is-Primary, Mac-Validate-Strict
  Mac-Validate Failures: Packets: 0, Bytes: 0
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 11.1.1/24, Local: 11.1.1.1, Broadcast: 11.1.1.255,
    Generation: 434
```

**show interfaces**  
**(PPPoE over**  
**Aggregated Ethernet)**

```
user@host> show interfaces demux0.100
Logical interface demux0.100 (Index 76) (SNMP ifIndex 61160)
  Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.100 ]
  Encapsulation: ENET2
  Demux:
    Underlying interface: ae0 (Index 199)
  Link:
    ge-1/0/0
    ge-1/1/0
  Input packets : 0
  Output packets: 0
  Protocol pppoe
    Dynamic Profile: pppoe-profile,
    Service Name Table: service-table1,
    Max Sessions: 100, Duplicate Protection: On,
    AC Name: pppoe-server-1
```

**show interfaces**  
**extensive (Targeted**  
**Distribution for**

```
user@host> show interfaces demux0.1073741824 extensive

Logical interface demux0.1073741824 (Index 75) (SNMP ifIndex 558) (Generation
346)
```



### Aggregated Ethernet Links)

```
Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.1 ] Encapsulation: ENET2
Demux:
  Underlying interface: ae0 (Index 201)
Link:
  ge-1/0/0
  ge-1/1/0
  ge-2/0/7
  ge-2/0/8
Targeting summary:
  ge-1/1/0, primary, Physical link is Up
  ge-2/0/8, backup, Physical link is Up
Bandwidth: 1000mbps
```

### show interfaces demux0 (ACI Interface Set Configured)

```
user@host> show interfaces demux0.1073741827
Logical interface demux0.1073741827 (Index 346) (SNMP ifIndex 527)
Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.1802 0x8100.302 ] Encapsulation:
ENET2
Demux: Source Family Inet
ACI VLAN:
  Dynamic Profile: aci-vlan-set-profile
Demux:
  Underlying interface: ge-1/0/0 (Index 138)
Input packets : 18
Output packets: 16
Protocol inet, MTU: 1500
  Flags: Sendbcst-pkt-to-re, Unnumbered
  Donor interface: lo0.0 (Index 322)
  Preferred source address: 100.20.200.202
  Addresses, Flags: Primary Is-Default Is-Primary
    Local: 10.4.12.119
Protocol pppoe
  Dynamic Profile: aci-vlan-pppoe-profile,
  Service Name Table: None,
  Max Sessions: 32000, Max Sessions VSA Ignore: Off,
  Duplicate Protection: On, Short Cycle Protection: Off,
  AC Name: nbc
```



## PART 5

# PPP and PPPoE Interfaces

- [PPP Interface Operational Mode Commands on page 499](#)
- [PPPoE Interface Operational Mode Commands on page 521](#)



## CHAPTER 8

# PPP Interface Operational Mode Commands


Table 78 on page 499 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot Point-to-Point Protocol (PPP) interfaces. Commands are listed in alphabetical order.

**Table 78: PPP Interfaces Operational Mode Commands**

Task	Command
Clear PPP statistics.	<code>clear ppp statistics</code>
Display PPP address pool information.	<code>show ppp address-pool</code>
Display PPP session information for an interface.	<code>show ppp interface</code>
Display PPP session statistics.	<code>show ppp statistics</code>
Display summary information about PPP-configured interfaces.	<code>show ppp summary</code>

## clear ppp statistics

---

<b>Syntax</b>	clear ppp statistics <interface <i>interface-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 7.6.
<b>Description</b>	Reset PPP session statistics information.
	<div> <b>NOTE:</b> This command is not supported on PPPoE (pp0) and Inline Service (SI) interfaces.</div>
<b>Options</b>	<b>none</b> —Reset PPP statistics for all interfaces.  <b>interface <i>interface-name</i></b> —(Optional) Reset PPP statistics for the specified interface.
<b>Required Privilege Level</b>	clear
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show pppoe statistics on page 551</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear ppp statistics on page 500</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

**clear ppp statistics**      user@host> clear ppp statistics

## show ppp address-pool

<b>Syntax</b>	<code>show ppp address-pool <i>pool-name</i> &lt;detail&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 7.5.
<b>Description</b>	Display PPP address pool information.
<b>Options</b>	<p><i>pool-name</i>—Address pool name.</p> <p><b>detail</b>—(Optional) Display detailed address pool information.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show ppp address-pool on page 502</a></p> <p><a href="#">show ppp address-pool detail on page 502</a></p>
<b>Output Fields</b>	<p><a href="#">Table 79 on page 501</a> lists the output fields for the <b>show ppp address-pool</b> command. Output fields are listed in the approximate order in which they appear.</p>

**Table 79: show ppp address-pool Output Fields**

Field Name	Field Description	Level of Output
<b>Address pool</b>	Trace address pool code.	All levels
<b>Address range</b>	Range of sequentially ordered IP addresses contained in the address pool.	<b>detail</b>
<b>Number of assigned addresses</b>	Fixed IP address that is to be given to remote users when they dial in. This is a host-only IP address (subnet mask is 255.255.255.255) and is only for single connection receiver profiles.	All levels
<b>Number of addresses configured</b>	Number of IP addresses that are available for allocation and used by PPP sessions.	All levels
<b>Assigned addresses</b>	Addresses assigned to PPP sessions from the address pool.	<b>detail</b>

## Sample Output

**show ppp  
address-pool**

```
user@host> show ppp address-pool
Address pool ppp1
  Address range: 10.10.220.1 - 10.10.220.10
  Number of assigned addresses: 0
  Number of addresses configured: 10
```

**show ppp  
address-pool detail**

```
user@host> show ppp address-pool ppp1 detail
Address pool ppp1
  Address range: 10.10.220.1 - 10.10.220.10
  Number of assigned addresses: 2
  Number of addresses configured: 10
  Assigned addresses:
    10.10.220.1
    10.10.220.2
```



## show ppp interface

<b>Syntax</b>	<code>show ppp interface <i>interface-name</i></code> <code>&lt;extensive  terse&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 7.5.
<b>Description</b>	Display information about PPP interfaces.
<b>Options</b>	<i>interface-name</i> —Name of a logical interface.  <b>extensive   terse</b> —(Optional) Display the specified level of output.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show ppp interface on page 511</a> <a href="#">show ppp interface extensive on page 511</a> <a href="#">show ppp interface terse on page 511</a>
<b>Output Fields</b>	<a href="#">Table 80 on page 503</a> lists the output fields for the <b>show ppp interface</b> command. Output fields are listed in the approximate order in which they appear.

**Table 80: show ppp interface Output Fields**

Field Name	Field Description	Level of Output
<b>Session</b>	Name of the logical interface on which the session is running.	All levels
<b>Type</b>	Session type: PPP.	All levels
<b>Phase</b>	PPP process phase: <b>Authenticate</b> , <b>Pending</b> , <b>Establish</b> , <b>LCP</b> , <b>Network</b> , <b>Disabled</b> , and <b>Tunneled</b> .	All levels
<b>Session flags</b>	Special conditions present in the session: <b>Bundled</b> , <b>TCC</b> , <b>No-keepalives</b> , <b>Looped</b> , <b>Monitored</b> , and <b>NCP-only</b> .	All levels
<b><i>protocol</i> State</b>	Protocol state information. See specific protocol state fields for information.	None specified
<b>AUTHENTICATION</b>	Challenge-Handshake Authentication Protocol (CHAP) authentication state information or Password Authentication Protocol (PAP) state information. See the <b>Authentication</b> field description for further information.	None specified

Table 80: show ppp interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Keepalive settings</b>	<p>Keepalive settings for the PPP sessions on the L2TP network server (LNS). LNS based PPP sessions are supported only on service interfaces (si).</p> <ul style="list-style-type: none"> <li>• <b>Interval</b>—Time in seconds between successive keepalive requests. Keepalive aging timeout is calculated as a product of the <b>interval</b> and <b>Down-count</b> values. If the keepalive aging timeout is greater than 180 seconds, the keepalive packets are handled by the Routing Engine. If the aging timeout is less than or equal to 180 seconds, the packets are handled by the Packet Forwarding Engine.</li> <li>• <b>Up-count</b>—The number of keepalive packets a destination must receive to change a link's status from down to up.</li> <li>• <b>Down-count</b>—The number of keepalive packets a destination must fail to receive before the network takes down a link.</li> </ul>	<b>extensive</b>
<b>RE Keepalive statistics</b>	<p>Keepalive statistics for the packets handled by the Routing Engine.</p> <ul style="list-style-type: none"> <li>• <b>LCP echo req Tx</b>—LCP echo requests sent from the Routing Engine.</li> <li>• <b>LCP echo req Rx</b>—LCP echo requests received at the Routing Engine.</li> <li>• <b>LCP echo rep Tx</b>—LCP echo responses sent from the Routing Engine.</li> <li>• <b>LCP echo rep Rx</b>—LCP echo responses received at the Routing Engine.</li> <li>• <b>LCP echo req timeout</b>—Number of keepalive packets where the keepalive aging timer has expired.</li> <li>• <b>LCP Rx echo req Magic Num Failures</b>—LCP echo requests where the magic numbers shared between the PPP peers during LCP negotiation did not match.</li> <li>• <b>LCP Rx echo rep Magic Num Failures</b>—LCP echo responses where the magic numbers shared between the PPP peers during LCP negotiation did not match.</li> </ul>	<b>extensive</b>

Table 80: show ppp interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
LCP	<p><b>LCP information:</b></p> <ul style="list-style-type: none"> <li>• <b>State</b>—LCP protocol state (all platforms except M120 and M320 routers): <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is not available for traffic.</li> <li>• <b>Opened</b>—Link is administratively available for traffic.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection.</li> </ul> </li> <li>• <b>State</b>—LCP protocol state (M120 and M320 routers): <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is available (up), but no Open has occurred.</li> <li>• <b>Closing</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> <li>• <b>Opened</b>—Link is administratively available for traffic. A Configure-Ack has been both sent and received.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection. A Configure-Request has been sent but a Configure-Ack has not yet been received.</li> <li>• <b>Starting</b>—An administrative Open has been initiated, but the lower layer is still unavailable (Down).</li> <li>• <b>Stopped</b>—The system is waiting for a Down event after the This-Layer-Finished action, or after sending a Terminate-Ack.</li> <li>• <b>Stopping</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> </ul> </li> <li>• <b>Last started</b>—LCP state start time.</li> <li>• <b>Last completed</b>—LCP state completion time.</li> </ul>	extensive

Table 80: show ppp interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
	<ul style="list-style-type: none"> <li>• <b>Negotiated options:</b> <ul style="list-style-type: none"> <li>• <b>ACFC</b>—Address and-Control Field Compression. A configuration option that provides a method to negotiate the compression of the Data Link Layer Address and Control fields.</li> <li>• <b>Asynchronous map</b>—Asynchronous control character map. A configuration option used on asynchronous links such as telephone lines to identify control characters that must be replaced by a two-character sequence to prevent them from being interpreted by equipment used to establish the link.</li> <li>• <b>Authentication protocol</b>—Protocol used for authentication. This option provides a method to negotiate the use of a specific protocol for authentication. It requires a peer to authenticate itself before allowing network-layer protocol packets to be exchanged. By default, authentication is not required.</li> <li>• <b>Authentication algorithm</b>—Type of authentication algorithm. The Message Digest algorithm (MD5) is the only algorithm supported.</li> <li>• <b>Endpoint discriminator class</b>—For multilink PPP (MLPPP), a configuration option that identifies the system transmitting the packet. This option advises a system that the peer on this link could be the same as the peer on another existing link.</li> <li>• <b>Magic number</b>—A configuration option that provides a method to detect looped-back links and other data-link layer anomalies. By default, the magic number is not negotiated.</li> <li>• <b>MRU</b>—Maximum receive unit. A configuration option that may be sent to inform the peer that the implementation can receive larger packets, or to request that the peer send smaller packets. The default value is 1500 octets.</li> <li>• <b>MRRU</b>—For multilink PPP, the maximum receive reconstructed unit. A configuration option that specifies the maximum number of octets in the Information fields of reassembled packets.</li> <li>• <b>Multilink header suspendable classes</b>—For MLPPP, an LCP option that advises the peer that the implementation wishes to receive fragments with a format given by the code number, with the maximum number of suspendable classes given.</li> <li>• <b>Multilink header format classes</b>—For MLPPP, an LCP option that advises the peer that the implementation wishes to receive fragments with a format given by the code number.</li> <li>• <b>PFC</b>—Protocol-Field-Compression. A configuration option that provides a method to negotiate the compression of the PPP Protocol field.</li> <li>• <b>short sequence</b>—For MLPPP, an option that advises the peer that the implementation wishes to receive fragments with short, 12-bit sequence numbers.</li> </ul> </li> </ul>	

Table 80: show ppp interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Authentication</b>	<p>CHAP or PAP authentication state information. For CHAP authentication:</p> <ul style="list-style-type: none"> <li>• <b>Chap-ans-rcvd</b>—Packet was sent from the peer, indicating that the peer received the <b>Chap-resp-sent</b> packet.</li> <li>• <b>Chap-ans-sent</b>—Packet was sent from the authenticator, indicating that the authenticator received the peer's <b>Chap-resp-rcvd</b> packet.</li> <li>• <b>Chap-chal-rcvd</b>—Challenge packet has been received by the peer.</li> <li>• <b>Chap-chal-sent</b>—Challenge packet has been sent by the authenticator to begin the CHAP protocol or has been transmitted at any time during the Network-Layer Protocol (NCP) phase to ensure that the connection has not been altered.</li> <li>• <b>Chap-resp-rcvd</b>—CHAP response packet has been received by the authenticator.</li> <li>• <b>Chap-resp-sent</b>—CHAP response packet has been sent to the authenticator.</li> <li>• <b>Closed</b>—Link is not available for authentication.</li> <li>• <b>Failure</b>—Authenticator compares the response value in the response packet from the peer with its own response value, but the value does not match. Authentication fails.</li> <li>• <b>Success</b>—Authenticator compares the response value in the response packet from the peer with its own response value, and the value matches. Authentication is successful.</li> </ul> <p>For PAP authentication:</p> <ul style="list-style-type: none"> <li>• <b>Pap-resp-sent</b>—PAP response sent to peer (ACK/NACK)t.</li> <li>• <b>Pap-req-rcvd</b>—PAP request packet received from peer.</li> <li>• <b>Pap-resp-rcvd</b>—PAP response received from the peer (ACK/NACK).</li> <li>• <b>Pap-req-sent</b>—PAP request packet sent to the peer.</li> <li>• <b>Closed</b>—Link is not available for authentication.</li> <li>• <b>Failure</b>—Authenticator compares the response value in the response packet from the peer with its own response value, but the value does not match. Authentication fails.</li> <li>• <b>Success</b>—Authenticator compares the response value in the response packet from the peer with its own response value, and the value matches. Authentication is successful.</li> </ul>	None specified

Table 80: show ppp interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
IPCP	<p>Internet Protocol Control Protocol (IPCP) information.</p> <ul style="list-style-type: none"> <li>• <b>State</b>—(All platforms except M120 and M320 routers) One of the following values: <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is not available for traffic.</li> <li>• <b>Opened</b>—Link is administratively available for traffic.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection.</li> </ul> </li> <li>• <b>State</b>—(M120 and M320 routers) One of the following values: <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is available (up), but no Open has occurred.</li> <li>• <b>Closing</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> <li>• <b>Opened</b>—Link is administratively available for traffic. A Configure-Ack has been both sent and received.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection. A Configure-Request has been sent but a Configure-Ack has not yet been received.</li> <li>• <b>Starting</b>—An administrative Open has been initiated, but the lower layer is still unavailable (Down).</li> <li>• <b>Stopped</b>—The system is waiting for a Down event after the This-Layer-Finished action, or after sending a Terminate-Ack.</li> <li>• <b>Stopping</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> </ul> </li> <li>• <b>Last started</b>—IPCP state start time.</li> <li>• <b>Last completed</b>—IPCP state authentication completion time.</li> <li>• <b>Negotiated options</b>: <ul style="list-style-type: none"> <li>• <b>compression protocol</b>—Negotiate the use of a specific compression protocol. By default, compression is not enabled.</li> <li>• <b>local address</b>—Desired local address of the sender of a Configure-Request. If all four octets are set to zero, the peer provides the IP address.</li> <li>• <b>primary DNS server</b>—Negotiate with the remote peer to select the address of the primary DNS server to be used on the local end of the link.</li> <li>• <b>primary WINS server</b>—Negotiate with the remote peer to select the address of the primary WINS server to be used on the local end of the link.</li> <li>• <b>remote address</b>—IP address of the remote end of the link in dotted quad notation.</li> <li>• <b>secondary DNS server</b>—Negotiate with the remote peer to select the address of the secondary DNS server to be used on the local end of the link.</li> <li>• <b>secondary WINS server</b>—Negotiate with the remote peer to select the address of the secondary WINS server to be used on the local end of the link.</li> </ul> </li> </ul>	extensive

Table 80: show ppp interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
IPV6CP	<p>Internet Protocol version 6 Control Protocol (IPV6CP) information.</p> <ul style="list-style-type: none"> <li>• <b>State</b>—(All platforms except M120 and M320 routers) One of the following values: <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is not available for traffic.</li> <li>• <b>Opened</b>—Link is administratively available for traffic.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection.</li> </ul> </li> <li>• <b>State</b>—(M120 and M320 routers) One of the following values: <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is available (up), but no Open has occurred.</li> <li>• <b>Closing</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> <li>• <b>Opened</b>—Link is administratively available for traffic. A Configure-Ack has been both sent and received.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection. A Configure-Request has been sent but a Configure-Ack has not yet been received.</li> <li>• <b>Starting</b>—An administrative Open has been initiated, but the lower layer is still unavailable (Down).</li> <li>• <b>Stopped</b>—The system is waiting for a Down event after the This-Layer-Finished action, or after sending a Terminate-Ack.</li> <li>• <b>Stopping</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> </ul> </li> <li>• <b>Last started</b>—IPV6CP state start time.</li> <li>• <b>Last completed</b>—IPV6CP state authentication completion time.</li> <li>• <b>Negotiated options</b>: <ul style="list-style-type: none"> <li>• <b>local interface identifier</b>—Desired local address of the sender of a Configure-Request. If all four octets are set to zero, the peer provides the IP address.</li> <li>• <b>remote interface identifier</b>—IP address of the remote end of the link in dotted quad notation.</li> </ul> </li> </ul>	extensive
OSINLCP State	<p>OSI Network Layer Control Protocol (OSINLCP) protocol state information (all platforms except M120 and M320 routers):</p> <ul style="list-style-type: none"> <li>• <b>State</b>: <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—Configure-Request has been sent and Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—Configure-Request and Configure-Ack have both been sent, but Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is not available for traffic.</li> <li>• <b>Opened</b>—Link is administratively available for traffic.</li> <li>• <b>Req-sent</b>—Attempt has been made to configure the connection.</li> </ul> </li> <li>• <b>Last started</b>—OSINLCP state start time.</li> <li>• <b>Last completed</b>—OSINLCP state completion time.</li> </ul>	extensive

Table 80: show ppp interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>TAGCP</b>	<p>TAGCP information.</p> <ul style="list-style-type: none"> <li>• <b>State</b>—(All platforms except M120 and M320 routers) One of the following values: <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is not available for traffic.</li> <li>• <b>Opened</b>—Link is administratively available for traffic.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection.</li> </ul> </li> <li>• <b>State</b>—(M120 and M320 routers) One of the following values: <ul style="list-style-type: none"> <li>• <b>Ack-rcvd</b>—A Configure-Request has been sent and a Configure-Ack has been received.</li> <li>• <b>Ack-sent</b>—A Configure-Request and a Configure-Ack have both been sent, but a Configure-Ack has not yet been received.</li> <li>• <b>Closed</b>—Link is available (up), but no Open has occurred.</li> <li>• <b>Closing</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> <li>• <b>Opened</b>—Link is administratively available for traffic. A Configure-Ack has been both sent and received.</li> <li>• <b>Req-sent</b>—An attempt has been made to configure the connection. A Configure-Request has been sent but a Configure-Ack has not yet been received.</li> <li>• <b>Starting</b>—An administrative Open has been initiated, but the lower layer is still unavailable (Down).</li> <li>• <b>Stopped</b>—The system is waiting for a Down event after the This-Layer-Finished action, or after sending a Terminate-Ack.</li> <li>• <b>Stopping</b>—A Terminate-Request has been sent but a Terminate-Ack has not yet been received.</li> </ul> </li> <li>• <b>Last started</b>—TAGCP state start time.</li> <li>• <b>Last completed</b>—TAGCP state authentication completion time.</li> </ul>	<b>extensive</b> <b>none</b>



## Sample Output

### show ppp interface

```
user@host> show ppp interface si-1/3/0.0
Session si-1/3/0.0, Type: PPP, Phase: Authenticate
Session flags: Monitored
LCP State: Opened
AUTHENTICATION: CHAP State: Chap-resp-sent, Chap-ans-sent
IPCP State: Closed, OSINLCP State: Closed
```


### show ppp interface extensive

```
user@host> show ppp interface si-0/0/3.0 extensive
Session si-0/0/3.0, Type: PPP, Phase: Network
Keepalive settings: Interval 30 seconds, Up-count 1, Down-count 3
RE Keepalive statistics:
LCP echo req Tx      : 657 (last sent 00:50:10 ago)
LCP echo req Rx      : 0 (last seen: never)
LCP echo rep Tx      : 0
LCP echo rep Rx      : 657
LCP echo req timeout : 0
LCP Rx echo req Magic Num Failures : 0
LCP Rx echo rep Magic Num Failures : 0
LCP
State: Opened
Last started: 2007-01-29 10:43:50 PST
Last completed: 2007-01-29 10:43:50 PST
Negotiated options:
Authentication protocol: PAP, Magic number: 2341124815, MRU: 4470
Authentication: PAP
State: Success
Last started: 2007-01-29 10:43:50 PST
Last completed: 2007-01-29 10:43:50 PST
IPCP
State: Opened
Last started: 2007-01-29 10:43:50 PST
Last completed: 2007-01-29 10:43:50 PST
Negotiated options:
Local address: 10.10.10.1, Remote address: 10.10.10.2
```

### show ppp interface terse

```
user@host> show ppp interface si-1/3/0 terse
Session name  Session type  Session phase  Session flags
si-1/3/0.0    PPP           Authenticate    Monitored
```

## show ppp statistics

<b>Syntax</b>	show ppp statistics <detail> <memory> <recovery>
<b>Release Information</b>	Command introduced in Junos OS Release 7.5.
<b>Description</b>	Display PPP interface statistics information.
<b>Options</b>	<p><b>detail</b>—(Optional) Display the detailed statistics.</p> <p><b>memory</b>—(Optional) Display PPP process memory statistics.</p> <p><b>recovery</b>—(Optional) Display recovery state of PPP after a GRES or restart. It is safe to force another GRES or restart only when the recovery state indicates the recovery is done.</p>
	<div>  <p><b>NOTE:</b> When you issue this command option during the recovery process, the command may time out or fail silently rather than display output. Recovery is not complete until the command displays <b>Recovery state: recovery done</b>.</p> </div>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show ppp statistics on page 517</a> <a href="#">show ppp statistics detail on page 517</a> <a href="#">show ppp statistics recovery (Safe to Restart) on page 518</a> <a href="#">show ppp statistics recovery (Unsafe to Restart) on page 518</a>
<b>Output Fields</b>	Table 81 on page 512 lists the output fields for the <b>show ppp statistics</b> command. Output fields are listed in the approximate order in which they appear.

**Table 81: show ppp statistics Output Fields**

Field Name	Field Description	Level of Output
<b>Total sessions</b>	Number of PPP sessions on an interface.	none <b>detail</b>
<b>Sessions in disabled phase</b>	Number of PPP sessions disabled. Number of sessions where the link is either administratively or physically down. Once the PPP process learns from the kernel that Layer 2 is ready to send and receive traffic, it will do a phase transition from disabled to established. When LCP and NCP transitions through states, links transition to the establish phase when terminate packets are exchanged or some other failure, such as authentication or expiration of a timer occurs.	none <b>detail</b>

Table 81: show ppp statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Sessions in establish phase</b>	Number of PPP sessions in establish phase. In order to establish communications over a point-to-point link, each end of the PPP link must first send LCP packets to configure and test the data link.	none <b>detail</b>
<b>Sessions in authenticate phase</b>	Number of PPP sessions in authenticate phase. Each end of the PPP link must first send LCP packets to configure the data link during the link establishment phase. After the link has been established, PPP provides for an optional authentication phase before proceeding to the Network-Layer Protocol (NLP) phase.	none <b>detail</b>
<b>Sessions in network phase</b>	Number of PPP sessions in the network phase. After a link has been established and optional facilities have been negotiated as needed by the LCP, PPP must send Network Control Protocol (NCP) packets to choose and configure one or more network-layer protocols, such as IP, IPX, or AppleTalk. Once each of the chosen network-layer protocols has been configured, datagrams from each network-layer protocol can be sent over the link.	none <b>detail</b>
<b>Bundles in pending phase</b>	Number of unique bundles to which PPP links are referring.	none <b>detail</b>
<b>Type</b>	<p>Type of structure for which memory is allocated.</p> <ul style="list-style-type: none"> <li>• <b>Queued rtsock msgs</b>—Queued route socket messages. When a PPP process is unable to send a route socket message to the kernel (typically because of congestion of the route socket interface), the message is queued for deferred processing.</li> <li>• <b>PPP session</b>—Active PPP session. Stores all the information for a PPP session, such as authentication, sequence number, LCP session, and NCP session information.</li> <li>• <b>Interface address</b>—Interface address associated with a PPP connection. Stores the information about the interface address that PPP obtains from the kernel.</li> <li>• <b>Destination profile</b>—Stores the destination profile information associated with an interface address.</li> <li>• <b>ML link settings</b>—Stores information about an MLPPP link, such as the bundle name and compressed real-time transport protocol (CRTP) settings.</li> <li>• <b>IPCP blocked address</b>—When addresses are blocked in an address pool (for example, when the interface address is within the range of an address pool, it will be implicitly blocked), this structure is used to store the address in the pool.</li> <li>• <b>PPP session trace</b>—A PPP session trace is allocated for record keeping for each session listed at the [set protocols ppp monitor-session] hierarchy level.</li> <li>• <b>IFL redundancy state</b>—Stores redundancy state information needed for high availability (HA) operation.</li> <li>• <b>Protocol family</b>—Stores the information about the protocol family that PPP obtains from the kernel.</li> </ul>	<b>detail</b>

Table 81: show ppp statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
Type (continued)	<ul style="list-style-type: none"> <li>• <b>ML bundle settings</b>—Multilink bundle settings. Stores the context information for a MLPPP bundle.</li> <li>• <b>PPP LCP session</b>—PPP Link Control Protocol session, used for establishing, configuring, and testing the data-link connection. Stores the information for an LCP session, such as negotiated options, current state, and statistics.</li> <li>• <b>PPP NCP session</b>—PPP Network Control Protocol (NCP) phase in the PPP link connection process. Stores the information for an NCP session, such as negotiated options, current state, address family, and statistics.</li> <li>• <b>Physical interface</b>—Stores the information about the physical interface that PPP obtains from the kernel.</li> <li>• <b>Access profile</b>—Stores the information found at the [edit access profile] hierarchy level for each profile.</li> <li>• <b>ML wait entry</b>—Created when there are MLPPP links joining a bundle. before its addition to the PPP process. Links are saved here, and when the bundle is added, are properly assigned to the bundle.</li> <li>• <b>Group profile</b>—Stores information set in the PPP stanza of a group profile, such as the primary and secondary Domain Name System (DNS), primary and secondary NDNS, and address pool name.</li> <li>• <b>Profile client</b>—Stores the per-client information of the access profile (information obtained from the [set access profile name client client-name] hierarchy level.</li> <li>• <b>PPP Auth session</b>—PPP authentication session. Stores all the session-specific authentication protocol parameters.</li> <li>• <b>Logical interface</b>—Stores the information about the logical interface that PPP obtains from the kernel.</li> <li>• <b>Non-tagged</b>—Generic catch-all for allocations not of a particular structure type.</li> </ul>	detail

Table 81: show ppp statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Type</b>	<p>If you specify the <b>memory</b> keyword, the following memory statistics are displayed for Ethernet interfaces on M120 and M320 routers.</p> <ul style="list-style-type: none"> <li>• <b>authenticate</b>—Stores information common to all PPP authentication protocols.</li> <li>• <b>linkInterface</b>—Stores information about PPP link interfaces.</li> <li>• <b>pap</b>—Stores information about PPP PAP authentication protocol. Includes authenticator and authenticate state machines.</li> <li>• <b>lcp</b>—PPP Link Control Protocol session. Used for establishing, configuring and testing the data-link connection. Stores information for LCP session, such as negotiated options, state, and statistics.</li> <li>• <b>chap</b>—Stores information about PPP CHAP authentication protocol. Includes authenticator and authenticate state machines.</li> <li>• <b>eapBuffer</b>—Stores runtime authentication information for EAP.</li> <li>• <b>eap</b>—Stores information about PPP EAP authentication protocol. Includes authenticator and authenticate state machines.</li> <li>• <b>authNone</b>—Stores information about no PPP authentication. Includes the authenticator state machine.</li> <li>• <b>networkInterface</b>—Stores information about NCP portions of PPP protocol.</li> <li>• <b>ipNcp</b>—PPP IPCP session information. Used for configuring, negotiating, and establishing IPCP protocol. Stores the current state, and configured and negotiated options.</li> <li>• <b>ipv6Ncp</b>—PPP IPv6CP session information. Used for configuring, negotiating, and establishing IPv6CP protocol. Stores the current state, and configured and negotiated options.</li> <li>• <b>osiNcp</b>—PPP OSICP session information. Used for configuring, negotiating, and establishing OSICP protocol. Stores the current state, and configured and negotiated options.</li> <li>• <b>mplsNcp</b>—PPP MPLSCP session information. Used for configuring, negotiating, and establishing MPLSCP protocol. Stores the current state.</li> <li>• <b>trace</b>—Stores information for PPP debugging.</li> </ul>	<b>memory</b>
<b>Total</b>	Total memory allocations.	<b>detail</b>
<b>Size</b>	Size of the structure.	<b>detail</b>
<b>Active</b>	Number of instances of the structure that are used.	<b>detail</b>
<b>Free</b>	Number of instances of the structure that are on the free list. Types with a number in the <b>Free</b> column are pooled structures, and are typically types that are often used.	<b>detail</b>
<b>Limit</b>	Maximum number of instances that can be on the free list. Types with a number in the <b>Limit</b> column are pooled structures, and are typically types that are often used.	<b>detail</b>
<b>Total size</b>	Total amount of memory being used by a type of structure (includes active and free instances).	<b>detail</b>
<b>Requests</b>	Number of allocation requests made by a type of structure.	<b>detail</b>

Table 81: show ppp statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Failures</b>	Number of failed allocations.	<b>detail</b>
<b>Recovery state</b>	State of PPP recovery after a GRES or restart: <ul style="list-style-type: none"> <li>• recovery done—All sessions have recovered; it is safe to force another GRES or restart.</li> <li>• recovery cleanup pending—Not all PPP sessions have recovered; it is not safe to force another GRES or restart.</li> </ul>	none
<b>Subscriber sessions pending retention</b>	Number of PPP subscriber sessions that are in the process of being recovered.	none
<b>Subscriber sessions recovered OK</b>	Number of PPP subscriber sessions that have recovered after a GRES or restart.	none
<b>Subscriber sessions recovery failed</b>	Number of PPP subscriber sessions that have failed to recover after a GRES or restart.	none

## Sample Output

### show ppp statistics

```
user@host> show ppp statistics
Session statistics from PPP process
  Total sessions: 0
    Sessions in disabled phase   : 0
    Sessions in establish phase  : 0
    Sessions in authenticate phase: 0
    Sessions in network phase    : 0
    Bundles in pending phase     : 0

Session statistics from PPP universal edge process
  Total subscriber sessions: 32
    Subscriber sessions in disabled phase   : 32
    Subscriber sessions in establish phase  : 0
    Subscriber sessions in authenticate phase: 0
    Subscriber sessions in network phase    : 0
```

### show ppp statistics detail

```
user@host> show ppp statistics detail
Session statistics from PPP process
  Total sessions: 0
    Sessions in disabled phase   : 0
    Sessions in establish phase  : 0
    Sessions in authenticate phase: 0
    Sessions in network phase    : 0
    Bundles in pending phase     : 0
```

Type	Size	Active	Free	Limit	Total size	Requests	Failures
Queued rtsock msgs	28	0	0	65535	0	0	
PPP session	60	0			0	0	
Interface address	64	0	0	65535	0	0	
Destination profile	65	0			0	0	
ML link settings	68	0			0	0	
IPCP blocked address	68	0			0	0	
PPP session trace	76	0			0	0	
IFL redundancy state	76	0			0	0	
Protocol family	84	0	0	65535	0	0	
ML bundle settings	108	0			0	0	
PPP LCP session	120	0			0	0	
PPP NCP session	124	0			0	0	
Physical interface	124	170	0	65535	21080	170	
Access profile	132	0			0	0	
ML wait entry	144	0	0	20	0	0	
Group profile	164	0			0	0	
Profile client	272	0			0	0	
PPP Auth session	356	0			0	0	
Logical interface	524	0	0	65535	0	0	
Non-tagged					8	2	
Total					21088	172	0

```

Session statistics from PPP universal edge process
  Total subscriber sessions: 32
    Subscriber sessions in disabled phase   : 32
    Subscriber sessions in establish phase  : 0
    Subscriber sessions in authenticate phase: 0
    Subscriber sessions in network phase    : 0
```

Type	Size	Active	Free	Limit	Total size	Requests	Failures
authenticate	224	1	99	16384	224	0	0
linkInterface	152	1	99	16384	152	0	0
pap	256	1	99	16384	256	0	0

lcp	272	1	99	16384	272	0	0
chap	284	0	0	16384	0	0	0
eapBuffer	1464	0	0	16384	0	0	0
eap	276	0	0	16384	0	0	0
authNone							
networkInterface	220	1	99	16384	220	0	0
ipNcp	256	1	99	16384	256	0	0
ipv6Ncp	204	0	0	16384	0	0	0
osiNcp	192	0	0	16384	0	0	0
mplsNcp	188	0	0	16384	0	0	0
trace	2052	0	16	16	0	0	0
Total					1380	0	0

#### show ppp statistics recovery (Safe to Restart)

```
user@host> show ppp statistics recovery
Recovery statistics from PPP universal edge process
Recovery state: recovery done
  Subscriber sessions recovered OK      : 32001
  Subscriber sessions recovery failed   : 0
```

#### show ppp statistics recovery (Unsafe to Restart)

```
user@host> show ppp statistics recovery
Recovery statistics from PPP universal edge process
Recovery state: recovery cleanup pending
  Subscriber sessions pending retention : 32001
  Subscriber sessions recovered OK      : 0
  Subscriber sessions recovery failed   : 0
```



## show ppp summary

<b>Syntax</b>	show ppp summary
<b>Release Information</b>	Command introduced in Junos OS Release 7.5.
<b>Description</b>	Display PPP session summary information.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show ppp summary on page 519</a>
<b>Output Fields</b>	<a href="#">Table 82 on page 519</a> lists the output fields for the <b>show ppp summary</b> command. Output fields are listed in the approximate order in which they appear.

**Table 82: show ppp summary Output Fields**

Field Name	Field Description
<b>Interface</b>	Interface on which the PPP session is running. An interface type of pp0 indicates an Ethernet interface type on a M120 or M320 router.
<b>Session type</b>	Type of session: <b>PPP</b> or <b>Cisco-HDLC</b> .
<b>Session phase</b>	PPP process phases: <b>Authenticate</b> , <b>Pending</b> , <b>Establish</b> , <b>Network</b> , <b>Disabled</b> .
<b>Session flags</b>	Special conditions present in the session, such as <b>Bundled</b> , <b>TCC</b> , <b>No-keepalives</b> , <b>Looped</b> , <b>Monitored</b> , and <b>NCP-only</b> .

## Sample Output

```

user@host> show ppp summary
Interface      Session type  Session phase  Session flags
at-4/0/0.456   PPP           Network
lsq-0/3/0.0    PPP           Disabled
lsq-1/0/0.0    PPP           Disabled
rlsq0.0        PPP           Network        NCP-only
so-1/0/0.0     PPP           Authenticate
so-1/0/1.0     PPP           Disabled        Looped
so-2/0/0.0     Cisco-HDLC    Establish
so-4/0/0.0     PPP           Establish        Monitored
t1-1/3/0:1.0   PPP           Network        Bundled
t1-1/3/0:2.0   PPP           Network        Bundled
pp0.12         PPP           Network

```



# PPPoE Interface Operational Mode Commands

Table 83 on page 521 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot Point-to-Point Protocol over Ethernet (PPPoE) interfaces. Commands are listed in alphabetical order.

**Table 83: PPPoE Interfaces Operational Mode Commands**

Task	Command
Clear the lockout condition for the PPPoE client associated with the specified MAC source address.	<code>clear pppoe lockout</code>
Clear PPPoE sessions.	<code>clear pppoe sessions</code>
Clear PPPoE session statistics.	<code>clear pppoe statistics</code>
Display interface-specific information about PPPoE-configured interfaces.	<code>show interfaces (PPPoE)</code>
Display session-specific information about PPPoE-configured interfaces	<code>show pppoe interfaces</code>
Display summary information about PPPoE clients currently undergoing lockout or currently in a lockout grace period.	<code>show pppoe lockout</code>
Display PPPoE service name table information.	<code>show pppoe service-name-tables</code>
Display PPPoE active session information.	<code>show pppoe sessions</code>
Display PPPoE session statistics.	<code>show pppoe statistics</code>
Display PPPoE underlying interface information.	<code>show pppoe underlying-interfaces</code>
Display PPPoE version information.	<code>show pppoe version</code>



.....

**NOTE:** PPPoE interfaces are supported on Fast Ethernet and ATM-over-ADSL and ATM-over-SHDSL interfaces on the J Series routers. PPPoE interfaces connect multiple PPPoE-client hosts on an Ethernet LAN to a remote site through a J Series Services Router. The J Series router can only be configured as a PPPoE client. Hosts share a common digital subscriber line (DSL), a cable modem, or a wireless connection to the Internet. For information about how to configure PPPoE interfaces, see the *J Series Services Router Basic LAN and WAN Access Configuration Guide* or the Junos® OS Network Interfaces.

For information about monitoring and troubleshooting Fast Ethernet interfaces, see *Ethernet Interface Operational Mode Commands*.

For information about monitoring and troubleshooting ATM-over-ADSL and ATM-over-SHDSL, interfaces, see *ATM Interface Operational Mode Commands*.

.....

## clear pppoe logout

<b>Syntax</b>	clear pppoe logout <mac-address <i>mac-address</i> > <underlying-interfaces <i>underlying-interface-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 11.4.
<b>Description</b>	Clear the lockout condition for the PPPoE client associated with the specified MAC source address.
<b>Options</b>	<p><b>none</b>—Clear the lockout condition for the PPPoE clients associated with all MAC source addresses on all PPPoE underlying interfaces.</p> <p><b>mac-address <i>mac-address</i></b>—(Optional) Clear the lockout condition for the PPPoE client associated with the specified MAC source address.</p> <p><b>underlying-interfaces <i>underlying-interface-name</i></b>—(Optional) Clear the lockout condition for all PPPoE clients associated with the specified PPPoE underlying interface.</p>
<b>Required Privilege Level</b>	clear
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Clearing Lockout of PPPoE Subscriber Sessions</li> <li>Configuring Lockout of PPPoE Subscriber Sessions</li> </ul>
<b>List of Sample Output</b>	<p><a href="#">clear pppoe logout (Clear All MAC Source Addresses on All Underlying Interfaces) on page 523</a></p> <p><a href="#">clear pppoe logout mac-address (Clear Specified MAC Source Address) on page 523</a></p> <p><a href="#">clear pppoe logout underlying-interfaces (Clear All MAC Source Addresses on Specified Underlying Interface) on page 523</a></p> <p><a href="#">clear pppoe logout mac-address underlying-interfaces (Clear Specified MAC Source Address on Specified Underlying Interface) on page 524</a></p>

## Sample Output

<a href="#">clear pppoe logout (Clear All MAC Source Addresses on All Underlying Interfaces)</a>	user@host> clear pppoe logout
<a href="#">clear pppoe logout mac-address (Clear Specified MAC Source Address)</a>	user@host> clear pppoe logout mac-address 00:1d:72:bc:53:30
<a href="#">clear pppoe logout underlying-interfaces (Clear All MAC Source)</a>	user@host> clear pppoe logout underlying-interfaces ge-1/0/0.101

### Addresses on Specified Underlying Interface)

`clear pppoe lockout  
mac-address  
underlying-interfaces`  
(Clear Specified MAC  
Source Address on  
Specified Underlying  
Interface)

```
user@host> clear pppoe lockout mac-address 00:1d:72:bc:53:30 underlying-interfaces  
ge-1/0/0.101
```

## clear pppoe sessions

---

<b>Syntax</b>	clear pppoe sessions <interface <i>interface-name</i> >
<b>Release Information</b>	Command introduced in Junos OS Release 7.5.
<b>Description</b>	(J Series routers, M120 routers, and M320 routers only) Reset PPPoE sessions.
<b>Options</b>	<b>none</b> —Reset PPPoE sessions for all interfaces.  <b>interface <i>interface-name</i></b> —(Optional) Reset PPPoE sessions for the specified interface.
<b>Required Privilege Level</b>	clear
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show pppoe interfaces on page 539</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear pppoe sessions on page 525</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

**clear pppoe sessions**      user@host> clear pppoe sessions

## clear pppoe statistics

---

<b>Syntax</b>	<code>clear pppoe statistics</code> <code>&lt;interface <i>interface-name</i>&gt;</code> <code>&lt;underlying-interface-name&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. <i>underlying-interface-name</i> option introduced in Junos OS Release 9.5.
<b>Description</b>	(J Series routers, M120 routers, M320 routers, and MX Series routers only) Reset PPPoE session statistics information.
<b>Options</b>	<b>none</b> —Reset PPPoE statistics for all interfaces.  <b>interface <i>interface-name</i></b> —(J Series routers) (Optional) Reset PPPoE statistics for the specified interface.  <b><i>underlying-interface-name</i></b> —(M120 routers, M320 routers, and MX Series routers) (Optional) Reset PPPoE statistics for the specified underlying PPPoE interface.
<b>Required Privilege Level</b>	clear
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show pppoe statistics on page 551</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear pppoe statistics on page 526</a> <a href="#">clear pppoe statistics interface (PPPoE Interfaces on J Series Routers) on page 526</a> <a href="#">clear pppoe statistics (PPPoE Underlying Interfaces on M Series and MX Series Routers) on page 526</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

<code>clear pppoe statistics</code>	<code>user@host&gt; clear pppoe statistics</code>
<code>clear pppoe statistics interface (PPPoE Interfaces on J Series Routers)</code>	<code>user@host&gt; clear pppoe statistics interface pp0.1073741827</code>
<code>clear pppoe statistics (PPPoE Underlying Interfaces on M Series and MX Series Routers)</code>	<code>user@host&gt; clear pppoe statistics ge-4/0/3.2</code>



## show interfaces (PPPoE)

<b>Syntax</b>	<pre>show interfaces pp0.logical &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series Services Routers, M120 routers, M320 routers, and MX Series routers only) Display status information about the PPPoE interface.
<b>Options</b>	<p><b>pp0.logical</b>—Display standard status information about the PPPoE interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about PPPoE interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display PPPoE interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces (PPPoE) on page 534</a> <a href="#">show interfaces (PPPoE over Aggregated Ethernet) on page 534</a> <a href="#">show interfaces brief (PPPoE) on page 534</a> <a href="#">show interfaces detail (PPPoE) on page 535</a> <a href="#">show interfaces detail (PPPoE on J Series Services Routers) on page 535</a> <a href="#">show interfaces extensive (PPPoE on M120 and M320 Routers) on page 536</a>
<b>Output Fields</b>	Table 84 on page 527 lists the output fields for the <b>show interfaces</b> (PPPoE) command. Output fields are listed in the approximate order in which they appear.

Table 84: show interfaces (PPPoE) Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “Common Output Fields Description” on page 141.	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>

Table 84: show interfaces (PPPoE) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Physical interface type (PPPoE).	All levels
<b>Link-level type</b>	Encapsulation on the physical interface (PPPoE).	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source. It can be <b>Internal</b> or <b>External</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link type</b>	Physical interface link type: <b>full duplex</b> or <b>half duplex</b> .	All levels
<b>Link flags</b>	Information about the interface. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Physical Info</b>	Physical interface information.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b>
<b>Hardware address</b>	MAC address of the hardware.	<b>detail extensive</b>
<b>Alternate link address</b>	Backup address of the link.	<b>detail extensive</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 84: show interfaces (PPPoE) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>IPv6 transit statistics</b>	<p>Number of IPv6 transit bytes and packets received and transmitted on the physical interface if IPv6 statistics tracking is enabled.</p> <p><b>NOTE:</b> These fields include dropped traffic and exception traffic, as those fields are not separately defined.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of B chip Tx drops and IXP Tx net transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b> —Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), then the cable, the far-end system, or the PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of B chip Tx drops and IXP Tx net transmit drops.</li> </ul>	<b>extensive</b>

---

#### Logical Interface

---

Table 84: show interfaces (PPPoE) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number (which reflects its initialization sequence).	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Type of encapsulation configured on the logical interface.	All levels
<b>PPP parameters</b>	PPP status: <ul style="list-style-type: none"> <li>LCP restart timer—Length of time (in milliseconds) between successive Link Control Protocol (LCP) configuration requests.</li> <li>NCP restart timer—Length of time (in milliseconds) between successive Network Control Protocol (NCP) configuration requests.</li> </ul>	<b>detail</b>
<b>PPPoE</b>	PPPoE status: <ul style="list-style-type: none"> <li><b>State</b>—State of the logical interface (<b>up</b> or <b>down</b>).</li> <li><b>Session ID</b>—PPPoE session ID.</li> <li><b>Service name</b>—Type of service required. Can be used to indicate an Internet service provider (ISP) name or a class or quality of service.</li> <li><b>Configured AC name</b>—Configured access concentrator name.</li> <li><b>Auto-reconnect timeout</b>—Time after which to try to reconnect after a PPPoE session is terminated, in seconds.</li> <li><b>Idle Timeout</b>—Length of time (in seconds) that a connection can be idle before disconnecting.</li> <li><b>Underlying interface</b>—Interface on which PPPoE is running.</li> </ul>	All levels
<b>Link</b>	Name of the physical interfaces for member links in an aggregated Ethernet bundle for a PPPoE over aggregated Ethernet configuration. PPPoE traffic goes out on these interfaces.	All levels
<b>Traffic statistics</b>	Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. This counter usually takes less than 1 second to stabilize.	<b>detail extensive</b>

Table 84: show interfaces (PPPoE) Output Fields (*continued*)

Field Name	Field Description	Level of Output
IPv6 transit statistics	<p>Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.</p> <p><b>NOTE:</b> The packet and byte counts in these fields include traffic that is dropped and does not leave the router.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	detail extensive
Local statistics	<p>Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. This counter usually takes less than 1 second to stabilize.</p>	detail extensive
Transit statistics	<p>Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. This counter usually takes less than 1 second to stabilize.</p> <p><b>NOTE:</b> The packet and byte counts in these fields include traffic that is dropped and does not leave the router.</p>	detail extensive
Keepalive settings	<p>(PPP and HDLC) Configured settings for keepalives.</p> <ul style="list-style-type: none"> <li>• <b>interval seconds</b>—The time in seconds between successive keepalive requests. The range is 10 seconds through 32,767 seconds, with a default of 10 seconds.</li> <li>• <b>down-count number</b>—The number of keepalive packets a destination must fail to receive before the network takes a link down. The range is 1 through 255, with a default of 3.</li> <li>• <b>up-count number</b>—The number of keepalive packets a destination must receive to change a link's status from down to up. The range is 1 through 255, with a default of 1.</li> </ul>	detail extensive
Keepalive statistics	<p>(PPP and HDLC) Information about keepalive packets.</p> <ul style="list-style-type: none"> <li>• <b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li>• <b>(last seen 00:00:00 ago)</b>—Time the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li>• <b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li>• <b>(last seen 00:00:00 ago)</b>—Time the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul> <p>(MX Series routers with MPCs/MICs) When an MX Series router with MPCs/MICs is using PPP fast keepalive for a PPP link, the display does not include the number of keepalive packets received or sent, or the amount of time since the router received or sent the last keepalive packet.</p>	detail extensive
Input packets	Number of packets received on the logical interface.	None specified
Output packets	Number of packets transmitted on the logical interface.	None specified

Table 84: show interfaces (PPPoE) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>LCP state</b>	(PPP) Link Control Protocol state.  <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—LCP is not configured on the interface.</li> <li>• <b>Opened</b>—LCP negotiation is successful.</li> </ul>	none <b>detail extensive</b>
<b>NCP state</b>	(PPP) Network Control Protocol state.  <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive</b> none
<b>CHAP state</b>	(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction.  <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the Success state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Closed</b>—CHAP authentication is incomplete.</li> <li>• <b>Failure</b>—CHAP authentication failed.</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Success</b>—CHAP authentication was successful.</li> </ul>	none <b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive</b> none
<i><b>protocol-family</b></i>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b> none
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b> none

Table 84: show interfaces (PPPoE) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Addresses, Flags</b>	Information about the addresses configured for the protocol family. Possible values are described in the "Addresses Flags" section under <a href="#">"Common Output Fields Description"</a> on page 141.	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>

## Sample Output

### show interfaces (PPPoE)

```

user@host> show interfaces pp0
Physical interface: pp0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 24
  Type: PPPoE, Link-level type: PPPoE, MTU: 1532
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link type      : Full-Duplex
  Link flags     : None
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

Logical interface pp0.0 (Index 72) (SNMP ifIndex 72)
  Flags: Hardware-Down Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPPoE
  PPPoE:
    State: SessionDown, Session ID: None,
    Service name: None, Configured AC name: sapphire,
    Auto-reconnect timeout: 100 seconds, Idle timeout: Never,
    Underlying interface: at-5/0/0.0 (Index 70)
  Input packets : 0
  Output packets: 0
  LCP state: Not-configured
  NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Closed
    Protocol inet, MTU: 100
    Flags: User-MTU, Negotiate-Address

```

### show interfaces (PPPoE over Aggregated Ethernet)

```

user@host> show interfaces pp0.1073773821
Logical interface pp0.1073773821 (Index 80) (SNMP ifIndex 32584)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPPoE
  PPPoE:
    State: SessionUp, Session ID: 1,
    Session AC name: alcor, Remote MAC address: 00:10:94:00:00:01,
    Underlying interface: demux0.100 (Index 88)
  Link:
    ge-1/0/0.32767
    ge-1/0/1.32767
  Input packets : 6
  Output packets: 6
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
  Not-configured
  CHAP state: Closed
  PAP state: Success
    Protocol inet, MTU: 1500
    Flags: Sendbcst-pkt-to-re
    Addresses, Flags: Is-Primary
    Local: 45.63.24.1

```

### show interfaces brief (PPPoE)

```

user@host> show interfaces pp0 brief
Physical interface: pp0, Enabled, Physical link is Up
  Type: PPPoE, Link-level type: PPPoE, MTU: 1532, Speed: Unspecified
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps

Logical interface pp0.0

```



```

Flags: Hardware-Down Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPPoE
PPPoE:
  State: SessionDown, Session ID: None,
  Service name: None, Configured AC name: sapphire,
  Auto-reconnect timeout: 100 seconds, Idle timeout: Never,
  Underlying interface: at-5/0/0.0 (Index 70)
inet

```

#### show interfaces detail (PPPoE)

```

user@host> show interfaces pp0 detail
Physical interface: pp0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 24, Generation: 9
  Type: PPPoE, Link-level type: PPPoE, MTU: 1532, Speed: Unspecified
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
Logical interface pp0.0 (Index 72) (SNMP ifIndex 72) (Generation 14)
  Flags: Hardware-Down Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPPoE
  PPPoE:
    State: SessionDown, Session ID: None,
    Service name: None, Configured AC name: sapphire,
    Auto-reconnect timeout: 100 seconds, Idle timeout: Never,
    Underlying interface: at-5/0/0.0 (Index 70)
  Traffic statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Local statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Transit statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
  LCP state: Not-configured
  NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Closed
    Protocol inet, MTU: 100, Generation: 14, Route table: 0
    Flags: User-MTU, Negotiate-Address

```

#### show interfaces detail (PPPoE on J Series Services Routers)

```

user@host> show interfaces pp0 detail
Physical interface: pp0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 24, Generation: 9
  Type: PPPoE, Link-level type: PPPoE, MTU: 1532, Speed: Unspecified
  Device flags   : Present Running

```

```

Interface flags: Point-To-Point SNMP-Traps
Link type      : Full-Duplex
Link flags     : None
Physical info  : Unspecified
Hold-times    : Up 0 ms, Down 0 ms
Current address: Unspecified, Hardware address: Unspecified
Alternate link address: Unspecified
Statistics last cleared: Never
Traffic statistics:
  Input bytes  :                0                0 bps
  Output bytes :                0                0 bps
  Input packets:                0                0 pps
  Output packets:              0                0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
  Resource errors: 0

Logical interface pp0.0 (Index 72) (SNMP ifIndex 72) (Generation 14)
Flags: Hardware-Down Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPPoE
PPPoE:
  State: SessionDown, Session ID: None,
  Service name: None, Configured AC name: sapphire,
  Auto-reconnect timeout: 100 seconds, Idle timeout: Never,
  Underlying interface: at-5/0/0.0 (Index 70)
Traffic statistics:
  Input bytes  :                0
  Output bytes :                0
  Input packets:                0
  Output packets:              0
Local statistics:
  Input bytes  :                0
  Output bytes :                0
  Input packets:                0
  Output packets:              0
Transit statistics:
  Input bytes  :                0                0 bps
  Output bytes :                0                0 bps
  Input packets:                0                0 pps
  Output packets:              0                0 pps
LCP state: Not-configured
NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
mpls: Not-configured
CHAP state: Closed
  Protocol inet, MTU: 100, Generation: 14, Route table: 0
  Flags: User-MTU, Negotiate-Address

```

**show interfaces**  
**extensive (PPPoE on**

```

user@host> show interfaces pp0 extensive
Physical interface: pp0, Enabled, Physical link is Up
Interface index: 128, SNMP ifIndex: 93, Generation: 129

```

M120 and M320  
Routers)

```

Type: PPPoE, Link-level type: PPPoE, MTU: 1532, Speed: Unspecified
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps
Link type : Full-Duplex
Link flags : None
Physical info : Unspecified
Hold-times : Up 0 ms, Down 0 ms
Current address: Unspecified, Hardware address: Unspecified
Alternate link address: Unspecified
Statistics last cleared: Never
Traffic statistics:
Input bytes : 972192 0 bps
Output bytes : 975010 0 bps
Input packets: 1338 0 pps
Output packets: 1473 0 pps
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0,
Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0

Logical interface pp0.0 (Index 69) (SNMP ifIndex 96) (Generation 194)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPPoE
PPPoE:
State: SessionUp, Session ID: 26,
Session AC name: None, AC MAC address: 00:17:cb:48:c8:12,
Service name: None, Configured AC name: None,
Auto-reconnect timeout: Never, Idle timeout: Never,
Underlying interface: ge-3/0/1.0 (Index 67)
Traffic statistics:
Input bytes : 252
Output bytes : 296
Input packets: 7
Output packets: 8
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Local statistics:
Input bytes : 252
Output bytes : 296
Input packets: 7
Output packets: 8
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

```
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 1 (last seen 00:00:00 ago)
  Output: 1 (last sent 00:00:03 ago)
LCP state: Opened
NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
Not-configured
CHAP state: Closed
PAP state: Closed
  Protocol inet, MTU: 1492, Generation: 171, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 12.12.12.2, Local: 12.12.12.1, Broadcast: Unspecified,
Generation: 206
```

## show pppoe interfaces

<b>Syntax</b>	show pppoe interfaces <brief   detail   extensive> <pp0.logical>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series Services Routers, M120 routers, M320 routers, and MX Series routers only) Display session-specific information about PPPoE interfaces.
<b>Options</b>	<p><b>none</b>—Display interface information for all PPPoE interfaces.</p> <p><b>brief   detail</b>—(Optional) Display the specified level of output.</p> <p><b>extensive</b>—(J Series Services Routers) (Optional) Display information about the number of packets sent and received and the number of timeouts during a PPPoE session.</p> <p><b>pp0.logical</b>—(Optional) Name of an interface. The logical unit number for static interfaces can be a value from 0 through 16385. The logical unit number for dynamic interfaces can be a value from 1073741824 through the maximum number of logical interfaces supported on your router.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying and Managing Agent Circuit Identifier-Based Dynamic VLAN Configuration</li> </ul>
<b>List of Sample Output</b>	<a href="#">show pppoe interfaces on page 542</a> <a href="#">show pppoe interfaces (Status for the Specified Interface) on page 542</a> <a href="#">show pppoe interfaces brief on page 542</a> <a href="#">show pppoe interfaces detail on page 542</a> <a href="#">show pppoe interfaces extensive (J Series Services Routers only) on page 542</a> <a href="#">show pppoe interfaces (PPPoE Subscriber Interface with ACI Interface Set) on page 543</a>
<b>Output Fields</b>	<p>Table 85 on page 539 lists the output fields for the <b>show pppoe interfaces</b> command. Output fields are listed in the approximate order in which they appear. Not all fields are displayed for PPPoE interfaces on M120 and M320 routers in server mode.</p>

Table 85: show pppoe interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>State</b>	State of the logical interface: <b>up</b> or <b>down</b> .	All levels

Table 85: show pppoe interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Session ID</b>	Session ID.	All levels
<b>Type</b>	Origin of the logical interface: <b>Static</b> or <b>Dynamic</b> . Indicates whether the interface was statically or dynamically created.	<b>detail extensive none</b>
<b>Service name</b>	Type of service required (can be used to indicate an ISP name or a class or quality of service).	<b>detail extensive none</b>
<b>Configured AC name</b>	Configured access concentrator name.	<b>detail extensive none</b>
<b>Session AC name</b>	Name of the access concentrator.	<b>detail extensive none</b>
<b>Remote MAC address or Remote MAC</b>	MAC address of the remote side of the connection, either the access concentrator or the PPPoE client.	All levels
<b>Auto-reconnect timeout</b>	(J Series Services Routers only) Time after which to try to reconnect after a PPPoE session is terminated, in seconds.	<b>detail extensive none</b>
<b>Idle timeout</b>	(J Series Services Routers only) Length of time (in seconds) that a connection can be idle before disconnecting.	<b>detail extensive none</b>
<b>Session uptime</b>	Length of time the session has been up, in <i>hh:mm:ss</i> .	<b>detail extensive none</b>
<b>Dynamic Profile</b>	Name of the dynamic profile that was used to create this interface. If the interface was statically created, this field is not displayed.	<b>detail extensive none</b>
<b>Underlying interface</b>	Interface on which PPPoE is running.	All levels
<b>Agent Circuit ID</b>	Agent circuit identifier (ACI) that corresponds to the DSLAM interface that initiated the client service request. An asterisk is interpreted as a wildcard character and can appear at the beginning, the end, or both the beginning and end of the string. If the agent circuit ID is not configured, this field is not displayed.	<b>detail extensive none</b>
<b>Agent Remote ID</b>	Agent remote identifier that corresponds to the subscriber associated with the DSLAM interface that initiated the service request. An asterisk is interpreted as a wildcard character and can appear at the beginning, the end, or both at the beginning and end of the string. If the agent remote ID is not configured, this field is not displayed.	<b>detail extensive none</b>
<b>ACI Interface Set</b>	Internally-generated name of the dynamic ACI interface set, if configured, and the set index number of the ACI entry in the session database.	<b>detail extensive none</b>

Table 85: show pppoe interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Packet Type</b>	<p>Number of packets sent and received during the PPPoE session, categorized by packet type and packet errors:</p> <ul style="list-style-type: none"> <li>• <b>PADI</b>—PPPoE Active Discovery Initiation packets.</li> <li>• <b>PADO</b>—PPPoE Active Discovery Offer packets.</li> <li>• <b>PADR</b>—PPPoE Active Discovery Request packets.</li> <li>• <b>PADS</b>—PPPoE Active Discovery Session-Confirmation packets.</li> <li>• <b>PADT</b>—PPPoE Active Discovery Termination packets.</li> <li>• <b>Service name error</b>—Packets for which the Service-Name request could not be honored.</li> <li>• <b>AC system error</b>—Packets for which the access concentrator experienced an error in performing the host request. For example, the host had insufficient resources to create a virtual circuit.</li> <li>• <b>Generic error</b>—Packets that indicate an unrecoverable error occurred.</li> <li>• <b>Malformed packets</b>—Malformed or short packets that caused the packet handler to discard the frame as unreadable.</li> <li>• <b>Unknown packets</b>—Unrecognized packets.</li> </ul>	<b>extensive</b>
<b>Timeout</b>	<p>(J Series Services Routers only) Information about timeouts that occurred during the PPPoE session:</p> <ul style="list-style-type: none"> <li>• <b>PADI</b>—No PADO packet has been received within the timeout period.</li> <li>• <b>PADO</b>—No PADR packet has been received within the timeout period. (This value is always zero and is not supported.)</li> <li>• <b>PADR</b>—No PADS packet has been received within the timeout period.</li> </ul>	<b>extensive</b>

## Sample Output

```

show pppoe interfaces      user@host> show pppoe interfaces
                             pp0.0 Index 66
                             State: Down, Session ID: None,
                             Service name: None, Configured AC name: sapphire,
                             Session AC name: None, Remote MAC address: 00:00:00:00:00:00,
                             Auto-reconnect timeout: 100 seconds, Idle timeout: Never,
                             Underlying interface: at-5/0/0.0 Index 71

show pppoe interfaces      user@host> show pppoe interfaces pp0.1073741827
(Status for the           pp0.1073741827 Index 70
Specified Interface)      State: Session Up, Session ID: 30, Type: Dynamic,
                             Session AC name: velorum,
                             Remote MAC address: 00:90:1A:42:0A:C1,
                             Session uptime: 16:45:46 ago,
                             Underlying interface: ge-2/0/3.1 Index 73
                             Service name: premium
                             Dynamic Profile: PppoeProfile
                             Agent Circuit ID: velorum-ge-2/0/3
                             Agent Remote ID: westford

show pppoe interfaces      user@host> show pppoe interfaces brief
brief
                             Interface      Underlying      State      Session      Remote
                             interface      ID      MAC
                             pp0.0          ge-2/0/3.2      Session Up  27          00:90:1A:42:0A:C1
                             pp0.1          ge-2/0/3.2      Session Up  28          00:90:1A:42:0A:C1
                             pp0.1073741824 ge-2/0/3.1      Session Up  29          00:90:1A:42:0A:C1
                             pp0.1073741825 ge-2/0/3.1      Session Up  30          00:90:1A:42:0A:C1
                             pp0.1073741826 ge-2/0/3.1      Session Up  31          00:90:1A:42:0A:C1

show pppoe interfaces      user@host> show pppoe interfaces detail
detail
                             pp0.0 Index 66
                             State: Down, Session ID: None, Type: Static,
                             Service name: None, Configured AC name: sapphire,
                             Session AC name: None, Remote MAC address: 00:00:00:00:00:00,
                             Auto-reconnect timeout: 100 seconds, Idle timeout: Never,
                             Underlying interface: at-5/0/0.0 Index 71

show pppoe interfaces      user@host> show pppoe interfaces pp0.1 extensive
extensive (J Series       pp0.1 Index 66
Services Routers only)   State: Down, Session ID: 26, Type: Static,
                             Service name: None, Configured AC name: sapphire,
                             Session AC name: None, Remote MAC address: 00:00:00:00:00:00,
                             Auto-reconnect timeout: 100 seconds, Idle timeout: Never,
                             Underlying interface: ge-3/0/3.1 Index 71
                             PacketType      Sent      Received
                             PADI             0          0
                             PADO             0          0
                             PADR             0          6
                             PADS             6          0
                             PADT             6          0
                             Service name error 0          0
                             AC system error    0          0
                             Generic error      0          0
                             Malformed packets 0          0

```



Unknown packets	0	0
Timeout		
PADI	0	
PADO	0	
PADR	0	

**show pppoe interfaces**  
(PPPoE Subscriber  
Interface with ACI  
Interface Set)

```
user@host> show pppoe interfaces pp0.1073741827
pp0.1073741827 Index 346
  State: Session Up, Session ID: 4, Type: Dynamic,
  Service name: AGILENT, Remote MAC address: 00:00:64:39:01:02,
  Session AC name: nbc,
  Session uptime: 6d 02:22 ago,
  Dynamic Profile: aci-vlan-pppoe-profile,
  Underlying interface: demux0.1073741826 Index 345
  Agent Circuit ID: aci-ppp-dhcp-dvlan-50
ACI Interface Set: aci-1002-demux0.1073741826 Index 2
```

## show pppoe logout

<b>Syntax</b>	show pppoe logout <underlying-interface-name>
<b>Release Information</b>	Command introduced in Junos OS Release 11.4.
<b>Description</b>	Display summary information about PPPoE clients currently undergoing lockout or currently in a lockout grace period on all PPPoE underlying logical interfaces or on a specified PPPoE underlying logical interface.
<b>Options</b>	<p><b>none</b>—Display information about the lockout condition and the lockout grace period for PPPoE clients on all PPPoE underlying logical interfaces.</p> <p><b>underlying-interface-name</b>—(Optional) Name of the PPPoE underlying logical interface.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying and Managing Dynamic PPPoE Configuration</li> <li>Configuring Lockout of PPPoE Subscriber Sessions</li> </ul>
<b>List of Sample Output</b>	<a href="#">show pppoe logout underlying-interface-name on page 545</a>
<b>Output Fields</b>	<a href="#">Table 86 on page 544</a> lists the output fields for the <b>show pppoe logout</b> command. Output fields are listed in the approximate order in which they appear.

**Table 86: show pppoe logout Output Fields**

Field Name	Field Description
<i>underlying-Interface-name</i>	Name of the PPPoE underlying logical interface.
<b>Index</b>	Index number of the logical interface, which reflects its initialization sequence.
<b>Lockout Time (seconds)</b>	<p>Displays the PPPoE lockout time range, the number of PPPoE clients in lockout condition, and the number of PPPoE clients in a lockout grace period:</p> <ul style="list-style-type: none"> <li><b>Min</b>—Minimum lockout time, in seconds, configured on the PPPoE underlying interface.</li> <li><b>Max</b>—Maximum lockout time, in seconds, configured on the PPPoE underlying interface.</li> <li><b>Total clients in lockout</b>—Number of PPPoE clients currently undergoing lockout.</li> <li><b>Total clients in lockout grace period</b>—Number of PPPoE clients currently in a lockout grace period. A <i>lockout grace period</i> occurs when the time between lockout events is greater than either 15 minutes or the maximum lockout time.</li> </ul>
<b>Client Address</b>	MAC source address of the PPPoE client.
<b>Current</b>	Current lockout time, in seconds; displays <b>0</b> (zero) if the PPPoE client is not undergoing lockout.
<b>Elapsed</b>	Time elapsed into the lockout period, in seconds; displays <b>0</b> (zero) if the PPPoE client is not undergoing lockout

Table 86: show pppoe lockout Output Fields (*continued*)

Field Name	Field Description
<b>Next</b>	Lockout time, in seconds, that the router uses for the next lockout event; displays a nonzero value if the PPPoE client is currently in a lockout grace period.

## Sample Output

```
show pppoe lockout          user@host> show pppoe lockout xe-1/0/0.0
underlying-interface-name  xe-1/0/0.0 Index 10305
                           Lockout Time (seconds): Min: 1, Max: 300
                           Total clients in lockout: 2
                           Total clients in lockout grace period: 1

Client Address              Current   Elapsed   Next
02:01:00:00:00:05          16       10        32
04:01:00:00:00:ab          256      168       300
0b:cd:ef:00:00:23           0         0         8
```

## show pppoe service-name-tables

<b>Syntax</b>	show pppoe service-name-tables <table-name>
<b>Release Information</b>	Command introduced in Junos OS Release 10.0.
<b>Description</b>	(M120 routers, M320 routers, and MX Series routers only) Display configuration information about PPPoE service name tables.
<b>Options</b>	<b>none</b> —Display the names of configured PPPoE service name tables.  <b>table-name</b> —(Optional) Name of a configured PPPoE service name table.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying a PPPoE Configuration</li> <li>Verifying and Managing Dynamic PPPoE Configuration</li> </ul>
<b>List of Sample Output</b>	<a href="#">show pppoe service-name-tables on page 547</a> <a href="#">show pppoe service-name-tables (For the Specified Table Name) on page 547</a>
<b>Output Fields</b>	Table 87 on page 546 lists the output fields for the <b>show pppoe service-name-tables</b> command. Output fields are listed in the approximate order in which they appear.

Table 87: show pppoe service-name-tables Output Fields

Field Name	Field Description	Level of Output
<b>Service Name Table</b>	Name of the PPPoE service name table.	none
<b>Service Name</b>	Name of a configured service in the PPPoE service name table: <ul style="list-style-type: none"> <li><b>&lt;empty&gt;</b>—Service of zero length that represents an unspecified service</li> <li><b>&lt;any&gt;</b>—Default service for non-empty service entries that do not match the configured empty or named service entries</li> <li><b>service-name</b>—Named service entry</li> </ul>	none
<b>Action</b>	Action taken when the PPPoE underlying interface interface receives a PPPoE Active Discovery Initiation (PADI) packet with the specified named service, <b>empty</b> service, <b>any</b> service, or ACI/ARI pair: <ul style="list-style-type: none"> <li><b>Delay seconds</b>—Number of seconds that the interface delays before responding with a PPPoE Active Discovery Offer (PADO) packet</li> <li><b>Drop</b>—Interface drops (ignores) the packet.</li> <li><b>Terminate</b>—Interface responds immediately with a PADO packet</li> </ul>	none
<b>Dynamic Profile</b>	Name of the dynamic profile with which the router creates a dynamic PPPoE subscriber interface. A dynamic profile can be assigned to a named service, <b>empty</b> service, <b>any</b> service, or ACI/ARI pair.	none

Table 87: show pppoe service-name-tables Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Routing Instance</b>	Name of the routing instance in which to instantiate the dynamic PPPoE subscriber interface. A routing instance can be assigned to a named service, <b>empty</b> service, <b>any</b> service, or ACI/ARI pair.	none
<b>Max Sessions</b>	Maximum number of active PPPoE sessions that the router can establish with the specified named service, <b>empty</b> service, or <b>any</b> service.	none
<b>Active Sessions</b>	Current count of active PPPoE sessions created using the specified named service, <b>empty</b> service, or <b>any</b> service. The Active Sessions value cannot exceed the Max Sessions value.	none
<b>ACI</b>	Agent circuit identifier (ACI) that corresponds to the DSLAM interface that initiated the client service request. An asterisk is interpreted as a wildcard character and can appear at the beginning, the end, or both the beginning and end of the string. An ACI can be configured as part of an ACI/ARI pair for a named service, <b>empty</b> service, or <b>any</b> service.	none
<b>ARI</b>	Agent remote identifier (ARI) that corresponds to the subscriber associated with the DSLAM interface that initiated the service request. An asterisk is interpreted as a wildcard character and can appear at the beginning, the end, or both at the beginning and end of the string. An ARI can be configured as part of an ACI/ARI pair for a named service, <b>empty</b> service, or <b>any</b> service.	none
<b>Static Interface</b>	Name of the static PPPoE interface reserved for exclusive use by the PPPoE client with matching ACI/ARI information. A static interface can be configured only for an ACI/ARI pair.	none

## Sample Output

```

show pppoe service-name-tables user@host> show pppoe service-name-tables
Service Name Table: test1
Service Name Table: test2
Service Name Table: test3

```

```

show pppoe service-name-tables user@host> show pppoe service-name-tables Table1
Service Name Table: Table1
Service Name: <empty>

```

(For the Specified  
Table Name)

```
Action: Terminate
Dynamic Profile: BasicPppoeProfile
Max Sessions: 100
Active Sessions: 3
Service Name: <any>
Action: Drop
ACI: velorum-ge-2/0/3
ARI: westford
    Action: Terminate
    Static Interface: pp0.100
ACI: volantis-ge-5/0/5
ARI: sunnyvale
    Action: Terminate
    Static Interface: pp0.101
Service Name: Wholesale
Action: Terminate
Dynamic Profile: WholesalePppoeProfile
Routing Instance: WholesaleRI
Max Sessions: 16000
Active Sessions: 4
```

## show pppoe sessions

<b>Syntax</b>	<pre>show pppoe sessions &lt;aci circuit-id-string&gt; &lt;ari remote-id-string&gt; &lt;service service-name&gt;</pre>	
<b>Release Information</b>	Command introduced in Junos OS Release 10.2.	
<b>Description</b>	(M120 routers, M320 routers, and MX Series routers only) Display information about all active PPPoE sessions on the router, or about the active PPPoE sessions established for a specified service name, agent circuit identifier (ACI), or agent remote identifier (ARI).	
<b>Options</b>	<p><b>none</b>—Display information for all active PPPoE sessions on the router.</p> <p><b>aci circuit-id-string</b>—(Optional) Display information only for active PPPoE sessions established with the specified agent circuit identifier. The agent circuit identifier corresponds to the DSLAM interface that initiated the service request.</p> <p><b>ari remote-id-string</b>—(Optional) Display information only for active PPPoE sessions established with the specified agent remote identifier. The agent remote identifier corresponds to the subscriber associated with the DSLAM interface that initiated the service request.</p> <p><b>service service-name</b>—(Optional) Display information only for active PPPoE sessions established with the specified service, where <i>service-name</i> can be <b>empty</b>, <b>any</b>, or a named service.</p>	
<b>Required Privilege Level</b>	view	
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying a PPPoE Configuration</li> <li>Verifying and Managing Dynamic PPPoE Configuration</li> </ul>	
<b>List of Sample Output</b>	<a href="#">show pppoe sessions (For All Active Sessions) on page 550</a> <a href="#">show pppoe sessions (For All Active Sessions Matching the Agent Circuit Identifier) on page 550</a>	
<b>Output Fields</b>	Table 88 on page 549 lists the output fields for the <b>show pppoe sessions</b> command. Output fields are listed in the approximate order in which they appear.	

Table 88: show pppoe sessions Output Fields

Field Name	Field Description	Level of Output
<b>Interface</b>	Name of the statically-created or dynamically-created PPPoE interface for the active PPPoE session.	none
<b>Underlying interface</b>	Interface on which PPPoE is running.	none

Table 88: show pppoe sessions Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>State</b>	State of the PPPoE session; displays <b>Session Up</b> for active PPPoE sessions.	none
<b>Session ID</b>	PPPoE session identifier.	none
<b>Remote MAC</b>	MAC address of the remote side of the connection, either the access concentrator or the PPPoE client.	none

### Sample Output

**show pppoe sessions**  
(For All Active Sessions)

```
user@host> show pppoe sessions
Interface      Underlying      State      Session      Remote
              interface
pp0.0          ge-2/0/3.2      Session Up  27           00:90:1A:42:0A:C1
pp0.1          ge-2/0/3.2      Session Up  28           00:90:1A:42:0A:C1
pp0.1073741824 ge-2/0/3.1      Session Up  29           00:90:1A:42:0A:C1
pp0.1073741825 ge-2/0/3.1      Session Up  30           00:90:1A:42:0A:C1
pp0.1073741826 ge-2/0/3.1      Session Up  31           00:90:1A:42:0A:C1
```

**show pppoe sessions**  
(For All Active Sessions Matching the Agent Circuit Identifier)

```
user@host> show pppoe sessions aci "velorum-ge-2/0/3"
Interface      Underlying      State      Session      Remote
              interface
pp0.0          ge-2/0/3.2      Session Up  27           00:90:1A:42:0A:C1
pp0.1          ge-2/0/3.2      Session Up  28           00:90:1A:42:0A:C1
```



## show pppoe statistics

<b>Syntax</b>	show pppoe statistics <logical-interface-name>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. <i>logical-interface-name</i> option introduced in Junos OS Release 10.1.
<b>Description</b>	(J Series Services Routers, M120 routers, M320 routers, and MX Series routers only) Display statistics information about PPPoE interfaces.
<b>Options</b>	<b>none</b> —Display PPPoE statistics for all interfaces.  <i>logical-interface-name</i> —(Optional) Name of a PPPoE underlying logical interface. Supported for M120 routers, M320 routers, and MX Series routers only.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show ppp address-pool on page 501</a></li> <li>• <a href="#">show pppoe underlying-interfaces on page 553</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show pppoe statistics on page 552</a> <a href="#">show pppoe statistics (For the Specified Underlying Interface Only) on page 552</a>
<b>Output Fields</b>	<a href="#">Table 89 on page 551</a> lists the output fields for the <b>show pppoe statistics</b> command. Output fields are listed in the approximate order in which they appear.

**Table 89: show pppoe statistics Output Fields**

Field Name	Field Description
<b>Active PPPoE sessions</b>	<p>Total number of active PPPoE sessions and the number of packets sent and received during the PPPoE session, categorized by packet type and packet errors:</p> <ul style="list-style-type: none"> <li>• <b>PADI</b>—PPPoE Active Discovery Initiation packets.</li> <li>• <b>PADO</b>—PPPoE Active Discovery Offer packets.</li> <li>• <b>PADR</b>—PPPoE Active Discovery Request packets.</li> <li>• <b>PADS</b>—PPPoE Active Discovery Session-Confirmation packets.</li> <li>• <b>PADT</b>—PPPoE Active Discovery Termination packets.</li> <li>• <b>Service name error</b>—Packets for which the Service-Name request could not be honored.</li> <li>• <b>AC system error</b>—Packets for which the access concentrator experienced an error in performing the host request. For example, the host had insufficient resources to create a virtual circuit.</li> <li>• <b>Generic error</b>—Packets that indicate an unrecoverable error occurred.</li> <li>• <b>Malformed packets</b>—Malformed or short packets that caused the packet handler to discard the frame as unreadable.</li> <li>• <b>Unknown packets</b>—Unrecognized packets.</li> </ul>

Table 89: show pppoe statistics Output Fields (*continued*)

Field Name	Field Description
<b>Timeouts</b>	<p>Information about timeouts that occurred during the PPPoE session (not displayed for M120, M320, and MX Series routers):</p> <ul style="list-style-type: none"> <li><b>PADI</b>—No PADR packet has been received within the timeout period. (This value is always zero and is not supported.)</li> <li><b>PADO</b>—No PPPoE Active Discovery Offer packet has been received within the timeout period.</li> <li><b>PADR</b>—No PADS packet has been received within the timeout period.</li> </ul>

## Sample Output

### show pppoe statistics

```

user@host> show pppoe statistics
Active PPPoE sessions: 1
PacketType      Sent      Received
PADI             0          0
PADO             0          0
PADR             0          0
PADS             0          0
PADT             0          0
Service name error 0          0
AC system error   0          0
Generic error     0          0
Malformed packets 0          0
Unknown packets   0          0
Timeouts
PADI             0
PADO             0
PADR             0

```

### show pppoe statistics (For the Specified Underlying Interface Only)

```

user@host> show pppoe statistics ge-4/0/3.2
Active PPPoE sessions: 4
PacketType      Sent      Received
PADI             0          5
PADO             5          0
PADR             0          5
PADS             4          0
PADT             0          1
Service name error 0          0
AC system error   0          0
Generic error     0          0
Malformed packets 0          0
Unknown packets   0          0

```

## show pppoe underlying-interfaces

<b>Syntax</b>	show pppoe underlying-interfaces <brief   detail   extensive> <lockout> <logical-interface-name>
<b>Release Information</b>	Command introduced in Junos OS Release 10.0. <b>lockout</b> option added in Junos OS Release 11.4.
<b>Description</b>	(M120, M320, and MX Series routers only) Display information about PPPoE underlying interfaces.
<b>Options</b>	<b>brief   detail   extensive</b> —(Optional) Display the specified level of output.  <b>lockout</b> —(Optional) Display summary information about the lockout condition and the lockout grace period for PPPoE clients on the PPPoE underlying interface.  <b>logical-interface-name</b> —(Optional) Name of a PPPoE underlying logical interface.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>Verifying and Managing Dynamic PPPoE Configuration</li> <li>Configuring an Underlying Interface for Dynamic PPPoE Subscriber Interfaces</li> <li>Configuring the PPPoE Family for an Underlying Interface</li> <li>Verifying and Managing Agent Circuit Identifier-Based Dynamic VLAN Configuration</li> </ul>
<b>List of Sample Output</b>	<a href="#">show pppoe underlying-interfaces brief on page 556</a> <a href="#">show pppoe underlying-interfaces detail on page 556</a> <a href="#">show pppoe underlying-interfaces extensive on page 556</a> <a href="#">show pppoe underlying-interfaces extensive (PPPoE client in lockout condition) on page 557</a> <a href="#">show pppoe underlying-interfaces lockout on page 557</a> <a href="#">show pppoe underlying-interfaces detail (Autosensing Configured for ACI-based Dynamic VLANs) on page 557</a>
<b>Output Fields</b>	<a href="#">Table 90 on page 553</a> lists the output fields for the <b>show pppoe underlying-interfaces</b> command. Output fields are listed in the approximate order in which they appear.

**Table 90: show pppoe underlying-interfaces Output Fields**

Field Name	Field Description	Level of Output
Underlying Interface	Name of the PPPoE underlying logical interface.	All levels
Service Name Table	Name of the service name table.	All levels

Table 90: show pppoe underlying-interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Dynamic Profile</b>	Name of the dynamic profile that was used to create this interface. If the interface was statically created, then the value is <b>none</b> .	All levels
<b>Index</b>	Index number of the logical interface, which reflects its initialization sequence.	<b>detail extensive</b>
<b>State</b>	Origin of the logical interface: <b>Static</b> or <b>Dynamic</b> . Indicates whether the interface was statically or dynamically created.	<b>detail extensive</b>
<b>Operational States</b>	Fields in this block are actual operational values rather than simply the configured values. The operational values can be the result of RADIUS-initiated changes.	<b>detail extensive</b>
<b>Max Sessions</b>	Maximum number of PPPoE logical interfaces that can be activated on the underlying interface. When this number of logical interfaces has been established, all subsequent PPPoE Active Discovery Initiation (PADI) packets are dropped and all subsequent PPPoE Active Discovery Request (PADR) packets trigger PPPoE Active Discovery Session (PADS) error responses.	<b>detail extensive</b>
<b>Max Sessions VSA Ignore</b>	Whether the router is configured to ignore (clear) the PPPoE maximum session value returned by RADIUS in the Max-Clients-Per-Interface Juniper Networks VSA [26-143] and restore the PPPoE maximum session value on the underlying interface to the value configure with the <b>max-sessions</b> statement: <b>Off</b> (default) or <b>On</b> .	<b>detail extensive none</b>
<b>Active Sessions</b>	Number of active PPPoE sessions on the underlying interface. If a dynamic profile is listed, then it is the number of active PPPoE sessions on the underlying interface that are using this profile. The Active Sessions value must not exceed the Max Sessions value.	<b>detail extensive</b>
<b>Agent Circuit Identifier</b>	Whether the underlying interface is configured to enable creation of (autosense) dynamic VLAN subscriber interfaces based on agent circuit identifier (ACI) information. <b>Autosensing</b> indicates that creation of ACI-based dynamic VLAN interfaces is enabled on the underlying interface. If creation of ACI-based dynamic VLANs is not configured on the underlying interface, this field does not appear.	<b>detail extensive none</b>
<b>Duplicate Protection</b>	State of PPPoE duplicate protection: <b>On</b> or <b>Off</b> . When duplicate protection is configured for the underlying interface, a dynamic PPPoE logical interface cannot be activated when an existing active logical interface is present for the same PPPoE client. The uniqueness of the PPPoE client is determined by the client's MAC address.	<b>detail extensive</b>
<b>Short Cycle Protection</b>	State of PPPoE short cycle protection: <b>On</b> or <b>Off</b> . Enabling short cycle protection, also known as PPPoE lockout, on the PPPoE underlying interface temporarily prevents (locks out) a failed or short-lived (short-cycle) PPPoE subscriber session from reconnecting to the router for a default or configurable period of time. PPPoE client sessions are identified by their unique media access control (MAC) source address.	<b>detail extensive</b>
<b>AC Name</b>	Name of the access concentrator.	<b>detail extensive</b>

Table 90: show pppoe underlying-interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>PacketType</b>	<p>Number of packets sent and received during the PPPoE session, categorized by packet type and packet errors:</p> <ul style="list-style-type: none"> <li>• <b>PADI</b>—PPPoE Active Discovery Initiation packets.</li> <li>• <b>PADO</b>—PPPoE Active Discovery Offer packets.</li> <li>• <b>PADR</b>—PPPoE Active Discovery Request packets.</li> <li>• <b>PADS</b>—PPPoE Active Discovery Session-Confirmation packets.</li> <li>• <b>PADT</b>—PPPoE Active Discovery Termination packets.</li> <li>• <b>Service name error</b>—Packets for which the Service-Name request could not be honored.</li> <li>• <b>AC system error</b>—Packets for which the access concentrator experienced an error in performing the host request. For example, the host had insufficient resources to create a virtual circuit.</li> <li>• <b>Generic error</b>—Packets that indicate an unrecoverable error occurred.</li> <li>• <b>Malformed packets</b>—Malformed or short packets that caused the packet handler to discard the frame as unreadable.</li> <li>• <b>Unknown packets</b>—Unrecognized packets.</li> </ul>	<b>extensive</b>
<b>Lockout Time (sec)</b>	<p>The PPPoE lockout time range, the number of PPPoE clients in lockout condition, and the number of PPPoE clients in a lockout grace period if <b>Short Cycle Protection</b> is enabled (<b>On</b>):</p> <ul style="list-style-type: none"> <li>• <b>Min</b>—Minimum lockout time, in seconds, configured on the PPPoE underlying interface.</li> <li>• <b>Max</b>—Maximum lockout time, in seconds, configured on the PPPoE underlying interface.</li> <li>• <b>Total clients in lockout</b>—Number of PPPoE clients currently undergoing lockout.</li> <li>• <b>Total clients in lockout grace period</b>—Number of PPPoE clients currently in a lockout grace period. A <i>lockout grace period</i> occurs when the time between lockout events is greater than either 15 minutes or the maximum lockout time.</li> </ul>	<b>extensive</b>
<b>Client Address</b>	MAC source address of the PPPoE client.	<b>extensive</b>
<b>Current</b>	Current lockout time, in seconds; displays <b>0</b> (zero) if the PPPoE client is not undergoing lockout.	<b>extensive</b>
<b>Elapsed</b>	Time elapsed into the lockout period, in seconds; displays <b>0</b> (zero) if the PPPoE client is not undergoing lockout	<b>extensive</b>
<b>Next</b>	Lockout time, in seconds, that the router uses for the next lockout event; displays a nonzero value if the PPPoE client is currently in a lockout grace period.	<b>extensive</b>

## Sample Output

**show pppoe  
underlying-interfaces  
brief**

```
user@host> show pppoe underlying-interfaces brief
Underlying Interface  Service Name Table  Dynamic Profile
ge-4/0/3.1           Premium             None
ge-4/0/3.2           None                PppoeProfile
```

**show pppoe  
underlying-interfaces  
detail**

```
user@host> show pppoe underlying-interfaces detail
ge-4/0/3.1 Index 73
  Operational States:
  State: Static, Dynamic Profile: None,
  Max Sessions: 4000, Max Sessions VSA Ignore: Off,
  Active Sessions: 0,
  Service Name Table: Premium,
  AC Name: velorum, Duplicate Protection: Off,
  Short Cycle Protection: On

ge-4/0/3.2 Index 78
  Operational States:
  State: Dynamic, Dynamic Profile: PppoeProfile,
  Max Sessions: 500, Max Sessions VSA Ignore: Off,
  Active Sessions: 3,
  Service Name Table: None,
  AC Name: velorum, Duplicate Protection: On,
  Short Cycle Protection: On
```

**show pppoe  
underlying-interfaces  
extensive**

```
user@host> show pppoe underlying-interfaces extensive
ge-4/0/3.1 Index 73
  Operational States:
  State: Static, Dynamic Profile: None,
  Max Sessions: 4000, Max Sessions VSA Ignore Off,
  Active Sessions: 0,
  Service Name Table: None,
  AC Name: velorum, Duplicate Protection: Off,
  Short Cycle Protection: Off

  PacketType           Sent      Received
  PADI                  0          0
  PADO                  0          0
  PADR                  0          0
  PADS                  0          0
  PADT                  0          0
  Service name error    0          0
  AC system error       0          0
  Generic error         0          0
  Malformed packets    0          0
  Unknown packets       0          0

ge-4/0/3.2 Index 78
  Operational States:
  State: Dynamic, Dynamic Profile: PppoeProfile,
  Max Sessions: 4000, Max Sessions VSA Ignore: Off,
  Active Sessions: 3,
  Service Name Table: None,
  AC Name: velorum, Duplicate Protection: Off,
  Short Cycle Protection: Off
```

PacketType	Sent	Received
PADI	0	5
PADO	5	0
PADR	0	5
PADS	4	0
PADT	0	1
Service name error	0	0
AC system error	0	0
Generic error	0	0
Malformed packets	0	0
Unknown packets	0	0

**show pppoe  
underlying-interfaces  
extensive (PPPoE  
client in lockout  
condition)**

```
user@host> show pppoe underlying-interfaces ge-1/0/0.0 extensive
ge-1/0/0.0 Index 71
```

```
State: Static, Dynamic Profile: None,
Max Sessions: 32000, Max Sessions VSA Ignore: Off,
Active Sessions: 0,
Service Name Table: None,
AC name: winona, Duplicate Protection: On,
Short Cycle Protection: On
```

PacketType	Sent	Received
PADI	0	7
PADO	3	0
PADR	0	3
PADS	3	0
PADT	2	1
Service name error	0	0
AC system error	0	0
Generic error	0	0
Malformed packets	0	0
Unknown packets	0	0

```
Lockout Time (sec): Min: 1, Max: 30
Total clients in lockout: 1
Total clients in lockout grace period: 0
```

Client Address	Current	Elapsed	Next
00:10:94:00:00:01	4	3	8

**show pppoe  
underlying-interfaces  
lockout**

```
user@host> show pppoe underlying-interfaces ge-1/0/0.0 lockout
ge-1/0/0.0 Index 71
```

```
Short Cycle Protection: On,
Lockout Time (sec): Min: 10, Max: 60
Total clients in lockout: 0
Total clients in lockout grace period: 0
```

**show pppoe  
underlying-interfaces  
detail (Autosensing  
Configured for  
ACI-based Dynamic  
VLANs)**

```
user@host> show pppoe underlying-interfaces demux0.1073741826 detail
demux0.1073741826 Index 345
```

```
State: Dynamic, Dynamic Profile: aci-vlan-pppoe-profile,
Max Sessions: 32000, Max Sessions VSA Ignore: Off,
Active Sessions: 1,
Agent Circuit Identifier: Autosensing,
Service Name Table: None,
Duplicate Protection: On, Short Cycle Protection: Off,
AC Name: nbc,
```

## show pppoe version

<b>Syntax</b>	show pppoe version
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series Services Routers, M120 routers, and M320 routers only) Display version information about PPPoE.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show pppoe version on page 559</a>
<b>Output Fields</b>	<a href="#">Table 91 on page 558</a> lists the output fields for the <b>show pppoe version</b> command. Output fields are listed in the approximate order in which they appear.

**Table 91: show pppoe version Output Fields**

Field Name	Field Description
version <i>n</i>	PPPoE version number and RFC. For example, <b>version 1, rfc 2516</b> .
PPPoE protocol	State of the PPPoE protocol: <b>enabled</b> or <b>disabled</b> .
Maximum Sessions	Maximum active sessions supported per router. The default is 256 sessions.
PADI resend timeout	Initial time, in seconds, that the router waits to receive a PPoE Active Discovery Offer (PADO) packet for the PPoE Active Discovery Initiation (PADI) packet sent. This timeout doubles for each successive PADI packet sent. Not displayed for M120 and M320 routers.
PADR resend timeout	Initial time, in seconds, that the router waits to receive a PPoE Active Discovery Session Confirmation (PADS) packet for the PPoE Active Discovery Request (PADR) packet sent. This timeout doubles for each successive PADR packet sent. Not displayed for M120 and M320 routers.
Max resend timeout	Maximum value, in seconds, that the PADI or PADR resend timer can accept. The maximum value is 64. Not displayed for M120 and M320 routers.
Max Configured AC timeout	Time, in seconds, during which the configured access concentrator must respond. Not displayed for M120 and M320 routers.



## Sample Output

`show pppoe version`

```
user@host> show pppoe version
Point-to-Point Protocol Over Ethernet, version 1. rfc2516
  PPPoE protocol           = Enabled
  Maximum Sessions         = 256
  PADI resend timeout      = 2 seconds
  PADR resend timeout      = 16 seconds
  Max resend timeout       = 64 seconds
  Max Configured AC timeout = 4 seconds
```



## PART 6

# Serial Interfaces

- [Serial Interface Operational Mode Commands on page 563](#)



## CHAPTER 10

# Serial Interface Operational Mode Commands

Table 92 on page 563 summarizes the command-line interface (CLI) command that you can use to monitor and troubleshoot serial interfaces.

**Table 92: Serial Interface Operational Mode Commands**

Task	Command
Display status information about serial interfaces.	<code>show interfaces (Serial)</code>

## show interfaces (Serial)

<b>Syntax</b>	<pre>show interfaces <i>interface-type</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about serial interfaces, including RS-232, RS-422/449, EIA-530, X.21, and V.35.
<b>Options</b>	<p><b><i>interface-type</i></b>—On M Series and T Series routers, the interface type is <b><i>se-fpc/pic/port</i></b>. On the J Series routers, the interface type is <b><i>se-pim/0/port</i></b>.</p> <p><b><i>brief   detail   extensive   terse</i></b>—(Optional) Display the specified level of output.</p> <p><b><i>descriptions</i></b>—(Optional) Display interface description strings.</p> <p><b><i>media</i></b>—(Optional) Display media-specific information about network interfaces.</p> <p><b><i>snmp-index snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b><i>statistics</i></b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Serial, EIA-530) on page 571</a></p> <p><a href="#">show interfaces brief (Serial, EIA-530) on page 571</a></p> <p><a href="#">show interfaces detail (Serial, EIA-530) on page 571</a></p> <p><a href="#">show interfaces extensive (Serial, EIA-530) on page 572</a></p> <p><a href="#">show interfaces (Serial, V.35) on page 573</a></p> <p><a href="#">show interfaces brief (Serial, V.35) on page 573</a></p> <p><a href="#">show interfaces detail (Serial, V.35) on page 574</a></p> <p><a href="#">show interfaces extensive (Serial, V.35) on page 574</a></p> <p><a href="#">show interfaces statistics detail (RS 449) on page 576</a></p>
<b>Output Fields</b>	Table 93 on page 564 lists the output fields for the <b>show interfaces (Serial)</b> command. Output fields are listed in the approximate order in which they appear.

Table 93: show interfaces (Serial) Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
Physical interface	Name of the physical interface.	All levels

Table 93: show interfaces (Serial) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit (MTU) size on the physical interface.	All levels
<b>Maximum speed</b>	Maximum speed. The nonconfigurable value is 16,384 kbps.	<b>detail extensive none</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Keepalive settings</b>	(PPP and HDLC) Configured settings for keepalive packets. <ul style="list-style-type: none"> <li><b>Interval <i>seconds</i></b>—Time between successive keepalive requests. The range of values, in seconds, is 10 to 32,767. The default value is 10.</li> <li><b>Up-count <i>number</i></b>—Number of keepalive packets a destination must receive to change a link's status from down to up. The range of values is 1 to 255. The default value is 1.</li> <li><b>Down-count <i>number</i></b>—Number of keepalive packets a destination must fail to receive before the network takes a link down. The range is 1 to 255. The default value is 3.</li> </ul>	All levels
<b>Keepalive</b>	(PPP and HDLC) Information about keepalive packets. <ul style="list-style-type: none"> <li><b>Input: <i>number (hh:mm:ss ago)</i></b>—Number of keepalive packets received by PPP and the time since the last keepalive packet was received.</li> <li><b>Output: <i>number (hh:mm:ss ago)</i></b>—Number of keepalive packets sent by PPP and the time since the last keepalive packet was sent.</li> </ul>	<b>brief none</b>

Table 93: show interfaces (Serial) Output Fields (*continued*)

Field Name	Field Description	Level of Output
Keepalive statistics	(PPP and HDLC) Information about keepalive packets. <ul style="list-style-type: none"> <li>• <b>Input: <i>number</i> (last seen <i>hh:mm:ssago</i>)</b>—Number of keepalive packets received by PPP and the time since the last keepalive packet was received.</li> <li>• <b>Output: <i>number</i> (last seen <i>hh:mm:ss ago</i>)</b>—Number of keepalive packets sent by PPP and the time since the last keepalive packet was sent.</li> </ul>	detail extensive
LCP state	(PPP) Link Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—LCP is not configured on the interface.</li> <li>• <b>Opened</b>—LCP negotiation is successful.</li> </ul>	detail extensive none
NCP state	(PPP) Network Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	detail extensive none
CHAP state	(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction. <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the Success state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Closed</b>—CHAP authentication is incomplete.</li> <li>• <b>Failure</b>—CHAP authentication failed.</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Success</b>—CHAP authentication was successful.</li> </ul>	detail extensive none
CoS queues	Number of CoS queues configured.	detail extensive none
Last flapped	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: <i>year-month-day hour:minute:second timezone</i> (<i>hour:minute:second ago</i>)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	detail extensive none
Input Rate	Input rate in bits per second (bps) and packets per second (pps).	None specified
Output Rate	Output rate in bps and pps.	None specified



Table 93: show interfaces (Serial) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeds the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues supported</b>	Total number of egress queues supported on the specified interface. Displayed with the <b>statistics</b> option.	<b>detail extensive</b>
<b>Egress queues in use</b>	Total number of egress queues in use on the specified interface. Displayed with the <b>statistics</b> option.	<b>detail extensive</b>

Table 93: show interfaces (Serial) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Queue counters</b>	CoS queue number and its associated user-configured forwarding class name. Displayed with the <b>statistics</b> option. <ul style="list-style-type: none"> <li><b>Queued packets</b>—Number of queued packets.</li> <li><b>Transmitted packets</b>—Number of transmitted packets.</li> <li><b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Serial media information</b>	Information about the physical media: <ul style="list-style-type: none"> <li><b>Line protocol</b>—<b>eia530</b>, <b>eia530a</b>, <b>rs232</b>, <b>rs449</b>, <b>v.35</b>, or <b>x.21</b>.</li> <li><b>Resync history</b>—Information about resynchronization events: <ul style="list-style-type: none"> <li><b>Sync loss count</b>—Number of times the synchronization was lost.</li> </ul> </li> <li><b>Data signal</b>—(X.21 and V.35) Information about the data signal: <ul style="list-style-type: none"> <li><b>Rx Clock</b>—Receive clock status: OK (DTE is receiving the receive clock signal) or Not detected (receive clock signal is not being received).</li> </ul> </li> <li><b>Control signals</b>—Information about modem control signals: <ul style="list-style-type: none"> <li><b>Local mode</b>: DCE (data communication equipment) or DTE (data terminal equipment)</li> <li><b>To DCE</b>—Control signals that the Serial PIC sent to the DCE: DTR (Data Terminal Ready: <b>up</b> or <b>down</b>) or RTS (Request To Send: <b>up</b> or <b>down</b>.)</li> <li><b>From DC</b>—Control signals that the Serial PIC received from the DCE: CTS (Clear To Send: <b>up</b> or <b>down</b>), DCD (Data Carrier Detect: <b>up</b> or <b>down</b>), DSR (Data Set Ready: <b>up</b> or <b>down</b>), or TM (Test Mode: <b>up</b> or <b>down</b>).</li> </ul> </li> <li><b>Clocking mode</b>—Clocking used for the transmit clock: <ul style="list-style-type: none"> <li><b>dte</b>—Transmit clock is generated by DTE.</li> <li><b>dce</b>—Transmit clock is generated by the DCE and is looped back as the transmit clock.</li> <li><b>loop-timed</b>—Receive clock from the DCE is looped back as the transmit clock.</li> </ul> </li> <li><b>Clock rate</b>—Rate, in megahertz (MHz), at which the clock is configured.</li> <li><b>Loopback</b>—Configured loopback mode for the interface: <b>dce-remote</b>, <b>dce-local</b>, <b>liu</b>, <b>local</b>, or <b>none</b>.</li> <li><b>Tx clock</b>—Clocking phase of the transmit clock: <b>invert</b> (transmit clock polarity is inverted) or <b>non-invert</b> (transmit clock polarity is not inverted).</li> <li><b>Line encoding</b>—Type of line encoding used: <b>nrz</b> (nonreturn to zero) or <b>nrzi</b> (return to zero inverted).</li> </ul>	<b>detail extensive</b>
<b>Packet Forwarding Engine configuration</b>	Information about the configuration of the Packet Forwarding Engine: <ul style="list-style-type: none"> <li><b>Destination slot</b>—FPC slot number.</li> <li><b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>

Table 93: show interfaces (Serial) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	Information about the CoS queue for the physical interface: <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the source and destination address are also displayed.	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mpls</b> .	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	<b>detail extensive</b>

Table 93: show interfaces (Serial) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces (Serial, EIA-530)

```
user@host> show interfaces se-5/0/1
Physical interface: se-5/0/1, Enabled, Physical link is Up
  Interface index: 144, SNMP ifIndex: 41
  Type: Serial, Link-level type: PPP, MTU: 1504, Maximum speed: 16384kbps
  Device flags   : Present Running
  Interface flags: Point-To-Point Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 32 (00:00:10 ago), Output: 31 (00:00:07 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
  Not-configured
  CHAP state: Closed
  CoS queues    : 8 supported, 8 maximum usable queues
  Last flapped  : 2006-04-26 15:10:18 PDT (00:05:22 ago)
  Input rate    : 0 bps (0 pps)
  Output rate   : 0 bps (0 pps)

Logical interface se-5/0/1.0 (Index 71) (SNMP ifIndex 45)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  Protocol inet, MTU: 1500
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 12.0.0.0/30, Local: 12.0.0.1, Broadcast: 12.0.0.3
```

### show interfaces brief (Serial, EIA-530)

```
user@host> show interfaces se-5/0/1 brief
Physical interface: se-5/0/1, Enabled, Physical link is Up
  Type: Serial, Link-level type: PPP, MTU: 1504
  Device flags   : Present Running
  Interface flags: Point-To-Point Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 235 (00:00:10 ago), Output: 234 (00:00:00 ago)

Logical interface se-5/0/1.0
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  inet 12.0.0.1/30
```

### show interfaces detail (Serial, EIA-530)

```
user@host> show interfaces se-5/0/1 detail
Physical interface: se-5/0/1, Enabled, Physical link is Up
  Interface index: 144, SNMP ifIndex: 41, Generation: 25
  Type: Serial, Link-level type: PPP, MTU: 1504, Maximum speed: 16384kbps
  Device flags   : Present Running
  Interface flags: Point-To-Point Internal: 0x4000
  Link flags     : Keepalives
  Hold-times     : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 37 (last seen 00:00:06 ago)
    Output: 35 (last sent 00:00:01 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
  Not-configured
  CHAP state: Closed
  CoS queues    : 8 supported, 8 maximum usable queues
  Last flapped  : 2006-04-26 15:10:18 PDT (00:06:02 ago)
```

```

Statistics last cleared: Never
Traffic statistics:
  Input bytes :          928          40 bps
  Output bytes :        1023          48 bps
  Input packets:          76           0 pps
  Output packets:        77           0 pps
Serial media information:
  Line protocol: eia530
  Resync history:
    Sync loss count: 0
  Data signal:
    Rx Clock: OK
  Control signals:
    Local mode: DTE
    To DCE: DTR: up, RTS: up
    From DCE: CTS: up, DCD: up, DSR: up
  Clocking mode: loop-timed
  Clock rate: 8.0 MHz
  Loopback: none
  Tx clock: non-invert
  Line encoding: nrz

Logical interface se-5/0/1.0 (Index 71) (SNMP ifIndex 45) (Generation 9)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
Protocol inet, MTU: 1500, Generation: 15, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 12.0.0.0/30, Local: 12.0.0.1, Broadcast: 12.0.0.3,
  Generation: 23

```

### show interfaces extensive (Serial, EIA-530)

```

user@host> show interfaces se-5/0/1 extensive
Physical interface: se-5/0/1, Enabled, Physical link is Up
Interface index: 144, SNMP ifIndex: 41, Generation: 25
Type: Serial, Link-level type: PPP, MTU: 1504, Maximum speed: 16384kbps
Device flags : Present Running
Interface flags: Point-To-Point Internal: 0x4000
Link flags : Keepalives
Hold-times : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 40 (last seen 00:00:00 ago)
  Output: 37 (last sent 00:00:09 ago)
LCP state: Opened
NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
Not-configured
CHAP state: Closed
CoS queues : 8 supported, 8 maximum usable queues
Last flapped : 2006-04-26 15:10:18 PDT (00:06:28 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :          988          40 bps
  Output bytes :        1088          48 bps
  Input packets:          81           0 pps
  Output packets:        82           0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 2, Runts: 0, Giants: 0,
  Policed discards: 0, Resource errors: 0
Output errors:
  Carrier transitions: 1, Errors: 0, Drops: 0, MTU errors: 0,
  Resource errors: 0
Serial media information:

```

```

Line protocol: eia530
Resync history:
  Sync loss count: 0
Data signal:
  Rx Clock: OK
Control signals:
  Local mode: DTE
  To DCE: DTR: up, RTS: up
  From DCE: CTS: up, DCD: up, DSR: up
Clocking mode: loop-timed
Clock rate: 8.0 MHz
Loopback: none
Tx clock: non-invert
Line encoding: nrz
Packet Forwarding Engine configuration:
  Destination slot: 5, PLP byte: 1 (0x00)
CoS information:
  CoS transmit queue      Bandwidth      Buffer      Priority      Limit
                           %          bps          %          usec
0 best-effort             95      15564800    95           0          low      none
3 network-control         5        819200      5           0          low      none

Logical interface se-5/0/1.0 (Index 71) (SNMP ifIndex 45) (Generation 9)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
Protocol inet, MTU: 1500, Generation: 15, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 12.0.0.0/30, Local: 12.0.0.1, Broadcast: 12.0.0.3,
  Generation: 23

```

### show interfaces (Serial, V.35)

```

user@host> show interfaces se-5/0/0
Physical interface: se-5/0/0, Enabled, Physical link is Down
Interface index: 150, SNMP ifIndex: 39
Type: Serial, Link-level type: PPP, MTU: 1504, Maximum speed: 16384kbps
Device flags   : Present Running Down
Interface flags: Hardware-Down Point-To-Point Internal: 0x4000
Link flags     : Loose-NCP
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive: Input: 0 (never), Output: 0 (never)
LCP state: Down
NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
mpls: Not-configured
CHAP state: Closed
CoS queues     : 8 supported, 8 maximum usable queues
Last flapped   : 2006-04-26 14:51:27 PDT (01:02:23 ago)
Input rate     : 0 bps (0 pps)
Output rate    : 0 bps (0 pps)

Logical interface se-5/0/0.0 (Index 73) (SNMP ifIndex 27)
Flags: Hardware-Down Device-Down Point-To-Point SNMP-Traps
Encapsulation: PPP
Protocol inet, MTU: 1500
Flags: Protocol-Down
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
  Destination: 13.0.0.0/30, Local: 13.0.0.2, Broadcast: 13.0.0.3

```

### show interfaces brief (Serial, V.35)

```

user@host> show interfaces se-5/0/0 brief
Physical interface: se-5/0/0, Enabled, Physical link is Down
Type: Serial, Link-level type: PPP, MTU: 1504
Device flags   : Present Running Down

```

```

Interface flags: Hardware-Down Point-To-Point Internal: 0x4000
Link flags      : Loose-NCP
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive: Input: 0 (never), Output: 0 (never)

```

```

Logical interface se-5/0/0.0
  Flags: Hardware-Down Device-Down Point-To-Point SNMP-Traps
  Encapsulation: PPP
  inet 13.0.0.2/30

```

### show interfaces detail (Serial, V.35)

```

user@host> show interfaces se-5/0/0 detail
Physical interface: se-5/0/0, Enabled, Physical link is Down
  Interface index: 150, SNMP ifIndex: 39, Generation: 31
  Type: Serial, Link-level type: PPP, MTU: 1504, Maximum speed: 16384kbps
  Device flags   : Present Running Down
  Interface flags: Hardware-Down Point-To-Point Internal: 0x4000
  Link flags     : Loose-NCP
  Hold-times    : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 0 (last seen: never)
    Output: 0 (last sent: never)
  LCP state: Down
  NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Closed
  CoS queues   : 8 supported, 8 maximum usable queues
  Last flapped : 2006-04-26 14:51:27 PDT (01:03:15 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes : 0 0 bps
    Output bytes: 0 0 bps
    Input packets: 0 0 pps
    Output packets: 0 0 pps
  Serial media information:
    Line protocol: v.35
    Resync history:
      Sync loss count: 0
    Data signal:
      Rx Clock: Not Detected
    Control signals:
      Local mode: DCE
      To DTE: CTS: down, DCD: down, DSR: up
      From DTE: DTR: down, RTS: down
    DCE loopback override: Off
    Clocking mode: internal
    Clock rate: 38.4 KHz
    Loopback: none
    Tx clock: non-invert
    Line encoding: nrz

Logical interface se-5/0/0.0 (Index 73) (SNMP ifIndex 27) (Generation 12)
  Flags: Hardware-Down Device-Down Point-To-Point SNMP-Traps
  Encapsulation: PPP
  Protocol inet, MTU: 1500, Generation: 17, Route table: 0
  Flags: Protocol-Down
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 13.0.0.0/30, Local: 13.0.0.2, Broadcast: 13.0.0.3,
    Generation: 23

```



## show interfaces extensive (Serial, V.35)

```

user@host> show interfaces se-5/0/0 extensive
Physical interface: se-5/0/0, Enabled, Physical link is Down
Interface index: 150, SNMP ifIndex: 39, Generation: 31
Type: Serial, Link-level type: PPP, MTU: 1504, Maximum speed: 16384kbps
Device flags   : Present Running Down
Interface flags: Hardware-Down Point-To-Point Internal: 0x4000
Link flags     : Loose-NCP
Hold-times     : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 0 (last seen: never)
  Output: 0 (last sent: never)
LCP state: Down
NCP state: inet: Not-configured, inet6: Not-configured, iso: Not-configured,
mpls: Not-configured
CHAP state: Closed
CoS queues   : 8 supported, 8 maximum usable queues
Last flapped : 2006-04-26 14:51:27 PDT (01:04:17 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   :                0                0 bps
Output bytes  :                0                0 bps
Input packets:                0                0 pps
Output packets:              0                0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
  Resource errors: 0
Serial media information:
  Line protocol: v.35
  Resync history:
    Sync loss count: 0
  Data signal:
    Rx Clock: Not Detected
  Control signals:
    Local mode: DCE
    To DTE: CTS: down, DCD: down, DSR: up
    From DTE: DTR: down, RTS: down
  DCE loopback override: Off
  Clocking mode: internal
  Clock rate: 38.4 KHz
  Loopback: none
  Tx clock: non-invert
  Line encoding: nrz
Packet Forwarding Engine configuration:
  Destination slot: 5, PLP byte: 1 (0x00)
CoS information:
  CoS transmit queue      Bandwidth      Buffer      Priority  Limit
                           %          bps      %      usec
  0 best-effort           95        15564800   95        0         low    none
  3 network-control       5          819200     5         0         low    none

Logical interface se-5/0/0.0 (Index 73) (SNMP ifIndex 27) (Generation 12)
Flags: Hardware-Down Device-Down Point-To-Point SNMP-Traps
Encapsulation: PPP
Protocol inet, MTU: 1500, Generation: 17, Route table: 0
Flags: Protocol-Down
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
  Destination: 13.0.0.0/30, Local: 13.0.0.2, Broadcast: 13.0.0.3,

```

Generation: 23

**show interfaces  
statistics detail (RS  
449)**

```

user@host> show interfaces se-6/0/0 statistics detail
Interface index: 149, SNMP ifIndex: 59, Generation: 150
Type: Serial, Link-level type: PPP, MTU: 1504, Maximum speed: 8mbps
Device flags   : Present Running
Interface flags: Point-To-Point Internal: 0x4000
Link flags     : No-Keepalives Loose-NCP
Hold-times    : Up 0 ms, Down 0 ms
LCP state: Opened
NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mppls:
Not-configured
CHAP state: Closed
PAP state: Closed
CoS queues    : 8 supported, 8 maximum usable queues
Last flapped  : 2007-11-28 19:38:36 PST (00:14:06 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :           744           0 bps
  Output bytes  :          5978           0 bps
  Input packets :            33           0 pps
  Output packets:           129           0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0,
  Resource errors: 0
Output errors:
  Carrier transitions: 13, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0
Egress queues: 8 supported, 5 in use
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	24	24	0
1 expedited-fo	0	0	0
2 bulk	0	0	0
3 assured-forw	105	105	0
4 voip	0	0	0

```

Serial media information:
Line protocol: rs449
Resync history:
  Sync loss count: 0
Data signal:
  Rx Clock: OK
Control signals:
  Local mode: DTE
  To DCE: DTR: up, RTS: up
  From DCE: CTS: up, DCD: up, DSR: up
Clocking mode: internal
Loopback: none
Tx clock: non-invert
Line encoding: nrz

Logical interface se-6/0/0.0 (Index 75) (SNMP ifIndex 69) (Generation 141)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
Protocol inet, MTU: 256, Generation: 145, Route table: 0
Flags: None

```

Addresses, Flags: Is-Preferred Is-Primary  
Destination: 11.11.11/24, Local: 11.11.11.2, Broadcast: 11.11.11.255,  
Generation: 157



## PART 7

# Optical Interfaces

- [SONET/SDH Interface Operational Mode Commands on page 581](#)



# SONET/SDH Interface Operational Mode Commands

Table 94 on page 581 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot aggregated SONET/SDH interfaces and SONET/SDH interfaces. Commands are listed in alphabetical order.

**Table 94: SONET/SDH Interface Operational Mode Commands**

Task	Command
Monitor Automatic Protection Switching (APS) information.	<code>show aps</code>
Display status information about aggregated SONET/SDH interfaces.	<code>show interfaces (Aggregated SONET/SDH)</code>
Display status information about SONET/SDH interfaces.	<code>show interfaces (SONET/SDH)</code>
Display the transceiver temperature, laser bias current, laser output power, receive optical power, and related alarms for SONET interfaces.	<code>show interfaces diagnostics optics (SONET)</code>

For more information about monitoring and troubleshooting SONET interfaces, see “Investigate SONET Interfaces” in the *Junos Interfaces Network Operations Guide*.

## show aps

---

<b>Syntax</b>	<code>show aps</code> <code>&lt;brief   detail   extensive   summary&gt;</code> <code>&lt;group <i>group</i>   interface <i>so-fpc/pic/port</i>&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display information about Automatic Protection Switching (APS) for SONET configurations and about Multiplex Section Protection (MSP) for SDH configurations.
<b>Options</b>	<b>none</b> —(Same as brief) Display brief information about APS or MSP for all groups and SONET/SDH interfaces.  <b>brief   detail   extensive   summary</b> —(Optional) Display the specified level of output.  <b>group <i>group</i></b> —(Optional) Display APS or MSP information for the specified group.  <b>interface <i>so-fpc/pic/port</i></b> —(Optional) Display APS information for the specified SONET/SDH interface.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show aps on page 585</a> <a href="#">show aps brief on page 585</a> <a href="#">show aps detail on page 585</a> <a href="#">show aps extensive on page 585</a>
<b>Output Fields</b>	<a href="#">Table 95 on page 583</a> lists the output fields for the <b>show aps</b> command. Output fields are listed in the approximate order in which they appear.



Table 95: show aps Output Fields

Field Name	Field Description	Level of Output
<b>Interface</b>	Name of the SONET/SDH interface.	All levels
<b>Group</b>	Group name.	All levels
<b>Circuit</b>	Circuit type: <b>Working</b> or <b>Protect</b> .	All levels
<b>Intf state</b>	<p>State of the circuit and interface in the format <i>circuit-state</i>, <i>interface-state</i>:</p> <p>For <i>circuit-state</i>:</p> <ul style="list-style-type: none"> <li>• <b>enabled</b></li> <li>• <b>disabled</b></li> <li>• <b>invalid</b></li> <li>• <b>unknown</b></li> </ul> <p>For <i>interface-state</i>:</p> <ul style="list-style-type: none"> <li>• <b>admin down</b></li> <li>• <b>degraded</b></li> <li>• <b>down</b></li> <li>• <b>invalid</b></li> <li>• <b>nonexistent</b></li> <li>• <b>unknown</b></li> <li>• <b>up</b></li> </ul>	All levels
<b>Neighbor</b>	Address and state of neighbor interface. If the working and protect interfaces are on the same router, the neighbor address is displayed as <b>0.0.0.0</b> .	<b>detail extensive</b>
<b>adj</b>	<p>State of the neighbor adjacency:</p> <ul style="list-style-type: none"> <li>• <b>Down</b></li> <li>• <b>Init</b></li> <li>• <b>Invalid</b></li> <li>• <b>Unknown</b></li> <li>• <b>Up</b></li> </ul>	<b>detail extensive</b>
<b>neighbor interface</b>	State of the neighbor interface: <b>enabled</b> or <b>disabled</b> .	<b>detail extensive</b>
<b>dead</b>	Number of seconds before the neighbor is declared dead	<b>detail extensive</b>
<b>Channel state</b>	Circuit that has been selected: <b>Working</b> or <b>Protect</b> . On SDH configurations using Multiplex Section Protection (MSP), the APS Annex B (G.841) Lockout status is also shown in <b>extensive</b> output.	<b>detail extensive</b>
<b>Local-mode</b>	Mode in which the local router is configured to interoperate with SONET line-terminating equipment (LTE): <b>unidirectional</b> or <b>bidirectional</b> . The parenthetical value represents the mode type in the K2 byte.	<b>extensive</b>

Table 95: show aps Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>neighbor-mode</b>	Mode in which the neighboring device is operating: <b>unidirectional</b> or <b>bidirectional</b> . The parenthetical value represents the mode type in the K2 byte.	<b>extensive</b>
<b>Protect circuit is on</b>	Interface name of the APS protect circuit, displayed when both the working circuit and protect circuit are on the same router.	<b>detail extensive</b>
<b>Working circuit is on</b>	Interface name of the APS working circuit, displayed when both the working circuit and protect circuit are on the same router.	<b>detail extensive</b>
<b>Req K1</b>	Value of the SONET/SDH K1 byte requested to be transmitted by this circuit.	<b>extensive</b>
<b>rcv K1</b>	Value of the SONET/SDH K1 byte received on this interface. (Valid only on the protect circuit.)	<b>extensive</b>
<b>xmit K1</b>	Value of the SONET/SDH K1 byte being transmitted on this interface. (Valid only on the protect circuit.)	<b>extensive</b>
<b>nbr K1</b>	Value of the SONET/SDH K1 byte requested to be transmitted by the neighbor.	<b>extensive</b>
<b>nbr paired req</b>	Nonzero if the neighbor is requesting a particular K1 value because of a change in the paired circuit.	<b>extensive</b>
<b>Revert time</b>	Configured time to wait after the working circuit has become functional before making the working circuit active again.	<b>extensive</b>
<b>neighbor revert time</b>	Configured time, on the neighbor interface, to wait after the working circuit has again become functional before making the working circuit active again.	<b>extensive</b>
<b>Hello due in</b>	Time until the next hello packet is sent.	<b>extensive</b>

## Sample Output

### show aps

```
user@host> show aps
Interface    Group          Circuit  Intf state
so-0/0/0     aviva-aps      Working  enabled, up
so-0/0/1     aviva-aps      Protect  disabled, up
```

### show aps brief

The output for the **show aps brief** command is identical to that for the **show aps** command. For sample output, see [show aps on page 585](#).

### show aps detail

```
user@host> show aps detail
Interface    Group          Circuit  Intf state
so-0/0/0     aviva-aps      Working  enabled, up
Neighbor 0.0.0.0, adj up, neighbor interface disabled, dead 2.987
so-0/0/1     aviva-aps      Protect  disabled, up
Neighbor 0.0.0.0, adj up, neighbor interface enabled, dead 2.147
```

### show aps extensive

The following sample shows output from a SONET configuration:

```
user@host> show aps extensive
Interface    Group          Circuit  Intf state
so-0/0/0     aviva-aps      Working  enabled, up
Neighbor 0.0.0.0, adj up, neighbor interface disabled, dead 2.511
Channel state Working
Protect circuit is on interface so-0/0/1
Local-mode bidirectional(5), neighbor-mode bidirectional(5)
Req K1 0x00, rcv K1 0x00, xmit K1 0x00, nbr K1 0x00, nbr paired req 0
Revert time 0, neighbor revert time 0
Hello due in 0.055
so-0/0/1     aviva-aps      Protect  disabled, up
Neighbor 0.0.0.0, adj up, neighbor interface enabled, dead 2.230
Channel state Working
Working circuit is on interface so-0/0/0
Local-mode bidirectional(5), neighbor-mode bidirectional(5)
Req K1 0x00, rcv K1 0x00, xmit K1 0x00, nbr K1 0x00, nbr paired req 0
Revert time 0, neighbor revert time 0
Hello due in 0.416
```

The following sample shows output from an SDH configuration:

```
user@host> show aps extensive
Interface    Group          Circuit  Intf state
cstm4-1/1/0  TO_MALIBU      Working  enabled, up
Neighbor 0.0.0.0, adj up, neighbor interface disabled, dead 2.833
Channel state Working, annex-b, lockout
Protect circuit is on interface cstm4-1/2/0
Local-mode bidirectional(5), neighbor-mode bidirectional(5)
Req K1 0x00, rcv K1 0x00, xmit K1 0x00, nbr K1 0x00
      , rcv K2 0x10, xmit K2 0x10, nbr paired req 0
Wait to restore time 30, neighbor wait to restore time 30
Hello due in 0.945
cstm4-1/2/0  TO_MALIBU      Protect  disabled, up
Neighbor 0.0.0.0, adj up, neighbor interface enabled, dead 2.955
Channel state Working, annex-b
Working circuit is on interface cstm4-1/1/0
Local-mode bidirectional(5), neighbor-mode bidirectional(5)
Req K1 0x00, rcv K1 0x00, xmit K1 0x00, nbr K1 0x00
```

```
      , rcv K2 0x10, xmit K2 0x10, nbr paired req 0  
Wait to restore time 30, neighbor wait to restore time 30  
Hello due in 0.735
```

## show interfaces (Aggregated SONET/SDH)

<b>Syntax</b>	<pre>show interfaces <i>asnumber</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified aggregated SONET/SDH interface.
<b>Options</b>	<p><b><i>asnumber</i></b>—Display standard information about the specified aggregated SONET/SDH interface.</p> <p><b><i>brief   detail   extensive   terse</i></b>—(Optional) Display brief interface information.</p> <p><b><i>descriptions</i></b>—(Optional) Display interface description strings.</p> <p><b><i>media</i></b>—(Optional) Display media-specific information about network interfaces.</p> <p><b><i>snmp-index snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b><i>statistics</i></b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Aggregated SONET) on page 592</a></p> <p><a href="#">show interfaces brief (Aggregated SONET) on page 592</a></p> <p><a href="#">show interfaces detail (Aggregated SONET) on page 592</a></p> <p><a href="#">show interfaces extensive (Aggregated SONET) on page 593</a></p>
<b>Output Fields</b>	Table 96 on page 587 lists the output fields for the <b>show interfaces</b> (aggregated SONET/SDH) command. Output fields are listed in the approximate order in which they appear.

Table 96: Aggregated SONET/SDH show interfaces Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “Common Output Fields Description” on page 141.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>

Table 96: Aggregated SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Minimum links needed</b>	Number of child links that must be operational for the aggregated interface to be operational.	<b>detail extensive none</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Keepalive settings</b>	(PPP and HDLC) Configured settings for keepalives. <ul style="list-style-type: none"> <li><b>interval seconds</b>—The time in seconds between successive keepalive requests. The range is 10 seconds through 32,767 seconds, with a default of 10 seconds.</li> <li><b>up-count number</b>—The number of keepalive packets a destination must receive to change a link's status from down to up. The range is 1 through 255, with a default of 1.</li> <li><b>down-count number</b>—The number of keepalive packets a destination must fail to receive before the network takes a link down. The range is 1 through 255, with a default of 3.</li> </ul>	All levels
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 96: Aggregated SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number of bytes and packets received and transmitted on the physical interface, and the traffic rate in bits per seconds (bps).</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface whose definitions are as follows:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeds the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels

Table 96: Aggregated SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Index</b>	Logical interface's index number (which reflects its initialization sequence).	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface's SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Bandwidth</b>	Interface bandwidth.	<b>detail extensive none</b>
<b>Statistics</b>	<p>Information about fragments and packets received and sent by the router. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router.</p> <p>Statistics include input and output counts for packets, packets per second (pps), bytes, and bytes per second (Bps) for the following entities:</p> <ul style="list-style-type: none"> <li>• <b>Bundle</b>—Information about bundles.</li> <li>• <b>Link</b>—Information about links used in the multilink operation.</li> </ul>	<b>detail extensive none</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the source and destination address are also displayed.	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the "Family Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the "Addresses Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>



Table 96: Aggregated SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive</b>

## Sample Output

### show interfaces (Aggregated SONET)

```

user@host> show interfaces as0
Physical interface: as0, Enabled, Physical link is Up
  Interface index: 149, SNMP ifIndex: 45
  Link-level type: PPP, MTU: 4474, Speed: 466560kbps, Minimum links needed: 1
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Last flapped   : Never
  Input rate     : 216 bps (1 pps)
  Output rate    : 48 bps (0 pps)

Logical interface as0.0 (Index 79) (SNMP ifIndex 55)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  Bandwidth: 311040kbps
  Statistics
  Packets      pps      Bytes      bps
  Bundle:
    Input :      1178      1      11772      176
    Output:         0      0         0         0
  Protocol inet, MTU: 4470
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.100.1.1, Local: 10.100.1.2

```

### show interfaces brief (Aggregated SONET)

```

user@host> show interfaces as0 brief
Physical interface: as0, Enabled, Physical link is Up
  Link-level type: PPP, MTU: 4474, Speed: 466560kbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3

Logical interface as0.0
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  inet 10.100.1.2 --> 10.100.1.1

```

### show interfaces detail (Aggregated SONET)

```

user@host> show interfaces as0 detail
Physical interface: as0, Enabled, Physical link is Up
  Interface index: 149, SNMP ifIndex: 45, Generation: 32
  Link-level type: PPP, MTU: 4474, Speed: 466560kbps, Minimum links needed: 1
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Last flapped   : Never
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :      15888      272 bps
    Output bytes :       6189       48 bps
    Input packets:       1547       2 pps
    Output packets:       393       0 pps
  Egress queues: 4 supported, 4 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets
    0 best-effort      0              0              0

```

1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	196806	196806	0

Logical interface as0.0 (Index 79) (SNMP ifIndex 55) (Generation 18)

Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP

Bandwidth: 311040kbps

Statistics Packets pps Bytes bps

Bundle:

Input : 1334 2 13332 232

Output: 0 0 0 0

Link:

so-0/0/0.0 <-- down

Input : 0 0 0 0

Output: 0 0 0 0

so-0/0/1.0

Input : 541 1 5406 120

Output: 0 0 0 0

so-0/0/2.0

Input : 793 1 7926 112

Output: 0 0 0 0

Protocol inet, MTU: 4470, Generation: 38, Route table: 0

Flags: None

Addresses, Flags: Is-Preferred Is-Primary

Destination: 10.100.1.1, Local: 10.100.1.2, Broadcast: Unspecified,

Generation: 40

### show interfaces extensive (Aggregated SONET)

userhost1> show interfaces as0 extensive

Physical interface: as0, Enabled, Physical link is Up

Interface index: 149, SNMP ifIndex: 45, Generation: 32

Link-level type: PPP, MTU: 4474, Speed: 466560kbps, Minimum links needed: 1

Device flags : Present Running

Interface flags: SNMP-Traps Internal: 0x4000

Link flags : Keepalives

Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3

Last flapped : Never

Statistics last cleared: Never

Traffic statistics:

Input bytes : 17562 136 bps

Output bytes : 6862 72 bps

Input packets: 1710 1 pps

Output packets: 436 0 pps

Input errors:

Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,

Policed discards: 0, Resource errors: 0

Output errors:

Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,

Resource errors: 0

Egress queues: 4 supported, 4 in use

Queue counters: Queued packets Transmitted packets Dropped packets

0 best-effort 0 0 0

1 expedited-fo 0 0 0

2 assured-forw 0 0 0

3 network-cont 196848 196848 0

```
Logical interface as0.0 (Index 79) (SNMP ifIndex 55) (Generation 18)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
Bandwidth: 311040kbps
Statistics          Packets          pps          Bytes          bps
Bundle:
  Input :           1475             1         14742          136
  Output:              0             0              0           0
Link:
  so-0/0/0.0 <-- down
    Input :              0             0              0           0
    Output:              0             0              0           0
  so-0/0/1.0
    Input :             598             0          5976           24
    Output:              0             0              0           0
  so-0/0/2.0
    Input :             877             1          8766          112
    Output:              0             0              0           0
Protocol inet, MTU: 4470, Generation: 38, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 10.100.1.1, Local: 10.100.1.2, Broadcast: Unspecified,
  Generation: 40
```

## show interfaces (SONET/SDH)

<b>Syntax</b>	<pre>show interfaces so-fpc/pic/port &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified SONET/SDH interface.
<b>Options</b>	<p><b>so-fpc/pic/port</b>—Display standard information about the specified SONET/SDH interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (SDH Mode, PPP) on page 609</a></p> <p><a href="#">show interfaces brief (SDH Mode, PPP) on page 609</a></p> <p><a href="#">show interfaces detail (SDH Mode, PPP) on page 609</a></p> <p><a href="#">show interfaces extensive (SDH Mode, PPP) on page 610</a></p> <p><a href="#">show interfaces brief (SONET Mode, Frame Relay) on page 612</a></p> <p><a href="#">show interfaces (SONET Mode, Frame Relay) on page 613</a></p> <p><a href="#">show interfaces detail (SONET Mode, Frame Relay) on page 613</a></p> <p><a href="#">show interfaces extensive (SONET Mode, Frame Relay) on page 615</a></p> <p><a href="#">show interfaces extensive (OC768-over-4xOC192 Mode) on page 618</a></p> <p><a href="#">show interfaces detail (IPv6 Tracking) on page 621</a></p> <p><a href="#">show interfaces (shared interface) on page 622</a></p>
<b>Output Fields</b>	Table 97 on page 595 lists the output fields for the <b>show interfaces</b> (SONET/SDH) command. Output fields are listed in the approximate order in which they appear.

Table 97: SONET/SDH show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	SONET/SDH reference clock source: <b>Internal</b> or <b>External</b> . Clocking is configured and displayed only for channel 0.	All levels
<b>Framing mode</b>	Framing mode: <b>SONET</b> or <b>SDH</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>FCS</b>	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16</b> bits.	All levels
<b>Payload scrambler</b>	Whether payload scrambling is enabled.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Shared-interface</b>	Indicates whether the routing domain is the owner or non-owner of the shared interface. If the routing domain is the Root System Domain (RSD), the value is <b>Owner</b> . If the routing domain is a Protected System Domain (PSD) under the RSD, the value is <b>Non-owner</b> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>ANSI or ITU LMI settings</b>	<p>(Frame Relay) Settings for Local Management Interface (LMI). The format is (ANSI or ITU) LMI settings: <i>value</i>, <i>value</i>... <i>xx</i> seconds, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li>• <b>n391dte</b>—DTE full status polling interval (1-255)</li> <li>• <b>n392dce</b>—DCE error threshold (1-10)</li> <li>• <b>n392dte</b>—DTE error threshold (1-10)</li> <li>• <b>n393dce</b>—DCE monitored event count (1-10)</li> <li>• <b>n393dte</b>—DTE monitored event count (1-10)</li> <li>• <b>t391dte</b>—DTE polling timer (5-30 seconds)</li> <li>• <b>t392dce</b>—DCE polling verification timer (5-30 seconds)</li> </ul>	All levels
<b>LMI</b>	Input: <i>value (hh:mm:ss ago)</i> , Output: <i>value (hh:mm:ss ago)</i>	<b>brief</b> none
<b>LMI statistics</b>	<p>(Frame Relay) LMI packet statistics:</p> <ul style="list-style-type: none"> <li>• <b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: <i>nn</i> (last seen <i>hh:mm:ss ago</i>)</b>.</li> <li>• <b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: <i>nn</i> (last sent <i>hh:mm:ss ago</i>)</b>.</li> </ul>	<b>detail</b> extensive
<b>DTE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the data terminal equipment (DTE) to the data circuit-terminating equipment (DCE):</p> <ul style="list-style-type: none"> <li>• <b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li>• <b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li>• <b>Enquiry responses received</b>—Number of enquiry responses received by the DTE from the DCE.</li> <li>• <b>Full enquiry responses received</b>—Number of full enquiry responses sent from the DTE to the DCE.</li> </ul>	<b>detail</b> extensive none
<b>DCE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the DCE to the DTE:</p> <ul style="list-style-type: none"> <li>• <b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li>• <b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li>• <b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li>• <b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	<b>detail</b> extensive none

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Common statistics</b>	(Frame Relay) Statistics about messages sent between the DTE and the DCE: <ul style="list-style-type: none"> <li>• <b>Unknown messages received</b>—Number of received packets that do not fall into any category.</li> <li>• <b>Asynchronous updates received</b>—Number of link status peer changes received.</li> <li>• <b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li>• <b>Keepalive responses timedout</b>—Number of keepalive responses that timed out when no LMI packet was reported for <b>n392dte</b> or <b>n393dce</b> intervals. (See <b>LMI settings</b>.)</li> </ul>	<b>detail extensive none</b>
<b>Nonmatching DCE-end DLCIs</b>	(Frame Relay. Displayed only from the DTE) Number of DLCIs configured from the DCE.	<b>detail extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Keepalive settings</b>	(PPP and HDLC) Configured settings for keepalives. <ul style="list-style-type: none"> <li>• <b>interval seconds</b>—The time in seconds between successive keepalive requests. The range is <b>10</b> seconds through <b>32,767</b> seconds, with a default of <b>10</b> seconds.</li> <li>• <b>down-count number</b>—The number of keepalive packets a destination must fail to receive before the network takes a link down. The range is <b>1</b> through <b>255</b>, with a default of <b>3</b>.</li> <li>• <b>up-count number</b>—The number of keepalive packets a destination must receive to change a link's status from down to up. The range is <b>1</b> through <b>255</b>, with a default of <b>1</b>.</li> </ul>	All levels
<b>Keepalive or Keepalive statistics</b>	(PPP and HDLC) Information about keepalive packets. <ul style="list-style-type: none"> <li>• <b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li>• <b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was received, in the format <b>hh:mm:ss</b>.</li> </ul> </li> <li>• <b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li>• <b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was sent, in the format <b>hh:mm:ss</b>.</li> </ul> </li> </ul>	All levels
<b>LCP state</b>	(PPP) Link Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—LCP is not configured on the interface.</li> <li>• <b>Opened</b>—LCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>



Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>NCP state</b>	(PPP) Network Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>CHAP state</b>	(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction. <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the <b>Success</b> state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Closed</b>—CHAP authentication is incomplete.</li> <li>• <b>Failure</b>—CHAP authentication failed.</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Success</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>CoS queues</b>	Number of CoS queues configured.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number of bytes and packets received and transmitted on the physical interface, and the traffic rate in bits per seconds (bps). <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Label-switched interface (LSI) traffic statistics</b>	<p>(Frame Relay) LSI traffic statistics:</p> <ul style="list-style-type: none"> <li><b>Input bytes</b>—Number of bytes and speed, in bits per second (bps), received on the interface.</li> <li><b>Output packets</b>—Number of packets and speed, in bps, transmitted on the interface.</li> </ul>	<b>extensive</b>
<b>Input errors</b>	<p>Input errors on the interface whose definitions are as follows:</p> <ul style="list-style-type: none"> <li><b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li><b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li><b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li><b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li><b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li><b>Bucket Drops</b>—Drops resulting from the traffic load exceeding the interface transmit/receive leaky bucket configuration. The default is <b>off</b>.</li> <li><b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li><b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li><b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li><b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li><b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li><b>HS link FIFO overflows</b>—Number of FIFO overflows on the high-speed links between the ASICs responsible for handling the router interfaces.</li> </ul>	<b>extensive</b>

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>HS link FIFO underflows</b>—Number of FIFO underflows on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeds the MTU of the interface.</li> </ul>	<b>extensive</b>
<b>IPv6 transit statistics</b>	<p>Number of transit bytes and packets received and transmitted on the physical interface if IPv6 statistics tracking is enabled.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>extensive</b>
<b>SONET alarms</b> <b>SONET defects</b>	(SONET) SONET media-specific alarms and defects that prevents the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router or light the red or yellow alarm LED on the craft interface. See these fields for possible alarms and defects: <b>SONET PHY</b> , <b>SONET section</b> , <b>SONET line</b> , and <b>SONET path</b> .	All levels
<b>Link</b>	(For 4-port OC192c PIC operating in OC768-over-4xOC192 mode) The link number. Errors and alarms are displayed for each link.	<b>extensive</b>

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SONET PHY</b>	<p>Counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>
<b>SONET section</b>	<p>Counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B1</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>LOL</b>—Loss of light</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>ES-S</b>—Errored seconds (section)</li> <li>• <b>SES-S</b>—Severely errored seconds (section)</li> <li>• <b>SEFS-S</b>—Severely errored framing seconds (section)</li> </ul>	<b>extensive</b>
<b>SONET line</b>	<p>Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>REI-L</b>—Remote error indication (near-end line)</li> <li>• <b>RDI-L</b>—Remote defect indication (near-end line)</li> <li>• <b>AIS-L</b>—Alarm indication signal (near-end line)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>ES-L</b>—Errored seconds (near-end line)</li> <li>• <b>SES-L</b>—Severely errored seconds (near-end line)</li> <li>• <b>UAS-L</b>—Unavailable seconds (near-end line)</li> <li>• <b>ES-LFE</b>—Errored seconds (far-end line)</li> <li>• <b>SES-LFE</b>—Severely errored seconds (far-end line)</li> <li>• <b>UAS-LFE</b>—Unavailable seconds (far-end line)</li> </ul>	<b>extensive</b>

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SONET path</b>	<p>Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B3</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>REI-P</b>—Remote error indication</li> <li>• <b>LOP-P</b>—Loss of pointer (path)</li> <li>• <b>AIS-P</b>—Path alarm indication signal</li> <li>• <b>RDI-P</b>—Path remote defect indication</li> <li>• <b>UNEQ-P</b>—Path unequipped</li> <li>• <b>PLM-P</b>—Path payload (signal) label mismatch</li> <li>• <b>ES-P</b>—Errored seconds (near-end STS path)</li> <li>• <b>SES-P</b>—Severely errored seconds (near-end STS path)</li> <li>• <b>UAS-P</b>—Unavailable seconds (near-end STS path)</li> <li>• <b>ES-PFE</b>—Errored seconds (far-end STS path)</li> <li>• <b>SES-PFE</b>—Severely errored seconds (far-end STS path)</li> <li>• <b>UAS-PFE</b>—Unavailable seconds (far-end STS path)</li> </ul>	<b>extensive</b>
<b>Received SONET overhead</b>  <b>Transmitted SONET overhead</b>	<p>Values of the received and transmitted SONET overhead:</p> <ul style="list-style-type: none"> <li>• <b>C2</b>—Signal label. Allocated to identify the construction and content of the STS-level SPE and for PDI-P.</li> <li>• <b>F1</b>—Section user channel byte. This byte is set aside for the purposes of users.</li> <li>• <b>K1 and K2</b>—These bytes are allocated for APS signaling for the protection of the multiplex section.</li> <li>• <b>J0</b>—Section trace. This byte is defined for STS-1 number 1 of an STS-<i>N</i> signal. Used to transmit a 1-byte fixed-length string or a 16-byte message so that a receiving terminal in a section can verify its continued connection to the intended transmitter.</li> <li>• <b>S1</b>—Synchronization status. The S1 byte is located in the first STS-1 of an STS-<i>N</i>.</li> <li>• <b>Z3 and Z4</b>—Allocated for future use.</li> </ul>	<b>extensive</b>
<b>SDH alarms</b>  <b>SDH defects</b>	<p>SDH media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router or light the red or yellow alarm LED on the craft interface. See these fields for possible alarms and defects: <b>SDH PHY</b>, <b>SDH regenerator section</b>, <b>SDH multiplex section</b>, and <b>SDH path</b>.</p>	All levels

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SDH PHY</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>
<b>SDH regenerator section</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>RS-BIP8</b>—24-bit BIP for multiplex section overhead (B2 bytes)</li> <li>• <b>OOF</b>—Out of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>RS-ES</b>—Errored seconds (near-end regenerator section)</li> <li>• <b>RS-SES</b>—Severely errored seconds (near-end regenerator section)</li> <li>• <b>RS-SEFS</b>—Severely errored framing seconds (regenerator section)</li> </ul>	<b>extensive</b>
<b>SDH multiplex section</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>MS-BIP24</b>—8-bit BIP for high-order path overhead (B3 byte)</li> <li>• <b>MS-FEBE</b>—Far-end block error (multiplex section)</li> <li>• <b>MS-FERF</b>—Far-end remote fail (multiplex section)</li> <li>• <b>MS-AIS</b>—Alarm indication signal (multiplex section)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>MS-ES</b>—Errored seconds (near-end multiplex section)</li> <li>• <b>MS-SES</b>—Severely errored seconds (near-end multiplex section)</li> <li>• <b>MS-UAS</b>—Unavailable seconds (near-end multiplex section)</li> <li>• <b>MS-ES-FE</b>—Errored seconds (far-end multiplex section)</li> <li>• <b>MS-SES-FE</b>—Severely errored seconds (far-end multiplex section)</li> <li>• <b>MS-UAS-FE</b>—Unavailable seconds (far-end multiplex section)</li> </ul>	<b>extensive</b>

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SDH path</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>HP-BIP8</b>—8-bit BIP for regenerator section overhead (B1 byte)</li> <li>• <b>HP-FEBE</b>—Far-end block error (high-order path)</li> <li>• <b>HP-LOP</b>—Loss of pointer (high-order path)</li> <li>• <b>HP-AIS</b>—High-order-path alarm indication signal</li> <li>• <b>HP-FERF</b>—Far-end remote fail (high-order path)</li> <li>• <b>HP-UNEQ</b>—Unequipped (high-order path)</li> <li>• <b>HP-PLM</b>—Payload label mismatch (high-order path)</li> <li>• <b>HP-ES</b>—Errored seconds (near-end high-order path)</li> <li>• <b>HP-SES</b>—Severely errored seconds (near-end high-order path)</li> <li>• <b>HP-UAS</b>—Unavailable seconds (near-end high-order path)</li> <li>• <b>HP-ES-FE</b>—Errored seconds (far-end high-order path)</li> <li>• <b>HP-SES-FE</b>—Severely errored seconds (far-end high-order path)</li> <li>• <b>HP-UAS-FE</b>—Unavailable seconds (far-end high-order path)</li> </ul>	<b>extensive</b>
<b>Received SDH overhead</b>  <b>Transmitted SDH overhead</b>	<p>Values of the received and transmitted SONET overhead:</p> <ul style="list-style-type: none"> <li>• <b>C2</b>—Signal label. Allocated to identify the construction and content of the STS-level SPE and for PDI-P.</li> <li>• <b>F1</b>—Section user channel byte. This byte is set aside for the purposes of users.</li> <li>• <b>K1</b> and <b>K2</b>—These bytes are allocated for APS signaling for the protection of the multiplex section.</li> <li>• <b>J0</b>—Section trace. This byte is defined for STS-1 number 1 of an STS-<i>N</i> signal. Used to transmit a 1-byte fixed-length string or a 16-byte message so that a receiving terminal in a section can verify its continued connection to the intended transmitter.</li> <li>• <b>S1</b>—Synchronization status. The S1 byte is located in the first STS-1 of an STS-<i>N</i>.</li> <li>• <b>Z3</b> and <b>Z4</b>—Allocated for future use.</li> </ul>	<b>extensive</b>
<b>Received path trace</b>  <b>Transmitted path trace</b>	<p>SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits.</p>	<b>extensive</b>

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>HDLC configuration</b>	Information about the HDLC configuration. <ul style="list-style-type: none"> <li>• <b>Policing bucket</b>—Configured state of the receiving policer.</li> <li>• <b>Shaping bucket</b>—Configured state of the transmitting shaper.</li> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> </ul>	<b>extensive</b>
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Packet Forwarding Engine configuration</b>	Information about the configuration of the Packet Forwarding Engine: <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>PPP parameters</b>	The PPP loopback clear timer value.	<b>extensive</b>



Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Shared interface</b>	Provides the following information: <ul style="list-style-type: none"> <li>• <b>shared with</b>—(RSD only) Indicates which PSD owns the logical shared interface. For example, <b>psd3</b>.</li> <li>• <b>peer interface</b>—(PSD only) Lists the logical tunnel interface that peers with the logical shared interface. For example, <b>ut-2/1/0.2</b>.</li> <li>• <b>tunnel token</b>—Specifies the receive (RX) and transmit (TX) tunnel tokens. For example, <b>Rx: 5.519, Tx: 13.514</b>.</li> </ul>	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Multilink bundle</b>	(If the logical interface is configured as part of a multilink bundle.) Interface name for the multilink bundle.	<b>detail extensive none</b>
<b>AS bundle</b>	(If the logical interface is configured as part of an aggregated SONET bundle.) AS bundle number.	<b>detail extensive</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>

Table 97: SONET/SDH show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the interface.	<b>detail extensive none</b>
<b>DLCI</b>	<p>(Frame Relay) DLCI number of the logical interface. The following DLCI information is displayed: <b>Flags</b>, <b>Total down time</b>, <b>Last down</b>, and <b>Traffic statistics</b>. <b>Flags</b> is one or more of the following:</p> <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when the link is active, but no information is received from the DCE.</li> <li>• <b>Unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the corresponding DLCI in the DCE is configured.</li> <li>• <b>Dce-configured</b>—Displayed when the command is issued from the DTE.</li> </ul>	<b>detail extensive</b>
<b>DLCI statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	<b>detail extensive none</b>

## Sample Output

### show interfaces (SDH Mode, PPP)

```
user@host> show interfaces so-0/0/0
Physical interface: so-0/0/0, Enabled, Physical link is Up
  Interface index: 149, SNMP ifIndex: 66
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SDH mode, Speed: OC3,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 30 (00:00:07 ago), Output: 29 (00:00:05 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
  Not-configured
  CHAP state: Closed
  CoS queues     : 4 supported, 4 maximum usable queues
  Last flapped   : 2006-03-24 13:20:56 PST (00:05:09 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  SDH alarms     : None
  SDH defects    : None

Logical interface so-0/0/0.0 (Index 66) (SNMP ifIndex 43)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  Protocol inet, MTU: 4470
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.0.12.0/30, Local: 10.0.12.1, Broadcast: 10.0.12.3
  Protocol iso, MTU: 4470
    Flags: Protocol-Down
  Protocol mpls, MTU: 4458, Maximum labels: 3
    Flags: Protocol-Down, Is-Primary
```

### show interfaces brief (SDH Mode, PPP)

```
user@host> show interfaces so-0/0/0 brief
Physical interface: so-0/0/0, Enabled, Physical link is Up
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SDH mode, Speed: OC3,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 25 (00:00:01 ago), Output: 24 (00:00:04 ago)
  SDH alarms     : None
  SDH defects    : None

Logical interface so-0/0/0.0
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
  inet 10.0.12.1/30
  iso
  mpls
```

### show interfaces detail (SDH Mode, PPP)

```
user@host> show interfaces so-0/0/0 detail
Physical interface: so-0/0/0, Enabled, Physical link is Up
  Interface index: 149, SNMP ifIndex: 66, Generation: 35
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SDH mode, Speed: OC3,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
```

```

Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags      : Keepalives
Hold-times      : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 33 (last seen 00:00:05 ago)
  Output: 32 (last sent 00:00:06 ago)
LCP state: Opened
NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
Not-configured
CHAP state: Closed
CoS queues : 4 supported, 4 maximum usable queues
Last flapped : 2006-03-24 13:20:56 PST (00:05:38 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :          862          0 bps
  Output bytes:         3592         64 bps
  Input packets:           70          0 pps
  Output packets:         330          0 pps
Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort              0              0              0
  1 expedited-fo             0              0              0
  2 assured-forw             0              0              0
  3 network-cont            329             329             0

SDH  alarms : None
SDH  defects : None

Logical interface so-0/0/0.0 (Index 66) (SNMP ifIndex 43) (Generation 19)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
Protocol inet, MTU: 4470, Generation: 48, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.12.0/30, Local: 10.0.12.1, Broadcast: 10.0.12.3,
    Generation: 48
Protocol iso, MTU: 4470, Generation: 49, Route table: 0
  Flags: Protocol-Down
Protocol mpls, MTU: 4458, Maximum labels: 3, Generation: 50, Route table: 0
  Flags: Protocol-Down, Is-Primary

```

### show interfaces extensive (SDH Mode, PPP)

```

user@host> show interfaces so-0/0/0 extensive
Physical interface: so-0/0/0, Enabled, Physical link is Up
Interface index: 149, SNMP ifIndex: 66, Generation: 35
Link-level type: PPP, MTU: 4474, Clocking: Internal, SDH mode, Speed: OC3,
Loopback: None, FCS: 16, Payload scrambler: Enabled
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags      : Keepalives
Hold-times      : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 36 (last seen 00:00:01 ago)
  Output: 35 (last sent 00:00:10 ago)
LCP state: Opened
NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
Not-configured

```

```

CHAP state: Closed
CoS queues      : 4 supported, 4 maximum usable queues
Last flapped   : 2006-03-24 13:20:56 PST (00:06:08 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :          922          0 bps
  Output bytes :        3850         64 bps
  Input packets:          75          0 pps
  Output packets:        356          0 pps
Label-switched interface (LSI) traffic statistics:
  Input bytes :          0          0 bps
  Input packets:          0          0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Bucket drops: 0, Policed discards: 218, L3 incompletes: 0,
  L2 channel errors: 0, L2 mismatch timeouts: 2, HS link CRC errors: 0,
  HS link FIFO overflows: 0
Output errors:
  Carrier transitions: 3, Errors: 0, Drops: 0, Aged packets: 0,
  HS link FIFO underflows: 0, MTU errors: 0
Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort              0              0              0
  1 expedited-fo             0              0              0
  2 assured-forw             0              0              0
  3 network-cont            354             354             0

SDH  alarms   : None
SDH  defects  : None
SDH PHY:
  Seconds      Count  State
  PLL Lock     0      0 OK
  PHY Light    2      1 OK
SDH regenerator section:
  RS-BIP8      0      0
  OOF          3      8 OK
  LOS          3      2 OK
  LOF          3      2 OK
  RS-ES        3
  RS-SES       3
  RS-SEFS      3
SDH multiplex section:
  MS-BIP24     0      0
  MS-FEBE      0      0
  MS-FERF      3      2 OK
  MS-AIS       2      1 OK
  BERR-SF      0      0 OK
  BERR-SD      0      0 OK
  MS-ES        3
  MS-SES       3
  MS-UAS       0
  MS-SES-FE    3
  MS-UAS-FE    0
SDH path:
  HP-BIP8      0      0
  HP-FEBE      0      0
  HP-LOP       1      1 OK
  HP-AIS       2      1 OK

```

```

HP-FERF                3                2 OK
HP-UNEQ                0                0 OK
HP-PLM                 1                1 OK
HP-ES                  3
HP-SES                 3
HP-UAS                 0
HP-ES-FE               3
HP-SES-FE              3
HP-UAS-FE              0
Received SDH overhead:
F1      : 0x00, J0      : 0x00, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0xcf, C2(cmp) : 0xcf, F2      : 0x00
Z3      : 0x00, Z4      : 0x00, S1(cmp) : 0x00
Transmitted SDH overhead:
F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0xcf, F2      : 0x00, Z3      : 0x00
Z4      : 0x00
Received path trace: R2 so-0/0/0
 52 32 20 73 6f 2d 30 2f 30 2f 30 00 00 00 00 00  R2 so-0/0/0.....
Transmitted path trace: R1 so-0/0/0
 52 31 20 73 6f 2d 30 2f 30 2f 30 00 00 00 00 00  R1 so-0/0/0.....
HDLC configuration:
  Policing bucket: Disabled
  Shaping bucket : Disabled
  Giant threshold: 4484, Runt threshold: 3
Packet Forwarding Engine configuration:
  Destination slot: 0, PLP byte: 1 (0x00)
CoS information:
  CoS transmit queue  Bandwidth      Buffer Priority  Limit
                      %             bps      %         usec
  0 best-effort       95 147744000 95         0         low  none
  3 network-control   5  7776000  5         0         low  none

Logical interface so-0/0/0.0 (Index 66) (SNMP ifIndex 43) (Generation 19)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
PPP parameters:
  PPP loopback clear timer: 3 sec
Protocol inet, MTU: 4470, Generation: 48, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.12.0/30, Local: 10.0.12.1, Broadcast: 10.0.12.3,
    Generation: 48
Protocol iso, MTU: 4470, Generation: 49, Route table: 0
  Flags: Protocol-Down
Protocol mpls, MTU: 4458, Maximum labels: 3, Generation: 50, Route table: 0
  Flags: Protocol-Down, Is-Primary
MS-ES-FE                3

```

### show interfaces brief (SONET Mode, Frame Relay)

```

user@host> show interfaces so-0/0/0 brief
Physical interface: so-0/0/0, Enabled, Physical link is Up
Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, FCS: 16, Payload scrambler: Enabled
Device flags      : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
Link flags       : Keepalives DTE
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI: Input: 29 (00:00:02 ago), Output: 28 (00:00:01 ago)
SONET alarms     : None
SONET defects    : None

Logical interface so-0/0/0.0

```

```

Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
inet 10.0.12.1      --> 10.0.12.2
iso
mpls
DLCI 16
  Flags: Down, DCE-Unconfigured
  Total down time: 00:04:12 sec, Last down: 00:04:12 ago

```

### show interfaces (SONET Mode, Frame Relay)

```

user@host> show interfaces so-0/0/0
Physical interface: so-0/0/0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 66
  Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, SONET mode,
  Speed: OC3, Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
  Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives DTE
  ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
  LMI: Input: 23 (00:00:05 ago), Output: 22 (00:00:03 ago)
  DTE statistics:
    Enquiries sent           : 19
    Full enquiries sent      : 3
    Enquiry responses received : 20
    Full enquiry responses received : 3
  DCE statistics:
    Enquiries received       : 0
    Full enquiries received   : 0
    Enquiry responses sent    : 0
    Full enquiry responses sent : 0
  Common statistics:
    Unknown messages received : 0
    Asynchronous updates received : 0
    Out-of-sequence packets received : 0
    Keepalive responses timedout : 1
  CoS queues   : 4 supported, 4 maximum usable queues
  Last flapped : 2006-03-06 11:53:20 PST (3d 03:09 ago)
  Input rate   : 0 bps (0 pps)
  Output rate  : 56 bps (0 pps)
  SONET alarms : None
  SONET defects : None

Logical interface so-0/0/0.0 (Index 79) (SNMP ifIndex 43)
  Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 4470
    Flags: None
    Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
      Destination: 10.0.12.2, Local: 10.0.12.1
  Protocol iso, MTU: 4470
    Flags: None
  Protocol mpls, MTU: 4450, Maximum labels: 3
  DLCI 16
    Flags: Down, DCE-Unconfigured
    Total down time: 00:03:11 sec, Last down: 00:03:11 ago
    Input packets : 0
    Output packets: 0
  DLCI statistics:
    Active DLCI :0 Inactive DLCI :1

```

```

user@host> show interfaces so-0/0/0 detail

```

**show interfaces detail**  
**(SONET Mode,**  
**Frame Relay)**

```
Physical interface: so-0/0/0, Enabled, Physical link is Up
Interface index: 128, SNMP ifIndex: 66, Generation: 11
Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, FCS: 16, Payload scrambler: Enabled
Device flags   : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives DTE
Hold-times    : Up 0 ms, Down 0 ms
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI statistics:
  Input : 33 (last seen 00:00:09 ago)
  Output: 32 (last sent 00:00:01 ago)
DTE statistics:
  Enquiries sent           : 27
  Full enquiries sent      : 5
  Enquiry responses received : 28
  Full enquiry responses received : 5
DCE statistics:
  Enquiries received       : 0
  Full enquiries received  : 0
  Enquiry responses sent   : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout : 1
CoS queues : 4 supported, 4 maximum usable queues
Last flapped : 2006-03-06 11:53:20 PST (3d 03:10 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes : 495368 0 bps
  Output bytes : 2765014 56 bps
  Input packets: 41165 0 pps
  Output packets: 133530 0 pps
Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets  Dropped packets

  0 best-effort      18              18              0

  1 expedited-fo      0              0              0

  2 assured-forw      0              0              0

  3 network-cont    133506         133506         0

SONET alarms : None
SONET defects : None
Logical interface so-0/0/0.0 (Index 79) (SNMP ifIndex 43) (Generation 28)
Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Transit statistics:
```



```

Input bytes :                0                0 bps
Output bytes :                0                0 bps
Input packets:               0                0 pps
Output packets:              0                0 pps
Protocol inet, MTU: 4470, Generation: 49, Route table: 0
  Flags: None
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 10.0.12.2, Local: 10.0.12.1, Broadcast: Unspecified,
    Generation: 61
Protocol iso, MTU: 4470, Generation: 50, Route table: 0
  Flags: None
Protocol mpls, MTU: 4450, Maximum labels: 3, Generation: 51, Route table: 0
DLCI 16
  Flags: Down, DCE-Unconfigured
  Total down time: 00:04:54 sec, Last down: 00:04:54 ago
  Traffic statistics:
    Input bytes :                0
    Output bytes :                0
    Input packets:               0
    Output packets:              0
  DLCI statistics:
    Active DLCI :0 Inactive DLCI :1

```

#### show interfaces extensive

```

user@host> show interfaces so-0/0/0 extensive
Physical interface: so-0/0/0, Enabled, Physical link is Up
Interface index: 128, SNMP ifIndex: 66, Generation: 11

```

**(SONET Mode,  
Frame Relay)**

```

Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, FCS: 16, Payload scrambler: Enabled
Device flags   : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives DTE
Hold-times    : Up 0 ms, Down 0 ms
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI statistics:
  Input : 39 (last seen 00:00:02 ago)
  Output: 36 (last sent 00:00:07 ago)
DTE statistics:
  Enquiries sent           : 30
  Full enquiries sent      : 6
  Enquiry responses received : 33
  Full enquiry responses received : 6
DCE statistics:
  Enquiries received       : 0
  Full enquiries received  : 0
  Enquiry responses sent   : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout : 1
CoS queues : 4 supported, 4 maximum usable queues
Last flapped : 2006-03-06 11:53:20 PST (3d 03:11 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes : 495452 56 bps
  Output bytes : 2765074 0 bps
  Input packets: 41171 0 pps
  Output packets: 133534 0 pps
Label-switched interface (LSI) traffic statistics:
  Input bytes : 0 0 bps
  Input packets: 0 0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Bucket drops: 0, Policed discards: 0, L3 incompletes: 0,
  L2 channel errors: 0, L2 mismatch timeouts: 0, HS link CRC errors: 0,
  HS link FIFO overflows: 0
Output errors:
  Carrier transitions: 3, Errors: 0, Drops: 0, Aged packets: 0,
  HS link FIFO underflows: 0, MTU errors: 0
Egress queues: 4 supported, 4 in use
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	18	18	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	133510	133510	0

```

SONET alarms : None
SONET defects : None
SONET PHY:
  Seconds      Count  State
  PLL Lock     0      0 OK
  PHY Light    60      1 OK
SONET section:

```

```

BIP-B1          0          0
SEF             108        158 OK
LOS             108        2  OK
LOF             108        2  OK
ES-S            108
SES-S            108
SEFS-S          108
SONET line:
BIP-B2          0          0
REI-L           0          0
RDI-L           1          1  OK
AIS-L           107        1  OK
BERR-SF         0          0  OK
BERR-SD         44         2  OK
ES-L            108
SES-L            108
UAS-L           97
ES-LFE          1
SES-LFE          1
UAS-LFE          0
SONET path:
BIP-B3          0          0
REI-P           0          0
LOP-P           1          1  OK
AIS-P           107        1  OK
RDI-P           1          1  OK
UNEQ-P          0          0  OK
PLM-P           1          1  OK
ES-P            108
SES-P            108
UAS-P           97
ES-PFE          1
SES-PFE          1
UAS-PFE          0
Received SONET overhead:
F1      : 0x00, J0      : 0x00, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0xcf, C2(cmp) : 0xcf, F2      : 0x00
Z3      : 0x00, Z4      : 0x00, S1(cmp) : 0x00
Transmitted SONET overhead:
F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0xcf, F2      : 0x00, Z3      : 0x00
Z4      : 0x00
Received path trace: R2 so-0/0/0
52 32 20 73 6f 2d 30 2f 30 2f 30 00 00 00 00 00  R2 so-0/0/0.....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 0d 0a .....
Transmitted path trace: R1 so-0/0/0
52 31 20 73 6f 2d 30 2f 30 2f 30 00 00 00 00 00  R1 so-0/0/0.....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
HDLC configuration:
  Policing bucket: Disabled
  Shaping bucket : Disabled
  Giant threshold: 4484, Runt threshold: 3
Packet Forwarding Engine configuration:
  Destination slot: 0, PLP byte: 1 (0x00)
CoS information:
  CoS transmit queue      Bandwidth      Buffer  Priority  Limit
                           %      bps      %      usec

```

```

0 best-effort      95      147744000  95          0      low  none
3 network-control  5        7776000   5          0      low  none

```

Logical interface so-0/0/0.0 (Index 79) (SNMP ifIndex 43) (Generation 28)

Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID

Traffic statistics:

```

Input bytes :          0
Output bytes :          0
Input packets:          0
Output packets:         0

```

Local statistics:

```

Input bytes :          0
Output bytes :          0
Input packets:          0
Output packets:         0

```

Transit statistics:

```

Input bytes :          0          0 bps
Output bytes :          0          0 bps
Input packets:          0          0 pps
Output packets:         0          0 pps

```

Protocol inet, MTU: 4470, Generation: 49, Route table: 0

Flags: None

Addresses, Flags: Dest-route-down Is-Preferred Is-Primary

Destination: 10.0.12.2, Local: 10.0.12.1, Broadcast: Unspecified,  
Generation: 61

Protocol iso, MTU: 4470, Generation: 50, Route table: 0

Flags: None

Protocol mpls, MTU: 4450, Maximum labels: 3, Generation: 51, Route table: 0

DLCI 16

Flags: Down, DCE-Unconfigured

Total down time: 00:05:42 sec, Last down: 00:05:42 ago

Traffic statistics:

```

Input bytes :          0
Output bytes :          0
Input packets:          0
Output packets:         0

```

DLCI statistics:

Active DLCI :0 Inactive DLCI :1

**show interfaces  
extensive**

user@host> show interfaces so-7/0/0 extensive

Physical interface: so-7/0/0, Enabled, Physical link is Up

Interface index: 163, SNMP ifIndex: 23, Generation: 186

## (OC768-over-4xOC192 Mode)

```

Link-level type: Cisco-HDLC, MTU: 4474, Clocking: Internal, SONET mode, Speed:
OC768,
Loopback: Local, FCS: 16, Payload scrambler: Enabled
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : No-Keepalives
Hold-times    : Up 0 ms, Down 0 ms
CoS queues    : 8 supported, 8 maximum usable queues
Last flapped   : 2006-01-13 10:43:39 PST (01:05:33 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :          76992          200 bps
  Output bytes  :          83707          216 bps
  Input packets :          1343           0 pps
  Output packets:          1343           0 pps
Input errors:
  Errors: 0, Drops: 3885, Framing errors: 68154624, Runts: 0, Giants: 0, Bucket
drops: 0,
  Policed discards: 0, L3 incompletes: 95040248, L2 channel errors: 0, L2
mismatch timeouts: 0,
  HS link CRC errors: 0, HS link FIFO overflows: 30742070
Output errors:
  Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0, HS link FIFO
underflows: 0,
  MTU errors: 0
Egress queues: 8 supported, 4 in use
Queue counters:
  Queued packets  Transmitted packets  Dropped packets

  0 best-effort           2              2              0
  1 expedited-fo          0              0              0
  2 assured-forw          0              0              0
  3 network-cont         1341           1341           0

SONET alarms   : None
SONET defects  : None
Link : 0
SONET alarms   : None
SONET defects  : None
SONET PHY:
  Seconds      Count  State
  PLL Lock     0       0 OK
  PHY Light    0       0 OK
SONET section:
  BIP-B1       0       0
  SEF          2       1 OK
  LOS          0       0 OK
  LOF          3       2 OK
  ES-S         2
  SES-S        2
  SEFS-S       2
SONET line:
  BIP-B2       0       0
  REI-L        0       0
  RDI-L        1       1 OK
  AIS-L        2       1 OK
  BERR-SF      0       0 OK
  BERR-SD      0       0 OK
  ES-L         3
  SES-L        3

```

```

UAS-L                0
ES-LFE               1
SES-LFE              1
UAS-LFE              0
SONET path:
  BIP-B3              0          0
  REI-P               0          0
  LOP-P               0          0 OK
  AIS-P               2          1 OK
  RDI-P               0          0 OK
  UNEQ-P              0          0 OK
  PLM-P               0          0 OK
  ES-P                3
  SES-P                3
  UAS-P                0
  ES-PFE              0
  SES-PFE              0
  UAS-PFE              0
Payload pointer:
  Current pointer      : 522
  Pointer increment count : 0
  Pointer decrement count : 0
  New pointer NDF count : 0
Received SONET overhead:
  F1 : 0x00, J0 : 0x01, K1 : 0x00, K2 : 0x00
  S1 : 0x00, C2 : 0xcf, C2(cmp) : 0xcf, F2 : 0x00
  Z3 : 0x00, Z4 : 0x00, S1(cmp) : 0x00
Transmitted SONET overhead:
  F1 : 0x00, J0 : 0x01, K1 : 0x00, K2 : 0x00
  S1 : 0x00, C2 : 0xcf, F2 : 0x00, Z3 : 0x00
  Z4 : 0x00
Received path trace: fold so-7/0/0
  66 6f 6c 64 20 73 6f 2d 37 2f 30 2f 30 00 00 00 fold so-7/0/0...
  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
  00 00 00 00 00 00 00 00 00 00 00 00 00 00 0d 0a .....
Transmitted path trace: fold so-7/0/0
  66 6f 6c 64 20 73 6f 2d 37 2f 30 2f 30 00 00 00 fold so-7/0/0...
  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
Link : 1
SONET alarms : None
SONET defects : None
SONET PHY:
  Seconds Count State
  PLL Lock 0 0 OK
  PHY Light 0 0 OK
SONET section:
  BIP-B1 0 0
  SEF 2 1 OK
  LOS 0 0 OK
  LOF 3 2 OK
  ES-S 2
  SES-S 2
  SEFS-S 2
SONET line:
  BIP-B2 0 0
  REI-L 0 0
  RDI-L 0 0 OK
  AIS-L 2 1 OK
  BERR-SF 0 0 OK

```

```

BERR-SD          0          0 OK
ES-L             3
SES-L            3
UAS-L            0
ES-LFE           0
SES-LFE           0
UAS-LFE           0
SONET path:
BIP-B3           0          0
REI-P            0          0
LOP-P            0          0 OK
AIS-P            2          1 OK
RDI-P            0          0 OK
UNEQ-P           0          0 OK
PLM-P            0          0 OK
ES-P             3
SES-P            3
UAS-P            0
ES-PFE           0
SES-PFE           0
UAS-PFE           0
Payload pointer:
Current pointer   : 522
Pointer increment count : 0
Pointer decrement count : 0
New pointer NDF count : 0
Received SONET overhead:
F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0xcf, C2(cmp) : 0xcf, F2      : 0x00
Z3      : 0x00, Z4      : 0x00, S1(cmp) : 0x00
Transmitted SONET overhead:
F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0xcf, F2      : 0x00, Z3      : 0x00
Z4      : 0x00
Received path trace: fold so-7/0/0
66 6f 6c 64 20 73 6f 2d 37 2f 30 2f 30 00 00 00   fold so-7/0/0...
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 0d 0a .....
Transmitted path trace: fold so-7/0/0
66 6f 6c 64 20 73 6f 2d 37 2f 30 2f 30 00 00 00   fold so-7/0/0...
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
...

```

### show interfaces detail (IPv6 Tracking)

```

user@host> show interfaces so-0/2/0 detail
Physical interface: so-0/2/0, Enabled, Physical link is Up
  Interface index: 130, SNMP ifIndex: 26, Generation: 131
  Link-level type: PPP, MTU: 4474, Clocking: Internal, SONET mode,
Speed: OC3,
  Loopback: None, FCS: 16, Payload scrambler: Enabled
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : Keepalives
  Hold-times    : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 7 (last seen 00:00:01 ago)
    Output: 6 (last sent 00:00:08 ago)
  LCP state: Opened

```

```

NCP state: inet: Not-configured, inet6: Opened, iso: Not- configured, mpls:
Not-configured
CHAP state: Closed
PAP state: Closed
CoS queues      : 4 supported, 4 maximum usable queues
Last flapped    : 2007-11-29 08:45:47 PST (1d 03:44 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :          7407782          40 bps
  Output bytes  :          7307322          48 bps
  Input packets :          107570           0 pps
  Output packets:          108893           0 pps
IPv6 transit statistics:
  Input bytes   :          57328
  Output bytes  :          57400
  Input packets :           1024
  Output packets:           1025
Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets  Dropped packets
0 best-effort        1191             1191                 0
1 expedited-fo       0                 0                     0
2 assured-forw       0                 0                     0
3 network-cont      107700            107700                 0
SONET alarms      : None
SONET defects     : None

Logical interface so-0/2/0.0 (Index 70) (SNMP ifIndex 47) (Generation 231)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: PPP
Protocol inet6, MTU: 4470, Generation: 433, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: abcd::a18:104/126, Local: abcd::a18:105,
  Broadcast: Unspecified, Generation: 683
Addresses, Flags: Is-Preferred
  Destination: fe80::/64, Local: fe80::2a0:a5ff:fe56:52a,
  Broadcast: Unspecified, Generation: 684

```

### show interfaces (shared interface)

```

user@rsd1> show interfaces so-7/2/0
Physical interface: so-7/2/0, Enabled, Physical link is Down
Interface index: 128, SNMP ifIndex: 109
Link-level type: Frame-Relay, MTU: 4474, Clocking: Internal, SONET mode,
Speed: OC192, Loopback: None, FCS: 16, Payload scrambler: Enabled
Device flags   : Present Running Down
Interface flags: Hardware-Down Point-To-Point SNMP-Traps Internal: 0x4000
Shared-interface : Owner
Link flags      : No-Keepalives DTE
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI: Input: 0 (never), Output: 0 (never)
DTE statistics:
  Enquiries sent           : 0
  Full enquiries sent      : 0
  Enquiry responses received : 0
  Full enquiry responses received : 0
DCE statistics:
  Enquiries received       : 0
  Full enquiries received  : 0
  Enquiry responses sent   : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0

```



```
Out-of-sequence packets received      : 0
Keepalive responses timedout           : 0
CoS queues      : 8 supported, 8 maximum usable queues
Last flapped    : 2008-08-11 10:51:51 PDT (1w1d 04:47 ago)
Input rate      : 0 bps (0 pps)
Output rate     : 0 bps (0 pps)
SONET alarms    : LOL, PLL
SONET defects   : LOL, PLL, LOF, SEF, AIS-L, AIS-P

Logical interface so-7/2/0.0 (Index 67) (SNMP ifIndex 117)
  Flags: Device-Down Point-To-Point SNMP-Traps 0x4000 Encapsulation: FR-NLPID
  Shared interface:
    Shared with: psd5
    Tunnel token: Rx: 2.517, Tx: 1.517
  Input packets : 0
  Output packets: 0
  DLCI 700
    Flags: Active
    Total down time: 00:01:09 sec, Last down: 284:58:21 ago
    Input packets : 0
    Output packets: 0
  DLCI statistics:
    Active DLCI  :1 Inactive DLCI  :0
```

## show interfaces diagnostics optics (SONET)


<b>Syntax</b>	<code>show interfaces diagnostics optics so-<i>fpc/pic/port</i></code>
<b>Release Information</b>	Command introduced in Junos OS Release 7.5.
<b>Description</b>	(M320, T320, T640, and T1600 routers only) For SONET/SDH interfaces that support optical diagnostics and monitoring, display transceiver diagnostics and data alarms.
<b>Options</b>	<code>so-<i>fpc/pic/port</i></code> —SONET/SDH interface name.
<b>Additional Information</b>	<p>The transceivers are polled in 1-second intervals for diagnostics data, alarms, and warnings and stores them into memory. The alarms will not cause the links to go down or the LEDs to change color or generate SNMP traps. Changes in alarm and warning status will generate system log messages.</p> <p>Thresholds that trigger a high alarm, low alarm, high warning, or low warning are set by the transceiver vendors. Generally, a high alarm or low alarm indicates that the optics module is not operating properly. This information can be used to diagnose why a PIC is not working.</p> <p>In the output fields, when an alarm is <b>On</b>, this indicates an error condition. Alarm <b>Off</b> indicates normal operation.</p> <div style="margin-top: 20px;">  <p><b>NOTE:</b> The <code>show interfaces diagnostics optics</code> command for optical interfaces does not report the decibel (dBm) value of the received signal if the received power is zero milliwatts (0.0000 mW).</p> </div>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces diagnostics optics (OC768 PIC) on page 632</a> <a href="#">show interfaces diagnostics optics (Multi-rate SONET/SDH PICs with SFP) on page 632</a> <a href="#">show interfaces diagnostics optics (OC192 PICs with XFP) on page 633</a>
<b>Output Fields</b>	Table 98 on page 624 lists the output fields for the <code>show interfaces diagnostics optics</code> command for OC768 PICs. Output fields are listed in the approximate order in which they appear.

Table 98: OC768 show interfaces diagnostics optics Output Fields

Field Name	Field Description
Physical interface	Name of the physical interface.
Laser bias current	Magnitude of the laser bias power setting current, in milliamperes. This indicator is a software equivalent to the LsBIASMON pin in hardware.

Table 98: OC768 show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser output power	Laser output power, in milliwatts (mW) and decibels, referenced to 1.0 mW (dBm). This is a software equivalent to the <b>LsPOWMON</b> pin in hardware.
Receiver signal average optical power	Average received optical power, in mW and dBm. This indicator is a software equivalent to the <b>RxPOWMON</b> pin in hardware. Average optical power is vendor-specific.
Laser end-of-life alarm	Laser end-of-life alarm: <b>On</b> or <b>Off</b> .
Laser wavelength alarm	Laser wavelength alarm: <b>On</b> or <b>Off</b> .
Laser bias current alarm	Laser bias current alarm: <b>On</b> or <b>Off</b> .
Laser temperature alarm	Laser temperature alarm: <b>On</b> or <b>Off</b> .
Laser power alarm	Laser power alarm: <b>On</b> or <b>Off</b> .
Modulator temperature alarm	Modulator temperature alarm: <b>On</b> or <b>Off</b> .  Transceivers from some vendors do not support this field.
Modulator bias alarm	Modulator bias alarm: <b>On</b> or <b>Off</b> .
Tx multiplexer FIFO error alarm	Transmit multiplexer first in, first out (FIFO) error alarm: <b>On</b> or <b>Off</b> .
Tx loss of PLL lock alarm	Transmit loss of phase-locked loop (PLL) lock alarm: <b>On</b> or <b>Off</b> .
Rx loss of average optical power alarm	Receive loss of average optical power alarm: <b>On</b> or <b>Off</b> .
Rx loss of AC power alarm	Receive loss of AC power alarm: <b>On</b> or <b>Off</b> .  Transceivers from some vendors do not support this field.
Rx loss of PLL lock alarm	Receive loss of phase-locked loop (PLL) lock alarm: <b>On</b> or <b>Off</b> .

Table 99 on page 625 lists the output fields for the **show interfaces diagnostics optics** command for multi-rate SONET/SDH PICs with SFP transceivers. Output fields are listed in the approximate order in which they appear.

Table 99: Multi-rate SONET/SDH PICs with SFP show interfaces diagnostics optics Output Fields

Field Name	Field Description
Physical interface	Name of the physical interface.

Table 99: Multi-rate SONET/SDH PICs with SFP show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
<b>Laser bias current</b>	Magnitude of the laser bias power setting current, in milliamperes. The laser bias provides direct modulation of laser diodes and modulates currents.
<b>Laser output power</b>	Laser output power, in milliwatts (mW) and decibels, referenced to 1.0 mW (dBm).
<b>Module temperature</b>	Temperature of the XFP optics module, in Celsius and Fahrenheit.
<b>Module voltage</b>	Internally measured module voltage.
<b>Receiver signal average optical power</b>	Average received optical power, in mW and dBm.
<b>Laser bias current high alarm</b>	Laser bias power setting high alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser bias current low alarm</b>	Laser bias power setting low alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser bias current high warning</b>	Laser bias power setting high warning. Displays <b>on</b> or <b>off</b> .
<b>Laser bias current low warning</b>	Laser bias power setting low warning. Displays <b>on</b> or <b>off</b> .
<b>Laser output power high alarm</b>	Laser output power high alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser output power low alarm</b>	Laser output power low alarm. Displays <b>on</b> or <b>off</b> .
<b>Laser output power high warning</b>	Laser output power high warning. Displays <b>on</b> or <b>off</b> .
<b>Laser output power low warning</b>	Laser output power low warning. Displays <b>on</b> or <b>off</b> .
<b>Module temperature high alarm</b>	Module temperature high alarm. Displays <b>on</b> or <b>off</b> .
<b>Module temperature low alarm</b>	Module temperature low alarm. Displays <b>on</b> or <b>off</b> .
<b>Module temperature high warning</b>	Module temperature high warning. Displays <b>on</b> or <b>off</b> .
<b>Module temperature low warning</b>	Module temperature low warning. Displays <b>on</b> or <b>off</b> .

Table 99: Multi-rate SONET/SDH PICs with SFP show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Module voltage high alarm	Module voltage high alarm. Displays <b>on</b> or <b>off</b> .
Module voltage low alarm	Module voltage low alarm. Displays <b>on</b> or <b>off</b> .
Module voltage high warning	Module voltage high warning . Displays <b>on</b> or <b>off</b> .
Module voltage low warning	Module voltage high warning . Displays <b>on</b> or <b>off</b> .
Laser rx power high alarm	Receive laser power high alarm. Displays <b>on</b> or <b>off</b> .
Laser rx power low alarm	Receive laser power low alarm. Displays <b>on</b> or <b>off</b> .
Laser rx power high warning	Receive laser power high warning. Displays <b>on</b> or <b>off</b> .
Laser rx power low warning	Receive laser power low warning. Displays <b>on</b> or <b>off</b> .
Laser bias current high alarm threshold	Vendor-specified threshold for the laser bias current high alarm: <b>80.000 mA</b> .
Laser bias current low alarm threshold	Vendor-specified threshold for the laser bias current low alarm: <b>2.000 mA</b> .
Laser bias current high warning threshold	Vendor-specified threshold for the laser bias current high warning: <b>70.000 mA</b> .
Laser bias current low warning threshold	Vendor-specified threshold for the laser bias current low warning: <b>4.000 mA</b> .
Laser output power high alarm threshold	Vendor-specified threshold for the laser output power high alarm: <b>1.2600 mW</b> or <b>1.00 dBm</b> .
Laser output power low alarm threshold	Vendor-specified threshold for the laser output power low alarm: <b>0.0440 mW</b> or <b>-13.57 dBm</b> .
Laser output power high warning threshold	Vendor-specified threshold for the laser output power high warning: <b>0.7950 mW</b> or <b>-1.00 dBm</b> .
Laser output power low warning threshold	Vendor-specified threshold for the laser output power low warning: <b>0.0700 mW</b> or <b>-11.55 dBm</b> .

**Table 99: Multi-rate SONET/SDH PICs with SFP show interfaces diagnostics optics Output Fields (*continued*)**

Field Name	Field Description
Module temperature high alarm threshold	Vendor-specified threshold for the module temperature high alarm: 110° C or 230° F.
Module temperature low alarm threshold	Vendor-specified threshold for the module temperature low alarm: -40° C or -40° F.
Module temperature high warning threshold	Vendor-specified threshold for the module temperature high warning: 93° C or 199° F.
Module temperature low warning threshold	Vendor-specified threshold for the module temperature low warning: -30° C or -22° F.
Module voltage high alarm threshold	Module voltage high alarm threshold: 3.900 v.
Module voltage low alarm threshold	Module voltage low alarm threshold: 2.700 v.
Module voltage high warning threshold	Module voltage high warning threshold: 3.700 v.
Module voltage low warning threshold	Module voltage high warning threshold: 2.900 v.
Laser rx power high alarm threshold	Vendor-specified threshold for the laser Rx power high alarm: 1.1749 mW or 0.70 dBm.
Laser rx power low alarm threshold	Vendor-specified threshold for the laser Rx power low alarm: 0.0039 mW or -24.09 dBm.
Laser rx power high warning threshold	Vendor-specified threshold for the laser Rx power high warning: 0.7942 mW or 1.00 dBm.
Laser rx power low warning threshold	Vendor-specified threshold for the laser Rx power low warning: 0.0100 mW or -20.00 dBm.

[Table 100 on page 628](#) lists the output fields for the **show interfaces diagnostics optics** command for OC192 PICs with XFP transceivers. Output fields are listed in the approximate order in which they appear.

**Table 100: OC192 PIC with XFP show interfaces diagnostics optics Output Fields**

Field Name	Field Description
Physical interface	Name of the physical interface.
Link	(For 4-port OC192c PIC operating in OC768-over-4xOC192 mode) The link number. Diagnostics and alarms are displayed for each link.

Table 100: OC192 PIC with XFP show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser bias current	Magnitude of the laser bias power setting current, in milliamperes. The laser bias provides direct modulation of laser diodes and modulates currents.
Laser output power	Laser output power, in milliwatts (mW) and decibels, referenced to 1.0 mW (dBm). This is a software equivalent to the <b>LsPOWMON</b> pin in hardware.
Module temperature	Temperature of the XFP optics module, in Celsius and Fahrenheit.
Laser rx power	Laser received optical power, in mW and dBm.
Laser bias current high alarm	Laser bias power setting high alarm. Displays <b>on</b> or <b>off</b> .
Laser bias current low alarm	Laser bias power setting low alarm. Displays <b>on</b> or <b>off</b> .
Laser bias current high warning	Laser bias power setting high warning. Displays <b>on</b> or <b>off</b> .
Laser bias current low warning	Laser bias power setting low warning. Displays <b>on</b> or <b>off</b> .
Laser output power high alarm	Laser output power high alarm. Displays <b>on</b> or <b>off</b> .
Laser output power low alarm	Laser output power low alarm. Displays <b>on</b> or <b>off</b> .
Laser output power high warning	Laser output power high warning. Displays <b>on</b> or <b>off</b> .
Laser output power low warning	Laser output power low warning. Displays <b>on</b> or <b>off</b> .
Module temperature high alarm	Module temperature high alarm. Displays <b>on</b> or <b>off</b> .
Module temperature low alarm	Module temperature low alarm. Displays <b>on</b> or <b>off</b> .
Module temperature high warning	Module temperature high warning. Displays <b>on</b> or <b>off</b> .
Module temperature low warning	Module temperature low warning. Displays <b>on</b> or <b>off</b> .
Laser rx power high alarm	Receive laser power high alarm. Displays <b>on</b> or <b>off</b> .

Table 100: OC192 PIC with XFP show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser rx power low alarm	Receive laser power low alarm. Displays <b>on</b> or <b>off</b> .
Laser rx power high warning	Receive laser power high warning. Displays <b>on</b> or <b>off</b> .
Laser rx power low warning	Receive laser power low warning. Displays <b>on</b> or <b>off</b> .
Module not ready alarm	Module not ready alarm. When <b>on</b> , indicates the module has an operational fault. Displays <b>on</b> or <b>off</b> .
Module power down alarm	Module power down alarm. When <b>on</b> , module is in a limited power mode, low for normal operation. Displays <b>on</b> or <b>off</b> .
Tx data not ready alarm	Any condition leading to invalid data on the transmit path. Displays <b>on</b> or <b>off</b> .
Tx not ready alarm	Any condition leading to invalid data on the transmit path. Displays <b>on</b> or <b>off</b> .
Tx laser fault alarm	Laser fault condition. Displays <b>on</b> or <b>off</b> .
Tx CDR loss of lock alarm	Transmit clock and data recovery (CDR) loss of lock. Loss of lock on the transmit side of the CDR. Displays <b>on</b> or <b>off</b> .
Rx not ready alarm	Any condition leading to invalid data on the receive path. Displays <b>on</b> or <b>off</b> .
Rx loss of signal alarm	Receive Loss of Signal alarm. When <b>on</b> , indicates insufficient optical input power to the module. Displays <b>on</b> or <b>off</b> .
Rx CDR loss of lock alarm	Receive CDR loss of lock. Loss of lock on the receive side of the CDR. Displays <b>on</b> or <b>off</b> .
Laser bias current high alarm threshold	Vendor-specified threshold for the laser bias current high alarm: <b>130.000 mA</b> .
Laser bias current low alarm threshold	Vendor-specified threshold for the laser bias current low alarm: <b>10.000 mA</b> .
Laser bias current high warning threshold	Vendor-specified threshold for the laser bias current high warning: <b>120.000 mA</b> .
Laser bias current low warning threshold	Vendor-specified threshold for the laser bias current low warning: <b>12.000 mA</b> .
Laser output power high alarm threshold	Vendor-specified threshold for the laser output power high alarm: <b>0.8910 mW</b> or <b>-0.50 dBm</b> .
Laser output power low alarm threshold	Vendor-specified threshold for the laser output power low alarm: <b>0.2230 mW</b> or <b>-6.52 dBm</b> .



Table 100: OC192 PIC with XFP show interfaces diagnostics optics Output Fields (*continued*)

Field Name	Field Description
Laser output power high warning threshold	Vendor-specified threshold for the laser output power high warning: 0.7940 mW or -100 dBm.
Laser output power low warning threshold	Vendor-specified threshold for the laser output power low warning: 0.2510 mW or -600dBm.
Module temperature high alarm threshold	Vendor-specified threshold for the module temperature high alarm: 90 °C or 194 °F.
Module temperature low alarm threshold	Vendor-specified threshold for the module temperature low alarm: -5 °C or 23 °F.
Module temperature high warning threshold	Vendor-specified threshold for the module temperature high warning: 85 °C or 185 °F.
Module temperature low warning threshold	Vendor-specified threshold for the module temperature low warning: 0 °C or 32 °F.
Laser rx power high alarm threshold	Vendor-specified threshold for the laser Rx power high alarm: 1.2589 mW or 1.00 dBm.
Laser rx power low alarm threshold	Vendor-specified threshold for the laser Rx power low alarm: 0.0323 mW or -14.91 dBm.
Laser rx power high warning threshold	Vendor-specified threshold for the laser Rx power high warning: 1.1220 mW or 0.50 dBm.
Laser rx power low warning threshold	Vendor-specified threshold for the laser Rx power low warning: 0.0363 mW or -14.40 dBm.

## Sample Output

**show interfaces  
diagnostics optics  
(OC768 PIC)**

```
user@host> show interfaces diagnostics optics so-4/0/0
Physical interface: so-4/0/0
  Laser bias current           : 79.938 mA
  Laser output power           : 1.592 mW / 2.02 dBm
  Receiver signal average optical power : 1.3854 mW / 1.42 dBm
  Laser end-of-life alarm      : Off
  Laser wavelength alarm       : Off
  Laser bias current alarm     : Off
  Laser temperature alarm      : Off
  Laser power alarm            : Off
  Modulator temperature alarm  : Off
  Modulator bias alarm         : Off
  Tx multiplexer FIFO error alarm : Off
  Tx loss of PLL lock alarm    : Off
  Rx loss of average optical power alarm: Off
  Rx loss of AC power alarm    : Off
  Rx loss of PLL lock alarm    : Off
```

**show interfaces  
diagnostics optics  
(Multi-rate)**

```
user@host> show interfaces diagnostics optics so-1/0/0
Physical interface: so-1/0/0
  Laser bias current           : 24.008 mA
  Laser output power           : 0.2620 mW / -5.82 dBm
```

## SONET/SDH PICs with SFP)

```

Module temperature           : 62 degrees C / 144 degrees F
Module voltage               : 3.3280 V
Receiver signal average optical power : 0.2685 mW / -5.71 dBm
Laser bias current high alarm : Off
Laser bias current low alarm  : Off
Laser bias current high warning : Off
Laser bias current low warning : Off
Laser output power high alarm : Off
Laser output power low alarm  : Off
Laser output power high warning : Off
Laser output power low warning : Off
Module temperature high alarm : Off
Module temperature low alarm  : Off
Module temperature high warning : Off
Module temperature low warning : Off
Module voltage high alarm     : Off
Module voltage low alarm      : Off
Module voltage high warning   : Off
Module voltage low warning    : Off
Laser rx power high alarm     : Off
Laser rx power low alarm      : Off
Laser rx power high warning   : Off
Laser rx power low warning    : Off
Laser bias current high alarm threshold : 80.000 mA
Laser bias current low alarm threshold  : 2.000 mA
Laser bias current high warning threshold : 70.000 mA
Laser bias current low warning threshold : 4.000 mA
Laser output power high alarm threshold : 1.2600 mW / 1.00 dBm
Laser output power low alarm threshold  : 0.0440 mW / -13.57 dBm
Laser output power high warning threshold : 0.7950 mW / -1.00 dBm
Laser output power low warning threshold : 0.0700 mW / -11.55 dBm
Module temperature high alarm threshold : 110 degrees C / 230 degrees F
Module temperature low alarm threshold  : -40 degrees C / -40 degrees F
Module temperature high warning threshold : 93 degrees C / 199 degrees F
Module temperature low warning threshold : -30 degrees C / -22 degrees F
Module voltage high alarm threshold     : 3.900 V
Module voltage low alarm threshold      : 2.700 V
Module voltage high warning threshold   : 3.700 V
Module voltage low warning threshold    : 2.900 V
Laser rx power high alarm threshold     : 1.1749 mW / 0.70 dBm
Laser rx power low alarm threshold      : 0.0039 mW / -24.09 dBm
Laser rx power high warning threshold   : 0.7942 mW / -1.00 dBm
Laser rx power low warning threshold    : 0.0100 mW / -20.00 dBm

```

show interfaces  
diagnostics optics  
(OC192 PICs with XFP)

```
user@host> show interfaces diagnostics optics so-7/0/0
```

```
Physical interface: so-7/0/0
```

```

Link : 0
Laser bias current           : 50.776 mA
Laser output power           : 0.4030 mW / -3.95 dBm
Laser temperature            : 29.0 degrees C / 84.2 degrees F
Laser rx power               : 0.4671 mW / -3.31 dBm
Laser bias current high alarm : Off
Laser bias current low alarm  : Off
Laser bias current high warning : Off
Laser bias current low warning : Off
Laser output power high alarm : Off
Laser output power low alarm  : Off
Laser output power high warning : Off
Laser output power low warning : Off
Laser temperature high alarm  : Off
Laser temperature low alarm   : Off

```

```
Laser temperature high warning      : Off
Laser temperature low warning       : Off
Laser rx power high alarm           : Off
Laser rx power low alarm            : Off
Laser rx power high warning         : Off
Laser rx power low warning          : Off
Module not ready alarm              : Off
Module power down alarm             : Off
Tx data not ready alarm             : Off
Tx not ready alarm                  : Off
Tx laser fault alarm                : Off
Tx CDR loss of lock alarm           : Off
Rx not ready alarm                  : Off
Rx loss of signal alarm             : Off
Rx CDR loss of lock alarm           : Off
Laser bias current high alarm threshold : 130.000 mA
Laser bias current low alarm threshold : 10.000 mA
Laser bias current high warning threshold : 120.000 mA
Laser bias current low warning threshold : 12.000 mA
Laser output power high alarm threshold : 0.8910 mW / -0.50 dBm
Laser output power low alarm threshold : 0.2230 mW / -6.52 dBm
Laser output power high warning threshold : 0.7940 mW / -1.00 dBm
Laser output power low warning threshold : 0.2510 mW / -6.00 dBm
Laser temperature high alarm threshold : 90.0 degrees C / 194.0 degrees F
Laser temperature low alarm threshold : -5.0 degrees C / 23.0 degrees F
Laser temperature high warning threshold : 85.0 degrees C / 185.0 degrees F
Laser temperature low warning threshold : 0.0 degrees C / 32.0 degrees F
Laser rx power high alarm threshold : 1.2589 mW / 1.00 dBm
Laser rx power low alarm threshold : 0.0323 mW / -14.91 dBm
Laser rx power high warning threshold : 1.1220 mW / 0.50 dBm
Laser rx power low warning threshold : 0.0363 mW / -14.40 dBm
...
```

## PART 8

# ATM Interfaces

- [ATM Interface Operational Mode Commands on page 637](#)
- [ILMI Interface Operational Mode Commands on page 691](#)



# ATM Interface Operational Mode Commands

Table 101 on page 637 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot Asynchronous Transfer Mode (ATM) interfaces on M Series and T Series routers, and ATM-over-asymmetrical digital subscriber line (ADSL) and ATM-over-symmetric high-speed digital subscriber line (SHDSL) interfaces on the J Series routers. An ATM-over-ADSL interface and an ATM-over-SHDSL interface is configured over an underlying ATM interface.

**Table 101: ATM Interface Operational Mode Commands**

Task	Command
Display status information about ATM interfaces.	<a href="#">show interfaces (ATM)</a>
Display status information about ATM-over-ADSL interfaces.	<a href="#">show interfaces (ATM-over-ADSL)</a>
Display status information about ATM-over-SHDSL interfaces.	<a href="#">show interfaces (ATM-over-SHDSL)</a>

ATM-over-ADSL interfaces are used to transport Point-to-Point Protocol over Ethernet (PPPoE) frames or Point-to-Point Protocol over ATM (PPPoA) frames over an ADSL loop and a digital subscriber line access multiplexer (DSLAM). Both PPPoE and PPPoA connect multiple hosts on an Ethernet LAN to a remote site through the J Series Services Router. The hosts share a common digital subscriber line (DSL), a cable modem, or a wireless connection to the Internet.

ATM-over-SHDSL interfaces are used to transport network traffic through a point-to-point connection to a DSL access multiplexer (DSLAM).



**NOTE:** For information about monitoring and troubleshooting PPPoE interfaces (`pp0`), which are used in conjunction with ATM-over-ADSL interfaces, see *PPPoE Interface Operational Mode Commands*. For more information about monitoring and troubleshooting ATM interfaces, see “Investigate ATM Interfaces” in the *Junos Interfaces Network Operations Guide*.

## show interfaces (ATM)

<b>Syntax</b>	<pre>show interfaces at-<i>fpc/pic/port</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified ATM interface.
<b>Options</b>	<p><b>at-<i>fpc/pic/port</i></b>—Display standard information about the specified ATM interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display the SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (ATM, IMA Group) on page 654</a></p> <p><a href="#">show interfaces extensive (ATM IMA Group) on page 654</a></p> <p><a href="#">show interfaces (ATM1, SONET Mode) on page 655</a></p> <p><a href="#">show interfaces brief (ATM1, SONET Mode) on page 656</a></p> <p><a href="#">show interfaces detail (ATM1, SONET Mode) on page 656</a></p> <p><a href="#">show interfaces extensive (ATM1, SONET Mode) on page 657</a></p> <p><a href="#">show interfaces (ATM2, SDH Mode) on page 659</a></p> <p><a href="#">show interfaces brief (ATM2, SDH Mode) on page 660</a></p> <p><a href="#">show interfaces detail (ATM2, SDH Mode) on page 661</a></p> <p><a href="#">show interfaces extensive (ATM2, SDH Mode) on page 662</a></p> <p><a href="#">show interfaces (ATM2, SONET Mode) on page 665</a></p> <p><a href="#">show interfaces brief (ATM2, SONET Mode) on page 666</a></p> <p><a href="#">show interfaces detail (ATM2, SONET Mode) on page 667</a></p> <p><a href="#">show interfaces extensive (ATM2, SONET Mode) on page 669</a></p>
<b>Output Fields</b>	<p><a href="#">Table 102 on page 638</a> lists the output fields for the <b>show interfaces (ATM)</b> command. Output fields are listed in the approximate order in which they appear.</p>

Table 102: ATM show interfaces Output Fields

Field Name	Field Description	Level of Output
Physical Interface		



Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Description</b>	Configured interface description.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface: <ul style="list-style-type: none"> <li>• <b>ATM-CCC-CELL-RELAY</b>—ATM cell relay for CCC.</li> <li>• <b>ATM-CCC-VC-MUX</b>—ATM virtual circuit (VC) for CCC.</li> <li>• <b>ATM-CISCO-NLPID</b>—Cisco-compatible ATM NLPID encapsulation.</li> <li>• <b>ATM-MIPP-LLC</b>—ATM MLPPP over ATM Adaptation Layer 5 (AAL5)/logical link control (LLC).</li> <li>• <b>ATM-NLPID</b>—ATM NLPID encapsulation.</li> <li>• <b>ATM-PPP-LLC</b>—ATM PPP over AAL5/LLC.</li> <li>• <b>ATM-PPP-VC-MUX</b>—ATM PPP over raw AAL5.</li> <li>• <b>ATM-PVC</b>—ATM permanent virtual circuits.</li> <li>• <b>ATM-SNAP</b>—ATM LLC/SNAP encapsulation.</li> <li>• <b>ATM-TCC-SNAP</b>—ATM LLC/SNAP for translational cross-connection.</li> <li>• <b>ATM-TCC-VC-MUX</b>—ATM VC for translational cross-connection.</li> <li>• <b>ATM-VC-MUX</b>—ATM VC multiplexing.</li> <li>• <b>ETHER-OVER-ATM-LLC</b>—Ethernet over ATM (LLC/SNAP) encapsulation.</li> <li>• <b>ETHER-VPLS-OVER-ATM-LLC</b>—Ethernet VPLS over ATM (bridging) encapsulation.</li> </ul>	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source: <b>Internal</b> or <b>External</b> .	All levels
<b>framing Mode</b>	Framing mode: <b>SONET</b> or <b>SDH</b> .	All levels
<b>Speed</b>	Speed at which the interface is running as represented by the interface type (for example, <b>OC3</b> , <b>ADSL2+</b> , and <b>SHDSL(2-wire)</b> ).	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>Payload scrambler</b>	Whether payload scrambling is enabled.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>CoS queues</b>	Number of CoS queues configured.	<b>detail extensive none</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Ethernet MAC address for this interface for Ethernet over ATM encapsulation.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Statistics for traffic on the interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	Input errors on the interface whose definitions are as follows: <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and frame check sequence (FCS) errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's random early detection (RED) mechanism.</li> <li>• <b>Invalid VCs</b>—Number of cells that arrived for a nonexistent VC.</li> <li>• <b>Framing errors</b>—Sum of AAL5 packets that have FCS errors, reassembly timeout errors, and length errors.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If it increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained so long in shared packet SDRAM that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul> <p><b>NOTE:</b> Physical interface queue counters of ATM2 PICs displayed by the <b>show interfaces at-fpc/pic/port detail</b> command show the packet forwarding stream statistics associated with the ATM2 ports. Since multiple ports of the ATM2 PICs (except for the ATM2 dual-port OC12) share one packet forwarding stream, the physical interface queue counters reflect the aggregate of ATM2 port statistics.</p>	<b>detail extensive</b>
<b>SONET alarms</b> <b>SONET defects</b>	<p>SONET media-specific defects that prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router or light the red or yellow alarm LED on the craft interface. See these fields for possible alarms and defects: <b>SONET PHY</b>, <b>SONET section</b>, <b>SONET line</b>, and <b>SONET path</b>.</p>	<b>detail extensive none</b>

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SONET PHY</b>	<p>Counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>
<b>SONET section</b>	<p>Counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B1</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>LOL</b>—Loss of light</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>ES-S</b>—Errored seconds (section)</li> <li>• <b>SES-S</b>—Severely errored seconds (section)</li> <li>• <b>SEFS-S</b>—Severely errored framing seconds (section)</li> </ul>	<b>extensive</b>
<b>SONET line</b>	<p>Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>REI-L</b>—Remote error indication (near-end line)</li> <li>• <b>RDI-L</b>—Remote defect indication (near-end line)</li> <li>• <b>AIS-L</b>—Alarm indication signal (near-end line)</li> <li>• <b>BERR-SF</b>—Bit error rate fault signal failure</li> <li>• <b>BERR-SD</b>—Bit error rate defect signal degradation</li> <li>• <b>ES-L</b>—Errored seconds (near-end line)</li> <li>• <b>SES-L</b>—Severely errored seconds (near-end line)</li> <li>• <b>UAS-L</b>—Unavailable seconds (near-end line)</li> <li>• <b>ES-LFE</b>—Errored seconds (far-end line)</li> <li>• <b>SES-LFE</b>—Severely errored seconds (far-end line)</li> <li>• <b>UAS-LFE</b>—Unavailable seconds (far-end line)</li> </ul>	<b>extensive</b>

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SONET path</b>	<p>Active alarms and defects, plus counts of specific SONET errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B3</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>REI-P</b>—Remote error indication</li> <li>• <b>LOP-P</b>—Loss of pointer (path)</li> <li>• <b>AIS-P</b>—Path alarm indication signal</li> <li>• <b>RDI-P</b>—Path remote defect indication</li> <li>• <b>UNEQ-P</b>—Path unequipped</li> <li>• <b>PLM-P</b>—Path payload (signal) label mismatch</li> <li>• <b>ES-P</b>—Errored seconds (near-end STS path)</li> <li>• <b>SES-P</b>—Severely errored seconds (near-end STS path)</li> <li>• <b>UAS-P</b>—Unavailable seconds (near-end STS path)</li> <li>• <b>ES-PFE</b>—Errored seconds (far-end STS path)</li> <li>• <b>SES-PFE</b>—Severely errored seconds (far-end STS path)</li> <li>• <b>UAS-PFE</b>—Unavailable seconds (far-end STS path)</li> </ul>	<b>extensive</b>
<b>Received SONET overhead</b>  <b>Transmitted SONET overhead</b>	<p>Values of the received and transmitted SONET overhead:</p> <ul style="list-style-type: none"> <li>• <b>C2</b>—Signal label. Allocated to identify the construction and content of the STS-level SPE and for PDI-P.</li> <li>• <b>F1</b>—Section user channel byte. This byte is set aside for the purposes of users.</li> <li>• <b>K1 and K2</b>—These bytes are allocated for APS signaling for the protection of the multiplex section.</li> <li>• <b>J0</b>—Section trace. This byte is defined for STS-1 number 1 of an STS-<i>N</i> signal. Used to transmit a 1-byte fixed-length string or a 16-byte message so that a receiving terminal in a section can verify its continued connection to the intended transmitter.</li> <li>• <b>S1</b>—Synchronization status. The S1 byte is located in the first STS-1 of an STS-<i>N</i>.</li> <li>• <b>Z3 and Z4</b>—Allocated for future use.</li> </ul>	<b>extensive</b>
<b>SDH alarms</b>  <b>SDH defects</b>	<p>SDH media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router or light the red or yellow alarm LED on the craft interface. See these fields for possible alarms and defects: <b>SDH PHY</b>, <b>SDH regenerator section</b>, <b>SDH multiplex section</b>, and <b>SDH path</b>.</p>	All levels

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SDH PHY</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>
<b>SDH regenerator section</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>RS-BIP8</b>—24-bit BIP for multiplex section overhead (B2 bytes)</li> <li>• <b>OOF</b>—Out of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>RS-ES</b>—Errored seconds (near-end regenerator section)</li> <li>• <b>RS-SES</b>—Severely errored seconds (near-end regenerator section)</li> <li>• <b>RS-SEFS</b>—Severely errored framing seconds (regenerator section)</li> </ul>	<b>extensive</b>
<b>SDH multiplex section</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>MS-BIP24</b>—8-bit BIP for high-order path overhead (B3 byte)</li> <li>• <b>MS-FEBE</b>—Far-end block error (multiplex section)</li> <li>• <b>MS-FERF</b>—Far-end remote fail (multiplex section)</li> <li>• <b>MS-AIS</b>—Alarm indication signal (multiplex section)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>MS-ES</b>—Errored seconds (near-end multiplex section)</li> <li>• <b>MS-SES</b>—Severely errored seconds (near-end multiplex section)</li> <li>• <b>MS-UAS</b>—Unavailable seconds (near-end multiplex section)</li> <li>• <b>MS-ES-FE</b>—Errored seconds (far-end multiplex section)</li> <li>• <b>MS-SES-FE</b>—Severely errored seconds (far-end multiplex section)</li> <li>• <b>MS-UAS-FE</b>—Unavailable seconds (far-end multiplex section)</li> </ul>	<b>extensive</b>

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SDH path</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>HP-BIP8</b>—8-bit BIP for regenerator section overhead (B1 byte)</li> <li>• <b>HP-FEBE</b>—Far-end block error (high-order path)</li> <li>• <b>HP-LOP</b>—Loss of pointer (high-order path)</li> <li>• <b>HP-AIS</b>—High-order-path alarm indication signal</li> <li>• <b>HP-FERF</b>—Far-end remote fail (high-order path)</li> <li>• <b>HP-UNEQ</b>—Unequipped (high-order path)</li> <li>• <b>HP-PLM</b>—Payload label mismatch (high-order path)</li> <li>• <b>HP-ES</b>—Errored seconds (near-end high-order path)</li> <li>• <b>HP-SES</b>—Severely errored seconds (near-end high-order path)</li> <li>• <b>HP-UAS</b>—Unavailable seconds (near-end high-order path)</li> <li>• <b>HP-ES-FE</b>—Errored seconds (far-end high-order path)</li> <li>• <b>HP-SES-FE</b>—Severely errored seconds (far-end high-order path)</li> <li>• <b>HP-UAS-FE</b>—Unavailable seconds (far-end high-order path)</li> </ul>	<b>extensive</b>
<b>Received SDH overhead</b>  <b>Transmitted SDH overhead</b>	<p>Values of the received and transmitted SONET overhead:</p> <ul style="list-style-type: none"> <li>• <b>C2</b>—Signal label. This byte is allocated to identify the construction and content of the STS-level SPE and for PDI-P.</li> <li>• <b>F1</b>—Section user channel byte. This byte is set aside for the purposes of users.</li> <li>• <b>K1</b> and <b>K2</b>—These bytes are allocated for APS signaling for the protection of the multiplex section.</li> <li>• <b>J0</b>—Section trace. This byte is defined for STS-1 number 1 of an STS-<i>N</i> signal. This byte is used to transmit a 1-byte fixed-length string or a 16-byte message so that a receiving terminal in a section can verify its continued connection to the intended transmitter.</li> <li>• <b>S1</b>—Synchronization status. The S1 byte is located in the first STS-1 of an STS-<i>N</i>.</li> <li>• <b>Z3</b> and <b>Z4</b>—These bytes are allocated for future use.</li> </ul>	<b>extensive</b>
<b>Received path trace</b>  <b>Transmitted path trace</b>	<p>SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits.</p>	<b>extensive</b>

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>ATM Status</b>	ATM state information: <ul style="list-style-type: none"><li>• <b>HCS State</b>—Status of the header check sequence. ATM uses the HCS field in the cell header in the cell delineation process to frame ATM cell boundaries. The HCS is an FCS-8 calculation over the first four octets of the ATM cell header.</li><li>• <b>LOC</b>—Current loss of cell (LOC) delineation state. <b>OK</b> means that no LOC is currently asserted.</li></ul>	<b>extensive</b>



Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
ATM Statistics	<p>ATM statistics for the interface:</p> <ul style="list-style-type: none"> <li>• <b>Uncorrectable HCS errors</b>—Number of cells dropped because the cell delineation failed. These errors most likely indicate that a SONET/SDH layer problem has occurred.</li> <li>• <b>Correctable HCS errors</b>—Number of correctable HCS errors that occurred. The cell delineation process can recover from these errors and locate the ATM cell boundary, although the framing process is not quite stable. The ATM cell is not dropped. This counter increases when the cell delineation process changes its state from <b>present</b> to <b>sync</b> (for example, when a cable is plugged into the interface).</li> </ul> <p>The following error statistics are from the framer:</p> <ul style="list-style-type: none"> <li>• <b>Tx cell FIFO overruns</b>—Number of overruns in the transmit FIFO.</li> <li>• <b>Rx cell FIFO overruns</b>—Number of overruns in the receive FIFO.</li> <li>• <b>Rx cell FIFO underruns</b>—Number of underruns in the receive FIFO.</li> <li>• <b>Input cell count</b>—Number of ATM cells received by the interface (not including idle cells).</li> <li>• <b>Output cell count</b>—Number of ATM cells transmitted by the interface (including idle cells).</li> <li>• <b>Output idle cell count</b>—Number of idle cells sent by the port. When ATM has nothing to send, it sends idle cells to fill the time slot.</li> <li>• <b>Output VC queue drops</b>—Number of packets dropped by a port on the PIC. Packets are dropped because of queue limits on the VCs.</li> </ul> <p>The following error statistics are from the SAR:</p> <ul style="list-style-type: none"> <li>• <b>Input no buffers</b>—Number of AAL5 packets dropped because no channel blocks or buffers were available to handle them.</li> <li>• <b>Input length errors</b>—Number of AAL5 packets dropped because their length was incorrect. Usually, these errors occur because a cell has been corrupted or lost, or because the length field was corrupted. They can also mean the AAL5 length field was zero.</li> <li>• <b>Input timeouts</b>—Number of AAL5 packets dropped because of a reassembly timeout.</li> <li>• <b>Input invalid VCs</b>—Number of AAL5 packets dropped because the header was unrecognized (because the VC was not correct or not configured).</li> <li>• <b>Input bad CRCs</b>—Number of AAL5 packets dropped because of frame check sequence errors.</li> <li>• <b>Input OAM cell no buffers</b>—Number of received OAM cells or raw cells dropped because no buffers were available to handle them.</li> <li>• <b>L2 circuit out-of-sequence packets</b>—(Layer 2 AAL5 mode) Number of AAL5 packets that are out of sequential order.</li> <li>• <b>Denied packets count</b>—The number of packets dropped due to VLAN priority deny packets or due to an error forwarding configuration that might cause a negative frame length, that is, the stripping size is larger than the packet size.</li> </ul>	extensive
Packet Forwarding Engine configuration	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> </ul>	extensive

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
CoS information	<p>Information about the CoS queue for the physical interface.</p> <ul style="list-style-type: none"><li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li><li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li><li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li><li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li><li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li><li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li><li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li></ul>	extensive

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
VPI	<p>(ATM2) Virtual path identifier information:</p> <ul style="list-style-type: none"> <li>• <b>Flags</b>—VPI flags can be one or more of the following: <ul style="list-style-type: none"> <li>• <b>Active</b> (virtual path is up)</li> <li>• <b>OAM</b> (operation and maintenance is enabled)</li> <li>• <b>Shaping</b> (shaping is configured)</li> </ul> </li> <li>• <b>CBR, Peak</b></li> <li>• <b>OAM, Period</b>—Interval at which OAM F4 loopback cells are sent.</li> <li>• <b>Up count</b>—Number of F4 OAM cells required to consider the virtual path up; the range is 1 through 255.</li> <li>• <b>Down count</b>—Number of F4 OAM cells required to consider the virtual path down; the range is 1 through 255.</li> <li>• <b>Total down time</b>—Total number of seconds the VPI has been down since it was opened, using the format <b>Total down time: hh:mm:ss</b> or <b>Never</b>.</li> <li>• <b>Last down</b>—Time of last <b>Down</b> transition, using the format <b>Last down: hh:mm:ss ago</b> or <b>Never</b>.</li> <li>• <b>OAM F4 cell statistics</b>—(Nonpromiscuous mode) OAM F4 statistics: <ul style="list-style-type: none"> <li>• <b>Total received</b>—Number of OAM F4 cells received.</li> <li>• <b>Total sent</b>—Number of OAM F4 cells sent.</li> <li>• <b>Loopback received</b>—Number of OAM F4 loopback cells received.</li> <li>• <b>Loopback sent</b>—Number of OAM F4 loopback cells sent.</li> <li>• <b>Last received</b>—Time at which the last OAM F4 cell was received.</li> <li>• <b>Last sent</b>—Time at which the last OAM F4 cell was sent.</li> <li>• <b>RDI received</b>—Number of OAM F4 cells received with the remote defect indication bit set.</li> <li>• <b>RDI sent</b>—Number of OAM F4 cells sent with the RDI bit set.</li> <li>• <b>AIS received</b>—Number of OAM F4 cells received with the alarm indication signal bit set.</li> <li>• <b>AIS sent</b>—Number of OAM F4 cells sent with the AIS bit set.</li> </ul> </li> </ul> <p><b>Traffic statistics:</b></p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the VPI.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the VPI.</li> <li>• <b>Input packets</b>—Number of packets received on the VPI.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the VPI.</li> </ul>	detail extensive none
<b>Logical Interface</b>		
Logical interface	Name of the logical interface.	All levels
Index	Logical interface index number, which reflects its initialization sequence.	detail extensive none
SNMP ifIndex	Logical interface SNMP interface index number.	detail extensive none
Generation	Unique number for use by Juniper Networks technical support only.	detail extensive

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Traffic statistics</b>	Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes a while (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes a while (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes a while (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>VCI</b>	Virtual circuit identifier number and information: <ul style="list-style-type: none"> <li>• <b>Flags</b>—VCI flags:               <ul style="list-style-type: none"> <li>• <b>Active</b>—VCI is up and in working condition.</li> <li>• <b>CCC down</b>—VCI CCC is not in working condition.</li> <li>• <b>Closed</b>—VCI is closed because the user disabled the logical or physical interface from the CLI.</li> <li>• <b>Configured</b>—VCI is configured.</li> <li>• <b>Down</b>—VCI is not in working condition. The VCI might have alarms, defects, F5 AIS/RDI, or no response to OAM loopback cells.</li> <li>• <b>ILMI</b>—VCI is up and in working condition.</li> <li>• <b>OAM</b>—OAM loopback is enabled.</li> <li>• <b>Multicast</b>—VCI is a multicast VCI or DLCI.</li> <li>• <b>Multipoint destination</b>—VCI is configured as a multipoint destination.</li> <li>• <b>None</b>—No VCI flags.</li> <li>• <b>Passive-OAM</b>—Passive OAM is enabled.</li> <li>• <b>Shaping</b>—Shaping is enabled.</li> <li>• <b>Sustained</b>—Shaping rate is set to <b>Sustained</b>.</li> <li>• <b>Unconfigured</b>—VCI is not configured.</li> </ul> </li> <li>• <b>Total down time</b>—Total number of seconds the VCI has been down, using the format <b>Total down time: hh:mm:ss</b> or <b>Never</b>.</li> <li>• <b>Last down</b>—Time of last <b>Down</b> transition, using the format <b>Last down: hh:mm:ss</b>.</li> <li>• <b>EPD threshold</b>—(ATM2 only) Threshold at which a packet is dropped when the queue size (in number of cells) exceeds the early packet-discard (EPD) value.</li> </ul>	All levels

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
VCI (continued)	<ul style="list-style-type: none"> <li>• <b>Transmit weight cells</b>—(ATM2 only) Amount of bandwidth assigned to this queue.</li> <li>• <b>ATM per-VC transmit statistics:</b> <ul style="list-style-type: none"> <li>• <b>Tail queue packet drops</b>—Number of packets dropped because of bandwidth constraints. This value indicates that packets are queued to send out at a rate faster than allowed.</li> </ul> </li> <li>• <b>OAM F4 cell statistics</b>—(Nonpromiscuous mode) OAM F4 statistics: <ul style="list-style-type: none"> <li>• <b>Total received</b>—Number of OAM F4 cells received.</li> <li>• <b>Total sent</b>—Number of OAM F4 cells sent.</li> <li>• <b>Loopback received</b>—Number of OAM F4 loopback cells received.</li> <li>• <b>Loopback sent</b>—Number of OAM F4 loopback cells sent.</li> <li>• <b>Last received</b>—Time at which the last OAM F4 cell was received.</li> <li>• <b>Last sent</b>—Time at which the last OAM F4 cell was sent.</li> <li>• <b>RDI received</b>—Number of OAM F4 cells received with the remote defect indication bit set.</li> <li>• <b>RDI sent</b>—Number of OAM F4 cells sent with the RDI bit set.</li> <li>• <b>AIS received</b>—Number of OAM F4 cells received with the alarm indication signal bit set.</li> <li>• <b>AIS sent</b>—Number of OAM F4 cells sent with the AIS bit set.</li> </ul> </li> <li>• <b>Traffic statistics</b>—Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul> </li> </ul>	All levels
IMA group properties	<ul style="list-style-type: none"> <li>• <b>Version</b>—The specified IMA specification version, either IMA 1.0 or IMA 1.1.</li> <li>• <b>Frame length</b>—The specified frame size, which can be 32, 64, 128, or 256.</li> <li>• <b>Differential delay</b>—Maximum differential delay among links in milliseconds.</li> <li>• <b>Symmetry</b>—Either Common Transmit Clock or Independent Transmit Clock timing mode.</li> <li>• <b>Transmit clock</b>—The specified IMA clock mode, either common or independent.</li> <li>• <b>Minimum links</b>—The number of minimum active links specified in both transmit and receive directions. <ul style="list-style-type: none"> <li>• <b>Transmit</b>—The per-PIC limit on the number of minimum active links in the transmit direction.</li> <li>• <b>Receive</b>—The per-PIC limit on the number of minimum active links in the receive direction.</li> </ul> </li> <li>• <b>Frame synchronization</b>—The specified IMA frame synchronization state transition variables (Alpha, Beta, and Gamma) and their specified values. <ul style="list-style-type: none"> <li>• <b>Alpha</b>—The number of consecutive invalid ICP cells for IFSM.</li> <li>• <b>Beta</b>—The number of consecutive errored ICP cells for IFSM.</li> <li>• <b>Gamma</b>—The number of consecutive valid ICP cells for IFSM.</li> </ul> </li> <li>• <b>Links</b>—The number of IMA links assigned to the IMA group.</li> </ul>	detail extensive none

Table 102: ATM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
IMA group alarms	<ul style="list-style-type: none"> <li>• <b>Start-up-FE</b>—Far-end group alarm status</li> <li>• <b>Config-Aborted</b>—Near-end configuration aborted group alarm status</li> <li>• <b>Config-Aborted-FE</b>—Far-end configuration aborted group alarm status</li> <li>• <b>Insufficient-Links</b>—Near-end insufficient links group alarm status</li> <li>• <b>Insufficient-Links-FE</b>—Far-end insufficient links group alarm status</li> <li>• <b>Blocked-FE</b>—Far-end blocked group alarm status</li> <li>• <b>GR-Timing-Mismatch</b>—Group timing mismatch alarm status</li> </ul>	detail extensive none
IMA group defects	<ul style="list-style-type: none"> <li>• <b>Start-up-FE</b>—Far-end group defect status</li> <li>• <b>Config-Aborted</b>—Near-end configuration aborted group defect status</li> <li>• <b>Config-Aborted-FE</b>—Far-end configuration aborted group defect status</li> <li>• <b>Insufficient-Links</b>—Near-end insufficient links group defect status</li> <li>• <b>Insufficient-Links-FE</b>—Far-end insufficient links group defect status</li> <li>• <b>Blocked-FE</b>—Far-end blocked group defect status</li> <li>• <b>GR-Timing-Mismatch</b>—Group timing mismatch defect status</li> </ul>	detail extensive none
IMA Group state	Near-end and far-end group status	detail extensive none
IMA group media	<p>IMA group media status, including seconds, count and state for the following media parameters:</p> <ul style="list-style-type: none"> <li>• FC</li> <li>• FC-FE</li> <li>• Addr-Mismatch</li> <li>• Running</li> <li>• UAS</li> </ul>	detail extensive none

## Sample Output

### show interfaces (ATM, IMA Group)

```

user@host> show interfaces at-1/0/0
Physical interface: at-1/0/0, Enabled, Physical link is Up
  IMA group properties:
    Version           : 1.1
    Frame length      : 128
    Differential delay : 25 milliseconds
    Symmetry          : Symmetrical Configuration and Operation
    Transmit clock     : Common
    Minimum links      : Transmit: 1, Receive: 1
    Frame synchronization: Alpha: 2, Beta: 2, Gamma: 1
    Links             : None
  IMA group alarms : Start-up-FE Config-Aborted Config-Aborted-FE
                    Insufficient-Links Insufficient-Links-FE Blocked-FE GR-Timing-Mismatch
  IMA group defects : Start-up-FE Config-Aborted Config-Aborted-FE
                    Insufficient-Links Insufficient-Links-FE Blocked-FE GR-Timing-Mismatch
  IMA Group state:
    Near end : Start up
    Far end  : Start up
  IMA group media:
    Seconds      Count  State
  FC             0
  FC-FE          0
  Addr-Mismatch  0
  Running        0
  UAS            0

```

### show interfaces extensive (ATM IMA Group)

```

user@host> show interfaces at-0/0/10 extensive
Physical interface: at-0/0/10, Enabled, Physical link is Up
  Interface index: 178, SNMP ifIndex: 540, Generation: 531
  Link-level type: ATM-PVC, MTU: 2048, Speed: Unspecified, Loopback: None, Payload
  scrambler: Enabled
  Device flags   : Present Running
  Link flags     : None
  CoS queues     : 8 supported, 4 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 84:18:88:c0:33:0a
  Last flapped   : 2012-03-16 16:49:15 PDT (2d 07:12 ago)
  Statistics last cleared: 2012-03-16 16:56:58 PDT (2d 07:05 ago)
  Traffic statistics:
    Input bytes : 0          0 bps
    Output bytes : 0          0 bps
    Input packets: 0          0 pps
    Output packets: 0          0 pps
  IPv6 transit statistics:
    Input bytes : 0
    Output bytes : 0
    Input packets: 0
    Output packets: 0
  Input errors:
    Errors: 0, Drops: 0, Invalid VCs: 0, Framing errors: 0, Policed discards:
0, L3 incompletes: 0, L2 channel errors: 0,
    L2 mismatch timeouts: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0, MTU errors:
0, Resource errors: 0
  IMA group properties:
    Version           : 1.1
    Frame length      : 128

```



```

Differential delay : 25 milliseconds
Symmetry          : Symmetrical Configuration and Operation
Transmit clock    : Common
Minimum links     : Transmit: 1, Receive: 1
Frame synchronization: Alpha: 2, Beta: 2, Gamma: 1
Link #1           : t1-0/0/4          up
IMA Group alarms  : None
IMA Group defects : None

IMA Group state:
Near end : Operational
Far end  : Operational
IMA group media:
Seconds      Count  State
FC           0
FC-FE        0
Addr-Mismatch 0
Running      198306
UAS          0
ATM status:
HCS state:   Sync
LOC         : OK
ATM Statistics:
Uncorrectable HCS errors: 0, Correctable HCS errors: 0, Tx cell FIFO overruns:
0, Rx cell FIFO overruns: 0,
Rx cell FIFO underruns: 0, Input cell count: 0, Output cell count: 0, Output
idle cell count: 0,
Output VC queue drops: 0, Input no buffers: 0, Input length errors: 0, Input
timeouts: 0, Input invalid VCs: 0,
Input bad CRCs: 0, Input OAM cell no buffers: 0
Packet Forwarding Engine configuration:
Destination slot: 0
VPI 2
Flags: Active
Total down time: 0 sec, Last down: Never
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

Logical interface at-0/0/10.602 (Index 71) (SNMP ifIndex 1057) (Generation
17226)
Flags: Point-To-Point SNMP-Traps CCC-Down 0x0 Encapsulation:
ATM-CCC-Cell-Relay
L2 circuit cell bundle size: 1, bundle timeout: 125 usec, timeout count: 0
L2 circuit out-of-sequence count: 0, denied packets count: 0

```

### show interfaces (ATM1, SONET Mode)

```

user@host> show interfaces at-1/0/0
Physical interface: at-1/0/0, Enabled, Physical link is Up
Interface index: 300, SNMP ifIndex: 194
Description: to allspice at-1/0/0
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags : Present Running
Link flags   : None
CoS queues   : 4 supported, 4 maximum usable queues
Current address: 00:05:85:02:38:7e
Last flapped : 2006-02-24 14:28:12 PST (6d 01:51 ago)
Input rate   : 0 bps (0 pps)
Output rate  : 0 bps (0 pps)
SONET alarms : None

```

SONET defects : None

Logical interface at-1/0/0.0 (Index 64) (SNMP ifIndex 204)  
 Flags: Point-To-Point SNMP-Traps Encapsulation: ATM-SNAP  
 Input packets : 0  
 Output packets: 0  
 Protocol inet, MTU: 4470  
 Flags: None  
 Addresses, Flags: Is-Preferred Is-Primary  
 Destination: 192.168.220.24/30, Local: 192.168.220.26,  
 Broadcast: 192.168.220.27  
 Protocol iso, MTU: 4470  
 Flags: None  
 VCI 0.128  
 Flags: Active  
 Total down time: 0 sec, Last down: Never  
 Input packets : 0  
 Output packets: 0

#### show interfaces brief (ATM1, SONET Mode)

```
user@host> show interfaces at-1/0/0 brief
Physical interface: at-1/0/0, Enabled, Physical link is Up
Description: to allspice at-1/0/0
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags : Present Running
Link flags   : None

Logical interface at-1/0/0.0
Flags: Point-To-Point SNMP-Traps Encapsulation: ATM-SNAP
inet 192.168.220.26/30
iso
VCI 0.128
Flags: Active
Total down time: 0 sec, Last down: Never
```

#### show interfaces detail (ATM1, SONET Mode)

```
user@host> show interfaces at-1/0/0 detail
Physical interface: at-1/0/0, Enabled, Physical link is Up
Interface index: 300, SNMP ifIndex: 194, Generation: 183
Description: to allspice at-1/0/0
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags : Present Running
Link flags   : None
CoS queues   : 4 supported, 4 maximum usable queues
Hold-times   : Up 0 ms, Down 0 ms
Current address: 00:05:85:02:38:7e
Last flapped : 2006-02-24 14:28:12 PST (6d 01:55 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
Egress queues: 4 supported, 4 in use
Queue counters: Queued packets Transmitted packets Dropped packets

0 best-effort 0 0 0
1 expedited-fo 0 0 0
```

```

2 assured-forw          0          0          0
3 network-cont          0          0          0

SONET alarms   : None
SONET defects  : None

Logical interface at-1/0/0.0 (Index 64) (SNMP ifIndex 204) (Generation 5)
  Flags: Point-To-Point SNMP-Traps Encapsulation: ATM-SNAP
  Traffic statistics:
    Input bytes   :          0
    Output bytes  :          0
    Input packets :          0
    Output packets:          0
  Local statistics:
    Input bytes   :          0
    Output bytes  :          0
    Input packets :          0
    Output packets:          0
  Transit statistics:
    Input bytes   :          0          0 bps
    Output bytes  :          0          0 bps
    Input packets :          0          0 pps
    Output packets:          0          0 pps
  Protocol inet, MTU: 4470, Generation: 13, Route table: 0
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 192.168.220.24/30, Local: 192.168.220.26,
      Broadcast: 192.168.220.27, Generation: 14
  Protocol iso, MTU: 4470, Generation: 14, Route table: 0
    Flags: None
  VCI 0.128
    Flags: Active
    Total down time: 0 sec, Last down: Never
    ATM per-VC transmit statistics:
      Tail queue packet drops: 0
    Traffic statistics:
      Input bytes   :          0
      Output bytes  :          0
      Input packets :          0
      Output packets:          0

```

**show interfaces  
extensive  
(ATM1, SONET Mode)**

```

user@host> show interfaces at-1/0/0 extensive
Physical interface: at-1/0/0, Enabled, Physical link is Up
Interface index: 300, SNMP ifIndex: 194, Generation: 183
Description: to allspice at-1/0/0
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : None
CoS queues     : 4 supported, 4 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:05:85:02:38:7e
Last flapped   : 2006-02-24 14:28:12 PST (6d 01:56 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :          0          0 bps
  Output bytes  :          0          0 bps
  Input packets :          0          0 pps
  Output packets:          0          0 pps
Input errors:

```

Errors: 0, Drops: 0, Invalid VCs: 0, Framing errors: 0, Policed discards: 0,

L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,  
Resource errors: 0

Output errors:

Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,

Resource errors: 0

Egress queues: 4 supported, 4 in use

Queue counters:	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	0	0	0

SONET alarms : None

SONET defects : None

SONET PHY:	Seconds	Count	State
PLL Lock	0	0	OK
PHY Light	0	0	OK
SONET section:			
BIP-B1	0	0	
SEF	0	0	OK
LOS	0	0	OK
LOF	0	0	OK
ES-S	0		
SES-S	0		
SEFS-S	0		
SONET line:			
BIP-B2	0	0	
REI-L	0	0	
RDI-L	0	0	OK
AIS-L	0	0	OK
BERR-SF	0	0	OK
BERR-SD	0	0	OK
ES-L	0		
SES-L	0		
UAS-L	0		
ES-LFE	0		
SES-LFE	0		
UAS-LFE	0		
SONET path:			
BIP-B3	0	0	
REI-P	0	0	
LOP-P	0	0	OK
AIS-P	0	0	OK
RDI-P	0	0	OK
UNEQ-P	1	1	OK
PLM-P	0	0	OK
ES-P	1		
SES-P	1		
UAS-P	0		
ES-PFE	0		
SES-PFE	0		
UAS-PFE	0		
Received SONET overhead:			
F1	: 0x00, J0	: 0x00, K1	: 0x00, K2 : 0x00

```

S1      : 0x00, C2      : 0x13, C2(cmp) : 0x13, F2      : 0x00
Z3      : 0x00, Z4      : 0x00, S1(cmp) : 0x00
Transmitted SONET overhead:
F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0x13, F2      : 0x00, Z3      : 0x00
Z4      : 0x00
ATM status:
HCS state: Sync
LOC      : OK
ATM Statistics:
Uncorrectable HCS errors: 0, Correctable HCS errors: 0,
Tx cell FIFO overruns: 0, Rx cell FIFO overruns: 0,
Rx cell FIFO underruns: 0, Input cell count: 0, Output cell count: 0,
Output idle cell count: 0, Output VC queue drops: 0, Input no buffers: 0,
Input length errors: 0, Input timeouts: 0, Input invalid VCs: 0,
Input bad CRCs: 0, Input OAM cell no buffers: 0
Packet Forwarding Engine configuration:
Destination slot: 1
CoS information:
CoS transmit queue      Bandwidth      Buffer      Priority      Limit
                        %      bps      %      usec
0 best-effort           95      147744000  95      0           low      none
3 network-control       5       7776000   5       0           low      none

Logical interface at-1/0/0.0 (Index 64) (SNMP ifIndex 204) (Generation 5)
Flags: Point-To-Point SNMP-Traps Encapsulation: ATM-SNAP
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Local statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
Protocol inet, MTU: 4470, Generation: 13, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
Destination: 192.168.220.24/30, Local: 192.168.220.26,
Broadcast: 192.168.220.27, Generation: 14
Protocol iso, MTU: 4470, Generation: 14, Route table: 0
Flags: None
VCI 0.128
Flags: Active
Total down time: 0 sec, Last down: Never
ATM per-VC transmit statistics:
Tail queue packet drops: 0
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

**show interfaces**

```

user@host> show interfaces at-0/2/1
Physical interface: at-0/2/1, Enabled, Physical link is Up

```

**(ATM2, SDH Mode)**

```

Interface index: 154, SNMP ifIndex: 42
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SDH mode, Speed: OC3,

Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : None
CoS queues     : 4 supported, 4 maximum usable queues
Current address: 00:05:85:8f:30:3f
Last flapped   : 2006-03-24 13:29:58 PST (00:04:48 ago)
Input rate     : 0 bps (0 pps)
Output rate    : 0 bps (0 pps)
SDH alarms     : None
SDH defects    : None
  VPI 0
    Flags: Active
    Total down time: 0 sec, Last down: Never
Traffic statistics:
  Input packets:          0
  Output packets:         0

Logical interface at-0/2/1.0 (Index 75) (SNMP ifIndex 51)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: ATM-SNAP
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 4470
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.0.12.6, Local: 10.0.12.5
  Protocol iso, MTU: 4470
    Flags: None
  VCI 0.128
    Flags: Active
    Total down time: 0 sec, Last down: Never
    EPD threshold: 2129, Transmit weight cells: 0
      Input packets : 0
      Output packets: 0

Logical interface at-0/2/1.32767 (Index 76) (SNMP ifIndex 50)
  Flags: Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
  Encapsulation: ATM-VCMUX
  Input packets : 0
  Output packets: 0
  VCI 0.4
    Flags: Active
    Total down time: 0 sec, Last down: Never
    EPD threshold: 0, Transmit weight cells: 0
      Input packets : 0
      Output packets: 0

```

**show interfaces brief  
(ATM2, SDH Mode)**

```

user@host> show interfaces at-0/2/1 brief
Physical interface: at-0/2/1, Enabled, Physical link is Up
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SDH mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : None
Logical interface at-0/2/1.0
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: ATM-SNAP
  inet 10.0.12.5    --> 10.0.12.6
  iso
  VCI 0.128
    Flags: Active

```

Total down time: 0 sec, Last down: Never  
 EPD threshold: 2129, Transmit weight cells: 0

Logical interface at-0/2/1.32767  
 Flags: Point-To-Multipoint No-Multicast SNMP-Traps 0x4000  
 Encapsulation: ATM-VCMUX  
 VCI 0.4  
 Flags: Active  
 Total down time: 0 sec, Last down: Never  
 EPD threshold: 0, Transmit weight cells: 0

#### show interfaces detail (ATM2, SDH Mode)

```
user@host> show interfaces at-0/2/1 detail
Physical interface: at-0/2/1, Enabled, Physical link is Up
Interface index: 154, SNMP ifIndex: 42, Generation: 40
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SDH mode, Speed: OC3,

Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : None
CoS queues     : 4 supported, 4 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:05:85:8f:30:3f
Last flapped   : 2006-03-24 13:29:58 PST (00:05:10 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :                0                0 bps
  Output bytes  :                0                0 bps
  Input packets :                0                0 pps
  Output packets:                0                0 pps
Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets  Dropped packets

  0 best-effort                0                0                0
  1 expedited-fo                0                0                0
  2 assured-forw                0                0                0
  3 network-cont                0                0                0

SDH  alarms   : None
SDH  defects  : None
VPI 0
  Flags: Active
  Total down time: 0 sec, Last down: Never
  Traffic statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0

Logical interface at-0/2/1.0 (Index 75) (SNMP ifIndex 51) (Generation 25)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: ATM-SNAP
Traffic statistics:
  Input bytes   :                0
  Output bytes  :                0
  Input packets :                0
  Output packets:                0
Local statistics:
  Input bytes   :                0
  Output bytes  :                0
```

```

Input packets:                0
Output packets:               0
Transit statistics:
Input bytes :                  0                0 bps
Output bytes :                 0                0 bps
Input packets:                0                0 pps
Output packets:               0                0 pps
Protocol inet, MTU: 4470, Generation: 62, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.12.6, Local: 10.0.12.5, Broadcast: Unspecified,
    Generation: 58
Protocol iso, MTU: 4470, Generation: 63, Route table: 0
  Flags: None
VCI 0.128
  Flags: Active
  Total down time: 0 sec, Last down: Never
  EPD threshold: 2129, Transmit weight cells: 0
  ATM per-VC transmit statistics:
    Tail queue packet drops: 0
  Traffic statistics:
    Input bytes :                0
    Output bytes :               0
    Input packets:               0
    Output packets:              0
Logical interface at-0/2/1.32767 (Index 76) (SNMP ifIndex 50) (Generation 26)
  Flags: Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
  Encapsulation: ATM-VCMUX
  Traffic statistics:
    Input bytes :                0
    Output bytes :               0
    Input packets:               0
    Output packets:              0
  Local statistics:
    Input bytes :                0
    Output bytes :               0
    Input packets:               0
    Output packets:              0
VCI 0.4
  Flags: Active
  Total down time: 0 sec, Last down: Never
  EPD threshold: 0, Transmit weight cells: 0
  ATM per-VC transmit statistics:
    Tail queue packet drops: 0
  Traffic statistics:
    Input bytes :                0
    Output bytes :               0
    Input packets:               0
    Output packets:              0

```

#### show interfaces extensive (ATM2, SDH Mode)

```

user@host> show interfaces at-0/2/1 extensive
Physical interface: at-0/2/1, Enabled, Physical link is Up
Interface index: 154, SNMP ifIndex: 42, Generation: 40
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SDH mode, Speed: OC3,

Loopback: None, Payload scrambler: Enabled
Device flags : Present Running
Link flags   : None
CoS queues   : 4 supported, 4 maximum usable queues
Hold-times   : Up 0 ms, Down 0 ms
Current address: 00:05:85:8f:30:3f

```



```

Last flapped   : 2006-03-24 13:29:58 PST (00:06:49 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :                0                0 bps
  Output bytes  :                0                0 bps
  Input packets :                0                0 pps
  Output packets:                0                0 pps
Input errors:
  Errors: 0, Drops: 0, Invalid VCs: 0, Framing errors: 0, Policed discards: 0,

  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  Resource errors: 0
Output errors:
  Carrier transitions: 3, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,

  Resource errors: 0
Egress queues: 4 supported, 4 in use
Queue counters:
  Queued packets  Transmitted packets  Dropped packets

  0 best-effort           0                0                0
  1 expedited-fo         0                0                0
  2 assured-forw         0                0                0
  3 network-cont         0                0                0

SDH  alarms   : None
SDH  defects   : None
SDH PHY:
  Seconds      Count  State
  PLL Lock     0       OK
  PHY Light    1       OK
SDH regenerator section:
  RS-BIP8      2       8828
  OOF          2        2 OK
  LOS          2        1 OK
  LOF          2        1 OK
  RS-ES        4
  RS-SES       3
  RS-SEFS      2
SDH multiplex section:
  MS-BIP24     2       771
  MS-FEBE      1      17476
  MS-FERF      2        1 OK
  MS-AIS       2        1 OK
  BERR-SF      0        0 OK
  BERR-SD      0        0 OK
  MS-ES        4
  MS-SES       2
  MS-UAS       0
  MS-ES-FE     3
  MS-SES-FE    2
  MS-UAS-FE    0
SDH path:
  HP-BIP8      1        6
  HP-FEBE      1      251
  HP-LOP       0        0 OK
  HP-AIS       2        1 OK
  HP-FERF      3        2 OK
  HP-UNEQ      1        1 OK
  HP-PLM       2        1 OK

```

```

HP-ES                4
HP-SES               3
HP-UAS               0
HP-ES-FE             3
HP-SES-FE            3
HP-UAS-FE            0
Received SDH overhead:
F1      : 0x00, J0      : 0x00, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0x13, C2(cmp) : 0x13, F2      : 0x00
Z3      : 0x00, Z4      : 0x00, S1(cmp) : 0x00
Transmitted SDH overhead:
F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0x13, F2      : 0x00, Z3      : 0x00
Z4      : 0x00
ATM status:
HCS state:      Sync
LOC      :      OK
ATM Statistics:
Uncorrectable HCS errors: 0, Correctable HCS errors: 0,
Tx cell FIFO overruns: 0, Rx cell FIFO overruns: 0,
Rx cell FIFO underruns: 0, Input cell count: 0, Output cell count: 0,
Output idle cell count: 0, Output VC queue drops: 0, Input no buffers: 0,
Input length errors: 0, Input timeouts: 0, Input invalid VCs: 0,
Input bad CRCs: 0, Input OAM cell no buffers: 0
Packet Forwarding Engine configuration:
Destination slot: 0
VPI 0
Flags: Active
Total down time: 0 sec, Last down: Never
Traffic statistics:
Input bytes      :      0
Output bytes     :      0
Input packets    :      0
Output packets   :      0

Logical interface at-0/2/1.0 (Index 75) (SNMP ifIndex 51) (Generation 25)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: ATM-SNAP
Traffic statistics:
Input bytes      :      0
Output bytes     :      0
Input packets    :      0
Output packets   :      0
Local statistics:
Input bytes      :      0
Output bytes     :      0
Input packets    :      0
Output packets   :      0
Transit statistics:
Input bytes      :      0      0 bps
Output bytes     :      0      0 bps
Input packets    :      0      0 pps
Output packets   :      0      0 pps
Protocol inet, MTU: 4470, Generation: 62, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.0.12.6, Local: 10.0.12.5, Broadcast: Unspecified,
Generation: 58
Protocol iso, MTU: 4470, Generation: 63, Route table: 0
Flags: None
VCI 0.128
Flags: Active

```

```

Total down time: 0 sec, Last down: Never
EPD threshold: 2129, Transmit weight cells: 0
ATM per-VC transmit statistics:
Tail queue packet drops: 0
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Logical interface at-0/2/1.32767 (Index 76) (SNMP ifIndex 50) (Generation 26)
Flags: Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
Encapsulation: ATM-VCMUX
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Local statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
VCI 0.4
Flags: Active
Total down time: 0 sec, Last down: Never
EPD threshold: 0, Transmit weight cells: 0
ATM per-VC transmit statistics:
Tail queue packet drops: 0
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

### show interfaces (ATM2, SONET Mode)

```

user@host> show interfaces at-0/3/1
Physical interface: at-0/3/1, Enabled, Physical link is Up
Interface index: 139, SNMP ifIndex: 67
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags : Present Running
Link flags : None
CoS queues : 4 supported, 4 maximum usable queues
Current address: 00:14:f6:22:58:5e
Last flapped : 2006-03-13 17:46:36 PST (16:01:12 ago)
Input rate : 0 bps (0 pps)
Output rate : 0 bps (0 pps)
SONET alarms : None
SONET defects : None
VPI 0
Flags: Active, OAM, Shaping
CBR, Peak: 50kbps
OAM, Period 30 sec, Up count: 10, Down count: 10
Total down time: 0 sec, Last down: Never
OAM F4 cell statistics:
Total received: 4, Total sent: 4
Loopback received: 4, Loopback sent: 4
RDI received: 0, RDI sent: 0
AIS received: 0
Traffic statistics:
Input packets: 4
Output packets: 30

```

```

VPI 10
  Flags: Active
  Total down time: 0 sec, Last down: Never
Traffic statistics:
  Input packets: 0
  Output packets: 0
Logical interface at-0/3/1.0 (Index 78) (SNMP ifIndex 77)
  Flags: Point-To-Point Copy-PLP-To-CLP SNMP-Traps 0x4000
  Encapsulation: ATM-SNAP
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 4470
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.59.5, Local: 10.0.59.6
  Protocol iso, MTU: 4470
  Flags: None
VCI 0.128
  Flags: Active
  Total down time: 0 sec, Last down: Never
  EPD threshold: 2129, Transmit weight cells: 10
  Input packets : 0
  Output packets: 0

Logical interface at-0/3/1.32767 (Index 79) (SNMP ifIndex 76)
  Flags: Point-To-Multipoint Copy-PLP-To-CLP No-Multicast SNMP-Traps 0x4000
  Encapsulation: ATM-VCMUX
  Input packets : 4
  Output packets: 30
VCI 0.16
  Flags: Active, ILMI
  Total down time: 0 sec, Last down: Never
  EPD threshold: 0, Transmit weight cells: 0
  Input packets : 0
  Output packets: 26
VCI 0.4
  Flags: Active, OAM
  OAM, Period 30 sec, Up count: 10, Down count: 10
  Total down time: 0 sec, Last down: Never
  EPD threshold: 2129, Transmit weight cells: 0
  Input packets : 4
  Output packets: 4
  OAM F4 cell statistics:
    Total received: 4, Total sent: 4
    Loopback received: 4, Loopback sent: 4
    RDI received: 0, RDI sent: 0
    AIS received: 0, AIS sent: 0

```

#### show interfaces brief (ATM2, SONET Mode)

```

user@host> show interfaces at-0/3/1 brief
Physical interface: at-0/3/1, Enabled, Physical link is Up
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : None

Logical interface at-0/3/1.0
  Flags: Point-To-Point Copy-PLP-To-CLP SNMP-Traps 0x4000
  Encapsulation: ATM-SNAP
  inet 10.0.59.6      --> 10.0.59.5
  iso
  VCI 0.128

```

```

Flags: Active
Total down time: 0 sec, Last down: Never
EPD threshold: 2129, Transmit weight cells: 10

```

Logical interface at-0/3/1.32767

```

Flags: Point-To-Multipoint Copy-PLP-To-CLP No-Multicast SNMP-Traps 0x4000
Encapsulation: ATM-VCMUX

```

VCI 0.16

```

Flags: Active, ILMI
Total down time: 0 sec, Last down: Never
EPD threshold: 0, Transmit weight cells: 0

```

VCI 0.4

```

Flags: Active, OAM
Total down time: 0 sec, Last down: Never
EPD threshold: 2129, Transmit weight cells: 0

```

#### show interfaces detail (ATM2, SONET Mode)

user@host> show interfaces at-0/3/1 detail

```

Physical interface: at-0/3/1, Enabled, Physical link is Up
Interface index: 139, SNMP ifIndex: 67, Generation: 22
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : None
CoS queues     : 4 supported, 4 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:14:f6:22:58:5e
Last flapped   : 2006-03-13 17:46:36 PST (16:02:39 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          312          0 bps
Output bytes  :         2952          0 bps
Input packets :           6          0 pps
Output packets:          50          0 pps
Egress queues: 4 supported, 4 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort          44             44             0

  1 expedited-fo         0              0             0

  2 assured-forw         0              0             0

  3 network-cont         6              6             0

SONET alarms   : None
SONET defects  : None
VPI 0
Flags: Active, OAM, Shaping
CBR, Peak: 50kbps
OAM, Period 30 sec, Up count: 10, Down count: 10
Total down time: 0 sec, Last down: Never
OAM F4 cell statistics:
Total received: 6, Total sent: 6
Loopback received: 6, Loopback sent: 6
Last received: 00:00:29, Last sent: 00:00:29
RDI received: 0, RDI sent: 0
AIS received: 0
Traffic statistics:
Input bytes   :          312
Output bytes  :         2952
Input packets :           6

```

```

        Output packets:                50
VPI 10
  Flags: Active
  Total down time: 0 sec, Last down: Never
  Traffic statistics:
    Input bytes :                      0
    Output bytes :                     0
    Input packets:                     0
    Output packets:                    0

Logical interface at-0/3/1.0 (Index 78) (SNMP ifIndex 77) (Generation 20)
  Flags: Point-To-Point Copy-PLP-To-CLP SNMP-Traps 0x4000
  Encapsulation: ATM-SNAP
  Traffic statistics:
    Input bytes :                      0
    Output bytes :                     0
    Input packets:                     0
    Output packets:                    0
  Local statistics:
    Input bytes :                      0
    Output bytes :                     0
    Input packets:                     0
    Output packets:                    0
  Transit statistics:
    Input bytes :                      0                0 bps
    Output bytes :                     0                0 bps
    Input packets:                     0                0 pps
    Output packets:                    0                0 pps
  Protocol inet, MTU: 4470, Generation: 38, Route table: 0
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.0.59.5, Local: 10.0.59.6, Broadcast: Unspecified,
      Generation: 44
  Protocol iso, MTU: 4470, Generation: 39, Route table: 0
    Flags: None
  VCI 0.128
    Flags: Active
    Total down time: 0 sec, Last down: Never
    EPD threshold: 2129, Transmit weight cells: 10
    ATM per-VC transmit statistics:
      Tail queue packet drops: 0
    Traffic statistics:
      Input bytes :                      0
      Output bytes :                     0
      Input packets:                     0
      Output packets:                    0

Logical interface at-0/3/1.32767 (Index 79) (SNMP ifIndex 76) (Generation 21)
  Flags: Point-To-Multipoint Copy-PLP-To-CLP No-Multicast SNMP-Traps 0x4000
  Encapsulation: ATM-VCMUX
  Traffic statistics:
    Input bytes :                      360
    Output bytes :                     3302
    Input packets:                      6
    Output packets:                     50
  Local statistics:
    Input bytes :                      360
    Output bytes :                     3302
    Input packets:                      6
    Output packets:                     50
  VCI 0.16
    Flags: Active, ILMI

```

```

Total down time: 0 sec, Last down: Never
EPD threshold: 0, Transmit weight cells: 0
ATM per-VC transmit statistics:
  Tail queue packet drops: 0
Traffic statistics:
  Input bytes   : 0
  Output bytes  : 2640
  Input packets: 0
  Output packets: 44
VCI 0.4
Flags: Active, OAM
OAM, Period 30 sec, Up count: 10, Down count: 10
Total down time: 0 sec, Last down: Never
EPD threshold: 2129, Transmit weight cells: 0
ATM per-VC transmit statistics:
  Tail queue packet drops: 0
Traffic statistics:
  Input bytes   : 312
  Output bytes  : 312
  Input packets: 6
  Output packets: 6
OAM F4 cell statistics:
Total received: 6, Total sent: 6
Loopback received: 6, Loopback sent: 6
Last received: 00:00:29, Last sent: 00:00:29
RDI received: 0, RDI sent: 0
AIS received: 0, AIS sent: 0

```

**show interfaces  
extensive  
(ATM2, SONET Mode)**

```

user@host> show interfaces at-0/3/1 extensive
Physical interface: at-0/3/1, Enabled, Physical link is Up
Interface index: 139, SNMP ifIndex: 67, Generation: 22
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : None
CoS queues     : 4 supported, 4 maximum usable queues
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:14:f6:22:58:5e
Last flapped   : 2006-03-13 17:46:36 PST (16:04:12 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   : 520          0 bps
Output bytes  : 4240         0 bps
Input packets : 10           0 pps
Output packets: 72           0 pps
Input errors:
Errors: 0, Drops: 0, Invalid VCs: 0, Framing errors: 0, Policed discards: 0,

L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
Resource errors: 0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,

Resource errors: 0
Egress queues: 4 supported, 4 in use
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	62	62	0
1 expedited-fo	0	0	0

2 assured-forw	0	0	0
3 network-cont	10	10	0

SONET alarms : None  
SONET defects : None

SONET PHY:	Seconds	Count	State
PLL Lock	0	0	OK
PHY Light	0	0	OK

SONET section:

BIP-B1	0	0	
SEF	0	0	OK
LOS	0	0	OK
LOF	0	0	OK
ES-S	0		
SES-S	0		
SEFS-S	0		

SONET line:

BIP-B2	0	0	
REI-L	0	0	
RDI-L	0	0	OK
AIS-L	0	0	OK
BERR-SF	0	0	OK
BERR-SD	0	0	OK
ES-L	0		
SES-L	0		
UAS-L	0		
ES-LFE	0		
SES-LFE	0		
UAS-LFE	0		

SONET path:

BIP-B3	0	0	
REI-P	0	0	
LOP-P	0	0	OK
AIS-P	0	0	OK
RDI-P	0	0	OK
UNEQ-P	1	1	OK
PLM-P	0	0	OK
ES-P	1		
SES-P	1		
UAS-P	0		
ES-PFE	0		
SES-PFE	0		
UAS-PFE	0		

Received SONET overhead:

F1	: 0x00, J0	: 0x00, K1	: 0x00, K2	: 0x00
S1	: 0x00, C2	: 0x13, C2(cmp)	: 0x13, F2	: 0x00
Z3	: 0x00, Z4	: 0x00, S1(cmp)	: 0x00	

Transmitted SONET overhead:

F1	: 0x00, J0	: 0x01, K1	: 0x00, K2	: 0x00
S1	: 0x00, C2	: 0x13, F2	: 0x00, Z3	: 0x00
Z4	: 0x00			

ATM status:

HCS state: Sync  
LOC : OK

ATM Statistics:

Uncorrectable HCS errors: 0, Correctable HCS errors: 0,  
Tx cell FIFO overruns: 0, Rx cell FIFO overruns: 0,  
Rx cell FIFO underruns: 0, Input cell count: 0, Output cell count: 0,  
Output idle cell count: 0, Output VC queue drops: 0, Input no buffers: 0,  
Input length errors: 0, Input timeouts: 0, Input invalid VCs: 0,



```

Input bad CRCs: 0, Input OAM cell no buffers: 0
Packet Forwarding Engine configuration:
Destination slot: 0
VPI 0
  Flags: Active, OAM, Shaping
  CBR, Peak: 50kbps
  OAM, Period 30 sec, Up count: 10, Down count: 10
  Total down time: 0 sec, Last down: Never
  OAM F4 cell statistics:
  Total received: 10, Total sent: 10
  Loopback received: 10, Loopback sent: 10
  Last received: 00:00:02, Last sent: 00:00:02
  RDI received: 0, RDI sent: 0
  AIS received: 0
  Traffic statistics:
    Input bytes :          520
    Output bytes :         4240
    Input packets:          10
    Output packets:         72
VPI 10
  Flags: Active
  Total down time: 0 sec, Last down: Never
  Traffic statistics:
    Input bytes :          0
    Output bytes :          0
    Input packets:          0
    Output packets:         0

Logical interface at-0/3/1.0 (Index 78) (SNMP ifIndex 77) (Generation 20)
Flags: Point-To-Point Copy-PLP-To-CLP SNMP-Traps 0x4000
Encapsulation: ATM-SNAP
Traffic statistics:
  Input bytes :          0
  Output bytes :          0
  Input packets:          0
  Output packets:         0
Local statistics:
  Input bytes :          0
  Output bytes :          0
  Input packets:          0
  Output packets:         0
Transit statistics:
  Input bytes :          0          0 bps
  Output bytes :          0          0 bps
  Input packets:          0          0 pps
  Output packets:         0          0 pps
Protocol inet, MTU: 4470, Generation: 38, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.59.5, Local: 10.0.59.6, Broadcast: Unspecified,
    Generation: 44
Protocol iso, MTU: 4470, Generation: 39, Route table: 0
  Flags: None
VCI 0.128
  Flags: Active
  Total down time: 0 sec, Last down: Never
  EPD threshold: 2129, Transmit weight cells: 10
  ATM per-VC transmit statistics:
  Tail queue packet drops: 0
  Traffic statistics:
    Input bytes :          0

```

```
Output bytes : 0
Input packets: 0
Output packets: 0

Logical interface at-0/3/1.32767 (Index 79) (SNMP ifIndex 76) (Generation 21)
Flags: Point-To-Multipoint Copy-PLP-To-CLP No-Multicast SNMP-Traps 0x4000
Encapsulation: ATM-VCMUX
Traffic statistics:
  Input bytes : 660
  Output bytes : 5473
  Input packets: 11
  Output packets: 83
Local statistics:
  Input bytes : 660
  Output bytes : 5473
  Input packets: 11
  Output packets: 83
VCI 0.16
  Flags: Active, ILMI
  Total down time: 0 sec, Last down: Never
  EPD threshold: 0, Transmit weight cells: 0
  ATM per-VC transmit statistics:
  Tail queue packet drops: 0
  Traffic statistics:
    Input bytes : 0
    Output bytes : 4320
    Input packets: 0
    Output packets: 72
VCI 0.4
  Flags: Active, OAM
  OAM, Period 30 sec, Up count: 10, Down count: 10
  Total down time: 0 sec, Last down: Never
  EPD threshold: 2129, Transmit weight cells: 0
  ATM per-VC transmit statistics:
  Tail queue packet drops: 0
  Traffic statistics:
    Input bytes : 572
    Output bytes : 572
    Input packets: 11
    Output packets: 11
  OAM F4 cell statistics:
    Total received: 11, Total sent: 11
    Loopback received: 11, Loopback sent: 11
    Last received: 00:00:18, Last sent: 00:00:18
    RDI received: 0, RDI sent: 0
    AIS received: 0, AIS sent: 0
```

## show interfaces (ATM-over-ADSL)

<b>Syntax</b>	<pre>show interfaces at-pim/0/port &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers) Display status information about the specified ATM-over-asynchronous DSL (ADSL) interface.
<b>Options</b>	<p><b>at-pim/0/port</b>—Display standard information about the specified ADSL interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display the SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (ATM-over-ADSL) on page 675</a></p> <p><a href="#">show interfaces brief (ATM-over-ADSL) on page 675</a></p> <p><a href="#">show interfaces detail (ATM-over-ADSL) on page 676</a></p> <p><a href="#">show interfaces extensive (ATM-over-ADSL) on page 677</a></p>
<b>Output Fields</b>	Table 103 on page 673 lists only output fields that are specific to the <b>show interfaces</b> (ATM-over-ADSL) command. For information about all other output fields, see Table 92 under the <a href="#">show interfaces (ATM)</a> command.

Table 103: ATM-over-ADSL show interfaces Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
ADSL alarms	Number and type of ADSL alarms. See “ADSL media” for details.	detail extensive none
ADSL defects	Number and type of ADSL defects. See “ADSL media” for details.	detail extensive none

Table 103: ATM-over-ADSL show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>ADSL status</b>	<p>Operational information for ATM-over-ADSL interfaces.</p> <ul style="list-style-type: none"> <li>• <b>Modem status</b>—Status of the modem: <b>Down</b>, <b>Training</b>, or <b>Showtime</b>.</li> <li>• <b>DSL mode</b>—Configured line type of the digital subscriber line: <b>adsl2plus</b>, <b>ansi-dmt</b>, <b>auto</b>, <b>itu-dmt</b>, or <b>itu-dmt-bis</b>.</li> <li>• <b>Last fail code</b>—Reason for failure: <b>ATU-C not detected</b>, <b>incompatible line condition</b>, <b>protocol error</b>, <b>message error</b>, <b>spurious ATU detected</b>, <b>forced silence</b>, <b>unselectable operation mode</b>, or <b>none</b>.</li> <li>• <b>Subfunction</b>—Specified analog front-end chip and discrete front.</li> <li>• <b>Seconds in showtime</b>—Number of seconds the ADSL connection is in showtime.</li> </ul>	<b>detail extensive none</b>
<b>ADSL media</b>	<p>Information about ADSL media-specific defects that can prevent the interface from passing packets. The following information is displayed for each defect:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. A state other than <b>OK</b> indicates a problem.</li> </ul> <p>The possible defects are as follows:</p> <ul style="list-style-type: none"> <li>• <b>LOF</b>—Loss of frame.</li> <li>• <b>LOS</b>—Loss of signal.</li> <li>• <b>LOM</b>—Loss of multiframe.</li> <li>• <b>LOP</b>—Loss of pointer.</li> <li>• <b>LOCDI</b>—Loss of cell delineation for an interleaved channel.</li> <li>• <b>LOCDNI</b>—Loss of cell delineation for a noninterleaved channel.</li> </ul>	<b>extensive</b>
<b>ADSL Statistics</b>	<p>Information about the ADSL terminal unit-remote (ATU-R) at the far end of the connection and the ADSL terminal unit-central office (ATU-C) at the near end:</p> <ul style="list-style-type: none"> <li>• <b>Attenuation (dB)</b>—Attenuation in decibels.</li> <li>• <b>Capacity used (%)</b>—Percentage of capacity used.</li> <li>• <b>Noise margin (dB)</b>—Maximum extraneous signal allowed without causing the output to deviate from an allowable level, in decibels.</li> <li>• <b>Output power (dBm)</b>—Amount of power used by the ATM-over-ADSL interface.</li> <li>• <b>Bit rate (kbps)</b>—Speed of data transfer on the ATM-over-ADSL interface, in kilobits per second.</li> <li>• <b>CRC</b>—Number of cyclic redundancy check errors.</li> <li>• <b>FEC</b>—Number of forward error corrections.</li> <li>• <b>HEC</b>—Number of header error checksums.</li> <li>• <b>Received cells</b>—Number of cells received through the interface.</li> <li>• <b>Transmitted cells</b>—Number of cells sent through the interface.</li> </ul>	<b>detail extensive</b>

## Sample Output

### show interfaces (ATM-over-ADSL)

```

user@host> show interfaces at-5/0/0
Physical interface: at-5/0/0, Enabled, Physical link is Down
  Interface index: 149, SNMP ifIndex: 68
  Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, ADSL mode,
  Speed: ADSL2+, Loopback: None
  Device flags   : Present Running Down
  Link flags     : None
  CoS queues     : 8 supported, 8 in use
  Current address: 00:05:85:c3:85:84
  Last flapped   : 2005-12-19 15:36:02 PST (12w0d 18:33 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  ADSL alarms    : None
  ADSL defects   : None
  ADSL status:
    Modem status : Training
    DSL mode      : Adsl2plus Annex A
    Last fail code: ATU-C not detected
    Subfunction   : 0x00
    Seconds in showtime : 0

Logical interface at-5/0/0.0 (Index 70) (SNMP ifIndex 71)
  Flags: Device-Down Point-To-Multipoint SNMP-Traps 0x4000
  Encapsulation: Ether-over-ATM-LLC
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 1500
  Flags: None
  VCI 0.128
  Flags: Active, Multicast
  Total down time: 0 sec, Last down: Never
  Input packets : 0
  Output packets: 0

Logical interface at-5/0/0.32767 (Index 71) (SNMP ifIndex 70)
  Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
  Encapsulation: ATM-VCMUX
  Input packets : 0
  Output packets: 0
  VCI 0.4
  Flags: Active
  Total down time: 0 sec, Last down: Never
  Input packets : 0
  Output packets: 0

```

### show interfaces brief (ATM-over-ADSL)

```

user@host> show interfaces at-5/0/0 brief
Physical interface: at-5/0/0, Enabled, Physical link is Down
  Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, ADSL mode,
  Speed: ADSL2+, Loopback: None
  Device flags   : Present Running Down
  Link flags     : None
Logical interface at-5/0/0.0
  Flags: Device-Down Point-To-Multipoint SNMP-Traps 0x4000
  Encapsulation: Ether-over-ATM-LLC
  inet
  VCI 0.128
  Flags: Active, Multicast

```

Total down time: 0 sec, Last down: Never

Logical interface at-5/0/0.32767

Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000

Encapsulation: ATM-VCMUX

VCI 0.4

Flags: Active

Total down time: 0 sec, Last down: Never

### show interfaces detail (ATM-over-ADSL)

user@host> show interfaces at-5/0/0 detail

Physical interface: at-5/0/0, Enabled, Physical link is Down

Interface index: 149, SNMP ifIndex: 68, Generation: 30

Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, ADSL mode,

Speed: ADSL2+, Loopback: None

Device flags : Present Running Down

Link flags : None

CoS queues : 8 supported, 8 in use

Hold-times : Up 0 ms, Down 0 ms

Current address: 00:05:85:c3:85:84

Last flapped : 2005-12-19 15:36:02 PST (12w0d 18:33 ago)

Statistics last cleared: Never

Traffic statistics:

Input bytes :	0	0 bps
Output bytes :	0	0 bps
Input packets:	0	0 pps
Output packets:	0	0 pps

Queue counters:	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	0	0	0
4 be-class	0	0	0
5 ef-class	0	0	0
6 af-class	0	0	0

ADSL alarms : None

ADSL defects : None

ADSL status:

Modem status : Training

DSL mode : Adsl2plus Annex A

Last fail code: ATU-C not detected

Subfunction : 0x00

Seconds in showtime : 0

ADSL Statistics:	ATU-R	ATU-C
Attenuation (dB) :	0.0	0.0
Capacity used (%) :	0	0
Noise margin (dB) :	0.0	0.0
Output power (dBm) :	0.0	0.0

	Interleave	Fast	Interleave	Fast
Bit rate (kbps) :	0	0	0	0
CRC :	0	0	0	0
FEC :	0	0	0	0
HEC :	0	0	0	0

```

Received cells      :          0          0
Transmitted cells   :          0          0

```

Logical interface at-5/0/0.0 (Index 70) (SNMP ifIndex 71) (Generation 8)

Flags: Device-Down Point-To-Multipoint SNMP-Traps 0x4000

Encapsulation: Ether-over-ATM-LLC

Traffic statistics:

```

Input bytes  :          0
Output bytes  :          0
Input packets:          0
Output packets:         0

```

Local statistics:

```

Input bytes  :          0
Output bytes  :          0
Input packets:          0
Output packets:         0

```

Transit statistics:

```

Input bytes  :          0          0 bps
Output bytes  :          0          0 bps
Input packets:          0          0 pps
Output packets:         0          0 pps

```

Protocol inet, MTU: 1500, Generation: 12, Route table: 0

Flags: None

VCI 0.128

Flags: Active, Multicast

Total down time: 0 sec, Last down: Never

ATM per-VC transmit statistics:

Tail queue packet drops: 0

Traffic statistics:

```

Input bytes  :          0
Output bytes  :          0
Input packets:          0
Output packets:         0

```

Logical interface at-5/0/0.32767 (Index 71) (SNMP ifIndex 70) (Generation 9)

Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000

Encapsulation: ATM-VCMUX

Traffic statistics:

```

Input bytes  :          0
Output bytes  :          0
Input packets:          0
Output packets:         0

```

Local statistics:

```

Input bytes  :          0
Output bytes  :          0
Input packets:          0
Output packets:         0

```

VCI 0.4

Flags: Active

Total down time: 0 sec, Last down: Never

ATM per-VC transmit statistics:

Tail queue packet drops: 0

Traffic statistics:

```

Input bytes  :          0
Output bytes  :          0
Input packets:          0
Output packets:         0

```

**show interfaces  
extensive**

user@host> **show interfaces at-5/0/0 extensive**

Physical interface: at-5/0/0, Enabled, Physical link is Down

Interface index: 149, SNMP ifIndex: 68, Generation: 30

## (ATM-over-ADSL)

Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, ADSL mode,  
 Speed: ADSL2+, Loopback: None  
 Device flags : Present Running Down  
 Link flags : None  
 CoS queues : 8 supported, 8 in use  
 Hold-times : Up 0 ms, Down 0 ms  
 Current address: 00:05:85:c3:85:84  
 Last flapped : 2005-12-19 15:36:02 PST (12w0d 18:34 ago)  
 Statistics last cleared: Never

## Traffic statistics:

Input bytes :	0	0 bps
Output bytes :	0	0 bps
Input packets:	0	0 pps
Output packets:	0	0 pps

## Input errors:

Errors: 0, Drops: 0, Invalid VCs: 0, Framing errors: 0, Policed discards: 0,  
 L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0, Resource  
 errors: 0

## Output errors:

Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,  
 Resource errors: 0

Queue counters:	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	0	0	0
4 be-class	0	0	0
5 ef-class	0	0	0
6 af-class	0	0	0

ADSL alarms : None

ADSL defects : None

ADSL media:	Seconds	Count	State
LOF	0	0	OK
LOS	0	0	OK
LOM	0	0	OK
LOP	0	0	OK
LOCDI	0	0	OK
LOCDNI	0	0	OK

## ADSL status:

Modem status : Training  
 DSL mode : Adsl2plus Annex A  
 Last fail code: ATU-C not detected  
 Subfunction : 0x00  
 Seconds in showtime : 0

ADSL Statistics:	ATU-R	ATU-C
Attenuation (dB) :	0.0	0.0
Capacity used (%) :	0	0
Noise margin (dB) :	0.0	0.0
Output power (dBm) :	0.0	0.0

	Interleave	Fast	Interleave	Fast
Bit rate (kbps) :	0	0	0	0
CRC :	0	0	0	0



```

FEC          :          0          0          0          0
HEC          :          0          0          0          0
Received cells :          0          0
Transmitted cells :          0          0
ATM status:
HCS state:    Hunt
LOC          :    OK
ATM Statistics:
Uncorrectable HCS errors: 0, Correctable HCS errors: 0,
Tx cell FIFO overruns: 0, Rx cell FIFO overruns: 0,
Rx cell FIFO underruns: 0, Input cell count: 0, Output cell count: 0,
Output idle cell count: 0, Output VC queue drops: 0, Input no buffers: 0,
Input length errors: 0, Input timeouts: 0, Input invalid VCs: 0,
Input bad CRCs: 0, Input OAM cell no buffers: 0
Packet Forwarding Engine configuration:
Destination slot: 5
CoS information:
CoS transmit queue      Bandwidth      Buffer      Priority      Limit
                        %          bps          %          usec
0 best-effort           95      7600000    95           0          low      none
3 network-control       5       400000     5           0          low      none

Logical interface at-5/0/0.0 (Index 70) (SNMP ifIndex 71) (Generation 8)
Flags: Device-Down Point-To-Multipoint SNMP-Traps 0x4000
Encapsulation: Ether-over-ATM-LLC
Traffic statistics:
Input bytes :          0
Output bytes :          0
Input packets:          0
Output packets:          0
Local statistics:
Input bytes :          0
Output bytes :          0
Input packets:          0
Output packets:          0
Transit statistics:
Input bytes :          0          0 bps
Output bytes :          0          0 bps
Input packets:          0          0 pps
Output packets:          0          0 pps
Protocol inet, MTU: 1500, Generation: 12, Route table: 0
Flags: None
VCI 0.128
Flags: Active, Multicast
Total down time: 0 sec, Last down: Never
ATM per-VC transmit statistics:
Tail queue packet drops: 0
Traffic statistics:
Input bytes :          0
Output bytes :          0
Input packets:          0
Output packets:          0
Logical interface at-5/0/0.32767 (Index 71) (SNMP ifIndex 70) (Generation 9)
Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
Encapsulation: ATM-VCMUX
Traffic statistics:
Input bytes :          0
Output bytes :          0
Input packets:          0
Output packets:          0
Local statistics:

```

```
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
VCI 0.4
Flags: Active
Total down time: 0 sec, Last down: Never
ATM per-VC transmit statistics:
Tail queue packet drops: 0
Traffic statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
```

## show interfaces (ATM-over-SHDSL)

---

<b>Syntax</b>	<pre>show interfaces at-pim/0/port &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers) Display status information about the specified ATM-over-symmetric high-speed DSL (SHDSL) interface.
<b>Options</b>	<p><b>at-pim/0/port</b>—Display standard information about the specified SHDSL interface</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display the SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (ATM-over-SHDSL) on page 684</a></p> <p><a href="#">show interfaces brief (ATM-over-SHDSL) on page 684</a></p> <p><a href="#">show interfaces detail (ATM-over-SHDSL) on page 685</a></p> <p><a href="#">show interfaces extensive (ATM-over-SHDSL) on page 687</a></p>
<b>Output Fields</b>	Table 104 on page 682 lists only output fields that are specific to the <b>show interfaces</b> (ATM-over-SHDSL) command. For information about all other output fields, see Table 92 under the <a href="#">show interfaces (ATM)</a> command.

Table 104: ATM-over-SHDSL show interfaces Output Fields

Field Name	Field Description	Level of Output
SHDSL alarms	Number and type of SHDSL alarms. See "SHDSL media" for details.	detail extensive none
SHDSL defects	Number and type of SHDSL defects. See "SHDSL media" for details.	detail extensive none
SHDSL media	<p>Information about the SHDSL media-specific defects that can prevent the interface from passing packets. The following information is displayed for each defect:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. A state other than <b>OK</b> indicates a problem.</li> </ul> <p>The possible defects are as follows:</p> <ul style="list-style-type: none"> <li>• <b>LOSD</b>—Loss of signal was detected at the remote application interface.</li> <li>• <b>LOSW</b>—Loss of sync word. A message ID was sent.</li> <li>• <b>ES</b>—Errored seconds. One or more cyclic redundancy check (CRC) anomalies were detected.</li> <li>• <b>SES</b>—Severely errored seconds. At least 50 CRC anomalies were detected.</li> <li>• <b>UAS</b>—Unavailable seconds. An interval occurred during which one or more LOSW defects were detected.</li> </ul>	extensive
SHDSL status	<p>Operational information for ATM-over-SHDSL interfaces.</p> <ul style="list-style-type: none"> <li>• <b>Line termination</b>—SHDLS transceiver unit- remote (STU-R) (Only customer premises equipment is supported.)</li> <li>• <b>Annex</b>—Either Annex A or Annex B. Annex A is supported in North America, and Annex B is supported in Europe.</li> <li>• <b>Line mode</b>—SHDSL mode configured on the G.SHDSL Physical Interface Module (PIM), either 2-wire or 4-wire.</li> <li>• <b>Modem status</b>—Data.</li> <li>• <b>Bit rate (kbps)</b>—Speed of data transfer on the ATM-over-G.SHDSL interface, in kilobits per second.</li> <li>• <b>Last fail mode</b>—Code for the last interface failure.</li> <li>• <b>Framer mode</b>—Framer mode of the underlying interface: ATM.</li> <li>• <b>Dying gasp</b>—Ability of a J Series router that has lost power to send a message informing the attached DSL access multiplexer (DSLAM) that it is about to go offline: <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Framer sync status</b>—Framer synchronization status: <b>In sync</b> or <b>Out of sync (OOS)</b>.</li> <li>• <b>Chipset version</b>—Version number of the chipset on the interface.</li> <li>• <b>Firmware version</b>—Version number of the firmware on the interface.</li> </ul>	detail extensive none

Table 104: ATM-over-SHDSL show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
SHDSL statistics	<ul style="list-style-type: none"> <li>• <b>Loop Attenuation (dB)</b>—Attenuation in decibels.</li> <li>• <b>Transmit power (dBm)</b>—Power of the transmitting interface.</li> <li>• <b>Receiver gain (db)</b>—Power increase of the receiving interface, in decibels.</li> <li>• <b>SNR sampling (dB)</b>—Signal-to-noise ratio at a receiver point, in decibels.</li> <li>• <b>CRC errors</b>—Number of cyclic redundancy check errors.</li> <li>• <b>SEGA errors</b>—Number of segment anomaly errors. A regenerator operating on a segment received corrupted data.</li> <li>• <b>LOSW errors</b>—Number of loss of signal defect errors. Three or more consecutively received frames contained one or more errors in the framing bits.</li> <li>• <b>Received cells</b>—Number of cells received through the interface.</li> <li>• <b>Transmitted cells</b>—Number of cells sent through the interface.</li> <li>• <b>HEC errors</b>—Number of header error checksum errors.</li> <li>• <b>Cell Drop</b>—Number of dropped cells on the interface.</li> </ul>	detail extensive

## Sample Output

### show interfaces (ATM-over-SHDSL)

```

user@host> show interfaces at-4/0/0
Physical interface: at-4/0/0, Enabled, Physical link is Down
  Interface index: 141, SNMP ifIndex: 41
  Link-level type: Ethernet-over-ATM, MTU: 4482, Clocking: Internal,
  Speed: SHDSL(2-wire), Loopback: None
  Device flags   : Present Running Down
  Link flags     : None
  CoS queues     : 8 supported, 8 in use
  Current address: 00:05:85:c2:44:60
  Last flapped   : 2006-03-21 15:07:11 PST (2w0d 00:59 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  SHDSL alarms   : LOSD
  SHDSL defects  : LOSD
  SHDSL status:
    Line termination : STU-R
    Annex             : Unknown
    Line mode         : 2-wire
    Modem status      : Training
    Bit rate (kbps)   : 0
    Last fail mode    : No failure (0x00)
    Frammer mode      : ATM
    Dying gasp        : Enabled
    Frammer sync status : Out of sync
    Chipset version   : 00
    Firmware version  : R3.0.1

Logical interface at-4/0/0.0 (Index 68) (SNMP ifIndex 44)
  Flags: Device-Down Point-To-Point SNMP-Traps 0x4000
  Encapsulation: Ether-over-ATM-LLC
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 1500
  Flags: None
  VCI 0.128
  Flags: Active
  Total down time: 0 sec, Last down: Never
  Input packets : 0
  Output packets: 0
Logical interface at-4/0/0.32767 (Index 69) (SNMP ifIndex 43)
  Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
  Encapsulation: ATM-VCMUX
  Input packets : 0
  Output packets: 0
  VCI 0.4
  Flags: Active
  Total down time: 0 sec, Last down: Never
  Input packets : 0
  Output packets: 0

```

### show interfaces brief (ATM-over-SHDSL)

```

user@host> show interfaces at-4/0/0 brief
Physical interface: at-4/0/0, Enabled, Physical link is Down
  Link-level type: Ethernet-over-ATM, MTU: 4482, Clocking: Internal,
  Speed: SHDSL(2-wire), Loopback: None
  Device flags   : Present Running Down
  Link flags     : None

```

```

Logical interface at-4/0/0.0
  Flags: Device-Down Point-To-Point SNMP-Traps 0x4000
  Encapsulation: Ether-over-ATM-LLC
  inet
  VCI 0.128
    Flags: Active
    Total down time: 0 sec, Last down: Never

Logical interface at-4/0/0.32767
  Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
  Encapsulation: ATM-VCMUX
  VCI 0.4
    Flags: Active
    Total down time: 0 sec, Last down: Never

```

#### show interfaces detail (ATM-over-SHDSL)

```

user@host> show interfaces at-4/0/0 detail
Physical interface: at-4/0/0, Enabled, Physical link is Down
  Interface index: 141, SNMP ifIndex: 41, Generation: 22
  Link-level type: Ethernet-over-ATM, MTU: 4482, Clocking: Internal,
  Speed: SHDSL(2-wire), Loopback: None
  Device flags   : Present Running Down
  Link flags     : None
  CoS queues     : 8 supported, 8 in use
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:05:85:c2:44:60
  Last flapped   : 2006-03-21 15:07:11 PST (2w0d 01:00 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   : 0          0 bps
    Output bytes  : 0          0 bps
    Input packets : 0          0 pps
    Output packets: 0          0 pps
  Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	0	0	0

```

  SHDSL alarms   : LOSD
  SHDSL defects  : LOSD
  SHDSL status:
    Line termination : STU-R
    Annex            : Unknown
    Line mode         : 2-wire
    Modem status      : Training
    Bit rate (kbps)   : 0
    Last fail mode    : No failure (0x00)
    Framers mode      : ATM
    Dying gasp        : Enabled
    Framers sync status : Out of sync
    Chipset version    : 00
    Firmware version   : R3.0.1
  SHDSL statistics:
    Loop attenuation (dB) : 2.3
    Transmit power (dBm)  : 0.0
    Receiver gain (dB)    : 20.412
    CRC errors            : 0

```

```

SEGA errors      : 0
LOSW errors      : 0
Received cells   : 0
Transmitted cells : 0
HEC errors       : 0
Cell drop        : 0

```

Logical interface at-4/0/0.0 (Index 68) (SNMP ifIndex 44) (Generation 8)

Flags: Device-Down Point-To-Point SNMP-Traps 0x4000

Encapsulation: Ether-over-ATM-LLC

Traffic statistics:

```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

Local statistics:

```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

Transit statistics:

```

Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps

```

Protocol inet, MTU: 1500, Generation: 11, Route table: 0

Flags: None

VCI 0.128

Flags: Active

Total down time: 0 sec, Last down: Never

ATM per-VC transmit statistics:

Tail queue packet drops: 0

Traffic statistics:

```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

Logical interface at-4/0/0.32767 (Index 69) (SNMP ifIndex 43) (Generation 9)

Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000

Encapsulation: ATM-VCMUX

Traffic statistics:

```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

Local statistics:

```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```

VCI 0.4

Flags: Active

Total down time: 0 sec, Last down: Never

ATM per-VC transmit statistics:

Tail queue packet drops: 0

Traffic statistics:

```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0

```



**show interfaces  
extensive  
(ATM-over-SHDSL)**

```

user@host> show interfaces at-4/0/0 extensive
Physical interface: at-4/0/0, Enabled, Physical link is Down
Interface index: 141, SNMP ifIndex: 41, Generation: 22
Link-level type: Ethernet-over-ATM, MTU: 4482, Clocking: Internal,
Speed: SHDSL(2-wire), Loopback: None
Device flags   : Present Running Down
Link flags     : None
CoS queues     : 8 supported, 8 in use
Hold-times    : Up 0 ms, Down 0 ms
Current address: 00:05:85:c2:44:60
Last flapped   : 2006-03-21 15:07:11 PST (2w0d 01:02 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :                0                0 bps
  Output bytes  :                0                0 bps
  Input packets :                0                0 pps
  Output packets:                0                0 pps
Input errors:
  Errors: 0, Drops: 0, Invalid VCs: 0, Framing errors: 0, Policed discards: 0,

  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,

  Resource errors: 0
Queue counters:
  Queued packets  Transmitted packets  Dropped packets

  0 best-effort   0                0                0
  1 expedited-fo  0                0                0
  2 assured-forw  0                0                0
  3 network-cont  0                0                0

SHDSL alarms   : LOSD
SHDSL defects  : LOSD
SHDSL media:
  Seconds      Count  State
  LOSD         1228405  1 Defect Active
  LOSW         0        0 OK
  ES           0
  SES          0
  UAS          1228402
SHDSL status:
  Line termination : STU-R
  Annex            : Unknown
  Line mode        : 2-wire
  Modem status     : Training
  Bit rate (kbps)  : 0
  Last fail mode   : No failure (0x00)
  Framing mode     : ATM
  Dying gasp       : Enabled
  Framing sync status : Out of sync
  Chipset version  : 00
  Firmware version : R3.0.1
SHDSL statistics:
  Loop attenuation (dB) : 2.3
  Transmit power (dBm) : 0.0
  Receiver gain (dB)   : 20.412
  CRC errors           : 0

```

```

SEGA errors          : 0
LOSW errors          : 0
Received cells       : 0
Transmitted cells    : 0
HEC errors           : 0
Cell drop            : 0
Packet Forwarding Engine configuration:
  Destination slot: 4
CoS information:
  CoS transmit queue      Bandwidth      Buffer      Priority  Limit
                           %      bps      %      usec
0 best-effort             95      2196400  95      0      low     none
3 network-control         5      115600   5      0      low     none

Logical interface at-4/0/0.0 (Index 68) (SNMP ifIndex 44) (Generation 8)
Flags: Device-Down Point-To-Point SNMP-Traps 0x4000
Encapsulation: Ether-over-ATM-LLC
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Transit statistics:
  Input bytes : 0 0 bps
  Output bytes : 0 0 bps
  Input packets: 0 0 pps
  Output packets: 0 0 pps
Protocol inet, MTU: 1500, Generation: 11, Route table: 0
  Flags: None
VCI 0.128
  Flags: Active
  Total down time: 0 sec, Last down: Never
  ATM per-VC transmit statistics:
  Tail queue packet drops: 0
  Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0

Logical interface at-4/0/0.32767 (Index 69) (SNMP ifIndex 43) (Generation 9)
Flags: Device-Down Point-To-Multipoint No-Multicast SNMP-Traps 0x4000
Encapsulation: ATM-VCMUX
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
VCI 0.4
  Flags: Active
  Total down time: 0 sec, Last down: Never

```

```
ATM per-VC transmit statistics:
  Tail queue packet drops: 0
Traffic statistics:
  Input bytes :           0
  Output bytes :          0
  Input packets:          0
  Output packets:         0
```



# ILMI Interface Operational Mode Commands

Table 105 on page 691 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot Integrated Local Management Interface (ILMI) operations on ATM1 and ATM2 intelligent queuing (IQ) interfaces. Commands are listed in alphabetical order.

**Table 105: ILMI Operational Mode Commands**

Task	Command
Clear (set to zero) ILMI statistics.	<code>clear ilmi statistics</code>
Display ILMI messages.	<code>show ilmi</code>
Display ILMI statistics.	<code>show ilmi statistics</code>

## clear ilmi statistics

---

<b>Syntax</b>	clear ilmi statistics
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Set Integrated Local Management Interface (ILMI) statistics to zero.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	clear
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show ilmi statistics on page 694</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear ilmi statistics on page 692</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

`clear ilmi statistics`      user@host> `clear ilmi statistics`

## show ilmi

<b>Syntax</b>	<code>show ilmi</code> <code>&lt;all   interface <i>interface-name</i>&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display Integrated Local Management Interface (ILMI) information.
<b>Options</b>	<p><b>none</b>—Display information for all ILMI-enabled ATM devices.</p> <p><b>all   interface <i>interface-name</i></b>—(Optional) Display IP addresses and port names for all ILMI-enabled ATM devices or for a particular device.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show ilmi all on page 693</a> <a href="#">show ilmi interface on page 693</a>
<b>Output Fields</b>	Table 106 on page 693 lists the output fields for the <b>show ilmi</b> command. Output fields are listed in the approximate order in which they appear.

**Table 106: show ilmi Output Fields**

Field Name	Field Description
Physical interface	Name of the physical interface.
VCI	Virtual connection identifier.
Peer IP address	IP address of the peer.
Peer interface name	Port interface name of the peer.

## Sample Output

### show ilmi all

```
user@host> show ilmi all
Physical interface: at-6/2/1, VCI: 0.16
Peer IP address: 192.168.4.24, Peer interface name: 1C4
Physical interface: at-6/3/0, VCI: 0.16
Peer IP address: 192.168.7.6, Peer interface name: 2C3
Physical interface: at-6/4/0, VCI: 0.16
Peer IP address: 192.168.9.10, Peer interface name: 1C2
```

### show ilmi interface

```
user@host> show ilmi interface at-6/2/1
Physical interface: at-6/2/1, VCI: 0.16
Peer IP address: 192.168.4.24, Peer interface name: 1C4
```

## show ilmi statistics

---

<b>Syntax</b>	show ilmi statistics
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display input and output Integrated Local Management Interface (ILMI) statistics.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">clear ilmi statistics on page 692</a></li></ul>
<b>List of Sample Output</b>	<a href="#">show ilmi statistics on page 696</a>
<b>Output Fields</b>	<a href="#">Table 107 on page 695</a> lists the output fields for the <b>show ilmi statistics</b> command. Output fields are listed in the approximate order in which they appear.



Table 107: show ilmi statistics Output Fields

Field Name	Field Description
<b>Input</b>	<p>Information about received ILMI packets:</p> <ul style="list-style-type: none"> <li>• <b>Packets</b>—Total number of messages delivered to the ILMI entity from the transport service.</li> <li>• <b>Bad versions</b>—Total number of messages delivered to the ILMI entity that were for an unsupported ILMI version.</li> <li>• <b>Bad community names</b>—Total number of messages delivered to the ILMI entity that did not use an ILMI community name.</li> <li>• <b>Bad community uses</b>—Total number of messages delivered to the ILMI entity that represented an ILMI operation that was not allowed by the ILMI community named in the message.</li> <li>• <b>ASN parse errors</b>—Total number of ASN.1 or BER errors encountered by the ILMI entity when decoding received ILMI messages.</li> <li>• <b>Too bigs</b>—Total number of ILMI packets delivered to the ILMI entity with an error status field of <b>tooBig</b>.</li> <li>• <b>No such names</b>—Total number of ILMI packets delivered to the ILMI entity with an error status field of <b>noSuchName</b>.</li> <li>• <b>Bad values</b>—Total number of ILMI packets delivered to the ILMI entity with an error status field of <b>badValue</b>.</li> <li>• <b>Read onlys</b>—Total number of valid ILMI packets delivered to the ILMI entity with an error status field of <b>readOnly</b>. Only incorrect implementations of ILMI generate this error.</li> <li>• <b>General errors</b>—Total number of ILMI packets delivered to the ILMI entity with an error status field of <b>genErr</b>.</li> <li>• <b>Total request varbinds</b>—Total number of objects retrieved successfully by the ILMI entity as a result of receiving valid ILMI <b>GetRequest</b> and <b>GetNext</b> packets.</li> <li>• <b>Total set varbinds</b>—Total number of objects modified successfully by the ILMI entity as a result of receiving valid ILMI <b>SetRequest</b> packets.</li> <li>• <b>Get requests</b>—Total number of ILMI <b>GetRequest</b> packets that have been accepted and processed by the ILMI entity.</li> <li>• <b>Get nexts</b>—Total number of ILMI <b>GetNext</b> packets that have been accepted and processed by the ILMI entity.</li> <li>• <b>Set requests</b>—Total number of ILMI <b>SetRequest</b> packets that have been accepted and processed by the ILMI entity.</li> <li>• <b>Get responses</b>—Total number of ILMI <b>GetResponse</b> packets that have been accepted and processed by the ILMI entity.</li> <li>• <b>Traps</b>—Total number of ILMI traps received by the ILMI entity.</li> <li>• <b>Silent drops</b>—Total number of <b>GetRequest</b>, <b>GetNextRequest</b>, <b>GetBulkRequest</b>, <b>SetRequest</b>, and <b>InformRequest</b> packets delivered to the ILMI entity that were silently dropped because the size of a reply containing an alternate response packet with an empty variable-bindings field was greater than either a local constraint or the maximum message size associated with the originator of the requests.</li> <li>• <b>Proxy drops</b>—Total number of <b>GetRequest</b>, <b>GetNextRequest</b>, <b>GetBulkRequest</b>, <b>SetRequest</b>, and <b>InformRequest</b> packets delivered to the ILMI entity that were silently dropped because the transmission of the (possibly translated) message to a proxy target failed in such a way (other than a timeout) that no response packet could be returned.</li> </ul>
<b>Output</b>	<p>Information about transmitted ILMI packets:</p> <ul style="list-style-type: none"> <li>• <b>Packets</b>—Total number of messages passed from the ILMI entity to the transport service.</li> <li>• <b>Too bigs</b>—Total number of ILMI packets generated by the ILMI entity with an error status field of <b>tooBig</b>.</li> <li>• <b>No such names</b>—Total number of ILMI packets generated by the ILMI entity with an error status field of <b>noSuchName</b>.</li> <li>• <b>Bad values</b>—Total number of ILMI packets generated by the ILMI entity with an error status field of <b>badValue</b>.</li> <li>• <b>General errors</b>—Total number of ILMI packets generated by the ILMI entity with an error status field of <b>genErr</b>.</li> <li>• <b>Get requests</b>—Total number of ILMI <b>GetRequest</b> packets that have been generated by the ILMI entity.</li> <li>• <b>Get nexts</b>—Total number of ILMI <b>GetNext</b> packets that have been generated by the ILMI entity.</li> <li>• <b>Set requests</b>—Total number of ILMI <b>SetRequest</b> packets that have been generated by the ILMI entity.</li> <li>• <b>Get responses</b>—Total number of ILMI <b>GetResponse</b> packets that have been generated by the ILMI entity.</li> <li>• <b>Traps</b>—Total number of ILMI traps generated by the ILMI entity.</li> </ul>

## Sample Output

**show ilmi statistics**

```
user@host> show ilmi statistics
ILMI statistics:
Input:
  Packets: 0, Bad versions: 0, Bad community names: 0,
  Bad community uses: 0, ASN parse errors: 0,
  Too bigs: 0, No such names: 0, Bad values: 0,
  Read onlys: 0, General errors: 0,
  Total request varbinds: 0, Total set varbinds: 0,
  Get requests: 0, Get nexts: 0, Set requests: 0,
  Get responses: 0, Traps: 0,
  Silent drops: 0, Proxy drops 0
Output:
  Packets: 0, Too bigs: 0, No such names: 0,
  Bad values: 0, General errors: 0,
  Get requests: 0, Get nexts: 0, Set requests: 0,
  Get responses: 0, Traps: 0
```

## PART 9

# ISDN Interfaces

- [ISDN Interface Operational Mode Commands on page 699](#)



# ISDN Interface Operational Mode Commands

Table 108 on page 699 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot Integrated Services Digital Network (ISDN) interfaces. Commands are listed in alphabetical order.

**Table 108: ISDN Interface Operational Mode Commands**

Task	Command
Clear ISDN Q.921 statistics.	<code>clear isdn q921 statistics</code>
Clear ISDN Q.931 statistics.	<code>clear isdn q931 statistics</code>
Display ISDN services default software values.	<code>show dialer defaults</code>
Display ISDN dialer interface information.	<code>show dialer interfaces</code>
Display ISDN dialer pool information.	<code>show dialer pools</code>
Display ISDN B-channel interface information.	<code>show interfaces (ISDN B-Channel)</code>
Display ISDN Basic Rate Interface (BRI) information.	<code>show interfaces (ISDN BRI)</code>
Display ISDN D-channel interface information.	<code>show interfaces (ISDN D-channel)</code>
Display ISDN dialer interface information.	<code>show interfaces (ISDN Dialer)</code>
Display ISDN calls.	<code>show isdn calls</code>
Display ISDN call history.	<code>show isdn history</code>
Display Layer 2 ISDN status and statistics.	<code>show isdn q921 statistics</code>
Display Layer 3 ISDN status and statistics.	<code>show isdn q931 statistics</code>
Display ISDN status information.	<code>show isdn status</code>



.....

**NOTE:** ISDN is supported on the J Series Services Routers only. J Series routers can be configured to "fail over" to an ISDN interface when the primary connection experiences interruptions in Internet connectivity. The following interfaces support ISDN backup connectivity: E1, E3, Fast Ethernet, generic routing encapsulation (GRE), Point-to-Point Protocol over Ethernet (PPPoE), serial, T1, and T3. For information about how to configure ISDN interfaces, see the *J Series Services Router Basic LAN and WAN Access Configuration Guide* or the *Junos Network Interfaces Configuration Guide*.

.....

## clear isdn q921 statistics

---

<b>Syntax</b>	clear isdn q921 statistics <br-pim/0/port>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Clear ISDN Layer 2 statistics based on the Q.921 standard.
<b>Options</b>	<b>none</b> —Clear ISDN Q.921 statistics for all Basic Rate Interface (BRI) interfaces. <b>br-pim/0/port</b> —(Optional) Clear ISDN Q.921 statistics for the specified BRI interface only.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show isdn q921 statistics on page 738</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear isdn q921 statistics on page 701</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

<code>clear isdn q921 statistics</code>	<code>user@host&gt; clear isdn q921 statistics</code>
---	---

## clear isdn q931 statistics

---

<b>Syntax</b>	clear isdn q931 statistics <br-pim/0/port>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Clear ISDN Layer 3 statistics based on the Q.931 standard.
<b>Options</b>	<b>none</b> —Clear ISDN Q.931 statistics for all Basic Rate Interface (BRI) interfaces. <b>br-pim/0/port</b> —(Optional) Clear ISDN Q.931 statistics for the specified BRI interface only.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show isdn q931 statistics on page 740</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear isdn q931 statistics on page 702</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

## Sample Output

clear isdn q931 statistics	user@host> clear isdn q931 statistics
----------------------------	---------------------------------------



## show dialer defaults

<b>Syntax</b>	show dialer defaults
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display ISDN services default software values.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show dialer defaults on page 704</a>
<b>Output Fields</b>	<a href="#">Table 109 on page 703</a> lists the output fields for the <b>show dialer defaults</b> command. Output fields are listed in the approximate order in which they appear.

**Table 109: show dialer defaults Output Fields**

Field Name	Field Description
Idle timeout	Length of time (in seconds) that a connection can be idle before disconnecting.
Activation delay	Length of time (in seconds) to wait before enabling the interface after the primary interface has failed.
Deactivation delay	Length of time (in seconds) to wait before disabling the interface after the primary interface is operational.
Dialer watch initial route check time	Length of time (in seconds) before a route is checked for status.
Dialer pool priority	Priority of the dialer interface.
Dialer load threshold	Bandwidth threshold percentage used for adding interfaces. Another link is added to the multilink bundle when the bandwidth reaches the threshold value you set. The range of values is 0 through 100. When the value is set to 0, all available channels are dialed. The default value is 100.
Dialer load interval	Interval used to calculate the average load on the network. The range of values, in seconds, is 20 through 180, configurable in intervals of 10 seconds. The default value is 60.
Dialer redial delay	Delay, in seconds, between two successive calls made by the dialer (for dialout). The default value is 3 seconds.
Dialer callback wait period	For interfaces configured for ISDN with callback, the amount of time the dialer waits before calling back the caller. The default value is 5 seconds.

## Sample Output

```
show dialer defaults      user@host> show dialer defaults
Dialer services related defaults :
  Idle timeout: 120 seconds
  Activation delay: 0 seconds
  Deactivation delay: 0 seconds
  Dialer watch initial route check time: 120 seconds
  Dialer pool priority: 0 seconds
  Dialer load threshold: 100%
  Dialer load interval: 60 seconds
  Dialer redial delay: 3 seconds
  Dialer callback wait period : 5 seconds
```

## show dialer interfaces

<b>Syntax</b>	<code>show dialer interfaces</code> <code>&lt;brief   detail&gt;</code> <code>&lt;dlnumber&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display ISDN dialer interface information.
<b>Options</b>	<p><b>none</b>—(Same as detail) Display detailed information about all ISDN dialer interfaces.</p> <p><b>brief   detail</b>—(Optional) Display the specified level of output.</p> <p><b>dlnumber</b>—(Optional) Display information about the specified dialer interface only.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show dialer interfaces on page 706</a> <a href="#">show dialer interfaces brief on page 706</a> <a href="#">show dialer interfaces detail on page 706</a>
<b>Output Fields</b>	<p>Table 110 on page 705 lists the output fields for the <b>show dialer interfaces</b> command.</p> <p>Output fields are listed in the approximate order in which they appear.</p>

Table 110: show dialer interfaces Output Fields

Field Name	Field Description	Level of Output
<i>Interface-name</i>	Dialer interface name.	All levels
<b>State</b>	State of the interface: <b>Active</b> or <b>Inactive</b>	All levels
<b>Dial pool</b>	Dial pool name.	All levels
<b>Dial strings</b>	Dialing number for the ISDN connection.	<b>detail none</b>
<b>Subordinate interfaces</b>	Associated B-channel or USB modem interface name and SNMP index number.	All levels
<b>Activation delay</b>	Length of time (in seconds) to wait before enabling the interface after the primary interface has failed.	<b>detail none</b>
<b>Deactivation delay</b>	Length of time (in seconds) to wait before disabling the interface after the primary interface is operational.	<b>detail none</b>
<b>Initial route check delay</b>	Wait period (in seconds) for the software to check if the primary interface is up after the router comes up. The range is from 1 through 300 seconds. The default is 120 seconds.	<b>detail none</b>

Table 110: show dialer interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Redial delay</b>	(Available on interfaces configured for ISDN dial-out.) Delay, in seconds, between two successive calls made. The range is from <b>2</b> to <b>255</b> . The default value is <b>3</b> .	<b>detail none</b>
<b>Callback wait period</b>	Time, in seconds, that the dialer waits before it calls back the caller ID. The default value is <b>5</b> .	<b>detail none</b>
<b>Load threshold</b>	Bandwidth threshold percentage used for adding interfaces. Another link is added to the multilink bundle when the load reaches the threshold value you set. The range of values is from <b>0</b> to <b>100</b> . The default value is <b>100</b> .	<b>detail none</b>
<b>Load interval</b>	Interval used to calculate the average load on the network. By default, the average interface load is calculated every 60 seconds.	<b>detail none</b>

## Sample Output

**show dialer interfaces**      user@host> **show dialer interfaces**

```
d10.0
  State: Active
  Dial Pool: 10
  Dial strings: 5551212
  Subordinate interfaces: bc-4/0/0:1 (Index 151)
  Activation delay: 0, Deactivation delay: 0
  Initial route check delay: 120
  Redial delay: 3
  Callback wait period: 5
  Load threshold: 0, Load interval: 60
```

**show dialer interfaces brief**      user@host> **show dialer interfaces brief**

```
d10.0
  State: Active
  Dial Pool: 10
  Subordinate interfaces: bc-4/0/0:1
```

**show dialer interfaces detail**      The output for the **show dialer interfaces detail** command is identical to that for the **show dialer interfaces** command. For sample output, see [show dialer interfaces on page 706](#).

## show dialer pools

<b>Syntax</b>	show dialer pools <brief   detail> <pool-name>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display dialer pool information. The dialer pool provides a group of dialing options for ISDN interfaces.
<b>Options</b>	<p><b>none</b>—(Same as detail) Display detailed information about all ISDN dialer pools.</p> <p><b>brief   detail</b>—(Optional) Display the specified level of output.</p> <p><b>pool-name</b>—(Optional) Display information about the specified dialer pool only.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show dialer pools on page 708</a> <a href="#">show dialer pools brief on page 708</a> <a href="#">show dialer pools detail on page 708</a>
<b>Output Fields</b>	Table 111 on page 707 lists the output fields for the <b>show dialer pools</b> command. Output fields are listed in the approximate order in which they appear.

Table 111: show dialer pools Output Fields

Field Name	Field Description	Level of Output
<b>Pool</b>	Name of the dialer pool.	All levels
<b>Dialer Interfaces</b>		
<b>Name</b>	Name of configured dialer interfaces.	All levels
<b>State</b>	Status of the dialer interface: <b>Active</b> or <b>Inactive</b>	All levels
<b>Subordinate Interfaces</b>		
<b>Name</b>	Name of each physical ISDN interface configured as part of the dialer interface.	All levels
<b>Flags</b>	Status of the physical B-channel interface.	All levels
<b>Priority</b>	Priority of the interface.	All levels

## Sample Output

### show dialer pools

```
user@host> show dialer pools
Pool: 10
  Dialer interfaces:      Name      State
                        d10.0      Active
  Subordinate interfaces: Name      Flags      Priority
                        bc-4/0/0:1  Active      0
                        bc-4/0/0:2  Inactive     0
```

### show dialer pools brief

```
user@host> show dialer pools brief
Pool      Dialer interface      Subordinate interface
          Name  State
10        d10.0  Active
          Name  State      Name      Flags      Priority
          bc-4/0/0:1  Active      0
          bc-4/0/0:2  Inactive     0
```

### show dialer pools detail

The output for the **show dialer pools detail** command is identical to that for the **show dialer pools** command.

## show interfaces (ISDN B-Channel)

<b>Syntax</b>	<pre>show interfaces bc-pim/0/port:channel &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display information about the specified ISDN B-channel interface.
<b>Options</b>	<p><b>bc-pim/0/port:channel</b>—Display standard information about the specified ISDN B-channel interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display the interface description string.</p> <p><b>media</b>—(Optional) Display media-specific information.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Additional Information</b>	There are no user-configurable fields on B-channel interfaces.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces (ISDN B-Channel) on page 713</a> <a href="#">show interfaces brief (ISDN B-Channel) on page 713</a> <a href="#">show interfaces detail (ISDN B-Channel) on page 713</a> <a href="#">show interfaces extensive (ISDN B-Channel) on page 714</a>
<b>Output Fields</b>	Table 112 on page 709 lists the output fields for the <b>show interfaces</b> (ISDN B-channel) command. Output fields are listed in the approximate order in which they appear.

Table 112: ISDN B-Channel show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>	Name of the physical interface type.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Fiel” section under “Common Output Fields Description” on page 141.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>

Table 112: ISDN B-Channel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit (MTU)—Size of the largest packet to be transmitted.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Parent</b>	Name and interface index of the interface to which a particular child interface belongs. <b>None</b> indicates that this is the top level.	<b>detail extensive none</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link type</b>	Data transmission type.	<b>detail extensive none</b>
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured media access control (MAC) address.	<b>detail extensive</b>
<b>Hardware address</b>	MAC address of the hardware.	<b>detail extensive</b>
<b>Alternate link address</b>	Backup address of the link.	<b>detail extensive</b>
<b>CoS queues</b>	Number of class-of-service (CoS) queues configured.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and length of time since the interface changed its status from down to up.	<b>detail extensive none</b>
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	none specified
<b>Output rate</b>	Output rate in bps and pps.	none specified
<b>Statistics last cleared</b>	Time when the interface statistics were last set to zero.	<b>detail extensive</b>



Table 112: ISDN B-Channel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the logical and physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Frames that the incoming packet match code discarded because they were not recognized or were not of interest. Usually, this field reports protocols that the Junos OS does not support.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>

Table 112: ISDN B-Channel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface (which reflects its initialization sequence).	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP interface index number for the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels

## Sample Output

### show interfaces (ISDN B-Channel)

```
user@host> show interfaces bc-4/0/0:1
Physical interface: bc-4/0/0:1, Enabled, Physical link is Up
  Interface index: 151, SNMP ifIndex: 75
  Type: Serial, Link-level type: 57, MTU: 4092, Clocking: Internal,
  Speed: 64kbps,
  Parent: br-4/0/0 Interface index 129
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  CoS queues     : 8 supported, 8 maximum usable queues
  Last flapped   : 2006-06-13 19:50:38 PDT (14:39:03 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

Logical interface bc-4/0/0:1.0 (Index 74) (SNMP ifIndex 79)
  Flags: Point-To-Point SNMP-Traps Encapsulation: 64
```

### show interfaces brief (ISDN B-Channel)

```
user@host> show interfaces bc-4/0/0:1 brief
Physical interface: bc-4/0/0:1, Enabled, Physical link is Up
  Type: Serial, Link-level type: 57, MTU: 4092, Clocking: Internal,
  Speed: 64kbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000

Logical interface bc-4/0/0:1.0
  Flags: Point-To-Point SNMP-Traps Encapsulation: 64
```

### show interfaces detail (ISDN B-Channel)

```
user@host> show interfaces bc-4/0/0:1 detail
Physical interface: bc-4/0/0:1, Enabled, Physical link is Up
  Interface index: 151, SNMP ifIndex: 75, Generation: 152
  Type: Serial, Link-level type: 57, MTU: 4092, Clocking: Internal,
  Speed: 64kbps,
  Parent: br-4/0/0 Interface index 129
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info   : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  CoS queues     : 8 supported, 8 maximum usable queues
  Last flapped   : 2006-06-13 19:50:38 PDT (14:39:06 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :          4096          0 bps
    Output bytes  :        128423         96 bps
    Input packets :           0          0 pps
    Output packets:         9801         0 pps
  Egress queues: 8 supported, 8 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort   13                  13              0
    1 expedited-fo  0                   0              0
```

2 assured-forw	0	0	0
3 network-cont	9788	9788	0

Logical interface bc-4/0/0:1.0 (Index 74) (SNMP ifIndex 79) (Generation 140)  
Flags: Point-To-Point SNMP-Traps Encapsulation: 64

**show interfaces  
extensive  
(ISDN B-Channel)**

```

user@host> show interfaces bc-4/0/0:1 extensive
Physical interface: bc-4/0/0:1, Enabled, Physical link is Up
Interface index: 151, SNMP ifIndex: 75, Generation: 152
Type: Serial, Link-level type: 57, MTU: 4092, Clocking: Internal,
Speed: 64kbps,
Parent: br-4/0/0 Interface index 129
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Link type : Full-Duplex
Link flags : None
Physical info : Unspecified
Hold-times : Up 0 ms, Down 0 ms
Current address: Unspecified, Hardware address: Unspecified
Alternate link address: Unspecified
CoS queues : 8 supported, 8 maximum usable queues
Last flapped : 2006-06-13 19:50:38 PDT (14:39:12 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes : 4096 0 bps
Output bytes : 128423 0 bps
Input packets: 0 0 pps
Output packets: 9801 0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Policed discards: 0, Resource errors: 0
Output errors:
Carrier transitions: 4, Errors: 0, Drops: 0, MTU errors: 0,
Resource errors: 0
Egress queues: 8 supported, 8 in use
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	13	13	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	9788	9788	0

```

Packet Forwarding Engine configuration:
Destination slot: 4, PLP byte: 1 (0x00)
CoS information:
CoS transmit queue      Bandwidth      Buffer  Priority Limit
                        %      bps      %      usec
0 best-effort           95      60800 95      0      low  none
3 network-control       5       3200  5       0      low  none
Logical interface bc-4/0/0:1.0 (Index 74) (SNMP ifIndex 79) (Generation 140)
Flags: Point-To-Point SNMP-Traps Encapsulation: 64

```

## show interfaces (ISDN BRI)

<b>Syntax</b>	<pre>show interfaces br-pim/0/port &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display status information about the specified ISDN Basic Rate Interface (BRI) interface.
<b>Options</b>	<p><b>br-pim/0/port</b>—Display standard information about the specified ISDN BRI interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display the interface description string.</p> <p><b>media</b>—(Optional) Display media-specific information.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (ISDN BRI) on page 718</a></p> <p><a href="#">show interfaces brief (ISDN BRI) on page 718</a></p> <p><a href="#">show interfaces detail (ISDN BRI) on page 718</a></p> <p><a href="#">show interfaces extensive (ISDN BRI) on page 718</a></p>
<b>Output Fields</b>	Table 113 on page 715 lists the output fields for the <b>show interfaces (ISDN BRI)</b> command. Output fields are listed in the approximate order in which they appear.

**Table 113: ISDN BRI show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>	Name of the physical interface type.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface index number that reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

Table 113: ISDN BRI show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation type used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit (MTU)—Size of the largest packet to be transmitted.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Parent</b>	Name and interface index of the interface to which a particular child interface belongs. <b>None</b> indicates that this is the top level.	<b>detail extensive none</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link type</b>	Data transmission type.	<b>detail extensive none</b>
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive none</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b>
<b>Hardware address</b>	Media access control (MAC) address of the interface.	<b>detail extensive</b>
<b>Alternate link address</b>	Backup link address.	<b>detail extensive</b>
<b>Last flapped</b>	Date, time, and length of time since the interface changed its status from down to up.	<b>detail extensive none</b>
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	none specified
<b>Output rate</b>	Output rate in bps and pps.	none specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 113: ISDN BRI show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the logical and physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Frames that the incoming packet match code discarded because they were not recognized or were not of interest. Usually, this field reports protocols that the Junos OS does not support.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b> —Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

## Sample Output

### show interfaces (ISDN BRI)

```
user@host> show interfaces br-4/0/0
Physical interface: br-4/0/0, Enabled, Physical link is Up
  Interface index: 129, SNMP ifIndex: 59
  Type: BRI, Link-level type: Controller, MTU: 4092, Clocking: 1,
  Speed: 128kbps, Parent: None
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : S/T
  Last flapped   : 2006-06-13 19:50:38 PDT (15:18:26 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
```

### show interfaces brief (ISDN BRI)

```
user@host> show interfaces brief br-4/0/0
Physical interface: br-4/0/0, Enabled, Physical link is Up
  Type: BRI, Link-level type: Controller, MTU: 4092, Clocking: 1, Speed: 128kbps

  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
```

### show interfaces detail (ISDN BRI)

```
user@host> show interfaces br-4/0/0 detail
Physical interface: br-4/0/0, Enabled, Physical link is Up
  Interface index: 129, SNMP ifIndex: 59, Generation: 130
  Type: BRI, Link-level type: Controller, MTU: 4092, Clocking: 1,
  Speed: 128kbps, Parent: None
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : S/T
  Hold-times     : Up 0 ms, Down 0 ms
  Last flapped   : 2006-06-13 19:50:38 PDT (15:18:32 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                      0          0 bps
    Output bytes  :                      0          0 bps
    Input packets :                      0          0 pps
    Output packets:                      0          0 pps
```

### show interfaces extensive (ISDN BRI)

```
user@host> show interfaces br-4/0/0 extensive
Physical interface: br-4/0/0, Enabled, Physical link is Up
  Interface index: 129, SNMP ifIndex: 59, Generation: 130
  Type: BRI, Link-level type: Controller, MTU: 4092, Clocking: 1,
  Speed: 128kbps, Parent: None
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex  Link flags   : None
  Physical info  : S/T
  Hold-times     : Up 0 ms, Down 0 ms
  Last flapped   : 2006-06-13 19:50:38 PDT (15:18:38 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                      0          0 bps
    Output bytes  :                      0          0 bps
```



```
Input  packets:           0           0 pps
Output packets:           0           0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Policed discards: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
Resource errors: 0
```

## show interfaces (ISDN D-channel)

<b>Syntax</b>	<pre>show interfaces dc-pim/0/port:0 &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display information about the specified ISDN D-channel interface.
<b>Options</b>	<p><b>dc-pim/0/port:0</b>—Display standard information about the specified ISDN D-channel interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display the interface description string.</p> <p><b>media</b>—(Optional) Display media-specific information.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Additional Information</b>	There are no user-configurable features on D-channel interfaces.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces (ISDN D-Channel) on page 724</a> <a href="#">show interfaces brief (ISDN D-Channel) on page 724</a> <a href="#">show interfaces detail (ISDN D-Channel) on page 724</a> <a href="#">show interfaces extensive (ISDN D-Channel) on page 725</a>
<b>Output Fields</b>	Table 114 on page 720 lists the output fields for the <b>show interfaces</b> (ISDN D-channel) command. Output fields are listed in the approximate order in which they appear.

**Table 114: ISDN D-Channel show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical Interface</b>	Name of the physical interface type.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface index</b>	Physical interface index number that reflects its initialization sequence.	<b>detail extensive none</b>

Table 114: ISDN D-Channel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation type used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit—Size of the largest packet to be transmitted.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Parent</b>	Name and interface index of the interface to which a particular child interface belongs. None indicates that this is the top level.	<b>detail extensive none</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link type</b>	Type of data transmission.	<b>detail extensive none</b>
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b>
<b>Hardware address</b>	MAC address of the hardware.	<b>detail extensive</b>
<b>Alternate link address</b>	Backup address for the link.	<b>detail extensive</b>
<b>Last flapped</b>	Date, time, and length of time since the interface changed its status from down to up.	<b>detail extensive none</b>
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	none specified
<b>Output rate</b>	Output rate in bps and pps.	none specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 114: ISDN D-Channel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li><b>Input bytes</b>—Number of bytes received on the interface.</li> <li><b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li><b>Input packets</b>—Number of packets received on the interface.</li> <li><b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<ul style="list-style-type: none"> <li><b>Errors</b>—Input errors on the interface.</li> <li><b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li><b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li><b>Runts</b>—Frames received smaller than the runt threshold.</li> <li><b>Giants</b>—Frames received larger than the giant threshold.</li> <li><b>Policed Discards</b>—Frames that the incoming packet match code discarded because they were not recognized or were not of interest. Usually, this field reports protocols that Junos does not support.</li> <li><b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<ul style="list-style-type: none"> <li><b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li><b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li><b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC Red mechanism.</li> <li><b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li><b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>ISDN Alarms</b>	ISDN alarms.	All levels
<b>ISDN Media</b>	<ul style="list-style-type: none"> <li><b>LOF</b>—Loss of frame</li> <li><b>LOS</b>—Loss of signal</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface (which reflects its initialization sequence).	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP interface index number for the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

Table 114: ISDN D-Channel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the logical interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the logical interface</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>

## Sample Output

### show interfaces (ISDN D-Channel)

```
user@host> show interfaces dc-4/0/0
Physical interface: dc-4/0/0, Enabled, Physical link is Up
  Interface index: 150, SNMP ifIndex: 73
  Type: Serial, Link-level type: 55, MTU: 4092, Clocking: Internal,
  Speed: 16kbps,
  Parent: br-4/0/0 Interface index 129
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Last flapped   : 2006-06-13 19:50:38 PDT (15:29:32 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  ISDN alarms    : None

Logical interface dc-4/0/0.32767 (Index 73) (SNMP ifIndex 74)
  Flags: Point-To-Point SNMP-Traps Encapsulation: 60
  Input packets : 23482
  Output packets: 21686
```

### show interfaces brief (ISDN D-Channel)

```
user@host> show interfaces dc-4/0/0 brief
Physical interface: dc-4/0/0, Enabled, Physical link is Up
  Type: Serial, Link-level type: 55, MTU: 4092, Clocking: Internal,
  Speed: 16kbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  ISDN alarms    : None

Logical interface dc-4/0/0.32767
  Flags: Point-To-Point SNMP-Traps Encapsulation: 60
```

### show interfaces detail (ISDN D-Channel)

```
user@host> show interfaces dc-4/0/0 detail
Physical interface: dc-4/0/0, Enabled, Physical link is Up
  Interface index: 150, SNMP ifIndex: 73, Generation: 151
  Type: Serial, Link-level type: 55, MTU: 4092, Clocking: Internal,
  Speed: 16kbps,
  Parent: br-4/0/0 Interface index 129
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info   : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : 2006-06-13 19:50:38 PDT (15:29:42 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :          257592          0 bps
    Output bytes  :          231162          0 bps
    Input packets :          23483          0 pps
    Output packets:          21687          0 pps
  ISDN alarms    : None

Logical interface dc-4/0/0.32767 (Index 73) (SNMP ifIndex 74) (Generation 139)
```

```

Flags: Point-To-Point SNMP-Traps Encapsulation: 60
Traffic statistics:
  Input bytes :          257592
  Output bytes :         664902
  Input packets:         23483
  Output packets:        21687
Local statistics:
  Input bytes :          257592
  Output bytes :         664902
  Input packets:         23483
  Output packets:        21687

```

**show interfaces  
extensive  
(ISDN D-Channel)**

```

user@host> show interfaces dc-4/0/0 extensive
Physical interface: dc-4/0/0, Enabled, Physical link is Up
  Interface index: 150, SNMP ifIndex: 73, Generation: 151
  Type: Serial, Link-level type: 55, MTU: 4092, Clocking: Internal,
  Speed: 16kbps,
  Parent: br-4/0/0 Interface index 129
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times    : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped  : 2006-06-13 19:50:38 PDT (15:29:49 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :          257596          0 bps
    Output bytes :         231167          0 bps
    Input packets:         23484          0 pps
    Output packets:        21688          0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 5, Errors: 0, Drops: 0, MTU errors: 0,
    Resource errors: 0
  ISDN alarms : None
  ISDN media:
    Seconds      Count  State
    LOF          1874    2   OK
    LOS          1874    2   OK

Logical interface dc-4/0/0.32767 (Index 73) (SNMP ifIndex 74) (Generation 139)

Flags: Point-To-Point SNMP-Traps Encapsulation: 60
Traffic statistics:
  Input bytes :          257596
  Output bytes :         664927
  Input packets:         23484
  Output packets:        21688
Local statistics:
  Input bytes :          257596
  Output bytes :         664927
  Input packets:         23484
  Output packets:        21688

```

## show interfaces (ISDN Dialer)

<b>Syntax</b>	<pre>show interfaces <i>dlnumber</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display information about the ISDN dialer interface.
<b>Options</b>	<p><b><i>dlnumber</i></b>—Display standard information about the specified ISDN dialer interface.</p> <p><b><i>brief   detail   extensive   terse</i></b>—(Optional) Display brief interface information.</p> <p><b><i>descriptions</i></b>—(Optional) Display the interface description string.</p> <p><b><i>media</i></b>—(Optional) Display media-specific information.</p> <p><b><i>snmp-index snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b><i>statistics</i></b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (ISDN Dialer) on page 732</a></p> <p><a href="#">show interfaces brief (ISDN Dialer) on page 732</a></p> <p><a href="#">show interfaces detail (ISDN Dialer) on page 733</a></p> <p><a href="#">show interfaces extensive (ISDN Dialer) on page 734</a></p>
<b>Output Fields</b>	<p><a href="#">Table 115 on page 726</a> lists the output fields for the <b>show interfaces (ISDN dialer)</b> command. Output fields are listed in the approximate order in which they appear.</p>

Table 115: ISDN Dialer show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical Interface</b>	Name of the physical interface type.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface index number that reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>



Table 115: ISDN Dialer show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Type</b>	Interface type.	All levels
<b>Link-level type</b>	Type of encapsulation configured on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit (MTU)—Size of the largest transmitted packet.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Device flags</b>	Information about the physical device.	All levels
<b>Interface flags</b>	Information about the interface.	All levels
<b>Link type</b>	Data transmission type.	<b>detail extensive none</b>
<b>Link flags</b>	Information about the link.	<b>detail extensive none</b>
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b>
<b>Hardware address</b>	MAC address of the hardware.	<b>detail extensive</b>
<b>Alternate link address</b>	Backup link address.	<b>detail extensive</b>
<b>Last flapped</b>	Date, time, and length of time since the interface status changed from <b>down</b> to <b>up</b> .	<b>detail extensive none</b>
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	none specified
<b>Output rate</b>	Output rate in bps and pps.	none specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 115: ISDN Dialer show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Frames that the incoming packet match code discarded because they were not recognized or were not of interest. Usually, this field reports protocols that the Junos OS does not support.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Index number of the logical interface (which reflects its initialization sequence).	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP interface index number for the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels

Table 115: ISDN Dialer show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Dialer	<p>Information about the status and configuration of the dialer interface:</p> <ul style="list-style-type: none"> <li>• <b>State</b>—State of the interface: <b>Active</b> or <b>Inactive</b>.</li> <li>• <b>Dial pool</b>—Dial pool name.</li> <li>• <b>Dial strings</b>—Dialing number for the ISDN connection.</li> <li>• <b>Subordinate interfaces</b>—Associated B-channel interface name and SNMP index number.</li> <li>• <b>Activation delay</b>—Length of time (in seconds) to wait before enabling the interface after the primary interface has failed.</li> <li>• <b>Deactivation delay</b>—Length of time (in seconds) to wait before disabling the interface after the primary interface is operational.</li> <li>• <b>Initial route check delay</b>—Wait period (in seconds) for the software to check if the primary interface is up after the router comes up. The range is from 1 through 300 seconds. The default is 120 seconds.</li> <li>• <b>Redial delay</b>—(Available on interfaces configured for ISDN dial-out.) Delay, in seconds, between two successive calls made. The range of values is 2 to 255. The default value is 3.</li> <li>• <b>Callback wait period</b>—Time, in seconds, that the dialer waits before it calls back the caller ID. The default value is 5.</li> <li>• <b>Load threshold</b>—Bandwidth threshold percentage used for adding interfaces. Another link is added to the multilink bundle when the load reaches the threshold value you set. The range of values is 0 to 100. The default value is 100.</li> <li>• <b>Load interval</b>—Interval used to calculate the average load on the network. By default, the average interface load is calculated every 60 seconds.</li> </ul>	All levels
Bandwidth	Speed at which the interface is running.	detail extensive none
Input packets	Number of packets received on the logical interface.	None specified
Output packets	Number of packets transmitted on the logical interface.	None specified
Traffic statistics	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the logical interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the logical interface</li> </ul>	detail extensive
Local statistics	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	detail extensive

Table 115: ISDN Dialer show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. This counter normally stabilizes in less than 1 second.	<b>detail extensive</b>
<b>Keepalive settings</b>	<p>Configured settings for keepalives.</p> <ul style="list-style-type: none"> <li><b>interval <i>seconds</i></b>—Time in seconds between successive keepalive requests. The range is 10 seconds through 32,767 seconds, with a default of 10 seconds.</li> <li><b>up-count <i>number</i></b>—Number of keepalive packets a destination must receive to change a link's status from down to up. The range is 1 through 255, with a default of 1.</li> <li><b>down-count <i>number</i></b>—Number of keepalive packets a destination must fail to receive before the network takes a link down. The range is 1 through 255, with a default of 3.</li> </ul>	<b>detail extensive none</b>
<b>Keepalive statistics</b>	<p>Information about keepalive packets. (When no level of output is specified, the word "statistics" is not part of the field name and the phrase "last seen" is not displayed.)</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li><b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul>	<b>detail extensive none</b>
<b>LCP state</b>	<p>Link Control Protocol state.</p> <ul style="list-style-type: none"> <li><b>Conf-ack-received</b>—Acknowledgement was received.</li> <li><b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li><b>Conf-req-sent</b>—Request was sent.</li> <li><b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li><b>Not configured</b>—LCP is not configured on the interface.</li> <li><b>Opened</b>—LCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>NCP state</b>	<p>Network Control Protocol state.</p> <ul style="list-style-type: none"> <li><b>Conf-ack-received</b>—Acknowledgement was received.</li> <li><b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li><b>Conf-req-sent</b>—Request was sent.</li> <li><b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li><b>Not configured</b>—NCP is not configured on the interface.</li> <li><b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>

Table 115: ISDN Dialer show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CHAP state</b>	Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction. <ul style="list-style-type: none"> <li>• <b>Chap-Resp-received</b>—Response received for the challenge sent, but CHAP not yet moved into the Success state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response sent for the challenge received.</li> <li>• <b>Chap-Chal-sent</b>—Challenge sent.</li> <li>• <b>Chap-Chal-received</b>—Challenge received but response not yet sent.</li> <li>• <b>Down</b>—CHAP authentication is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Opened</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>protocol family</b>	Protocol family configured on the logical interface. If the family is <b>inet</b> , the IP address of the logical interface and the IP address on the remote side of the connection are included.	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces (ISDN Dialer)

```
user@host>show interfaces d10
Physical interface: d10, Enabled, Physical link is Up
  Interface index: 153, SNMP ifIndex: 77
  Type: 27, Link-level type: PPP, MTU: 1504
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Link type      : Full-Duplex
  Link flags     : Keepalives
  Last flapped   : Never
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

Logical interface d10.0 (Index 76) (SNMP ifIndex 78)
  Flags: Point-To-Point SNMP-Traps 0x4000 LinkAddress 23-0 Encapsulation: PPP
  Dialer:
    State: Active, Dial pool: 10
    Dial strings: 5551212
    Subordinate interfaces: bc-4/0/0:1 (Index 151)
    Activation delay: 0, Deactivation delay: 0
    Initial route check delay: 120
    Redial delay: 3
    Callback wait period: 5
    Load threshold: 0, Load interval: 60
  Bandwidth: 64kbps
  Input packets : 13
  Output packets: 10846
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 5412 (00:00:06 ago), Output: 5416 (00:00:05 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Closed
    Protocol inet, MTU: 1500
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.40.1, Local: 10.0.40.2
```

### show interfaces brief (ISDN Dialer)

```
user@host> show interfaces d10 brief
Physical interface: d10, Enabled, Physical link is Up
  Type: 27, Link-level type: PPP, MTU: 1504, Clocking: Unspecified,
  Speed: Unspecified
  Device flags   : Present Running
  Interface flags: SNMP-Traps

Logical interface d10.0
  Flags: Point-To-Point SNMP-Traps 0x4000 LinkAddress 23-0 Encapsulation: PPP
  Dialer:
    State: Active, Dial pool: 10
    Dial strings: 5551212
    Subordinate interfaces: bc-4/0/0:1 (Index 151)
    Activation delay: 0, Deactivation delay: 0
    Initial route check delay: 120
    Redial delay: 3
    Callback wait period: 5
    Load threshold: 0, Load interval: 60
  inet 10.0.40.2      --> 10.0.40.1
```

## show interfaces detail (ISDN Dialer)

```

user@host> show interfaces d10 detail
Physical interface: d10, Enabled, Physical link is Up
  Interface index: 153, SNMP ifIndex: 77, Generation: 154
  Type: 27, Link-level type: PPP, MTU: 1504, Clocking: Unspecified,
  Speed: Unspecified
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Link type      : Full-Duplex
  Link flags     : Keepalives
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : Never
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :          131116          40 bps
    Output bytes  :              0          0 bps
    Input packets :          10847          0 pps
    Output packets:              0          0 pps

Logical interface d10.0 (Index 76) (SNMP ifIndex 78) (Generation 142)
  Flags: Point-To-Point SNMP-Traps 0x4000 LinkAddress 23-0 Encapsulation: PPP
  Dialer:
    State: Active, Dial pool: 10
    Dial strings: 5551212
    Subordinate interfaces: bc-4/0/0:1 (Index 151)
    Activation delay: 0, Deactivation delay: 0
    Initial route check delay: 120
    Redial delay: 3
    Callback wait period: 5
    Load threshold: 0, Load interval: 60
  Bandwidth: 64kbps
  Traffic statistics:
    Input bytes   :          1092
    Output bytes  :        131459
    Input packets :           13
    Output packets:        10848
  Local statistics:
    Input bytes   :          1092
    Output bytes  :        131459
    Input packets :           13
    Output packets:        10848
  Transit statistics:
    Input bytes   :              0          0 bps
    Output bytes  :              0          0 bps
    Input packets :              0          0 pps
    Output packets:              0          0 pps
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 5413 (last seen 00:00:03 ago)
    Output: 5417 (last sent 00:00:02 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Closed
    Protocol inet, MTU: 1500, Generation: 142, Route table: 0
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.0.40.1, Local: 10.0.40.2, Broadcast: Unspecified,
      Generation: 142

```

# show interfaces extensive (ISDN Dialer)

```

user@host> show interfaces d10 extensive
Physical interface: d10, Enabled, Physical link is Up
  Interface index: 153, SNMP ifIndex: 77, Generation: 154
  Type: 27, Link-level type: PPP, MTU: 1504, Clocking: Unspecified,
  Speed: Unspecified
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Link type      : Full-Duplex
  Link flags     : Keepalives
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : Never
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :           131116           0 bps
    Output bytes  :              0           0 bps
    Input packets :          10847           0 pps
    Output packets:              0           0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0,
    Resource errors: 0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
    Resource errors: 0

Logical interface d10.0 (Index 76) (SNMP ifIndex 78) (Generation 142)
  Flags: Point-To-Point SNMP-Traps 0x4000 LinkAddress 23-0 Encapsulation: PPP
  Dialer:
    State: Active, Dial pool: 10
    Dial strings: 5551212
    Subordinate interfaces: bc-4/0/0:1 (Index 151)
    Activation delay: 0, Deactivation delay: 0
    Initial route check delay: 120
    Redial delay: 3
    Callback wait period: 5
    Load threshold: 0, Load interval: 60
  Bandwidth: 64kbps
  Traffic statistics:
    Input bytes   :           1092
    Output bytes  :          131459
    Input packets :             13
    Output packets:          10848
  Local statistics:
    Input bytes   :           1092
    Output bytes  :          131459
    Input packets :             13
    Output packets:          10848
  Transit statistics:
    Input bytes   :              0           0 bps
    Output bytes  :              0           0 bps
    Input packets :              0           0 pps
    Output packets:              0           0 pps
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 5413 (last seen 00:00:07 ago)
    Output: 5417 (last sent 00:00:06 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured,

```



```
mpls: Not-configured
CHAP state: Closed
  Protocol inet, MTU: 1500, Generation: 142, Route table: 0
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.0.40.1, Local: 10.0.40.2, Broadcast: Unspecified,
      Generation: 142
```

## show isdn calls

<b>Syntax</b>	show isdn calls
<b>Release Information</b>	Command introduced in Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display ISDN connection calls.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show isdn calls on page 736</a>
<b>Output Fields</b>	<a href="#">Table 116 on page 736</a> lists the output fields for the <b>show isdn calls</b> command. Output fields are listed in the approximate order in which they appear.

Table 116: show isdn calls Output Fields

Field Name	Field Description
<b>Interface</b>	ISDN interface configured for calling out.
<b>Status</b>	Current calling conditions of the ISDN interface.
<b>Call Duration</b>	Connection time (in seconds) for the call.
<b>Call Direction</b>	Indicates whether the call is a <b>Dialout</b> call, <b>Dialincall</b> , or <b>Callback</b> call.
<b>Most recent error code</b>	Calling errors on the ISDN interface.

## Sample Output

### show isdn calls

```
user@host> show isdn calls
Interface: bc-4/0/0:1
  Status: No call in progress
  Most recent error code: protocol error, unspecified
Interface: bc-4/0/0:2
  Status: Connected to 5552121
  Call Duration: 58549 seconds
  Call Direction: Dialout
  Most recent error code: No error
```

## show isdn history

<b>Syntax</b>	show isdn history
<b>Release Information</b>	Command introduced in Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display ISDN call history.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show isdn history on page 737</a>
<b>Output Fields</b>	<a href="#">Table 117 on page 737</a> lists the output fields for the <b>show isdn history</b> command. Output fields are listed in the approximate order in which they appear.

**Table 117: show isdn history Output Fields**

Field Name	Field Description
<b>Calling Number</b>	Telephone number configured as the primary dialing number.
<b>Called Number</b>	Telephone number used to dial the service provider.
<b>Interface</b>	ISDN interface used for calling the service provider.
<b>Duration</b>	Length of time (in seconds) that the ISDN call is connected.
<b>Direction</b>	Indicates whether the call is a <b>Dialout</b> call, <b>Dialin</b> call, or <b>Callback</b> call.

## Sample Output

```

show isdn history
user@host> show isdn history
Calling      Called      Interface   Duration    Direction
Number      Number
551212      5552121     bc-4/0/0:1  58663       Dialin

```

## show isdn q921 statistics

<b>Syntax</b>	<code>show isdn q921 statistics br-pim/0/port</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display ISDN Layer 2 statistics based on the Q.921 standard for the specified Basic Rate Interface (BRI) interface.
<b>Options</b>	<code>br-pim/0/port</code> —Basic Rate Interface (BRI) interface name.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li><a href="#">clear isdn q921 statistics on page 701</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show isdn q921 statistics on page 739</a>
<b>Output Fields</b>	<a href="#">Table 118 on page 738</a> lists the output fields for the <b>show isdn q921 statistics</b> command. Output fields are listed in the approximate order in which they appear.

**Table 118: show isdn q921 statistics Output Fields**

Field Name	Field Description
Frame Type	<p>Frame type:</p> <ul style="list-style-type: none"> <li><b>INFO</b>—Number of information frames sent and received.</li> <li><b>RR</b>—Number of receive ready frames sent and received.</li> <li><b>RNR</b>—Number of receive not ready frames sent and received.</li> <li><b>REJ</b>—Number of reject frames sent and received.</li> <li><b>SABME</b>—Number of set asynchronous balanced mode extended frames sent and received.</li> <li><b>DISC</b>—Number of disconnect frames sent and received.</li> <li><b>UA</b>—Number of unnumbered acknowledgement frames sent and received.</li> <li><b>DM</b>—Number of disconnect mode frames sent and received.</li> <li><b>FRMR</b>—Number of frame reject frames sent and received.</li> <li><b>XID</b>—Number of exchange identification frames sent and received.</li> <li><b>UI</b>—Number of unnumbered information frames sent and received.</li> </ul>
Transmitted	Number of frames transmitted.
Received	Number of frames received.

## Sample Output

`show isdn q921  
statistics`

`user@host> show isdn q921 statistics br-6/0/0`

Frame Type	Transmitted	Received
INFO	2196	3290
RR	9853	8759
RNR	0	0
REJ	0	0
SABME	1	0
DISC	0	0
UA	0	1
DM	0	0
FRMR	0	0
XID	0	0
UI	1	1

## show isdn q931 statistics

---

<b>Syntax</b>	<code>show isdn q931 statistics br-pim/0/port</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display ISDN Layer 3 statistics based on the Q.931 standard for the specified Basic Rate Interface (BRI) interface.
<b>Options</b>	<code>br-pim/0/port</code> —Basic Rate Interface (BRI) interface name.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">clear isdn q931 statistics on page 702</a></li></ul>
<b>List of Sample Output</b>	<a href="#">show isdn q931 statistics on page 742</a>
<b>Output Fields</b>	<a href="#">Table 119 on page 741</a> lists the output fields for the <code>show isdn q931 statistics</code> command. Output fields are listed in the approximate order in which they appear.

Table 119: show isdn q931 Statistics Output Fields

Field Name	Field Description
Message Type	<p>Type of message:</p> <ul style="list-style-type: none"> <li>• <b>ALERTING</b>—Number of messages indicating that called user alerting is initiated.</li> <li>• <b>CALL PROCEED</b>—Number of messages indicating that requested call establishment has been initiated and no more call establishment information is accepted.</li> <li>• <b>CONNECT</b>—Number of messages indicating that a call has gone through and is accepted.</li> <li>• <b>CONNECT ACK</b>—Number of messages sent by the network to the called user to indicate that the user is awarded the call.</li> <li>• <b>PROGRESS</b>—Number of messages indicating the progress of a call in relation to the provision of inband information or patterns.</li> <li>• <b>SETUP</b>—Number of requests to initiate call establishment.</li> <li>• <b>SETUP ACK</b>—Number of messages indicating that call establishment is initiated but additional information might be required.</li> <li>• <b>DISCONNECT</b>—Number of messages sent by the user to request clearing an end-to-end connection.</li> <li>• <b>RELEASE</b>—Number of messages sent by the network to indicate that the equipment sending the message has disconnected the channel and intends to release the channel and call reference.</li> <li>• <b>RELEASE COMPLETE</b>—Number of messages sent by the user or network to indicate that the equipment sending the message has released the channel and call reference, and that the channel is available for reuse.</li> <li>• <b>RESTART</b>—Number of messages that restart a call connection.</li> <li>• <b>RESTART ACK</b>—Number of messages that acknowledge the restart request by the remote network.</li> <li>• <b>INFORMATION</b>—Number of messages that provide information for call establishment or miscellaneous call-related information.</li> <li>• <b>NOTIFY</b>—Number of messages that contain information pertaining to a call.</li> <li>• <b>STATUS</b>—Number of messages sent in response to a status enquiry message or at any time during a call to report certain error conditions.</li> <li>• <b>STATUS ENQUIRY</b>—Number of messages sent to solicit a status message from the peer Layer 3 entity.</li> </ul>
Transmitted	Number of messages transmitted.
Received	Number of messages received.

## Sample Output

**show isdn q931  
statistics**

```
user@host> show isdn q931 statistics br-4/0/0
Message Type      Transmitted      Received
ALERTING           1                 0
CALL PROCEED       1                229
CONNECT            1                 0
CONNECT ACK        0                 1
PROGRESS           0                 0
SETUP              229              1096
SETUP ACK          0                 0
DISCONNECT         0                229
RELEASE            1324              0
RELEASE COMPLETE   0                1324
RESTART            0                 0
RESTART ACK        0                 0
INFORMATION        0                 0
NOTIFY             0                 0
STATUS             0                 0
STATUS ENQUIRY     0                 0
```



## show isdn status

<b>Syntax</b>	show isdn status <brief   detail> <br-pim/0/port>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display ISDN status information.
<b>Options</b>	<p><b>none</b>—Display standard ISDN status information for all Basic Rate Interface (BRI) interfaces.</p> <p><b>brief   detail</b>—(Optional) Display the specified level of output.</p> <p><b>br-pim/0/port</b>—(Optional) Display status information for the specified BRI interface only.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show isdn status on page 744</a>
<b>Output Fields</b>	Table 120 on page 743 lists the output fields for the <b>show isdn status</b> command. Output fields are listed in the approximate order in which they appear.

**Table 120: show isdn status Output Fields**

Field Name	Field Description
<b>Interface</b>	ISDN BRI interface name.
<b>Layer 1 status</b>	Layer 1 status: <b>active</b> or <b>inactive</b> .
<b>Layer 2 status</b>	Layer 2 status: <ul style="list-style-type: none"> <li>• <b>CES</b>—Common endpoint suffix value.</li> <li>• <b>Q.921</b>—Q.921 status: <b>up</b> or <b>down</b>.</li> <li>• <b>TEI</b>—Assigned terminal endpoint identifier (TEI) number.</li> </ul>
<b>Layer 3 status</b>	Number of active calls, plus: <ul style="list-style-type: none"> <li>• <b>Switch Type</b>—Type of ISDN switch based on the manufacturer.</li> <li>• <b>Interface Type</b>—Information relating to a local or network interface.</li> <li>• <b>Calling number</b>—Telephone number configured as the primary dialing number.</li> <li>• <b>T310</b>—Q.931-specific timer value.</li> <li>• <b>Tei Option</b>—Initial connectivity configuration of the ISDN interface.</li> </ul>

## Sample Output

### show isdn status

```
user@host> show isdn status
Interface: br-4/0/0
Layer 1 status: active
Layer 2 status:
  CES: 0, Q.921: up, TEI: 64
Layer 3 status: 1 Active calls
Switch Type       : ATT5E
Interface Type    : USER
Calling number    : 5551212
T310              : 10 seconds
Tei Option        : Power Up
```

## PART 10

# Channelized Interfaces

- [Channelized E1 Interface Operational Mode Commands on page 747](#)
- [Channelized OC Interface Operational Commands on page 765](#)
- [Channelized STM1 Interface Operational Mode Commands on page 799](#)
- [Channelized T1 and T3 Interface Operational Mode Commands on page 819](#)



# Channelized E1 Interface Operational Mode Commands

Table 121 on page 747 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot channelized E1 interfaces. Commands are listed in alphabetical order.

**Table 121: Channelized E1 Interface Operational Mode Commands**

Task	Command
Display status information about channelized E1 interfaces.	<code>show interfaces (Channelized E1)</code>
Display channelized E1 IQ interface information.	<code>show interfaces (Channelized E1 IQ)</code>
Display the interface names of the physical channelized E1 IQ interface and the channels configured on each interface.	<code>show interfaces controller (Channelized E1 IQ)</code>



**NOTE:** For more information about the channel type and level of channelization, and for information about the number of channels that are supported on the channelized E1 interface, see the Junos® OS Network Interfaces.

For channelization illustrations and configuration examples for channelized IQ interfaces, see the *Junos Feature Guide*.

## show interfaces (Channelized E1)

<b>Syntax</b>	<pre>show interfaces ds-fpc/pic/port:ds0channel &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information the specified channelized E1 interface.
<b>Options</b>	<p><b>ds-fpc/pic/port:ds0channel</b>—Display standard information about the specified channelized E1 interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Channelized E1) on page 757</a>
<b>Output Fields</b>	Table 122 on page 748 lists the output fields for the <b>show interfaces</b> (Channelized E1 and Channelized E1 IQ) command. Output fields are listed in the approximate order in which they appear.

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the "Enabled Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	detail extensive none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	detail extensive none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	detail extensive

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Link-level type	Encapsulation being used on the physical interface.	All levels
MTU	MTU size on the physical interface.	All levels
Clocking	Reference clock source: <b>Internal</b> or <b>External</b> .	All levels
Speed	Speed at which the interface is running.	All levels
Loopback	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
FCS	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16</b> bits.	All levels
Framing	Physical layer framing format used on the link. It can be <b>G704</b> , <b>G704-NO-CRC4</b> , or <b>Unframed</b> . The default is <b>G704</b> .	All levels
Parent	(Channelized E1 IQ interfaces only) Name and interface index of the interface to which a particular child interface belongs. <b>None</b> indicates that this interface is the top level.	All levels
Device flags	Information about the physical device. Possible values are described in the "Device Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
Interface flags	Information about the interface. Possible values are described in the "Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
Link flags	Information about the link. Possible values are described in the "Link Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
Hold-times	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
Keepalive settings	(PPP and HDLC) Configured settings for keepalives. <ul style="list-style-type: none"> <li><b>Interval <i>seconds</i></b>—Time in seconds between successive keepalive requests. The range is <b>10</b> seconds through <b>32,767</b> seconds, with a default of <b>10</b> seconds.</li> <li><b>Down-count <i>number</i></b>—Number of keepalive packets a destination must fail to receive before the network takes a link down. The range is <b>1</b> through <b>255</b>, with a default of <b>3</b>.</li> <li><b>Up-count <i>number</i></b>—Number of keepalive packets a destination must receive to change a link's status from down to up. The range is <b>1</b> through <b>255</b>, with a default of <b>1</b>.</li> </ul>	<b>detail extensive none</b>

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Keepalive statistics	<p>(PPP and HDLC) Information about keepalive packets.</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li>(<b>last seen 00:00:00 ago</b>)—Time since the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li><b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li>(<b>last seen 00:00:00 ago</b>)—Time since the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul>	detail extensive none
LMI settings	<p>(Frame Relay) Settings for link management can be either ANSI LMI settings or ITU LMI settings. ANSI LMI settings is the default. The format is (<b>ANSI or ITU</b>) <b>LMI settings: value, value...xx</b> seconds, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li><b>n391dte</b>—DTE full status polling interval (1–255)</li> <li><b>n392dce</b>—DCE error threshold (1–10)</li> <li><b>n392dte</b>—DTE error threshold (1–10)</li> <li><b>n393dce</b>—DCE monitored event count (1–10)</li> <li><b>n393dte</b>—DTE monitored event count (1–10)</li> <li><b>t391dte</b>—DTE polling timer (5–30 seconds)</li> <li><b>t392dce</b>—DCE polling verification timer (5–30 seconds)</li> </ul>	detail extensive none
LMI	<p>(Frame Relay) Statistics about the link management.</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: nn (last seen hh:mm:ss ago)</b></li> <li><b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: nn (last sent hh:mm:ss ago)</b>.</li> </ul>	detail extensive none
DTE statistics	<p>(Frame Relay) Statistics about messages transmitted from the data terminal equipment (DTE) to the data circuit-terminating equipment (DCE):</p> <ul style="list-style-type: none"> <li><b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li><b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li><b>Enquiry responses received</b>—Number of enquiry responses received by the DTE from the DCE.</li> <li><b>Full enquiry responses received</b>—Number of full enquiry responses sent from the DTE to the DCE.</li> </ul>	detail extensive none
DCE statistics	<p>(Frame Relay) Statistics about messages transmitted from the DCE to the DTE:</p> <ul style="list-style-type: none"> <li><b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li><b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li><b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li><b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	detail extensive none



Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Common statistics</b>	<p>(Frame Relay) Statistics about messages sent between the DTE and the DCE:</p> <ul style="list-style-type: none"> <li>• <b>Unknown messages received</b>—Number of received packets that do not fall into any category.</li> <li>• <b>Asynchronous updates received</b>—Number of link status peer changes received.</li> <li>• <b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li>• <b>Keepalive responses timedout</b>—Number of keepalive responses that timed out when no LMI packet was reported for <code>n392dte</code> or <code>n393dce</code> intervals. (See <b>LMI settings</b>).</li> </ul>	<b>detail extensive none</b>
<b>Nonmatching DCE-end DLCIs</b>	(Frame Relay, displayed only from the DTE) Number of DLCIs configured from the DCE.	<b>detail extensive none</b>
<b>LCP state</b>	<p>(PPP) Link Control Protocol state.</p> <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—LCP is not configured on the interface.</li> <li>• <b>Opened</b>—LCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>CHAP state</b>	<p>(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction.</p> <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the Success state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Closed</b>—CHAP authentication is incomplete.</li> <li>• <b>Failure</b>—CHAP authentication failed.</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Success</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went down to up. The format is <b>Last flapped: <i>year-month-day hour:minute:second timezone (hour:minute:second ago)</i></b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>CoS Queues</b>	Number of CoS queues configured.	<b>detail extensive none</b>
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), then either the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>DS1 alarms</b> <b>DS1 defects</b>	<p>E1 media-specific defects that can render the interface unable to pass packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. The following lists all possible alarms and defects. For complete explanations of most of these alarms and defects, see <i>Bellcore Telcordia GR-499-CORE</i>.</p> <ul style="list-style-type: none"> <li>• <b>LOS</b>—Loss of signal.</li> <li>• <b>LOF</b>—Loss of frame.</li> <li>• <b>AIS</b>—Alarm indication signal.</li> <li>• <b>YLW</b>—Yellow alarm. Indicates errors at the remote site receiver.</li> </ul>	<b>detail extensive none</b>

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>E1 media</b>	<p>Active alarms and defects, plus counts of specific E1 errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than OK indicates a problem.</li> </ul> <p>The E1 media-specific error types can be:</p> <ul style="list-style-type: none"> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>BEE</b>—Bit error</li> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>PCV</b>—Pulse code violation</li> <li>• <b>CS</b>—Carrier state</li> <li>• <b>FEBS</b>—Far-end block error</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>ES</b>—Errored seconds</li> <li>• <b>BES</b>—Bursty errored seconds</li> <li>• <b>SES</b>—Severely errored seconds</li> <li>• <b>SEFS</b>—Severely errored framing seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> </ul>	<b>extensive</b>
<b>HDLC configuration</b>	<p>Information about the HDLC configuration.</p> <ul style="list-style-type: none"> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> <li>• <b>Timeslots</b>—Configured time slots for the interface.</li> <li>• <b>Line encodingHDB3</b>—Line encoding used.</li> </ul>	<b>extensive</b>
<b>Interface transmit queues</b>	<p>Names of the transmit queues and their associated statistics for each DSO channel on the Channelized E1 to DSO PIC.</p> <ul style="list-style-type: none"> <li>• <b>B/W</b>—Queue bandwidth as a percentage of the total interface bandwidth.</li> <li>• <b>WRR</b>—Weighted round robin (in percent).</li> <li>• <b>Packets</b>—Number of packets transmitted.</li> <li>• <b>Bytes</b>—Number of bytes transmitted.</li> <li>• <b>Drops</b>—Number of packets dropped.</li> <li>• <b>Errors</b>—Number of packet errors.</li> </ul>	<b>extensive</b>

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DSx BERT configuration</b>	<p>BERT (bit error rate test) checks the quality of the line. This output appears only when a BERT is run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>BERT time period</b>—Configured total time period that the BERT is to run.</li> <li>• <b>Elapsed</b>—Actual time elapsed since the start of the BERT (in seconds).</li> <li>• <b>Induced error rate</b>—Configured rate at which the bit errors are induced in the BERT pattern.</li> <li>• <b>Algorithm</b>—Type of algorithm selected for the BERT.</li> </ul>	<b>detail extensive none</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>
<b>CoS information</b>	<p>Information about the CoS queue for the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified

Table 122: Channelized E1 and Channelized E1 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the logical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	(Frame Relay) Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than one second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	(Frame Relay) Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mpls</b> .	<b>detail extensive none</b>
<b>Multilink bundle</b>	(Multilink) Interface name for the multilink bundle, if configured.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>DLCI</b>	<p>(Frame Relay) DLCI number of the logical interface. The following DLCI information is displayed: <b>Flags</b>, <b>Total down time</b>, <b>Last down</b>, and <b>Traffic statistics</b>. <b>Flags</b> is one or more of the following:</p> <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when link is active, but no information is received from the DCE.</li> <li>• <b>Unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the corresponding DLCI in the DCE is configured.</li> <li>• <b>Dce-configured</b>—Displayed when the command is issued from the DTE.</li> </ul>	<b>detail extensive none</b>
<b>DLCI statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	<b>detail extensive none</b>

## Sample Output

show interfaces  
extensive  
(Channelized E1)

```
user@host> show interfaces ds-0/1/1:1 extensive
Physical interface: ds-0/1/1:1, Enabled, Physical link is Down
Interface index: 163, SNMP ifIndex: 37, Generation: 46
Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: E1,
Loopback: None, FCS: 16, Framing: G704
Device flags   : Present Running Down
Interface flags: Hardware-Down Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : Keepalives
Hold-times     : Up 0 ms, Down 0 ms
CoS queues     : 4 supported, 4 maximum usable queues
Last flapped   : 2005-12-28 14:44:06 PST (00:00:30 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   :                0                0 bps
Output bytes  :                0                0 bps
Input packets :                0                0 pps
Output packets:                0                0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Policed discards: 0,
L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
HS link CRC errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,
Resource errors: 0
DS1 alarms   : LOF, LOS
DS1 defects  : LOF, LOS
E1 media:
Seconds      Count  State
SEF          982318    1 Defect Active
BEE           0         0 OK
AIS           0         0 OK
LOF          982318    1 Defect Active
LOS          982318    1 Defect Active
YELLOW        0         0 OK
BPV           1         1
EXZ           1         1
LCV           1         1
PCV           1         2
CS            0         0
FEBE          1         9
LES           1
ES          982318
SES          982318
SEFS         982318
BES           1
UAS           0
Interface transmit queues:
      B/W  WRR    Packets      Bytes      Drops      Errors
Queue0   95  95         0         0         0         0
Queue1    5   5         0         0         0         0
HDLC configuration:
Giant threshold: 1514, Runt threshold: 3
Timeslots      : 31
Line encoding: HDB3, Data inversion: Disabled, Idle cycle flag: flags,
Start end flag: shared
DS1 BERT configuration:
BERT time period: 0 seconds, Elapsed: 0 seconds
Induced Error rate: 10e-0, Algorithm: 2^11 - 1, 0.152 and 0.153 (2047 type),
Pseudorandom (8)
```

Packet Forwarding Engine configuration:  
Destination slot: 0, PLP byte: 2 (0x1b)

CoS information:

CoS	transmit queue		Bandwidth		Buffer	Priority	Limit
		%	bps	%	usec		
0	best-effort	95	1945600	95	0	low	none
3	network-control	5	102400	5	0	low	none



## show interfaces (Channelized E1 IQ)

<b>Syntax</b>	<pre>show interfaces (ce1-fpc/pic/port   type-fpc/pic/port&lt;:channel&gt;) &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized E1 IQ interface.
<b>Options</b>	<p><b>type-fpc/pic/port:&lt;channel&gt;</b>—Interface type with optional corresponding channel levels. For the physical channelized E1 IQ interface, <b>type</b> is <b>ce</b>. For the clear channel, <b>type</b> is <b>e1</b>. At the first level of channelization, <b>type</b> is <b>ds</b>.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Channelized E1 IQ) (Physical) on page 760</a></p> <p><a href="#">show interfaces extensive (Channelized E1 IQ Multilink PPP Encapsulation) on page 760</a></p> <p><a href="#">show interfaces extensive (Channelized E1 IQ MLFR Encapsulation) on page 761</a></p> <p><a href="#">show interfaces detail (Clear Channel E1) on page 763</a></p>
<b>Output Fields</b>	For information about output fields, see the output field table for the <a href="#">show interfaces (Channelized E1)</a> command. Output fields are listed in the approximate order in which they appear.

## Sample Output

**show interfaces**  
**(Channelized E1 IQ)**  
**(Physical)**

```
user@host> show interfaces ce1-1/2/3
Physical interface: ce1-1/2/3, Enabled, Physical link is Up
  Interface index: 18, SNMP ifIndex: 1128
  Link-level type: Frame-relay, Controller, MTU: 1504, Clocking: Internal, Speed:
  E1, Loopback: None, FCS: 16, Framing: G704, Parent: None
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : Keepalives DTE
  ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
  LMI: Input: 51700 (00:00:02 ago), Output: 51701 (00:00:02 ago)
  DTE statistics:
    Enquiries sent           : 43186
    Full enquiries sent      : 8515
    Enquiry responses received : 43185
    Full enquiry responses received : 8515
  DCE statistics:
    Enquiries received       : 0
    Full enquiries received  : 0
    Enquiry responses sent   : 0
    Full enquiry responses sent : 0
  Common statistics:
    Unknown messages received : 0
    Asynchronous updates received : 0
    Out-of-sequence packets received : 0
    Keepalive responses timedout : 0
  Nonmatching DCE-end DLCIs:
    2
  Last flapped   : 2002-10-04 17:52:51 PDT (00:32:57 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  DS1 alarms    : None
  DS1 defects    : None
```

**show interfaces**  
**extensive (Channelized**

```
user@host> show interfaces ds-0/3/4:1 extensive
Physical interface: ds-0/3/4:1, Enabled, Physical link is Up
  Interface index: 151, SNMP ifIndex: 63, Generation: 34
```

## E1 IQ Multilink PPP Encapsulation)

```

Link-level type: Multilink-PPP, MTU: 1518, Clocking: Internal, Speed: 64kbps,
Loopback: None, FCS: 16,
Parent: ce1-0/3/4 Interface index 150
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : None
Hold-times    : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
  Input : 0 (last seen: never)
  Output: 0 (last sent: never)
LCP state: Down
CHAP state: Closed
CoS queues   : 4 supported, 4 maximum usable queues
Last flapped : Never
Statistics last cleared: 2005-12-21 10:32:15 PST (1w0d 03:10 ago)
Traffic statistics:
  Input bytes   :                0                0 bps
  Output bytes  :            6070570            224 bps
  Input packets:                0                0 pps
  Output packets:          209330                0 pps
Input errors:
  Errors: 3, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, L3 incompletes: 0, L2 channel errors: 0,
  L2 mismatch timeouts: 0, HS link CRC errors: 0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,
  Resource errors: 0
HDLC configuration:
  Giant threshold: 1528, Runt threshold: 2
  Timeslots      : 1
  Data inversion: Disabled, Idle cycle flag: flags, Start end flag: shared
DSO BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
  Destination slot: 0, PLP byte: 4 (0x00)

Logical interface ds-0/3/4:1.0 (Index 74) (SNMP ifIndex 64) (Generation 13)
Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP
Protocol mlppp, Multilink bundle: ls-0/1/0.0, MTU: 1514, Generation: 24,
Route table: 0

```

## show interfaces extensive (Channelized

```

user@host> show interfaces ds-0/3/4:5 extensive
Physical interface: ds-0/3/4:5, Enabled, Physical link is Up
Interface index: 155, SNMP ifIndex: 72, Generation: 38

```

## E1 IQ MLFR Encapsulation)

```

Link-level type: Multilink-FR, MTU: 1518, Clocking: Internal, Speed: 64kbps,
Loopback: None, FCS: 16,
Parent: ce1-0/3/4 Interface index 150
Device flags   : Present Running
Interface flags: Link-Layer-Down Point-To-Point SNMP-Traps Internal: 0x4000
Link flags     : No-Keepalives DCE
Hold-times     : Up 0 ms, Down 0 ms
ANSI LMI settings: n392dce 3, n393dce 4, t392dce 15 seconds
LMI statistics:
  Input : 0 (last seen: never)
  Output: 0 (last sent: never)
DTE statistics:
  Enquiries sent           : 0
  Full enquiries sent      : 0
  Enquiry responses received : 0
  Full enquiry responses received : 0
DCE statistics:
  Enquiries received       : 0
  Full enquiries received  : 0
  Enquiry responses sent   : 0
  Full enquiry responses sent : 0
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timedout : 0
CoS queues      : 4 supported, 4 maximum usable queues
Last flapped    : 2005-12-21 09:59:01 PST (1w0d 03:44 ago)
Statistics last cleared: 2005-12-21 10:32:15 PST (1w0d 03:10 ago)
Traffic statistics:
  Input bytes : 0 0 bps
  Output bytes : 0 0 bps
  Input packets: 0 0 pps
  Output packets: 0 0 pps
Input errors:
  Errors: 3, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, L3 incompletes: 0, L2 channel errors: 0,
  L2 mismatch timeouts: 0, HS link CRC errors: 0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,
  Resource errors: 0
HDLC configuration:
  Giant threshold: 1528, Runt threshold: 2
  Timeslots : 5
  Data inversion: Disabled, Idle cycle flag: flags, Start end flag: shared
DSO BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
  Destination slot: 0, PLP byte: 4 (0x01)

Logical interface ds-0/3/4:5.0 (Index 78) (SNMP ifIndex 73) (Generation 17)
Flags: Device-Down Point-To-Point SNMP-Traps Encapsulation: FR-NLPID
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:
  Input bytes : 0
  Output bytes : 0

```

```

      Input packets:          0
      Output packets:        0
      Transit statistics:
      Input bytes  :          0          0 bps
      Output bytes :          0          0 bps
      Input packets:          0          0 pps
      Output packets:         0          0 pps
      Protocol mlfrr, Multilink bundle: ls-0/1/0.1, MTU: 1514, Generation: 28, Route
table: 0
      DLCI 10
      Flags: Active
      Total down time: 0 sec, Last down: Never
      Traffic statistics:
      Input bytes  :          0
      Output bytes :          0
      Input packets:          0
      Output packets:         0
      DLCI statistics:
      Active DLCI  :1 Inactive DLCI :0

```

#### show interfaces detail (Clear Channel E1)

```

user@host> show interfaces e1-1/2/6 detail
Physical interface: e1-1/2/6, Enabled, Physical link is Up
Interface index: 89, SNMP ifIndex: 1278, Generation: 341
Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: E1, Loopback:None,
...
Logical interface e1-1/2/6.0 (Index 52) (SNMP ifIndex 1279) (Generation 169)
Flags: Point-To-Point SNMP-Traps Encapsulation: PPP
Bandwidth: 0
...

```

## show interfaces controller (Channelized E1 IQ)

<b>Syntax</b>	<code>show interfaces controller <i>ce1-fpc/pic/port</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display the interface names of the physical channelized E1 IQ interface and the channels configured on each interface.
<b>Options</b>	<i>ce1-fpc/pic/port</i> —Basic Rate Interface (BRI) interface name.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces controller (Channelized E1 IQ with Logical E1) on page 764</a> <a href="#">show interfaces controller (Channelized E1 IQ with Logical DS0) on page 764</a>
<b>Output Fields</b>	Table 123 on page 764 lists the output fields for the <b>show interfaces controller</b> (Channelized E1 IQ) command. Output fields are listed in the approximate order in which they appear.

**Table 123: Channelized E1 IQ show interfaces controller Output Fields**

Field Name	Field Description
<b>Controller</b>	Physical channelized interface name and the names of any channels configured on it.
<b>Admin</b>	Administrative status of the interface.
<b>Link</b>	Link status of the interface.

## Sample Output

show interfaces controller (Channelized E1 IQ with Logical E1)	user@host> show interfaces controller ce1-1/2/6		
	Controller	Admin	Link
	ce1-1/2/6	up	up
	e1-1/2/6	up	up
show interfaces controller (Channelized E1 IQ with Logical DS0)	user@host> show interfaces controller ce1-1/2/3		
	Controller	Admin	Link
	ce1-1/2/3	up	up
	ds-1/2/3:1	up	up
	ds-1/2/3:2	up	up

# Channelized OC Interface Operational Commands

Table 124 on page 765 summarizes the command-line interface (CLI) commands to monitor and troubleshoot channelized OC interfaces. Commands are listed in alphabetical order.

**Table 124: Channelized OC Interface Operational Mode Commands**

Task or Information to Monitor	CLI Command
Display channelized OC3 IQ and IQE interface information.	<code>show interfaces (Channelized OC3 IQ and IQE)</code>
Display status information about channelized OC12 interfaces.	<code>show interfaces (Channelized OC12)</code>
Display channelized OC12 IQ and IQE interface information.	<code>show interfaces (Channelized OC12 IQ and IQE)</code>
Display the interface names of the physical channelized OC3 IQ and IQE interface and the channels configured on each interface.	<code>show interfaces controller (Channelized OC3 IQ and IQE)</code>
Display the interface names of the physical channelized OC12 IQ and IQE interface and the channels configured on each interface.	<code>show interfaces controller (Channelized OC12 IQ and IQE)</code>
Display channelized OC48 IQ and IQE interface information.	<code>show interfaces (Channelized OC48 IQ and IQE)</code>



**NOTE:** For more information about the channel type and level of channelization, and for information about the number of channels that are supported on channelized OC interfaces, see the *Junos Network Interfaces Configuration Guide*.

For channelization illustrations and configuration examples for channelized IQ and IQE interfaces, see the *Junos Feature Guide*.

## show interfaces (Channelized OC3 IQ and IQE)

<b>Syntax</b>	<pre>show interfaces (type-fpc/pic/port &lt;:channel&gt;&lt;:channel&gt;&lt;:channel&gt;) &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized OC3 IQ or IQE interface.
<b>Options</b>	<p><b>type-fpc/pic/port:channel:channel:channel</b>—Interface type with optional corresponding channel levels. The interface type can be one of the following:</p> <ul style="list-style-type: none"> <li><b>type-fpc/pic/port</b>—For the physical interface, <b>type</b> is <b>coc3</b>. For the clear channel, <b>type</b> is <b>so</b> (for OC3).</li> <li><b>type-fpc/pic/port:channel</b>—At the first level of channelization, <b>type</b> can be <b>coc1</b> (channelized OC1), <b>ct3</b> (from <b>coc1</b>), or <b>t3</b> (from <b>coc1</b>).</li> <li><b>type-fpc/pic/port:channel:channel</b>—At the second level of channelization, <b>type</b> can be <b>ct1</b> (from <b>coc1</b> or <b>ct3</b>) or <b>t1</b> (from <b>coc1</b> or <b>ct3</b>).</li> <li><b>type-fpc/pic/port:channel:channel:channel</b>—At the third level of channelization, <b>type</b> can be <b>ds</b> (from <b>ct1</b>).</li> </ul> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces extensive (Channelized OC3 IQ) (Physical) on page 781</a></p> <p><a href="#">show interfaces extensive (Channelized OC1 on Channelized OC3 IQ) on page 781</a></p> <p><a href="#">show interfaces extensive (Channelized T1 on Channelized OC3 IQ) on page 782</a></p> <p><a href="#">show interfaces extensive (DSO on Channelized OC3 IQ) on page 783</a></p>
<b>Output Fields</b>	Table 125 on page 767 lists the output fields for the <b>show interfaces</b> (all Channelized OC interfaces) command. Output fields are listed in the approximate order in which they appear.



Table 125: Channelized OC show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Description</b>	Interface description.	All levels
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	SONET/SDH reference clock source. It can be <b>Internal</b> or <b>External</b> . Clocking is configured and displayed only for channel 0.	All levels
<b>Framing mode</b>	Framing mode: <b>SONET</b> or <b>SDH</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>SONET loopback</b>	Whether loopback is enabled on a SONET/SDH interface, and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>FCS</b>	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16-bit</b> .	All levels
<b>Payload scrambler</b>	Whether payload scrambling is enabled.	All levels
<b>Parent</b>	Name and interface index of the interface to which a particular child interface belongs. <b>None</b> indicates that this interface is the top level.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>ANSI or ITU LMI settings</b>	<p>(Frame Relay) Settings for Local Management Interface (LMI). The format is (ANSI or ITU) LMI settings: <i>value</i>, <i>value... nn</i> seconds, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li>• <b>n391dte</b>—DTE full status polling interval (1–255)</li> <li>• <b>n392dce</b>—DCE error threshold (1–10)</li> <li>• <b>n392dte</b>—DTE error threshold (1–10)</li> <li>• <b>n393dce</b>—DCE monitored event count (1–10)</li> <li>• <b>n393dte</b>—DTE monitored event count (1–10)</li> <li>• <b>t391dte</b>—DTE polling timer (5–30 seconds)</li> <li>• <b>t392dce</b>—DCE polling verification timer (5–30 seconds)</li> </ul>	All levels
<b>LMI statistics</b>	<p>(Frame Relay) Statistics about the link management.</p> <ul style="list-style-type: none"> <li>• <b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: nn (last sent hh:mm:ss ago)</b>.</li> <li>• <b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: nn (last sent hh:mm:ss ago)</b>.</li> </ul>	detail extensive
<b>DTE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the data terminal equipment (DTE) to the data circuit-terminating equipment (DCE):</p> <ul style="list-style-type: none"> <li>• <b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li>• <b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li>• <b>Enquiry responses received</b>—Number of enquiry responses received by the DTE from the DCE.</li> <li>• <b>Full enquiry responses received</b>—Number of full enquiry responses sent from the DTE to the DCE.</li> </ul>	detail extensive none
<b>DCE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the DCE to the DTE:</p> <ul style="list-style-type: none"> <li>• <b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li>• <b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li>• <b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li>• <b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	detail extensive none
<b>Common statistics</b>	<p>(Frame Relay) Statistics about messages sent between the DTE and the DCE:</p> <ul style="list-style-type: none"> <li>• <b>Unknown messages received</b>—Number of received packets that do not fall into any category.</li> <li>• <b>Asynchronous updates received</b>—Number of link status peer changes received.</li> <li>• <b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li>• <b>Keepalive responses timedout</b>—Number of keepalive responses that timed out when no LMI packet was reported for <b>n392dte</b> or <b>n393dce</b> intervals. (See LMI settings.)</li> </ul>	detail extensive none

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Nonmatching DCE-end DLCIs</b>	(Frame Relay) Number of DLCIs configured from the DCE, displayed only from the DTE.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: <i>year-month-day hh:mm:ss timezone year-month-day (hh:mm:ss ago)</i></b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>CoS Queues</b>	Number of CoS queues configured.	<b>detail extensive none</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>DS1 alarms</b> <b>DS1 defects</b>	<p>Elor T1 media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. See the following list for all possible alarms and defects. For complete explanations of most of these alarms and defects, see <i>Bellcore Telcordia GR-499-CORE</i>.</p> <ul style="list-style-type: none"> <li>• <b>LOS</b>—Loss of signal.</li> <li>• <b>LOF</b>—Loss of frame.</li> <li>• <b>AIS</b>—Alarm indication signal.</li> <li>• <b>YLW</b>—Yellow alarm. Indicates errors at the remote site receiver.</li> </ul>	<b>detail extensive none</b>

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>T1 media</b>	<p>Counts of T1 or E1 media-specific errors.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>The T1 or E1 media-specific error types are:</p> <ul style="list-style-type: none"> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>BEE</b>—Bit error</li> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>PCV</b>—Pulse code violation</li> <li>• <b>CS</b>—Carrier state</li> <li>• <b>FEBE</b>—Far-end block error (E1 only)</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>ES</b>—Errored seconds</li> <li>• <b>BES</b>—Bit error seconds</li> <li>• <b>SES</b>—Severely errored seconds</li> <li>• <b>SEFS</b>—Severely errored framing seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> </ul>	<b>extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runs</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Bucket Drops</b>—Drops caused by traffic load exceeding the interface transmit/receive leaky bucket configuration. The default is off.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>SRAM errors</b>—Number of hardware errors that occurred in the static RAM (SRAM) on the PIC. If the value of this field increments, the PIC is malfunctioning.</li> <li>• <b>HS link FIFO overflows</b>—Number of FIFO overflows on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>HS link FIFO underflows</b>—Number of FIFO underflows on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeds the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Active alarms</b>	Defects that can prevent the interface from passing packets:	<b>detail extensive</b>
<b>Active defects</b>	<ul style="list-style-type: none"> <li>• <b>None</b>—There are no active defects or alarms.</li> <li>• <b>LOF</b>—Loss of frame.</li> </ul>	
<b>SONET alarms</b>	Media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm.	All levels
<b>SONET defects</b>	Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router or light the red or yellow alarm LED on the craft interface. See these fields for possible alarms and defects: <b>SONET PHY</b> , <b>SONET section</b> , <b>SONET line</b> , and <b>SONET path</b> .	

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
SONET vt	<p>SONET virtual-tributary (VT) alarms and defects:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>REI-V</b>—Remote error indication (near-end VT)</li> <li>• <b>LOP-V</b>—Loss of pointer (near-end VT)</li> <li>• <b>AIS-V</b>—Alarm indication signal (near-end VT)</li> <li>• <b>RDI-V</b>—Remote defect indication (near-end VT)</li> <li>• <b>UNEQ-V</b>—Unequipped (near-end VT)</li> <li>• <b>PLM-V</b>—Payload label mismatch (near-end VT)</li> <li>• <b>ES-V</b>—Errored seconds (near-end VT)</li> <li>• <b>SES-V</b>—Severely errored seconds (near-end VT)</li> <li>• <b>UAS-V</b>—Unavailable seconds (near-end VT)</li> <li>• <b>ES-VFE</b>—Errored seconds (far-end VT)</li> <li>• <b>SES-VFE</b>—Severely errored seconds (far-end VT)</li> <li>• <b>UAS-VFE</b>—Unavailable seconds (far-end VT)</li> </ul>	extensive
SONET PHY	<p>Counts of specific SONET errors with detailed information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	extensive
SONET section	<p>Counts of specific SONET errors with detailed information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B1</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>LOL</b>—Loss of light</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>ES-S</b>—Errored seconds (section)</li> <li>• <b>SES-S</b>—Severely errored seconds (section)</li> <li>• <b>SEFS-S</b>—Severely errored framing seconds (section)</li> </ul>	extensive

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SONET line</b>	<p>Active alarms and defects, plus counts of specific SONET errors with detailed information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>REI-L</b>—Remote error indication (near-end line)</li> <li>• <b>RDI-L</b>—Remote defect indication (near-end line)</li> <li>• <b>AIS-L</b>—Alarm indication signal (near-end line)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>ES-L</b>—Errored seconds (near-end line)</li> <li>• <b>SES-L</b>—Severely errored seconds (near-end line)</li> <li>• <b>UAS-L</b>—Unavailable seconds (near-end line)</li> <li>• <b>ES-LFE</b>—Errored seconds (far-end line)</li> <li>• <b>SES-LFE</b>—Severely errored seconds (far-end line)</li> <li>• <b>UAS-LFE</b>—Unavailable seconds (far-end line)</li> </ul>	<b>extensive</b>
<b>SONET path</b>	<p>Active alarms and defects, plus counts of specific SONET errors with detailed information:</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>BIP-B3</b>—Bit interleaved parity for SONET section overhead</li> <li>• <b>REI-P</b>—Remote error indication</li> <li>• <b>LOP-P</b>—Loss of pointer (path)</li> <li>• <b>AIS-P</b>—Path alarm indication signal</li> <li>• <b>RDI-P</b>—Path remote defect indication</li> <li>• <b>UNEQ-P</b>—Path unequipped</li> <li>• <b>PLM-P</b>—Path payload (signal) label mismatch</li> <li>• <b>ES-P</b>—Errored seconds (near-end STS path)</li> <li>• <b>SES-P</b>—Severely errored seconds (near-end STS path)</li> <li>• <b>UAS-P</b>—Unavailable seconds (near-end STS path)</li> <li>• <b>ES-PFE</b>—Errored seconds (far-end STS path)</li> <li>• <b>SES-PFE</b>—Severely errored seconds (far-end STS path)</li> <li>• <b>UAS-PFE</b>—Unavailable seconds (far-end STS path)</li> </ul>	<b>extensive</b>



Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Received SONET overhead	Values of the received and transmitted SONET/SDH overhead:	extensive
Transmitted SONET overhead	<p>F1—Section user channel byte. This byte is set aside for the purposes of users.</p> <p>S1—Synchronization Status (S1). The S1 byte is located in the first STS-1 of an STS-N. Bits 5 through 8 convey the synchronization status of the network element.</p> <p>Z3 and Z4—Path overhead.</p> <p>V5—Virtual Tributary (VT) path overhead byte.</p>	
SDH alarms	SDH media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router or light the red or yellow alarm LED on the craft interface. See these fields for possible alarms and defects: SDH PHY, SDH regenerator section, SDH multiplex section, and SDH path.	All levels
SDH defects	<p><b>NOTE:</b> For controller based SONET PICs, the SDH alarms and SDH defects output in the <b>show interface coc3 extensive</b> command output only shows the section and line level defects. The path level defects can be found under the SONET (so) interface output.</p>	
SDH PHY	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	extensive
SDH regenerator section	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>RS-BIP8</b>—24-bit BIP for multiplex section overhead (B2 bytes)</li> <li>• <b>OOF</b>—Out of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>RS-ES</b>—Errored seconds (near-end regenerator section)</li> <li>• <b>RS-SES</b>—Severely errored seconds (near-end regenerator section)</li> <li>• <b>RS-SEFS</b>—Severely errored framing seconds (regenerator section)</li> </ul>	extensive

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SDH multiplex section</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>MS-BIP24</b>—8-bit BIP for high-order path overhead (B3 byte)</li> <li>• <b>MS-FEBE</b>—Far-end block error (multiplex section)</li> <li>• <b>MS-FERF</b>—Far-end remote fail (multiplex section)</li> <li>• <b>MS-AIS</b>—alarm indication signal (multiplex section)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>MS-ES</b>—Errored seconds (near-end multiplex section)</li> <li>• <b>MS-SES</b>—Severely errored seconds (near-end multiplex section)</li> <li>• <b>MS-UAS</b>—Unavailable seconds (near-end multiplex section)</li> <li>• <b>MS-ES-FE</b>—Errored seconds (far-end multiplex section)</li> <li>• <b>MS-SES-FE</b>—Severely errored seconds (far-end multiplex section)</li> <li>• <b>MS-UAS-FE</b>—Unavailable seconds (far-end multiplex section)</li> </ul>	<b>extensive</b>
<b>SDH path</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>HP-BIP8</b>—8-bit BIP for regenerator section overhead (B1 byte)</li> <li>• <b>HP-FEBE</b>—Far-end block error (high-order path)</li> <li>• <b>HP-LOP</b>—Loss of pointer (high-order path)</li> <li>• <b>HP-AIS</b>—High-order-path alarm indication signal</li> <li>• <b>HP-FERF</b>—Far-end remote fail (high-order path)</li> <li>• <b>HP-UNEQ</b>—Unequipped (high-order path)</li> <li>• <b>HP-PLM</b>—Payload label mismatch (high-order path)</li> <li>• <b>HP-ES</b>—Errored seconds (near-end high-order path)</li> <li>• <b>HP-SES</b>—Severely errored seconds (near-end high-order path)</li> <li>• <b>HP-UAS</b>—Unavailable seconds (near-end high-order path)</li> <li>• <b>HP-ES-FE</b>—Errored seconds (far-end high-order path)</li> <li>• <b>HP-SES-FE</b>—Severely errored seconds (far-end high-order path)</li> <li>• <b>HP-UAS-FE</b>—Unavailable seconds (far-end high-order path)</li> </ul>	<b>extensive</b>

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Received SDH overhead	Values of the received and transmitted SONET overhead:	extensive
Transmitted SDH overhead	<ul style="list-style-type: none"> <li>• <b>C2</b>—Signal label. Allocated to identify the construction and content of the STS-level SPE and for PDI-P.</li> <li>• <b>F1</b>—Section user channel byte. This byte is set aside for the purposes of users.</li> <li>• <b>K1</b> and <b>K2</b>—These bytes are allocated for APS signaling for the protection of the multiplex section.</li> <li>• <b>J0</b>—Section trace. This byte is defined for STS-1 number 1 of an STS-<i>N</i> signal. Used to transmit a 1-byte fixed-length string or a 16-byte message so that a receiving terminal in a section can verify its continued connection to the intended transmitter.</li> <li>• <b>S1</b>—Synchronization status. The S1 byte is located in the first STS-1 of an STS-<i>N</i>.</li> <li>• <b>Z3</b> and <b>Z4</b>—Allocated for future use.</li> </ul>	
Received path trace	Channelized OC12 interfaces allow path trace bytes to be sent inband across the SONET/SDH link. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits. This information is specific to each of the 12 channelized OC12 interfaces.	extensive
Transmitted path trace		
DS3 media	<p>Counts of T3 media-specific errors. For detailed definitions of the T3 (DS-3) error events (BPV, EXZ, LCV, PCV, and CCV) and performance parameters (LES, PES, PSES, CES, CSES, SEFS, and UAS), see RFC 2496.</p> <p>The DS3 or E3 media-specific error types can be:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop out of lock</li> <li>• <b>Reframing</b>—Frame alignment recovery time</li> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>IDLE</b>—Idle code detected</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>PCV</b>—(DS3 only) Pulse code violation</li> <li>• <b>CCV</b>—(DS3 only) C-bit coding violation</li> <li>• <b>FEBE</b>—(DS3 only) Far-end block error</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>PES</b>—(DS3 only) P-bit errored seconds</li> <li>• <b>PSES</b>—(DS3 only) P-bit errored seconds (section)</li> <li>• <b>CES</b>—(DS3 only) C-bit errored seconds</li> <li>• <b>CSES</b>—(DS3 only) C-bit severely errored seconds</li> <li>• <b>SEFS</b>—Severely errored framing seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> </ul>	extensive

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>HDLC configuration</b>	<p>Information about the HDLC configuration.</p> <ul style="list-style-type: none"> <li>• <b>Policing bucket</b>—Configured state of the receiving policer.</li> <li>• <b>Shaping bucket</b>—Configured state of the transmitting shaper.</li> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> <li>• <b>Timeslots</b>—Configured time slots for the interface.</li> <li>• <b>Line encoding</b>—Line encoding used. It is always <b>HDB3</b>.</li> <li>• <b>Byte encoding</b>—(T1 only) Byte encoding used: <b>Nx64K</b> or <b>Nx56K</b>.</li> <li>• <b>Line encoding</b>—Line encoding used. For T1, the value can be <b>B8ZS</b> or <b>AMI</b>. For E1, the value is <b>HDB3</b>.</li> <li>• <b>Data inversion</b>—HDLC data inversion setting: <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Idle cycle flag</b>—Idle cycle flags.</li> <li>• <b>Start end flag</b>—Start and end flag.</li> </ul>	<b>extensive</b>
<b>Interface transmit queues</b>	<p>Name of the transmit queues and their associated statistics for each DS3 channel on the Channelized OC12 PIC.</p> <ul style="list-style-type: none"> <li>• <b>B/W</b>—Queue bandwidth as a percentage of the total interface bandwidth.</li> <li>• <b>WRR</b>—Weighted round-robin (in percent).</li> <li>• <b>Packets</b>—Number of packets transmitted.</li> <li>• <b>Bytes</b>—Number of bytes transmitted.</li> <li>• <b>Drops</b>—Number of packets dropped.</li> <li>• <b>Errors</b>—Number of packet errors.</li> </ul>	<b>extensive</b>
<b>DSU configuration</b>	<p>Information about the DSU configuration. The last three lines (<b>Bit count</b>, <b>Error bit count</b>, and <b>LOS information</b>) are displayed only if a BERT has ever been run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>Compatibility mode</b>—CSU/DSU compatibility mode: <b>None</b>, <b>Larscom</b>, <b>Kentrox</b>, or <b>Digital-Link</b>.</li> <li>• <b>Scrambling</b>—Payload scrambling. It can be <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Subrate</b>—Configured subrate setting. Applies only when <b>Digital-Link</b> compatibility mode is used. It can be <b>Disabled</b> or display units in kbps.</li> <li>• <b>FEAC loopback</b>—(T3) Whether a far-end alarm and control (FEAC) loopback is <b>Active</b> or <b>Inactive</b>. This feature is used to send alarm or status information from the far-end terminal back to the near-end terminal and to initiate T3 loopbacks at the far-end terminal from the near-end terminal.</li> <li>• <b>Response</b>—Whether the FEAC signal is <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Count</b>—Number of FEAC loopbacks.</li> </ul>	<b>extensive</b>
<b>BERT configuration</b>	<p>(DS interfaces) BERT (bit error rate test) checks the quality of the line. This output appears only when a BERT is run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>BERT time period</b>—Configured total time period that the BERT is to run.</li> <li>• <b>Elapsed</b>—Actual time elapsed since the start of the BERT (in seconds).</li> <li>• <b>Induced error rate</b>—Configured rate at which the bit errors are induced in the BERT pattern.</li> <li>• <b>Algorithm</b>—Type of algorithm selected for the BERT.</li> </ul>	<b>detail extensive none</b>

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Packet Forwarding Engine configuration</b>	Information about the configuration of the Packet Forwarding Engine: <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Traffic statistics</b>	Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize. <ul style="list-style-type: none"> <li>• <b>Input rate</b>—Rate of bits and packets received on the interface.</li> <li>• <b>Output rate</b>—Rate of bits and packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>

Table 125: Channelized OC show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b>Multilink bundle</b>	(If the logical interface is configured as part of a multilink bundle.) Interface name for the multilink bundle.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the "Addresses Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>DLCI</b>	<p>(Frame Relay) DLCI number of the logical interface. The following DLCI information is displayed: <b>Flags</b>, <b>Total down time</b>, <b>Last down</b>, and <b>Traffic statistics</b>. <b>Flags</b> is one or more of the following:</p> <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when the link is active, but no information is received from the DCE.</li> <li>• <b>Unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the corresponding DLCI in the DCE is configured.</li> <li>• <b>Dce-configured</b>—Displayed when the command is issued from the DTE.</li> </ul>	<b>detail extensive none</b>
<b>DLCI statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	<b>detail extensive none</b>

## Sample Output

show interfaces  
extensive (Channelized  
OC3 IQ) (Physical)

```
user@host> show interfaces extensive coc3-0/0/0
Physical interface: coc3-0/0/0, Enabled, Physical link is Down
Interface index: 128, SNMP ifIndex: 22, Generation: 11
Description: pink coc3-0/0/0
Link-level type: Controller, Clocking: Internal, SONET mode, Speed: OC3,
Loopback: None, Parent: None
Device flags   : Present Running Down
Interface flags: Hardware-Down Point-To-Point SNMP-Traps 16384
Link flags     : None
Hold-times     : Up 0 ms, Down 0 ms
CoS queues     : 4 supported
Last flapped   : 2005-01-27 16:39:21 PST (1w0d 22:09 ago)
Statistics last cleared: Never
SONET alarms   : PLL, LOS
SONET defects  : PLL, LOF, LOS, SEF, AIS-L
SONET PHY:
  Seconds      Count  State
  PLL Lock     681767    1  PLL Lock Error
  PHY Light     0         0  OK
SONET section:
  BIP-B1        0         0
  SEF           681767    1  Defect Active
  LOS           681767    1  Defect Active
  LOF           681767    1  Defect Active
  ES-S          681767
  SES-S         681767
  SEFS-S        681767
SONET line:
  BIP-B2        0         0
  REI-L         0         0
  RDI-L         0         0  OK
  AIS-L         681767    1  Defect Active
  BERR-SF       0         0  OK
  BERR-SD       0         0  OK
  ES-L          681767
  SES-L         681767
  UAS-L         681757
  ES-LFE        0
  SES-LFE       0
  UAS-LFE       0
Received SONET overhead:
  F1      : 0x00, J0      : 0x00, K1      : 0xff, K2      : 0xff
  S1      : 0xff
Transmitted SONET overhead:
  F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
  S1      : 0x00
```

show interfaces  
extensive (Channelized

```
user@host> show interfaces extensive coc1-0/0/0:1
Physical interface: coc1-0/0/0:1, Enabled, Physical link is Down
Interface index: 133, SNMP ifIndex: 27, Generation: 16
```

## OC1 on Channelized OC3 IQ)

Link-level type: Controller, Clocking: Internal, SONET mode, Speed: 51840kbps,

Loopback: None, Parent: coc3-0/0/0

Interface index 128

Device flags : Present Running Down 16384

Interface flags: Hardware-Down Point-To-Point SNMP-Traps 16384

Link flags : None

Hold-times : Up 0 ms, Down 0 ms

CoS queues : 4 supported

Last flapped : 2005-02-04 14:51:07 PST (00:00:35 ago)

Statistics last cleared: Never

SONET alarms : None

SONET defects : AIS-P

SONET path:

BIP-B3	0	0	
REI-P	0	0	
LOP-P	0	0	OK
AIS-P	36	1	Defect Active
RDI-P	0	0	OK
UNEQ-P	0	0	OK
PLM-P	0	0	OK
ES-P	36		
SES-P	36		
UAS-P	26		
ES-PFE	0		
SES-PFE	0		
UAS-PFE	0		

Received SONET overhead:

C2 : 0xff, C2(cmp) : 0x01, F2 : 0x00, Z3 : 0x00  
Z4 : 0x00, S1(cmp) : 0x00

Transmitted SONET overhead:

C2 : 0x01, F2 : 0x00, Z3 : 0x00, Z4 : 0x00

Received path trace:

```
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
```

Transmitted path trace: router-1 coc1-0/0/0:1

```
6b 61 76 65 72 69 20 63 6f 63 31 2d 30 2f 30 2f router-1 coc1-0/0/0:1
30 3a 31 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
```

Packet Forwarding Engine configuration:

Destination slot: 0 (0x00)

## show interfaces extensive(Channelized

user@host> show interfaces extensive ct1-0/0/0:1:1

Physical interface: ct1-0/0/0:1:1, Enabled, Physical link is Down

Interface index: 134, SNMP ifIndex: 62, Generation: 17



### T1 on Channelized OC3 IQ)

```

Link-level type: Controller, Clocking: Internal, Speed: T1, Loopback: None,
Framing: ESF, Parent: coc1-0/0/0:1 Interface index 133
Device flags   : Present Running Down 16384
Interface flags: Hardware-Down Point-To-Point SNMP-Traps 16384
Link flags     : None
Hold-times     : Up 0 ms, Down 0 ms
CoS queues     : 4 supported
Last flapped   : 2005-02-04 14:54:35 PST (00:00:18 ago)
Statistics last cleared: Never
DS1 alarms     : None
DS1 defects    : AIS, LOF
T1 media:
      Seconds      Count  State
SEF              1       1  OK
BEE              1       1  OK
AIS             18       1 Defect Active
LOF             18       1 Defect Active
LOS              0       0  OK
YELLOW           0       0  OK
BPV              0       0
EXZ              0       0
LCV              0       0
PCV              0       0
CS               0       0
LES             18
ES              18
SES             18
SEFS            18
BES              0
UAS             14
DS1 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
SONET alarms    : None
SONET defects    : None
SONET vt:
      BIP-BIP2      0       0
      REI-V         0       0
      LOP-V         0       0  OK
      AIS-V         19       1 Defect Active
      RDI-V         19       1 Defect Active
      UNEQ-V        0       0  OK
      PLM-V         19       1 Defect Active
      ES-V          19
      SES-V         19
      UAS-V         9
      ES-VFE        0
      SES-VFE       0
      UAS-VFE       0
Received SONET overhead:
  V5      : 0x07, V5(cmp) : 0x02
Transmitted SONET overhead:
  V5      : 0x02
Packet Forwarding Engine configuration:
  Destination slot: 0 (0x00)

```

### show interfaces extensive (DS0 on Channelized OC3 IQ)

```

user@host> show interfaces extensive ds-0/0/0:1:1
Physical interface: ds-0/0/0:1:1:1, Enabled, Physical link is Down
Interface index: 135, SNMP ifIndex: 63, Generation: 18
Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: 320kbps,
Loopback: None, FCS: 16, Parent: ct1-0/0/0:1:1 Interface index 134
Device flags   : Present Running

```

```
Interface flags: Hardware-Down Point-To-Point SNMP-Traps 16384
Link flags      : Keepalives
Hold-times     : Up 0 ms, Down 0 ms
CoS queues     : 4 supported
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes    :                0                0 bps
Output bytes   :                0                0 bps
Input packets  :                0                0 pps
Output packets :                0                0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Policed discards: 0, L3 incompletes: 0, L2 channel errors: 0,
L2 mismatch timeouts: 0, HS link CRC errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0, MTU errors: 0,
Resource errors: 0
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort                0                0                0

1 expedited-fo                0                0                0

2 assured-forw                0                0                0

3 network-cont                0                0                0

HDLC configuration:
Giant threshold: 1514, Runt threshold: 2
Timeslots      : 1-5
Byte encoding: Nx64K, Data inversion: Disabled, Idle cycle flag: flags,
Start end flag: shared
DSO BERT configuration:
BERT time period: 10 seconds, Elapsed: 0 seconds
Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
Destination slot: 0, PLP byte: 4 (0x00)
```

## show interfaces (Channelized OC12)

<b>Syntax</b>	<pre>show interfaces t3-fpc/pic/port:t3channel &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified channelized OC12 interface.
<b>Options</b>	<p><b>t3-fpc/pic/port:t3channel</b>—Display standard information about the specified channelized OC12 interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Channelized OC12) on page 786</a>
<b>Output Fields</b>	See the output field table for the <a href="#">show interfaces (Channelized OC3 IQ and IQE)</a> command.

## Sample Output

show interfaces  
extensive (Channelized  
OC12)

```
user@host> show interfaces t3-0/3/0:0 extensive
Physical interface: t3-0/3/0:0, Enabled, Physical link is Up
  Interface index: 32, SNMP ifIndex: 21, Generation: 2719
  Link-level type: Frame-Relay, PPP, MTU: 4474, Clocking: Internal, SONET mode,
  Speed: T3, Loopback: None, SONET Loopback: None, FCS: 16, Mode: C/Bit parity
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : Keepalives DTE
  ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
  LMI: Input: 51700 (00:00:02 ago), Output: 51701 (00:00:02 ago)
  DTE statistics:
    Enquiries sent           : 43186
    Full enquiries sent      : 8515
    Enquiry responses received : 43185
    Full enquiry responses received : 8515
  DCE statistics:
    Enquiries received       : 0
    Full enquiries received  : 0
    Enquiry responses sent   : 0
    Full enquiry responses sent : 0
  Common statistics:
    Unknown messages received : 0
    Asynchronous updates received : 0
    Out-of-sequence packets received : 0
    Keepalive responses timedout : 0
  Nonmatching DCE-end DLCIs:
    2
  Hold-times      : Up 0 ms, Down 0 ms
  Last flapped   : 2002-05-23 16:59:03 PDT (18:23:58 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes  : 1700          0 bps
    Output bytes : 1714          0 bps
    Input packets: 123           0 pps
    Output packets: 124          0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 1100817, Bucket drops: 0,
    Policed discards: 0, L3 incompletes: 0, L2 channel errors: 0,
    L2 mismatch timeouts: 0, HS link CRC errors: 0, SRAM errors: 0
  Output errors:
    Carrier transitions: 3, Errors: 0, Drops: 0, Aged packets: 0
  DS3 alarms : None
  SONET alarms : None
  DS3 defects : None
  SONET defects : None
  DS3 media:
    Seconds      Count  State
    AIS          0      0 OK
    LOF          18      1 OK
    LOS          0      0 OK
    IDLE         0      0 OK
    YELLOW       0      0 OK
    BPV          0      0
    EXZ          0      0
    LCV          0      0
    PCV          36     122399
    CCV          72     91948
    LES          0
    PES          18
```

```

PSES                      18
CES                      18
CSES                     18
SEFS                     18
UAS                      0
HDLC configuration:
  Policing bucket: Disabled
  Shaping bucket : Disabled
  Giant threshold: 4484, Runt threshold: 3
DSU configuration:
  Compatibility mode: None, Scrambling: Disabled, Subrate: Disabled
  FEAC loopback: Inactive, Response: Disabled, Count: 0
DS3 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Algorithm: Unknown (0), Induced error rate: 10e-0
Interface transmit queues:
      B/W  WRR      Packets      Bytes      Drops      Errors
Queue0   95   95          0          0          0          0
Queue1    5    5        529        6348          0          0
SONET PHY:
      Seconds      Count  State
  PLL Lock          0        0  OK
  PHY Light        20        1  OK
SONET section:
      BIP-B1          0        0
      SEF            20        1  OK
      LOS            20        1  OK
      LOF            20        1  OK
      ES-S           20
      SES-S          20
      SEFS-S         20
SONET line:
      BIP-B2          0        0
      REI-L           0        0
      RDI-L           0        0  OK
      AIS-L           0        0  OK
      BERR-SF         18        1  OK
      BERR-SD          2        1  OK
      ES-L            20
      SES-L           20
      UAS-L           10
      ES-LFE          0
      SES-LFE         0
      UAS-LFE         0
SONET path:
      BIP-B3          0        0
      REI-P           0        0
      LOP-P           20        1  OK
      AIS-P           0        0  OK
      RDI-P           0        0  OK
      UNEQ-P          0        0  OK
      PLM-P           20        1  OK
      ES-P            20
      SES-P           20
      UAS-P           10
      ES-PFE          0
      SES-PFE         0
      UAS-PFE         0
Received SONET overhead:
F1      : 0x00, J0      : 0x00, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0x04, C2(cmp) : 0x04, F2      : 0x00
Z3      : 0x00, Z4      : 0x00, S1(cmp) : 0x00, V5      : 0x00

```

```

V5(cmp) : 0x00
Transmitted SONET overhead:
  F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
  S1      : 0x00, C2      : 0x04, F2      : 0x00, Z3      : 0x00
  Z4      : 0x00, V5      : 0x00
Received path trace: t3-0/3/0:0
  74 33 2d 30 2f 33 2f 30 3a 30 00 00 00 0d 0a  t3-0/3/0:0.....
Transmitted path trace: t3-0/3/0:0
  74 33 2d 30 2f 33 2f 30 3a 30 00 00 00 00 00  t3-0/3/0:0.....
Packet Forwarding Engine configuration:
  Destination slot: 0, PLP byte: 1 (0x00)
CoS information:
  CoS transmit queue      Bandwidth      Buffer Priority  Limit
                           %      bps      %      usec
  0 best-effort           95      42499200  95      0      low  none
  3 network-control       5       2236800   5       0      low  none
Logical interface t3-0/3/0:0.0 (Index 11) (SNMP ifIndex 268) (Generation 499)
Flags: Point-To-Point SNMP-Traps Encapsulation: PPP
Protocol inet, MTU: 4470, Generation: 578, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 22.22.22.1, Local: 22.22.22.2, Broadcast: Unspecified,
Generation: 98
DLCI 100
  Flags: Active, Dce-configured
  Total down time: 0 sec, Last down: Never
  Traffic statistics:
    Input bytes : 0
    Output bytes : 0
    Input packets: 0
    Output packets: 0
  DLCI statistics:
    Active DLCI :2 Inactive DLCI : 0

```

## show interfaces (Channelized OC12 IQ and IQE)

**Syntax** `show interfaces (type-fpc/pic/port<:channel><:channel><:channel>)  
<brief | detail | extensive | terse>  
<descriptions>  
<media>  
<snmp-index snmp-index>  
<statistics>`

**Release Information** Command introduced before Junos OS Release 7.4.

**Description** Display status information about the specified channelized OC12 IQ and IQE interface.

**Options** `type-fpc/pic/port:channel:channel:channel`—Interface type with optional corresponding channel levels.

For SONET mode, the interface type can be one of the following:

- `type-fpc/pic/port`—For the physical channelized OC12 IQ or IQE interface, **type** is `coc12`. For the clear channel, **type** is `so` (for OC12).
- `type-fpc/pic/port:channel`—At the first level of channelization, **type** can be `coc1` (channelized OC1), `ct3` (from `coc1`), `so` (for OC3), or `t3`.
- `type-fpc/pic/port:channel:channel`—At the second level of channelization, **type** can be `ct1` (from `ct3` or `coc1`) or `t1` (from `ct3` or `coc1`).
- `type-fpc/pic/port:channel:channel:channel`—At the third level of channelization, **type** is `ds` (from `ct1`).

For SDH mode, the interface type can be one of the following:

- `type-fpc/pic/port`—For the physical channelized OC12 IQ or IQE interface, **type** is `cstm4`. For the clear channel, **type** is `so` (for SONET/SDH (vc-4-4c)).
- `type-fpc/pic/port:channel`—At the first level of channelization, **type** can be `so` (from `cstm4`) or `cau4` (from `cstm4`).
- `type-fpc/pic/port:channel:channel`—At the second level of channelization, **type** can be `ct3` or `t3` (from or `cau4`).
- `type-fpc/pic/port:channel:channel:channel`—At the third level of channelization, **type** is `ct1` or `t1` (from `ct3`).
- `type-fpc/pic/port:channel:channel:channel:channel`—At the fourth level of channelization, **type** is `ds` (from `ct1`).

**brief | detail | extensive | terse**—(Optional) Display the specified level of output.

**descriptions**—(Optional) Display interface description strings.

**media**—(Optional) Display media-specific information about network interfaces.

**snmp-index snmp-index**—(Optional) Display information for the specified SNMP index of the interface.

**statistics**—(Optional) Display static interface statistics.

<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (CAU4 on Channelized OC-12 IQ) on page 790</a> <a href="#">show interfaces extensive (Channelized OC1 on Channelized OC12 IQ) on page 790</a> <a href="#">show interfaces extensive (Channelized OC12 IQ) (Physical) on page 791</a> <a href="#">show interfaces extensive (Channelized T1 from Channelized OC12 IQ) on page 791</a> <a href="#">show interfaces extensive (Channelized T3 on Channelized OC12 IQ) on page 791</a> <a href="#">show interfaces extensive (CSTM4 on Channelized OC-12 IQ) on page 792</a> <a href="#">show interfaces extensive (DS0 on Channelized OC12 IQ) on page 792</a> <a href="#">show interfaces extensive (SONET Interface on Channelized OC12 IQ) on page 792</a> <a href="#">show interfaces extensive (T1 on Channelized OC12 IQ) on page 792</a>
<b>Output Fields</b>	See the output field table for the <a href="#">show interfaces (Channelized OC3 IQ and IQE)</a> command.

## Sample Output

[show interfaces extensive \(CAU4 on Channelized OC-12 IQ\)](#)

```
user@host> show interfaces cau4-0/2/0:1 extensive
Physical interface: cau4-0/2/0:1, Enabled, Physical link is Up
  Interface index: 219, SNMP ifIndex: 139, Generation: 221
  Link-level type: Controller, Clocking: Internal, SDH mode, Speed: OC3,
  Loopback: None, Parent: cstm4-0/2/0 Interface index 216
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : None
...
```

[show interfaces extensive \(Channelized](#)

```
user@host> show interfaces extensive coc1-4/2/0:7
Physical interface: coc1-4/2/0:7, Enabled, Physical link is Up
  Interface index: 381, SNMP ifIndex: 2524, Generation: 728
```



### OC1 on Channelized OC12 IQ)

```
Link-level type: Controller, MTU: 4474, Clocking: Internal, SONET mode,
Speed: 51840kbps, Loopback: None,
FCS: 16, Payload scrambler: Disabled, Parent: coc12-4/2/0 (Index 266)
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps
Link flags     : None
...
```

### show interfaces extensive (Channelized OC12 IQ) (Physical)

```
user@host> show interfaces extensive coc12-4/2/0
Physical interface: coc12-4/2/0, Enabled, Physical link is Up
Interface index: 266, SNMP ifIndex: 1269, Generation: 601
Link-level type: Controller, MTU: 4474, Clocking: Internal, SONET mode,
Speed: OC12, Loopback: None,
FCS: 16, Payload scrambler: Disabled, Parent: None Device flags   : Present
Running
Interface flags: Point-To-Point SNMP-Traps
Link flags     : Keepalives DTE
...
```

### show interfaces extensive (Channelized T1 from Channelized OC12 IQ)

```
user@host> show interfaces extensive ct1-4/2/0:7:1
Physical interface: ct1-4/2/0:4:1, Enabled, Physical link is Up
Interface index: 305, SNMP ifIndex: 2410, Generation: 640
Link-level type: Controller, MTU: 1504, Clocking: Internal, Speed: T1,
Loopback: None, FCS: 16,
Framing: ESF, Parent: coc1-4/2/0:7 (Index 304)
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps
Link flags     : None
...
```

### show interfaces extensive (Channelized

```
user@host> show interfaces ct3-0/2/0:1 extensive
Physical interface: ct3-0/2/0:1:1, Enabled, Physical link is Up
Interface index: 220, SNMP ifIndex: 140, Generation: 222
```

**T3 on Channelized OC12 IQ)**

```
Link-level type: Controller, Clocking: Internal, Speed: T3, Loopback: None,
Mode: C/Bit parity, Parent: cau4-0/2/0:1 Interface index 219
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags : None
```

```
...
```

**show interfaces extensive (CSTM4 on Channelized OC-12 IQ)**

```
user@host> show interfaces cstm4-0/2/0 extensive
Physical interface: cstm4-0/2/0, Enabled, Physical link is Up
Interface index: 216, SNMP ifIndex: 33, Generation: 218
Link-level type: Controller, Clocking: Internal, SDH mode, Speed: OC12,
Loopback: None, Parent: None Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags : None
```

```
...
```

**show interfaces extensive (DS0 on Channelized OC12 IQ)**

```
user@host> show interfaces extensive ds-4/2/0:7:1:1
Physical interface: ds-4/2/0:4:1:1, Enabled, Physical link is Up
Interface index: 306, SNMP ifIndex: 2411, Generation: 641
Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: 64kbps,
Loopback: None, FCS: 16, Parent: ct1-4/2/0:7:1 (Index 305)
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps
Link flags : Keepalives
```

```
...
```

**show interfaces extensive (SONET Interface on Channelized OC12 IQ)**

```
user@host> show interfaces so-0/2/0:1 extensive
Physical interface: so-0/2/0:1, Enabled, Physical link is Up
Interface index: 750, SNMP ifIndex: 23, Generation: 11709
Link-level type: Multilink-FR, MTU: 4474, Clocking: Internal, SONET mode,
Speed: OC3, Loopback: None, FCS: 16,
Payload scrambler: Enabled, Parent: coc12-0/2/0 Interface index 749
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags : Keepalives DTE
```

```
...
```

**show interfaces extensive (T1 on Channelized OC12 IQ)**

```
user@host> show interfaces t1-0/2/0:1:1:1 extensive
Physical interface: t1-0/2/0:1:1:1, Enabled, Physical link is Up
Interface index: 222, SNMP ifIndex: 143, Generation: 226
Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: T1,
Loopback: None, FCS: 16, Framing: ESF, Parent: ct3-0/2/0:1:1
Interface index 221
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Link flags : Keepalives
```

```
...
```

## show interfaces controller (Channelized OC3 IQ and IQE)

<b>Syntax</b>	<code>show interfaces controller coc3-<i>fpc/pic/slot</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display a list of channels configured on a channelized OC3 IQ and IQE interface.
<b>Options</b>	<code>coc3-<i>fpc/pic/slot</i></code> —channelized OC3 IQ or IQE interface name.
<b>Required Privilege Level</b>	view

**List of Sample Output** [show interfaces controller \(Channelized OC3 IQ\) on page 793](#)

**Output Fields** [Table 126 on page 793](#) lists the output fields for the **show interfaces controller** (Channelized OC3 IQ) command. Output fields are listed in the approximate order in which they appear.

**Table 126: Channelized OC3 IQ and IQE show interfaces controller Output Fields**

Field Name	Field Description
<b>Controller</b>	Physical channelized interface name and the names of any channels configured on it.
<b>Admin</b>	Administrative status of the interface.
<b>Link</b>	Link status of the interface.

## Sample Output

```

show interfaces controller (Channelized OC3 IQ)
user@host> show interfaces controller coc3-4/2/0
Controller
coc3-4/2/0
  coc1-4/2/0:1
    ct1-4/2/0:1:1
      ds-4/2/0:1:1:1
ct3-0/2/0
ct3-0/2/1
ct3-0/2/2
ct3-0/2/3
Admin Link
up      up
up      up
up      up
up      up
up      up
up      up
up      up

```

## show interfaces controller (Channelized OC12 IQ and IQE)

<b>Syntax</b>	<code>show interfaces controller coc12-<i>fpc/pic/port</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display a list of channels configured on a channelized OC12 IQ or IQE interface.
<b>Options</b>	<code>coc12-<i>fpc/pic/slot</i></code> —Channelized OC12 IQ or IQE interface name.
<b>Required Privilege Level</b>	view

**List of Sample Output** [show interfaces controller \(Channelized OC12 IQ\) on page 795](#)

**Output Fields** [Table 127 on page 794](#) lists the output fields for the **show interfaces controller** (Channelized OC12 IQ and IQE) command. Output fields are listed in the approximate order in which they appear.

**Table 127: Channelized OC12 IQ and IQE show interfaces controller Output Fields**

Field Name	Field Description
<b>Controller</b>	Physical channelized interface name and the names of any channels configured on it.
<b>Admin</b>	Administrative status of the interface.
<b>Link</b>	Link status of the interface.

## Sample Output

```

show interfaces controller
(Channelized OC12 IQ)
user@host> show interfaces controller
Controller
coc12-4/2/0
  so-4/2/0:1
  t3-4/2/0:2
  ct3-4/2/0:3
    t1-4/2/0:3:1
    t1-4/2/0:3:2
  ...
    t1-4/2/0:3:28
  ct3-4/2/0:4
    ct1-4/2/0:4:1
      ds-4/2/0:4:1:1
      ds-4/2/0:4:1:2
    ...
      ds-4/2/0:4:1:24
    ct1-4/2/0:4:2
      ds-4/2/0:4:2:1
      ds-4/2/0:4:2:2
    ...
      ds-4/2/0:4:2:6
    t1-4/2/0:4:3
    t1-4/2/0:4:4
  ...
    t1-4/2/0:4:28
  t3-4/2/0:5
  coc1-4/2/0:6
    t1-4/2/0:6:1
    t1-4/2/0:6:2
  ...
    t1-4/2/0:6:28
  coc1-4/2/0:7
    ct1-4/2/0:7:1
      ds-4/2/0:7:1:1
      ds-4/2/0:7:1:2
    ...
      ds-4/2/0:7:1:24
    ct1-4/2/0:7:2
      ds-4/2/0:7:2:1
      ds-4/2/0:7:2:2
    ...
      ds-4/2/0:7:2:6
    t1-4/2/0:7:3
    t1-4/2/0:7:4
  ...
    t1-4/2/0:7:28
  so-4/2/0:8

```

	Admin	Link
coc12-4/2/0	up	up
so-4/2/0:1	up	up
t3-4/2/0:2	up	up
ct3-4/2/0:3	up	up
t1-4/2/0:3:1	up	up
t1-4/2/0:3:2	up	up
...		
t1-4/2/0:3:28	up	up
ct3-4/2/0:4	up	up
ct1-4/2/0:4:1	up	up
ds-4/2/0:4:1:1	up	up
ds-4/2/0:4:1:2	up	up
...		
ds-4/2/0:4:1:24	up	up
ct1-4/2/0:4:2	up	up
ds-4/2/0:4:2:1	up	up
ds-4/2/0:4:2:2	up	up
...		
ds-4/2/0:4:2:6	up	up
t1-4/2/0:4:3	up	up
t1-4/2/0:4:4	up	up
...		
t1-4/2/0:4:28	up	up
t3-4/2/0:5	up	up
coc1-4/2/0:6	up	up
t1-4/2/0:6:1	up	up
t1-4/2/0:6:2	up	up
...		
t1-4/2/0:6:28	up	up
coc1-4/2/0:7	up	up
ct1-4/2/0:7:1	up	up
ds-4/2/0:7:1:1	up	up
ds-4/2/0:7:1:2	up	up
...		
ds-4/2/0:7:1:24	up	up
ct1-4/2/0:7:2	up	up
ds-4/2/0:7:2:1	up	up
ds-4/2/0:7:2:2	up	up
...		
ds-4/2/0:7:2:6	up	up
t1-4/2/0:7:3	up	up
t1-4/2/0:7:4	up	up
...		
t1-4/2/0:7:28	up	up
so-4/2/0:8	up	up

## show interfaces (Channelized OC48 IQ and IQE)

---

<b>Syntax</b>	<code>show interfaces coc48-fpc/pic/port:channel</code> <code>&lt;brief   detail   extensive   terse&gt;</code> <code>&lt;descriptions&gt;</code> <code>&lt;media&gt;</code> <code>&lt;snmp-index <i>snmp-index</i>&gt;</code> <code>&lt;statistics&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 12.3.
<b>Description</b>	Display status information about the specified channelized OC48 interface.
<b>Options</b>	<p><code>coc48-fpc/pic/port:channel</code>—Display standard information about the specified channelized OC48 interface as shown in the sample output.</p> <p><code>brief   detail   extensive   terse</code>—(Optional) Display the specified level of output.</p> <p><code>descriptions</code>—(Optional) Display interface description strings.</p> <p><code>media</code>—(Optional) Display media-specific information about network interfaces.</p> <p><code>snmp-index <i>snmp-index</i></code>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><code>statistics</code>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Channelized OC48 IQ) on page 797</a>
<b>Output Fields</b>	See the output field table for the <a href="#">show interfaces (Channelized OC3 IQ and IQE)</a> command.

## Sample Output

show interfaces  
extensive (Channelized  
OC48 IQ)

```
user@host> show interfaces coc48-4/1/0 extensive
Physical interface: coc48-4/1/0, Enabled, Physical link is Up
  Interface index: 138, SNMP ifIndex: 550, Generation: 141
  Link-level type: Controller, Clocking: Internal, SONET mode, Speed: OC48,
  Loopback: None, Parent: None
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link flags     : None
  Hold-times     : Up 0 ms, Down 0 ms
  CoS queues     : 8 supported, 8 maximum usable queues
  Last flapped   : 2012-07-10 01:55:53 PDT (00:50:07 ago)
  Statistics last cleared: Never
  Interface preservation: disabled
  SONET alarms   : None
  SONET defects  : None
  SONET PHY:
    Seconds      Count    State
    PLL Lock      0         0 OK
    PHY Light      0         0 OK
  SONET section:
    BIP-B1         0         0
    SEF            0         0 OK
    LOS            0         0 OK
    LOF            0         0 OK
    ES-S           0
    SES-S          0
    SEFS-S         0
  SONET line:
    BIP-B2         0         0
    REI-L          0         0
    RDI-L          0         0 OK
    AIS-L          0         0 OK
    BERR-SF        0         0 OK
    BERR-SD        0         0 OK
    ES-L           0
    SES-L          0
    UAS-L          0
    ES-LFE         0
    SES-LFE        0
    UAS-LFE        0
  Received SONET overhead:
    F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
    S1      : 0x00
  Transmitted SONET overhead:
    F1      : 0x00, J0      : 0x01, K1      : 0x00, K2      : 0x00
    S1      : 0x00
```





# Channelized STM1 Interface Operational Mode Commands

Table 128 on page 799 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot channelized STM1 interfaces. Commands are listed in alphabetical order.

**Table 128: Channelized STM1 Interface Operational Mode Commands**

Task	Command
Display status information about channelized STM1 interfaces.	<code>show interfaces (Channelized STM1)</code>
Display channelized STM1 IQ interface information.	<code>show interfaces (Channelized STM1 IQ)</code>
Display the interface names of the physical channelized STM1 IQ interface and the channels configured on each interface.	<code>show interfaces controller (Channelized STM1 IQ)</code>



**NOTE:** For more information about the channel type and level of channelization, and for information about the number of channels that are supported on the channelized STM1 interface, see the *Junos Network Interfaces Configuration Guide*.

For channelization illustrations and configuration examples for channelized IQ interfaces, see the *Junos Feature Guide*.

## show interfaces (Channelized STM1)

<b>Syntax</b>	<pre>show interfaces e1-fpc/pic/port:e1channel &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized STM1 interface.
<b>Options</b>	<p><b>e1-fpc/pic/port:e1channel</b>—Display standard status information about the specified channelized STM1 interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Channelized STM1, SDH) on page 812</a>
<b>Output Fields</b>	<a href="#">Table 129 on page 800</a> lists the output fields for the <b>show interfaces</b> (all Channelized STM1 interfaces) command. Output fields are listed in the approximate order in which they appear.

Table 129: Channelized STM1 show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the "Enabled Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source. It can be <b>Internal</b> or <b>External</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>FCS</b>	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16</b> bits.	All levels
<b>Framing</b>	Physical layer framing format used on the link. It can be <b>G704</b> , <b>G704-NO-CRC4</b> , or <b>Unframed</b> . The default is <b>G704</b> .	All levels
<b>Parent</b>	(Channelized STM1 IQ interfaces only) Name and interface index of the interface to which a particular child interface belongs. <b>None</b> indicates that this interface is the top level.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Keepalive settings</b>	(PPP and HDLC) Configured settings for keepalives. <ul style="list-style-type: none"> <li><b>intervalseconds</b>—The time in seconds between successive keepalive requests. The range is <b>10</b> seconds through <b>32,767</b> seconds, with a default of <b>10</b> seconds.</li> <li><b>down-count number</b>—The number of keepalive packets a destination must fail to receive before the network takes a link down. The range is <b>1</b> through <b>255</b>, with a default of <b>3</b>.</li> <li><b>up-count number</b>—The number of keepalive packets a destination must receive to change a link's status from down to up. The range is <b>1</b> through <b>255</b>, with a default of <b>1</b>.</li> </ul>	<b>detail extensive none</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Keepalive statistics</b>	<p>(PPP and HDLC) Information about keepalive packets.</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li><b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul>	<b>detail extensive none</b>
<b>ANSI LMI settings</b> or <b>ITU LMI settings</b>	<p>(Frame Relay) Local Management Interface settings. The format is <b>(ANSI or ITU) LMI settings: value, value... xx</b> seconds, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li><b>n391dte</b>—DTE full status polling interval (1- 255)</li> <li><b>n392dce</b>—DCE error threshold (1-10)</li> <li><b>n392dte</b>—DTE error threshold (1-10)</li> <li><b>n393dce</b>—DCE monitored event count (1-10)</li> <li><b>n393dte</b>—DTE monitored event count (1-10)</li> <li><b>t391dte</b>—DTE polling timer (5-30 seconds)</li> <li><b>t392dce</b>—DCE polling verification timer (5-30 seconds)</li> </ul>	<b>detail extensive none</b>
<b>LMI</b>	<p>(Frame Relay) Statistics about the link management.</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: nn (last seen hh:mm:ss ago)</b>.</li> <li><b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: nn (last seen hh:mm:ss ago)</b>.</li> </ul>	<b>detail extensive none</b>
<b>DTE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the data terminal equipment (DTE) to the data circuit-terminating equipment (DCE):</p> <ul style="list-style-type: none"> <li><b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li><b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li><b>Enquiry responses received</b>—Number of enquiry responses received by the DTE from the DCE.</li> <li><b>Full enquiry responses received</b>—Number of full enquiry responses sent from the DTE to the DCE.</li> </ul>	<b>detail extensive none</b>
<b>DCE statistics</b>	<p>(Frame Relay) Statistics about messages transmitted from the DCE to the DTE:</p> <ul style="list-style-type: none"> <li><b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li><b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li><b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li><b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	<b>detail extensive none</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Common statistics</b>	(Frame Relay) Statistics about messages sent between the DTE and the DCE: <ul style="list-style-type: none"> <li>• <b>Unknown messages received</b>—Number of received packets that do not fall into any category.</li> <li>• <b>Asynchronous updates received</b>—Number of link status peer changes received.</li> <li>• <b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li>• <b>Keepalive responses timedout</b>—Number of keepalive responses that timed out when no LMI packet was reported for <b>n392dte</b> or <b>n393dce</b> intervals. (See <b>LMI settings</b>.)</li> </ul>	<b>detail extensive none</b>
<b>Nonmatching DCE-end DLCIs</b>	(Frame Relay, displayed only from the DTE) Number of DLCIs configured from the DCE.	<b>detail extensive none</b>
<b>LCP state</b>	(PPP) Link Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—LCP is not configured on the interface.</li> <li>• <b>Opened</b>—LCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>NCP state</b>	(PPP) Network Control Protocol state. <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>CHAP state</b>	(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction. <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the Success state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Closed</b>—CHAP authentication is incomplete.</li> <li>• <b>Failure</b>—CHAP authentication failed.</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Success</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>SRAM errors</b>—Number of hardware errors that occurred in the static RAM (SRAM) on the PIC. If the value of this field increments, the PIC is malfunctioning.</li> </ul>	<b>extensive</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> </ul>	<b>extensive</b>
<b>DS1 alarms</b> <b>DS1 defects</b>	<p>E1 media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. The following lists all possible alarms and defects. For complete explanations of most of these alarms and defects, see <i>Bellcore Telcordia GR-499-CORE</i>.</p> <ul style="list-style-type: none"> <li>• <b>LOS</b>—Loss of signal.</li> <li>• <b>LOF</b>—Loss of frame.</li> <li>• <b>AIS</b>—Alarm indication signal.</li> <li>• <b>YLW</b>—Yellow alarm. Indicates errors at the remote site receiver.</li> </ul>	<b>detail extensive none</b>
<b>SDH alarms</b> <b>SDH defects</b>	<p>SDH media-specific defects that can prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router or light the red or yellow alarm LED on the craft interface. See these fields for possible alarms and defects: SDH PHY, SDH regenerator section, SDH multiplex section, and SDH path.</p> <p><b>NOTE:</b> For controller-based SONET PICs, the SDH alarms and SDH defects output in the <b>show interface cstm1 extensive</b> command output only shows the section and line level defects. The path level defects can be found under the SONET (so) interface output.</p>	<b>All levels</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>E1 media</b>	<p>Active alarms and defects, plus counts of specific E1 errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Error types can be:</p> <ul style="list-style-type: none"> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>BEE</b>—Bit error</li> <li>• <b>BES</b>—Bit error seconds</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>CS</b>—Carrier state</li> <li>• <b>ES</b>—Errored seconds</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>FEBE</b>—Far-end block error</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>PCV</b>—Pulse code violation</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>SEFS-S</b>—Severely errored framing seconds (section)</li> <li>• <b>SES</b>—Severely errored seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> </ul>	<b>extensive</b>
<b>Interface transmit queues</b>	<p>Names of the transmit queues and their associated statistics for each E1 channel on the Channelized STM1-to-E1 PIC.</p> <ul style="list-style-type: none"> <li>• <b>B/W</b>—Queue bandwidth as a percentage of the total interface bandwidth.</li> <li>• <b>WRR</b>—Weighted round-robin (in percent).</li> <li>• <b>Packets</b>—Number of packets transmitted.</li> <li>• <b>Bytes</b>—Number of bytes transmitted.</li> <li>• <b>Drops</b>—Number of packets dropped.</li> <li>• <b>Errors</b>—Number of packet errors.</li> </ul>	<b>extensive</b>
<b>HDLC configuration</b>	<p>Information about the HDLC configuration.</p> <ul style="list-style-type: none"> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> <li>• <b>Timeslots</b>—Configured time slots for the interface.</li> <li>• <b>Line encoding</b>—Line encoding used. It is always <b>HDB3</b>.</li> </ul>	<b>extensive</b>



Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DS1 BERT configuration</b>	<p>BERT (bit error rate test) checks the quality of the line. This output appears only when a BERT is run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>BERT time period</b>—Configured total time period that the BERT is to run.</li> <li>• <b>Elapsed</b>—Actual time elapsed since the start of the BERT (in seconds).</li> <li>• <b>Induced error rate</b>—Configured rate at which the bit errors are induced in the BERT pattern.</li> <li>• <b>Algorithm</b>—Type of algorithm selected for the BERT.</li> </ul>	<b>detail extensive none</b>
<b>SDH PHY</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop</li> <li>• <b>PHY Light</b>—Loss of optical signal</li> </ul>	<b>extensive</b>
<b>SDH regenerator section</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>RS-BIP8</b>—24-bit BIP for multiplex section overhead (B2 bytes)</li> <li>• <b>OOF</b>—Out of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>RS-ES</b>—Errored seconds (near-end regenerator section)</li> <li>• <b>RS-SES</b>—Severely errored seconds (near-end regenerator section)</li> <li>• <b>RS-SEFS</b>—Severely errored framing seconds (regenerator section)</li> </ul>	<b>extensive</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SDH multiplex section</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>MS-BIP24</b>—8-bit BIP for high-order path overhead (B3 byte)</li> <li>• <b>MS-FEBE</b>—Far-end block error (multiplex section)</li> <li>• <b>MS-FERF</b>—Far-end remote fail (multiplex section)</li> <li>• <b>MS-AIS</b>—alarm indication signal (multiplex section)</li> <li>• <b>BERR-SF</b>—Bit error rate fault (signal failure)</li> <li>• <b>BERR-SD</b>—Bit error rate defect (signal degradation)</li> <li>• <b>MS-ES</b>—Errored seconds (near-end multiplex section)</li> <li>• <b>MS-SES</b>—Severely errored seconds (near-end multiplex section)</li> <li>• <b>MS-UAS</b>—Unavailable seconds (near-end multiplex section)</li> <li>• <b>MS-ES-FE</b>—Errored seconds (far-end multiplex section)</li> <li>• <b>MS-SES-FE</b>—Severely errored seconds (far-end multiplex section)</li> <li>• <b>MS-UAS-FE</b>—Unavailable seconds (far-end multiplex section)</li> </ul>	<b>extensive</b>
<b>SDH path</b>	<p>Active alarms and defects, plus counts of specific SDH errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>HP-BIP8</b>—8-bit BIP for regenerator section overhead (B1 byte)</li> <li>• <b>HP-FEBE</b>—Far-end block error (high-order path)</li> <li>• <b>HP-LOP</b>—Loss of pointer (high-order path)</li> <li>• <b>HP-AIS</b>—High-order-path alarm indication signal</li> <li>• <b>HP-FERF</b>—Far-end remote fail (high-order path)</li> <li>• <b>HP-UNEQ</b>—Unequipped (high-order path)</li> <li>• <b>HP-PLM</b>—Payload label mismatch (high-order path)</li> <li>• <b>HP-ES</b>—Errored seconds (near-end high-order path)</li> <li>• <b>HP-SES</b>—Severely errored seconds (near-end high-order path)</li> <li>• <b>HP-UAS</b>—Unavailable seconds (near-end high-order path)</li> <li>• <b>HP-ES-FE</b>—Errored seconds (far-end high-order path)</li> <li>• <b>HP-SES-FE</b>—Severely errored seconds (far-end high-order path)</li> <li>• <b>HP-UAS-FE</b>—Unavailable seconds (far-end high-order path)</li> </ul>	<b>extensive</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SDH tu</b>	<p>Active alarms and defects, plus counts of specific SDH tributary unit (TU) errors with detailed information.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>Subfields are:</p> <ul style="list-style-type: none"> <li>• <b>TU-BIP-2</b>—Bit interleaved parity for SONET line overhead</li> <li>• <b>TU-FEBE</b>—(near-end TU)</li> <li>• <b>TU-LOP</b>—Loss of pointer (near-end TU)</li> <li>• <b>TU-AIS</b>—Alarm indication signal (near-end TU)</li> <li>• <b>TU-FERF</b>—(near-end TU)</li> <li>• <b>TU-UNEQ</b>—Unequipped (near-end TU)</li> <li>• <b>TU-PLM</b>—Payload label mismatch (near-end TU)</li> <li>• <b>TU-ES</b>—Errored seconds (near-end TU)</li> <li>• <b>TU-SES</b>—Severely errored seconds (near-end TU)</li> <li>• <b>TU-UAS</b>—Unavailable seconds (near-end TU)</li> <li>• <b>TU-ES-FE</b>—Errored seconds (far-end TU)</li> <li>• <b>TU-SES-FE</b>—Severely errored seconds (far-end TU)</li> <li>• <b>TU-UAS-FE</b>—Unavailable seconds (far-end TU)</li> </ul>	<b>extensive</b>
<b>Received SDH overhead</b>  <b>Transmitted SDH overhead</b>	<p>Values of the received and transmitted SONET overhead:</p> <ul style="list-style-type: none"> <li>• <b>C2</b>—Signal label. Allocated to identify the construction and content of the STS-level SPE and for PDI-P.</li> <li>• <b>F1</b>—Section user channel byte. This byte is set aside for the purposes of users.</li> <li>• <b>K1</b> and <b>K2</b>—These bytes are allocated for APS signaling for the protection of the multiplex section.</li> <li>• <b>J0</b>—Section trace. This byte is defined for STS-1 number 1 of an STS-<i>N</i> signal. Used to transmit a 1-byte fixed-length string or a 16-byte message so that a receiving terminal in a section can verify its continued connection to the intended transmitter.</li> <li>• <b>S1</b>—Synchronization status. The S1 byte is located in the first STS-1 of an STS-<i>N</i> signal.</li> <li>• <b>Z3</b> and <b>Z4</b>—Allocated for future use.</li> </ul>	<b>extensive</b>
<b>Received path trace</b>  <b>Transmitted path trace</b>	<p>Channelized OC12 interfaces allow path trace bytes to be sent inband across the SONET/SDH link. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits. This information is specific to each of the 12 channelized OC12 interfaces.</p>	<b>extensive</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>

Table 129: Channelized STM1 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>DLCI</b>	<p>(Frame Relay) DLCI number of the logical interface. The following DLCI information is displayed: <b>Flags</b>, <b>Total down time</b>, <b>Last down</b>, and <b>Traffic statistics</b>. <b>Flags</b> is one or more of the following:</p> <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when the link is active, but no information is received from the DCE.</li> <li>• <b>Unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the corresponding DLCI in the DCE is configured.</li> <li>• <b>Dce-configured</b>—Displayed when the command is issued from the DTE.</li> </ul>	<b>detail extensive none</b>
<b>DLCI statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	<b>detail extensive none</b>

## Sample Output

show interfaces  
extensive (Channelized  
STM1, SDH)

```

user@host> show interfaces e1-1/0/0:1 extensive
Physical interface: e1-1/0/0:1, Enabled, Physical link is Up
  Interface index: 148, SNMP ifIndex: 285, Generation: 2915
  Link-level type: Frame-relay, MTU: 1504, SDH mode, Speed: E1, Loopback: None,
  FCS: 16, Framing: G704
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : Keepalives DTE
  ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
  LMI: Input: 51700 (00:00:02 ago), Output: 51701 (00:00:02 ago)
  DTE statistics:
    Enquiries sent           : 43186
    Full enquiries sent      : 8515
    Enquiry responses received : 43185
    Full enquiry responses received : 8515
  DCE statistics:
    Enquiries received       : 0
    Full enquiries received  : 0
    Enquiry responses sent   : 0
    Full enquiry responses sent : 0
  Common statistics:
    Unknown messages received : 0
    Asynchronous updates received : 0
    Out-of-sequence packets received : 0
    Keepalive responses timeout : 0
  Nonmatching DCE-end DLCIs:
    2
  Hold-times      : Up 0 ms, Down 0 ms
  Last flapped   : 2002-05-23 17:02:59 PDT (17:23:45 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes  :          592          48 bps
    Output bytes :          644          48 bps
    Input packets:          46           0 pps
    Output packets:         46           0 pps
  Input errors:
    Errors: 0, Drops: 9, Framing errors: 0, Policed discards: 0,
    L3 incompletes: 0, L2 channel errors: 11, L2 mismatch timeouts: 0,
    HS link CRC errors: 0, SRAM errors: 0
  Output errors:
    Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0
  DS1  alarms : None
  DS1  defects: None
  SDH   alarms : None
  SDH   defects: None
  E1  media:
    Seconds      Count  State
    SEF          0       0 OK
    BEE          0       0 OK
    AIS         124       1 OK
    LOF         124       1 OK
    LOS          0       0 OK
    YELLOW       0       0 OK
    BPV          0       0
    EXZ          0       0
    LCV          0       0
    PCV          0       0
    CS           0       0
    FEBE         0       0

```

```

LES                      124
ES                       125
SES                      124
SEFS                     124
BES                      0
UAS                      37
Interface transmit queues:
      B/W  WRR      Packets      Bytes      Drops      Errors
Queue0   95  95           0         0         0         0
Queue1    5   5         529       6348         0         0
HDLC configuration:
Giant threshold: 0, Runt threshold: 0
Timeslots      : All active
Line encoding: HDB3
DS1 BERT configuration:
BERT time period: 10 seconds, Elapsed: 0 seconds
Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
SDH PHY:
      Seconds      Count  State
PLL Lock           0        0  OK
PHY Light          0        0  OK
SDH regenerator section:
      Seconds      Count
RS-BIP8           0        0
OOF               125        1  OK
LOS               125        1  OK
LOF               125        1  OK
RS-ES             125
RS-SES            125
RS-SEFS           125
SDH multiplex section:
      Seconds      Count
MS-BIP24          0        0
MS-FEBE           0        0
MS-FERF           0        0  OK
MS-AIS            125        1  OK
BERR-SF           0        0  OK
BERR-SD           0        0  OK
MS-ES             125
MS-SES            125
MS-UAS            115
MS-ES-FE          0
MS-SES-FE         0
MS-UAS-FE         0
SDH path:
      Seconds      Count
HP-BIP8           0        0
HP-FEBE           0        0
HP-LOP            0        0  OK
HP-AIS            125        1  OK
HP-FERF           0        0  OK
HP-UNEQ           0        0  OK
HP-PLM            125        1  OK
HP-ES             125
HP-SES            125
HP-UAS            115
HP-ES-FE          0
HP-SES-FE         0
HP-UAS-FE         0
SDH tu:
      Seconds      Count
TU-BIP2           0        0
TU-FEBE           124        1
TU-LOP            0        0  OK
TU-AIS            124        1  OK
TU-FERF           124        1  OK

```

```

TU-UNEQ                0                0 OK
TU-PLM                 124              1 OK
TU-ES                  125
TU-SES                 125
TU-UAS                 115
TU-ES-FE               0
TU-SES-FE              0
TU-UAS-FE              0
Received SDH overhead:
F1      : 0x00, J0      : 0x00, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0x02, C2(cmp) : 0x02, F2      : 0x00
Z3      : 0x00, Z4      : 0x00, S1(cmp) : 0x00, V5      : 0x02
V5(cmp) : 0x02
Transmitted SDH overhead:
F1      : 0x00, J0      : 0x00, K1      : 0x00, K2      : 0x00
S1      : 0x00, C2      : 0x02, F2      : 0x00, Z3      : 0x00
Z4      : 0x00, V5      : 0x02
Received path trace:
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
Transmitted path trace:
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
Packet Forwarding Engine configuration:
Destination slot: 1, PLP byte: 2 (0x07)
CoS information:
  CoS transmit queue      Bandwidth      Buffer Priority  Limit
                           %      bps      %      usec
  0 best-effort           95      1945600  95      0      low  none
  3 network-control       5       102400   5      0      low  none
Logical interface e1-1/0/0:1.0 (Index 10) (SNMP ifIndex 369) (Generation 496)
Flags: Point-To-Point SNMP-Traps Encapsulation: PPP
Protocol inet, MTU: 1500, Generation: 575, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 19.19.19.3, Local: 19.19.19.4, Broadcast: Unspecified,
  Generation: 975
DLCI 100
Flags: Active, Dce-configured
Total down time: 0 sec, Last down: Never
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
DLCI statistics:
  Active DLCI :2 Inactive DLCI : 0

```



## show interfaces (Channelized STM1 IQ)

<b>Syntax</b>	<pre>show interfaces (type-fpc/pic/port &lt;:channel&gt;&lt;:channel&gt;) &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized STM1 IQ interface.
<b>Options</b>	<p><b>type-fpc/pic/port:channel:channel</b>—Interface type with optional corresponding channel levels. The interface type can be one of the following types:</p> <ul style="list-style-type: none"> <li><b>type-fpc/pic/port:channel</b>—For the physical channelized STM1 IQ interface, <b>type</b> is <b>cstm1</b>. For the clear channel, <b>type</b> is <b>so</b>. For channelization, the STM1 IQ interface must be converted to interface type <b>cau4</b>.</li> <li><b>type-fpc/pic/port:channel</b>—At the first level of channelization, <b>type</b> can be <b>ce1</b> or <b>e1</b> (clear channel or fractional channel from <b>cau4</b>).</li> <li><b>type-fpc/pic/port:channel:channel</b>—At the second level of channelization, <b>type</b> is <b>ds</b> (from <b>ce1</b>).</li> </ul> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Channelized STM1 IQ) (Physical) on page 816</a></p> <p><a href="#">show interfaces (Channelized AU-4) (Physical) on page 816</a></p> <p><a href="#">show interfaces (Channelized E1) (Physical) on page 816</a></p> <p><a href="#">show interfaces (DS) on page 817</a></p>
<b>Output Fields</b>	See the output field table for the <a href="#">show interfaces (Channelized STM1)</a> command.

## Sample Output

**show interfaces**  
(Channelized STM1 IQ)  
(Physical)

```
user@host> show interfaces cstm1-0/0/0
Physical interface: cstm1-0/0/0, Enabled, Physical link is Up
  Interface index: 146, SNMP ifIndex: 35
  Link-level type: Frame-relay, Controller, Clocking: Internal, SDH mode,
  Speed: OC3, Loopback: None, Parent: None Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags      : Keepalives DTE
  ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
  LMI: Input: 51700 (00:00:02 ago), Output: 51701 (00:00:02 ago)
  DTE statistics:
    Enquiries sent                : 43186
    Full enquiries sent           : 8515
    Enquiry responses received    : 43185
    Full enquiry responses received : 8515
  DCE statistics:
    Enquiries received            : 0
    Full enquiries received       : 0
    Enquiry responses sent        : 0
    Full enquiry responses sent   : 0
  Common statistics:
    Unknown messages received     : 0
    Asynchronous updates received : 0
    Out-of-sequence packets received : 0
    Keepalive responses timeout   : 0
  Nonmatching DCE-end DLCIs:
    2
  Last flapped   : 2003-02-06 15:01:56 PST (07:15:06 ago)
...
```

**show interfaces**  
(Channelized AU-4)  
(Physical)

```
user@host> show interfaces cau4-0/0/0
Physical interface: cau4-0/0/0, Enabled, Physical link is Up
  Interface index: 147, SNMP ifIndex: 36
  Link-level type: Controller, Clocking: Internal, SDH mode, Speed: OC3,
  Loopback: None, Parent: cstm1-0/0/0 Interface index 146
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : None
  Last flapped   : 2003-02-06 19:36:31 PST (02:40:42 ago)
  SDH  alarms    : None
  SDH  defects   : None
...
```

**show interfaces**  
(Channelized E1)  
(Physical)

```
user@host> show interfaces ce1-0/0/0:11
Physical interface: ce1-0/0/0:11, Enabled, Physical link is Up
  Interface index: 169, SNMP ifIndex: 288
  Link-level type: Frame-relay, Controller, Clocking: Internal, Speed: E1,
  Loopback: None, Framing: G704, Parent: cau4-0/0/0 Interface index 147
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : Keepalives DTE
  ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
  LMI: Input: 51700 (00:00:02 ago), Output: 51701 (00:00:02 ago)
  DTE statistics:
    Enquiries sent                : 43186
    Full enquiries sent           : 8515
    Enquiry responses received    : 43185
```

```

    Full enquiry responses received      : 8515
DCE statistics:
    Enquiries received                  : 0
    Full enquiries received              : 0
    Enquiry responses sent               : 0
    Full enquiry responses sent          : 0
Common statistics:
    Unknown messages received            : 0
    Asynchronous updates received        : 0
    Out-of-sequence packets received     : 0
    Keepalive responses timedout          : 0
Nonmatching DCE-end DLCIs:
    2
Last flapped      : 2003-02-06 22:05:23 PST (00:13:45 ago)
DS1  alarms       : None
DS1  defects       : None
SDH   alarms       : None
SDH   defects       : None
...

```

**show interfaces (DS)**

```

user@host> show interfaces ds-0/0/0:11:1
Physical interface: ds-0/0/0:11:1, Enabled, Physical link is Up
  Interface index: 170, SNMP ifIndex: 289
  Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: 640kbps,
  Loopback: Illegal, FCS: 16, Parent: ce1-0/0/0:11 Interface index 169
  Device flags      : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags        : Keepalives
  CoS Queues: 8 maximum usable queues, 4 in use
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive: Input: 0 (never), Output: 0 (never)
  LCP state: Conf-req-sent
  Egress queues: 8 supported, 4 in use
...
Logical interface ds-0/0/0:11:1.0 (Index 77) (SNMP ifIndex 290)
  Flags: Hardware-Down Point-To-Point SNMP-Traps Encapsulation: PPP
  Bandwidth: 0
  Protocol inet, MTU: 1500
  Flags: Protocol-Down
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 10.134.1.0/30, Local: 10.134.1.1
DLCI 100
  Flags: Active, Dce-configured
  Total down time: 0 sec, Last down: Never
  Traffic statistics:
    Input  bytes :                0
    Output bytes :                0
    Input packets:                0
    Output packets:               0
...

```

## show interfaces controller (Channelized STM1 IQ)

<b>Syntax</b>	<code>show interfaces controller cstm1-<i>fpc/pic/port</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display the interface names of the physical channelized STM1 IQ interface and the channels configured on each interface.
<b>Options</b>	<code>cstm1-<i>fpc/pic/slot</i></code> —Channelized STM1 IQ interface name.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces controller (Physical Channelized STM1 IQ with Logical E1) on page 818</a>
<b>Output Fields</b>	<a href="#">Table 130 on page 818</a> lists the output fields for the <b>show interfaces controller</b> (Channelized STM1 IQ) command. Output fields are listed in the approximate order in which they appear.

**Table 130: Channelized STM1 IQ show interfaces controller Output Fields**

Field Name	Field Description
<b>Controller</b>	Physical channelized interface name and the names of any channels configured on it.
<b>Admin</b>	Administrative status of the interface.
<b>Link</b>	Link status of the interface.

## Sample Output

### show interfaces controller (Physical Channelized STM1 IQ with Logical E1)

```

user@host> show interfaces controller cstm1-0/0/0
Controller
cstm1-0/0/0
cau4-0/0/0
  e1-0/0/0:1
  e1-0/0/0:2
  e1-0/0/0:3
  e1-0/0/0:4
  e1-0/0/0:5
  e1-0/0/0:6
  e1-0/0/0:7
  e1-0/0/0:8
  e1-0/0/0:9
  e1-0/0/0:10
  ce1-0/0/0:11
    ds-0/0/0:11:1
    ds-0/0/0:11:2
    ds-0/0/0:11:3
    ds-0/0/0:11:4

```

	Admin	Link
cstm1-0/0/0	up	up
cau4-0/0/0	up	up
e1-0/0/0:1	up	up
e1-0/0/0:2	up	up
e1-0/0/0:3	up	up
e1-0/0/0:4	up	up
e1-0/0/0:5	up	up
e1-0/0/0:6	up	up
e1-0/0/0:7	up	up
e1-0/0/0:8	up	up
e1-0/0/0:9	up	up
e1-0/0/0:10	up	up
ce1-0/0/0:11	up	up
ds-0/0/0:11:1	up	up
ds-0/0/0:11:2	up	up
ds-0/0/0:11:3	up	up
ds-0/0/0:11:4	up	up

## Channelized T1 and T3 Interface Operational Mode Commands

Table 131 on page 819 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot channelized T1 and T3 interfaces. Commands are listed in alphabetical order.

**Table 131: Channelized T1 and T3 Interface Operational Mode Commands**

Task	Command
Display status information about channelized DS3-to-DS0 interfaces.	<code>show interfaces (Channelized DS3-to-DS0)</code>
Display status information about channelized DS3-to-DS1 interfaces.	<code>show interfaces (Channelized DS3-to-DS1)</code>
Display channelized T1 IQ interface information.	<code>show interfaces (Channelized T1 IQ)</code>
Display channelized T3 IQ interface information.	<code>show interfaces (Channelized T3 IQ)</code>
Display the interface names of the physical channelized T1 IQ interface and the channels configured on each interface.	<code>show interfaces controller (Channelized T1 IQ)</code>
Display the interface names of the physical channelized T3 IQ interface and the channels configured on each interface.	<code>show interfaces controller (Channelized T3 IQ)</code>



.....

**NOTE:** For more information about the channel type and level of channelization, and for information about the number of channels that are supported on the different types of channelized T1 and T3 interfaces, see the *Junos Network Interfaces Configuration Guide*.

For more information on monitoring and troubleshooting channelized DS3-to-DS0 and DS3-to-DS1 interfaces, see the *Junos Interfaces Network Operations Guide*.

For channelization illustrations and configuration examples for channelized IQ interfaces, see the *Junos Feature Guide*.

.....

## show interfaces (Channelized DS3-to-DS0)

<b>Syntax</b>	<pre>show interfaces ds-fpc/pic/port:t1channel:ds0channel &lt;brief   detail   extensive&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized DS3-to-DS0 interface.
<b>Options</b>	<p><b>ds-fpc/pic/port:t1channel:ds0channel</b>—Display standard information about the specified channelized DS3-to-DS0 interface.</p> <p><b>brief   detail   extensive</b>—(Optional) Display the specified level of output interface.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Channelized DS3-to-DS0) on page 830</a>
<b>Output Fields</b>	<a href="#">Table 132 on page 821</a> lists the output fields for the <b>show interfaces</b> (all Channelized DS3 interfaces) command. Output fields are listed in the approximate order in which they appear.

Table 132: Channelized DS3 show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source. It can be <b>Internal</b> or <b>External</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>FCS</b>	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16</b> bits.	All levels
<b>Mode</b>	Whether C-bit parity mode or M13 mode is enabled.	All levels
<b>Framing</b>	Physical layer framing format used on the link. It can be <b>ESF</b> or <b>SF</b> . The default is <b>ESF</b> .	All levels
<b>Parent</b>	(Channelized IQ interfaces only) Name and interface index of the interface to which a particular child interface belongs. <b>None</b> indicates that this interface is the top level.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Keepalive settings</b>	(PPP and HDLC) Configured settings for keepalives. <ul style="list-style-type: none"> <li><b>interval seconds</b>—The time in seconds between successive keepalive requests. The range is <b>10</b> seconds through <b>32,767</b> seconds, with a default of <b>10</b> seconds.</li> <li><b>down-count number</b>—The number of keepalive packets that a destination must fail to receive before the network takes a link down. The range is <b>1</b> through <b>255</b>, with a default of <b>3</b>.</li> <li><b>up-count number</b>—The number of keepalive packets a destination must receive to change a link's status from down to up. The range is <b>1</b> through <b>255</b>, with a default of <b>1</b>.</li> </ul>	<b>detail extensive none</b>



Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Keepalive statistics	<p>(PPP and HDLC) Information about keepalive packets.</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li><b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li><b>(last seen 00:00:00 ago)</b>—Time since the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul>	detail extensive none
LMI settings	<p>(Frame Relay) Settings for Local Management Interface (LMI) can be either <b>ANSI LMI settings</b> or <b>ITU LMI settings</b>. ANSI LMI settings is the default. The format is (ANSI or ITU) <b>LMI settings: value, value, value...xx</b> seconds, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li><b>n391dte</b>—DTE full status polling interval (1–255)</li> <li><b>n392dce</b>—DCE error threshold (1–10)</li> <li><b>n392dte</b>—DTE error threshold (1–10)</li> <li><b>n393dce</b>—DCE monitored event count (1–10)</li> <li><b>n393dte</b>—DTE monitored event count (1–10)</li> <li><b>t391dte</b>—DTE polling timer (5–30 seconds)</li> <li><b>t392dce</b>—DCE polling verification timer (5–30 seconds)</li> </ul>	detail extensive none
LMI	<p>(Frame Relay) LMI packet statistics:</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: nn (last seen hh:mm:ss ago)</b>.</li> <li><b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: nn (last seen hh:mm:ss ago)</b>.</li> </ul>	detail extensive none
LCP state	<p>(PPP) Link Control Protocol state.</p> <ul style="list-style-type: none"> <li><b>Conf-ack-received</b>—Acknowledgement was received.</li> <li><b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li><b>Conf-req-sent</b>—Request was sent.</li> <li><b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li><b>Not-configured</b>—LCP is not configured on the interface.</li> <li><b>Opened</b>—LCP negotiation is successful.</li> </ul>	detail extensive none
NCP state	<p>(PPP) Network Control Protocol state.</p> <ul style="list-style-type: none"> <li><b>Conf-ack-received</b>—Acknowledgement was received.</li> <li><b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li><b>Conf-req-sent</b>—Request was sent.</li> <li><b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li><b>Not-configured</b>—NCP is not configured on the interface.</li> <li><b>Opened</b>—NCP negotiation is successful.</li> </ul>	detail extensive none

Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CHAP state</b>	<p>(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction.</p> <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the <b>Success</b> state. (Most likely with RADIUS authentication).</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Closed</b>—CHAP authentication is incomplete.</li> <li>• <b>Failure</b>—CHAP authentication failed.</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Success</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: <i>year-month-day hour:minute:second timezone hh:mm:ss ago</i></b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Counter increments when the software could not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Count of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>SRAM errors</b>—Number of hardware errors that occurred in the static RAM (SRAM) on the PIC. If the value in this field increments, the PIC is malfunctioning.</li> <li>• <b>HS link CRC errors</b>—Count of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly, (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> </ul>	<b>extensive</b>

Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DS1 alarms</b>	Media-specific defects that can render the interface unable to pass packets. When a defect persists for a certain amount of time, it is promoted to an alarm.	<b>detail extensive none</b>
<b>DS1 defects</b>	Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. <ul style="list-style-type: none"> <li>• <b>LOS</b>—Loss of signal.</li> <li>• <b>LOF</b>—Loss of frame.</li> <li>• <b>AIS</b>—Alarm indication signal.</li> <li>• <b>YLW</b>—Yellow alarm. Indicates errors at the remote site receiver.</li> </ul>	
<b>T1 media</b>	Counts of T1 media-specific errors. <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>The T1 media-specific error types can be:</p> <ul style="list-style-type: none"> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>BEE</b>—Bit error event</li> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>PCV</b>—Pulse code violation</li> <li>• <b>CS</b>—Carrier state</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>ES</b>—Errored seconds</li> <li>• <b>SEFS</b>—Severely errored framing seconds (section)</li> <li>• <b>SES</b>—Severely errored seconds</li> <li>• <b>BES</b>—Bit error seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> </ul>	<b>extensive</b>

Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DS3 media</b>	<p>Counts of T3 media-specific errors. For detailed definitions of the T3 (DS-3) error events (BPV, EXZ, LCV, PCV, and CCV) and performance parameters (LES, PES, PSES, CES, CSES, SEFS, and UAS), see RFC 2496.</p> <ul style="list-style-type: none"> <li>• <b>PLL Lock</b>—Phase-locked loop out of lock</li> <li>• <b>Reframing</b>—Frame alignment recovery time</li> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>IDLE</b>—Idle code detected</li> <li>• <b>YELLOW</b>—Remote defect indication</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>PCV</b>—Pulse code violation</li> <li>• <b>CCV</b>—C-bit coding violation</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>PES</b>—P-bit errored seconds</li> <li>• <b>PSES</b>—P-bit errored seconds (section)</li> <li>• <b>CES</b>—C-bit errored seconds</li> <li>• <b>CSES</b>—C-bit severely errored seconds</li> <li>• <b>SEFS</b>—Severely errored framing seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> </ul>	<b>extensive</b>
<b>HDLC configuration</b>	<p>Information about the HDLC configuration.</p> <ul style="list-style-type: none"> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> <li>• <b>Timeslots</b>—Configured time slots for the interface.</li> <li>• <b>Byte encoding</b>—Byte encoding used: <b>Nx64K</b> or <b>Nx56K</b>.</li> <li>• <b>Data inversion</b>—HDLC data inversion setting: <b>Enabled</b> or <b>Disabled</b></li> </ul>	<b>extensive</b>
<b>Interface transmit queues</b>	<p>Name of the transmit queues and their associated statistics for each DS1 channel on the Channelized DS3-to-DS1 PIC.</p> <ul style="list-style-type: none"> <li>• <b>B/W</b>—Queue bandwidth as a percentage of the total interface bandwidth.</li> <li>• <b>WRR</b>—Weighted round-robin (in percent).</li> <li>• <b>Packets</b>—Number of packets transmitted.</li> <li>• <b>Bytes</b>—Number of bytes transmitted.</li> <li>• <b>Drops</b>—Number of packets dropped.</li> <li>• <b>Errors</b>—Number of packet errors.</li> </ul>	<b>extensive</b>

Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DS1 or DS3 BERT configuration</b>	<p>BERT (bit error rate test) checks the quality of the line. This output appears only when a BERT is run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>BERT time period</b>—Configured total time period that the BERT is to run.</li> <li>• <b>Elapsed</b>—Actual time elapsed since the start of the BERT (in seconds).</li> <li>• <b>Induced error rate</b>—Configured rate at which the bit errors are induced in the BERT pattern.</li> <li>• <b>Algorithm</b>—Type of algorithm selected for the BERT.</li> </ul>	<b>detail extensive none</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>
<b>CoS information</b>	<p>Information about the CoS queue for the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface; values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Bandwidth</b>	Bandwidth configured on the interface.	All levels
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mpls</b> .	<b>detail extensive none</b>

Table 132: Channelized DS3 show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive none</b>
<b>Redundant Link</b>	(LSQ redundancy) Backup link for Link Services IQ redundancy.	<b>detail extensive none</b>

## Sample Output

show interfaces  
extensive (Channelized  
DS3-to-DS0)

```
user@host> show interfaces ds-0/0/0:0:0 extensive
Physical interface: ds-0/0/0:0:0, Enabled, Physical link is Up
  Interface index: 174, SNMP ifIndex: 4298, Generation: 177
  Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: 640kbps, FCS: 16,
  Mode: C/Bit parity, Framing: ESF
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : Keepalives
  Hold-times    : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 280 (last seen 00:00:09 ago)
    Output: 286 (last sent 00:00:00 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  CHAP state: Not-configured
  Last flapped   : 2002-05-23 17:53:29 PDT (00:46:46 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :           6814           16 bps
    Output bytes :          28840           72 bps
    Input packets:            568            0 pps
    Output packets:           893            0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 39, Policed discards: 0,
    L3 incompletes: 0, L2 channel errors: 2, L2 mismatch timeouts: 0,
    HS link CRC errors: 0
  Output errors:
    Carrier transitions: 3, Errors: 0, Drops: 0, Aged packets: 0
  DS1 alarms   : None
  DS3 alarms   : None
  DS1 defects  : None
  DS3 defects  : None
  T1 media:
    Seconds      Count  State
    SEF          0        0 OK
    BEE          5        1 OK
    AIS          0        0 OK
    LOF          0        0 OK
    LOS          0        0 OK
    YELLOW       17        1 OK
    BPV          0         0
    EXZ          0         0
    LCV          5       27765
    PCV          0         0
    CS           0         0
    LES          0
    ES           0
    SES          5
    SEFS         10
    BES          0
    UAS          0
  DS3 media:
    Seconds      Count  State
    PLL Lock     0        0 OK
    Reframing    0        0 OK
    AIS          0        0 OK
    LOF          0        0 OK
    LOS          0        0 OK
```



```

IDLE          0          0 OK
YELLOW        0          0 OK
BPV           1        65535
EXZ           1        65535
LCV           2       131070
PCV           1        1825
CCV           0          0
LES           1
PES           1
PSES          1
CES           0
CSES          0
SEFS          0
UAS           0
Interface transmit queues:
      B/W  WRR      Packets      Bytes      Drops      Errors
Queue0   95  95          0          0          0          0
Queue1    5   5         893       28840          0          0
HDLC configuration:
  Giant threshold: 1514, Runt threshold: 3
  Timeslots      : 1-10
  Byte encoding: Nx64K, Data inversion: Disabled
DS3 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Algorithm: 2^15 - 1, Induced error rate: 10e-0
DS1 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
  Destination slot: 0, PLP byte: 2 (0x01)
CoS information:      CoS transmit queue      Bandwidth      Buffer
Priority  Limit
          %      bps  %      usec
0 best-effort      95    608000  95      0    low  none
3 network-control  5     32000   5      0    low  none
Logical interface ds-0/0/0:0:0.0 (Index 5) (SNMP ifIndex 4299)
(Generation 943)
Flags: Point-To-Point SNMP-Traps Encapsulation: PPP
Protocol inet, MTU: 1500, Generation: 949, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
Destination: 18.18.18.1, Local: 18.18.18.2, Broadcast: Unspecified,
Generation: 1849

```

## show interfaces (Channelized DS3-to-DS1)

---

<b>Syntax</b>	<code>show interfaces t1-fpc/pic/port:t1channel</code> <code>&lt;brief   detail   extensive   terse&gt;</code> <code>&lt;descriptions&gt;</code> <code>&lt;media&gt;</code> <code>&lt;snmp-index <i>snmp-index</i>&gt;</code> <code>&lt;statistics&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized DS3-to-DS1 interface.
<b>Options</b>	<p><code>t1-fpc/pic/port:t1channel</code>—Display standard information about the specified channelized DS3-to-DS1 interface.</p> <p><code>brief   detail   extensive   terse</code>—(Optional) Display brief interface information.</p> <p><code>descriptions</code>—(Optional) Display interface description strings.</p> <p><code>media</code>—(Optional) Display media-specific information about network interfaces.</p> <p><code>snmp-index <i>snmp-index</i></code>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><code>statistics</code>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (channelized DS3-to-DS1) on page 833</a>
<b>Output Fields</b>	See the output field table for the <a href="#">show interfaces (Channelized DS3-to-DS0)</a> command.

## Sample Output

show interfaces  
extensive (channelized  
DS3-to-DS1)

```
user@host> show interfaces t1-0/0/0:0 extensive
Physical interface: t1-0/0/0:0, Enabled, Physical link is Up
  Interface index: 210, SNMP ifIndex: 14, Generation: 2977
  Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: 640kbps,
  Loopback: None, FCS: 16, Mode: C/Bit parity, Framing: ESF
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : Keepalives
  Hold-times    : Up 0 ms, Down 0 ms
  Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
  Keepalive statistics:
    Input : 30 (last seen 00:00:05 ago)
    Output: 29 (last sent 00:00:00 ago)
  LCP state: Opened
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
  Not-configured
  CHAP state: Not-configured
  Last flapped   : 2002-05-23 17:30:12 PDT (17:29:43 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :           944           16 bps
    Output bytes  :          1162           16 bps
    Input packets :            66            0 pps
    Output packets:            82            0 pps
  Input errors:
    Errors: 1, Drops: 0, Framing errors: 1, Policed discards: 8,
    L3 incompletes: 0, L2 channel errors: 1, L2 mismatch timeouts: 0,
    HS link CRC errors: 0, SRAM errors: 0
  Output errors:
    Carrier transitions: 3, Errors: 0, Drops: 0, Aged packets: 0
  DS1 alarms   : None
  DS3 alarms   : None
  DS1 defects  : None
  DS3 defects  : None
  T1 media:
    Seconds      Count  State
    SEF          0        0 OK
    BEE          11        5 OK
    AIS          28        1 OK
    LOF          27        1 OK
    LOS          0         0 OK
    YELLOW       23        1 OK
    BPV          0         0
    EXZ          0         0
    LCV          11       20574
    PCV          0         0
    CS           0         0
    LES          28
    ES           28
    SES          39
    SEFS         50
    BES          0
    UAS          0
  DS3 media:
    Seconds      Count  State
    PLL Lock     0        0 OK
    Reframing    0        0 OK
    AIS          0        0 OK
    LOF          1        1 OK
    LOS          1        1 OK
```

```

IDLE          0          0 OK
YELLOW        0          0 OK
BPV           2        131070
EXZ           3        49910
LCV           5        180980
PCV           2         327
CCV          12       264558
LES           3
PES           3
PSES         2
CES          13
CSES         13
SEFS         1
UAS          35
Interface transmit queues:
      B/W  WRR      Packets      Bytes      Drops      Errors
Queue0   95  95          0         0         0         0
Queue1    5   5         82       1162         0         0
HDLC configuration:
  Giant threshold: 1514, Runt threshold: 3
  Timeslots      : 1-10
  Line encoding: B8ZS, Byte encoding: Nx64K, Data inversion: Disabled
DS3 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Algorithm: 2^15 - 1, Induced error rate: 10e-0
DS1 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
  Destination slot: 0, PLP byte: 2 (0x00) CoS information:
  CoS transmit queue      Bandwidth      Buffer Priority  Limit
                        %      bps      %      usec
0 best-effort            95      608000  95         0    low  none
3 network-control        5       32000   5         0    low  none
Logical interface t1-0/0/0:0.0 (Index 11) (SNMP ifIndex 23) (Generation 497)
Flags: Point-To-Point SNMP-Traps Encapsulation: PPP
Bandwidth: 0
Protocol inet, MTU: 1500, Generation: 576, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 21.21.21.2, Local: 21.21.21.1, Broadcast: Unspecified,
  Generation: 977

```

## show interfaces (Channelized T1 IQ)

<b>Syntax</b>	<pre>show interfaces (ct1-fpc/pic/port   type-fpc/pic/port&lt;:channel&gt;&lt;:channel&gt;) &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized T1 IQ interface.
<b>Options</b>	<p><b>type-fpc/pic/port:channel</b>—Interface type. With optional corresponding channel levels, the interface type can be one of the following:</p> <ul style="list-style-type: none"> <li><b>type-fpc/pic/port</b>—For the physical channelized T1 IQ interface, <b>type</b> is <b>ct1</b>.</li> <li><b>type-fpc/pic/port:channel</b>—For the clear channel, <b>type</b> is <b>t1</b>. At the first level of channelization, <b>type</b> can be <b>ct1</b> or <b>t1</b>.</li> <li><b>type-fpc/pic/port:channel:channel</b>—At the second level of channelization, <b>type</b> can be <b>ds</b>.</li> </ul> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces extensive (CT1) on page 844</a></p> <p><a href="#">show interfaces extensive (T1) on page 844</a></p> <p><a href="#">show interfaces extensive (DS0) on page 845</a></p>
<b>Output Fields</b>	Table 133 on page 835 lists the output fields for the <b>show interfaces</b> (Channelized T1 IQ and T3 IQ interfaces) command. Output fields are listed in the approximate order in which they appear.

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
Physical interface	Name of the physical interface.	All levels

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source. It can be <b>Internal</b> or <b>External</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Loopback</b>	Whether loopback is enabled and the type of loopback ( <b>local</b> or <b>remote</b> ).	All levels
<b>FCS</b>	Frame check sequence on the interface (either <b>16</b> or <b>32</b> ). The default is <b>16</b> bits.	All levels
<b>Framing</b>	Physical layer framing format used on the link. It can be <b>ESF</b> or <b>SF</b> . The default is <b>ESF</b> .	All levels
<b>Parent</b>	Name and interface index of the interface to which a particular child interface belongs. <b>None</b> indicates that this interface is the top level.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Keepalive settings</b>	Configured settings for keepalives. <ul style="list-style-type: none"> <li><b>interval seconds</b>—The time in seconds between successive keepalive requests. The range is <b>10</b> seconds through <b>32,767</b> seconds, with a default of <b>10</b> seconds.</li> <li><b>down-count number</b>—The number of keepalive packets a destination must fail to receive before the network takes a link down. The range is <b>1</b> through <b>255</b>, with a default of <b>3</b>.</li> <li><b>up-count number</b>—The number of keepalive packets a destination must receive to change a link's status from down to up. The range is <b>1</b> through <b>255</b>, with a default of <b>1</b>.</li> </ul>	<b>detail extensive</b> none

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Keepalive statistics	<p>Information about keepalive packets.</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of keepalive packets received by PPP. <ul style="list-style-type: none"> <li>(<b>last seen 00:00:00 ago</b>)—Time since the last keepalive packet was received, in the format <i>hh:mm:ss</i>.</li> </ul> </li> <li><b>Output</b>—Number of keepalive packets sent by PPP and how long ago the last keepalive packets were sent and received. <ul style="list-style-type: none"> <li>(<b>last seen 00:00:00 ago</b>)—Time since the last keepalive packet was sent, in the format <i>hh:mm:ss</i>.</li> </ul> </li> </ul>	detail extensive none
LMI settings	<p>(Frame Relay) Settings for Local Management Interface (LMI) can be either <b>ANSI LMI settings</b> or <b>ITU LMI settings</b>. ANSI LMI settings is the default. The format is (ANSI or ITU) <b>LMI settings: value, value... xx seconds</b>, where <i>value</i> can be:</p> <ul style="list-style-type: none"> <li><b>n391dte</b>—DTE full status polling interval (1–255)</li> <li><b>n392dce</b>—DCE error threshold (1–10)</li> <li><b>n392dte</b>—DTE error threshold (1–10)</li> <li><b>n393dce</b>—DCE monitored event count (1–10)</li> <li><b>n393dte</b>—DTE monitored event count (1–10)</li> <li><b>t391dte</b>—DTE polling timer (5–30 seconds)</li> <li><b>t392dce</b>—DCE polling verification timer (5–30 seconds)</li> </ul>	detail extensive none
LMI	<p>(Frame Relay) LMI packet statistics:</p> <ul style="list-style-type: none"> <li><b>Input</b>—Number of packets coming in on the interface (<i>nn</i>) and how much time has passed since the last packet arrived. The format is <b>Input: nn (last seen hh:mm:ss ago)</b>.</li> <li><b>Output</b>—Number of packets sent out on the interface (<i>nn</i>) and how much time has passed since the last packet was sent. The format is <b>Output: nn (last sent hh:mm:ss ago)</b>.</li> </ul>	detail extensive none
DTE statistics	<p>(Frame Relay) Statistics about messages transmitted from the data terminal equipment (DTE) to the data communication equipment (DCE):</p> <ul style="list-style-type: none"> <li><b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li><b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li><b>Enquiry responses received</b>—Number of enquiry responses received by the DTE from the DCE.</li> <li><b>Full enquiry responses received</b>—Number of full enquiry responses sent from the DTE to the DCE.</li> </ul>	detail extensive none
DCE statistics	<p>(Frame Relay) Statistics about messages transmitted from the DCE to the DTE:</p> <ul style="list-style-type: none"> <li><b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li><b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li><b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li><b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	detail extensive none

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Common statistics</b>	<p>(Frame Relay) Statistics about messages sent between the DTE and the DCE:</p> <ul style="list-style-type: none"> <li>• <b>Unknown messages received</b>—Number of received packets that do not fall into any category.</li> <li>• <b>Asynchronous updates received</b>—Number of link status peer changes received.</li> <li>• <b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li>• <b>Keepalive responses timedout</b>—Number of keepalive responses that timed out when no LMI packet was reported for <b>n392dte</b> or <b>n393dce</b> intervals. (See <b>LMI settings</b>.)</li> </ul>	<b>detail extensive none</b>
<b>Nonmatching DCE-end DLCIs</b>	(Frame Relay) Number of DLCIs configured from the DCE, displayed only from the DTE.	<b>detail extensive none</b>
<b>LCP state</b>	<p>(PPP) Link Control Protocol state.</p> <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—LCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—LCP is not configured on the interface.</li> <li>• <b>Opened</b>—LCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>NCP state</b>	<p>(PPP) Network Control Protocol state.</p> <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>CHAP state</b>	<p>(PPP) Displays the state of the Challenge Handshake Authentication Protocol (CHAP) during its transaction.</p> <ul style="list-style-type: none"> <li>• <b>Chap-Chal-received</b>—Challenge was received but response not yet sent.</li> <li>• <b>Chap-Chal-sent</b>—Challenge was sent.</li> <li>• <b>Chap-Resp-received</b>—Response was received for the challenge sent, but CHAP has not yet moved into the <b>Success</b> state. (Most likely with RADIUS authentication.)</li> <li>• <b>Chap-Resp-sent</b>—Response was sent for the challenge received.</li> <li>• <b>Closed</b>—CHAP authentication is incomplete.</li> <li>• <b>Failure</b>—CHAP authentication failed.</li> <li>• <b>Not-configured</b>—CHAP is not configured on the interface.</li> <li>• <b>Success</b>—CHAP authentication was successful.</li> </ul>	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>



Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
CoS queues	Number of CoS queues configured.	detail extensive none
Statistics last cleared	Time when the statistics for the interface were last set to zero.	detail extensive
Traffic statistics	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	detail extensive
Input errors	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Counter increments when the software could not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Count of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>HS link CRC errors</b>—Count of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>SRAM errors</b>—Number of hardware errors that occurred in the static RAM (SRAM) on the PIC. If the value in this field increments, the PIC is malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	extensive

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeds the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>DS1 alarms DS1 defects</b>	<p>Media-specific defects that can render the interface unable to pass packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface.</p> <ul style="list-style-type: none"> <li>• <b>LOS</b>—Loss of signal.</li> <li>• <b>LOF</b>—Loss of frame.</li> <li>• <b>AIS</b>—Alarm indication signal.</li> <li>• <b>YLW</b>—Yellow alarm. Indicates errors at the remote site receiver.</li> </ul>	<b>detail extensive none</b>

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>T1 media</b>	<p>Counts of T1 media-specific errors.</p> <ul style="list-style-type: none"> <li>• <b>Seconds</b>—Number of seconds the defect has been active.</li> <li>• <b>Count</b>—Number of times that the defect has gone from inactive to active.</li> <li>• <b>State</b>—State of the error. State other than <b>OK</b> indicates a problem.</li> </ul> <p>The T1 media-specific error types can be:</p> <ul style="list-style-type: none"> <li>• <b>AIS</b>—Alarm indication signal</li> <li>• <b>BEE</b>—Bit error event</li> <li>• <b>BES</b>—Bit error seconds</li> <li>• <b>BPV</b>—Bipolar violation</li> <li>• <b>CS</b>—Carrier state</li> <li>• <b>ES</b>—Errored seconds</li> <li>• <b>EXZ</b>—Excessive zeros</li> <li>• <b>FEBE</b>—Far-end block error</li> <li>• <b>LCV</b>—Line code violation</li> <li>• <b>LES</b>—Line error seconds</li> <li>• <b>LOF</b>—Loss of frame</li> <li>• <b>LOS</b>—Loss of signal</li> <li>• <b>PCV</b>—Pulse code violation</li> <li>• <b>SEF</b>—Severely errored framing</li> <li>• <b>SEFS</b>—Severely errored framing seconds (section)</li> <li>• <b>SES</b>—Severely errored seconds</li> <li>• <b>UAS</b>—Unavailable seconds</li> <li>• <b>YELLOW</b>—Errors at the remote site receiver</li> </ul>	<b>extensive</b>
<b>Line encoding</b>	Line encoding used: <b>B8ZS</b> or <b>AMI</b> .	All levels
<b>Buildout</b>	Buildout setting.	All levels
<b>HDLC configuration</b>	<p>Information about the HDLC configuration.</p> <ul style="list-style-type: none"> <li>• <b>Policing bucket</b>—Configured state of the receiving policer.</li> <li>• <b>Shaping bucket</b>—Configured state of the transmitting shaper.</li> <li>• <b>Giant threshold</b>—Giant threshold programmed into the hardware.</li> <li>• <b>Runt threshold</b>—Runt threshold programmed into the hardware.</li> <li>• <b>Timeslots</b>—Configured time slots for the interface.</li> <li>• <b>Line encoding</b>—Line encoding used: <b>B8ZS</b> or <b>AMI</b>.</li> <li>• <b>Byte encoding</b>—Byte encoding used: <b>Nx64K</b> or <b>Nx56K</b>.</li> <li>• <b>Data inversion</b>—HDLC data inversion setting: <b>Enabled</b> or <b>Disabled</b>.</li> <li>• <b>Idle cycle Flag</b>—Idle cycle flags.</li> <li>• <b>Start end Flag</b>—Start and end flag.</li> </ul>	<b>extensive</b>

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DSO or DS1 BERT configuration</b>	<p>BERT (bit error rate test) checks the quality of the line. This output appears only when a BERT is run on the interface.</p> <ul style="list-style-type: none"> <li>• <b>BERT time period</b>—Configured total time period that the BERT is to run.</li> <li>• <b>Elapsed</b>—Actual time elapsed since the start of the BERT (in seconds).</li> <li>• <b>Induced error rate</b>—Configured rate at which the bit errors are induced in the BERT pattern.</li> <li>• <b>Algorithm</b>—Type of algorithm selected for the BERT.</li> </ul>	<b>detail extensive none</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> <li>• <b>PLP byte</b>—Packet Level Protocol byte.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface; values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>All levels</b>
<b>Encapsulation</b>	Encapsulation on the logical interface.	<b>All levels</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>

Table 133: Channelized T1 IQ and T3 IQ show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>DLCI</b>	<p>(Frame Relay) DLCI number of the logical interface. The following DLCI information is displayed: <b>Flags</b>, <b>Total down time</b>, <b>Last down</b>, and <b>Traffic statistics</b>. <b>Flags</b> is one or more of the following:</p> <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when the link is active, but no information is received from the DCE.</li> <li>• <b>Unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the corresponding DLCI in the DCE is configured.</li> <li>• <b>Dce-configured</b>—Displayed when the command is issued from the DTE.</li> </ul>	<b>detail extensive none</b>
<b>DLCI statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	<b>detail extensive none</b>

## Sample Output

### show interfaces extensive (CT1)

```

user@host> show interfaces extensive ct1-0/1/1
Physical interface: ct1-0/1/1, Enabled, Physical link is Up
  Interface index: 145, SNMP ifIndex: 32, Generation: 28
  Link-level type: Controller, Clocking: Internal, Speed: T1,
  Loopback: None, Framing: ESF, Parent: None
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps 16384
Link flags     : None
Hold-times    : Up 0 ms, Down 0 ms
CoS queues    : 4 supported
Last flapped  : 2005-08-17 11:47:09 PDT (1d 03:38 ago)
Statistics last cleared: 2005-08-18 15:25:37 PDT (00:00:27 ago)
DS1 alarms    : None
DS1 defects   : None
T1 media:
      Seconds      Count  State
SEF              0        0  OK
BEE              0        0  OK
AIS              0        0  OK
LOF              0        0  OK
LOS              0        0  OK
YELLOW           0        0  OK
BPV              0        0
EXZ              0        0
LCV              0        0
PCV              0        0
CS               0        0
LES              0
ES               0
SES              0
SEFS             0
BES              0
UAS              0
Line encoding: B8ZS
Buildout      : 0 to 132 feet
DS1 BERT configuration:
  BERT time period: 10 seconds, Elapsed: 0 seconds
  Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
  Destination slot: 0 (0x00)

```

### show interfaces extensive (T1)

```

user@host> show interfaces extensive t1-0/2/0
Physical interface: t1-0/2/0, Enabled, Physical link is Up
  Interface index: 161, SNMP ifIndex: 33, Generation: 61
  Link-level type: PPP, MTU: 1504, Speed: T1, Loopback: None, FCS: 16,
  Parent: ct1-0/2/0 Interface index 148
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps 16384
Link flags     : Keepalives DTE
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI: Input: 51700 (00:00:02 ago), Output: 51701 (00:00:02 ago)
DTE statistics:
  Enquiries sent           : 43186
  Full enquiries sent      : 8515
  Enquiry responses received : 43185
  Full enquiry responses received : 8515
DCE statistics:
  Enquiries received       : 0

```

```

Full enquiries received      : 0
Enquiry responses sent      : 0
Full enquiry responses sent  : 0
Common statistics:
Unknown messages received   : 0
Asynchronous updates received : 0
Out-of-sequence packets received : 0
Keepalive responses timedout : 0
Nonmatching DCE-end DLCIs:
2
Hold-times      : Up 0 ms, Down 0 ms
CoS queues     : 4 supported
Last flapped   : 2005-09-07 15:43:47 PDT (00:00:06 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   : 0          0 bps
Output bytes  : 14         0 bps
Input packets : 0          0 pps
Output packets: 1          0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Policed discards: 0, L3 incompletes: 0,
L2 channel errors: 0, L2 mismatch timeouts: 0,
HS link CRC errors: 0, SRAM errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Aged packets: 0,
MTU errors: 0, Resource errors: 0
Queue counters:      Queued packets  Transmitted packets  Dropped packets
0 best-effort        0              0                  0
1 expedited-fo       0              0                  0
2 assured-forw       0              0                  0
3 network-cont       1              1                  0
DS1  alarms   : None
DS1  defects  : None
HDLC configuration:
Policing bucket: Disabled
Shaping bucket : Disabled
Giant threshold: 1514, Runt threshold: 2
Timeslots      : All active
Byte encoding: Nx64K, Data inversion: Disabled, Idle cycle flag:
flags, Start end flag: shared
Packet Forwarding Engine configuration:
Destination slot: 0, PLP byte: 4 (0x00)

```

### show interfaces extensive (DS0)

```

user@host> show interfaces extensive ds-0/1/0:0
Physical interface: ds-0/1/0:1, Enabled, Physical link is Up
Interface index: 157, SNMP ifIndex: 52, Generation: 46
Link-level type: Frame-Relay, PPP, MTU: 1504, Clocking: Internal,
Speed: 640kbps, Loopback: None, FCS:16,
Parent: ct1-0/1/0 Interface index 143
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps 16384
Link flags     : Keepalives DTE
ANSI LMI settings: n391dte 6, n392dte 3, n393dte 4, t391dte 10 seconds
LMI: Input: 51700 (00:00:02 ago), Output: 51701 (00:00:02 ago)
DTE statistics:
Enquiries sent      : 43186
Full enquiries sent : 8515
Enquiry responses received : 43185
Full enquiry responses received : 8515
DCE statistics:

```

```

    Enquiries received           : 0
    Full enquiries received      : 0
    Enquiry responses sent       : 0
    Full enquiry responses sent   : 0
Common statistics:
    Unknown messages received    : 0
    Asynchronous updates received : 0
    Out-of-sequence packets received : 0
    Keepalive responses timedout  : 0
Nonmatching DCE-end DLCIs:
    2
Hold-times      : Up 0 ms, Down 0 ms
Keepalive settings: Interval 10 seconds, Up-count 1, Down-count 3
Keepalive statistics:
    Input : 8 (last seen 00:00:12 ago)
    Output: 8 (last sent 00:00:07 ago)
LCP state: Opened
NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured,
mpls: Not-configured
CHAP state: Not-configured
CoS queues      : 4 supported
Last flapped    : 2005-08-18 15:23:46 PDT (00:03:17 ago)
Statistics last cleared: 2005-08-18 15:25:37 PDT (00:01:26 ago)
Traffic statistics:
    Input bytes :           840           0 bps
    Output bytes :          912           0 bps
    Input packets:           25           0 pps
    Output packets:          26           0 pps
Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0, L3 incompletes: 0,
    L2 channel errors: 0, L2 mismatch timeouts: 0, HS link CRC errors: 0,
    Resource errors: 0
Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, Aged packets: 0,
    MTU errors: 0, Resource errors: 0
Queue counters:      Queued packets  Transmitted packets  Dropped packets
0 best-effort        0                0                0
1 expedited-fo       0                0                0
2 assured-forw       0                0                0
3 network-cont       26                26                0
HDLC configuration:
    Giant threshold: 1514, Runt threshold: 2
    Timeslots      : 1-10
    Byte encoding: Nx64K, Data inversion: Disabled, Idle cycle flag: flags,
    Start end flag: shared
DSO BERT configuration:
    BERT time period: 10 seconds, Elapsed: 0 seconds
    Induced Error rate: 10e-0, Algorithm: 2^15 - 1, 0.151, Pseudorandom (9)
Packet Forwarding Engine configuration:
    Destination slot: 0, PLP byte: 4 (0x00)
Logical interface ds-0/1/0:1.0 (Index 67) (SNMP ifIndex 53) (Generation 11)
    Flags: Point-To-Point SNMP-Traps Encapsulation: PPP
    Protocol inet, MTU: 1500, Generation: 26, Route table: 0
    Flags: None
    Addresses, Flags: Is-Preferred Is-Primary
        Destination: 11.11.11.0/30, Local: 11.11.11.2, Broadcast: 11.11.11.3,
        Generation: 39
DLCI 100
    Flags: Active, Dce-configured
    Total down time: 0 sec, Last down: Never

```



```
Traffic statistics:
  Input bytes :          0
  Output bytes :          0
  Input packets:          0
  Output packets:         0
DLCI statistics:
  Active DLCI :2 Inactive DLCI : 0
...
```

## show interfaces (Channelized T3 IQ)

<b>Syntax</b>	<pre>show interfaces (ct3-fpc/pic/port   type-fpc/pic/port&lt;:channel&gt;&lt;:channel&gt;) &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified channelized T3 IQ interface.
<b>Options</b>	<p><b>type-fpc/pic/port:channel</b>—Interface type. With optional corresponding channel levels, the interface type can be one of the following:</p> <ul style="list-style-type: none"> <li><b>type-fpc/pic/port</b>—For the physical channelized T3 IQ interface, <b>type</b> is <b>ct3</b>.</li> <li><b>type-fpc/pic/port:channel</b>—For the clear channel, <b>type</b> is <b>t3</b>. At the first level of channelization, <b>type</b> can be <b>ct1</b> or <b>t1</b>.</li> <li><b>type-fpc/pic/port:channel:channel</b>—At the second level of channelization, <b>type</b> is <b>ds</b>.</li> </ul> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces extensive (Channelized T3 IQ) (Physical) on page 849</a></p> <p><a href="#">show interfaces extensive (Channelized T1 on Channelized T3 IQ) on page 849</a></p> <p><a href="#">show interfaces extensive (DSO on Channelized T3 IQ) on page 849</a></p>
<b>Output Fields</b>	See the output field table for the <a href="#">show interfaces (Channelized T1 IQ)</a> command.

## Sample Output

**show interfaces  
extensive (Channelized  
T3 IQ) (Physical)**

```
user@host> show interfaces extensive ct3-0/0/1
Physical interface: ct3-0/0/1, Enabled, Physical link is Up
  Interface index: 30, SNMP ifIndex: 317, Generation: 29
  Link-level type: Controller, MTU: 4474, Clocking: Internal, Speed: T3,
  Loopback: None, FCS: 16, Mode: C/Bit parity, Parent: None
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : None
...
```

**show interfaces  
extensive  
(Channelized T1 on  
Channelized T3 IQ)**

```
user@host> show interfaces extensive ct1-0/0/1:2
Physical interface: ct1-0/0/1:2, Enabled, Physical link is Up
  Interface index: 175, SNMP ifIndex: 1505, Generation: 174
  Link-level type: Controller, MTU: 1504, Clocking: Internal, Speed: T1,
  Loopback: None, FCS: 16, Framing: ESF, Parent: ct3-0/0/1 (Index 32)
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : None
...
```

**show interfaces  
extensive (DS0 on  
Channelized T3 IQ)**

```
user@host> show interfaces extensive ds-0/0/1:2:1
Physical interface: ds-0/0/1:2:1, Enabled, Physical link is Up
  Interface index: 176, SNMP ifIndex: 1563, Generation: 175
  Link-level type: PPP, MTU: 1504, Clocking: Internal, Speed: 640kbps,
  Loopback: None, FCS: 16, Parent: ct1-0/0/1:2 (Index 175)
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : Keepalives
...
```

## show interfaces controller (Channelized T1 IQ)

<b>Syntax</b>	<code>show interfaces controller ct1-<i>fpc/pic/slot</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display the interface names of the specified physical channelized T1 IQ interface and the channels configured on it.
<b>Options</b>	<code>ct1-<i>fpc/pic/slot</i></code> —Channelized T1 IQ interface name.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces controller (T1 IQ) (Clear-Channel T1) on page 850</a> <a href="#">show interfaces controller (T1 IQ) (Channelized DS) on page 850</a>
<b>Output Fields</b>	<a href="#">Table 134 on page 850</a> lists the output fields for the <b>show interfaces controller</b> (Channelized T1 IQ) command. Output fields are listed in the approximate order in which they appear.

**Table 134: Channelized T1 IQ show interfaces controller Output Fields**

Field Name	Field Description
<b>Controller</b>	Physical channelized interface name and the names of any channels configured on it.
<b>Admin</b>	Administrative status of the interface.
<b>Link</b>	Link status of the interface.

## Sample Output

### show interfaces controller (T1 IQ) (Clear-Channel T1)

The following sample output displays the channelized T1 IQ interface when it is configured as a clear-channel T1 interface:

```
user@host> show interfaces controller ct1-0/2/0
```

Controller	Admin	Link
ct1-0/2/0	up	up
t1-0/2/0	up	up

### show interfaces controller (T1 IQ) (Channelized DS)

The following sample output displays the channelized T1 IQ interfaces when it is configured down to the channelized DS level:

```
user@host> show interfaces controller ct1-0/2/1
```

Controller	Admin	Link
ct1-0/2/1	up	up
ds-0/2/1:1	up	up
ds-0/2/1:2	up	up

## show interfaces controller (Channelized T3 IQ)

<b>Syntax</b>	<code>show interfaces controller ct3-<i>fpc/pic/slot</i></code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display the interface names of the specified physical channelized T3 IQ interface and the channels configured on it.
<b>Options</b>	<code>ct3-<i>fpc/pic /slot</i></code> —Channelized T3 IQ interface name.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces controller (T3 IQ) on page 851</a>
<b>Output Fields</b>	<a href="#">Table 135 on page 851</a> lists the output fields for the <code>show interfaces controller</code> (Channelized T3 IQ) command. Output fields are listed in the approximate order in which they appear.

**Table 135: Channelized T3 IQ show interfaces controller Output Fields**

Field Name	Field Description
<b>Controller</b>	Physical channelized interface name and the names of any channels configured on it.
<b>Admin</b>	Administrative status of the interface.
<b>Link</b>	Link status of the interface.

## Sample Output

```

show interfaces controller (T3 IQ)
user@host> show interfaces controller ct3-0/0/1
Controller
ct3-0/0/1
  t1-0/0/1:1
  ct1-0/0/1:2
    ds-0/0/1:2:1
    ds-0/0/1:2:2
    ds-0/0/1:2:3
  t1-0/0/1:3
  ...
  t1-0/0/1:10
  ct1-0/0/1:11
  ...
  ct1-0/0/1:28
Admin Link
up      up
up      up
up      up
up      up
up      up
up      up
up      down
up      up
up      up
up      up

```



## PART 11

# Services Interfaces

- [Adaptive Services Interface Operational Mode Commands on page 855](#)
- [Encryption Interface Operational Mode Commands on page 869](#)
- [Flow Collector and Monitoring Interface Operational Mode Commands on page 877](#)
- [Link Services Interface Operational Mode Commands on page 893](#)
- [Tunnel Services Interface Operational Mode Commands on page 957](#)
- [VoIP Interface Operational Mode Commands on page 991](#)





# Adaptive Services Interface Operational Mode Commands

Table 136 on page 855 summarizes the command line interface (CLI) commands that you can use to monitor and troubleshoot adaptive services operations.


**Table 136: Adaptive Services Interface Operational Mode Commands**

Task	Command
(M Series and T Series routers only) Manually revert to the primary adaptive services interface or link services IQ interface, or to switch from the primary to the secondary interface.	<a href="#">request interface (revert   switchover) (Adaptive Services)</a>
Display status information about the specified adaptive services interface.	<a href="#">show interfaces (Adaptive Services)</a>
(M Series and T Series routers only) Display status information about the specified redundant adaptive services configuration.	<a href="#">show interfaces (Redundant Adaptive Services)</a>
(M series, T Series, and MX Series routers only) Display general information about adaptive services and link services intelligent queuing (IQ) interfaces redundancy.	<a href="#">show interfaces redundancy</a>



**NOTE:** For information about how to configure adaptive services, see the *Junos Services Interfaces Configuration Guide*.

## request interface (revert | switchover) (Adaptive Services)

<b>Syntax</b>	request interface (revert   switchover) ( <i>rspnumber</i>   <i>rlsnumber</i> )
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. Support for <b>rlsq</b> interfaces added in Junos OS Release 7.6.
<b>Description</b>	(M Series and T Series routers only) Manually revert to the primary adaptive services interface or link services IQ interface, or to switch from the primary to the secondary interface.
	<div>  <p><b>NOTE:</b> All <b>rlsq</b> switchover or revert operations are allowed from the <b>rlsnumber</b> level only and not for individual channelized interfaces (<b>rlsnumber:unit</b>).</p> </div> <p>On an aggregated Ethernet interface with link protection enabled, use the <b>request interface (revert   switchover)</b> (Aggregated Ethernet Link Protection) operational command to manually revert egress traffic from the designated backup link to the designated primary link, or to manually switch egress traffic from the primary link to the backup link. For information about this command, see <a href="#">request interface (revert   switchover) (Aggregated Ethernet Link Protection)</a>.</p>
<b>Options</b>	<p><b>(revert   switchover)</b>—The <b>revert</b> keyword restores active processing to the primary adaptive services (sp) or link services IQ (lsq) interface. The <b>switchover</b> keyword transfers active processing to the secondary (backup) interface.</p> <p><b>rspnumber</b>—Redundant adaptive services interface name.</p> <p><b>rlsnumber</b>—Redundant link services IQ interface name.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">request interface revert on page 856</a> <a href="#">request interface switchover on page 856</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

<b>request interface revert</b>	<pre>user@host&gt; request interface revert rlsq0 request succeeded</pre>
<b>request interface switchover</b>	<pre>user@host&gt; request interface switchover rlsq0 error: rlsq0: already on secondary</pre>

## show interfaces (Adaptive Services)

<b>Syntax</b>	<pre>show interfaces <i>interface-type</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified adaptive services interface.
<b>Options</b>	<p><b><i>interface-type</i></b>—On M Series and T Series routers, the interface type is <b>sp-<i>fpc/pic/port</i></b>. On J Series routers, the interface type is <b>sp-<i>pim/O/port</i></b>.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Adaptive Services) on page 862</a></p> <p><a href="#">show interfaces brief (Adaptive Services) on page 862</a></p> <p><a href="#">show interfaces detail (Adaptive Services) on page 862</a></p> <p><a href="#">show interfaces extensive (Adaptive Services) on page 863</a></p>
<b>Output Fields</b>	Table 137 on page 857 lists the output fields for the <b>show interfaces</b> (adaptive services and redundant adaptive services) command. Output fields are listed in the approximate order in which they appear.

**Table 137: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields**

Field Name	Field Description	Level of Output
Physical Interface		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>

Table 137: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields (continued)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Encapsulation being used on the interface.	All levels
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source: can be <b>Internal</b> or <b>External</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link type</b>	Physical interface link type: <b>Full-Duplex</b> or <b>Half-Duplex</b> .	<b>detail extensive none</b>
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive none</b>
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive none</b>
<b>Hardware address</b>	MAC address of the hardware.	<b>detail extensive none</b>
<b>Alternate link address</b>	Backup address of the link.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 137: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields (continued)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifindex</b>	SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

**Table 137: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields**  
(continued)

Field Name	Field Description	Level of Output
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the logical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes generally less than 1 second for the counter to stabilize.	<b>detail extensive</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mpls</b> .	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>

**Table 137: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields**  
(continued)

Field Name	Field Description	Level of Output
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces (Adaptive Services)

```
user@host> show interfaces sp-1/2/0
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Interface index: 147, SNMP ifIndex: 72
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Last flapped   : 2006-03-06 11:37:18 PST (00:57:29 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

Logical interface sp-1/2/0.16383 (Index 68) (SNMP ifIndex 73)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
  Input packets : 3057
  Output packets: 3044
  Protocol inet, MTU: 9192
    Flags: Receive-options, Receive-TTL-Exceeded
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.0.0.34, Local: 10.0.0.1
```

### show interfaces brief (Adaptive Services)

```
user@host> show interfaces sp-1/2/0 brief
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000

Logical interface sp-1/2/0.16383
  Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
  inet 10.0.0.1      --> 10.0.0.34
```

### show interfaces detail (Adaptive Services)

```
user@host> show interfaces sp-1/2/0 detail
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Interface index: 147, SNMP ifIndex: 72, Generation: 30
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info   : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : 2006-03-06 11:37:18 PST (00:57:56 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :          125147          0 bps
    Output bytes  :         1483113          0 bps
    Input packets :           3061          0 pps
    Output packets:           3048          0 pps

Logical interface sp-1/2/0.16383 (Index 68) (SNMP ifIndex 73) (Generation 7)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
```



```

Traffic statistics:
  Input bytes :          125147
  Output bytes :         1483113
  Input packets:          3061
  Output packets:         3048
Local statistics:
  Input bytes :          125147
  Output bytes :         1483113
  Input packets:          3061
  Output packets:         3048
Transit statistics:
  Input bytes :           0          0 bps
  Output bytes :           0          0 bps
  Input packets:           0          0 pps
  Output packets:          0          0 pps
Protocol inet, MTU: 9192, Generation: 20, Route table: 1
  Flags: Receive-options, Receive-TTL-Exceeded
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.0.34, Local: 10.0.0.1, Broadcast: Unspecified,
    Generation: 22

```

**show interfaces  
extensive  
(Adaptive Services)**

```

user@host> show interfaces sp-1/2/0 extensive
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Interface index: 147, SNMP ifIndex: 72, Generation: 30
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type : Full-Duplex
  Link flags : None
  Physical info : Unspecified
  Hold-times : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped : 2006-03-06 11:37:18 PST (00:58:40 ago)
  Statistics last cleared: Never
Traffic statistics:
  Input bytes :          125547          0 bps
  Output bytes :         1483353          0 bps
  Input packets:          3065          0 pps
  Output packets:         3052          0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, Resource errors: 0
Output errors:
  Carrier transitions: 2, Errors: 0, Drops: 0, MTU errors: 0,
  Resource errors: 0

Logical interface sp-1/2/0.16383 (Index 68) (SNMP ifIndex 73) (Generation 7)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
Traffic statistics:
  Input bytes :          125547
  Output bytes :         1483353
  Input packets:          3065
  Output packets:         3052
Local statistics:
  Input bytes :          125547
  Output bytes :         1483353
  Input packets:          3065
  Output packets:         3052
Transit statistics:

```

```
Input bytes :          0          0 bps
Output bytes :          0          0 bps
Input packets:          0          0 pps
Output packets:         0          0 pps
Protocol inet, MTU: 9192, Generation: 20, Route table: 1
  Flags: Receive-options, Receive-TTL-Exceeded
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.0.34, Local: 10.0.0.1, Broadcast: Unspecified,
    Generation: 22
```

## show interfaces (Redundant Adaptive Services)

---

<b>Syntax</b>	<code>show interfaces <i>rspnumber</i></code> <code>&lt;brief   detail   extensive   terse&gt;</code> <code>&lt;descriptions&gt;</code> <code>&lt;media&gt;</code> <code>&lt;snmp-index <i>snmp-index</i>&gt;</code> <code>&lt;statistics&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified redundant adaptive services configuration.
<b>Options</b>	<p><b><i>rspnumber</i></b>—Display standard status information about the specified redundant adaptive services configuration.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Redundant Adaptive Services) on page 866</a>
<b>Output Fields</b>	See the output field table for the <a href="#">show interfaces (Adaptive Services)</a> command.

## Sample Output

**show interfaces  
extensive (Redundant  
Adaptive Services)**

```

user@host> show interfaces rsp0 extensive
Physical interface: rsp0, Enabled, Physical link is Up
  Interface index: 150, SNMP ifIndex: 40, Generation: 44
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Redundancy-Device 16384
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : 2005-03-11 18:36:37 UTC (00:00:08 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
    Resource errors: 0

Logical interface rsp0.0 (Index 68) (SNMP ifIndex 42) (Generation 30)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
  Traffic statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Local statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Transit statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
  Protocol inet, MTU: 9192, Generation: 37, Route table: 0
    Flags: Receive-options, Receive-TTL-Exceeded

```

## show interfaces redundancy

<b>Syntax</b>	<code>show interfaces redundancy</code> <code>&lt;brief   detail&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4. <b>detail</b> option added in Junos OS Release 10.0.
<b>Description</b>	(M Series, T Series, and MX Series routers only) Display general information about adaptive services and link services intelligent queuing (IQ) interfaces and aggregated Ethernet interfaces redundancy.
<b>Options</b>	<b>brief   detail</b> —(Optional) Display the specified level of output.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces redundancy on page 868</a> <a href="#">show interfaces redundancy (Aggregated Ethernet) on page 868</a> <a href="#">show interfaces redundancy detail on page 868</a>
<b>Output Fields</b>	<a href="#">Table 138 on page 867</a> lists the output fields for the <b>show interfaces redundancy</b> command. Output fields are listed in the approximate order in which they appear.

**Table 138: show interfaces redundancy Output Fields**

Field Name	Field Description	Level of Output
<b>Interface</b>	Name of the redundant adaptive services, link services IQ interfaces, or aggregated Ethernet interfaces.	All levels
<b>State</b>	State of the redundant interface: <b>Not present</b> , <b>On primary</b> , <b>On secondary</b> or <b>Waiting for primary MS PIC</b> .	All levels
<b>Last Change</b>	Timestamp for the last change in status. This value resets after a master Routing Engine switchover event if any of the following conditions is met: <ul style="list-style-type: none"> <li>• GRES is not configured on the router.</li> <li>• The <b>rlsq</b> interface is configured without the <b>hot-standby</b> or <b>warm-standby</b> statements and the backup <b>lsq</b> interface was active before the switchover.</li> <li>• No logical interfaces are configured or all of the configured logical interfaces are down at the time of the switchover.</li> </ul>	All levels
<b>Primary</b>	Name of the interface configured to be the primary interface.	All levels
<b>Secondary</b>	Name of the interface configured to be the backup interface.	All levels
<b>Current Status</b>	Physical status of the primary and secondary interfaces.	All levels
<b>Mode</b>	Standby mode.	<b>detail</b>

## Sample Output

### show interfaces redundancy

```
user@host> show interfaces redundancy
Interface  State           Last change  Primary    Secondary   Current status
rsp0       Not present
rsp1       On secondary    1d 23:56     sp-1/2/0   sp-0/3/0    primary down
rsp2       On primary      10:10:27     sp-1/3/0   sp-0/2/0    secondary down
rlsq0      On primary      00:06:24     lsq-0/3/0   lsq-1/0/0    both up
```

### show interfaces redundancy (Aggregated Ethernet)

```
user@host> show interfaces redundancy
Interface  State           Last change  Primary    Secondary   Current status
rlsq0      On secondary    00:56:12     lsq-4/0/0   lsq-3/0/0    both up

ae0
ae1
ae2
ae3
ae4
```

### show interfaces redundancy detail

```
user@host> show interfaces redundancy detail
Interface   : rlsq0
State       : On primary
Last change : 00:45:47
Primary     : lsq-0/2/0
Secondary   : lsq-1/2/0
Current status : both up
Mode        : hot-standby

Interface   : rlsq0:0
State       : On primary
Last change : 00:45:46
Primary     : lsq-0/2/0:0
Secondary   : lsq-1/2/0:0
Current status : both up
Mode        : warm-standby
```

## CHAPTER 20

# Encryption Interface Operational Mode Commands

Table 139 on page 869 summarizes the command-line interface (CLI) command that you can use to monitor and troubleshoot encryption interfaces.

**Table 139: Encryption Interface Operational Mode Commands**

Task	Command
Display status information about encryption interfaces.	<a href="#">show interfaces (Encryption)</a>

## show interfaces (Encryption)

<b>Syntax</b>	<pre>show interfaces es-fpc/pic/port:channel &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified encryption interface.
<b>Options</b>	<p><b>es-fpc/pic/port:channel</b>—Display standard status information about the specified encryption interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces (Encryption) on page 874</a> <a href="#">show interfaces brief (Encryption) on page 874</a> <a href="#">show interfaces detail (Encryption) on page 874</a> <a href="#">show interfaces extensive (Encryption) on page 875</a>
<b>Output Fields</b>	Table 140 on page 870 lists the output fields for the <b>show interfaces</b> (ES) command. Output fields are listed in the approximate order in which they appear.

Table 140: Encryption show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>



Table 140: Encryption show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Encapsulation being used on the interface.	All levels
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> <li>• <b>Anti-replay failures</b>—Total number of antireplay failures seen on all tunnels configured on the ES PIC.</li> <li>• <b>Authentication</b>—Total number of authentication failures seen on all tunnels configured on the ES PIC.</li> </ul>	<b>detail extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters</b>	CoS queue number and its associated user-configured forwarding class name. <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>

Table 140: Encryption show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>IP-Header</b>	IP header of the logical interface.	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mpls</b> .	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .Address	<b>detail extensive none</b>

Table 140: Encryption show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interface.	<b>detail extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces (Encryption)

```
user@host> show interfaces es-0/3/0
Physical interface: es-0/3/0, Enabled, Physical link is Up
  Interface index: 138, SNMP ifIndex: 71
  Type: IPSEC, Link-level type: IPSEC-over-IP, MTU: 3900, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

Logical interface es-0/3/0.0 (Index 70) (SNMP ifIndex 45)
  Flags: Hardware-Down Point-To-Point SNMP-Traps
  IP-Header 10.0.10.2:10.0.10.1::df:64:00000000 Encapsulation: IPSEC
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 3800
  Flags: None
  Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
    Destination: 10.10.0.2, Local: 10.10.0.1
```

### show interfaces brief (Encryption)

```
user@host> show interfaces es-0/3/0 brief
Physical interface: es-0/3/0, Enabled, Physical link is Up
  Type: IPSEC, Link-level type: IPSEC-over-IP, MTU: 3900, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps

Logical interface es-0/3/0.0
  Flags: Hardware-Down Point-To-Point SNMP-Traps
  IP-Header 10.0.10.2:10.0.10.1::df:64:00000000 Encapsulation: IPSEC
  inet 10.10.0.1      --> 10.10.0.2s
```

### show interfaces detail (Encryption)

```
user@host> show interfaces es-0/3/0 detail
Physical interface: es-0/3/0, Enabled, Physical link is Up
  Interface index: 138, SNMP ifIndex: 71, Generation: 21
  Type: IPSEC, Link-level type: IPSEC-over-IP, MTU: 3900, Speed: 800mbps
  Hold-times      : Up 0 ms, Down 0 ms
  Device flags    : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes : 0 0 bps
    Output bytes : 0 0 bps
    Input packets: 0 0 pps
    Output packets: 0 0 pps
  Anti-replay failures : 0
  Authentication failures : 0
  Egress queues: 4 supported, 4 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort    0 0 0
    1 expedited-fo   0 0 0
    2 assured-forw   0 0 0
    3 network-cont   0 0 0
```

```

Logical interface es-0/3/0.0 (Index 70) (SNMP ifIndex 45) (Generation 9)
Flags: Hardware-Down Point-To-Point SNMP-Traps
IP-Header 10.0.10.2:10.0.10.1::df:64:00000000 Encapsulation: IPSEC
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Transit statistics:
  Input bytes : 0 0 bps
  Output bytes : 0 0 bps
  Input packets: 0 0 pps
  Output packets: 0 0 pps
Protocol inet, MTU: 3800, Generation: 22, Route table: 0
Flags: None
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 10.10.0.2, Local: 10.10.0.1, Broadcast: Unspecified,
Generation: 26

```

#### show interfaces extensive (Encryption)

```

user@host> show interfaces es-0/3/0 extensive
Physical interface: es-0/3/0, Enabled, Physical link is Up
Interface index: 138, SNMP ifIndex: 71, Generation: 21
Type: IPSEC, Link-level type: IPSEC-over-IP, MTU: 3900, Speed: 800mbps
Hold-times      : Up 0 ms, Down 0 ms
Device flags    : Present Running
Interface flags: Point-To-Point SNMP-Traps
Statistics last cleared: Never
Traffic statistics:
  Input bytes : 0 0 bps
  Output bytes : 0 0 bps
  Input packets: 0 0 pps
  Output packets: 0 0 pps
Anti-replay failures : 0
Authentication failures : 0
Egress queues: 4 supported, 4 in use
Queue counters:

```

	Queued packets	Transmitted packets	Dropped packets
0 best-effort	0	0	0
1 expedited-fo	0	0	0
2 assured-forw	0	0	0
3 network-cont	0	0	0

```

Logical interface es-0/3/0.0 (Index 70) (SNMP ifIndex 45) (Generation 9)
Flags: Hardware-Down Point-To-Point SNMP-Traps
IP-Header 10.0.10.2:10.0.10.1::df:64:00000000 Encapsulation: IPSEC
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Local statistics:

```

```
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
Protocol inet, MTU: 3800, Generation: 22, Route table: 0
Flags: None
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 10.10.0.2, Local: 10.10.0.1, Broadcast: Unspecified,
Generation: 26
```

# Flow Collector and Monitoring Interface Operational Mode Commands

Table 141 on page 877 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot flow collector and flow monitoring interfaces. Commands are listed in alphabetical order.

**Table 141: Flow Collector and Monitoring Interface Operational Mode Commands**

Task	Command
Display status information about dynamic flow capture interfaces.	<a href="#">show interfaces (Dynamic Flow Capture)</a>
Display status information about flow collector interfaces.	<a href="#">show interfaces (Flow Collector)</a>
Display status information about flow monitoring interfaces.	<a href="#">show interfaces (Flow Monitoring)</a>

## show interfaces (Dynamic Flow Capture)

<b>Syntax</b>	<code>show interfaces dfc-<i>fpc/pic/port:channel</i></code> <code>&lt;brief   detail   extensive   terse&gt;</code> <code>&lt;descriptions&gt;</code> <code>&lt;media&gt;</code> <code>&lt;snmp-index <i>snmp-index</i>&gt;</code> <code>&lt;statistics&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 7.4.
<b>Description</b>	(M320 and M120 routers and T Series routers only) Display status information about the specified dynamic flow capture interface.
<b>Options</b>	<p><code>dfc-<i>fpc/pic/port:channel</i></code>—Display standard status information about the specified dynamic flow capture interface.</p> <p><code>brief   detail   extensive   terse</code>—(Optional) Display the specified level of output.</p> <p><code>descriptions</code>—(Optional) Display interface description strings.</p> <p><code>media</code>—(Optional) Display media-specific information about network interfaces.</p> <p><code>snmp-index <i>snmp-index</i></code>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><code>statistics</code>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces (Dynamic Flow Capture) on page 881</a>
<b>Output Fields</b>	<a href="#">Table 142 on page 878</a> lists the output fields for the <b>show interfaces</b> (Dynamic Flow Capture) command. Output fields are listed in the approximate order in which they appear.

Table 142: Dynamic Flow Capture show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Type</b>	Type of interface.	All levels



Table 142: Dynamic Flow Capture show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Link-level type	Encapsulation type used on the physical interface.	All levels
MTU	Maximum Transmit Unit (MTU). Size of the largest packet to be transmitted.	All levels
Speed	Network speed on the interface.	All levels
Device flags	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
Interface flags	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
Link type	Data transmission type.	All levels
Link flags	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
Last flapped	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: <i>year-month-day hour:minute:second timezone (hour:minute:second ago)</i></b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	detail extensive
Input Rate	Input rate in bits per second (bps) and packets per second (pps).	None specified
Output Rate	Output rate in bps and pps.	None specified
Traffic statistics	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li><b>Input rate, Output rate</b>—Number of bits per second (packets per second) received and transmitted on the interface.</li> <li><b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	detail extensive
Input errors	<ul style="list-style-type: none"> <li><b>Errors</b>—Input errors on the interface.</li> <li><b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li><b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li><b>Runts</b>—Frames received smaller than the runt threshold.</li> <li><b>Giants</b>—Frames received larger than the giant threshold.</li> <li><b>Policed Discards</b>—Frames that the incoming packet match code discarded because the frames did not recognize them or were not of interest. Usually, this field reports protocols that the Junos OS does not support.</li> <li><b>Resource errors</b>—Sum of transmit drops.</li> </ul>	extensive

Table 142: Dynamic Flow Capture show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Flags</b>	Information about the logical interface; values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface (such as <b>iso</b> or <b>inet6</b> ).	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Addresses associated with the logical interface and information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>

Table 142: Dynamic Flow Capture show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>

## Sample Output

### show interfaces (Dynamic Flow Capture)

```

user@host> show interfaces dfc-0/0/0
Physical interface: dfc-0/0/0, Enabled, Physical link is Up
Interface index: 146, SNMP ifIndex: 36
Type: Adaptive-Services, Link-level type: Dynamic-Flow-Capture, MTU: 9192, Speed:
2488320kbps
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps 16384
Link type : Full-Duplex
Link flags : None
Last flapped : 2005-08-26 15:08:36 PDT (01:18:42 ago)
Input rate : 0 bps (0 pps)
Output rate : 44800440 bps (100000 pps)

Logical interface dfc-0/0/0.0 (Index 67) (SNMP ifIndex 43)
Flags: Point-To-Point SNMP-Traps Encapsulation: Dynamic-Flow-Capture
Input packets : 74
Output packets: 132
Protocol inet, MTU: 9192
Flags: Receive-options, Receive-TTL-Exceeded
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.36.100.1, Local: 10.36.100.2

Logical interface dfc-0/0/0.1 (Index 68) (SNMP ifIndex 49)
Flags: Point-To-Point SNMP-Traps Encapsulation: Dynamic-Flow-Capture
Input packets : 0
Output packets: 402927263
Protocol inet, MTU: 9192
Flags: Receive-options, Receive-TTL-Exceeded

Logical interface dfc-0/0/0.2 (Index 69) (SNMP ifIndex 50)
Flags: Point-To-Point SNMP-Traps Encapsulation: Dynamic-Flow-Capture
Input packets : 0
Output packets: 0
Protocol inet, MTU: 9192
Flags: Receive-options, Receive-TTL-Exceeded

Logical interface dfc-0/0/0.16383 (Index 70) (SNMP ifIndex 44)
Flags: Point-To-Point SNMP-Traps Encapsulation: Dynamic-Flow-Capture
Input packets : 1427
Output packets: 98
Protocol inet, MTU: 9192
Flags: Receive-options, Receive-TTL-Exceeded
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.0.0.16, Local: 10.0.0.1

```

## show interfaces (Flow Collector)

<b>Syntax</b>	<pre>show interfaces <i>cp-fpc/pic/port:channel</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified flow collector interface.
<b>Options</b>	<p><b><i>cp-fpc/pic/port:channel</i></b>—Display standard status information about the specified flow collector interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Flow Collector) on page 886</a>
<b>Output Fields</b>	<a href="#">Table 143 on page 882</a> lists the output fields for the <b>show interfaces</b> (Flow Collector) command. Output fields are listed in the approximate order in which they appear.

Table 143: Flow Collector Show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical Interface</b>	Name of the physical interface type.	All levels
<b>Link</b>	Status of the link: <b>up</b> or <b>down</b> .	All levels
<b>Enabled</b>	State of the interface type. Possible values are described in the “Enabled Devices” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>

Table 143: Flow Collector Show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation type used on the physical interface.	All levels
<b>MTU</b>	Maximum Transmit Unit (MTU). Size of the largest packet to be transmitted.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link type</b>	Data transmission type.	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Physical info</b>	Information about the physical interface.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive none</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive none</b>
<b>Hardware address</b>	Media access control (MAC) address of the interface.	<b>detail extensive none</b>
<b>Alternate link address</b>	Backup link address.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li><b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li><b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 143: Flow Collector Show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed Discards</b>—Frames that the incoming packet match code discarded because the frames did not recognize them or were not of interest. Usually, this field reports protocols that Junos does not support.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b> —Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface; values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Traffic statistics</b>	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 143: Flow Collector Show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface (such as <b>iso</b> or <b>inet6</b> ).	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Route table in which this address exists; for example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

show interfaces  
extensive  
(Flow Collector)

```

user@host> show interfaces extensive cp-5/0/0
Physical interface: cp-5/0/0, Enabled, Physical link is Up
  Interface index: 145, SNMP ifIndex: 52, Generation: 29
  Type: Flow-collector, Link-level type: Flow-collection, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps 16384
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times    : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : 2005-05-24 16:48:11 PDT (00:12:04 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :          2041661287          0 bps
    Output bytes  :          3795049544      43816664 bps
    Input packets :           1365534          0 pps
    Output packets:           3865644      3670 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 2, Errors: 0, Drops: 0, MTU errors: 0,
    Resource errors: 0

Logical interface cp-5/0/0.0 (Index 74) (SNMP ifIndex 53) (Generation 28)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Flow-collection
  Traffic statistics:
    Input bytes   :          1064651568
    Output bytes  :           37144290
    Input packets :           711324
    Output packets:           713672
  Local statistics:
    Input bytes   :              0
    Output bytes  :              0
    Input packets :              0
    Output packets:              0
  Transit statistics:
    Input bytes   :          1064651568          0 bps
    Output bytes  :           37144290          0 bps
    Input packets :           711324          0 pps
    Output packets:           713672          0 pps
  Protocol inet, MTU: 9192, Generation: 39, Route table: 0
    Flags: Receive-options, Receive-TTL-Exceeded
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 4.0.0.2, Local: 4.0.0.1, Broadcast: Unspecified,
      Generation: 40

Logical interface cp-5/0/0.1 (Index 75) (SNMP ifIndex 54) (Generation 29)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Flow-collection
  Traffic statistics:
    Input bytes   :          976793823
    Output bytes  :          34099481
    Input packets :           652729
    Output packets:           655127
  Local statistics:

```



```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 976793823 0 bps
Output bytes : 34099481 0 bps
Input packets: 652729 0 pps
Output packets: 655127 0 pps
Protocol inet, MTU: 9192, Generation: 40, Route table: 0
Flags: Receive-options, Receive-TTL-Exceeded
Addresses, Flags: Is-Preferred Is-Primary
Destination: 4.1.1.2, Local: 4.1.1.1, Broadcast: Unspecified,
Generation: 42

Logical interface cp-5/0/0.2 (Index 80) (SNMP ifIndex 55) (Generation 30)
Flags: Point-To-Point SNMP-Traps Encapsulation: Flow-collection
Traffic statistics:
Input bytes : 0
Output bytes : 3723079376
Input packets: 0
Output packets: 2495372
Local statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 3723079376 43816664 bps
Input packets: 0 0 pps
Output packets: 2495372 3670 pps
Protocol inet, MTU: 9192, Generation: 41, Route table: 0
Flags: Receive-options, Receive-TTL-Exceeded
Addresses, Flags: Is-Preferred Is-Primary
Destination: 4.2.2.2, Local: 4.2.2.1, Broadcast: Unspecified,
Generation: 44

Logical interface cp-5/0/0.16383 (Index 81) (SNMP ifIndex 56) (Generation 31)
...

```

## show interfaces (Flow Monitoring)

<b>Syntax</b>	<pre>show interfaces mo-fpc/pic/port:channel &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified flow monitoring interface.
<b>Options</b>	<p><b>mo-fpc/pic/port:channel</b>—Display standard status information about the specified flow monitoring interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Flow Monitoring) on page 892</a>
<b>Output Fields</b>	<a href="#">Table 144 on page 888</a> lists the output fields for the <b>show interfaces</b> (Flow Monitoring) command. Output fields are listed in the approximate order in which they appear.

**Table 144: Flow Monitoring show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Link</b>	Status of the link: <b>up</b> or <b>down</b> .	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>

Table 144: Flow Monitoring show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Description</b>	Description and name of the interface.	All levels
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation type used on the physical interface.	All levels
<b>MTU</b>	Maximum Transmit Unit (MTU). Size of the largest packet to be transmitted.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link type</b>	Data transmission type.	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Physical info</b>	Information about the physical interface.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive none</b>
<b>Hardware address</b>	Media access control (MAC) address of the interface.	<b>detail extensive none</b>
<b>Alternate link address</b>	Backup link address.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b>	<b>detail extensive</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 144: Flow Monitoring show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed Discards</b>—Frames that the incoming packet match code discarded because the frames did not recognize them or were not of interest. Usually, this field reports protocols that Junos does not support.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC Red mechanism.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface; values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels

Table 144: Flow Monitoring show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface (such as <b>iso</b> or <b>inet6</b> ).	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Route table in which this address exists; for example, <b>Route table:0</b> refers to <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>

## Sample Output

**show interfaces**  
**extensive**  
**(Flow Monitoring)**

```

user@host> show interfaces mo-4/0/0 extensive
Physical interface: mo-4/0/0, Enabled, Physical link is Up
  Interface index: 144, SNMP ifIndex: 42, Generation: 28
  Description: monitor pic 2
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: Unlimited,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps 16384
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times    : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped  : 2005-05-24 16:43:12 PDT (00:17:46 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :           756824218           8328536 bps
    Output bytes  :           872916185           8400160 bps
    Input packets :           508452           697 pps
    Output packets:          15577196          18750 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 2, Errors: 0, Drops: 0, MTU errors: 0,
    Resource errors: 0

Logical interface mo-4/0/0.0 (Index 83) (SNMP ifIndex 43) (Generation 26)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
  Traffic statistics:
    Input bytes   :           756781796
    Output bytes  :           872255328
    Input packets :           507233
    Output packets:          15575988
  Local statistics:
    Input bytes   :           0
    Output bytes  :           0
    Input packets :           0
    Output packets:           0
  Transit statistics:
    Input bytes   :           756781796           8328536 bps
    Output bytes  :           872255328           8400160 bps
    Input packets :           507233           697 pps
    Output packets:          15575988          18750 pps
  Protocol inet, MTU: Unlimited, Generation: 38, Route table: 0
  Flags: None

Logical interface mo-4/0/0.16383 (Index 84) (SNMP ifIndex 58) (Generation 27)
...

```

# Link Services Interface Operational Mode Commands

Table 145 on page 893 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot link services, link services IQ, and multilink services interfaces.

**Table 145: Link Services Interface Operational Mode Commands**

Task	Command
Display status information about link services interfaces.	<a href="#">show interfaces (Link Services)</a>
Display status information about link services IQ interfaces.	<a href="#">show interfaces (Link Services IQ)</a>
Display status information about multilink services interfaces.	<a href="#">show interfaces (Multilink Services)</a>
Display status information about redundant link services IQ interfaces.	<a href="#">show interfaces (Redundant Link Services IQ)</a>

## show interfaces (Link Services)

**Syntax** For Multilink Frame Relay user-to-user network-to-network interface (UNI NNI):

```
show interfaces interface-type :channel
<brief | detail | extensive | terse>
<descriptions>
<media>
<snmp-index snmp-index>
<statistics>
```

For Multilink Frame Relay end-to-end:

```
show interfaces interface-type
<brief | detail | extensive | terse>
<descriptions>
<media>
<snmp-index snmp-index>
<statistics>
```

**Release Information** Command introduced before Junos OS Release 7.4.

**Description** Display status information about the specified link services interface.

**Options** *interface-type*—On M Series and T Series routers, the interface type is *ls-fpc/pic/port*. On J Series routers, the interface type is *ls-pim/O/port*.

**brief | detail | extensive | terse**—(Optional) Display the specified level of output.

**descriptions**—(Optional) Display interface description strings.

**media**—(Optional) Display media-specific information about network interfaces.

**snmp-index *snmp-index***—(Optional) Display information for the specified SNMP index of the interface.

**statistics**—(Optional) Display static interface statistics.

**Required Privilege Level** view

**List of Sample Output** [show interfaces extensive \(MFR UNI NNI\) on page 903](#)  
[show interfaces extensive \(MFR End-to-End\) on page 905](#)

**Output Fields** [Table 146 on page 894](#) lists the output fields for the **show interfaces** (link services) command. Output fields are listed in the approximate order in which they appear.

**Table 146: Link Services show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels



Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface: <b>Multilink-Frame-Relay-UNI-NNI</b> (default), <b>LinkService</b> , <b>Frame-relay</b> , <b>Frame-relay-ccc</b> , or <b>Frame-relay-tcc</b> .	All levels
<b>MTU</b>	Maximum transmission unit size on the physical interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Hold-times</b>	Current interface hold time up and hold time down, in milliseconds, in the format <b>Up <i>n</i> ms, Down <i>n</i> ms</b> .	<b>detail extensive</b>

Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Multilink Frame Relay UNI NNI bundle options	<p>Multilink Frame Relay UNI NNI only) Configured information about Multilink Frame Relay bundle options.</p> <ul style="list-style-type: none"> <li>• <b>Device type</b>—DCE (Data Communication Equipment) or DTE (Data Terminal Equipment).</li> <li>• <b>MRRU</b>—Configured size of the maximum received reconstructed unit (MRRU): 1500 to 4500 bytes. The default is 1524 bytes.</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold: 128 through 16,320 bytes, in integer multiples of 64 bytes. The default setting is 0, which disables fragmentation.</li> <li>• <b>Red differential delay limit</b>—Red differential delay limit among bundle links has been reached, indicating an action will occur.</li> <li>• <b>Yellow differential delay limit</b>—Yellow differential delay among bundle links has been reached, indicating a warning will occur.</li> <li>• <b>Red differential delay action</b>—Type of actions taken when the red differential delay exceeds the red limit: <b>Disable link transmit</b> or <b>Remove link from service</b>.</li> <li>• <b>Reassembly drop timer</b>—Drop timeout value to provide a recovery mechanism if individual links in the link services bundle drop one or more packets: 1 through 127 milliseconds. By default, the drop timeout parameter is 0 (disabled). A value that is under 5 ms is not recommended.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: 1 through 8.</li> <li>• <b>LIP Hello timer</b>—Link Interleaving Protocol hello timer: 1 through 180 seconds. <ul style="list-style-type: none"> <li>• <b>Acknowledgement timer</b>—Maximum period to wait for an add link acknowledgement, hello acknowledgement, or remove link acknowledgement: 1 through 10 seconds.</li> <li>• <b>Acknowledgement retries</b>—Number of retransmission attempts to be made for consecutive hello or remove link messages after the expiration of the acknowledgement timer: 1 through 5.</li> </ul> </li> </ul>	detail extensive none
Multilink Frame Relay UNI NNI bundle options (continued)	<ul style="list-style-type: none"> <li>• <b>Bundle class</b>—Bundle class ID.</li> <li>• <b>LMI type</b>—Multilink Frame Relay UNI NNI LMI type: <b>ANSI</b> or <b>Q.933 ANNEX A</b>. <ul style="list-style-type: none"> <li>• <b>T391 LIV polling timer</b>—Multilink Frame Relay UNI NNI Full status polling counter: 1 through 255, with a default value of 6.</li> <li>• <b>T392 polling verification timer</b>—Multilink Frame Relay UNI NNI LMI error threshold. The number of errors required to bring down the link, within the event count specified by <b>N393</b>. The range is 1 through 10, with a default value of 3.</li> <li>• <b>N391 full status polling count</b>—Multilink Frame Relay UNI NNI Full status polling counter: 1 through 255.</li> <li>• <b>N392 error threshold</b>—Multilink Frame Relay UNI NNI LMI error threshold: 1 through 10.</li> </ul> </li> <li>• <b>N393 monitored event count</b>—Multilink Frame Relay UNI NNI LMI monitored event count: 1 through 10, with a default value of 4.</li> </ul>	detail extensive none
Traffic statistics	<p>Number and rate of bytes and packets received and transmitted on the physical interface. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router.</p>	detail extensive

Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Multilink Frame Relay UNI NNI bundle errors	Information about Multilink Frame Relay bundle errors. <ul style="list-style-type: none"> <li>• <b>Packet drops</b>—Number of packets dropped.</li> <li>• <b>Fragment drops</b>—Number of fragments dropped.</li> <li>• <b>MRRU exceeded</b>—Number of times a packet was dropped because the configured MRRU value was exceeded.</li> <li>• <b>Exception events</b>—Exception events counter.</li> </ul>	detail extensive
Multilink Frame Relay UNI NNI bundle statistics	Information about Multilink Frame Relay bundles. <ul style="list-style-type: none"> <li>• <b>Fragments</b>—Bundle fragment information.               <ul style="list-style-type: none"> <li>• <b>Input</b>—Total number and rate of frames and packets received, in <b>Frames</b>, <b>fps</b> (frames per second), <b>Bytes</b>, and <b>bps</b> (bits per second).</li> <li>• <b>Output</b>—Total number and rate of frames and packets transmitted, in <b>Frames</b>, <b>fps</b>, <b>Bytes</b>, and <b>bps</b>.</li> </ul> </li> <li>• <b>Packets</b>—Bundle packet information.               <ul style="list-style-type: none"> <li>• <b>Input</b>—Total number and rate of frames and packets received, in <b>Frames</b>, <b>fps</b> (frames per second), <b>Bytes</b>, and <b>bps</b> (bits per second).</li> <li>• <b>Output</b>—Total number and rate of frames and packets transmitted, in <b>Frames</b>, <b>fps</b>, <b>Bytes</b>, and <b>bps</b>.</li> </ul> </li> </ul>	detail extensive
Multilink Frame Relay UNI NNI bundle links information	<ul style="list-style-type: none"> <li>• <b>Active bundle links</b>—Number of bundle links that are currently active.</li> <li>• <b>Removed bundle links</b>—Number of bundle links that have been removed (RED differential delay action).</li> <li>• <b>Disabled bundle links</b>—Number of bundle links that have been disabled (RED differential delay action).</li> </ul>	detail extensive none
Multilink Frame Relay UNI NNI active bundle links statistics	(Multilink Frame Relay UNI NNI only) Display information for each active bundle link. <ul style="list-style-type: none"> <li>• <b>Frames</b>—Number of multilink control frames received on this bundle link.</li> <li>• <b>fps</b>—Rate of multilink control frames received on this bundle link (in frames per second).</li> <li>• <b>Bytes</b>—Number of bytes received on this bundle link.</li> <li>• <b>bps</b>—Number of bits per second received on this bundle link.</li> <li>• <b>interface-name</b>—Name of the bundle link interface.</li> <li>• <b>Input</b>—Total number and rate of frames and packets received.</li> <li>• <b>Output</b>—Total number and rate of frames and packets transmitted.</li> <li>• <b>Current differential delay</b>—Compare this bundle link's round trip time to the average of all bundle links' round trip times in <b>ms</b> (milliseconds).</li> <li>• <b>Recent high differential delay</b>—Highest differential delay value from the latest 10 intervals, in milliseconds.</li> <li>• <b>Times over red diff delay</b>—Number of times this bundle link exceeded the configured red differential delay limit.</li> <li>• <b>Times over yellow diff delay</b>—Number of times this bundle link exceeded the configured yellow differential delay limit.</li> </ul>	detail extensive

Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Multilink Frame Relay UNI NNI active bundle links statistics (continued)	<ul style="list-style-type: none"> <li><b>LIP</b>—Link Interleaving Protocol information.</li> <li><b>Rcv</b>—Number of messages received.</li> <li><b>Xmt</b>—Number of messages transmitted.</li> <li><b>add_lnk</b>—ADD_LINK message notifies the peer endpoint that the local endpoint supports frame processing. It is generated on both ends of a bundle link when a bundle link endpoint is ready to become operational.</li> <li><b>lnk_ack</b>—ADD_LINK_ACK message notifies the peer that the local router has received a valid ADD_LINK message.</li> <li><b>lnk_rej</b>—ADD_LINK_REJ message notifies the peer that the local router has received an invalid ADD_LINK message.</li> <li><b>hello</b>—HELLO message notifies the peer that the local router is up. Both ends of a link bundle generate this message.</li> <li><b>hel_ack</b>—HELLO_ACK message notifies the peer that the local router has received a valid HELLO message.</li> <li><b>lnk_rem</b>—REMOVE_LINK message notifies the peer that the local router has received a REMOVE_LINK message.</li> <li><b>rem_ack</b>—REMOVE_LINK_ACK message notifies the peer that the local router has received a valid ADD_LINK message.</li> </ul>	detail extensive
Frame exceptions	<p>For Multilink Frame Relay end-to-end only. Information about framing exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface.</p> <ul style="list-style-type: none"> <li><b>Oversized frames</b>—Number of frames received that exceed maximum frame length. Maximum length is 4500 Kb (kilobits).</li> <li><b>Errored input frames</b>—Number of input frame errors.</li> <li><b>Input on disabled link/bundle</b>—Number of frames received on disabled links. These frames can result either from an inconsistent configuration, or from a bundle or link being brought up or down with traffic actively flowing through it.</li> <li><b>Output for disabled link/bundle</b>—Number of frames sent for a disabled or unavailable link. These frames can result either from an inconsistent configuration, or from a bundle being brought up or down while traffic is flowing through it.</li> <li><b>Queuing drops</b>—Total number of packets dropped before traffic enters the link services IQ interface. Indicates that the interface is becoming oversubscribed.</li> </ul>	detail extensive
Buffering exceptions	<p>For Multilink Frame Relay end-to-end only. Information about buffering exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface:</p> <ul style="list-style-type: none"> <li><b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical link services interface capacity.</li> <li><b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services interface capacity. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	detail extensive

Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Assembly exceptions</b>	<p>For Multilink Frame Relay end-to-end only. Information about assembly exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface.</p> <p>An assembly exception does not necessarily indicate an operational problem with the physical link services interface itself. If multilink-encapsulated traffic is dropped or reordered after a sequence number has been assigned, the assembling multilink interface records one or more exception events. The multilink interface can drop multilink-encapsulated fragments itself as a result. Any multilink packets or fragments dropped by the physical link services interface itself result in packet or fragment drop counts on individual logical interfaces. If the logical interface drop counts are zero, but exception events are seen, the most likely cause is a problem with the individual link interfaces. Even if the logical interface fragment drop counts are nonzero, excess differential delay or traffic losses on individual interfaces can be the root cause.</p>	<b>detail extensive</b>
<b>Assembly exceptions (continued)</b>	<ul style="list-style-type: none"> <li>• <b>Fragment timeout</b>—The drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled. These events do not necessarily indicate any problem with the operation of the physical link services interface itself, but can occur when one or more individual links drop traffic. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle. These events do not necessarily indicate any problem with the operation of the physical link services interface itself, but can occur when one or more individual links drop traffic. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers occurred within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-range sequence number</b>—Frame was received with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	<b>detail extensive</b>
<b>Hardware errors</b>	<p>For Multilink Frame Relay end-to-end only. Information about hardware errors:</p> <ul style="list-style-type: none"> <li>• <b>Data memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> <li>• <b>Control memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> </ul>	<b>detail extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels

Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Encapsulation</b>	Encapsulation being used: PPP, Multilink - FR or Multilink - PPP	All levels
<b>Bandwidth</b>	Speed at which the interface is running.	All levels
<b>Bundle options</b>	For Multilink Frame Relay end-to-end interfaces only: <ul style="list-style-type: none"> <li>• <b>MRRU</b>—Configured size of the maximum received reconstructed unit (MRRU): 1500 to 4500 bytes. The default is 1524 bytes.</li> <li>• <b>Drop timer period</b>—Drop timeout value to provide a recovery mechanism if individual links in link services bundle drop one or more packets: 1 through 127 milliseconds. Values under 5 milliseconds are not recommended. The default setting is 0, which disables the timer.</li> <li>• <b>Sequence number format</b>—(MLPPP) Short sequence number header format.</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold: 128 through 16,320 bytes, in integer multiples of 64 bytes. The default setting is 0, which disables fragmentation.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: 1 through 8.</li> <li>• <b>Interleave fragments</b>—State of the process that interleaves long packets with high-priority ones. Only <b>Disabled</b> is currently supported.</li> <li>• <b>Remote MRRU</b>—MRRU value received from remote peer. If negotiation has not been initiated, the default value is displayed.</li> </ul>	<b>detail extensive none</b>
<b>Bundle status (MLPPP) or Multilink class status (MC-MLPPP)</b>	Information about bundle status: <ul style="list-style-type: none"> <li>• <b>Remote MRRU</b>—MRRU value received from remote peer. If negotiation has not been initiated, the default value is displayed.</li> <li>• <b>Received sequence number</b>—Sequence number for received packets.</li> <li>• <b>Transmit sequence number</b>—Sequence number for transmitted packets.</li> <li>• <b>Packet drops</b>—Number and byte count of output packets that were dropped, rather than being encapsulated and sent out of the router as fragments. The packet drop counter is incremented if there is a temporary shortage of packet memory on the AS PIC, which causes packet fragmentation to fail.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments that were dropped, rather than being reassembled and handled by the router as packets. This counter also includes fragments that have been received successfully but had to be dropped because not all fragments that constituted a packet had been received. The fragment drop counter is incremented when a fragment received on constituent links is dropped. Drop fragments can be triggered by sequence ordering errors, duplicate fragments, timed-out fragments, and bad multilink headers.</li> </ul>	<b>detail extensive none</b>

Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle status (MLPPP) or Multilink class status (MC-MLPPP) (continued)</b>	<ul style="list-style-type: none"> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU. This counter is not implemented in this release.</li> <li>• <b>Fragment timeout</b>—Drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled.</li> <li>• <b>Missing sequence number</b>—Gap detected in the sequence numbers of fragments on a bundle.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream.</li> <li>• <b>Out-of-range sequence number</b>—Frame with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up.</li> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity.</li> </ul>	<b>detail extensive none</b>
<b>Bundle errors</b>	<p>Information about bundle errors.</p> <ul style="list-style-type: none"> <li>• <b>Packet drops</b>—Number and byte count of output packets that were dropped, rather than being encapsulated and sent out of the router as fragments.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments that were dropped, rather than being reassembled and handled by the router as packets.</li> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU.</li> <li>• <b>Exception events</b>—Number of exceptional events encountered other than MRRU exceeded errors. These events are categorized under the physical interface: <b>Frame exceptions</b>, <b>Buffering exceptions</b>, and <b>Fragment exceptions</b>. Exception events do not necessarily indicate that the multilink interface is not operating properly. Individual link failures can produce exceptional events.</li> </ul>	<b>detail extensive</b>
<b>Statistics</b>	<p>Information about fragments and packets received and sent by the router. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router.</p> <ul style="list-style-type: none"> <li>• <b>Bundle</b>—Information about bundles.</li> <li>• <b>Link</b>—Information about links used in the multilink operation.</li> </ul>	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface. If the MTU value is negotiated down to meet the MRRU requirement on the remote side, this value is marked <b>Adjusted</b> .	<b>detail extensive none</b>

Table 146: Link Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which this address exists. For example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>



## Sample Output

show interfaces  
extensive (MFR UNI  
NNI)

```
user@host> show interfaces ls-1/3/0:0 extensive
Physical interface: ls-1/3/0:0, Enabled, Physical link is Up
Interface index: 25, SNMP ifIndex: 35, Generation: 124
Link-level type: Multilink-FR-UNI-NNI, MTU: 1524
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps
Last flapped   : 2002-11-01 15:26:25 PST (00:34:49 ago)
Statistics last cleared: Never
Link flags     : None
Hold-times     : Up 0 ms, Down 0 ms
Multilink Frame Relay UNI NNI bundle options:
  Device type           DTE
  MRRU                  1524
  Fragmentation threshold 1500
  Red differential delay limit 10
  Yellow differential delay limit 6
  Red differential delay action Disable link transmit
  Reassembly drop timer 0
  Links needed to sustain bundle 1
  LIP Hello timer       10
    Acknowledgement timer 4
    Acknowledgement retries 2
  Bundle class          A
  LMI type              Q.933 Annex A
    T391 LIV polling timer 10
    T392 polling verification timer 15
    N391 full status polling count 6
    N392 error threshold 3
    N393 monitored event count 4
Traffic statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Multilink Frame Relay UNI NNI bundle errors:
  Packet drops 0 (0 bytes)
  Fragment drops 0 (0 bytes)
  MRRU exceeded 0
  Exception events 0
Multilink Frame Relay UNI NNI bundle statistics
      Frames      fps      Bytes      bps
Fragments:
  Input : 0 0 0 0
  Output: 824 0 17304 320
Packets:
  Input : 0 0 0 0
  Output: 824 0 17304 320
Multilink Frame Relay UNI NNI bundle links info:
  Active bundle links 4
  Removed bundle links 0
  Disabled bundle links 0
Multilink Frame Relay UNI NNI active bundle links statistics:
      Frames      fps      Bytes      bps
t1-0/2/0:0.0
  Input : 0 0 0 0
  Output: 206 0 4326 80
  Current differential delay 0.2 ms
  Recent high differential delay 3.8 ms
```

```

Times over red diff delay      0
Times over yellow diff delay   0
LIP:add_lnk lnk_ack lnk_rej    hello hel_ack lnk_rem rem_ack
Rcv:      2      2      0      206      207      0      0
Xmt:      2      1      0      207      206      0      0
t1-0/2/0:1.0
Input :      0      0      0      0
Output:      206      0      4326      80
Current differential delay      0.2 ms
Recent high differential delay  3.7 ms
Times over red diff delay      0
Times over yellow diff delay    0
LIP:add_lnk lnk_ack lnk_rej    hello hel_ack lnk_rem rem_ack
Rcv:      2      2      0      206      207      0      0
Xmt:      2      1      0      207      206      0      0
t1-0/2/0:2.0
Input :      0      0      0      0
Output:      206      0      4326      80
Current differential delay      0.4 ms
Recent high differential delay  3.8 ms
Times over red diff delay      0
Times over yellow diff delay    0
LIP:add_lnk lnk_ack lnk_rej    hello hel_ack lnk_rem rem_ack
Rcv:      2      2      0      206      207      0      0
Xmt:      2      1      0      207      206      0      0
t1-0/2/0:3.0
Input :      0      0      0      0
Output:      206      0      4326      80
Current differential delay      0.3 ms
Recent high differential delay  3.8 ms
Times over red diff delay      0
Times over yellow diff delay    0
LIP:add_lnk lnk_ack lnk_rej    hello hel_ack lnk_rem rem_ack
Rcv:      2      2      0      206      207      0      0
Xmt:      2      1      0      207      206      0      0
Logical interface ls-1/3/0:0.0 (Index 5) (SNMP ifIndex 28) (Generation 10)
Flags: Point-To-Point SNMP-Traps Encapsulation: Multilink-FR-UNI-NNI
Bandwidth: 622080kbps
Bundle errors:
  Packet drops      0 (0 bytes)
  Fragment drops    0 (0 bytes)
  MRRU exceeded     0
  Exception events   0
Statistics          Frames      fps      Bytes      bps
Bundle:
  Fragments:
    Input :          0          0          0          0
    Output:         824          0      17304      320
  Packets:
    Input :          0          0          0          0
    Output:         824          0      17304      320
Link:
  t1-0/2/0:0.0
    Input :          0          0          0          0
    Output:         206          0      4326      80
  t1-0/2/0:1.0
    Input :          0          0          0          0
    Output:         206          0      4326      80
  t1-0/2/0:2.0
    Input :          0          0          0          0

```

```

      Output:          206          0          4326          80
t1-0/2/0:3.0
      Input :           0           0           0           0
      Output:          206          0          4326          80
Protocol inet, MTU: 1500 [Adjusted], Generation: 15, Route table: 0
Flags: User-MTU, MTU-Protocol-Adjusted
Addresses, Flags: Is-Preferred Is-Primary
Destination: 1.1.1.1, Local: 1.1.1.2, Broadcast: Unspecified,
Generation: 10

```

**show interfaces  
extensive (MFR  
End-to-End)**

```

user@host> show interfaces ls-0/3/0 extensive
Physical interface: ls-0/3/0, Enabled, Physical link is Up
Interface index: 264, SNMP ifIndex: 104, Generation: 525
Link-level type: LinkService, MTU: 1524
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps
Last flapped : 2002-10-16 17:53:49 PDT (00:22:00 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes :          73471          264 bps
Output bytes :          80335           0 bps
Input packets:           822           0 pps
Output packets:          819           0 pps
Frame exceptions:
Oversized frames          0
Errored input frames      0
Input on disabled link/bundle 0
Output for disabled link/bundle 4
Queuing drops             3
Buffering exceptions:
Packet data buffer overflow 0
Fragment data buffer overflow 0
Assembly exceptions:
Fragment timeout          0
Missing sequence number   0
Out-of-order sequence number 0
Out-of-range sequence number 0
Hardware errors (sticky):
Data memory error         0
Control memory error      0
Logical interface ls-0/3/0.0 (Index 5) (SNMP ifIndex 527) (Generation 47)
Flags: Point-To-Point SNMP-Traps Encapsulation: Multilink-PPP
Bandwidth: 1536kbps
Bundle options:
MRRU                      1524
Drop timer period         0
Sequence number format    long (24 bits)
Fragmentation threshold   0
Links needed to sustain bundle 1
Interleave fragments      Disabled
Bundle status:
Remote MRRU               1500
Received sequence number  0x19ec14
Transmit sequence number  0x38cfa8
Packet drops              0 (0 bytes)
Fragment drops            0 (0 bytes)
MRRU exceeded             0
Fragment timeout          0
Missing sequence number   0
Out-of-order sequence number 0
Out-of-range sequence number 0

```

```

    Packet data buffer overflow      0
    Fragment data buffer overflow    0
Bundle errors:
    Packet drops                    2 (68 bytes)
    Fragment drops                  0 (0 bytes)
    MRRU exceeded                   0
    Exception events                 0
Statistics      Frames      fps      Bytes      bps
Bundle:
  Fragments:
    Input :      172        0      15544      288
    Output:      165        0      16645        0
  Packets:
    Input :      143        0      12885      288
    Output:      134        0      12276        0
Link:
  t1-0/0/0.0
    Input :      143        0      12885      288
    Output:      134        0      12276        0
Protocol inet, MTU: 1500, Generation: 76, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.16.1.2, Local: 10.16.1.1, Broadcast:
    Unspecified, Generation: 81
Protocol iso, MTU: 1500 [Adjusted], Generation: 77, Route table: 0
  Flags: Is-Primary
Protocol inet6, MTU: 1500, Generation: 78, Route table: 0
  Flags: Is-Primary
  Addresses, Flags: Is-Default Is-Preferred Is-Primary
    Destination: 8016::1:0/126, Local: 8016::1:1,
    Broadcast: Unspecified, Generation: 83
  Addresses, Flags: Is-Preferred
    Destination: fe80::/64, Local: fe80::2a0:a5ff:fe12:4777,
    Broadcast: Unspecified,
    Generation: 85

```

## show interfaces (Link Services IQ)

<b>Syntax</b>	<pre>show interfaces lsq-fpc/pic/port &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;l2-statistics&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	<p>Command introduced before Junos OS Release 7.4.</p> <p><b>l2-statistics</b> option introduced with Junos OS Release 12.1.</p>
<b>Description</b>	(J Series, M Series, MX Series, and T Series routers only) Display status information about the specified link services intelligent queuing (IQ) interface.
<b>Options</b>	<p><b>lsq-fpc/pic/port</b>—Display standard status information about the specified link services IQ interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>l2-statistics</b>—(Optional) Display Layer 2 queue statistics for Multilink Point-to-Point Protocol (MLPPP), FRF.15, and FRF.16 bundles.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Additional Information</b>	Link services IQ interfaces are similar to link services interfaces. The important difference is that link services IQ interfaces fully support Junos OS class-of-service (CoS) components.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces extensive (MLPPP on Link Services IQ) on page 922</a></p> <p><a href="#">show interfaces extensive (Multiclass MLPPP on Link Services IQ) on page 923</a></p> <p><a href="#">show interfaces extensive (MLPPP on Link Services IQ Bundle) on page 925</a></p> <p><a href="#">show interfaces extensive (MFR on Link Services IQ Bundle) on page 927</a></p> <p><a href="#">show interfaces (Multiclass MLPPP on Link Services IQ) on page 929</a></p>
<b>Output Fields</b>	<a href="#">Table 147 on page 908</a> lists the output fields for the <b>show interfaces</b> (link services IQ) command. Output fields are listed in the approximate order in which they appear.

Table 147: show interfaces (Link Services IQ) Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface: <b>Multilink-Frame-Relay-UNI-NNI</b> (default), <b>LinkService</b> , <b>Frame-relay</b> , <b>Frame-relay-ccc</b> , or <b>Frame-relay-tcc</b> .	All levels
<b>MTU</b>	Maximum transmission unit size on the physical interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Multilink Frame Relay UNI NNI bundle options</b>	<p>Multilink Frame Relay UNI NNI only) Configured information about Multilink Frame Relay bundle options.</p> <ul style="list-style-type: none"> <li>• <b>Device type</b>—DCE (data communication equipment) or DTE (data terminal equipment).</li> <li>• <b>MRRU</b>—Configured size of the maximum received reconstructed unit (MRRU): 1500 to 4500 bytes. The default is 1524 bytes.</li> <li>• <b>Bandwidth</b>—Speed at which the interface is running.</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold: 128 through 16,320 bytes, in integer multiples of 64 bytes. The default setting is 0, which disables fragmentation.</li> <li>• <b>Red differential delay limit</b>—Red differential delay limit among bundle links has been reached, indicating an action will occur.</li> <li>• <b>Yellow differential delay limit</b>—Yellow differential delay among bundle links has been reached, indicating a warning will occur.</li> <li>• <b>Red differential delay action</b>—Type of actions taken when the red differential delay exceeds the red limit: <b>Disable link transmit</b> or <b>Remove link from service</b>.</li> <li>• <b>Link layer overhead</b>—Percentage of bundle bandwidth to be set aside for link layer overhead.</li> <li>• <b>Reassembly drop timer</b>—Drop timeout value to provide a recovery mechanism if individual links in the link services bundle drop one or more packets: 1 through 127 milliseconds. By default, the drop timeout parameter is 0 (disabled). A value under 5 ms is not recommended.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: 1 through 8.</li> <li>• <b>LIP Hello timer</b>—Link Interleaving Protocol hello timer: 1 through 180 seconds. <ul style="list-style-type: none"> <li>• <b>Acknowledgement timer</b>—Maximum period to wait for an add link acknowledgement, hello acknowledgement, or remove link acknowledgement: 1 through 10 seconds.</li> <li>• <b>Acknowledgement retries</b>—Number of retransmission attempts to be made for consecutive hello or remove link messages after the expiration of the acknowledgement timer: 1 through 5.</li> </ul> </li> </ul>	<b>detail extensive none</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
Multilink Frame Relay UNI NNI bundle options (continued)	<ul style="list-style-type: none"> <li>• <b>Bundle class</b>—Bundle class ID.</li> <li>• <b>LMI type</b>—Multilink Frame Relay UNI NNI LMI type: <b>ANSI</b>, <b>Q.933 ANNEX A</b>, or <b>Consortium</b>. <ul style="list-style-type: none"> <li>• <b>T391 LIV polling timer</b>—Multilink Frame Relay UNI NNI Full status polling counter: 1 through <b>255</b>, with a default value of <b>6</b>.</li> <li>• <b>T392 polling verification timer</b>—Multilink Frame Relay UNI NNI LMI error threshold. The number of errors required to bring down the link, within the event count specified by <b>N393</b>. The range is 1 through <b>10</b>, with a default value of <b>3</b>.</li> <li>• <b>N391 full status polling count</b>—Multilink Frame Relay UNI NNI Full status polling counter: 1 through <b>255</b>.</li> <li>• <b>N392 error threshold</b>—Multilink Frame Relay UNI NNI LMI error threshold: 1 through <b>10</b>.</li> </ul> </li> <li>• <b>N393 monitored event count</b>—Multilink Frame Relay UNI NNI LMI monitored event count: 1 through <b>10</b>, with a default value of <b>4</b>.</li> <li>• <b>Consortium LMI Settings</b> <ul style="list-style-type: none"> <li>• <b>n391dte</b>—DTE full status polling interval in seconds: 1 through <b>255</b>.</li> <li>• <b>n392dce</b>—DCE error threshold: 1 through <b>10</b>.</li> <li>• <b>n392dte</b>—DTE error threshold: 1 through <b>10</b>.</li> <li>• <b>n393dce</b>—DCE monitored event count: 1 through <b>10</b>.</li> <li>• <b>n393dte</b>—DTE monitored event count: 1 through <b>10</b>.</li> <li>• <b>t391dte</b>—DTE polling verification timer (in seconds): <b>5</b> through <b>30</b>.</li> <li>• <b>t392dce</b>—DCE polling verification timer (in seconds): <b>5</b> through <b>30</b>.</li> </ul> </li> </ul>	detail extensive none
LMI	<p>Local Managment Interface packet statistics:</p> <ul style="list-style-type: none"> <li>• <b>Input</b>—Number of packets arriving on the interface (nn) and timestamp of the most recent packet arrival, in the format: <b>Input: nn (last seen hh:mm:ss ago)</b></li> <li>• <b>Output</b>—Number of packets sent out on the interface (nn) and how much time has passed since the last packet was sent, in the format: <b>Output: nn (last seen hh:mm:ss ago)</b></li> </ul>	detail extensive none
DTE Statistics	<p>Statistics about information transferred from the data terminal equipment (DTE) to the data communications equipment (DCE).</p> <ul style="list-style-type: none"> <li>• <b>Enquiries sent</b>—Number of link status enquiries sent from the DTE to the DCE.</li> <li>• <b>Full enquiries sent</b>—Number of full enquiries sent from the DTE to the DCE.</li> <li>• <b>Enquiry responses received</b>—Number of enquiry responses received by the DCE from the DTE.</li> <li>• <b>Full enquiry responses received</b>—Number of full enquiry responses received by DCE from the DTE.</li> </ul>	detail extensive none



Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>DCE Statistics</b>	<p>Statistics about information transferred from the DCE to the DTE.</p> <ul style="list-style-type: none"> <li>• <b>Enquiries received</b>—Number of enquiries received by the DCE from the DTE.</li> <li>• <b>Full enquiries received</b>—Number of full enquiries received by the DCE from the DTE.</li> <li>• <b>Enquiry responses sent</b>—Number of enquiry responses sent from the DCE to the DTE.</li> <li>• <b>Full enquiry responses sent</b>—Number of full enquiry responses sent from the DCE to the DTE.</li> </ul>	<b>detail extensive none</b>
<b>Common Statistics</b>	<p>Statistics about messages snet between the DTE and the DCE.</p> <ul style="list-style-type: none"> <li>• <b>Unknown messages received</b>—Number of received packets that do not fall into any other category.</li> <li>• <b>Asynchronouts updates received</b>—Number of link status peer changes received.</li> <li>• <b>Out-of-sequence packets received</b>—Number of packets for which the sequence of the packets received is different from the expected sequence.</li> <li>• <b>Keepalive responses timed out</b>—Number of keepalive responses that time out when no Local Management Interface (LMI) packet was reported for <b>n392dte</b> or <b>n393dce</b> intervals. (See <b>LMI settings</b>.)</li> </ul>	
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface. All references to traffic direction (input or output) are defined with respect to the Packet Forwarding Engine (PFE). Input traffic refers to the fragments received by the ingress PFE, which get assembled into Layer 3 input packets. Output packets refer to the IP packets transmitted out of the ingress PFE to the LSQ, which get segmented into output fragments.</p>	<b>detail extensive</b>
<b>DLCInn</b>	<p>Data-link connection identifier (DLCI) number of the logical interview. The following information is displayed.</p> <ul style="list-style-type: none"> <li>• <b>Flags</b>—Values are: <ul style="list-style-type: none"> <li>• <b>Active</b>—Set when the link is active and the DTE and DCE are exchanging information.</li> <li>• <b>Down</b>—Set when the link is active, but no information is received from the DTE.</li> <li>• <b>DCE unconfigured</b>—Set when the corresponding DLCI in the DCE is not configured.</li> <li>• <b>Configured</b>—Set when the correspondening DLCCI is configured.</li> <li>• <b>DCE-Configured</b>—Displayed when the command is issued from the DTE.</li> </ul> </li> </ul>	
<b>DLCI Statistics</b>	<p>(Frame Relay) Data-link connection identifier (DLCI) statistics.</p> <ul style="list-style-type: none"> <li>• <b>Active DLCI</b>—Number of active DLCIs.</li> <li>• <b>Inactive DLCI</b>—Number of inactive DLCIs.</li> </ul>	
<b>Input rate</b>	(Redundant LSQ) Rate of bits and packets received on the interface.	None specified
<b>Output rate</b>	(Redundant LSQ) Rate of bits and packets transmitted on the interface.	None specified

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router.	<b>detail extensive</b>
<b>Frame exceptions</b>	<p>Information about framing exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface.</p> <ul style="list-style-type: none"> <li>• <b>Oversized frames</b>—Number of frames received that exceed maximum frame length. Maximum length is 4500 Kb (kilobits).</li> <li>• <b>Errored input frames</b>—Number of input frame errors.</li> <li>• <b>Input on disabled link/bundle</b>—Number of frames received on disabled links. These frames can result either from an inconsistent configuration, or from a bundle or link being brought up or down with traffic actively flowing through it.</li> <li>• <b>Output for disabled link/bundle</b>—Number of frames sent for a disabled or unavailable link. These frames can result either from an inconsistent configuration, or from a bundle being brought up or down while traffic is flowing through it.</li> <li>• <b>Queuing drops</b>—Total number of packets dropped before traffic enters the link services IQ interface. Indicates that the interface is becoming oversubscribed.</li> </ul>	<b>extensive</b>
<b>Buffering exceptions</b>	<p>Information about buffering exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface:</p> <ul style="list-style-type: none"> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	<b>extensive</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Assembly exceptions</b>	<p>(Multilink Frame Relay end-to-end only) Information about assembly exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface.</p> <p>An assembly exception does not necessarily indicate an operational problem with the physical link services IQ interface itself. If multilink-encapsulated traffic is dropped or reordered after a sequence number has been assigned, the interface records one or more exception events. The physical interface can drop multilink-encapsulated fragments itself as a result. Any multilink packets or fragments dropped by the interface itself result in packet or fragment drop counts on individual logical interfaces. If the logical interface drop counts are zero, but exception events are seen, the most likely cause is a problem with the individual link interfaces. Even if the logical interface fragment drop counts are nonzero, excess differential delay or traffic losses on individual interfaces can be the root cause.</p> <ul style="list-style-type: none"> <li>• <b>Fragment timeout</b>—The drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled. These events do not necessarily indicate any problem with the operation of the physical link services IQ interface itself, but can occur when one or more individual links drop traffic. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle. These events do not necessarily indicate any problem with the operation of the physical link services IQ interface itself, but can occur when one or more individual links drop traffic. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers within a single link. This event indicates that an individual link within a bundle reordered traffic, making the link services IQ interface unable to correctly process the resulting stream. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-range sequence number</b>—Received a frame with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	<b>extensive</b>
<b>Hardware errors (sticky)</b>	<p>(Multilink Frame Relay end-to-end only) Information about hardware errors:</p> <ul style="list-style-type: none"> <li>• <b>Data memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> <li>• <b>Control memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive none</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Queue counters</b>	Queue number and its associated user-configured forwarding class name. <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive none</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation being used: PPP or Multilink PPP.	All levels
<b>Bandwidth</b>	Speed at which the interface is running.	All levels
<b>Bundle options</b>	(Multilink Frame Relay end-to-end interfaces only) <ul style="list-style-type: none"> <li>• <b>MRRU</b>—Configured size of the maximum received reconstructed unit (MRRU): 1500 through 4500 bytes. The default is 1504 bytes.</li> <li>• <b>Drop timer period</b>—Drop timeout value to provide a recovery mechanism if individual links in link services bundle drop one or more packets: 0 through 2000 milliseconds. Values under 5 ms are not recommended. The default setting is 0, which disables the timer.</li> <li>• <b>Sequence number format</b>—Short sequence number header format (MLPPP only).</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold: 64 through 16,320 bytes, in integer multiples of 64 bytes. The default setting is 0, which disables fragmentation.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: 1 through 8.</li> <li>• <b>Multilink classes</b>—Number of multilink classes negotiated.</li> <li>• <b>Link layer overhead</b>—Percentage of bundle bandwidth to be set aside for link-layer overhead.</li> </ul>	<b>detail extensive none</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle status</b> (MLPPP) or <b>Multilink class status</b> (Multiclass MLPPP)	<p>Information about bundle status:</p> <ul style="list-style-type: none"> <li>• <b>Remote MRRU</b>—MRRU value received from remote peer. If negotiation has not been initiated, the default value is displayed.</li> <li>• <b>Received sequence number</b>—Sequence number for received packets.</li> <li>• <b>Transmitted sequence number</b>—Sequence number for transmitted packets.</li> <li>• <b>Packet drops</b>—Number and byte count of output packets that were dropped, rather than being encapsulated and sent out of the router as fragments. The packet drop counter is incremented if there is a temporary shortage of packet memory on the AS PIC, which causes packet fragmentation to fail.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments that were dropped, rather than being reassembled and handled by the router as packets. This counter also includes fragments that have been received successfully, but had to be dropped because not all fragments that constituted a packet had been received. The fragment drop counter is incremented when a fragment received on constituent links is dropped. Drop fragments can be triggered by sequence ordering errors, duplicate fragments, timed-out fragments, and bad multilink headers.</li> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU. This counter is not implemented in this release.</li> <li>• <b>Fragment timeout</b>—The drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream.</li> <li>• <b>Out-of-range sequence number</b>—Received a frame with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up.</li> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity.</li> </ul>	<b>detail extensive none</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Statistics</b>	<p>Information about fragments and packets received and sent by the router. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router. Each field has columns that indicate the number of frames received and transmitted, frames per second (fps), the number of bytes received and transmitted, and bits per second (bps).</p> <ul style="list-style-type: none"> <li>• <b>Bundle</b>—Information for each active bundle link. <ul style="list-style-type: none"> <li>• <b>Fragments: Input and Output</b>—Total number and rate of fragments received and transmitted.</li> <li>• <b>Packets: Input and Output</b>—Total number and rate of packets received and transmitted.</li> <li>• <b>Multilink class</b>—(Multiclass MLPPP only) Information about multiclass links used in the multilink operation.</li> </ul> </li> <li>• <b>Link</b>—Information about links used in the multilink operation. <ul style="list-style-type: none"> <li>• <b>Link name</b>—Interface name of the link services IQ channel and state information (physical link <b>up</b> or <b>down</b>).</li> <li>• <b>Input and Output</b>—Total number and rate of fragments and packets received and transmitted.</li> </ul> </li> </ul>	<b>detail extensive</b>
<b>NCP state</b>	<p>(PPP) Network Control Protocol state.</p> <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface. If the MTU value is negotiated down to meet the MRRU requirement on the remote side, this value is marked <b>Adjusted</b> .	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which this address exists. For example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the addresses configured on the logical interface. Possible values are described in the “Addresses Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>MLPPP Bundle Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>SNMP-Traps</b>	SNMP trap notifications are enabled.	All levels
<b>Encapsulation</b>	Encapsulation being used: PPP, Multilink PPP, or Multilink-FR.	All levels
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Bandwidth</b>	Speed at which the interface is running.	All levels
<b>Bundle links information</b>	Information about the bundled links. <ul style="list-style-type: none"> <li>• <b>Active bundle links</b>—Number of active links.</li> <li>• <b>Removed bundle links</b>—Information about links used in the multilink operation.</li> <li>• <b>Disabled bundle links</b>—Number of disabled links.</li> </ul>	<b>detail extensive none</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle options</b>	<p>(Multilink Frame Relay end-to-end interfaces only)</p> <ul style="list-style-type: none"> <li>• <b>MRRU</b>—Configured size of the maximum received reconstructed unit (MRRU): <b>1500</b> through <b>4500</b> bytes. The default is <b>1504</b> bytes.</li> <li>• <b>Drop timer period</b>—Drop timeout value to provide a recovery mechanism if individual links in link services bundle drop one or more packets: <b>0</b> through <b>2000</b> milliseconds. Values under 5 ms are not recommended. The default setting is <b>0</b>, which disables the timer.</li> <li>• <b>Inner PPP Protocol field compression</b>—Inner PPP protocol compression is enabled or disabled.</li> <li>• <b>Sequence number format</b>—Short sequence number header format (MLPPP only).</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold: <b>64</b> through <b>16,320</b> bytes, in integer multiples of <b>64</b> bytes. The default setting is <b>0</b>, which disables fragmentation.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: 1 through <b>8</b>.</li> <li>• <b>Multilink classes</b>—Number of multilink classes negotiated.</li> <li>• <b>Link layer overhead</b>—Percentage of bundle bandwidth to be set aside for link-layer overhead.</li> </ul>	<b>detail extensive none</b>



Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle status</b> (MLPPP)	<p>Information about bundle status:</p> <ul style="list-style-type: none"> <li>• <b>Received sequence number</b>—Sequence number for received packets.</li> <li>• <b>Transmit sequence number</b>—Sequence number for transmitted packets.</li> <li>• <b>Packet drops</b>—Number and byte count of output packets that were dropped, rather than being encapsulated and sent out of the router as fragments. The packet drop counter is incremented if there is a temporary shortage of packet memory on the AS PIC, which causes packet fragmentation to fail.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments that were dropped, rather than being reassembled and handled by the router as packets. This counter also includes fragments that have been received successfully but had to be dropped because not all fragments that constituted a packet had been received. The fragment drop counter is incremented when a fragment received on constituent links is dropped. Drop fragments can be triggered by sequence ordering errors, duplicate fragments, timed-out fragments, and bad multilink headers.</li> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU. This counter is not implemented in this release.</li> <li>• <b>Fragment timeout</b>—The drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers occurred within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream.</li> <li>• <b>Out-of-range sequence number</b>—A frame was received with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up.</li> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity.</li> </ul>	detail extensive none

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Statistics</b>	<p>Information about frames, bytes, and bits per second received and sent by the router. All references to traffic direction (input or output) are defined with respect to the router. Each field has columns that indicate the number of frames received and transmitted, frames per second (fps), the number of bytes received and transmitted, and bits per second (bps).</p> <p>The bundle, multilink, and network statistics are reported by the Packet Forwarding Engine (PFE). The Multi Link Detail statistics like fragments, non-fragments and LFI are reported by the PIC.</p> <p>However, the PFE reports an extra overhead of 2 bytes in the output when compared with the Multilink Detail Statistics. This is due to the service-cookie in the PFE which does the link demux for the ML header.</p> <p>The difference in the bytes received and transmitted from Network and Multilink interfaces and Multilink statistics for each member link is divided between the ML and the PPP headers. For example the header counter for a long sequence configuration would be as follows.</p> <ul style="list-style-type: none"> <li>• Input side - Total overhead = 6 bytes. <ul style="list-style-type: none"> <li>• ML: 4 bytes of ML header = 1 byte of Flag + 3 bytes of long sequence number.</li> <li>• PPP: 2 bytes of protocol field.</li> </ul> </li> <li>• Output side - Total overhead = 11 bytes. <ul style="list-style-type: none"> <li>• ML: 4 bytes of ML Header = 1 byte of Flag + 3 bytes of Long sequence number.</li> <li>• PPP: 5 bytes = 4 bytes of header + 1 byte of Idle flag.</li> <li>• 2 bytes of Service Cookie.</li> </ul> </li> <li>• <b>Bundle</b>—Information for each active bundle link. <ul style="list-style-type: none"> <li>• <b>Multilink: Input and Output</b>—Total number and rate of multilink frames, bytes, and bits per second received and transmitted. It is a module connecting LSQ PIC and its member link. Multilink Input displays L2 fragments received from the member link to the LSQ PIC. Multilink Output displays the L2 fragments transmitted from LSQ PIC to the member links.</li> <li>• <b>Network: Input and Output</b>—Total number of network frames, bytes, and bits per second received and transmitted. It refers to the packets transmitted from an ingress interface to the PFE and then to the LSQ PIC. Network Input displays the L3 packets received from the LSQ PIC to the PFE. Network Output displays the L3 packets transmitted from PFE to LSQ PIC.</li> </ul> </li> <li>• <b>Link</b>—Information about links used in the multilink operation. <ul style="list-style-type: none"> <li>• <b>Link name</b>—The interface name of the link services IQ channel and state information (physical link <b>up</b> or <b>down</b>) and up time.</li> <li>• <b>Input and Output</b>—Total number and rate of frames, bytes, and bits per second received and transmitted.</li> </ul> </li> </ul>	<b>extensive</b>

Table 147: show interfaces (Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Multilink detail statistics</b>	<p>Frames, bytes, and bits per second received and sent by the bundle. All references to traffic direction (input or output) are defined with respect to the router. Each field has columns that indicate the number of frames received and transmitted, frames per second (fps), the number of bytes received and transmitted, and bits per second (bps).</p> <p>The difference in the bytes received and transmitted from the bundle is divided between the ML and the PPP headers. For example the header counter for a long sequence configuration would be as follows:</p> <ul style="list-style-type: none"> <li>• Input side - Total overhead = 6 bytes. <ul style="list-style-type: none"> <li>• ML: 4 bytes of ML header = 1 byte of Flag + 3 bytes of long sequence number.</li> <li>• PPP: 2 bytes of protocol field.</li> </ul> </li> <li>• Output side - Total overhead = 9 bytes. <ul style="list-style-type: none"> <li>• ML: 4 bytes of ML Header = 1 byte of Flag + 3 bytes of Long sequence number.</li> <li>• PPP: 5 bytes = 4 bytes of header + 1 byte of Idle flag.</li> </ul> </li> <li>• <b>Bundle</b>—Information for the bundle link. <ul style="list-style-type: none"> <li>• <b>Fragments: Input and Output</b>—Total number and rate of multilink fragments received and transmitted.</li> <li>• <b>Non-fragments: Input and Output</b>—Total number and rate of nonfragmented multilink frames received and transmitted.</li> <li>• <b>LFI: Input and Output</b>—Total number and rate of link fragmented and interleaved frames and bytes.</li> </ul> </li> </ul>	<b>extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface. If the MTU value is negotiated down to meet the MRRU requirement on the remote side, this value is marked <b>Adjusted</b> .	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which this address exists. For example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Addresses, Flags</b>	Information about the addresses configured on the logical interface. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>

## Sample Output

**show interfaces  
extensive (MLPPP on  
Link Services IQ)**

```

user@host> show interfaces lsq-0/2/0 extensive
Physical interface: lsq-0/2/0, Enabled, Physical link is Up
  Interface index: 140, SNMP ifIndex: 25, Generation: 23
  Link-level type: LinkService, MTU: 1504
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Last flapped   : 2005-06-02 08:54:36 PDT (00:05:45 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :          8872424          229080 bps
    Output bytes :          9856960          234448 bps
    Input packets:           38202           117 pps
    Output packets:          39453           117 pps
  Frame exceptions:
    Oversized frames          0
    Errored input frames      0
    Input on disabled link/bundle 0
    Output for disabled link/bundle 0
    Queuing drops             0
  Buffering exceptions:
    Packet data buffer overflow 0
    Fragment data buffer overflow 0
  Assembly exceptions:
    Fragment timeout          0
    Missing sequence number    0
    Out-of-order sequence number 0
    Out-of-range sequence number 0
  Hardware errors (sticky):
    Data memory error          0
    Control memory error        0
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 be              0                  0                  0
    1 ef              0                  0                  0
    2 af              0                  0                  0
    3 nc              0                  0                  0

Logical interface lsq-0/2/0.0 (Index 66) (SNMP ifIndex 26) (Generation 5)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Multilink-PPP
  Bandwidth: 256kbps
  Bundle options:
    MRRU              1504
    Drop timer period 2000
    Sequence number format long (24 bits)
    Fragmentation threshold 0
    Links needed to sustain bundle 1
    Multilink classes 0
    Link layer overhead 4.0 %
  Bundle status:
    Remote MRRU        1500
    Received sequence number 0x0
    Transmit sequence number 0x0
    Packet drops        0 (0 bytes)
    Fragment drops       9 (1401 bytes)
    MRRU exceeded        0

```

```

Fragment timeout          0
Missing sequence number   0
Out-of-order sequence number 4
Out-of-range sequence number 0
Packet data buffer overflow 0
Fragment data buffer overflow 0
Statistics      Frames      fps      Bytes      bps
Bundle:
Multilink:
  Input :      79827      239      9593009      232288
  Output:      77533      234      9811743      238056
Network:
  Input :      38202      117      8872424      229080
  Output:      39453      117      9856960      234448
Link:
ds-1/0/2:1:1.0 <-- up
  Input :      1114      87      180183      113608
  Output:      1577      118      199215      119064
ds-1/0/2:1:2.0 <-- down
  Input :      1941      152      187948      118680
  Output:      1574      116      199494      118992
Protocol inet, MTU: 1500 [Adjusted]
Flags: User-MTU, MTU-Protocol-Adjusted
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.74.11/24, Local: 10.74.11.10
Protocol iso, MTU: 1500 [Adjusted]
Flags: User-MTU, MTU-Protocol-Adjusted
Protocol mpls, MTU: 1488 [Adjusted], Maximum labels: 3
Flags: User-MTU, MTU-Protocol-Adjusted

```

show interfaces  
extensive (Multiclass

```

user@host> show interfaces extensive lsq-0/2/0
Physical interface: lsq-0/2/0, Enabled, Physical link is Up
Interface index: 140, SNMP ifIndex: 25, Generation: 23

```

MLPPP on Link  
Services IQ)

```

Link-level type: LinkService, MTU: 1504
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps
Last flapped   : 2005-06-02 08:54:36 PDT (00:02:25 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :          3474024          223704 bps
  Output bytes :          4193992          233888 bps
  Input packets:           15809           116 pps
  Output packets:          16788           117 pps
Frame exceptions:
  Oversized frames          0
  Errored input frames      0
  Input on disabled link/bundle 0
  Output for disabled link/bundle 0
  Queuing drops            0
Buffering exceptions:
  Packet data buffer overflow 0
  Fragment data buffer overflow 0
Assembly exceptions:
  Fragment timeout          0
  Missing sequence number    0
  Out-of-order sequence number 0
  Out-of-range sequence number 0
Hardware errors (sticky):
  Data memory error         0
  Control memory error      0
Queue counters:      Queued packets  Transmitted packets  Dropped packets

  0 be                0                0                0
  1 ef                0                0                0
  2 af                0                0                0
  3 nc                0                0                0

Logical interface lsq-0/2/0.0 (Index 66) (SNMP ifIndex 26) (Generation 5)
Flags: Point-To-Point SNMP-Traps Encapsulation: Multilink-PPP
Bandwidth: 256kbps
Bundle options:
  MRRU          1504
  Drop timer period 2000
  Sequence number format long (24 bits)
  Fragmentation threshold 0
  Links needed to sustain bundle 1
  Multilink classes 2
  Link layer overhead 4.0 %
Multilink class 0 status:
  Received sequence number 0x4c38
  Transmit sequence number 0x4890
  Packet drops 0 (0 bytes)
  Fragment drops 2551 (397084 bytes)
  MRRU exceeded 0
  Fragment timeout 52
  Missing sequence number 0
  Out-of-order sequence number 953
  Out-of-range sequence number 0
  Packet data buffer overflow 0
  Fragment data buffer overflow 0
Multilink class 1 status:

```

```

Received sequence number      0xffffffff
Transmit sequence number      0x3710
Packet drops                  0 (0 bytes)
Fragment drops                0 (0 bytes)
MRRU exceeded                 0
Fragment timeout              0
Missing sequence number       0
Out-of-order sequence number  0
Out-of-range sequence number  0
Packet data buffer overflow   0
Fragment data buffer overflow  0
Statistics                    Frames      fps          Bytes        bps
Bundle:
Fragments:
  Input :                     33719      239          4041763      231632
  Output:                     32371      234          4096545      237488
Packets:
  Input :                     15809      116          3474024      223704
  Output:                     16788      117          4193992      233888
Multilink class 0:
Fragments:
  Input :                     19331        0            0            0
  Output:                      0        0            0            0
Packets:
  Input :                      2064        0            0            0
  Output:                      1864        0            0            0
Multilink class 1:
Fragments:
  Input :                      0        0            0            0
  Output:                     14096        0            0            0
Packets:
  Input :                     14096        0            0            0
  Output:                      0        0            0            0
Link:
ds-1/0/2:1:1.0, Enabled, Physical link is Up
  Input :                      20972      151          2030595      118080
  Output:                      16184      116          2048468      118488
ds-1/0/2:1:2.0, Enabled, Physical link is Up
  Input :                      12747       88          2011168      113552
  Output:                      16187      118          2048077      119000
Protocol inet, MTU: 1500 [Adjusted], Generation: 14, Route table: 0
Flags: User-MTU, MTU-Protocol-Adjusted
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.0.1.0/30, Local: 10.0.1.2, Broadcast: Unspecified,
Generation: 18

```

**show interfaces**  
**extensive (MLPPP on**

```

user@host> show interfaces lsq-7/1/0.0 extensive
Logical interface lsq-7/1/0.0 (Index 88) (SNMP ifIndex 114) (Generation 188)
Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: Multilink-FR

```

Link Services IQ  
Bundle)

```

Last flapped: Never
Bandwidth: 256kbps
Bundle links information:
  Active bundle links      2
  Removed bundle links     0
  Disabled bundle links    0
Bundle options:
  MRRU                      1504
  Drop timer period         1500
  Inner PPP Protocol field compression enabled
  Sequence number format    short (12 bits)
  Fragmentation threshold   0
  Links needed to sustain bundle 1
  Multilink classes         0
  Link layer overhead       4.0 %
Bundle status:
  Received sequence number  0xb74
  Transmit sequence number  0xb74
  Packet drops              0 (0 bytes)
  Fragment drops            0 (0 bytes)
  MRRU exceeded             0
  Fragment timeout          0
  Missing sequence number   0
  Out-of-order sequence number 0
  Out-of-range sequence number 0
  Packet data buffer overflow 0
  Fragment data buffer overflow 0
Statistics      Frames      fps      Bytes      bps
Bundle:
  Multilink:
    Input :      315381      0      42757818      0
    Output:      315381      0      43388580      0
  Network:
    Input :      315381      0      40952064      0
    Output:      315381      0      40952064      0
Link:
  ds-6/0/0:1:1.0
    Up time: Up since boot
    Input :      63794      0      25146728      0
    Output:      63778      0      25273164      0
  ds-6/0/0:1:2.0
    Up time: Up since boot
    Input :      251587      0      17611090      0
    Output:      251603      0      18115416      0
Multilink detail statistics:
Bundle:
  Fragments:
    Input :      0      0      0      0
    Output:      0      0      0      0
  Non-fragments:
    Input :      293748      0      19387368      0
    Output:      293748      0      20562360      0
  LFI:
    Input :      21633      0      22152192      0
    Output:      21633      0      22325256      0
Protocol inet, MTU: 1500, Generation: 204, Route table: 0
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.0.1.0/30, Local: 10.0.1.2, Broadcast:
Unspecified, Generation: 214

```



**show interfaces  
extensive (MFR on Link  
Services IQ Bundle)**

```

user@host> show interfaces lsq-1/0/0:0 extensive
Physical interface: lsq-1/0/0:0, Enabled, Physical link is Up
Interface index: 179, SNMP ifIndex: 746, Generation: 182
Link-level type: Multilink-FR-UNI-NNI, MTU: 1508
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
Last flapped : 2010-11-15 01:11:00 PST (00:31:58 ago)
Statistics last cleared: Never
Hold-times : Up 0 ms, Down 0 ms
Multilink Frame Relay UNI NNI bundle options:
  Device type DCE
  MRRU 1508
  Bandwidth 1536kbps
  Fragmentation threshold 0
  Red differential delay limit 120
  Yellow differential delay limit 72
  Red differential delay action Remove link
  Reassembly drop timer 65535
  Links needed to sustain bundle 1
  Link layer overhead 4.0 %
  LIP Hello timer 10
    Acknowledgement timer 4
    Acknowledgement retries 2
  Bundle class A
  LMI type Consortium
    T391 LIV polling timer 10
    T392 polling verification timer 15
    N391 full status polling count 6
    N392 error threshold 3
    N393 monitored event count 4
  Consortium LMI settings: n392dce 3, n393dce 4, t392dce 15 seconds
LMI statistics:
  Input : 188 (last seen 00:00:01 ago)
  Output: 189 (last sent 00:00:01 ago)
DTE statistics:
  Enquiries sent : 0
  Full enquiries sent : 0
  Enquiry responses received : 0
  Full enquiry responses received : 0
DCE statistics:
  Enquiries received : 157
  Full enquiries received : 31
  Enquiry responses sent : 158
  Full enquiry responses sent : 31
Common statistics:
  Unknown messages received : 0
  Asynchronous updates received : 0
  Out-of-sequence packets received : 0
  Keepalive responses timeout : 0
Traffic statistics:
  Input bytes : 0 0 bps
  Output bytes : 0 0 bps
  Input packets: 0 0 pps
  Output packets: 0 0 pps
IPv6 transit statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Multilink Frame Relay UNI NNI bundle errors:
  Packet drops 0 (0 bytes)

```

```

Fragment drops          0 (0 bytes)
MRRU exceeded           0
Exception events         0
Multilink Frame Relay UNI NNI bundle statistics:
      Frames      fps      Bytes      bps

Multilink:
  Input :          0          0          0          0
  Output:          0          0          0          0
Network:
  Input :          0          0          0          0
  Output:          0          0          0          0
Multilink Frame Relay UNI NNI bundle links information:
  Active bundle links    1
  Removed bundle links   0
  Disabled bundle links  0
Multilink Frame Relay UNI NNI active bundle links statistics:
      Frames      fps      Bytes      bps

t1-7/0/0:1:3.0
  Up time: 00:31:24
  Input :          0          0          0          0
  Output:          0          0          0          0
  Current differential delay    0.0 ms
  Recent high differential delay 0.0 ms
  Times over red diff delay     0
  Times over yellow diff delay  0
  LIP:add_lnk lnk_ack lnk_rej  hello hel_ack lnk_rem rem_ack
  Rcv:      2      2      0      0      189      0      0
  Xmt:      2      1      0      0      189      0      0

```

Logical interface lsq-1/0/0:2.0 (Index 77) (SNMP ifIndex 751) (Generation 142)

Flags: Point-To-Point SNMP-Traps Encapsulation: Multilink-FR-UNI-NNI  
 Last flapped: 2010-11-15 01:11:40 PST (00:31:18 ago)

Bundle status:

```

Received sequence number    0xffff
Transmit sequence number    0x0
Packet drops                0 (0 bytes)
Fragment drops              0 (0 bytes)
MRRU exceeded               0
Fragment timeout            0
Missing sequence number     0
Out-of-order sequence number 0
Out-of-range sequence number 0
Packet data buffer overflow  0
Fragment data buffer overflow 0

```

```

Statistics      Frames      fps      Bytes      bps
Bundle:
Multilink:
  Input :          0          0          0          0
  Output:          0          0          0          0
Network:
  Input :          0          0          0          0
  Output:          0          0          0          0
Link:
  t1-7/0/0:1:3.0
  Up time: 00:31:24
  Input :          0          0          0          0
  Output:          0          0          0          0
Multilink detail statistics:
Bundle:

```

```

Fragments:
  Input :          0          0          0          0
  Output:          0          0          0          0
Non-Fragments:
  Input :          0          0          0          0
  Output:          0          0          0          0
Protocol inet, MTU: 1500, Generation: 153, Route table: 0
Flags: Sendbcst-pkt-to-re
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 10.0.1.8/30, Local: 10.0.1.9, Broadcast: Unspecified,
Generation: 154
DLCI 12
  Flags: Active
  Total down time: 00:00:32 sec, Last down: 00:31:50 ago
  Traffic statistics:
    Input bytes :          0
    Output bytes :          0
    Input packets:          0
    Output packets:          0
  DLCI statistics:
    Active DLCI :1 Inactive DLCI :0

```

**show interfaces**  
**(Multiclass MLPPP on**  
**Link Services IQ)**

```

user@host> show interfaces extensive lsq-0/2/0
Physical interface: lsq-0/2/0, Enabled, Physical link is Up
Interface index: 140, SNMP ifIndex: 25, Generation: 23
Link-level type: LinkService, MTU: 1504
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps
Last flapped : 2005-06-02 08:54:36 PDT (00:02:25 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :          3474024          223704 bps
  Output bytes :          4193992          233888 bps
  Input packets:          15809          116 pps
  Output packets:          16788          117 pps
Frame exceptions:
  Oversized frames          0
  Errored input frames      0
  Input on disabled link/bundle 0
  Output for disabled link/bundle 0
  Queuing drops            0
Buffering exceptions:
  Packet data buffer overflow 0
  Fragment data buffer overflow 0
Assembly exceptions:
  Fragment timeout          0
  Missing sequence number    0
  Out-of-order sequence number 0
  Out-of-range sequence number 0
Hardware errors (sticky):
  Data memory error          0
  Control memory error        0
Queue counters:      Queued packets  Transmitted packets  Dropped packets

  0 be                0                0                0
  1 ef                0                0                0
  2 af                0                0                0
  3 nc                0                0                0

```

Logical interface lsq-0/2/0.0 (Index 66) (SNMP ifIndex 26) (Generation 5)

Flags: Point-To-Point SNMP-Traps Encapsulation: Multilink-PPP

Bandwidth: 256kbps

Bundle options:

MRRU	1504
Drop timer period	2000
Sequence number format	long (24 bits)
Fragmentation threshold	0
Links needed to sustain bundle	1
Multilink classes	2
Link layer overhead	4.0 %

Multilink class 0 status:

Received sequence number	0x4c38
Transmit sequence number	0x4890
Packet drops	0 (0 bytes)
Fragment drops	2551 (397084 bytes)
MRRU exceeded	0
Fragment timeout	52
Missing sequence number	0
Out-of-order sequence number	953
Out-of-range sequence number	0
Packet data buffer overflow	0
Fragment data buffer overflow	0

Multilink class 1 status:

Received sequence number	0xffffffff
Transmit sequence number	0x3710
Packet drops	0 (0 bytes)
Fragment drops	0 (0 bytes)
MRRU exceeded	0
Fragment timeout	0
Missing sequence number	0
Out-of-order sequence number	0
Out-of-range sequence number	0
Packet data buffer overflow	0
Fragment data buffer overflow	0

Statistics	Frames	fps	Bytes	bps
------------	--------	-----	-------	-----

Bundle:

Fragments:				
Input :	33719	239	4041763	231632
Output:	32371	234	4096545	237488
Packets:				
Input :	15809	116	3474024	223704
Output:	16788	117	4193992	233888

Multilink class 0:

Fragments:				
Input :	19331	0	0	0
Output:	0	0	0	0
Packets:				
Input :	2064	0	0	0
Output:	1864	0	0	0

Multilink class 1:

Fragments:				
Input :	0	0	0	0
Output:	14096	0	0	0
Packets:				
Input :	14096	0	0	0
Output:	0	0	0	0

Link:

ds-1/0/2:1:1.0, Enabled, Physical link is Up				
Input :	20972	151	2030595	118080

```
Output:      16184      116      2048468      118488
ds-1/0/2:1:2.0, Enabled, Physical link is Up
Input :      12747      88      2011168      113552
Output:      16187      118      2048077      119000
Protocol inet, MTU: 1500 [Adjusted], Generation: 14, Route table: 0
Flags: User-MTU, MTU-Protocol-Adjusted
Addresses, Flags: Is-Preferred Is-Primary
Destination: 10.0.1.0/30, Local: 10.0.1.2, Broadcast: Unspecified,
Generation: 18
```

## show interfaces (Multilink Services)

<b>Syntax</b>	<pre>show interfaces ml-fpc/pic/port &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified multilink services interface.
<b>Options</b>	<p><b>ml-fpc/pic/port</b>—Display standard status information about the specified multilink services interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index</b>—(Optional) Display the SNMP index of interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Multilink Services) on page 939</a>
<b>Output Fields</b>	<a href="#">Table 148 on page 932</a> lists the output fields for the <b>show interfaces</b> (Multilink Services) command. Output fields are listed in the approximate order in which they appear.

**Table 148: Multilink Services show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the "Enabled Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	detail extensive none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	detail extensive none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	detail extensive

Table 148: Multilink Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Link-level type</b>	Encapsulation being used on the physical interface: <b>Multilink</b> .	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive</b> none
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router.	<b>detail extensive</b>
<b>Frame exceptions</b>	Information about framing exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface: <ul style="list-style-type: none"> <li>• <b>Oversized frames</b>—Number of frames received that exceed maximum frame length. Maximum length is 4500 Kb (kilobits).</li> <li>• <b>Errored input frames</b>—Number of input frame errors.</li> <li>• <b>Input on disabled link/bundle</b>—Number of frames received on disabled links. These can result either from an inconsistent configuration, or from a bundle or link being brought up or down with traffic actively flowing through it.</li> <li>• <b>Output for disabled link/bundle</b>—Number of frames sent for a disabled or unavailable link. These can result either from an inconsistent configuration, or from a bundle being brought up or down with traffic actively flowing through it.</li> <li>• <b>Queuing drops</b>—Total number of packets dropped before traffic enters the link services IQ interface. Indicates that the interface is becoming oversubscribed.</li> </ul>	<b>extensive</b>
<b>Buffering exceptions</b>	Information about buffering exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface: <ul style="list-style-type: none"> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical multilink services interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical multilink services interface capacity. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	<b>extensive</b>

Table 148: Multilink Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Assembly exceptions</b>	<p>Information about assembly exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface.</p> <p>An assembly exception does not necessarily indicate an operational problem with the Multilink PIC itself. If multilink-encapsulated traffic is dropped or reordered after a sequence number has been assigned, the assembling multilink interface records one or more exception events. The multilink interface can drop multilink-encapsulated fragments itself as a result. Any multilink packets or fragments dropped by the Multilink PIC itself result in packet or fragment drop counts on individual logical interfaces. If the logical interface drop counts are zero, but exception events are seen, the most likely cause is a problem with the individual link interfaces. Even if the logical interface fragment drop counts are nonzero, excess differential delay or traffic losses on individual interfaces can be the root cause.</p> <ul style="list-style-type: none"> <li>• <b>Fragment timeout</b>—Drop-timer expired while a fragment sequence number was outstanding. Occurs only if drop-timer is enabled. This can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled. These events do not necessarily indicate any problem with the operation of the Multilink PIC itself. If one or more individual links drop traffic, these events can occur. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle. These events do not necessarily indicate any problem with the operation of the Multilink PIC itself. If one or more individual links drop traffic, these events can occur. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers occurred within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-range sequence number</b>—Frame was received with out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost, or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	<b>extensive</b>
<b>Hardware errors</b>	<p>Information about hardware errors:</p> <ul style="list-style-type: none"> <li>• <b>Data memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> <li>• <b>Control memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Logical interface name.	All levels



Table 148: Multilink Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP interface index number.	<b>detail extensive</b> none
<b>Encapsulation</b>	Encapsulation being used: PPP or Multilink PPP.	All levels
<b>Bandwidth</b>	Speed at which the interface is running.	All levels
<b>Flags</b>	Logical interface flags. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	<b>detail extensive</b> none
<b>Bundle options</b>	Information about configured bundle options: <ul style="list-style-type: none"> <li>• <b>MRRU</b>—Configured size of the MRRU (maximum received reconstructed unit). It can be <b>1500</b> to <b>4500</b> bytes.</li> <li>• <b>Drop timer period</b>—Configured drop timeout period. It can be <b>0</b> through <b>127</b> ms. A value of <b>0</b> disables the timer. The default setting is <b>0</b>.</li> <li>• <b>Sequence number format</b>—Configured size of the sequence header: <b>12</b> or <b>24</b> bits. The default is <b>24</b> bits.</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold. A value of <b>0</b> results in no fragmentation. Nonzero values can be <b>128</b> through <b>16,320</b> bytes, in integer multiples of <b>64</b> bytes. The default is <b>0</b>.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: <b>1</b> through <b>8</b>.</li> </ul>	<b>detail extensive</b> none

Table 148: Multilink Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle status (MLPPP) or Multilink class status (MC-MLPPP)</b>	<p>Information about bundle status:</p> <ul style="list-style-type: none"> <li>• <b>Remote MRRU</b>—MRRU value received from remote peer. If negotiation has not been initiated, the default value is displayed.</li> <li>• <b>Received sequence number</b>—Sequence number for received packets.</li> <li>• <b>Transmitted sequence number</b>—Sequence number for transmitted packets.</li> <li>• <b>Packet drops</b>—Number and byte count of output packets that were dropped, rather than being encapsulated and sent out of the router as fragments. The packet drop counter is incremented if there is a temporary shortage of packet memory on the AS PIC, which causes packet fragmentation to fail.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments that were dropped, rather than being reassembled and handled by the router as packets. This counter also includes fragments that have been received successfully but had to be dropped because not all fragments that constituted a packet had been received. The fragment drop counter is incremented when a fragment received on constituent links is dropped. Drop fragments can be triggered by sequence ordering errors, duplicate fragments, timed-out fragments, and bad multilink headers.</li> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU. This counter is not implemented in this release.</li> <li>• <b>Fragment timeout</b>—Drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled.</li> <li>• <b>Missing sequence number</b>—Gap detected in the sequence numbers of fragments on a bundle.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream.</li> <li>• <b>Out-of-range sequence number</b>—Frame with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up.</li> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity.</li> </ul>	<b>detail extensive</b>
<b>Remote MRRU</b>	MRRU value received from remote peer. If negotiation has not been initiated, the default value is displayed.	<b>detail extensive</b> none

Table 148: Multilink Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle errors</b>	<p>Information about bundle errors:</p> <ul style="list-style-type: none"> <li>• <b>Packet drops</b>—Number and byte count of output packets dropped, rather than being encapsulated and sent out of the router as fragments.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments dropped, rather than being reassembled and handled by the router as packets.</li> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU.</li> <li>• <b>Exception events</b>—Number of exceptional events encountered while handling traffic on the bundle, other than MRRU exceeded errors. These events are categorized under the physical interface: <b>Frame exceptions</b>, <b>Buffering exceptions</b>, and <b>Fragment exceptions</b>. Exception events do not necessarily indicate that the multilink interface is not operating properly. Individual link failures can produce exceptional events.</li> </ul>	<b>detail extensive</b>
<b>Statistics</b>	<p>Information about fragments and packets received and sent by the router. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router.</p> <ul style="list-style-type: none"> <li>• <b>Bundle</b>—Information about bundles.</li> <li>• <b>Link</b>—Information about links used in the multilink operation.</li> </ul>	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive</b> none
<b>MTU</b>	MTU size on the logical interface. If the MTU value is negotiated down to meet the MRRU requirement on the remote side, this value is marked <b>Adjusted</b> .	<b>detail extensive</b> none
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b> none
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Route table in which this address exists. For example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b> none
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive</b> none
<b>Local</b>	IP address of the logical interface.	<b>detail extensive</b> none
<b>Broadcast</b>	Broadcast address on the logical interface.	<b>detail extensive</b> none

Table 148: Multilink Services show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

---

## Sample Output

show interfaces  
extensive (Multilink  
Services)

```
user@host> show interfaces ml-0/3/0 extensive
Physical interface: ml-0/3/0, Enabled, Physical link is Up
Interface index: 273, SNMP ifIndex: 196, Generation: 535
Link-level type: Multilink, MTU: 4474
Device flags : Present Running
Interface flags: Point-To-Point SNMP-Traps
Last flapped : 2002-04-25 14:21:34 PDT (21:06:59 ago)
Statistics last cleared: Never
Traffic statistics:
  Input bytes :                3535                0 bps
  Output bytes :               4135                0 bps
  Input packets:                 87                0 pps
  Output packets:              103                0 pps
Frame exceptions:
  Oversized frames              0
  Errored input frames          0
  Input on disabled link/bundle 0
  Output for disabled link/bundle 0
  Queuing drops                 0
Buffering exceptions:
  Packet data buffer overflow    0
  Fragment data buffer overflow  0
Assembly exceptions:
  Fragment timeout              0
  Missing sequence number        0
  Out-of-order sequence number   0
  Out-of-range sequence number   0
Hardware errors (sticky):
  Data memory error             0
  Control memory error          0

Logical interface ml-0/3/0.1 (Index 110) (SNMP ifIndex 674)
(Generation 402)
Flags: Point-To-Point SNMP-Traps Encapsulation: Multilink-PPP
Bandwidth: 12288kbps
Bundle options:
  MRRU                          1524
  Drop timer period              0
  Sequence number format         long (24 bits)
  Fragmentation threshold        0
  Links needed to sustain bundle 1
Bundle status:
  Remote MRRU                    1500
  Received sequence number        0x19ec14
  Transmit sequence number        0x38cfa8
  Packet drops                    0 (0 bytes)
  Fragment drops                  0 (0 bytes)
  MRRU exceeded                  0
  Fragment timeout                0
  Missing sequence number         0
  Out-of-order sequence number    0
  Out-of-range sequence number    0
  Packet data buffer overflow     0
  Fragment data buffer overflow   0
Bundle errors:
  Packet drops                    0 (0 bytes)
  Fragment drops                  0 (0 bytes)
  MRRU exceeded                  0
```

Exception events	0			
Statistics	Frames	fps	Bytes	bps
Bundle:				
Fragments:				
Input :	5	0	450	0
Output:	6	0	499	0
Packets:				
Input :	5	0	450	0
Output:	12	0	1202	0
Link:				
t1-0/1/0:11.0				
Input :	1	0	90	0
Output:	1	0	92	0
t1-0/1/0:12.0				
Input :	1	0	90	0
Output:	1	0	92	0
t1-0/1/0:10.0				
Input :	1	0	90	0
Output:	1	0	92	0
t1-0/1/0:14.0				
Input :	1	0	90	0
Output:	1	0	92	0
t1-0/1/0:13.0				
Input :	1	0	90	0
Output:	1	0	92	0
t1-0/1/0:8.0				
Input :	0	0	0	0
Output:	0	0	0	0
t1-0/1/0:9.0				
Input :	0	0	0	0
Output:	0	0	0	0
Protocol inet, MTU: 1500 [Adjusted], Flags: Generation: 752 Route table: 0				
Addresses, Flags: Is-Preferred Is-Primary, MTU-Protocol-Adjusted				
Destination: 1.1.2.2, Local: 1.1.2.1, Broadcast: Unspecified,				
Generation: 1090				
Protocol iso, MTU: 1500 [Adjusted], Flags: Is-Primary,				
Generation: 753 Route table: 0				

## show interfaces (Redundant Link Services IQ)

<b>Syntax</b>	<pre>show interfaces rlsqnumber &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;queue&gt; &lt;routing&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 7.6.
<b>Description</b>	(M Series and T Series routers only) Display status information about the specified redundant link services intelligent queuing (IQ) configuration.
<b>Options</b>	<p><b>rlsqnumber</b>—Redundant link services IQ interface name. The logical interface number range of values is 0 through 127.</p> <p><b>none</b>—Display standard status information about the specified redundant link services IQ configuration.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>queue</b>—(Optional) Display queue information about network interfaces.</p> <p><b>routing</b>—(Optional) Display routing information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Redundant Link Services IQ) on page 953</a></p> <p><a href="#">show interfaces brief (Redundant Link Services IQ) on page 953</a></p> <p><a href="#">show interfaces detail (Redundant Link Services IQ) on page 953</a></p> <p><a href="#">show interfaces extensive (Redundant Link Services IQ) on page 955</a></p>
<b>Output Fields</b>	Table 149 on page 941 lists the output fields for the <b>show interfaces</b> (redundant link services IQ) command. Output fields are listed in the approximate order in which they appear.

Table 149: show interfaces (Redundant Link Services IQ) Output Fields

Field Name	Field Description	Level of Output
Physical Interface		

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the "Enabled Field" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Link-level type</b>	Encapsulation being used on the physical interface: <b>Multilink-Frame-Relay-UNI-NNI</b> (default), <b>LinkService</b> , <b>Frame-relay</b> , <b>Frame-relay-ccc</b> , or <b>Frame-relay-tcc</b> .	All levels
<b>MTU</b>	Maximum transmission unit size on the physical interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Input rate</b>	(Redundant LSQ) Rate of bits and packets received on the interface.	None specified
<b>Output rate</b>	(Redundant LSQ) Rate of bits and packets transmitted on the interface.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router.	<b>detail extensive</b>



Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Frame exceptions</b>	<p>Information about framing exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface.</p> <ul style="list-style-type: none"> <li>• <b>Oversized frames</b>—Number of frames received that exceed maximum frame length. Maximum length is 4500 Kb (kilobits).</li> <li>• <b>Errored input frames</b>—Number of input frame errors.</li> <li>• <b>Input on disabled link/bundle</b>—Number of frames received on disabled links. These frames can result either from an inconsistent configuration, or from a bundle or link being brought up or down with traffic actively flowing through it.</li> <li>• <b>Output for disabled link/bundle</b>—Number of frames sent for a disabled or unavailable link. These frames can result either from an inconsistent configuration, or from a bundle being brought up or down while traffic is flowing through it.</li> <li>• <b>Queuing drops</b>—Total number of packets dropped before traffic enters the link services IQ interface. Indicates that the interface is becoming oversubscribed.</li> </ul>	<b>extensive</b>
<b>Buffering exceptions</b>	<p>Information about buffering exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface:</p> <ul style="list-style-type: none"> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	<b>extensive</b>

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Assembly exceptions</b>	<p>(Multilink Frame Relay end-to-end only) Information about assembly exceptions. Includes events recorded under <b>Exception Events</b> for each logical interface.</p> <p>An assembly exception does not necessarily indicate an operational problem with the physical link services IQ interface itself. If multilink-encapsulated traffic is dropped or reordered after a sequence number has been assigned, the interface records one or more exception events. The physical interface can drop multilink-encapsulated fragments itself as a result. Any multilink packets or fragments dropped by the interface itself result in packet or fragment drop counts on individual logical interfaces. If the logical interface drop counts are zero, but exception events are seen, the most likely cause is a problem with the individual link interfaces. Even if the logical interface fragment drop counts are nonzero, excess differential delay or traffic losses on individual interfaces can be the root cause.</p> <ul style="list-style-type: none"> <li>• <b>Fragment timeout</b>—The drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled. These events do not necessarily indicate any problem with the operation of the physical link services IQ interface itself, but can occur when one or more individual links drop traffic. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle. These events do not necessarily indicate any problem with the operation of the physical link services IQ interface itself, but can occur when one or more individual links drop traffic. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers within a single link. This event indicates that an individual link within a bundle reordered traffic, making the link services IQ interface unable to correctly process the resulting stream. Check the logical interface exception event counters to determine which bundle is responsible.</li> <li>• <b>Out-of-range sequence number</b>—Received a frame with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up. Check the logical interface exception event counters to determine which bundle is responsible.</li> </ul>	<b>extensive</b>
<b>Hardware errors (sticky)</b>	<p>(Multilink Frame Relay end-to-end only) Information about hardware errors:</p> <ul style="list-style-type: none"> <li>• <b>Data memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> <li>• <b>Control memory error</b>—A memory error was detected on the interface DRAM. Indicates possible hardware failure. Contact Juniper Networks technical support.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive none</b>

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Queue counters</b>	Queue number and its associated user-configured forwarding class name. <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive none</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation being used: PPP or Multilink PPP.	All levels
<b>Bandwidth</b>	Speed at which the interface is running.	All levels
<b>Bundle options</b>	(Multilink Frame Relay end-to-end interfaces only) <ul style="list-style-type: none"> <li>• <b>MRRU</b>—Configured size of the maximum received reconstructed unit (MRRU): 1500 through 4500 bytes. The default is 1504 bytes.</li> <li>• <b>Drop timer period</b>—Drop timeout value to provide a recovery mechanism if individual links in link services bundle drop one or more packets: 0 through 2000 milliseconds. Values under 5 ms are not recommended. The default setting is 0, which disables the timer.</li> <li>• <b>Sequence number format</b>—Short sequence number header format (MLPPP only).</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold: 64 through 16,320 bytes, in integer multiples of 64 bytes. The default setting is 0, which disables fragmentation.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: 1 through 8.</li> <li>• <b>Multilink classes</b>—Number of multilink classes negotiated.</li> <li>• <b>Link layer overhead</b>—Percentage of bundle bandwidth to be set aside for link-layer overhead.</li> </ul>	<b>detail extensive none</b>

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle status</b> (MLPPP) or <b>Multilink class status</b> (MC-MLPPP)	Information about bundle status: <ul style="list-style-type: none"> <li>• <b>Remote MRRU</b>—MRRU value received from remote peer. If negotiation has not been initiated, the default value is displayed.</li> <li>• <b>Received sequence number</b>—Sequence number for received packets.</li> <li>• <b>Transmitted sequence number</b>—Sequence number for transmitted packets.</li> <li>• <b>Packet drops</b>—Number and byte count of output packets that were dropped, rather than being encapsulated and sent out of the router as fragments. The packet drop counter is incremented if there is a temporary shortage of packet memory on the AS PIC, which causes packet fragmentation to fail.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments that were dropped, rather than being reassembled and handled by the router as packets. This counter also includes fragments that have been received successfully but had to be dropped because not all fragments that constituted a packet had been received. The fragment drop counter is incremented when a fragment received on constituent links is dropped. Drop fragments can be triggered by sequence ordering errors, duplicate fragments, timed-out fragments, and bad multilink headers.</li> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU. This counter is not implemented in this release.</li> <li>• <b>Fragment timeout</b>—The drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream.</li> <li>• <b>Out-of-range sequence number</b>—Received a frame with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up.</li> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity.</li> </ul>	detail extensive none

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Statistics</b>	<p>Information about fragments and packets received and sent by the router. All references to traffic direction (input or output) are defined with respect to the router. Input fragments received by the router are assembled into input packets; output packets are segmented into output fragments for transmission out of the router. Each field has columns that indicate the number of frames received and transmitted, frames per second (fps), the number of bytes received and transmitted, and bits per second (bps).</p> <ul style="list-style-type: none"> <li>• <b>Bundle</b>—Information for each active bundle link. <ul style="list-style-type: none"> <li>• <b>Fragments: Input and Output</b>—Total number and rate of fragments received and transmitted.</li> <li>• <b>Packets: Input and Output</b>—Total number and rate of packets received and transmitted.</li> <li>• <b>Multilink class</b>—(MC-MLPPP only) Information about multiclass links used in the multilink operation.</li> </ul> </li> <li>• <b>Link</b>—Information about links used in the multilink operation. <ul style="list-style-type: none"> <li>• <b>Link name</b>—Interface name of the link services IQ channel and state information (physical link <b>up</b> or <b>down</b>).</li> <li>• <b>Input and Output</b>—Total number and rate of fragments and packets received and transmitted.</li> </ul> </li> </ul>	<b>detail extensive</b>
<b>NCP state</b>	<p>(PPP) Network Control Protocol state.</p> <ul style="list-style-type: none"> <li>• <b>Conf-ack-received</b>—Acknowledgement was received.</li> <li>• <b>Conf-ack-sent</b>—Acknowledgement was sent.</li> <li>• <b>Conf-req-sent</b>—Request was sent.</li> <li>• <b>Down</b>—NCP negotiation is incomplete (not yet completed or has failed).</li> <li>• <b>Not-configured</b>—NCP is not configured on the interface.</li> <li>• <b>Opened</b>—NCP negotiation is successful.</li> </ul>	<b>detail extensive none</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface. If the MTU value is negotiated down to meet the MRRU requirement on the remote side, this value is marked <b>Adjusted</b> .	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which this address exists. For example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the addresses configured on the logical interface. Possible values are described in the “Addresses Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>MLPPP Bundle Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>SNMP-Traps</b>	SNMP trap notifications are enabled.	All levels
<b>Encapsulation</b>	Encapsulation being used: PPP, Multilink PPP or Multilink-FR.	All levels
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Bandwidth</b>	Speed at which the interface is running.	All levels
<b>Bundle links information</b>	Information about the bundled links. <ul style="list-style-type: none"> <li>• <b>Active bundle links</b>—Number of active links.</li> <li>• <b>Removed bundle links</b>—Information about links used in the multilink operation.</li> <li>• <b>Disabled bundle links</b>—Number of disabled links.</li> </ul>	<b>detail extensive none</b>

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle options</b>	<p>(Multilink Frame Relay end-to-end interfaces only)</p> <ul style="list-style-type: none"> <li>• <b>MRRU</b>—Configured size of the maximum received reconstructed unit (MRRU): <b>1500</b> through <b>4500</b> bytes. The default is <b>1504</b> bytes.</li> <li>• <b>Drop timer period</b>—Drop timeout value to provide a recovery mechanism if individual links in link services bundle drop one or more packets: <b>0</b> through <b>2000</b> milliseconds. Values under 5 ms are not recommended. The default setting is <b>0</b>, which disables the timer.</li> <li>• <b>Inner PPP Protocol field compression</b>—Inner PPP protocol compression is enabled or disabled.</li> <li>• <b>Sequence number format</b>—Short sequence number header format (MLPPP only).</li> <li>• <b>Fragmentation threshold</b>—Configured fragmentation threshold: <b>64</b> through <b>16,320</b> bytes, in integer multiples of <b>64</b> bytes. The default setting is <b>0</b>, which disables fragmentation.</li> <li>• <b>Links needed to sustain bundle</b>—Minimum number of links to sustain the bundle: 1 through <b>8</b>.</li> <li>• <b>Multilink classes</b>—Number of multilink classes negotiated.</li> <li>• <b>Link layer overhead</b>—Percentage of bundle bandwidth to be set aside for link-layer overhead.</li> </ul>	<b>detail extensive none</b>

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bundle status</b> (MLPPP)	<p>Information about bundle status:</p> <ul style="list-style-type: none"> <li>• <b>Received sequence number</b>—Sequence number for received packets.</li> <li>• <b>Transmit sequence number</b>—Sequence number for transmitted packets.</li> <li>• <b>Packet drops</b>—Number and byte count of output packets that were dropped, rather than being encapsulated and sent out of the router as fragments. The packet drop counter is incremented if there is a temporary shortage of packet memory on the AS PIC, which causes packet fragmentation to fail.</li> <li>• <b>Fragment drops</b>—Number and byte count of input fragments that were dropped, rather than being reassembled and handled by the router as packets. This counter also includes fragments that have been received successfully but had to be dropped because not all fragments that constituted a packet had been received. The fragment drop counter is incremented when a fragment received on constituent links is dropped. Drop fragments can be triggered by sequence ordering errors, duplicate fragments, timed-out fragments, and bad multilink headers.</li> <li>• <b>MRRU exceeded</b>—Number of reassembled packets exceeding the MRRU. This counter is not implemented in this release.</li> <li>• <b>Fragment timeout</b>—The drop timer expired while a fragment sequence number was outstanding. Occurs only if the drop timer is enabled. This timeout can occur if the differential delay across the links in a bundle exceeds the drop-timer setting, or if a multilink packet is lost in transit while the drop timer is enabled.</li> <li>• <b>Missing sequence number</b>—A gap was detected in the sequence numbers of fragments on a bundle.</li> <li>• <b>Out-of-order sequence number</b>—Two frames with out-of-order sequence numbers occurred within a single link. This event indicates that an individual link within a bundle reordered traffic, making the multilink interface unable to correctly process the resulting stream.</li> <li>• <b>Out-of-range sequence number</b>—A frame was received with an out-of-range sequence number. These events can occur when a large amount of multilink-encapsulated traffic is lost or the multilink peer is reset, so that a large jump in sequence numbers results. A small number of these events can occur when the far end of a bundle is taken down or brought up.</li> <li>• <b>Packet data buffer overflow</b>—Packet buffer memory is full. This overflow can occur when the aggregate data rate exceeds the physical link services IQ interface capacity.</li> <li>• <b>Fragment data buffer overflow</b>—Fragment buffer memory is full. This overflow can occur when excessive differential delay is experienced across the links within a single bundle, or when the aggregate data rate exceeds the physical link services IQ capacity.</li> </ul>	detail extensive none



Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Statistics</b>	<p>Information about frames, bytes, and bits per second received and sent by the router. All references to traffic direction (input or output) are defined with respect to the router. Each field has columns that indicate the number of frames received and transmitted, frames per second (fps), the number of bytes received and transmitted, and bits per second (bps).</p> <ul style="list-style-type: none"> <li>• <b>Bundle</b>—Information for each active bundle link. <ul style="list-style-type: none"> <li>• <b>Multilink: Input and Output</b>—Total number and rate of multilink frames, bytes, and bits per second received and transmitted.</li> <li>• <b>Network: Input and Output</b>—Total number of multilink frames, bytes, and bits per second received and transmitted.</li> </ul> </li> <li>• <b>Link</b>—Information about links used in the multilink operation. <ul style="list-style-type: none"> <li>• <b>Link name</b> is the interface name of the link services IQ channel and state information (physical link <b>up</b> or <b>down</b>) and up time.</li> <li>• <b>Input and Output</b>—Total number and rate of frames, bytes, and bits per second received and transmitted.</li> </ul> </li> </ul>	<b>extensive</b>
<b>Multilink detail statistics</b>	<p>Frames, bytes, and bits per second received and sent by the bundle. All references to traffic direction (input or output) are defined with respect to the router. Each field has columns that indicate the number of frames received and transmitted, frames per second (fps), the number of bytes received and transmitted, and bits per second (bps).</p> <ul style="list-style-type: none"> <li>• <b>Bundle</b>—Information for the bundle link. <ul style="list-style-type: none"> <li>• <b>Fragments: Input and Output</b>—Total number and rate of multilink fragments received and transmitted.</li> <li>• <b>Non-fragments: Input and Output</b>—Total number and rate of nonfragmented multilink frames received and transmitted.</li> <li>• <b>LFI: Input and Output</b>—Total number and rate of link fragmented and interleaved frames and bytes.</li> </ul> </li> </ul>	<b>extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface. If the MTU value is negotiated down to meet the MRRU requirement on the remote side, this value is marked <b>Adjusted</b> .	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which this address exists. For example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Addresses, Flags</b>	Information about the addresses configured on the logical interface. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address on the logical interface.	<b>detail extensive none</b>

Table 149: show interfaces (Redundant Link Services IQ) Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>

---

## Sample Output

### show interfaces (Redundant Link Services IQ)

```

user@host> show interfaces rlsq0
Physical interface: rlsq0, Enabled, Physical link is Up
  Interface index: 196, SNMP ifIndex: 27
  Link-level type: LinkService, MTU: 1504
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Last flapped   : Never
  Input rate      : 0 bps (0 pps)
  Output rate     : 0 bps (0 pps)

Logical interface rlsq0.0 (Index 72) (SNMP ifIndex 88)
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: Multilink-PPP
  Bandwidth: 0
  Statistics
  Bundle:
    Fragments:
      Input :      3      0      255      0
      Output:      3      0      264      0
    Packets:
      Input :      3      0      252      0
      Output:      0      0       0      0
  Link:
    t1-1/3/0:1.0
      Input :      3      0      255      0
      Output:      0      0       0      0
    t1-1/3/0:2.0
      Input :      0      0       0      0
      Output:      3      0      264      0
  NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured,
  mpls: Not-configured
  Protocol inet, MTU: 1500
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 2.2.2.0/30, Local: 2.2.2.1

```

### show interfaces brief (Redundant Link Services IQ)

```

user@host> show interfaces rlsq0 brief
Physical interface: rlsq0, Enabled, Physical link is Up
  Link-level type: LinkService, MTU: 1504
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000

Logical interface rlsq0.0
  Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: Multilink-PPP
  inet 2.2.2.1/30

```

### show interfaces detail (Redundant Link Services IQ)

```

user@host> show interfaces rlsq0 detail
Physical interface: rlsq0, Enabled, Physical link is Up
  Interface index: 196, SNMP ifIndex: 27, Generation: 144
  Link-level type: LinkService, MTU: 1504
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Last flapped   : Never
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :      252      0 bps
    Output bytes :      276      0 bps

```

```

Input packets:          3          0 pps
Output packets:         3          0 pps
Frame exceptions:
  Oversized frames      0
  Errored input frames  0
  Input on disabled link/bundle 0
  Output for disabled link/bundle 0
  Queuing drops         0
Buffering exceptions:
  Packet data buffer overflow 0
  Fragment data buffer overflow 0
Assembly exceptions:
  Fragment timeout       0
  Missing sequence number 0
  Out-of-order sequence number 0
  Out-of-range sequence number 0
Hardware errors (sticky):
  Data memory error      0
  Control memory error   0
Egress queues: 8 supported, 4 in use
Queue counters:         Queued packets  Transmitted packets  Dropped packets

0 be                    0              0              0

1 expedited-fo          0              0              0

2 assured-forw          0              0              0

3 network-cont          0              0              0

```

Logical interface rlsq0.0 (Index 72) (SNMP ifIndex 88) (Generation 31)

Flags: Point-To-Point SNMP-Traps 0x4000 Encapsulation: Multilink-PPP

Bandwidth: 0

Bundle options:

```

MRRU                    1504
Remote MRRU             N/A
Drop timer period       2000
Sequence number format  long (24 bits)
Fragmentation threshold 0
Links needed to sustain bundle 1
Multilink classes       0
Link layer overhead     4.0 %

```

Bundle status:

```

Received sequence number 0xffffffff
Transmit sequence number 0x0
Packet drops             0 (0 bytes)
Fragment drops           0 (0 bytes)
MRRU exceeded            0
Fragment timeout         0
Missing sequence number  0
Out-of-order sequence number 0
Out-of-range sequence number 0
Packet data buffer overflow 0
Fragment data buffer overflow 0

```

Statistics	Frames	fps	Bytes	bps
------------	--------	-----	-------	-----

Bundle:

Fragments:

Input :	3	0	255	0
Output:	3	0	264	0

Packets:

```

      Input :          3          0          252          0
      Output:          0          0           0          0
Link:
  t1-1/3/0:1.0
      Input :          3          0          255          0
      Output:          0          0           0          0
  t1-1/3/0:2.0
      Input :          0          0           0          0
      Output:          3          0          264          0
NCP state: inet: Opened, inet6: Not-configured, iso: Not-configured, mpls:
Not-configured
  Protocol inet, MTU: 1500, Generation: 43, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 2.2.2.0/30, Local: 2.2.2.1, Broadcast: Unspecified,
    Generation: 45

```

[show interfaces  
extensive \(Redundant  
Link Services IQ\)](#)

The output for the **show interfaces rlsq extensive** command is identical to that for the **show interfaces rlsq detail** command. For sample output, see [show interfaces detail \(Redundant Link Services IQ\)](#) on page 953.



# Tunnel Services Interface Operational Mode Commands

Table 150 on page 957 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot tunnel services interfaces. Commands are listed in alphabetical order.

**Table 150: Tunnel Interface Operational Mode Commands**

Task	Command
Display status information about generic routing encapsulation (GRE) interfaces.	<a href="#">show interfaces (GRE)</a>
Display status information about IP-over-IP interfaces.	<a href="#">show interfaces (IP-over-IP)</a>
Display status information about logical tunnel interfaces.	<a href="#">show interfaces (Logical Tunnel)</a>
Display status information about IP multicast encapsulation and de-encapsulation tunnel interfaces.	<a href="#">show interfaces (Multicast Tunnel)</a>
Display status information about Protocol Independent Multicast (PIM) de-encapsulation and encapsulation tunnel interfaces.	<a href="#">show interfaces (PIM)</a>
Display status information about virtual loopback tunnel interfaces.	<a href="#">show interfaces (Virtual Loopback Tunnel)</a>

## show interfaces (GRE)


<b>Syntax</b>	<pre>show interfaces <i>interface-type</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 12.1 for EX Series switches.</p>
<b>Description</b>	Display status information about the specified generic routing encapsulation (GRE) interface.
<b>Options</b>	<p><b><i>interface-type</i></b>—On M Series and T Series routers and EX Series switches, the interface type is <b><i>gr-fpc/pic/port</i></b>. On J Series routers, the interface type is <b><i>gr-pim/0/port</i></b>.</p> <p><b><i>brief   detail   extensive   terse</i></b>—(Optional) Display the specified output level of interface information.</p> <p><b><i>descriptions</i></b>—(Optional) Display interface description strings.</p> <p><b><i>media</i></b>—(Optional) Display media-specific information about network interfaces.</p> <p><b><i>snmp-index snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b><i>statistics</i></b>—(Optional) Display static interface statistics.</p>
	<div>  <p><b>NOTE:</b> You can configure generic routing encapsulation (GRE) interfaces (<i>gre-x/y/z</i>) only for GMPLS control channels. GRE interfaces are not supported or configurable for other applications. For more information about GMPLS, see the Junos OS MPLS Applications Configuration Guide and the Junos OS Feature Guides.</p> </div>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (GRE) on page 962</a></p> <p><a href="#">show interfaces brief (GRE) on page 962</a></p> <p><a href="#">show interfaces detail (GRE) on page 962</a></p> <p><a href="#">show interfaces detail (GRE) on an EX4200 Virtual Chassis Member Switch on page 963</a></p> <p><a href="#">show interfaces extensive (GRE) on page 965</a></p>
<b>Output Fields</b>	<p><a href="#">Table 151 on page 959</a> lists the output fields for the <b>show interfaces (GRE)</b> command. Output fields are listed in the approximate order in which they appear.</p>



Table 151: GRE show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Device Flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface Flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	<p>The number of and the rate at which input and output bytes and packets are received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>

Table 151: GRE show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Flags</b>	<p>Information about the logical interface. Possible values listed in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> describe general information about the logical interface.</p> <p>GRE-specific information about the logical interface is indicated by the presence or absence of the following value in this field:</p> <ul style="list-style-type: none"> <li>• <b>Reassemble-Pkts</b>—If the <b>Flags</b> field includes this string, the GRE tunnel is configured to reassemble tunnel packets that were fragmented after tunnel encapsulation.</li> </ul>	All levels
<b>IP-Header</b>	<p>IP header of the logical interface. If the <b>tunnel key</b> statement is configured, this information is included in the <b>IP Header</b> entry.</p> <p>GRE-specific information about the logical interface is indicated by the presence or absence of the following value in this field:</p> <ul style="list-style-type: none"> <li>• <b>df</b>—If the <b>IP-Header</b> field includes this string immediately following the 16 bits of identification information (that is, if <b>:df:</b> displays after the twelfth byte), the GRE tunnel is configured to allow fragmentation of GRE packets after encapsulation.</li> </ul>	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Copy-tos-to-outer-ip-header</b>	<p>Status of type of service (ToS) bits in the GRE packet header:</p> <ul style="list-style-type: none"> <li>• <b>On</b>—ToS bits were copied from the payload packet header into the header of the IP packet sent through the GRE tunnel.</li> <li>• <b>Off</b>—ToS bits were not copied from the payload packet header and are set to 0 in the GRE packet header.</li> </ul> <p><b>NOTE:</b> EX Series switches do not support copying ToS bits to the encapsulated packet, so the value of this field is always <b>Off</b> in switch output.</p>	<b>detail extensive</b>
<b>Gre keepalives configured</b>	<p>Indicates whether a GRE keepalive time and hold time are configured for the GRE tunnel.</p> <p><b>NOTE:</b> EX Series switches do not support configuration of GRE tunnel keepalive times and hold times, so the value of this field is always <b>Off</b> in switch output.</p>	<b>detail extensive</b>
<b>Gre keepalives adjacency state</b>	Status of the other end of the GRE tunnel: <b>Up</b> or <b>Down</b> . If keepalive messages are not received by either end of the GRE tunnel within the hold-time period, the GRE keepalive adjacency state is down even when the GRE tunnel is up.	<b>detail extensive</b>
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified

Table 151: GRE show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Rate of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input rate</b>—Rate of bits and packets received on the interface.</li> <li>• <b>Output rate</b>—Rate of bits and packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive none</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

```

show interfaces (GRE) user@host> show interfaces gr-1/2/0
Physical interface: gr-0/0/0, Enabled, Physical link is Up
  Interface index: 132, SNMP ifIndex: 26
  Type: GRE, Link-level type: GRE, MTU: Unlimited, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

Logical interface gr-0/0/0.0 (Index 68) (SNMP ifIndex 47)
  Flags: Point-To-Point SNMP-Traps 16384
  IP-Header 1.1.1.2:1.1.1.1:47:df:64:0000000000000000 Encapsulation: GRE-NULL
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 1476
  Flags: None
  Addresses, Flags: Is-Primary
    Local: 1.10.1.1

show interfaces brief (GRE) user@host> show interfaces gr-1/2/0 brief
Physical interface: gr-1/2/0, Enabled, Physical link is Up
  Type: GRE, Link-level type: GRE, MTU: Unlimited, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps

Logical interface gr-1/2/0.0
  Flags: Hardware-Down Point-To-Point SNMP-Traps 0x4000
  IP-Header 10.10.0.2:10.10.0.1:47:df:64:0000000000000000
  Encapsulation: GRE-NULL
  inet 10.100.0.1/30
  mpls

show interfaces detail (GRE) user@host> show interfaces gr-1/2/0 detail
Physical interface: gr-0/0/0, Enabled, Physical link is Up
  Interface index: 132, SNMP ifIndex: 26, Generation: 13
  Type: GRE, Link-level type: GRE, MTU: Unlimited, Speed: 800mbps
  Hold-times      : Up 0 ms, Down 0 ms
  Device flags    : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   : 0 0 bps
    Output bytes  : 0 0 bps
    Input packets : 0 0 pps
    Output packets: 0 0 pps

Logical interface gr-0/0/0.0 (Index 68) (SNMP ifIndex 47) (Generation 8)
  Flags: Point-To-Point SNMP-Traps 16384
  IP-Header 1.1.1.2:1.1.1.1:47:df:64:0000000000000000 Encapsulation: GRE-NULL
  Traffic statistics:
    Input bytes   : 0
    Output bytes  : 0
    Input packets : 0
    Output packets: 0
  Local statistics:
    Input bytes   : 0

```

```
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
Protocol inet, MTU: 1476, Generation: 12, Route table: 0
Flags: None
Addresses, Flags: Is-Primary
Destination: Unspecified, Local: 1.10.1.1, Broadcast: Unspecified,
Generation: 15
```

**show interfaces detail  
(GRE) on an EX4200**

```
user@switch> show interfaces gr-2/0/15 detail
Physical interface: gr-2/0/15, Enabled, Physical link is Up
Interface index: 195, SNMP ifIndex: 846, Generation: 198
```

## Virtual Chassis Member Switch

```
Type: GRE, Link-level type: GRE, MTU: Unlimited, Speed: 1000mbps
Hold-times      : Up 0 ms, Down 0 ms
Current address: 00:1f:12:38:0f:d2, Hardware address: 00:1f:12:38:0f:d2
Device flags    : Present Running
Interface flags: Point-To-Point SNMP-Traps
Statistics last cleared: 2011-09-14 17:43:15 UTC (00:00:18 ago)
Traffic statistics:
Input bytes  :          5600636          0 bps
Output bytes :          5600636          0 bps
Input packets:          20007          0 pps
Output packets:         20007          0 pps
IPv6 transit statistics:
Input bytes  :              0
Output bytes :              0
Input packets:              0
Output packets:             0
```

```
Logical interface gr-2/0/15.0 (Index 75) (SNMP ifIndex 847) (HW Token 4093)
(Generation 140)
Flags: Point-To-Point SNMP-Traps 0x0
IP-Header 180.20.30.2:180.20.20.3:47:df:64:0000000000000000
Encapsulation: GRE-NULL
Copy-tos-to-outer-ip-header: Off
Gre keepalives configured: Off, Gre keepalives adjacency state: down
Traffic statistics:
Input bytes  :          5600886
Output bytes :          2881784
Input packets:          20010
Output packets:          10018
Local statistics:
Input bytes  :           398
Output bytes :           264
Input packets:            5
Output packets:            3
Transit statistics:
Input bytes  :          5600488          0 bps
Output bytes :          2881520          0 bps
Input packets:          20005          0 pps
Output packets:          10015          0 pps
Protocol inet, Generation: 159, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
Destination: 90.90.90/24, Local: 90.90.90.10, Broadcast: 90.90.90.255,
Generation: 144
```

```
Logical interface gr-2/0/15.1 (Index 80) (SNMP ifIndex 848) (HW Token 4088)
(Generation 150)
Flags: Point-To-Point SNMP-Traps 0x0
IP-Header 160.20.40.2:160.20.30.1:47:df:64:0000000000000000
Encapsulation: GRE-NULL
Copy-tos-to-outer-ip-header: Off
Gre keepalives configured: Off, Gre keepalives adjacency state: down
Traffic statistics:
Input bytes  :           260
Output bytes :          2880148
Input packets:            4
Output packets:          10002
Local statistics:
Input bytes  :           112
Output bytes :            0
Input packets:            2
```

```
Output packets:                0
Transit statistics:
Input bytes  :                148                0 bps
Output bytes :            2880148                0 bps
Input  packets:                 2                0 pps
Output packets:            10002                0 pps
Protocol inet, Generation: 171, Route table: 0
Flags: None
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 70.70.70/24, Local: 70.70.70.10, Broadcast: 70.70.70.255,
  Generation: 160
```

#### **show interfaces extensive (GRE)**

The output for the **show interfaces extensive** command is identical to that for the **show interfaces detail** command. For sample output, see [show interfaces detail \(GRE\) on page 962](#) and [show interfaces detail \(GRE\) on an EX4200 Virtual Chassis Member Switch on page 963](#).

## show interfaces (IP-over-IP)

<b>Syntax</b>	<pre>show interfaces <i>interface-type</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified IP-over-IP interface.
<b>Options</b>	<p><b><i>interface-type</i></b>—On M Series and T Series routers, the interface type is <b><i>ip-fpc/pic/port</i></b>. On J Series routers, the interface type is <b><i>ip-pim/O/port</i></b>.</p> <p><b><i>brief   detail   extensive   terse</i></b>—(Optional) Display the specified level of output.</p> <p><b><i>descriptions</i></b>—(Optional) Display interface description strings.</p> <p><b><i>media</i></b>—(Optional) Display media-specific information about network interfaces.</p> <p><b><i>snmp-index snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b><i>statistics</i></b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (IP-over-IP) on page 969</a></p> <p><a href="#">show interfaces brief (IP-over-IP) on page 969</a></p> <p><a href="#">show interfaces detail (IP-over-IP) on page 969</a></p> <p><a href="#">show interfaces extensive (IP-over-IP) on page 970</a></p>
<b>Output Fields</b>	<p><a href="#">Table 152 on page 966</a> lists the output fields for the <b>show interfaces (IP-over-IP)</b> command. Output fields are listed in the approximate order in which they appear.</p>

**Table 152: IP-over-IP show interfaces Output Fields**

Field	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the "Enabled Field" section under " <a href="#">Common Output Fields Description</a> " on page 141.	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>



Table 152: IP-over-IP show interfaces Output Fields (*continued*)

Field	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Input rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>IP Header</b>	IP header of the logical interface.	All levels

Table 152: IP-over-IP show interfaces Output Fields (*continued*)

Field	Field Description	Level of Output
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input rate</b>—Rate of bits and packets received on the interface.</li> <li>• <b>Output rate</b>—Rate of bits and packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , or <b>mpls</b> .	<b>detail extensive none</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>

## Sample Output

### show interfaces (IP-over-IP)

```
user@host> show interfaces ip-0/0/0
Physical interface: ip-0/0/0, Enabled, Physical link is Up
  Interface index: 133, SNMP ifIndex: 27
  Type: IPIP, Link-level type: IP-over-IP, MTU: Unlimited, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

  Logical interface ip-0/0/0.0 (Index 69) (SNMP ifIndex 49)
    Flags: Point-To-Point SNMP-Traps 16384
    IP-Header 2.2.2.1:2.2.2.2:4:df:64:00000000 Encapsulation: IPv4=NULL
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: 1480
  Flags: None
```

### show interfaces brief (IP-over-IP)

```
user@host> show interfaces ip-0/0/0 brief
Physical interface: ip-0/0/0, Enabled, Physical link is Up
  Type: IPIP, Link-level type: IP-over-IP, MTU: Unlimited, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps

  Logical interface ip-0/0/0.0
    Flags: Point-To-Point SNMP-Traps 16384
    IP-Header 2.2.2.1:2.2.2.2:4:df:64:00000000 Encapsulation: IPv4=NULL
  inet
```

### show interfaces detail (IP-over-IP)

```
user@host> show interfaces ip-0/0/0 detail
Physical interface: ip-0/0/0, Enabled, Physical link is Up
  Interface index: 133, SNMP ifIndex: 27, Generation: 14
  Type: IPIP, Link-level type: IP-over-IP, MTU: Unlimited, Speed: 800mbps
  Hold-times     : Up 0 ms, Down 0 ms
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   : 0 0 bps
    Output bytes  : 0 0 bps
    Input packets : 0 0 pps
    Output packets: 0 0 pps

  Logical interface ip-0/0/0.0 (Index 69) (SNMP ifIndex 49) (Generation 9)
    Flags: Point-To-Point SNMP-Traps 16384
    IP-Header 2.2.2.1:2.2.2.2:4:df:64:00000000 Encapsulation: IPv4=NULL
  Traffic statistics:
    Input bytes   : 0
    Output bytes  : 0
    Input packets : 0
    Output packets: 0
  Local statistics:
    Input bytes   : 0
    Output bytes  : 0
    Input packets : 0
    Output packets: 0
  Transit statistics:
```

```
Input bytes :          0          0 bps
Output bytes :          0          0 bps
Input packets:          0          0 pps
Output packets:         0          0 pps
Protocol inet, MTU: 1480, Generation: 13, Route table: 0
Flags: None
```

**[show interfaces  
extensive \(IP-over-IP\)](#)**

The output for the `show interfaces extensive` command is identical to that for the `show interfaces detail` command. For sample output, see [show interfaces detail \(IP-over-IP\)](#) on page 969.

## show interfaces (Logical Tunnel)

<b>Syntax</b>	show interfaces <i>interface-type</i> <brief   detail   extensive   terse> <descriptions> <media> <snmp-index <i>snmp-index</i> > <statistics>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified logical tunnel interface.
<b>Options</b>	<p><i>interface-type</i>—On M Series and T Series routers, the interface type is <i>lt-fpc/pic/port</i>. On J Series routers, the interface type is <i>lt-pim/0/port</i>.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces extensive (Logical Tunnel) on page 975</a>
<b>Output Fields</b>	<a href="#">Table 153 on page 971</a> lists the output fields for the <b>show interfaces</b> (logical tunnel) command. Output fields are listed in the approximate order in which they appear.

**Table 153: Logical Tunnel show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

Table 153: Logical Tunnel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Type</b>	Type of interface. <b>Software-Pseudo</b> indicates a standard software interface with no associated hardware device.	All levels
<b>Link-level type</b>	Encapsulation used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source: <b>Internal</b> or <b>External</b> when configured. Otherwise, <b>Unspecified</b> .	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link type</b>	Type of link.	All levels
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Physical info</b>	Information about the physical interface.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive none</b>
<b>Hardware address</b>	Hardware MAC address.	<b>detail extensive none</b>
<b>Alternate link address</b>	Backup link address.	<b>detail extensive none</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li><b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li><b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 153: Logical Tunnel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<p>Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifindex</b>	SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels

Table 153: Logical Tunnel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Rate of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Rate of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Rate of packets received on the interface.</li> <li>• <b>Output packets</b>—Rate of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , <b>mpls</b> .	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Route table in which this address exists. For example, <b>Route table:0</b> refers to <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under “ <a href="#">Common Output Fields Description</a> ” on <a href="#">page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address of the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>



## Sample Output

show interfaces  
extensive (Logical  
Tunnel)

```
user@host> show interfaces lt-1/0/0 extensive
Physical interface: lt-1/0/0, Enabled, Physical link is Up
  Interface index: 143, SNMP ifIndex: 70, Generation: 26
  Type: Logical-tunnel, Link-level type: Logical-tunnel, MTU: 0,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link type      : Unspecified
  Link flags     : None
  Physical info  : 13
  Hold-times    : Up 0 ms, Down 0 ms
  Current address: 00:90:69:a6:48:7e, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : 2004-03-03 15:53:52 PST (22:08:46 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0
  Output errors:
    Carrier transitions: 1, Errors: 0, Drops: 0, MTU errors: 0

Logical interface lt-1/0/0.0 (Index 66) (SNMP ifIndex 467) (Generation 3024)
  Flags: Point-To-Point SNMP-Traps 16384 DLCI 100 Encapsulation: FR-NLPID
  Traffic statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Local statistics:
    Input bytes   :                0
    Output bytes  :                0
    Input packets :                0
    Output packets:                0
  Transit statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
  Protocol inet, MTU: 4470, Generation: 7034, Route table: 0
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.1.1/24, Local: 10.1.1.1, Broadcast: Unspecified,
    Generation: 2054
```

## show interfaces (Multicast Tunnel)

---

<b>Syntax</b>	<code>show interfaces <i>interface-type</i></code> <code>&lt;brief   detail   extensive   terse&gt;</code> <code>&lt;descriptions&gt;</code> <code>&lt;media&gt;</code> <code>&lt;snmp-index <i>snmp-index</i>&gt;</code> <code>&lt;statistics&gt;</code>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified multicast tunnel interface and its logical encapsulation and de-encapsulation interfaces.
<b>Options</b>	<p><b><i>interface-type</i></b>—On M Series and T Series routers, the interface type is <b><i>mt-fpc/pic/port</i></b>. On J Series routers, the interface type is <b><i>mt-pim/0/port</i></b>.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Additional Information</b>	The multicast tunnel interface has two logical interfaces: encapsulation and de-encapsulation. These interfaces are automatically created by the Junos OS for every multicast-enabled VPN routing and forwarding (VRF) instance. The encapsulation interface carries multicast traffic traveling from the edge interface to the core interface. The de-encapsulation interface carries traffic coming from the core interface to the edge interface.
<b>Required Privilege Level</b>	view

**List of Sample Output** [show interfaces \(Multicast Tunnel\) on page 979](#)  
[show interfaces brief \(Multicast Tunnel\) on page 979](#)  
[show interfaces detail \(Multicast Tunnel\) on page 979](#)  
[show interfaces extensive \(Multicast Tunnel\) on page 979](#)  
[show interfaces \(Multicast Tunnel Encapsulation\) on page 980](#)  
[show interfaces \(Multicast Tunnel De-Encapsulation\) on page 981](#)

**Output Fields** [Table 154 on page 977](#) lists the output fields for the **show interfaces** (Multicast Tunnel) command. Output fields are listed in the approximate order in which they appear.

**Table 154: Multicast Tunnel show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 154: Multicast Tunnel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"><li>• <b>Input bytes</b>—Number of bytes received on the interface.</li><li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li><li>• <b>Input packets</b>—Number of packets received on the interface.</li><li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li></ul>	All levels

## Sample Output

### show interfaces (Multicast Tunnel)

```
user@host> show interfaces mt-1/2/0
Physical interface: mt-1/2/0, Enabled, Physical link is Up
Interface index: 145, SNMP ifIndex: 41
Type: Multicast-GRE, Link-level type: GRE, MTU: Unlimited, Speed: 800mbps
Device flags : Present Running
Interface flags: SNMP-Traps
Input rate   : 0 bps (0 pps)
Output rate  : 0 bps (0 pps)
```

### show interfaces brief (Multicast Tunnel)

```
user@host> show interfaces mt-1/2/0 brief
Physical interface: mt-1/2/0, Enabled, Physical link is Up
Type: Multicast-GRE, Link-level type: GRE, MTU: Unlimited, Speed: 800mbps
Device flags : Present Running
Interface flags: SNMP-Traps
```

### show interfaces detail (Multicast Tunnel)

```
user@host> show interfaces mt-1/2/0 detail
Physical interface: mt-1/2/0, Enabled, Physical link is Up
Interface index: 145, SNMP ifIndex: 41, Generation: 28
Type: Multicast-GRE, Link-level type: GRE, MTU: Unlimited, Speed: 800mbps
Hold-times      : Up 0 ms, Down 0 ms
Device flags    : Present Running
Interface flags: SNMP-Traps
Statistics last cleared: Never
Traffic statistics:
Input bytes :          170664562          560000 bps
Output bytes :          112345376          368176 bps
Input packets:           2439107           1000 pps
Output packets:          2439120           1000 pps
```

### show interfaces extensive (Multicast Tunnel)

```
user@host> show interfaces mt-1/2/0 extensive
Physical interface: mt-1/2/0, Enabled, Physical link is Up
Interface index: 141, SNMP ifIndex: 529, Generation: 144
Type: Multicast-GRE, Link-level type: GRE, MTU: Unlimited, Speed: 800mbps
Hold-times      : Up 0 ms, Down 0 ms
Device flags    : Present Running
Interface flags: SNMP-Traps
Statistics last cleared: Never
Traffic statistics:
Input bytes :          170664562          560000 bps
Output bytes :          112345376          368176 bps
Input packets:           2439107           1000 pps
Output packets:          2439120           1000 pps
IPv6 transit statistics:
Input bytes :              0
Output bytes :              0
Input packets:              0
Output packets:             0
```

```
Logical interface mt-1/2/0.32768 (Index 83) (SNMP ifIndex 556) (Generation 148)
```

```
Flags: Point-To-Point SNMP-Traps 0x4000 IP-Header
232.1.1.1:10.0.0.6:47:df:64:0000000800000000 Encapsulation: GRE-NULL
Traffic statistics:
Input bytes :          170418430
Output bytes :          112070294
```

```

Input packets:          2434549
Output packets:         2435593
IPv6 transit statistics:
  Input bytes :          0
  Output bytes :         0
  Input packets:         0
  Output packets:        0
Local statistics:
  Input bytes :          0
  Output bytes :        80442
  Input packets:         0
  Output packets:       1031
Transit statistics:
  Input bytes :       170418430      560000 bps
  Output bytes :     111989852      368176 bps
  Input packets:       2434549      1000 pps
  Output packets:     2434562      1000 pps
IPv6 transit statistics:
  Input bytes :          0
  Output bytes :         0
  Input packets:         0
  Output packets:        0
Protocol inet, MTU: 1572, Generation: 182, Route table: 4
Flags: None
Protocol inet6, MTU: 1572, Generation: 183, Route table: 4
Flags: None

```

Logical interface mt-1/2/0.1081344 (Index 84) (SNMP ifIndex 560) (Generation 149)

```

Flags: Point-To-Point SNMP-Traps 0x6000 Encapsulation: GRE=NULL
Traffic statistics:
  Input bytes :          246132
  Output bytes :         355524
  Input packets:         4558
  Output packets:        4558
IPv6 transit statistics:
  Input bytes :          0
  Output bytes :         0
  Input packets:         0
  Output packets:        0
Local statistics:
  Input bytes :          246132
  Output bytes :          0
  Input packets:         4558
  Output packets:          0
Transit statistics:
  Input bytes :          0      0 bps
  Output bytes :         355524 0 bps
  Input packets:          0      0 pps
  Output packets:        4558    0 pps
IPv6 transit statistics:
  Input bytes :          0
  Output bytes :         0
  Input packets:         0
  Output packets:        0
Protocol inet, MTU: Unlimited, Generation: 184, Route table: 4
Flags: None
Protocol inet6, MTU: Unlimited, Generation: 185, Route table: 4
Flags: None

```

user@host> show interfaces mt-3/1/0.32768

**show interfaces  
(Multicast Tunnel  
Encapsulation)**

```
Logical interface mt-3/1/0.32768 (Index 67) (SNMP ifIndex 0)
  Flags: Point-To-Point SNMP-Traps 0x4000
  IP-Header 239.1.1.1:10.255.70.15:47:df:64:0000000800000000
  Encapsulation: GRE-NULL
  Input packets : 0
  Output packets: 2
  Protocol inet, MTU: Unlimited
  Flags: None
```

**show interfaces  
(Multicast Tunnel  
De-Encapsulation)**

```
user@host> show interfaces mt-3/1/0.49152
Logical interface mt-3/1/0.49152 (Index 74) (SNMP ifIndex 0)
  Flags: Point-To-Point SNMP-Traps 0x6000 Encapsulation: GRE-NULL
  Input packets : 0
  Output packets: 2
  Protocol inet, MTU: Unlimited
  Flags: None
```

## show interfaces (PIM)

<b>Syntax</b>	<pre>show interfaces <i>interface-type</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified Protocol Independent Multicast (PIM) de-encapsulation or PIM encapsulation interface, respectively.
<b>Options</b>	<p><b><i>interface-type</i></b>—On M Series and T Series routers, the PIM de-encapsulation interface type is <b>pd-fpc/pic/port</b>. On J Series routers, it is <b>pd-pim/O/port</b>. On M Series and T Series routers, the PIM encapsulation interface type is <b>pe-fpc/pic/port</b>. On J Series routers, it is <b>pe-pim/O/port</b>.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (PIM De-Encapsulation) on page 984</a></p> <p><a href="#">show interfaces brief (PIM De-Encapsulation) on page 984</a></p> <p><a href="#">show interfaces detail (PIM De-Encapsulation) on page 984</a></p> <p><a href="#">show interfaces extensive (PIM Encapsulation) on page 984</a></p> <p><a href="#">show interfaces (PIM Encapsulation) on page 984</a></p> <p><a href="#">show interfaces brief (PIM Encapsulation) on page 984</a></p> <p><a href="#">show interfaces detail (PIM Encapsulation) on page 985</a></p> <p><a href="#">show interfaces extensive (PIM Encapsulation) on page 985</a></p>
<b>Output Fields</b>	Table 155 on page 982 lists the output fields for the <b>show interfaces</b> (PIM de-encapsulation or encapsulation) command. Output fields are listed in the approximate order in which they appear.

Table 155: PIM show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels



Table 155: PIM show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>

## Sample Output

### show interfaces (PIMDe-Encapsulation)

```
user@host> show interfaces pd-0/0/0
Physical interface: pd-0/0/0, Enabled, Physical link is Up
  Interface index: 130, SNMP ifIndex: 25
  Type: PIMD, Link-level type: PIM-Decapsulator, MTU: Unlimited, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
```

### show interfaces brief (PIM De-Encapsulation)

```
user@host> show interfaces pd-0/0/0 brief
Physical interface: pd-0/0/0, Enabled, Physical link is Up
  Type: PIMD, Link-level type: PIM-Decapsulator, MTU: Unlimited, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps
```

### show interfaces detail (PIM De-Encapsulation)

```
user@host> show interfaces pd-0/0/0 detail
Physical interface: pd-0/0/0, Enabled, Physical link is Up
  Interface index: 130, SNMP ifIndex: 25, Generation: 11
  Type: PIMD, Link-level type: PIM-Decapsulator, MTU: Unlimited, Speed: 800mbps
  Hold-times     : Up 0 ms, Down 0 ms
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
```

### show interfaces extensive (PIM Encapsulation)

```
user@host> show interfaces pd-0/0/0 extensive
Physical interface: pd-0/0/0, Enabled, Physical link is Up
  Interface index: 130, SNMP ifIndex: 25, Generation: 11
  Type: PIMD, Link-level type: PIM-Decapsulator, MTU: Unlimited, Speed: 800mbps
  Hold-times     : Up 0 ms, Down 0 ms
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   :                0                0 bps
    Output bytes  :                0                0 bps
    Input packets :                0                0 pps
    Output packets:                0                0 pps
```

### show interfaces (PIM Encapsulation)

```
user@host> show interfaces pe-0/0/0
Physical interface: pe-0/0/0, Enabled, Physical link is Up
  Interface index: 131, SNMP ifIndex: 26
  Type: PIME, Link-level type: PIM-Encapsulator, MTU: Unlimited, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
```

```
user@host> show interfaces pe-0/0/0 brief
```

**show interfaces brief  
(PIM Encapsulation)**

Physical interface: pe-0/0/0, Enabled, Physical link is Up  
 Type: PIME, Link-level type: PIM-Encapsulator, MTU: Unlimited, Speed: 800mbps  
 Device flags : Present Running  
 Interface flags: SNMP-Traps

**show interfaces detail  
(PIM Encapsulation)**

user@host> **show interfaces pe-0/0/0 detail**  
 Physical interface: pe-0/0/0, Enabled, Physical link is Up  
 Interface index: 131, SNMP ifIndex: 26, Generation: 12  
 Type: PIME, Link-level type: PIM-Encapsulator, MTU: Unlimited, Speed: 800mbps  
 Hold-times : Up 0 ms, Down 0 ms  
 Device flags : Present Running  
 Interface flags: SNMP-Traps  
 Statistics last cleared: Never  
 Traffic statistics:

Input bytes :	0	0 bps
Output bytes :	0	0 bps
Input packets:	0	0 pps
Output packets:	0	0 pps

**show interfaces  
extensive  
(PIM Encapsulation)**

user@host> **show interfaces pe-0/0/0 extensive**  
 Physical interface: pe-0/0/0, Enabled, Physical link is Up  
 Interface index: 131, SNMP ifIndex: 26, Generation: 12  
 Type: PIME, Link-level type: PIM-Encapsulator, MTU: Unlimited, Speed: 800mbps  
 Hold-times : Up 0 ms, Down 0 ms  
 Device flags : Present Running  
 Interface flags: SNMP-Traps  
 Statistics last cleared: Never  
 Traffic statistics:

Input bytes :	0	0 bps
Output bytes :	0	0 bps
Input packets:	0	0 pps
Output packets:	0	0 pps

## show interfaces (Virtual Loopback Tunnel)

<b>Syntax</b>	<pre>show interfaces vt-fpc/pic/port &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified virtual loopback tunnel interface.
<b>Options</b>	<p><b>vt-fpc/pic/port</b>—Display standard information about the specified virtual loopback tunnel interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index snmp-index</b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces (Virtual Loopback Tunnel) on page 989</a></p> <p><a href="#">show interfaces brief (Virtual Loopback Tunnel) on page 989</a></p> <p><a href="#">show interfaces detail (Virtual Loopback Tunnel) on page 989</a></p> <p><a href="#">show interfaces extensive (Virtual Loopback Tunnel) on page 990</a></p>
<b>Output Fields</b>	<a href="#">Table 156 on page 986</a> lists the output fields for the <b>show interfaces</b> (virtual loopback tunnel) command. Output fields are listed in the approximate order in which they appear.

**Table 156: Virtual Loopback Tunnel show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the "Enabled Field" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>

Table 156: Virtual Loopback Tunnel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed at which the interface is running.	All levels
<b>Hold-times</b>	Current interface hold-time up and hold-time down, in milliseconds.	<b>detail extensive</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Input packets</b>	Number of packets received on the logical interface.	None specified
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified

Table 156: Virtual Loopback Tunnel show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Bandwidth</b>	Bandwidth allotted to the logical interface, in kilobytes per second.	All levels
<b>Traffic statistics</b>	<p>Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Transit statistics</b>	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>MTU</b>	Maximum transmission unit size on the logical interface.	<b>detail extensive none</b>
<b>Maximum labels</b>	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>

## Sample Output

### show interfaces (Virtual Loopback Tunnel)

```
user@host> show interfaces vt-1/2/0
Physical interface: vt-1/2/0, Enabled, Physical link is Up
  Interface index: 144, SNMP ifIndex: 40
  Type: Loopback, Link-level type: Virtual-loopback-tunnel, MTU: Unlimited,
  Speed: 800mbps
  Device flags   : Present Running
  Input rate    : 0 bps (0 pps)
  Output rate   : 0 bps (0 pps)

  Logical interface vt-1/2/0.0 (Index 76) (SNMP ifIndex 57)
    Flags: Point-To-Point 16384 Encapsulation: Virtual-loopback-tunnel
    Input packets : 0
    Output packets: 0
    Protocol inet, MTU: Unlimited
      Flags: None
    Protocol mpls, MTU: Unlimited, Maximum labels: 3
      Flags: None
```

### show interfaces brief (Virtual Loopback Tunnel)

```
user@host> show interfaces vt-1/2/0 brief
Physical interface: vt-1/2/0, Enabled, Physical link is Up
  Type: Loopback, Link-level type: Virtual-loopback-tunnel, MTU: Unlimited,
  Speed: 800mbps
  Device flags   : Present Running

  Logical interface vt-1/2/0.0
    Flags: Point-To-Point 16384 Encapsulation: Virtual-loopback-tunnel
    inet
    mpls
```

### show interfaces detail (Virtual Loopback Tunnel)

```
user@host> show interfaces vt-1/2/0 detail
Physical interface: vt-1/2/0, Enabled, Physical link is Up
  Interface index: 144, SNMP ifIndex: 40, Generation: 27
  Type: Loopback, Link-level type: Virtual-loopback-tunnel, MTU: Unlimited,
  Speed: 800mbps
  Hold-times      : Up 0 ms, Down 0 ms
  Device flags    : Present Running
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   : 0 0 bps
    Output bytes  : 0 0 bps
    Input packets : 0 0 pps
    Output packets: 0 0 pps

  Logical interface vt-1/2/0.0 (Index 76) (SNMP ifIndex 57) (Generation 17)
    Flags: Point-To-Point 16384 Encapsulation: Virtual-loopback-tunnel
    Traffic statistics:
      Input bytes   : 0
      Output bytes  : 0
      Input packets : 0
      Output packets: 0
    Transit statistics:
      Input bytes   : 0 0 bps
      Output bytes  : 0 0 bps
      Input packets : 0 0 pps
      Output packets: 0 0 pps
    Protocol inet, MTU: Unlimited, Generation: 33, Route table: 0
```

```

    Flags: None
    Protocol mpls, MTU: Unlimited, Maximum labels: 3, Generation: 34, Route table:
0
    Flags: None

```

### show interfaces extensive (Virtual Loopback Tunnel)

```

user@host> show interfaces vt-1/2/0 extensive
Physical interface: vt-1/2/0, Enabled, Physical link is Up
Interface index: 144, SNMP ifIndex: 40, Generation: 27
Type: Loopback, Link-level type: Virtual-loopback-tunnel, MTU: Unlimited,
Speed: 800mbps
Hold-times      : Up 0 ms, Down 0 ms
Device flags    : Present Running
Statistics last cleared: Never
Traffic statistics:
Input bytes  :                0                0 bps
Output bytes :                0                0 bps
Input packets:                0                0 pps
Output packets:              0                0 pps

Logical interface vt-1/2/0.0 (Index 76) (SNMP ifIndex 57) (Generation 17)
Flags: Point-To-Point 16384 Encapsulation: Virtual-loopback-tunnel
Traffic statistics:
Input bytes  :                0
Output bytes :                0
Input packets:                0
Output packets:              0
Transit statistics:
Input bytes  :                0                0 bps
Output bytes :                0                0 bps
Input packets:                0                0 pps
Output packets:              0                0 pps
Protocol inet, MTU: Unlimited, Generation: 33, Route table: 0
Flags: None
Protocol mpls, MTU: Unlimited, Maximum labels: 3, Generation: 34, Route table:
0
Flags: None

```



# VoIP Interface Operational Mode Commands

Table 157 on page 991 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot the Avaya TGM550 VoIP module on J2320, J2350, J4350, and J6350 Services Routers. You can also monitor the Telephony Interfaces Modules (TIMs) to a limited extent. Commands are listed in alphabetical order.

**Table 157: VoIP Interface Operational Mode Commands**

Task	Command
Remove the Media Gateway Controller (MGC) list configured on the TGM550 module.	<code>clear tgm fpc</code>
Provide a method for user authentication on the TGM550 modules.	<code>request tgm login fpc</code>
Configure the MGC list on the TGM550 module.	<code>set tgm fpc</code>
Display status information about TGM550 modules.	<code>show interfaces (TGM550 Module)</code>
Display dynamic call admission control (CAC) information.	<code>show tgm dynamic-call-admission-control</code>
Display information about TGM550 module connectivity and digital signal processor (DSP) capacity.	<code>show tgm fpc</code>
Display online and offline status of Avaya VoIP Telephony Interface Modules (TIMs).	<code>show tgm telephony-interface-module status</code>

## clear tgm fpc

---

<b>Syntax</b>	<code>clear tgm fpc <i>slot-number</i> media-gateway-controller</code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.2.
<b>Description</b>	(J4350 and J6350 routers only) Remove the IP addresses of the Media Gateway Controllers (MGCs) configured in the MGC list for the TGM550 VoIP module.
<b>Options</b>	<p><b><i>slot-number</i></b>—FPC slot number in which the TGM550 VoIP module is installed.</p> <p><b><i>media-gateway-controller</i></b>—Remove the MGC list configuration for the TGM550 VoIP module.</p>
<b>Required Privilege Level</b>	maintenance
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">set tgm fpc on page 994</a></li><li>• <a href="#">show tgm fpc on page 1004</a></li></ul>
<b>List of Sample Output</b>	<a href="#">clear tgm fpc on page 992</a>

### Sample Output

`clear tgm fpc`                      `user@host> clear tgm fpc 2 media-gateway-controller`

## request tgm login fpc

---

<b>Syntax</b>	<code>request tgm login fpc <i>slot-number</i> user <i>tgm-user</i></code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.5.
<b>Description</b>	(J2300, J2320, J4350, and J6350 routers only) Provide a self-authenticating method for the user to log in to the TGM550 VoIP module by means of passwords and keys.
<b>Options</b>	<p><i>slot-number</i>—Number of the slot in which the TGM550 VoIP module is installed.</p> <p><i>tgm-user</i>—Username on the TGM550 VoIP module.</p>
<b>Required Privilege Level</b>	maintenance
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show tgm fpc on page 1004</a></li></ul>
<b>List of Sample Output</b>	<a href="#">request tgm login fpc on page 993</a>

## Sample Output

`request tgm login fpc`      `user@host> request tgm login fpc 2 user jnpr`

## set tgm fpc

---

<b>Syntax</b>	<code>set tgm fpc <i>slot-number</i> media-gateway-controller [ <i>ipaddress1 ipaddress2 ipaddress3 ipaddress4</i> ]</code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.2.
<b>Description</b>	(J4350 and J6350 routers only) Configure the Media Gateway Controller (MGC) list for the TGM550 VoIP module.
<b>Options</b>	<p><b><i>slot-number</i></b>—Number of the slot in which the TGM550 VoIP module is installed.</p> <p><b><i>media-gateway-controller</i></b>—Configure the MGC list for the TGM550 VoIP module.</p> <p><b>[ <i>ipaddress1 ipaddress2 ipaddress3 ipaddress4</i> ]</b>—Configure IP addresses of up to four MGCs to connect to and the order in which to reestablish the H.248 link. The first MGC in the list is the primary MGC. The TGM550 VoIP module searches for the primary MGC first. If the TGM550 VoIP module cannot connect to the primary MGC or loses its connection to the primary MGC, it attempts to connect to the next MGC in the list, and so on.</p>
<b>Required Privilege Level</b>	maintenance
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">show tgm fpc on page 1004</a></li></ul>
<b>List of Sample Output</b>	<a href="#">set tgm fpc on page 994</a>

### Sample Output

```
set tgm fpc          user@host> set tgm fpc 2 media-gateway-controller [173.26.232.77 10.10.10.30 10.10.10.40]
```

## show interfaces (TGM550 Module)

<b>Syntax</b>	<pre>show interfaces vp-pim/0/0 &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 8.2.
<b>Description</b>	(J4350 and J6350 routers only) Display status information about the specified TGM550 module.
<b>Options</b>	<p><b>vp-pim/0/0</b>—Display standard information about the specified TGM550 module.</p> <p><b>none</b>—Display standard status information about the TGM550 module.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information about network interfaces.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces (TGM550 Module) on page 1000</a> <a href="#">show interfaces brief (TGM550 Module) on page 1000</a> <a href="#">show interfaces detail (TGM550 Module) on page 1000</a> <a href="#">show interfaces extensive (TGM550 Module) on page 1001</a>
<b>Output Fields</b>	Table 158 on page 995 lists the output fields for the <b>show interfaces (TGM550 Module)</b> command. Output fields are listed in the approximate order in which they appear.

**Table 158: TGM550 Module show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Description</b>	Configured interface description.	All levels

Table 158: TGM550 Module show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b> none
<b>Type</b>	Type of interface.	<b>detail extensive</b> none
<b>Link-level type</b>	Encapsulation being used on the physical interface— <b>VP-AV</b> .	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Speed</b>	Speed in megabits per second (mbps) at which the interface is running.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Link type</b>	Physical interface link type: <b>Full-Duplex</b> or <b>Half-Duplex</b> .	<b>detail extensive</b> none
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	All levels
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive</b>
<b>CoS queues</b>	Number of CoS queues configured.	<b>detail extensive</b> none
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive</b> none
<b>Input Rate</b>	Input rate in bits per second (bps) and packets per second (pps).	None specified
<b>Output Rate</b>	Output rate in bps and pps.	None specified
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>
<b>Traffic statistics</b>	Statistics for traffic on the interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>	<b>detail extensive</b>

Table 158: TGM550 Module show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Input errors</b>	<p>Input errors on the interface:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and frame check sequence (FCS) errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's random early detection (RED) mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and up, or another problem occurs. If the number of carrier transitions increments quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If it increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Egress queues</b>	Total number of egress queues supported on the specified interface.	<b>detail extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Packet Forwarding Engine configuration</b>	<p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> </ul>	<b>extensive</b>

Table 158: TGM550 Module show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b><i>protocol-family</i></b>	Protocol family configured on the logical interface. If the protocol is <b>inet</b> , the IP address of the interface is also displayed.	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	<b>detail extensive none</b>



Table 158: TGM550 Module show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address.	<b>detail extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces (TGM550 Module)

```
user@host> show interfaces vp-2/0/0
Physical interface: vp-2/0/0, Enabled, Physical link is Up
  Interface index: 145, SNMP ifIndex: 21
  Type: VP-AV, Link-level type: VP-AV, MTU: 1518, Speed: 10mbps
  Device flags   : Present Running
  Link type      : Full-Duplex
  Link flags     : None
  CoS queues     : 8 supported, 8 maximum usable queues
  Last flapped   : 2006-10-30 10:03:37 UTC (07:26:46 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

Logical interface vp-2/0/0.0 (Index 73) (SNMP ifIndex 47)
  Flags: Point-To-Point SNMP-Traps Encapsulation: VP-AV
  Protocol inet, MTU: 1500
  Flags: None
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 31.31.31.20, Local: 33.33.33.1
```

### show interfaces brief (TGM550 Module)

```
user@host> show interfaces vp-2/0/0 brief
Physical interface: vp-2/0/0, Enabled, Physical link is Up
  Type: VP-AV, Link-level type: VP-AV, MTU: 1518, Speed: 10mbps
  Device flags   : Present Running

Logical interface vp-2/0/0.0
  Flags: Point-To-Point SNMP-Traps Encapsulation: VP-AV
  inet 33.33.33.1    --> 31.31.31.20
```

### show interfaces detail (TGM550 Module)

```
user@host> show interfaces vp-2/0/0 detail
Physical interface: vp-2/0/0, Enabled, Physical link is Up
  Interface index: 145, SNMP ifIndex: 21, Generation: 147
  Type: VP-AV, Link-level type: VP-AV, MTU: 1518, Speed: 10mbps
  Device flags   : Present Running
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  CoS queues     : 8 supported, 8 maximum usable queues
  Last flapped   : 2006-10-30 10:03:37 UTC (07:31:33 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes :          537968          0 bps
    Output bytes :          448102          0 bps
    Input packets:           6750          0 pps
    Output packets:          5141          0 pps
  Egress queues: 8 supported, 8 in use
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort          5141             5141             0
    1 expedited-fo           0              0              0
    2 assured-forw          0              0              0
    3 network-cont          0              0              0
```

```

Logical interface vp-2/0/0.0 (Index 73) (SNMP ifIndex 47) (Generation 142)
Flags: Point-To-Point SNMP-Traps Encapsulation: VP-AV
Protocol inet, MTU: 1500, Generation: 147, Route table: 0
Flags: None
Filters: Input: pcap, Output: pcap
Addresses, Flags: Is-Preferred Is-Primary
Destination: 31.31.31.20, Local: 33.33.33.1, Broadcast: Unspecified,
Generation: 154

```

### show interfaces extensive (TGM550 Module)

```

user@host> show interfaces vp-2/0/0 extensive
Physical interface: vp-2/0/0, Enabled, Physical link is Up
Interface index: 145, SNMP ifIndex: 21, Generation: 147
Type: VP-AV, Link-level type: VP-AV, MTU: 1518, Speed: 10mbps
Device flags   : Present Running
Link type      : Full-Duplex
Link flags     : None
Physical info   : Unspecified
CoS queues     : 8 supported, 8 maximum usable queues
Last flapped   : 2006-10-30 10:03:37 UTC (07:32:49 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          539206          0 bps
Output bytes  :          448993          0 bps
Input packets :          6764          0 pps
Output packets:          5150          0 pps
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Policed discards: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
Resource errors: 0
Egress queues: 8 supported, 8 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort          5150             5150             0

  1 expedited-fo           0             0             0

  2 assured-forw          0             0             0

  3 network-cont          0             0             0

Packet Forwarding Engine configuration:
Destination slot: 2
CoS information:
Direction : Output
CoS transmit queue      Bandwidth      Buffer Priority
Limit
          %      bps      %      usec      low
  0 best-effort      95      9500000      95      0
none
  3 network-control   5       500000      5       0
none

```

```

Logical interface vp-2/0/0.0 (Index 73) (SNMP ifIndex 47) (Generation 142)
Flags: Point-To-Point SNMP-Traps Encapsulation: VP-AV
Protocol inet, MTU: 1500, Generation: 147, Route table: 0
Flags: None
Filters: Input: pcap, Output: pcap
Addresses, Flags: Is-Preferred Is-Primary
Destination: 31.31.31.20, Local: 33.33.33.1, Broadcast: Unspecified,

```

Generation: 154

## show tgm dynamic-call-admission-control

<b>Syntax</b>	show tgm dynamic-call-admission-control
<b>Release Information</b>	Command introduced in Junos OS Release 8.2.
<b>Description</b>	(J4350 and J6350 routers only) Display dynamic call admission control (CAC) information.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show tgm dynamic-call-admission-control on page 1003</a>
<b>Output Fields</b>	<a href="#">Table 159 on page 1003</a> lists the output fields for the <b>show tgm dynamic-call-admission-control</b> command. Output fields are listed in the approximate order in which they appear.

Table 159: show tgm dynamic-call-admission-control Output Fields

Field Name	Field Description
<b>Reported bearer bandwidth limit</b>	<p>If dynamic CAC is configured on more than one active interface, the TGM550 VoIP module reports the bearer bandwidth limit (BBL) of the active interface with the highest activation priority.</p> <p>If more than one active interface has the same activation priority, the BBL is reported as the number of those interfaces times their lowest BBL. For example if two interfaces with the same activation priority have BBLs of 2000 Kbps and 1500 Kbps, the reported BBL is 3000 Kbps (2 x 1500 Kbps).</p>
<b>Interface</b>	Name of interface on which dynamic CAC is configured.
<b>State</b>	<p>Link state of the interface: <b>Up</b> or <b>Down</b>.</p> <p>The operational state is the physical state of the interface. If the interface is physically operational, even if it is not configured, the operational state is Up. An operational state of Down indicates a problem with the physical interface.</p>
<b>Activation priority</b>	Activation priority configured on the interface.
<b>Bearer bandwidth limit (Kbps)</b>	Maximum bandwidth available for voice traffic on the interface.

## Sample Output

```

show tgm dynamic-call-admission-control
user@host> show tgm dynamic-call-admission-control
Reported bearer bandwidth limit: 3000 Kbps
Interface      State      Activation priority  Bearer bandwidth limit (Kbps)
ge-0/0/3.0    up         200                 3000
t1-6/0/0.0    up         150                 1000

```

## show tgm fpc

<b>Syntax</b>	<code>show tgm fpc <i>slot-number</i> (media-gateway-controller   dsp-capacity)</code>
<b>Release Information</b>	Command extended in Junos OS Release 8.5.
<b>Description</b>	(J2320, J2300, J4350, and J6350 routers only) Display information about TGM550 VoIP module connectivity and digital signal processor (DSP) capacity.
<b>Options</b>	<p><b><i>slot-number</i></b>—Number of the slot in which the TGM550 VoIP module is installed.</p> <p><b><i>media-gateway-controller</i></b>—Display IP addresses of the Media Gateway Controllers (MGCs) configured in the MGC list for the TGM550 VoIP module.</p> <p><b><i>dsp-capacity</i></b>—Display the number of voice channels available on the TGM550 VoIP module.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">set tgm fpc on page 994</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show tgm fpc 2 media-gateway-controller on page 1005</a> <a href="#">show tgm fpc 3 dsp-capacity on page 1005</a>
<b>Output Fields</b>	<a href="#">Table 160 on page 1004</a> lists the output fields for the <b>show tgm fpc</b> command. Output fields are listed in the approximate order in which they appear.

**Table 160: show tgm fpc Output Fields**

Field Name	Field Description
Media gateway controller(s)	<p>Displays the IP addresses of the Media Gateway Controllers (MGCs) configured in the MGC list for the TGM550 VoIP module.</p> <p>The first MGC in the list is the primary MGC. The TGM550 VoIP module searches for the primary MGC first. If it cannot connect to the primary MGC or loses its connection to the primary MGC, it attempts to connect to the next MGC in the list, and so on.</p>
DSP Capacity	Displays the DSP capacity of the TGM VoIP module board in terms of the number of voice channels supported.

## Sample Output

```
show tgm fpc 2          user@host> show tgm fpc 2 media-gateway-controller
media-gateway-controller Media gateway controller(s): 173.26.232.77
                                     10.10.10.30
                                     10.10.10.40
```

```
show tgm fpc 3          root> Show tgm fpc 3 dsp-capacity
dsp-capacity            DSP Capacity:20 voice channels.
```

## show tgm telephony-interface-module status

<b>Syntax</b>	show tgm telephony-interface-module status
<b>Release Information</b>	Command extended in Junos OS Release 8.5.
<b>Description</b>	(J2320, J2300, J4350, and J6350 routers only) Display the online and offline status of the Telephony Interface Modules installed in a J Series router.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show tgm telephony-interface-module on page 1006</a>
<b>Output Fields</b>	<a href="#">Table 161 on page 1006</a> lists the output fields for the <b>show tgm telephony-interface-module status</b> command. Output fields are listed in the approximate order in which they appear.

**Table 161: show tgm telephony-interface-module status Output Fields**

Field Name	Field Description
Slot State	Status of the TIM, either online or offline.
Offline Reason	Explanation for the offline state: <ul style="list-style-type: none"> <li>• Busy out</li> <li>• Out of resources</li> </ul>

## Sample Output

```

show tgm
telephony-interface-module

user@host> show tgm telephony-interface-module status
Slot State  Offline Reason
1           Offline   Busy out
2           Online
5           Online
6           Online

```



## PART 12

# Management Interfaces

- [Discard Interface Operational Mode Commands on page 1009](#)
- [Loopback Interface Operational Mode Commands on page 1017](#)
- [Management Ethernet and Internal Ethernet Interface Operational Mode Commands on page 1027](#)



# Discard Interface Operational Mode Commands

Table 162 on page 1009 summarizes the command-line interface (CLI) command that you can use to monitor and troubleshoot the discard (**dsc**) interface.

**Table 162: Discard Interface Operational Mode Commands**

Task	Command
Monitor the discard interface.	<a href="#">show interfaces (Discard)</a>

The discard interface is not a physical interface, but a virtual interface that discards packets. You can configure one discard interface. The discard interface allows you to identify the ingress point of a denial-of-service (DoS) attack. When your network is under attack, the target host IP address is identified, and the local policy forwards attacking packets to the discard interface. Traffic routed out of the discard interface is silently discarded.

If an output filter is attached to the interface, the action specified by the filter causes the packets to be logged or counted before the traffic is discarded. For a complete discussion about using the discard interface to protect your network against DoS attacks, see the *Junos Policy Framework Configuration Guide*.

Statistics and media displayed by the **show interfaces** command are not relevant for the discard interface and always show values of 0.

## show interfaces (Discard)

<b>Syntax</b>	<pre>show interfaces dsc &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	Display status information about the specified discard interface.
<b>Options</b>	<p><b>dsc</b>—Display standard information about the specified discard interface.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—This option is not relevant for the discard interface and always shows a value of 0.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) This option is not relevant for the discard interface and always shows a value of 0.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">show interfaces (ATM) on page 638</a></li> <li>• <a href="#">show interfaces routing on page 108</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces dsc on page 1014</a> <a href="#">show interfaces dsc brief on page 1014</a> <a href="#">show interfaces dsc detail on page 1014</a> <a href="#">show interfaces dsc extensive on page 1014</a>
<b>Output Fields</b>	Table 163 on page 1010 lists the output fields for the <b>show interfaces</b> (discard) command. Output fields are listed in the approximate order in which they appear.

Table 163: Discard show interfaces Output Fields

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface, whether the interface is enabled, and the state of the physical interface: <b>Up</b> or <b>Down</b> .	All levels
<b>Interface index</b>	Physical interface's index number, which reflects its initialization sequence.	<b>detail extensive none</b>

Table 163: Discard show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Type</b>	Type of interface. <b>Software-Pseudo</b> indicates a standard software interface with no associated hardware device.	All levels
<b>Link-level type</b>	Encapsulation being used on the physical interface.	All levels
<b>MTU</b>	MTU size on the physical interface.	All levels
<b>Clocking</b>	Reference clock source. It can be <b>Internal</b> or <b>External</b> .	<b>brief detail extensive</b>
<b>Speed</b>	Speed at which the interface is running.	<b>brief detail extensive</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link type</b>	Encapsulation being used on the physical interface.	<b>detail extensive</b>
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive</b>
<b>Current address, Hardware address</b>	Configured MAC address and hardware MAC address.	<b>detail extensive</b>
<b>Alternate link address</b>	Backup address of the link.	<b>detail extensive</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	<b>detail extensive none</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 163: Discard show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<p>Input errors on the interface:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>detail extensive</b>
<b>Output errors</b>	<p>(Extensive only) Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>detail extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

Table 163: Discard show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Flags</b>	Information about the logical interface. Possible values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	All levels
<b>Protocol</b>	Protocol family configured on the logical interface, such as <b>iso</b> , <b>inet6</b> , or <b>mpls</b> .	All levels
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Routing table in which the logical interface address is located. For example, <b>0</b> refers to the routing table <b>inet.0</b> .	<b>detail extensive</b>

## Sample Output

### show interfaces dsc

```
user@host> show interfaces dsc
Physical interface: dsc, Enabled, Physical link is Up
  Interface index: 5, SNMP ifIndex: 5
  Type: Software-Pseudo, MTU: Unlimited
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link flags     : None
  Last flapped   : Never
    Input packets : 0
    Output packets: 0

Logical interface dsc.0 (Index 66) (SNMP ifIndex 235)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Unspecified
  Protocol inet, MTU: Unlimited
  Flags: None
```

### show interfaces dsc brief

```
user@host> show interfaces dsc brief
Physical interface: dsc, Enabled, Physical link is Up
  Type: Software-Pseudo, Link-level type: Unspecified, MTU: Unlimited, Clocking:
Unspecified, Speed: Unspecified
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps

Logical interface dsc.0
  Flags: Point-To-Point SNMP-Traps Encapsulation: Unspecified
  inet
```

### show interfaces dsc detail

```
user@host> show interfaces dsc detail
Physical interface: dsc, Enabled, Physical link is Up
  Interface index: 5, SNMP ifIndex: 5, Generation: 9
  Type: Software-Pseudo, Link-level type: Unspecified, MTU: Unlimited, Clocking:
Unspecified, Speed: Unspecified
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps
  Link type      : Unspecified
  Link flags     : None
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : Never
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes  : 0
    Output bytes : 0
    Input packets: 0
    Output packets: 0

Logical interface dsc.0 (Index 66) (SNMP ifIndex 235) (Generation 6)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Unspecified
  Protocol inet, MTU: Unlimited, Generation: 14, Route table: 0
  Flags: None
```

### show interfaces dsc

```
user@host> show interfaces dsc extensive
Physical interface: dsc, Enabled, Physical link is Up
```



## extensive

```

Interface index: 5, SNMP ifIndex: 5, Generation: 9
Type: Software-Pseudo, Link-level type: Unspecified, MTU: Unlimited, Clocking:
Unspecified, Speed: Unspecified
Device flags   : Present Running
Interface flags: Point-To-Point SNMP-Traps
Link type      : Unspecified
Link flags     : None
Physical info  : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: Unspecified, Hardware address: Unspecified
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
  Input bytes   : 0
  Output bytes  : 0
  Input packets: 0
  Output packets: 0
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
  Resource errors: 0
Logical interface dsc.0 (Index 66) (SNMP ifIndex 235) (Generation 6)
  Flags: Point-To-Point SNMP-Traps Encapsulation: Unspecified
  Protocol inet, MTU: Unlimited, Generation: 14, Route table: 0

```



# Loopback Interface Operational Mode Commands

Table 164 on page 1017 summarizes the command-line interface (CLI) command that you can use to monitor and troubleshoot the local loopback interface (lo0).

**Table 164: Loopback Interface Operational Mode Command**

Task	Command
Monitor the loopback interface.	<a href="#">show interfaces (Loopback)</a>

The Junos OS automatically configures one local loopback interface (lo0), choosing the first interface to come online as the default. You can also configure the loopback interface and one or more addresses on the interface. If you configure the loopback interface, it is automatically used for unnumbered interfaces.

A local loopback loops packets, including both data and timing information, back on the local Physical Interface Card (PIC) or Physical Interface Module (PIM). When you configure a local loopback, the interface transmits packets to the channel services unit (CSU) built into the interface. These packets are transmitted onto the circuit toward the far-end device. The PIC or PIM receives back its own transmission and ignores any data sent from the physical circuit and the CSU.

To test a local loopback, issue the **show interfaces *interface-name*** command. If PPP keepalives transmitted on the interface are received by the PIC or PIM, the **Device Flags** field contains the output **Loop-Detected**.

For more information about using the loopback interface to monitor and troubleshoot various interface types, see the *Junos Interfaces Network Operations Guide*.

## show interfaces (Loopback)

**Syntax**    `show interfaces lo0`  
               `<brief | detail | extensive | terse>`  
               `<descriptions>`  
               `<media>`  
               `<snmp-index snmp-index>`  
               `<statistics>`

**Release Information**    Command introduced before Junos OS Release 7.4.

**Description**    Display status information about the local loopback interface.



**NOTE:** Logical interface lo0.16385 is the loopback interface for the internal routing instance. Created by the internal routing service process, this interface facilitates internal traffic. It prevents any filter created on loopback lo0.0 from blocking internal traffic.

**Options**    **lo0**—Display standard status information about the local loopback interface.

**brief | detail | extensive | terse**—(Optional) Display the specified level of output.

**descriptions**—(Optional) Display interface description strings.

**media**—(Optional) Display media-specific information.

**snmp-index *snmp-index***—(Optional) Display information for the specified SNMP index of the interface.

**statistics**—(Optional) Display static interface statistics.

**Required Privilege Level**    view

**List of Sample Output**    [show interfaces \(Loopback\) on page 1022](#)  
                                   [show interfaces brief \(Loopback\) on page 1022](#)  
                                   [show interfaces detail \(Loopback\) on page 1022](#)  
                                   [show interfaces extensive \(Loopback\) on page 1023](#)

**Output Fields**    [Table 165 on page 1018](#) lists the output fields for the **show interfaces** (loopback) command. Output fields are listed in the approximate order in which they appear.

**Table 165: Loopback show interfaces Output Fields**

Field Name	Field Description	Level of Output
Physical Interface		
Physical Interface	Name of the physical interface.	All levels

Table 165: Loopback show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation type used on the physical interface.	All levels
<b>MTU</b>	Size of the largest packet to be transmitted.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	All levels
<b>Link type</b>	Data transmission type.	<b>detail extensive</b>
<b>Link flags</b>	Information about the link. Possible values are described in the “Link Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Physical info</b>	Information about the physical interface.	<b>detail extensive</b>
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	<b>detail extensive</b>
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b>
<b>Hardware address</b>	Media access control (MAC) address of the interface.	<b>detail extensive</b>
<b>Alternate link address</b>	Backup link address.	<b>detail extensive</b>
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago).	<b>detail extensive</b>
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	<b>detail extensive</b>

Table 165: Loopback show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed Discards</b>—Frames that the incoming packet match code discarded because the frames were not recognized or were not of interest. Usually, this field reports protocols that Junos does not support.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface; values are described in the "Logical Interface Flags" section under " <a href="#">Common Output Fields Description</a> " on page 141.	<b>brief detail extensive</b>
<b>Encapsulation</b>	Encapsulation on the logical interface.	<b>brief detail extensive</b>
<b>Input packets</b>	Number of packets received on the logical interface.	None specified

Table 165: Loopback show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output packets</b>	Number of packets transmitted on the logical interface.	None specified
<b>Traffic statistics</b>	Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Local statistics</b>	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	<b>detail extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface (such as <b>iso</b> or <b>inet6</b> ).	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Route table in which this address exists; for example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about the address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>
<b>Broadcast</b>	Broadcast address on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces (Loopback)

```
user@host> show interfaces lo0
Physical interface: lo0, Enabled, Physical link is Up
  Interface index: 6, SNMP ifIndex: 6
  Type: Loopback, MTU: Unlimited
  Device flags   : Present Running Loopback
  Interface flags: SNMP-Traps
  Link flags     : None
  Last flapped   : Never
    Input packets : 0
    Output packets: 0

Logical interface lo0.0 (Index 64) (SNMP ifIndex 16)
  Flags: SNMP-Traps Encapsulation: Unspecified
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: Unlimited
    Flags: None
    Addresses, Flags: Is-Default Is-Primary
      Local: 10.0.0.1
    Addresses
      Local: 127.0.0.1
  Protocol iso, MTU: Unlimited
    Flags: None
    Addresses, Flags: Is-Default Is-Primary
      Local: 49.0004.1000.0000.0001

Logical interface lo0.16385 (Index 65) (SNMP ifIndex 76)
  Flags: SNMP-Traps Encapsulation: Unspecified
  Input packets : 0
  Output packets: 0
  Protocol inet, MTU: Unlimited
    Flags: None
```

### show interfaces brief (Loopback)

```
user@host> show interfaces lo0 brief
Physical interface: lo0, Enabled, Physical link is Up
  Type: Loopback, Link-level type: Unspecified, MTU: Unlimited,
  Clocking: Unspecified, Speed: Unspecified
  Device flags   : Present Running Loopback
  Interface flags: SNMP-Traps

Logical interface lo0.0
  Flags: SNMP-Traps Encapsulation: Unspecified
  inet  10.0.0.1          --> 0/0
       127.0.0.1         --> 0/0
  iso   49.0004.1000.0000.0001

Logical interface lo0.16385
  Flags: SNMP-Traps Encapsulation: Unspecified
  inet
```

### show interfaces detail (Loopback)

```
user@host> show interfaces lo0 detail
Physical interface: lo0, Enabled, Physical link is Up
  Interface index: 6, SNMP ifIndex: 6, Generation: 4
  Type: Loopback, Link-level type: Unspecified, MTU: Unlimited,
  Clocking: Unspecified, Speed: Unspecified
  Device flags   : Present Running Loopback
```



```

Interface flags: SNMP-Traps
Link type      : Unspecified
Link flags     : None
Physical info  : Unspecified
Hold-times    : Up 0 ms, Down 0 ms
Current address: Unspecified, Hardware address: Unspecified
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Logical interface lo0.0 (Index 64) (SNMP ifIndex 16) (Generation 3)
Flags: SNMP-Traps Encapsulation: Unspecified
Traffic statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Local statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0

Protocol inet, MTU: Unlimited, Generation: 10, Route table: 0
Flags: None
Addresses, Flags: Is-Default Is-Primary
Destination: Unspecified, Local: 10.0.0.1, Broadcast: Unspecified,
Generation: 10
Addresses, Flags: None
Destination: Unspecified, Local: 127.0.0.1, Broadcast: Unspecified,
Generation: 12
Protocol iso, MTU: Unlimited, Generation: 11, Route table: 0
Flags: None
Addresses, Flags: Is-Default Is-Primary
Destination: Unspecified, Local: 49.0004.1000.0000.0001,
Broadcast: Unspecified, Generation: 14

Logical interface lo0.16385 (Index 65) (SNMP ifIndex 76) (Generation 4)
Flags: SNMP-Traps Encapsulation: Unspecified
Traffic statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Local statistics:
Input bytes   : 0
Output bytes  : 0
Input packets : 0
Output packets: 0
Protocol inet, MTU: Unlimited, Generation: 12, Route table: 1
Flags: None

```

**show interfaces  
extensive (Loopback)**

```

user@host> show interfaces lo0 extensive
Physical interface: lo0, Enabled, Physical link is Up
Interface index: 6, SNMP ifIndex: 6, Generation: 4
Type: Loopback, Link-level type: Unspecified, MTU: Unlimited,

```

Clocking: Unspecified, Speed: Unspecified  
Device flags : Present Running Loopback  
Interface flags: SNMP-Traps  
Link type : Unspecified  
Link flags : None  
Physical info : Unspecified  
Hold-times : Up 0 ms, Down 0 ms  
Current address: Unspecified, Hardware address: Unspecified  
Alternate link address: Unspecified  
Last flapped : Never  
Statistics last cleared: Never  
Traffic statistics:  
Input bytes : 0  
Output bytes : 0  
Input packets: 0  
Output packets: 0  
Input errors:  
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,  
Policed discards: 0, Resource errors: 0  
Output errors:  
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,  
Resource errors: 0

Logical interface lo0.0 (Index 64) (SNMP ifIndex 16) (Generation 3)

Flags: SNMP-Traps Encapsulation: Unspecified  
Traffic statistics:  
Input bytes : 0  
Output bytes : 0  
Input packets: 0  
Output packets: 0  
Local statistics:  
Input bytes : 0  
Output bytes : 0  
Input packets: 0  
Output packets: 0  
Protocol inet, MTU: Unlimited, Generation: 10, Route table: 0  
Flags: None  
Addresses, Flags: Is-Default Is-Primary  
Destination: Unspecified, Local: 10.0.0.1, Broadcast: Unspecified,  
Generation: 10  
Addresses, Flags: None  
Destination: Unspecified, Local: 127.0.0.1, Broadcast: Unspecified,  
Generation: 12  
Protocol iso, MTU: Unlimited, Generation: 11, Route table: 0  
Flags: None  
Addresses, Flags: Is-Default Is-Primary  
Destination: Unspecified, Local: 49.0004.1000.0000.0001,  
Broadcast: Unspecified, Generation: 14

Logical interface lo0.16385 (Index 65) (SNMP ifIndex 76) (Generation 4)

Flags: SNMP-Traps Encapsulation: Unspecified  
Traffic statistics:  
Input bytes : 0  
Output bytes : 0  
Input packets: 0  
Output packets: 0  
Local statistics:  
Input bytes : 0  
Output bytes : 0  
Input packets: 0  
Output packets: 0

Protocol inet, MTU: Unlimited, Generation: 12, Route table: 1  
Flags: None



# Management Ethernet and Internal Ethernet Interface Operational Mode Commands

Table 166 on page 1027 summarizes the command-line interface (CLI) commands that you can use to monitor and troubleshoot the management Ethernet interface and, in the case of M Series and T Series routers, the internal Ethernet interface.

**Table 166: Management Ethernet and Internal Ethernet Interface Operational Mode Commands**

Task	Command
Monitor the M Series and T Series router management Ethernet and internal Ethernet interfaces.	<a href="#">show interfaces (M Series and T Series Routers, and PTX Series Packet Transport Switches Management and Internal Ethernet)</a>
Monitor the J Series router management Ethernet interface.	<a href="#">show interfaces (J Series Router Management Ethernet)</a>

On the M Series and T Series routers other than the TX Matrix Plus router and T1600 routers in a routing matrix, the Junos OS automatically creates the router's management Ethernet interface, **fxp0**, which is an out-of-band management interface for connecting to the router, and the internal Ethernet interface, **fxp1**, which connects the Routing Engine to the Packet Forwarding Engine. If the platform has redundant Routing Engines, another internal Ethernet interface, **fxp2**, is created to connect the second Routing Engine (**re1**) to the Packet Forwarding Engine.

On TX Matrix Plus Routers and T1600 routers configured in a routing matrix, the Junos OS automatically creates the router's management Ethernet interface, **em0**. To use **em0** as a management port, you must configure its logical port, **em0.0**, with a valid IP address.

On a TX Matrix Plus router, the Routing Engine (RE-TXP-SFC) and Control Board (TXP-CB) function as a unit, or host subsystem. For each host subsystem in the router, the Junos OS automatically creates two internal Ethernet interfaces, **ixgbe0** and **ixgbe1**, for the two 10-Gigabit Ethernet ports on the Routing Engine.

For more information about the management Ethernet interface and internal Ethernet interfaces on a TX Matrix Plus router and T1600 routers configured in a routing matrix, see the *Junos Network Interfaces Configuration Guide*.

On J Series routers, the Junos OS automatically creates the router's management Ethernet interface, **fe-0/0/0**, which is an out-of-band management interface for connecting to the router.

## show interfaces (M Series and T Series Routers, and PTX Series Packet Transport Switches Management and Internal Ethernet)

<b>Syntax</b>	<pre>show interfaces <i>interface-name</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index <i>snmp-index</i>&gt; &lt;statistics&gt;</pre>
<b>Syntax (PTX Series Packet Transport Switches)</b>	<pre>show interfaces <i>interface-name</i> &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;statistics&gt;</pre>
<b>Release Information</b>	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced on PTX Series Packet Transport Switches for Junos OS Release 12.1.</p>
<b>Description</b>	(M Series, T Series, TX Matrix Plus, and PTX Series devices only) Display status information about the management Ethernet and internal Ethernet interfaces.
<b>Options</b>	<p><b>interface-name</b>—Specify one of the following management interface names: fxp0, fxp1, fxp2, ixgbe0, ixgbe1, bcm0, em0, or em1. For supported Ethernet interface by chassis and Routing Engine, see Supported Routing Engines by Chassis.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<p><a href="#">show interfaces brief (Management Ethernet) on page 1033</a></p> <p><a href="#">show interfaces (Management Ethernet) on page 1033</a></p> <p><a href="#">show interfaces (Management Ethernet [TX Matrix Plus Router]) on page 1033</a></p> <p><a href="#">show interfaces (Management Ethernet [PTX Series Packet Transport Switches]) on page 1034</a></p> <p><a href="#">show interfaces detail (Management Ethernet) on page 1035</a></p> <p><a href="#">show interfaces detail (Management Ethernet [TX Matrix Plus Router]) on page 1035</a></p> <p><a href="#">show interfaces detail (Management Ethernet [PTX Packet Transport Switches]) on page 1036</a></p> <p><a href="#">show interfaces extensive (Management Ethernet) on page 1037</a></p> <p><a href="#">show interfaces extensive (Management Ethernet [TX Matrix Plus Router]) on page 1038</a></p>

[show interfaces extensive \(Management Ethernet \[PTX Series Packet Transport Switches\]\) on page 1039](#)  
[show interfaces brief \(Management Ethernet\) on page 1040](#)  
[show interfaces brief \(Management Ethernet \[TX Matrix Plus Router\]\) on page 1040](#)  
[show interfaces brief \(Management Ethernet \[PTX Series Packet Transport Switches\]\) on page 1041](#)  
[show interfaces \(Internal Ethernet\) on page 1042](#)  
[show interfaces \(Internal Ethernet \[TX Matrix Plus Router\]\) on page 1042](#)  
[show interfaces detail \(Internal Ethernet\) on page 1043](#)  
[show interfaces detail \(Internal Ethernet \[TX Matrix Plus Router\]\) on page 1043](#)  
[show interfaces extensive \(internal Ethernet\) on page 1044](#)  
[show interfaces extensive \(internal Ethernet \[TX Matrix Plus Router\]\) on page 1045](#)

**Output Fields** Table 167 on page 1030 lists the output fields for the **show interfaces** (management) command on the M Series routers, T Series routers, TX Matrix Plus routers, and PTX Series Packet Transport Switches. Output fields are listed in the approximate order in which they appear.

**Table 167: M Series and T Series Router Management and Internal Ethernet show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Type</b>	Type of interface.	All levels
<b>Link-level type</b>	Encapsulation type used on the physical interface.	All levels
<b>MTU</b>	Maximum transmission unit (MTU)—Size of the largest packet to be transmitted.	All levels
<b>Clocking</b>	Reference clock source of the interface.	All levels
<b>Speed</b>	Network speed on the interface.	All levels
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Interface flags</b>	Information about the interface. Possible values are described in the “Interface Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels



Table 167: M Series and T Series Router Management and Internal Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
Link type	Data transmission type.	detail extensive none
Link flags	Information about the link. Possible values are described in the “Link Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	detail extensive
Physical info	Information about the physical interface.	detail extensive
Hold-times	Current interface hold-time up and hold-time down. Value is in milliseconds.	detail extensive
Current address	Configured MAC address.	detail extensive none
Hardware address	Media access control (MAC) address of the interface.	detail extensive none
Alternate link address	Backup link address.	detail extensive
Last flapped	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	detail extensive none
Input packets	Number of packets received on the physical interface.	None specified
Output packets	Number of packets transmitted on the physical interface.	None specified
Statistics last cleared	Time when the statistics for the interface were last set to zero.	detail extensive
Traffic statistics	<p>Number and rate of bytes and packets received and transmitted on the logical and physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	detail extensive
Input errors	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Giants</b>—Frames received larger than the giant threshold.</li> <li>• <b>Policed Discards</b>—Frames that the incoming packet match code discarded because they were not recognized or were not of interest. Usually, this field reports protocols that Junos does not support.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	extensive

Table 167: M Series and T Series Router Management and Internal Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	<b>detail extensive none</b>
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Flags</b>	Information about the logical interface; values are described in the “Device Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels
<b>Encapsulation</b>	Encapsulation on the logical interface.	<b>detail extensive none</b>
<b>inet</b>	IP address of the logical interface.	<b>brief</b>
<b>Protocol</b>	Protocol family configured on the logical interface (such as <b>iso</b> or <b>inet6</b> ).	<b>detail extensive none</b>
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route table</b>	Route table in which this address exists. For example, <b>Route table:0</b> refers to inet.0.	<b>detail extensive</b>
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	<b>detail extensive none</b>
<b>Addresses, Flags</b>	Information about address flags. Possible values are described in the “Addresses Flags” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	<b>detail extensive none</b>
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive none</b>
<b>Local</b>	IP address of the logical interface.	<b>detail extensive none</b>

Table 167: M Series and T Series Router Management and Internal Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Broadcast</b>	Broadcast address.	<b>detail extensive none</b>
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces brief (Management Ethernet)

```
user@host> show interfaces fxp0 brief
Physical interface: fxp0, Enabled, Physical link is Up
  Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
  Speed: 100mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps

Logical interface fxp0.0
  Flags: SNMP-Traps Encapsulation: ENET2
  inet 192.168.70.143/21
```

### show interfaces (Management Ethernet)

```
user@host> show interfaces fxp0
Physical interface: fxp0, Enabled, Physical link is Up
  Interface index: 1, SNMP ifIndex: 1
  Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Speed: 100mbps
  Device flags   : Present Running
  Interface flags: SNMP-Traps
  Link type      : Half-Duplex
  Current address: 00:a0:a5:56:01:89, Hardware address: 00:a0:a5:56:01:89
  Last flapped   : Never
    Input packets : 80804
    Output packets: 1105

Logical interface fxp0.0 (Index 2) (SNMP ifIndex 13)
  Flags: SNMP-Traps Encapsulation: ENET2
  Protocol inet, MTU: 1500
    Flags: Is-Primary
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 192.168.64/21, Local: 192.168.70.143,
      Broadcast: 192.168.71.255
```

### show interfaces (Management)

```
user@host> show interfaces em0
Physical interface: em0, Enabled, Physical link is Up
  Interface index: 8, SNMP ifIndex: 17
```

## Ethernet [TX Matrix Plus Router])

```
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Speed: 100mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Current address: 00:80:f9:26:00:c0, Hardware address: 00:80:f9:26:00:c0
Last flapped   : Never
  Input packets : 1424
  Output packets: 5282
```

```
Logical interface em0.0 (Index 3) (SNMP ifIndex 18)
  Flags: SNMP-Traps Encapsulation: ENET2
  Input packets : 1424
  Output packets: 5282
  Protocol inet, MTU: 1500
    Flags: Is-Primary
    Addresses, Flags: Is-Preferred Is-Primary
      Destination: 192.168.178.0/25, Local: 192.168.178.11, Broadcast:
192.168.178.127
```

## show interfaces (Management Ethernet [PTX Series

```
user@host> show interfaces em0
Physical interface: em0, Enabled, Physical link is Up
  Interface index: 8, SNMP ifIndex: 0
  Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps
```

**Packet Transport  
Switches])**

```

Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Current address: 00:80:f9:25:00:1b, Hardware address: 00:80:f9:25:00:1b
Last flapped   : Never
Input packets  : 212581
Output packets : 71

```

```

Logical interface em0.0 (Index 3) (SNMP ifIndex 0)
Flags: SNMP-Traps Encapsulation: ENET2
Input packets : 212551
Output packets : 71
Protocol inet, MTU: 1500
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: 192.168.3/24, Local: 192.168.3.30,
Broadcast: 192.168.3.255

```

**show interfaces detail  
(Management  
Ethernet)**

```

user@host> show interfaces fxp0 detail
Physical interface: fxp0, Enabled, Physical link is Up
Interface index: 1, SNMP ifIndex: 1, Generation: 0
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 100mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Half-Duplex
Physical info   : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:a0:a5:56:01:89, Hardware address: 00:a0:a5:56:01:89
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          6484031
Output bytes  :          167503
Input packets :           81008
Output packets:           1110

Logical interface fxp0.0 (Index 2) (SNMP ifIndex 13) (Generation 1)
Flags: SNMP-Traps Encapsulation: ENET2
Protocol inet, MTU: 1500, Generation: 6, Route table: 0
Flags: Is-Primary
Addresses, Flags: Is-Preferred Is-Primary
Destination: 192.168.64/21, Local: 192.168.70.143,
Broadcast: 192.168.71.255, Generation: 1

```

**show interfaces detail  
(Management**

```

user@host> show interfaces em0 detail
Physical interface: em0, Enabled, Physical link is Up
Interface index: 8, SNMP ifIndex: 17, Generation: 2

```

**Ethernet [TX Matrix Plus Router])**

```

Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 100mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Physical info   : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:80:f9:26:00:c0, Hardware address: 00:80:f9:26:00:c0
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          124351
Output bytes  :          1353212
Input packets :           1804
Output packets:           5344
IPv6 transit statistics:
Input bytes   :           0
Output bytes  :           0
Input packets :           0
Output packets:           0

```

Logical interface em0.0 (Index 3) (SNMP ifIndex 18) (Generation 1)

Flags: SNMP-Traps Encapsulation: ENET2

Traffic statistics:

```

Input bytes   :          117135
Output bytes  :          1331647
Input packets :           1804
Output packets:           5344

```

Local statistics:

```

Input bytes   :          117135
Output bytes  :          1331647
Input packets :           1804
Output packets:           5344

```

Protocol inet, MTU: 1500, Generation: 1, Route table: 0

Flags: Is-Primary

Addresses, Flags: Is-Preferred Is-Primary

Destination: 192.168.178.0/25, Local: 192.168.178.11, Broadcast: 192.168.178.127, Generation: 1

**show interfaces detail (Management**

```
user@host> show interfaces detail em0
```

Physical interface: em0, Enabled, Physical link is Up

Interface index: 8, SNMP ifIndex: 0, Generation: 3

**Ethernet [PTX Packet Transport Switches])**

```

Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 1000mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Physical info   : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:80:f9:25:00:1b, Hardware address: 00:80:f9:25:00:1b
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
  Input bytes   :          15255909
  Output bytes  :           4608
  Input packets:          214753
  Output packets:           72
IPv6 transit statistics:
  Input bytes   :           0
  Output bytes  :           0
  Input packets:           0
  Output packets:           0

Logical interface em0.0 (Index 3) (SNMP ifIndex 0) (Generation 1)
Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
  Input bytes   :          14394630
  Output bytes  :           3024
  Input packets:          214723
  Output packets:           72
Local statistics:
  Input bytes   :          14394630
  Output bytes  :           3024
  Input packets:          214723
  Output packets:           72
Protocol inet, MTU: 1500, Generation: 1, Route table: 0
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
  Destination: 192.168.3/24, Local: 192.168.3.30,
  Broadcast: 192.168.3.255, Generation: 1

```

**show interfaces  
extensive**

```

user@host> show interfaces fxp0 extensive
Physical interface: fxp0, Enabled, Physical link is Up
Interface index: 1, SNMP ifIndex: 1, Generation: 0

```

**(Management Ethernet)**

```
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 100mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Half-Duplex
Physical info  : Unspecified
Hold-times    : Up 0 ms, Down 0 ms
Current address: 00:a0:a5:56:01:89, Hardware address: 00:a0:a5:56:01:89
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          6678904
Output bytes  :          169657
Input packets :          83946
Output packets:          1127
Input errors:
  Errors: 12, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
  Policed discards: 0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
  Resource errors: 0

Logical interface fxp0.0 (Index 2) (SNMP ifIndex 13) (Generation 1)
Flags: SNMP-Traps Encapsulation: ENET2
Protocol inet, MTU: 1500, Generation: 6, Route table: 0
Flags: Is-Primary
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 192.168.64/21, Local: 192.168.70.143,
  Broadcast: 192.168.71.255, Generation: 1
```

**show interfaces  
extensive  
(Management)**

```
user@host> show interfaces em0 extensive
```

```
Physical interface: em0, Enabled, Physical link is Up
Interface index: 8, SNMP ifIndex: 17, Generation: 2
```



**Ethernet [TX Matrix  
Plus Router])**

```

Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 100mbps
Device flags : Present Running
Interface flags: SNMP-Traps
Link type : Full-Duplex
Physical info : Unspecified
Hold-times : Up 0 ms, Down 0 ms
Current address: 00:80:f9:26:00:c0, Hardware address: 00:80:f9:26:00:c0
Alternate link address: Unspecified
Last flapped : Never
Statistics last cleared: Never
Traffic statistics:
  Input bytes : 127120
  Output bytes : 1357414
  Input packets: 1843
  Output packets: 5372
IPv6 transit statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
Output errors:
  Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0

Logical interface em0.0 (Index 3) (SNMP ifIndex 18) (Generation 1)
Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
  Input bytes : 119748
  Output bytes : 1335719
  Input packets: 1843
  Output packets: 5372
Local statistics:
  Input bytes : 119748
  Output bytes : 1335719
  Input packets: 1843
  Output packets: 5372
Protocol inet, MTU: 1500, Generation: 1, Route table: 0
Flags: Is-Primary
Addresses, Flags: Is-Preferred Is-Primary
  Destination: 192.168.178.0/25, Local: 192.168.178.11, Broadcast:
192.168.178.127, Generation: 1

```

**show interfaces  
extensive  
(Management  
Ethernet [PTX Series**

```

user@host> show interfaces extensive em0
Physical interface: em0, Enabled, Physical link is Up
  Interface index: 8, SNMP ifIndex: 0, Generation: 3
  Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,

```

## Packet Transport Switches])

```

Speed: 1000mbps
Device flags : Present Running
Interface flags: SNMP-Traps
Link type : Full-Duplex
Physical info : Unspecified
Hold-times : Up 0 ms, Down 0 ms
Current address: 00:80:f9:25:00:1b, Hardware address: 00:80:f9:25:00:1b
Alternate link address: Unspecified
Last flapped : Never
Statistics last cleared: Never
Traffic statistics:
  Input bytes : 15236459
  Output bytes : 4608
  Input packets: 214482
  Output packets: 72
IPv6 transit statistics:
  Input bytes : 0
  Output bytes : 0
  Input packets: 0
  Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Policed discards: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
Resource errors: 0

Logical interface em0.0 (Index 3) (SNMP ifIndex 0) (Generation 1)
Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
  Input bytes : 14376264
  Output bytes : 3024
  Input packets: 214452
  Output packets: 72
Local statistics:
  Input bytes : 14376264
  Output bytes : 3024
  Input packets: 214452
  Output packets: 72
Protocol inet, MTU: 1500, Generation: 1, Route table: 0
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: 192.168.3/24, Local: 192.168.3.30,
Broadcast: 192.168.3.255, Generation: 1

```

## show interfaces brief (Management Ethernet)

```

user@host> show interfaces fxp1 brief
Physical interface: fxp1, Enabled, Physical link is Up
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 100mbps
Device flags : Present Running
Interface flags: SNMP-Traps

Logical interface fxp1.0
Flags: SNMP-Traps Encapsulation: ENET2
inet 10.0.0.4/8
inet6 fe80::200:ff:fe00:4/64
fec0::10:0:0:4/64
tnp 4

user@host> show interfaces em0 brief

```

**show interfaces brief**  
(Management  
Ethernet [TX Matrix  
Plus Router])

Physical interface: em0, Enabled, Physical link is Up  
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,  
Speed: 100mbps  
Device flags : Present Running  
Interface flags: SNMP-Traps  
  
Logical interface em0.0  
Flags: SNMP-Traps Encapsulation: ENET2  
inet 192.168.178.11/25

**show interfaces brief**  
(Management  
Ethernet [PTX Series

user@host> **show interfaces em0 brief**  
Physical interface: em0, Enabled, Physical link is Up  
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,

## Packet Transport Switches]]

Speed: 1000mbps  
Device flags : Present Running  
Interface flags: SNMP-Traps

Logical interface em0.0  
Flags: SNMP-Traps Encapsulation: ENET2  
inet 192.168.3.30/24

```
root@aboslutely> show interfaces em0 terse
Interface      Admin Link Proto  Local      Remote
em0            up    up
em0.0          up    up  inet    192.168.3.30/24
```

## show interfaces (Internal Ethernet)

```
user@host> show interfaces fxp1
Physical interface: fxp1, Enabled, Physical link is Up
Interface index: 2, SNMP ifIndex: 2
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Speed: 100mbps
Device flags : Present Running
Interface flags: SNMP-Traps
Link type : Full-Duplex
Current address: 02:00:00:00:00:04, Hardware address: 02:00:00:00:00:04
Last flapped : Never
Input packets : 30655
Output packets: 33323

Logical interface fxp1.0 (Index 3) (SNMP ifIndex 14)
Flags: SNMP-Traps Encapsulation: ENET2
Protocol inet, MTU: 1500
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: 10/8, Local: 10.0.0.4, Broadcast: 10.255.255.255
Protocol inet6, MTU: 1500
Flags: Is-Primary
Addresses, Flags: Is-Preferred
Destination: fe80::/64, Local: fe80::200:ff:fe00:4
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: fec0::/64, Local: fec0::10:0:0:4
Protocol tnp, MTU: 1500
Flags: Primary, Is-Primary
Addresses
Local: 4
```

## show interfaces (Internal Ethernet [TX Matrix Plus Router])

```
user@host> show interfaces ixgbe0
Physical interface: ixgbe0, Enabled, Physical link is Up
Interface index: 2, SNMP ifIndex: 116
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps
Device flags : Present Running
Interface flags: SNMP-Traps
Link type : Full-Duplex
Current address: 02:00:00:22:00:04, Hardware address: 02:00:00:22:00:04
Last flapped : Never
Input packets : 2301738
Output packets: 3951155

Logical interface ixgbe0.0 (Index 4) (SNMP ifIndex 117)
Flags: SNMP-Traps Encapsulation: ENET2
Input packets : 2301595
Output packets: 3951155
Protocol inet, MTU: 1500
Flags: Is-Primary
```

```

Addresses, Flags: Is-Preferred
  Destination: 10/8, Local: 10.34.0.4, Broadcast: 10.255.255.255
Addresses, Flags: Primary Is-Default Is-Preferred Is-Primary
  Destination: 128/2, Local: 162.0.0.4, Broadcast: 191.255.255.255
Protocol inet6, MTU: 1500
Flags: Is-Primary
Addresses, Flags: Is-Preferred
  Destination: fe80::/64, Local: fe80::200:ff:fe22:4
Addresses, Flags: Is-Default Is-Preferred Is-Primary
  Destination: fec0::/64, Local: fec0::a:22:0:4
Protocol tnp, MTU: 1500
Flags: Primary, Is-Primary
Addresses
  Local: 0x22000004

```

#### show interfaces detail (Internal Ethernet)

```

user@host> show interfaces fxp1 detail
Physical interface: fxp1, Enabled, Physical link is Up
Interface index: 2, SNMP ifIndex: 2, Generation: 1
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 100mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Physical info   : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: 02:00:00:00:00:04, Hardware address: 02:00:00:00:00:04
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          2339969
Output bytes  :          15880707
Input packets :           30758
Output packets:           33443

Logical interface fxp1.0 (Index 3) (SNMP ifIndex 14) (Generation 2)
Flags: SNMP-Traps Encapsulation: ENET2
Protocol inet, MTU: 1500, Generation: 7, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
  Destination: 10/8, Local: 10.0.0.4, Broadcast: 10.255.255.255,
  Generation: 3
Protocol inet6, MTU: 1500, Generation: 8, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Preferred
  Destination: fe80::/64, Local: fe80::200:ff:fe00:4,
  Broadcast: Unspecified, Generation: 5
Addresses, Flags: Is-Default Is-Preferred Is-Primary
  Destination: fec0::/64, Local: fec0::10:0:0:4, Broadcast: Unspecified,
  Generation: 7
Protocol tnp, MTU: 1500, Generation: 9, Route table: 1
Flags: Primary, Is-Primary
Addresses, Flags: None
  Destination: Unspecified, Local: 4, Broadcast: Unspecified,
  Generation: 8

```

#### show interfaces detail (Internal Ethernet [TX Matrix Plus Router])

```

user@host> show interfaces ixgbe0 detail
Physical interface: ixgbe0, Enabled, Physical link is Up
Interface index: 2, SNMP ifIndex: 116, Generation: 3
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,

```

```

Speed: 1000mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Physical info  : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: 02:00:00:22:00:04, Hardware address: 02:00:00:22:00:04
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          238172825
Output bytes  :          1338948955
Input packets :          2360984
Output packets:          4061512
IPv6 transit statistics:
Input bytes   :              0
Output bytes  :              0
Input packets :              0
Output packets:              0

Logical interface ixgbe0.0 (Index 4) (SNMP ifIndex 117) (Generation 2)
Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
Input bytes   :          228720309
Output bytes  :          1261387447
Input packets :          2360841
Output packets:          4061512
IPv6 transit statistics:
Input bytes   :              0
Output bytes  :              0
Input packets :              0
Output packets:              0
Local statistics:
Input bytes   :          228720309
Output bytes  :          1261387447
Input packets :          2360841
Output packets:          4061512
Protocol inet, MTU: 1500, Generation: 2, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Preferred
Destination: 10/8, Local: 10.34.0.4, Broadcast: 10.255.255.255, Generation:
2
Addresses, Flags: Primary Is-Default Is-Preferred Is-Primary
Destination: 128/2, Local: 162.0.0.4, Broadcast: 191.255.255.255,
Generation: 3
Protocol inet6, MTU: 1500, Generation: 3, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Preferred
Destination: fe80::/64, Local: fe80::200:ff:fe22:4
Generation: 4
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: fec0::/64, Local: fec0::a:22:0:4
Protocol tnp, MTU: 1500, Generation: 5
Generation: 4, Route table: 1
Flags: Primary, Is-Primary
Addresses, Flags: None
Destination: Unspecified, Local: 0x22000004, Broadcast: Unspecified,
Generation: 6

user@host> show interfaces fxp1 extensive

```

**show interfaces  
extensive  
(internal Ethernet)**

```
Physical interface: fxp1, Enabled, Physical link is Up
Interface index: 2, SNMP ifIndex: 2, Generation: 1
Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 100mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Physical info   : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: 02:00:00:00:00:04, Hardware address: 02:00:00:00:00:04
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          2349897
Output bytes  :          15888605
Input packets :           30896
Output packets:           33607
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
Policed discards: 0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0,
Resource errors: 0

Logical interface fxp1.0 (Index 3) (SNMP ifIndex 14) (Generation 2)
Flags: SNMP-Traps Encapsulation: ENET2
Protocol inet, MTU: 1500, Generation: 7, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: 10/8, Local: 10.0.0.4, Broadcast: 10.255.255.255,
Generation: 3
Protocol inet6, MTU: 1500, Generation: 8, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Preferred
Destination: fe80::/64, Local: fe80::200:ff:fe00:4,
Broadcast: Unspecified, Generation: 5
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: fec0::/64, Local: fec0::10:0:0:4, Broadcast: Unspecified,
Generation: 7
Protocol tnp, MTU: 1500, Generation: 9, Route table: 1
Flags: Primary, Is-Primary
Addresses, Flags: None
Destination: Unspecified, Local: 4, Broadcast: Unspecified,
Generation: 8
```

**show interfaces  
extensive**

```
user@host> show interfaces ixgbe0 extensive
Physical interface: ixgbe0, Enabled, Physical link is Up
Interface index: 2, SNMP ifIndex: 116, Generation: 3
```

**(internal Ethernet [TX  
Matrix Plus Router])**

```

Type: Ethernet, Link-level type: Ethernet, MTU: 1514, Clocking: Unspecified,
Speed: 1000mbps
Device flags   : Present Running
Interface flags: SNMP-Traps
Link type      : Full-Duplex
Physical info   : Unspecified
Hold-times     : Up 0 ms, Down 0 ms
Current address: 02:00:00:22:00:04, Hardware address: 02:00:00:22:00:04
Alternate link address: Unspecified
Last flapped   : Never
Statistics last cleared: Never
Traffic statistics:
Input bytes   :          242730780
Output bytes  :          1348312269
Input packets :          2398737
Output packets:          4133510
IPv6 transit statistics:
Input bytes   :          0
Output bytes  :          0
Input packets :          0
Output packets:          0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
0, Resource errors: 0
Output errors:
Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0

```

```

Logical interface ixgbe0.0 (Index 4) (SNMP ifIndex 117) (Generation 2)
Flags: SNMP-Traps Encapsulation: ENET2
Traffic statistics:
Input bytes   :          233127252
Output bytes  :          1269350897
Input packets :          2398594
Output packets:          4133510
IPv6 transit statistics:
Input bytes   :          0
Output bytes  :          0
Input packets :          0
Output packets:          0
Local statistics:
Input bytes   :          233127252
Output bytes  :          1269350897
Input packets :          2398594
Output packets:          4133510
Protocol inet, MTU: 1500, Generation: 2, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Preferred
Destination: 10/8, Local: 10.34.0.4, Broadcast: 10.255.255.255, Generation:
2
Addresses, Flags: Primary Is-Default Is-Preferred Is-Primary
Destination: 128/2, Local: 162.0.0.4, Broadcast: 191.255.255.255,
Generation: 3
Protocol inet6, MTU: 1500, Generation: 3, Route table: 1
Flags: Is-Primary
Addresses, Flags: Is-Preferred
Destination: fe80::/64, Local: fe80::200:ff:fe22:4
Generation: 4
Addresses, Flags: Is-Default Is-Preferred Is-Primary
Destination: fec0::/64, Local: fec0::a:22:0:4
Protocol tnp, MTU: 1500, Generation: 5

```



Generation: 4, Route table: 1  
Flags: Primary, Is-Primary  
Addresses, Flags: None  
Destination: Unspecified, Local: 0x22000004, Broadcast: Unspecified,  
Generation: 6

## show interfaces (J Series Router Management Ethernet)

<b>Syntax</b>	show interfaces fe-0/0/0<.0> <brief   detail   extensive   terse> <descriptions> <media> <snmp-index <i>snmp-index</i> > <statistics>
<b>Release Information</b>	Command introduced before Junos OS Release 7.4.
<b>Description</b>	(J Series routers only) Display status information about the management Ethernet interface.
<b>Options</b>	<p><b>fe-0/0/0&lt;.0&gt;</b>—Display standard information about the management Ethernet or internal Ethernet interface, respectively.</p> <p><b>brief   detail   extensive   terse</b>—(Optional) Display the specified level of output.</p> <p><b>descriptions</b>—(Optional) Display interface description strings.</p> <p><b>media</b>—(Optional) Display media-specific information.</p> <p><b>snmp-index <i>snmp-index</i></b>—(Optional) Display information for the specified SNMP index of the interface.</p> <p><b>statistics</b>—(Optional) Display static interface statistics.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show interfaces brief (Management Ethernet) on page 1056</a> <a href="#">show interfaces (Management Ethernet) on page 1056</a> <a href="#">show interfaces detail (Management Ethernet) on page 1056</a> <a href="#">show interfaces extensive (Management Ethernet) on page 1057</a>
<b>Output Fields</b>	Table 168 on page 1048 lists the output fields for the <b>show interfaces</b> (management) command on the J Series routers. Output fields are listed in the approximate order in which they appear.

**Table 168: J Series Router Management Ethernet show interfaces Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	All levels
<b>Link</b>	Status of the link: <b>up</b> or <b>down</b> .	All levels
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under “ <a href="#">Common Output Fields Description</a> ” on page 141.	All levels

Table 168: J Series Router Management Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	detail extensive
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	detail extensive
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	detail extensive
<b>Description</b>	Description and name of the interface.	detail extensive
<b>Link-level type</b>	Encapsulation type used on the physical interface.	brief detail extensive
<b>MTU</b>	Maximum transmission unit (MTU). Size of the largest packet to be transmitted.	brief detail extensive
<b>Speed</b>	Network speed on the interface.	brief detail extensive
<b>Loopback</b>	Whether loopback is enabled and the type of loopback (either <b>local</b> or <b>remote</b> ).	brief detail extensive
<b>Source filtering</b>	Whether source filtering is configured.	brief detail extensive
<b>Flow control</b>	Whether flow control is enabled or disabled.	brief detail extensive
<b>Device flags</b>	Information about the physical device. Possible values are described in the "Device Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	brief detail extensive
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	brief detail extensive
<b>Link flags</b>	Information about the link. Possible values are described in the "Link Flags" section under <a href="#">"Common Output Fields Description" on page 141</a> .	brief detail extensive
<b>CoS queues</b>	Number of CoS queues supported on this interface.	detail extensive
<b>Hold-times</b>	Current interface hold-time up and hold-time down. Value is in milliseconds.	detail extensive
<b>Current address</b>	Configured MAC address.	detail extensive
<b>Hardware address</b>	Media access control (MAC) address of the interface.	detail extensive
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .	detail extensive
<b>Statistics last cleared</b>	Time when the statistics for the interface were last set to zero.	detail extensive

Table 168: J Series Router Management Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Traffic statistics</b>	<p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>detail extensive</b>
<b>Input errors</b>	<ul style="list-style-type: none"> <li>• <b>Errors</b>—Input errors on the interface.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Frames received smaller than the runt threshold.</li> <li>• <b>Policed Discards</b>—Frames that the incoming packet match code discarded because the frames did not recognize them or were not of interest. Usually, this field reports protocols that Junos does not support.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded.</li> <li>• <b>L2 channel errors</b>—Number of times the software could not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that cause the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the receive direction as reported by the ASIC on the PIM. If this value is ever nonzero, the PIM is probably malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>

Table 168: J Series Router Management Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Output errors</b>	<ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly, possibly once every 10 seconds, the cable, the remote system, or the interface is malfunctioning.</li> <li>• <b>Errors</b>—Sum of outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet dropped by the ASIC RED mechanism.</li> <li>• <b>Collisions</b>—Number of Ethernet collisions.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the receive direction as reported by the ASIC on the PIM. If this value is ever nonzero, the PIM is probably malfunctioning.</li> <li>• <b>MTU errors</b>—Number of packets larger than the MTU threshold.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>	<b>extensive</b>
<b>Queue counters</b>	<p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>	<b>detail extensive</b>
<b>Active alarms and Active defects</b>	<p>Ethernet-specific defects that can prevent the interface from passing packets. When a defect persists for a certain period, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. These fields can contain the value <b>None</b> or <b>Link</b>.</p> <ul style="list-style-type: none"> <li>• <b>None</b>—There are no active defects or alarms.</li> <li>• <b>Link</b>—Interface has lost its link state, which usually means that the cable is unplugged, the far-end system has been turned off, or the PIM is malfunctioning.</li> </ul>	<b>detail extensive</b>

Table 168: J Series Router Management Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>MAC statistics</b>	<p>Statistics reported by the PIM's MAC subsystem, including the following:</p> <ul style="list-style-type: none"> <li>• <b>Total octets and total packets</b>—Total number of sent and received octets and packets.</li> <li>• <b>Unicast, broadcast, and multicast packets</b>—Number of unicast, broadcast, and multicast packets.</li> <li>• <b>CRC/Align errors</b>—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had either a bad FCS with an integral number of octets (FCS error) or a bad FCS with a nonintegral number of octets (alignment error).</li> <li>• <b>FIFO errors</b>—Number of FIFO errors that are reported by the ASIC on the PIM. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>MAC control frames</b>—Number of MAC control frames.</li> <li>• <b>MAC pause frames</b>—Number of MAC control frames with <b>pause</b> operational code.</li> <li>• <b>Oversized frames</b>—Number of frames that exceed the MTU.</li> <li>• <b>Jabber frames</b>—Number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10Base5) and section 10.3.1.4 (10Base2). These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.</li> <li>• <b>Fragment frames</b>—Total number of packets received that were less than 64 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. Fragment frames normally increment because both runts (which are normal occurrences caused by collisions) and noise hits are counted.</li> <li>• <b>VLAN tagged frames</b>—Number of frames that are VLAN tagged. The system uses the TPID of 0x8100 in the frame to determine whether a frame is tagged or not.</li> <li>• <b>Code violations</b>—Number of times an event caused the PHY to indicate "Data reception error" or "invalid data symbol error".</li> </ul>	<b>extensive</b>

Table 168: J Series Router Management Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Filter statistics</b>	<p>Statistics reported by the PIM's MAC address filter subsystem. The filtering is done by the content-addressable memory (CAM) on the PIM. The filter examines a packet's source and destination MAC addresses to determine whether the packet should enter the system or be rejected.</p> <ul style="list-style-type: none"> <li>• <b>Input packet count</b>—Number of packets received from the MAC hardware that the filter processed.</li> <li>• <b>Input packet rejects</b>—Number of packets that the filter rejected because of either the source MAC address or the destination MAC address.</li> <li>• <b>Input DA rejects</b>—Number of packets that the filter rejected because the destination MAC address of the packet is not on the accept list. It is normal for this value to increment. When it increments very quickly and no traffic is entering the router from the far-end system, either a bad ARP entry exists on the far-end system, or multicast routing is not on and the far-end system is sending many multicast packets to the local router (which the router is rejecting).</li> <li>• <b>Input SA rejects</b>—Number of packets that the filter rejected because the source MAC address of the packet is not on the accept list. The value in this field should increment only if source MAC address filtering has been enabled. If filtering is enabled, if the value increments quickly, and if the system is not receiving traffic that it should from the far-end system, it means that the user-configured source MAC addresses for this interface are incorrect.</li> <li>• <b>Output packet count</b>—Number of packets that the filter has given to the MAC hardware.</li> <li>• <b>Output packet pad count</b>—Number of packets the filter padded to the minimum Ethernet size (60 bytes) before giving the packet to the MAC hardware. Usually, padding is done only on small ARP packets, but some very small IP packets can also require padding. If this value increments rapidly, either the system is trying to find an ARP entry for a far-end system that does not exist or it is misconfigured.</li> <li>• <b>Output packet error count</b>—Number of packets with an indicated error that the filter was given to transmit. These packets are usually aged packets or are the result of a bandwidth problem. On a normal system, the value of this field should not increment.</li> <li>• <b>CAM destination filters, CAM source filters</b>—Number of entries in the CAM dedicated to destination and source MAC address filters. There can only be up to 64 source entries. If source filtering is disabled, which is the default, the values for these fields should be 0.</li> </ul>	<b>extensive</b>
<b>Autonegotiation information</b>	<p>Information about link autonegotiation.</p> <ul style="list-style-type: none"> <li>• <b>Negotiation status:</b> <ul style="list-style-type: none"> <li>• <b>Incomplete</b>—Ethernet interface has the speed or link mode configured.</li> <li>• <b>No autonegotiation</b>—Remote Ethernet interface has the speed or link mode configured, or does not perform autonegotiation.</li> <li>• <b>Complete</b>—Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> </ul> </li> <li>• <b>Link partner status</b>—OK when the Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> <li>• <b>Link partner</b>—Depending on the capability of the attached Ethernet device, either <b>Full-duplex</b> or <b>Half-duplex</b>.</li> <li>• <b>Flow control</b>—Types of flow control supported by the remote Ethernet device.</li> </ul>	<b>extensive</b>

Table 168: J Series Router Management Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Packet Forwarding Engine configuration</b>	Information about the configuration of the Packet Forwarding Engine: <ul style="list-style-type: none"> <li><b>Destination slot</b>—FPC slot number.</li> </ul>	<b>extensive</b>
<b>CoS information</b>	Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li><b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li><b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li><b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li><b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li><b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li><b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li><b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul>	<b>extensive</b>
<b>Logical Interface</b>		
<b>Logical interface</b>	Name of the logical interface.	All levels
<b>Index</b>	Logical interface index number, which reflects its initialization sequence.	All levels
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	All levels
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Description</b>	Description and name of the interface.	<b>brief detail extensive</b>
<b>Flags</b>	Information about the logical interface; values are described in the “Logical Interface Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>brief detail extensive</b>
<b>Encapsulation</b>	Encapsulation on the logical interface.	<b>brief detail extensive</b>
<b>Traffic statistics</b>	Total number of bytes and packets received and transmitted on the logical interface. These statistics are the sum of the local and transit statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize. <ul style="list-style-type: none"> <li><b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface.</li> <li><b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface.</li> </ul>	<b>extensive</b>
<b>Protocol</b>	Protocol family configured on the logical interface (such as <b>iso</b> or <b>inet6</b> ).	All levels



Table 168: J Series Router Management Ethernet show interfaces Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>MTU</b>	MTU size on the logical interface.	All levels
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>
<b>Route Table</b>	Route table in which this address exists. for example, <b>Route table:0</b> refers to inet.0.	All levels
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the “Family Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Addresses, Flags</b>	Information about address flags. Possible values are described in the “Addresses Flags” section under <a href="#">“Common Output Fields Description” on page 141</a> .	<b>detail extensive</b>
<b>Destination</b>	IP address of the remote side of the connection.	All levels
<b>Local</b>	IP address of the logical interface.	All levels
<b>Broadcast</b>	Broadcast address.	All levels
<b>Generation</b>	Unique number for use by Juniper Networks technical support only.	<b>detail extensive</b>

## Sample Output

### show interfaces brief (Management Ethernet)

```
user@host> show interfaces fe-0/0/0 brief
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000

Logical interface fe-0/0/0.0
  Flags: SNMP-Traps 0x1000000 Encapsulation: ENET2
  inet 192.168.69.55/21
```

### show interfaces (Management Ethernet)

```
user@host> show interfaces fe-0/0/0
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Interface index: 137, SNMP ifIndex: 31
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 8 supported, 8 in use
  Current address: 00:05:85:c3:84:d0, Hardware address: 00:05:85:c3:84:d0
  Last flapped   : 2005-12-19 15:35:53 PST (15w0d 22:17 ago)
  Input rate     : 243656 bps (506 pps)
  Output rate    : 2080 bps (3 pps)
  Active alarms  : None
  Active defects : None

Logical interface fe-0/0/0.0 (Index 67) (SNMP ifIndex 45)
  Flags: SNMP-Traps 0x1000000 Encapsulation: ENET2
  Protocol inet, MTU: 1500
  Flags: Is-Primary
  Addresses, Flags: Is-Default Is-Preferred Is-Primary
    Destination: 192.168.64/21, Local: 192.168.69.55,
    Broadcast: 192.168.71.255
```

### show interfaces detail (Management Ethernet)

```
user@host> show interfaces fe-0/0/0 detail
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Interface index: 137, SNMP ifIndex: 31, Generation: 18
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 8 supported, 8 in use
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:05:85:c3:84:d0, Hardware address: 00:05:85:c3:84:d0
  Last flapped   : 2005-12-19 15:35:53 PST (15w0d 22:25 ago)
  Statistics last cleared: Never
  Traffic statistics:
    Input bytes   : 18192489978          11520 bps
    Output bytes  : 338573758           2824 bps
    Input packets : 251397914           17 pps
    Output packets: 2840667             3 pps
  Queue counters:
    Queued packets  Transmitted packets  Dropped packets

    0 best-effort   1308091          1308091          0
    1 expedited-fo      0              0              0
```

2	assured-fow	0	0	0
3	network-cont	0	0	0
4	be-class	0	0	0
5	ef-class	0	0	0
6	af-class	1532576	1532576	0

Active alarms : None

Active defects : None

Logical interface fe-0/0/0.0 (Index 67) (SNMP ifIndex 45) (Generation 5)

Flags: SNMP-Traps 0x1000000 Encapsulation: ENET2

Protocol inet, MTU: 1500, Generation: 9, Route table: 0

Flags: Is-Primary

Addresses, Flags: Is-Default Is-Preferred Is-Primary

Destination: 192.168.64/21, Local: 192.168.69.55,

Broadcast: 192.168.71.255, Generation: 7

**show interfaces**  
**extensive**

user@host> **show interfaces fe-0/0/0 detail**

Physical interface: fe-0/0/0, Enabled, Physical link is Up

Interface index: 137, SNMP ifIndex: 31, Generation: 18

## (Management Ethernet)

```

Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
Source filtering: Disabled, Flow control: Enabled
Device flags   : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
CoS queues     : 8 supported, 8 in use
Hold-times     : Up 0 ms, Down 0 ms
Current address: 00:05:85:c3:84:d0, Hardware address: 00:05:85:c3:84:d0
Last flapped   : 2005-12-19 15:35:53 PST (15w0d 22:26 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes   :      18192523184      8848 bps
Output bytes  :      338578715      2656 bps
Input packets :      251398326      16 pps
Output packets:      2840696      4 pps
Input errors:
Errors: 4273531220, Drops: 0, Framing errors: 0, Runts: 0,
Policed discards: 187, L3 incompletes: 0, L2 channel errors: 0,
L2 mismatch timeouts: 0, FIFO errors: 0, Resource errors: 0
Output errors:
Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Queue counters:      Queued packets  Transmitted packets      Dropped packets

0 best-effort          1308111          1308111          0
1 expedited-fo          0              0              0
2 assured-forw          0              0              0
3 network-cont          0              0              0
4 be-class              0              0              0
5 ef-class              0              0              0
6 af-class              1532585         1532585         0

Active alarms : None
Active defects : None
MAC statistics:
Total octets          Receive      Transmit
Total packets         18544532244  360434659
Unicast packets        251398493    2840690
Broadcast packets      1141188      2558770
Multicast packets      244048157    281920
CRC/Align errors       6209148      0
FIFO errors            1121446      0
MAC control frames      0            0
MAC pause frames        0            0
Oversized frames        0            0
Jabber frames           591          0
Fragment frames         0            0
VLAN tagged frames      0            0
Code violations          0            0
Filter statistics:
Input packet count      13114864305
Input packet rejects    12863465812
Input DA rejects        12863465812
Input SA rejects         0
Output packet count      0

```

```
Output packet pad count                                0
Output packet error count                              0
CAM destination filters: 2, CAM source filters: 0
Autonegotiation information:
  Negotiation status: No-autonegotiation, Link partner status: Ok,
  Link partner: Unknown, Flow control: None
Packet Forwarding Engine configuration:
  Destination slot: 0
CoS information:
  CoS transmit queue      Bandwidth      Buffer      Priority  Limit
                           %      bps      %      usec
0 best-effort             95      95000000  95      0        low     none
3 network-control         5       5000000   5       0        low     none

Logical interface fe-0/0/0.0 (Index 67) (SNMP ifIndex 45) (Generation 5)
Flags: SNMP-Traps 0x1000000 Encapsulation: ENET2
Protocol inet, MTU: 1500, Generation: 9, Route table: 0
Flags: Is-Primary
Addresses, Flags: Is-Default Is-Preferred Is-Primary
  Destination: 192.168.64/21, Local: 192.168.69.55,
  Broadcast: 192.168.71.255, Generation: 7
```



## PART 13

# Index

- [Index on page 1063](#)
- [Index of Statements and Commands on page 1073](#)





# Index

## Symbols

!	
in interface names.....	6
#, comments in configuration statements.....	xvi
( ), in syntax descriptions.....	xvi
*	
in interface names.....	6
10-Gigabit Ethernet interfaces	
DWDM	
data and alarms, displaying.....	295
status information, displaying.....	283, 286
100-Gigabit Ethernet interfaces.....	295
< >, in syntax descriptions.....	xvi
[ ]	
in interface names.....	6
[ ], in configuration statements.....	xvi
{ }, in configuration statements.....	xvi
(pipe), in syntax descriptions.....	xvi

## A

ACI (agent circuit identifier) interface sets	
clearing.....	157
status information, displaying.....	283
adaptive services.....	855
adaptive services interfaces.....	857
status information, displaying.....	857
Addresses, flags field, content.....	142
ADSL	
ATM-over-ADSL interfaces	
status information, displaying.....	673
aenumber interface.....	12, 14
described.....	12, 14
<i>See also</i> aggregated Ethernet interfaces	
aggregated Ethernet interfaces	
status information, displaying.....	182
Aggregated Ethernet interfaces	
targeted distribution status, displaying.....	319
aggregated Ethernet interfaces with link protection	
manually switching to the backup link.....	175
reverting to the primary link.....	175

aggregated Ethernet interfaces without link protection	
manually rebalancing subscribers .....	174
rebalancing subscribers.....	174
aggregated Ethernet LACP link protection	
manually switching.....	176
aggregated SONET/SDH interfaces	
status information, displaying.....	587
APS	
real-time information, displaying.....	582
asnumber interface.....	12
described.....	12
<i>See also</i> aggregated SONET/SDH interfaces	
asymmetric digital subscriber line <i>See</i> ADSL	
Asynchronous Transfer Mode <i>See</i> ATM	
at- interface.....	12, 15
described.....	12, 15
<i>See also</i> ATM interfaces	
<i>See also</i> ATM-over-ADSL interfaces	
<i>See also</i> ATM-over-SHDSL interfaces	
ATM interfaces	
status information, displaying.....	638
ATM-over-ADSL interfaces	
status information, displaying.....	673
ATM-over-SHDSL interfaces	
status information, displaying.....	681
Automatic Protection Switching <i>See</i> APS	

## B

B-channel interface <i>See</i> ISDN	
Basic Rate Interface <i>See</i> ISDN	
bc- interface.....	15
described.....	15
<i>See also</i> ISDN	
br- interface.....	15
described.....	15
<i>See also</i> ISDN	
braces, in configuration statements.....	xvi
brackets	
angle, in syntax descriptions.....	xvi
square, in configuration statements.....	xvi

## C

cau4- interface.....	12
described.....	12
<i>See also</i> channelized OC12 IQ or IQE and channelized STM1 IQ interfaces	

cel- interface.....	12	channelized T3 IQ interfaces	
described.....	12	controller information, displaying.....	851
See also channelized E1 IQ interfaces		status information, displaying.....	848
CFM statistics		clear auto-configuration interfaces command.....	156
clearing.....	168	clear auto-configuration interfaces interface-set	
displaying for CFM interfaces.....	357	command.....	157
displaying for interfaces.....	345	clear ilmi statistics command.....	692
CFM, maintenance intermediate points		clear interfaces interface-set statistics	
displaying.....	384	command.....	29, 162
channelized AU-4 IQ interfaces See channelized		clear interfaces interval command.....	25
STM1 IQ interfaces and channelized OC12 IQ or		clear interfaces mac-database command.....	160
IQE interfaces		clear interfaces mac-database statistics	
channelized DS3-to-DS0 interfaces		command.....	161
status information, displaying.....	821	clear interfaces statistics command.....	28
channelized DS3-to-DS1 interfaces		clear isdn q921 statistics command.....	701
status information, displaying.....	832	clear isdn q931 statistics command.....	702
channelized E1 interfaces		clear lacp statistics command.....	158
status information, displaying.....	748	clear lacp timeouts.....	159
channelized E1 IQ interfaces		clear oam ethernet connectivity-fault-management	
controller information, displaying.....	764	continuity-measurement command.....	163
status information, displaying.....	759	clear oam ethernet connectivity-fault-management	
channelized OC12 interfaces		delay-statistics command.....	164
status information, displaying.....	785	clear oam ethernet connectivity-fault-management	
channelized OC12 IQ interfaces		linktrace path-database command.....	165
controller information, displaying.....	794	clear oam ethernet connectivity-fault-management	
status information, displaying.....	789	loss-statistics command.....	166
channelized OC12 IQE interfaces		clear oam ethernet connectivity-fault-management	
controller information, displaying.....	794	policer command.....	167
status information, displaying.....	789	clear oam ethernet connectivity-fault-management	
channelized OC3 IQ interfaces		statistics.....	168
controller information, displaying.....	793	clear oam ethernet link-fault-management state	
status information, displaying.....	766	command.....	169
channelized OC3 IQE interfaces		clear oam ethernet link-fault-management	
controller information, displaying.....	793	statistics command.....	170
status information, displaying.....	766	clear ppp statistics command.....	500
channelized OC48 IQ interfaces		clear pppoe lockout command.....	523
status information, displaying.....	796	clear pppoe sessions command.....	525
channelized OC48 IQE interfaces		clear pppoe statistics command.....	526
status information, displaying.....	796	clear protection-group ethernet-ring statistics	
channelized STM1 interfaces		command.....	171
status information, displaying.....	800	clear tgm fpc command.....	992
channelized STM1 IQ interfaces		clear vrrp command.....	426
controller information, displaying.....	818	coc1- interface.....	12
status information, displaying.....	815	described.....	12
channelized T1 IQ interfaces		See also channelized OC3 IQ and IQE interfaces	
controller information, displaying.....	850	coc12- interface.....	12
status information, displaying.....	835	described.....	12
		See also channelized OC12 IQ or IQE interfaces	

- 
- coc3- interface.....12
    - described.....12
    - See also channelized OC3 IQ interfaces
  - comments, in configuration statements.....xvi
  - connectivity-fault-management
    - linktrace database, clearing.....165
  - container interfaces.....22
  - conventions
    - text and syntax.....xv
  - CoS
    - byte count by PIC type
      - displaying.....75
  - cp- interface.....21
    - described.....21
    - See also flow collector interfaces
  - cstm1- interface.....12
    - described.....12
    - See also channelized STM1 IQ interfaces
  - cstm4- interface.....12
    - described.....12
    - See also channelized OC12 IQ or IQE interfaces
  - CSU alarm
    - clearing.....25
  - ct1- interface.....12
    - described.....12
    - See also channelized T3 IQ interfaces
  - ct3- interface.....13
    - described.....13
    - See also channelized T3 IQ interfaces
  - curly braces, in configuration statements.....xvi
  - customer support.....xvii
    - contacting JTAC.....xvii
  - D**
  - D-channel interface See ISDN
  - dc- interface.....15
    - described.....15
    - See also ISDN
  - destination class
    - interface information
      - displaying.....34
  - Destination class field, contents.....141
  - Device flags field, content.....143
  - dfc- interface.....21
    - described.....21
    - See also dynamic flow capture interfaces
  - dialer interface See ISDN
  - discard interface
    - described.....8
    - status information, displaying.....1010
  - dlnumber interface.....15
    - described.....15
    - See also ISDN
  - documentation
    - comments on.....xvii
  - DS interfaces
    - status information, displaying.....440
  - ds- interface.....13
    - See also channelized E1 IQ interfaces
    - See also channelized DS3-to-DS0 interfaces
    - See also channelized E1 interfaces
    - See also channelized E1 IQ interfaces
  - dsc interface.....8
    - described.....8
    - See also discard interface
  - DWDM 10-Gigabit Ethernet interfaces
    - data and alarms, displaying.....295
  - dynamic flow capture interfaces
    - displaying.....878
  - dynamic VLAN
    - agent circuit identifier interface sets
      - clearing.....157
  - dynamic vlan interfaces, clearing.....156
  - E**
  - E1 interfaces
    - status information, displaying.....440
  - e1- interface.....13
    - described.....13
    - See also channelized E1 IQ interfaces
  - E3 interfaces
    - status information, displaying.....465
  - e3- interface.....13
    - described.....13
    - See also E3 interfaces
  - Enabled field, contents.....141
  - encryption interfaces
    - status information, displaying.....870
  - es- interface.....21
    - described.....21
    - See also encryption interfaces
  - ETH-DM delay statistics
    - clearing.....164

ETH-DM frame counts (with CFM statistics)	
displaying for MEPs by enclosing CFM.....	357
displaying for MEPs by interface or domain level.....	345
ETH-DM statistics (only)	
displaying.....	337
ETH-DM statistics and frame counts	
clearing.....	168
displaying.....	367
ETH-LM statistics (only)	
displaying.....	378
ETH-LM statistics and frame counts	
clearing.....	166
ethernet APS.....	177, 178, 179, 180, 181
Ethernet interface set	
status information, displaying.....	283
Ethernet interface set queue	
status information, displaying.....	286
Ethernet interfaces	
CFM statistics	
clearing.....	168
displaying for CFM interfaces.....	357
displaying for interfaces.....	345
CFM, maintenance intermediate points	
displaying.....	384
connectivity-fault-management.....	165
ETH-DM delay statistics	
clearing.....	164
ETH-DM frame counts (with CFM statistics)	
displaying for MEPs by enclosing CFM.....	357
displaying for MEPs by interface or domain level.....	345
ETH-DM statistics (only)	
displaying.....	337
ETH-DM statistics and frame counts	
clearing.....	168
displaying.....	367
ETH-LM statistics (only)	
displaying.....	378
ETH-LM statistics and frame counts	
clearing.....	166
OAM state, clearing.....	169
OAM statistics, clearing.....	170
protection group statistics, clearing.....	171
status information, displaying	
aggregated.....	182
Fast Ethernet.....	194
Gigabit Ethernet.....	212, 236

internal.....	1029
management.....	1029, 1048
ethernet ring	
protection group APS.....	407
protection group data channel.....	409, 420
protection group interface.....	411
protection group node state.....	414
protection group statistics.....	417

## F

Family flags field, content.....	143
Fast Ethernet interfaces	
status information, displaying.....	194
fe- interface.....	13, 14
described.....	13, 14
<i>See also</i> Fast Ethernet interfaces	
Filters fields, contents.....	142
firewall filters	
displaying.....	60
flags	
address flags.....	142
device flags.....	143
family flags.....	143
interface flags.....	144
link flags.....	145
logical interface flags.....	145
flow collector interfaces	
status information, displaying.....	882
flow monitoring interfaces	
status information, displaying.....	888
fnp statement	
show oam ethernet fnp interface.....	392
show oam ethernet fnp messages.....	393
show oam ethernet fnp status .....	395
font conventions.....	xv
fxp interface.....	9
described.....	9
<i>See also</i> Ethernet interfaces	

## G

G.SHDSL <i>See</i> SHDSL	
ge- interface.....	13, 14
described.....	13, 14
<i>See also</i> Gigabit Ethernet interfaces	
ge-0/0/0 interface.....	10
described.....	10
<i>See also</i> Ethernet interfaces	
generic routing encapsulation <i>See</i> GRE	

- Gigabit Ethernet interfaces
  - demultiplexing interface information,
    - displaying.....486
  - diagnostics information, displaying.....295
  - LACP, displaying.....321
  - MAC database, displaying.....330
  - status information,
    - displaying.....212, 236, 283, 286
- Gigabit Ethernet IQ PIC
  - traffic and MAC statistics.....236
- gre interface
  - described.....11
- GRE interfaces
  - status information, displaying.....958
- I**
- icons defined, notice.....xv
- ILMI
  - statistics
    - clearing.....692
    - displaying.....694
  - status, displaying.....693
- Integrated Local Management Interface *See* ILMI
- integrated routing and bridging interfaces
  - integrated routing and bridging interfaces,
    - displaying.....312
- Integrated Services Digital Network *See* ISDN
- interface descriptions
  - displaying.....32
- Interface flags field, content.....144
- interface names
  - conventions.....4
  - loopback interfaces.....8
  - nonconfigurable interfaces.....11
  - routing interfaces.....11
  - services interfaces.....20
  - wildcard characters in.....6
- interfaces
  - container interfaces.....22
- internal Ethernet interface
  - described.....9
  - status information, displaying.....1029
- ip- interface.....20
  - described.....20
  - See also* IP-over-IP interfaces
- IP-over-IP interfaces
  - status information, displaying.....966
- ipip interface.....11
  - described.....11
  - See also* nonconfigurable interfaces
- ISDN
  - B-channel interfaces, displaying.....709
  - BRI interfaces, displaying.....715
  - calls, displaying.....736
  - D-channel interfaces, displaying.....720
  - default software values, displaying.....703
  - dialer interfaces, displaying.....705, 726
  - dialer pools, displaying.....707
  - history, displaying.....737
  - q921 statistics
    - clearing.....701
    - displaying.....738
  - q931 statistics
    - clearing.....702
    - displaying.....740
  - status, displaying.....743
- J**
- J Series router physical interfaces.....15
- J Series services interfaces.....22
- L**
- label-switched interface *See* LSI
- Label-switched interface (LSI) traffic statistics field,
  - content.....146
- LACP
  - displaying.....321
- LACP statistics
  - clearing.....158
  - displaying.....325
- Link Aggregation Control Protocol statistics
  - clearing.....158
  - displaying.....325
- Link flags field, content.....145
- link services interfaces
  - status information, displaying.....894
- link services IQ interfaces
  - status information, displaying.....907
- link-protected aggregated Ethernet interfaces
  - manually switching to the backup link.....175
  - reverting to the primary link.....175
- link-protected aggregated Ethernet LACP links
  - manually switching.....176
- linktrace
  - database, displaying.....355
  - tracing.....422

lo0 interface.....	8	mo- interface.....	21
described.....	8	described.....	21
<i>See also</i> loopback interface		<i>See also</i> flow monitoring interfaces	
Logical interface flags field.....	145	mt- interface.....	21
logical interfaces		described.....	21
assigned to a logical system.....	16	<i>See also</i> multicast tunnel interfaces	
unit numbers.....	5	mtun interface.....	11
logical systems		described.....	11
show interfaces command output.....	16	<i>See also</i> nonconfigurable interfaces	
logical tunnel interfaces		multi-chassis link aggregation interface	
status information, displaying.....	971	displaying.....	335
loopback interface		multicast tunnel interfaces	
status information, displaying.....	1018	status information, displaying.....	976
loopback protocol		multilink interfaces	
ping ethernet command.....	172	status information, displaying.....	932
ls- interface.....	20	Multiplex Section Protection <i>See</i> MSP	
described.....	20	MX Series router physical interfaces.....	14
<i>See also</i> link services interfaces			
LSI		<b>N</b>	
traffic statistics.....	146	non-link-protected aggregated Ethernet interfaces	
lsi interface.....	11	manually rebalancing subscribers.....	174
described.....	11	rebalancing subscribers.....	174
<i>See also</i> nonconfigurable interfaces		nonconfigurable interfaces.....	11
lsq- interface.....	21	notice icons defined.....	xv
described.....	21		
<i>See also</i> link services IQ interfaces		<b>O</b>	
lt- interface.....	21	OAM state	
described.....	21	clearing.....	169
<i>See also</i> logical tunnel interfaces		OAM statistics	
		clearing.....	170
<b>M</b>		oc3- interface.....	13
M Series physical interfaces.....	12	described.....	13
M Series services interfaces.....	20	<i>See also</i> channelized OC3 IQ and IQE interfaces	
MAC database, displaying.....	330		
management interface <i>See</i> Ethernet interfaces		<b>P</b>	
manuals		parentheses, in syntax descriptions.....	xvi
comments on.....	xvii	pd- interface.....	21
Media Gateway Controller <i>See</i> MGC		described.....	21
media-specific interface information		<i>See also</i> PIM de-encapsulation interfaces	
displaying.....	65	pe- interface.....	21
MGC		described.....	21
list, clearing on the TGM550 module.....	992	<i>See also</i> PIM encapsulation interfaces	
list, configuring on the TGM550		PIM de-encapsulation interfaces	
module.....	993, 994	status information, displaying.....	982
ml- interface.....	21	PIM encapsulation interfaces	
described.....	21	status information, displaying.....	982
<i>See also</i> multilink interfaces		pimd interface.....	11
		described.....	11
		<i>See also</i> nonconfigurable interfaces	

- pime interface.....11
    - described.....11
    - See also nonconfigurable interfaces
  - ping ethernet command.....172
  - Policer field, content.....147
  - policers, interface information
    - displaying.....67
  - pp0- interface.....13, 15
    - described.....13, 15
    - See also PPPoE
  - PPP
    - address pools, displaying.....501
    - interfaces, displaying.....503
    - statistics
      - clearing.....500
      - displaying.....512
  - PPPoE
    - interfaces, displaying.....527, 539
    - lockout
      - clearing.....523
      - displaying.....544
    - service name tables, displaying.....546
    - service name tables, displaying active sessions.....549
    - statistics
      - clearing.....526
      - displaying.....551
    - underlying interfaces, displaying.....553
    - version, displaying.....558
  - protection group
    - ethernet APS.....177, 178, 179, 180, 181
    - ethernet ring APS.....407
    - ethernet ring interface.....411
    - ethernet ring node state.....414
    - ethernet ring statistics.....417
    - ethernet ring VLANs.....409, 420
  - protection group statistics
    - clearing.....171
  - Protocol field, content.....147
- R**
- real-time monitoring
    - APS groups and interfaces.....582
  - redundant adaptive services interfaces
    - reverting to the primary interface.....856
    - status information, displaying.....865
    - switching to the secondary interface.....856
  - redundant link services IQ interfaces
    - status information, displaying.....941
  - request interface (revert | switchover) (Adaptive Services) command.....856
  - request interface (revert | switchover) (Aggregated Ethernet Link Protection) command.....175
  - request interface rebalance (Aggregated Ethernet for Subscriber Management) command.....174
  - request lacp link-switchover command.....176
  - request protection-group ethernet-aps clear.....177
  - request protection-group ethernet-aps
    - exercise.....178
  - request protection-group ethernet-aps
    - force-switch.....179
  - request protection-group ethernet-aps
    - lockout.....180
  - request protection-group ethernet-aps
    - manual-switch.....181
  - request tgm login fpc command.....993
  - rlsq- interface.....22
    - described.....22
    - See also redundant link services IQ interfaces
  - routing information
    - interfaces
      - state, displaying.....108
      - summary, displaying.....114
  - routing interfaces
    - types, defined.....11
  - RPF Failures field, content.....148
  - rsp- interface.....21
    - described.....21
    - See also redundant adaptive services interfaces
- S**
- se- interface.....13
    - described.....13
    - See also serial interfaces
  - serial interfaces
    - status information, displaying.....564
  - services interfaces
    - types, described.....20
  - set tgm fpc command.....994
  - SHDSL
    - ATM-over-SHDSL interfaces
      - status information, displaying.....681
  - show aps command.....582
  - show dialer defaults command.....703
  - show dialer interfaces command.....705
  - show dialer pools command.....707
  - show ilmi command.....693
  - show ilmi statistics command.....694

show interfaces		
logical system context.....	16	
show interfaces (10-Gigabit Ethernet)		
command.....	236	
show interfaces (Adaptive Services)		
command.....	857	
show interfaces (Aggregated Ethernet)		
command.....	182	
show interfaces (Aggregated SONET/SDH)		
command.....	587	
show interfaces (ATM) command.....	638	
show interfaces (ATM-over-ADSL)		
command.....	673	
show interfaces (ATM-over-SHDSL)		
command.....	681	
show interfaces (Channelized DS3-to-DS0)		
command.....	821	
show interfaces (Channelized DS3-to-DS1)		
command.....	832	
show interfaces (Channelized E1 IQ)		
command.....	759	
show interfaces (Channelized E1) command.....	748	
show interfaces (Channelized OC12 IQ)		
command.....	789	
show interfaces (Channelized OC12)		
command.....	785	
show interfaces (Channelized OC3 IQ and IQE)		
command.....	766	
show interfaces (Channelized OC48 IQ)		
command.....	796	
show interfaces (Channelized STM1 IQ)		
command.....	815	
show interfaces (Channelized STM1)		
command.....	800	
show interfaces (Channelized T1 IQ)		
command.....	835	
show interfaces (Channelized T3 IQ)		
command.....	848	
show interfaces (discard) command.....	1010	
show interfaces (Dynamic Flow Capture)		
command.....	878	
show interfaces (Encryption) command.....	870	
show interfaces (Fast Ethernet) command.....	194	
show interfaces (Flow Collector) command.....	882	
show interfaces (Flow Monitoring)		
command.....	888	
show interfaces (Gigabit Ethernet) command.....	212	
show interfaces (GRE) command.....	958	
show interfaces (IP-over-IP) command.....	966	
show interfaces (ISDN B-channel) command.....	709	
show interfaces (ISDN BRI) command.....	715	
show interfaces (ISDN D-channel) command.....	720	
show interfaces (ISDN dialer) command.....	726	
show interfaces (J Series Management Ethernet)		
command.....	1048	
show interfaces (Link Services IQ) command.....	907	
show interfaces (Link Services) command.....	894	
show interfaces (Logical Tunnel) command.....	971	
show interfaces (Loopback) command.....	1018	
show interfaces (M Series and T		
Series Management and Internal Ethernet)		
command.....	1029	
show interfaces (Multicast Tunnel)		
command.....	976	
show interfaces (Multilink Services)		
command.....	932	
show interfaces (PIM) command.....	982	
show interfaces (PPPoE) command.....	527	
show interfaces (Redundant Adaptive Services)		
command.....	865	
show interfaces (Redundant Link Services IQ)		
command.....	941	
show interfaces (Serial) command.....	564	
show interfaces (SONET/SDH) command.....	595	
show interfaces (T1, E1, or DS) command.....	440	
show interfaces (T3 or E3) command.....	465	
show interfaces (TGM550 module)		
command.....	995	
show interfaces (Virtual Loopback Tunnel)		
command.....	986	
show interfaces brief command.....	30	
show interfaces controller (Channelized E1 IQ)		
command.....	764	
show interfaces controller (Channelized OC12 IQ)		
command.....	794	
show interfaces controller (Channelized OC3 IQ		
and IQE) command.....	793	
show interfaces controller (Channelized STM1 IQ)		
command.....	818	
show interfaces controller (Channelized T1 IQ)		
command.....	850	
show interfaces controller (Channelized T3 IQ)		
command.....	851	
show interfaces demux0 (Demux Interfaces)		
command.....	486	
show interfaces descriptions command.....	32	
show interfaces destination-class command.....	34	
show interfaces detail command.....	37	



- 
- show interfaces diagnostics optics (Gigabit Ethernet) command.....295
  - show interfaces diagnostics optics (SONET) command.....624
  - show interfaces extensive command.....40, 263
  - show interfaces far-end-interval.....192
  - show interfaces filters command.....60
  - show interfaces interface-set command.....283
  - show interfaces interface-set queue command.....286
  - show interfaces interval command.....62
  - show interfaces irb command.....312
  - show interfaces mac-database (Gigabit Ethernet) command.....330
  - show interfaces mc-ae.....335
  - show interfaces media command.....65
  - show interfaces queue command.....69
  - show interfaces redundancy command.....867
  - show interfaces routing command.....108
  - show interfaces routing summary command.....114
  - show interfaces routing-instance command.....118
  - show interfaces snmp-index command.....120
  - show interfaces source-class command.....121
  - show interfaces statistics command.....124
  - show interfaces targeting command.....319
  - show interfaces terse command.....137
  - show isdn calls command.....736
  - show isdn history command.....737
  - show isdn q921 statistics command.....738
  - show isdn q931 statistics command.....740
  - show isdn status command.....743
  - show lacp interfaces command.....321
  - show lacp statistics command.....325
  - show lacp timeouts.....327
  - show oam ethernet connectivity-fault-management delay-statistics command.....337
  - show oam ethernet connectivity-fault-management forwarding-state command.....341
  - show oam ethernet connectivity-fault-management interfaces command.....345
  - show oam ethernet connectivity-fault-management linktrace path-database command.....355
  - show oam ethernet connectivity-fault-management loss-statistics command.....378
  - show oam ethernet connectivity-fault-management mep-database command.....357
  - show oam ethernet connectivity-fault-management mep-statistics command.....367
  - show oam ethernet connectivity-fault-management mip command.....384
  - show oam ethernet connectivity-fault-management path-database command.....386
  - show oam ethernet connectivity-fault-management policer command.....388
  - show oam ethernet fnp interface.....392
  - show oam ethernet fnp messages.....393
  - show oam ethernet fnp status.....395
  - show oam ethernet link-fault-management command.....397
  - show ppp address-pool command.....501
  - show ppp interface command.....503
  - show ppp statistics command.....512
  - show ppp summary command.....519
  - show pppoe interfaces command.....539
  - show pppoe lockout command.....544
  - show pppoe service-name-tables command.....546
  - show pppoe sessions command.....549
  - show pppoe statistics command.....551
  - show pppoe underlying-interfaces command.....553
  - show pppoe version command.....558
  - show protection-group ethernet-ring aps command.....407
  - show protection-group ethernet-ring data-channel command.....409
  - show protection-group ethernet-ring interface command.....411
  - show protection-group ethernet-ring node-state command.....414
  - show protection-group ethernet-ring statistics command.....417
  - show protection-group ethernet-ring vlan command.....420
  - show tgm dynamic-call-admission-control command.....1003
  - show tgm fpc command.....1004
    - dsp-capacity.....1004
  - show tgm fpc telephony-interface-module command.....1006
    - status.....1006
  - show vrrp command.....427
  - SNMP index
    - interface information, displaying.....120
  - so- interface.....13
    - See also channelized OC3 IQ and IQE interfaces
  - SONET interfaces
    - diagnostics information, displaying.....624

SONET/SDH interfaces	
status information, displaying	
aggregated.....	587
standard.....	595
source class	
interface information	
displaying.....	121
Source class field, content.....	148
sp- interface.....	20
described.....	20
<i>See also</i> adaptive services interfaces	
statistics	
interface set	
clearing.....	29
interfaces	
clearing.....	28
displaying.....	124
support, technical <i>See</i> technical support	
symmetric high-speed digital subscriber line <i>See</i>	
SHDSL	
syntax conventions.....	xv
<b>T</b>	
T Series physical interfaces.....	12
T Series services interfaces.....	20
T1 interfaces	
status information, displaying.....	440
t1- interface.....	14
<i>See also</i> channelized DS3-to-DS1 interfaces	
<i>See also</i> channelized T3 IQ and IQE interfaces	
T3 interfaces	
status information, displaying.....	465
t3- interface.....	14
<i>See also</i> channelized T3 IQ and IQE interfaces	
tap interface.....	11
described.....	11
<i>See also</i> nonconfigurable interfaces	
technical support	
contacting JTAC.....	xvii
TGM550 module	
CAC information, displaying.....	1003
FPCs, displaying.....	1004
interfaces, displaying.....	995
MGC list, configuring.....	993, 994
MGC, list, clearing.....	992
TIM status, displaying.....	1006
traceroute ethernet.....	422
traceroute ethernet command.....	422
tunnel services interfaces.....	957, 990
<b>V</b>	
virtual loopback tunnel interfaces	
status information, displaying.....	986
Virtual Router Redundancy Protocol <i>See</i> VRRP	
VRF table label	
traffic statistics.....	146
VRRP	
statistics	
clearing.....	426
displaying.....	427
vt- interface.....	22
described.....	22
<i>See also</i> virtual loopback tunnel interfaces	
<b>W</b>	
wildcard characters	
in interface names.....	6
<b>X</b>	
xe- interface.....	13, 14
described.....	13, 14
<i>See also</i> 10-Gigabit Ethernet interfaces	

# Index of Statements and Commands

## C

clear auto-configuration interfaces command.....	156
clear auto-configuration interfaces interface-set command.....	157
clear ilmi statistics command.....	692
clear interfaces interface-set statistics command.....	29, 162
clear interfaces interval command.....	25
clear interfaces mac-database command.....	160
clear interfaces mac-database statistics command.....	161
clear interfaces statistics command.....	28
clear isdn q921 statistics command.....	701
clear isdn q931 statistics command.....	702
clear lacp statistics command.....	158
clear oam ethernet connectivity-fault-management continuity-measurement command.....	163
clear oam ethernet connectivity-fault-management delay-statistics command.....	164
clear oam ethernet connectivity-fault-management linktrace path-database command.....	165
clear oam ethernet connectivity-fault-management loss-statistics command.....	166
clear oam ethernet connectivity-fault-management policer command.....	167
clear oam ethernet connectivity-fault-management statistics.....	168
clear oam ethernet link-fault-management state command.....	169
clear oam ethernet link-fault-management statistics command.....	170
clear ppp statistics command.....	500
clear pppoe lockout command.....	523
clear pppoe sessions command.....	525
clear pppoe statistics command.....	526

clear protection-group ethernet-ring statistics command.....	171
clear tgm fpc command.....	992
clear vrrp command.....	426

## F

fnp statement	
show oam ethernet fnp interface.....	392
show oam ethernet fnp messages.....	393
show oam ethernet fnp status .....	395

## P

ping ethernet command.....	172
----------------------------	-----

## R

request interface (revert   switchover) (Adaptive Services) command.....	856
request interface (revert   switchover) (Aggregated Ethernet Link Protection) command.....	175
request interface rebalance (Aggregated Ethernet for Subscriber Management) command.....	174
request lacp link-switchover command.....	176
request protection-group ethernet-aps clear.....	177
request protection-group ethernet-aps exercise.....	178
request protection-group ethernet-aps force-switch.....	179
request protection-group ethernet-aps lockout.....	180
request protection-group ethernet-aps manual-switch.....	181
request tgm login fpc command.....	993

## S

set tgm fpc command.....	994
show aps command.....	582
show dialer defaults command.....	703
show dialer interfaces command.....	705
show dialer pools command.....	707
show ilmi command.....	693
show ilmi statistics command.....	694
show interfaces (10-Gigabit Ethernet) command.....	236
show interfaces (Adaptive Services) command.....	857
show interfaces (Aggregated Ethernet) command.....	182
show interfaces (Aggregated SONET/SDH) command.....	587

show interfaces (ATM) command.....	638
show interfaces (ATM-over-ADSL) command.....	673
show interfaces (ATM-over-SHDSL) command.....	681
show interfaces (Channelized DS3-to-DS0) command.....	821
show interfaces (Channelized DS3-to-DS1) command.....	832
show interfaces (Channelized E1 IQ) command.....	759
show interfaces (Channelized E1) command.....	748
show interfaces (Channelized OC12 IQ) command.....	789
show interfaces (Channelized OC12) command.....	785
show interfaces (Channelized OC3 IQ and IQE) command.....	766
show interfaces (Channelized OC48 IQ) command.....	796
show interfaces (Channelized STM1 IQ) command.....	815
show interfaces (Channelized STM1) command.....	800
show interfaces (Channelized T1 IQ) command.....	835
show interfaces (Channelized T3 IQ) command.....	848
show interfaces (discard) command.....	1010
show interfaces (Dynamic Flow Capture) command.....	878
show interfaces (Encryption) command.....	870
show interfaces (Fast Ethernet) command.....	194
show interfaces (Flow Collector) command.....	882
show interfaces (Flow Monitoring) command.....	888
show interfaces (Gigabit Ethernet) command.....	212
show interfaces (GRE) command.....	958
show interfaces (IP-over-IP) command.....	966
show interfaces (ISDN B-channel) command.....	709
show interfaces (ISDN BRI) command.....	715
show interfaces (ISDN D-channel) command.....	720
show interfaces (ISDN dialer) command.....	726
show interfaces (J Series Management Ethernet) command.....	1048
show interfaces (Link Services IQ) command.....	907
show interfaces (Link Services) command.....	894
show interfaces (Logical Tunnel) command.....	971
show interfaces (Loopback) command.....	1018
show interfaces (M Series and T Series Management and Internal Ethernet) command.....	1029
show interfaces (Multicast Tunnel) command.....	976
show interfaces (Multilink Services) command.....	932
show interfaces (PIM) command.....	982
show interfaces (PPPoE) command.....	527
show interfaces (Redundant Adaptive Services) command.....	865
show interfaces (Redundant Link Services IQ) command.....	941
show interfaces (Serial) command.....	564
show interfaces (SONET/SDH) command.....	595
show interfaces (T1, E1, or DS) command.....	440
show interfaces (T3 or E3) command.....	465
show interfaces (TGM550 module) command.....	995
show interfaces (Virtual Loopback Tunnel) command.....	986
show interfaces brief command.....	30
show interfaces controller (Channelized E1 IQ) command.....	764
show interfaces controller (Channelized OC12 IQ) command.....	794
show interfaces controller (Channelized OC3 IQ and IQE) command.....	793
show interfaces controller (Channelized STM1 IQ) command.....	818
show interfaces controller (Channelized T1 IQ) command.....	850
show interfaces controller (Channelized T3 IQ) command.....	851
show interfaces demux0 (Demux Interfaces) command.....	486
show interfaces descriptions command.....	32
show interfaces destination-class command.....	34
show interfaces detail command.....	37
show interfaces diagnostics optics (Gigabit Ethernet) command.....	295
show interfaces diagnostics optics (SONET) command.....	624
show interfaces extensive command.....	40, 263
show interfaces far-end-interval.....	192
show interfaces filters command.....	60
show interfaces interface-set command.....	283
show interfaces interface-set queue command.....	286

show interfaces interval command.....	62	show ppoe interfaces command.....	539
show interfaces irb command.....	312	show ppoe lockout command.....	544
show interfaces mac-database (Gigabit Ethernet) command.....	330	show ppoe service-name-tables command.....	546
show interfaces mc-ae.....	335	show ppoe sessions command.....	549
show interfaces media command.....	65	show ppoe statistics command.....	551
show interfaces queue command.....	69	show ppoe underlying-interfaces command.....	553
show interfaces redundancy command.....	867	show ppoe version command.....	558
show interfaces routing command.....	108	show protection-group ethernet-ring aps command.....	407
show interfaces routing summary command.....	114	show protection-group ethernet-ring data-channel command.....	409
show interfaces routing-instance command.....	118	show protection-group ethernet-ring interface command.....	411
show interfaces snmp-index command.....	120	show protection-group ethernet-ring node-state command.....	414
show interfaces source-class command.....	121	show protection-group ethernet-ring statistics command.....	417
show interfaces statistics command.....	124	show protection-group ethernet-ring vlan command.....	420
show interfaces targeting command.....	319	show tgm dynamic-call-admission-control command.....	1003
show interfaces terse command.....	137	show tgm fpc command.....	1004
show isdn calls command.....	736	dsp-capacity.....	1004
show isdn history command.....	737	show tgm fpc telephony-interface-module command.....	1006
show isdn q921 statistics command.....	738	status.....	1006
show isdn q931 statistics command.....	740	show vrrp command.....	427
show isdn status command.....	743		
show lacp interfaces command.....	321	<b>T</b>	
show lacp statistics command.....	325	traceroute ethernet command.....	422
show oam ethernet connectivity-fault-management delay-statistics command.....	337		
show oam ethernet connectivity-fault-management forwarding-state command.....	341		
show oam ethernet connectivity-fault-management interfaces command.....	345		
show oam ethernet connectivity-fault-management linktrace path-database command.....	355		
show oam ethernet connectivity-fault-management loss-statistics command.....	378		
show oam ethernet connectivity-fault-management mep-database command.....	357		
show oam ethernet connectivity-fault-management mep-statistics command.....	367		
show oam ethernet connectivity-fault-management mip command.....	384		
show oam ethernet connectivity-fault-management path-database command.....	386		
show oam ethernet connectivity-fault-management policer command.....	388		
show oam ethernet link-fault-management command.....	397		
show ppp address-pool command.....	501		
show ppp interface command.....	503		
show ppp statistics command.....	512		
show ppp summary command.....	519		

