

## multilink-class

---

<b>Syntax</b>	multilink-class <i>number</i> ;
<b>Hierarchy Level</b>	[edit class-of-service fragmentation-maps <i>map-name</i> forwarding-class <i>class-name</i> ]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	<p>For AS PIC link services IQ interfaces (lsq) only, map a forwarding class into a multiclass MLPPP (MCML).</p> <p>The multilink-class statement and no-fragmentation statements are mutually exclusive.</p>
<b>Options</b>	<p><i>number</i>—The multilink class assigned to this forwarding class.</p> <p><b>Range:</b> 0 through 7</p> <p><b>Default:</b> None</p>
<b>Usage Guidelines</b>	See Configuring Fragmentation by Forwarding Class and the <i>JUNOS Services Interfaces Configuration Guide</i> .
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

---

Published: 2010-04-15