

## [edit forwarding-options helpers] Hierarchy Level

---

```
forwarding-options {
  helpers {
    bootp {
      client-response-ttl number;
      description text-description;
      dhcp-option82 {
        disable;
        circuit-id {
          prefix hostname;
          use-interface-description;
          use-vlan-id;
        }
        remote-id {
          prefix (hostname | mac | none);
          use-interface-description;
          use-string text-string;
        }
        vendor-id {
          text-string;
        }
      }
    }
    interface interface-name-or-wildcard {
      broadcast;
      client-response-ttl number;
      description text-description;
      dhcp-option82 {
        ... same statements as at the [edit forwarding-options helpers bootp]
            hierarchy level ...
      }
      maximum-hop-count number;
      minimum-wait-time seconds;
      no-listen;
      server address {
        logical-system logical-system-name <routing-instance [ <default>
            routing-instance-names ]>;
        routing-instance [ <default> routing-instance-names ];
      }
    }
    maximum-hop-count number;
    minimum-wait-time seconds;
    relay-agent-option;
    server address {
      logical-system logical-system-name <routing-instance [ <default>
          routing-instance-names ]>;
      routing-instance [ <default> routing-instance-names ];
    }
    vpn;
  }
}

helpers {
  domain {
```

```

description text-description;
interface {
    interface-name {
        broadcast;
        description text-description;
        no-listen;
        server <address> <logical-system logical-system-name>
            <routing-instance (default | routing-instance-name)>;
    }
}
server <address> <logical-system logical-system-name>
    <routing-instance (default | routing-instance-name)>;
}

helpers {
    port port-number {
        description text-description;
        interface {
            interface-name {
                broadcast;
                description text-description;
                no-listen;
                server <address> <logical-system logical-system-name>
                    <routing-instance (default | routing-instance-name)>;
            }
        }
        server <address> <logical-system logical-system-name>
            <routing-instance (default | routing-instance-name)>;
    }
}

helpers {
    tftp {
        description text-description;
        interface {
            interface-name {
                broadcast;
                description text-description;
                no-listen;
                server <address> <logical-system logical-system-name>
                    <routing-instance (default | routing-instance-name)>;
            }
        }
        server <address> <logical-system logical-system-name>
            <routing-instance (default | routing-instance-name)>;
    }
}

helpers {
    traceoptions {
        file <filename> <files number> <match regular-expression>
            <size maximum-file-size> <world-readable | no-world-readable>;
        flag flag;
        level severity;
    }
}

```

```
        no-remote-trace;  
    }  
}
```

- Related Topics**
- Notational Conventions Used in JUNOS Configuration Hierarchies
  - [edit forwarding-options] Hierarchy Level

---

Published: 2010-04-28