

vJunosEvolved Deployment Guide for KVM

Published
2023-05-26

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, the Juniper Networks logo, Juniper, and Junos are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

vJunosEvolved Deployment Guide for KVM

Copyright © 2023 Juniper Networks, Inc. All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <https://support.juniper.net/support/eula/>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

About This Guide | v

1

Overview

What is vJunosEvolved | 2

 Overview | 2

 Key Features | 3

 Benefits and Uses | 3

 Limitations | 4

vJunosEvolved Architecture | 5

2

Hardware and Software Requirements on KVM

Minimum Hardware and Software Requirements | 8

3

Install and Deploy vJunosEvolved on KVM

Install vJunosEvolved on KVM | 11

 Prepare the Linux Host Servers to Install vJunosEvolved | 11

Deploy and Manage vJunosEvolved on KVM | 11

 Set Up the vJunosEvolved Deployment on the Host Server | 12

 Verify the vJunosEvolved VM | 16

Configure vJunosEvolved on KVM | 18

 Connect to vJunosEvolved | 18

 Configure vJunosEvolved Channelization Interfaces | 18

 Configure the Media MTU | 20

4

Verify and Troubleshoot

Verify vJunosEvolved on KVM | 23

 Verify That the VM is Running | 23

 Verify CPU Information | 24

View Log Files | 25

Collect Core Files | 25

About This Guide

Use this guide to install the virtual JunosEvolved (vJunosEvolved) on KVM. This guide includes basic vJunosEvolved configuration and management procedures.

vJunosEvolved is a virtual version of the Junos OS Evolved-based PTX switching platform that represents a Juniper Networks® switch running Junos OS Evolved in kernel-based virtual machine (KVM) environment.

After installing and configuring the vJunosEvolved platform as covered in this guide, refer to Junos® operating system Evolved (Junos OS Evolved) documentation for information about additional software configurations.

RELATED DOCUMENTATION

| [Junos OS Evolved Documentation](#)

1

PART

Overview

[What is vJunosEvolved | 2](#)

[vJunosEvolved Architecture | 5](#)

What is vJunosEvolved

SUMMARY

This topic provides an overview, key features, benefits, and limitations of vJunosEvolved.

IN THIS SECTION

- [Overview | 2](#)
- [Key Features | 3](#)
- [Benefits and Uses | 3](#)
- [Limitations | 4](#)

Overview

IN THIS SECTION

- [vJunosEvolved Installation Overview | 3](#)

vJunosEvolved is a virtual version of a Juniper switch that runs the Junos OS Evolved. You can install a vJunosEvolved as a virtual machine (VM) on an x86 server.

You can configure and manage the vJunosEvolved in the same way as you manage a physical switch.

vJunosEvolved is a single virtual machine (VM) that you can use only in labs and not in the production environment. The vJunosEvolved is built using PTX10001-36MR as a reference Juniper switch, which is a fixed-configuration packet transport router on the Junos® OS Evolved platform.

The vJunosEvolved Routing Engine and the vBT-COSIM (a virtual BT chip) that performs the packet processing run on the same VM.

Instead of using hardware switches, you can use the vJunosEvolved to start the Junos software for testing the network configurations and protocols.

The vJunosEvolved virtual platform primarily acts as a test platform for lab simulations for the customers.

NOTE: Bandwidth licenses are not required and are not provided. You can ignore any license check messages if you get an alert.

vJunosEvolved Installation Overview

You can install the software components of vJunosEvolved on an industry-standard x86 server running a Linux KVM hypervisor (Ubuntu 18.04, 20.04, 22.04 or Debian 11 Bullseye).

On servers running the KVM hypervisor, you can also run applicable third-party software. You can install multiple vJunosEvolved instances on a single server.

Key Features

This topic provides you a list of key features that the vJunosEvolved platform supports.

The vJunosEvolved platform supports the following key features:

- Supports up to 12 switch interfaces and 25 channelized interfaces.
- Can simulate data center IP underlay and overlay topologies.
- Supports EVPN-VXLAN leaf and spine functionality
- Support EVPN-VXLAN border functionality (Type 5 to Type 5 stitching currently)
- Supports EVPN LAG multihoming in EVPN-VXLAN (ESI-LAG)

For details on configuration of these features, refer to [Software Documentation](#).

Benefits and Uses

The benefits and use cases of vJunosEvolved on standard x86 servers are as follows:

- **Reduce capital expenditure on physical lab**—You can use the vJunosEvolved platform for free to build test labs. This reduces the costs associated with physical switches and routers.
- **Reduce deployment time**—You can use the vJunosEvolved platform to build and test topologies virtually without building expensive physical labs. You can build virtual labs instantly, which helps in reducing costs and delays related to physical hardware deployment.

- **Eliminate lab hardware**—You can eliminate using lab hardware by downloading the vJunosEvolved platform instantly and for free
- **Educate and train**—You can use the vJunosEvolved platform to build labs for learning and education services for your employees.
- **Automate, build, and validate**—You can use the vJunosEvolved platform to validate various data center switching and routing topologies, pre-build configurations examples, and get automation ready.

The vJunosEvolved is intended only for lab use and not for commercial deployment.

Limitations

The vJunosEvolved has the following limitations:

- The vJunosEvolved has a fixed-form Junos OS Evolved architecture.
- You cannot upgrade vJunosEvolved on a running system. Instead, you can deploy a new instance with the new software.

The vJunosEvolved does not support in-service software upgrade (ISSU).

You cannot attach or detach interfaces while vJunosEvolved is running.

- Supports a maximum bandwidth of 2 Kpps or 3-5 Mbps over all the interfaces.
- To channelize WAN interfaces, run a boot argument with **channelized=yes** that is specified in the VM config and the interfaces speed config at vJunosEvolved CLI.

Example: `set interfaces et-0/0/0 speed 25g number-of-sub-ports 8`

- For non-channelization, **channelized=no** is the default config.
- vJunosEvolved does not support single-root I/O virtualization (SR-IOV)
- COSIM reliably works up to 2000 pps across 128B-1500B packet length. You do not need a bandwidth license.
- Currently maximum of 25 channelized interfaces are supported. Provisioning the 26th channelized interface leads to unstable system behavior or VM crash and is not advised.
- For vJunosEvolved to function correctly as a Virtual Extensible LAN (VXLAN) Tunnel End Point (VTEP), you must configure tunnel termination using the `set forwarding-options tunnel-termination` command. Otherwise the traffic in the tunnel drops on the egress VTEP.

vJunosEvolved does not support the following features:

- Port mirroring
- Storm control
- Multichassis link aggregation (MC-LAG)
- VXLAN seamless stitching for Data Center Interconnect (DCI)
- Virtual Router Redundancy Protocol (VRRP)
- Multicast
- Q-in-Q tunneling through an Ethernet VPN–Virtual Extensible LAN (EVPN-VXLAN) fabric
- Layer-2 egress filtering on EVPN-VXLAN-enabled integrated routing and bridging (IRB) interfaces
- IPv6 underlay and overlay
- MAC filtering in EVPN-VXLAN fabric using a MAC list
- EVPN-VXLAN fabric enhanced loop detection using connectivity fault management (CFM)


vJunosEvolved Architecture

The vJunosEvolved is a single VM solution where the Junos OS Evolved Routing Engine (RE), Packet Forwarding Engine (PFE) and vBT-COSIM run on the same VM. KVM is the hypervisor used to deploy Junos OS Evolved Linux VM.

When vJunosEvolved instance boots up, the vBT-COSIM simulation is also initialized along with Routing Engine and Packet Forwarding Engine (PFE).

vJunosEvolved can support up to 2000 pps of throughput (as per vBT-COSIM's specifications) using 4 cores and 8GB memory. Any additional cores and memory configured are allocated to the Junos OS Evolved Routing Engine. For the anticipated lab use cases, 4 cores and 8GB memory is sufficient.

Figure 1: vJunosEvolved Architecture



2

PART

Hardware and Software Requirements on KVM

Minimum Hardware and Software Requirements | 8

Minimum Hardware and Software Requirements

This topic provides you a list of hardware and software requirements to start a vJunosEvolved instance.

Minimum Hardware Requirements for vJunosEvolved lists the hardware requirements for vJunosEvolved.

Table 1: Minimum Hardware Requirements for vJunosEvolved

| Description | Value |
|-----------------------------|--|
| Sample system configuration | <p>For lab simulation and low performance (less than 100 Mbps) use cases, any x86 processor (Intel or AMD) with VT-x capability.</p> <p>Intel Ivy Bridge processors or later.</p> <p>Example of Ivy Bridge processor: Intel Xeon E5-2667 v2 @ 3.30 GHz 25 MB cache</p> |
| Number of cores | <p>A minimum of 4 cores are required.</p> <p>This is the standard support with vJunosEvolved platform and can be adjusted in the configuration based on requirement.</p> |
| Memory | <p>A minimum of 8GB is required.</p> |
| Other requirements | <ul style="list-style-type: none"> • Intel VT-x capability. • Hyperthreading (recommended) • AES-NI |

Table 2: Software Requirements for Ubuntu

| Description | Value |
|--|--|
| Operating system NOTE: Only English localization is supported. | <ul style="list-style-type: none"> • Ubuntu 22.04 LTS • Ubuntu 20.04 LTS • Ubuntu 18.04 LTS • Debian 11 Bullseye |

Table 2: Software Requirements for Ubuntu (*Continued*)

| Description | Value |
|--|---|
| Virtualization | <ul style="list-style-type: none"> • QEMU-KVM <p>The default version for each Ubuntu or Debian version is sufficient. The <code>apt-get install qemu-kvm</code> installs this default version.</p> |
| Required packages NOTE: Use the <code>apt-get install pkg-name</code> or <code>sudo apt-get install <pkg-name></code> commands to install a package. | <ul style="list-style-type: none"> • <code>qemu-kvm</code> <code>virt-manager</code> • <code>libvirt-daemon-system</code> • <code>virtinst</code> <code>libvirt-clients</code> <code>bridge-utils</code> |
| Supported Deployment Environments | QEMU-KVM using libvirt You can run vJunosEvolved with EVE-NG in a VM or on bare metal. |
| | QEMU-KVM using libvirt EVE-NG supported for both bare metal and in a VM. |
| vJunosEvolved Images | You can access the images from the vJunos Labs download area of juniper.net at: Test Drive Juniper |

3

PART

Install and Deploy vJunosEvolved on KVM

[Install vJunosEvolved on KVM | 11](#)

[Deploy and Manage vJunosEvolved on KVM | 11](#)

[Configure vJunosEvolved on KVM | 18](#)

Install vJunosEvolved on KVM

SUMMARY

Read this topic to understand how to install the vJunosEvolved in the KVM environment.

IN THIS SECTION

- [Prepare the Linux Host Servers to Install vJunosEvolved | 11](#)

Prepare the Linux Host Servers to Install vJunosEvolved

This section applies to both Ubuntu and Debian host servers.

1. Install the standard package versions for your Ubuntu or Debian host server to ensure that the servers meet the minimum hardware and software requirements.
2. Verify that Intel VT-x technology is enabled. Run the `lscpu` command on your host server.

The **Virtualization** field in the output of the `lscpu` command will display **VT-x**, if VT-x is enabled. If VT-x is not enabled, then see your server documentation to learn how to enable it in BIOS.

Deploy and Manage vJunosEvolved on KVM

SUMMARY

Read this topic to understand how to deploy and manage the vJunosEvolved instance after you install it on KVM.

IN THIS SECTION

- [Set Up the vJunosEvolved Deployment on the Host Server | 12](#)
- [Verify the vJunosEvolved VM | 16](#)

This topic describes:

- How to bring up vJunosEvolved on the KVM servers using libvirt.

- How to choose the amount of CPU and memory, set up the required bridges for connectivity, and configure the serial port.
- How to use relevant XML file sections for the configurations and selections listed earlier for deployment.

NOTE: Download the sample XML file and the vJunosEvolved image from the Juniper website.

Set Up the vJunosEvolved Deployment on the Host Server

This topic describes how to set up the vJunosEvolved deployment on the host server.

NOTE: This topic highlights only a few sections of the XML file that is used to deploy vJunosEvolved through libvirt.

The entire XML file **vJunosEvolved.xml** is available for download along with the VM image and associated documentation on the lab download page.

Install the packages mentioned in the minimum software requirements section, if they are not already installed. See Minimum Hardware Requirements for vJunosEvolved.

1. Create a Linux bridge for RPIO, Packet Forwarding Engine (PFE) links (Routing Engine-COSIM bridges), and WAN interfaces.

For example, et-0/0/0, et-0/0/1, and so on, of vJunosEvolved that you plan to use.

```
# ip link add PFE_LINK type bridge
# ip link add RPIO_LINK type bridge
# ip link add et000 type bridge
# ip link add et001 type bridge
```

NOTE: Currently, you must mention the PFE and RPIO bridge links for vJunosEvolved in the orchestration because the EVO architecture does not maintain ethernet interface numbering for these bridge links and may incorrectly consider the COSIM's WAN interfaces as the bridges, affecting the traffic path.

2. Make a live disk copy of the provided QCOW2 vJunosEvolved image.

```
# cd /root
# cp vJunosEvolved-<release>.qcow2 vJunosEvolved-<release>-live.qcow2
# chmod u+w vJunosEvolved-<release>-live.qcow2
```

Make a distinct copy for each vJunosEvolved that you plan to deploy. Making a live copy ensures that you do not make any permanent changes on the original image. The live image must also be writable by the userid deploying vJunosEvolved—typically the root user.

3. Specify the number of cores provided to vJunosEvolved by modifying the following stanza. For the default memory of 8GB required by vJunosEvolved, use the following code snippet:

```
<cpu>
  match="exact" mode="host-model">
    <topology cores="4" sockets="1" threads="1"/><model fallback="allow">qemu64</model>
    <feature name="svm" policy="disable"/>
</cpu>
```

NOTE: A sample **vJunosEvolved.xml** file is also available with the posted vJunosEvolved image. This document refers to key snippets from that sample file to illustrate the stanzas the you need to edit in the XML file.

Use the sample **vJunosEvolved.xml** snippet files that are available with the posted vJunosEvolved image to prevent errors.

The following codeblock provides an example CPU XML snippet, where the default number of cores required is 4, which is sufficient for most applications. You can increase the number of cores added, by modifying the below stanza.

```
<domain xmlns:ns0="http://libvirt.org/schemas/domain/qemu/1.0" type="kvm">
  <name>vJunosEvo</name>
  <memory unit="KiB">8388608</memory>
  <currentMemory unit="KiB">8388608</currentMemory>
  <vcpu placement="static">4</vcpu>
```

You can increase the memory if needed. It also shows the name of the specific vJunosEvolved being spawned, which is vJunosEvo in this case.

4. Modify the name and location of your vJunosEvolved image.

NOTE: For libvirt and QEMU-KVM, each vJunosEvolved VM on the host needs to be provided with its own uniquely named QCOW2 image.

Use the following XML snippet to specify the name and location for your vJunosEvolved image:

```
<disk device="disk" type="file">
  <driver cache="writeback" name="qemu" type="qcow2"/>
  <source file="/root/vJunosEvolved-live.qcow2"/>
  <target dev="vda" bus="virtio"/>
</disk>
```

5. Create the configuration disk image.

```
# ./make-config.sh <juniper.conf> <config.qcow2>
```

The vJunosEvolved accepts an initial configuration by connecting a second disk to the VM instance that contains the configuration. Use the provided script make-config.sh to create the disk image.

The XML file references this configuration drive as shown below:

```
<disk device="disk" type="file">
  <driver cache="writeback" name="qemu" type="qcow2"/>
  <source file="/root/config.qcow2"/>
  <target dev="vdb" bus="virtio"/>
</disk>
```

NOTE: If you do not prefer initial configuration, then remove the above stanza from the XML file.

6. Create a Linux bridge for each of the ports you specify in the XML file.

The port names are specified in the following codeblock.

The convention for vJunosEvolved is to use et00x. In the following example, et000 and et001 map to the Junos Evolved et-0/0/0 and et-0/0/1 interfaces respectively.

```
<interface>
  <interface type="bridge">
```

```

<source bridge="et000"/>
<model type="virtio"/>
<mtu size='9600' />
<alias name="net1"/>
<address bus="0x00" domain="0x0000" function="0x0" slot="0x08" type="pci"/>
</interface>
<interface type="bridge">
  <source bridge="et001"/>
  <model type="virtio"/>
  <mtu size='9600' />
  <alias name="net2"/>
  <address bus="0x00" domain="0x0000" function="0x0" slot="0x09" type="pci"/>
</interface>

```

7. Provide a unique serial console port number for each vJunosEvolved on your host server.

In this sample sinppet "8610" is chosen.

```

</interface>
<serial type="tcp">
<source host="127.0.0.1" mode="bind" service="8610"/>
<protocol type="telnet"/>
<target port="0"/>
<alias name="serial0"/>
</serial>

```

8. Create channelized or non-channelized interfaces.

The “channelized=yes” in the command line arg provides an option to create channelized WAN interfaces. If nothing mentioned or value of “no” mentioned, then non-channelized interfaces are initialized at COSIM.

```

<ns0:commandline>
  <ns0:arg value="-smbios"/>
  <ns0:arg value="type=0, vendor=Bochs, version=Bochs"/>
  <ns0:arg value="-smbios"/>
  <ns0:arg value="type=3, manufacturer=Bochs"/>
  <ns0:arg value="-smbios"/>
  <ns0:arg
  value="type=1, manufacturer=Bochs, product=Bochs, serial=chassis_no=0:slot=0:type=1:assembly_id=0

```

```
x0D20:platform=251:master=0: channelized=yes "/>
</ns0:commandline>
```

9. Create vJunosEvolved VM using the vJunosEvolved.xml file.

```
# virsh create vJunosEvolved.xml
```

This creates the first vJunosEvolved VM. The subsequent VMs can be vJunosEvolved2,vJunosEvolved3 and so on.

Domain vJunosEvolved created from **vJunosEvolved.xml**

Verify the vJunosEvolved VM

This topic describes how to verify whether vJunosEvolved is up and running.

1. Verify if the vJunosEvolved is up and running.

NOTE: The XML file for download is “vJunosEvolved.xml”. If you are creating more than one instance, then the domain and XML and live disk files names must be unique.

But for a single instance it looks like this:

```
# virsh list
  Id  Name      State
  -----
  74  vJunosEvolved running
```

2. Connect to the serial console of the Routing Engine VM.

You can find the port to connect to from the XML file.

NOTE: The telnet port number needs to be unique for each vJunosEvolved VM residing on the host server.

```
# telnet localhost 8610
Trying 127.0.0.1...
Connected to localhost.
```

```
Escape character is '^]'.
root@:~ #
```

3. Verify whether the ET interfaces that you had specified in your XML file are up.

```
show interfaces terse
```

For example if "et000" and "et001" were specified in your XML file, then the et-0/0/0 and et-0/0/1 interfaces should be in "up" state. Other interfaces also shows up, but those interfaces can't pass traffic.

```
root> show interfaces terse
Interface          Admin Link Proto  Local          Remote
et-0/0/0           up    up
et-0/0/0.16386     up    up    multiservice
pfh-0/0/0          up    up
pfh-0/0/0.16383   up    up    inet
et-0/0/1           up    up
et-0/0/1.16386    up    up    multiservice
[snip]
```

4. Verify whether a VNET interface under each corresponding "et" bridge is configured.

Use the brctl command on the host server once vJunosEvolved is started. This command shows a vnet interface under each corresponding "et" bridge:

```
# brctl show et000
bridge name    bridge id      STP enabled    interfaces
et000          8000.fe54001a0d69  no          vnet13
# brctl show et001
bridge name    bridge id      STP enabled    interfaces
et001          8000.fe540077af98  no          vnet14
```

Configure vJunosEvolved on KVM

SUMMARY

Read this topic to understand the connections and configurations of the vJunosEvolved instances deployment on KVM

IN THIS SECTION

- [Connect to vJunosEvolved | 18](#)
- [Configure vJunosEvolved Channelization Interfaces | 18](#)
- [Configure the Media MTU | 20](#)

Connect to vJunosEvolved

Telnet to the serial console number specified in the XML file to connect to vJunosEvolved. See details provided in the example below:

```
# telnet localhost 8610
Trying 127.0.0.1...
Connected to localhost.
Escape character is '^>'.
root@:~ # cli
root>
```

Configure vJunosEvolved Channelization Interfaces

The vJunosEvolved configurations are the same as the hardware configurations in Junos Evolved CLI.

If channelization of WAN interfaces is required, then boot argument “channelized=yes” must be specified in the XML configuration and the interfaces speed should be configured at Junos Evolved CLI. Sample configuration shown below:

Run the **set interfaces et-0/0/0 speed 25g number-of-sub-ports 8** command.

```
[edit]
# set interfaces et-0/0/0 speed 25g number-of-sub-ports 8
```

```
> show interfaces terse
Interface          Admin Link Proto  Local          Remote
et-0/0/0:0          up    up
et-0/0/0:0.16386   up    up    inet  multiservice
et-0/0/0:1          up    up
et-0/0/0:1.16386   up    up    multiservice
et-0/0/0:2          up    up
et-0/0/0:2.16386   up    up    multiservice
et-0/0/0:3          up    up
et-0/0/0:3.16386   up    up    multiservice
et-0/0/0:4          up    up
et-0/0/0:4.16386   up    up    multiservice
et-0/0/0:5          up    up
et-0/0/0:5.16386   up    up    multiservice
et-0/0/0:6          up    up
et-0/0/0:6.16386   up    up    multiservice
et-0/0/0:7          up    up
et-0/0/0:7.16386   up    up    multiservice
```

You can specify the number of sub ports under a WAN interface to channelize. The default number of non-channelized ports is 12 (et-0/0/0 to et-0/0/11), but you can channelize each interface with 8 sub-ports at 25G speed. You must have this Junos Evolved CLI configuration when channelized option is set to "yes" in the XML. Otherwise, traffic won't pass through.

NOTE: Currently vJunosEvolved supports a maximum of 25 channelized interfaces.

When you configure channelization on vJunosEvolved, if the number of ethernet interfaces exceed 25 (i.e post et-0/0/3:1) in the kernel, the RE VM stops during boot-up.

For more information on the supported ports and ports speed see [No Link Title](#)

Table 3: Supported Ports and Ports Speed on vJunosEvolved

| Physical Port | Ports | Speed |
|--------------------------|-------|-------|
| et-0/0/0:0 to et-0/0/0:7 | 8 | 8x25G |
| et-0/0/1:0 to et-0/0/1:7 | 8 | 8x25G |
| et-0/0/2:0 to et-0/0/2:7 | 8 | 8x25G |

Table 3: Supported Ports and Ports Speed on vJunosEvolved (Continued)

| Physical Port | Ports | Speed |
|----------------------------|-------|----------|
| et-0/0/3:0 to et-0/0/3:7 | 8 | 8x25G |
| et-0/0/4:0 to et-0/0/4:3 | 4 | 4x25G |
| et-0/0/5 | 0 | shutdown |
| et-0/0/6:0 to et-0/0/6:3 | 4 | 4x25G |
| et-0/0/7 | 0 | shutdown |
| et-0/0/8:0 to et-0/0/8:7 | 8 | 8x25G |
| et-0/0/9:0 to et-0/0/9:7 | 8 | 8x25G |
| et-0/0/10:0 to et-0/0/10:7 | 8 | 8x25G |
| et-0/0/11:0 to et-0/0/11:7 | 8 | 8x25G |

Configure the Media MTU

You can configure the media maximum transmission unit (MTU) in the range 288 through 16000. MTU values outside the above mentioned range are rejected.

You must configure the MTU by including the MTU statement at the [edit interface interface-name] hierarchy level.

Configure the MTU.

```
[edit]
user@host# set interface et-0/0/0 mtu <mtu>
```

NOTE: The maximum supported MTU value is 16000 bytes.

For example:

```
[edit]
user@host# set interface et-0/0/0 mtu 9192
```

4

PART

Verify and Troubleshoot

[Verify vJunosEvolved on KVM](#) | 23

Verify vJunosEvolved on KVM

SUMMARY

Use this topic to verify your vJunosEvolved configurations and for any troubleshooting information.

IN THIS SECTION

- [Verify That the VM is Running | 23](#)
- [Verify CPU Information | 24](#)
- [View Log Files | 25](#)
- [Collect Core Files | 25](#)

Verify That the VM is Running

- Verify whether vJunosEvolved is running after you install it.

```
virsh list
```

The virsh list command displays the name and state of the VM. The state can be: running, idle, paused, shutdown, crashed, or dying.

```
# virsh list
  Id  Name      State
  ----
  72  vJunosEvo-RE1  running
```

- You can stop and start the VMs with the following virsh commands:
 - virsh shutdown—Shut down the vJunosEvolved.
 - virsh start—Start an inactive VM that you defined previously.

NOTE: Do not use the virsh destroy command because this command can corrupt the vJunosEvolved VM disk.

If your VM stops and does not boot after using the `virsh destroy` command, then create a live QCOW2 disk copy of the original QCOW2 image provided.

Verify CPU Information

On the host server, use the `lscpu` command to display CPU information.

The output displays information such as the total number of CPUs, the number of cores per socket, and the number of CPU sockets.

For example, the following codeblock information is for an Ubuntu 20.04 LTS host server supporting a total of 32 CPUs.

```
root@vjunos-host:~# lscpu
Architecture:           x86_64
CPU op-mode(s):         32-bit, 64-bit
Byte Order:             Little Endian
Address sizes:          46 bits physical, 48 bits virtual
CPU(s):                 32
On-line CPU(s) list:   0-31
Thread(s) per core:    2
Core(s) per socket:    8
Socket(s):              2
NUMA node(s):           2
Vendor ID:              GenuineIntel
CPU family:             6
Model:                 62
Model name:             Intel(R) Xeon(R) CPU E5-2650 v2 @ 2.60GHz
Stepping:               4
CPU MHz:                2593.884
CPU max MHz:            3400.0000
CPU min MHz:            1200.0000
BogoMIPS:               5187.52
Virtualization:         VT-x
L1d cache:              512 KiB
L1i cache:              512 KiB
L2 cache:                4 MiB
L3 cache:                40 MiB
NUMA node0 CPU(s):      0-7,16-23
```

```
NUMA node1 CPU(s):          8-15,24-31
[snip]
```

View Log Files

View the system logs using the `show log` command on the vJunosEvolved instance.

```
root > show log ?
```

The `root > show log ?` command displays the list of log files available for viewing.

For example, to view the EVO init logs, run the `root> show log evoinit.log` command.

The log files can be viewed from the `/var/log` directory of the vJunosEvolved RE. These logs are the standard vJunosEvolved log files that are also found on other Juniper Networks® products. The serial console can be used to log in to the Routing Engine VM. Alternatively, you can SSH to the Routing Engine VM and view the same information.

Some of the key log files collected are the following:

- Use the `request system debug-info` command to transfer all the system traces in a file named `/var/tmp/debug_collector_<date_time>.tar.gz`
- `/var/log/cosim.log` and `/var/log/cosim_ppd.log`: COSIM traces during initialization.

Collect Core Files

Use the `show system core-dumps` command to view the collected core files. You can transfer these core files to an external server for analysis through the management interface on the Routing Engine.

The `/var/crash` of the directory of the JunosEvolved Routing Engine stores all the core files. You can follow the standard procedures of the Junos OS to transfer the core files vJunosEvolved Routing Engine to an external host.