

ACTIVATE YOUR JUNIPER NETWORKS FIREWALL/IPSEC VPN DEVICE FEATURE

This document briefly describes how to use your Juniper Networks Authorization Code to generate a license activation key for your Juniper Networks Firewall/IPsec VPN device.

Four Easy Steps to Activate Your Juniper Networks Product Feature

1. Gather your Authorization Code and Device serial number.

Authorization Code: The 16-digit alphanumeric Authorization Code is sent via email in response to your order and is required to generate the Firewall/IPsec VPN feature license activation key for your Juniper Networks Firewall/IPsec VPN device. The Authorization Code is required to generate your license activation key—it is not the actual license key.


Device Serial Number: The device serial number is a unique 16-character code Juniper Networks uses to identify your particular Juniper Networks Firewall/IPsec VPN device when generating license keys. You can find the device serial number at the bottom or back of the device. You can also find the serial number in the device information section in the GUI or by executing the “get system” command on the CLI.
2. Sign in to the Juniper Networks License Management System at www.juniper.net/generate_license, select the Firewall/IPsec VPN and Intrusion Prevention link, and follow the instructions in the system user interface.
3. The Juniper License Management System provides you the license key in one of two ways:
 - Download your license key to your computer.
 - You receive an email that contains the license key.
4. **WebUI:** Configuration > Update > ScreenOS/Keys > Select License Key Update (Features) > click Browse > select the file with the license key, then click Apply.

CLI: `exec license-key key_num` (copy and paste the license key for that device).

NSM: In the main navigation tree, right-click the device on which you want to install the license key and select Admin > Install License Key. The Install License Key dialog box appears. Either copy and paste the license key into the dialog box or click the Browse button to locate the license key file on your computer. Click OK.

You must reset the device after the key has been loaded to activate the subscription.

Obtaining and Activating License Keys



For detailed information regarding license keys, refer to the [Concepts and Examples ScreenOS Reference Guide Volume 3: Fundamentals](#).

For additional assistance, you may contact Juniper Networks Customer Care at +1-888-314-5822 (United States) or +1-408-936-1572 (outside the United States). Alternately, you may also open a case online via the Juniper Customer Support Center (CSC) Case Manager.