

ACTIVATE YOUR SRX SERIES AND J SERIES FEATURES

This document briefly describes how to use your Juniper Networks Authorization Code to generate a license activation key for your Juniper Networks SRX Series Services Gateways and J Series Services Routers.

Four Easy Steps to Activate Your Juniper Networks Product Features

- Gather your Authorization Code and Device Serial Number.

Authorization Code: The 16-digit alphanumeric Authorization Code is sent via email in response to your order and is required to generate the license activation key for your SRX Series device. The Authorization Code is required to generate your license key—it is not the actual license key.

Device Serial Number: The device serial number is a unique 12-digit alphanumeric code used to identify your SRX Series device when generating license keys. You can find the SRX Series device serial number either on the bottom or sides of the unit. You can also find the serial number via the NSM Device Inventory Hardware tab by executing the CLI command, “show chassis hardware,” or through the J-Web Monitor Dashboard.
- Sign in to the Juniper Networks License Management System at www.juniper.net/generate_license, select the J Series and SRX Series device link, and follow the instructions in the system user interface.
- The Juniper License Management System provides you with your license key in one of two ways:


 - Download your license key to your computer from the Juniper Networks License Management System.
 - You receive an email that contains the license key.
- On the SRX Series Device:**

CLI: request system license add terminal > Press Enter > When prompted, type the license key separating multiple license keys with a blank line > Ctrl-D.

J-Web Interface: Click **Maintain > Licenses** and enter the license key in one of the following ways:

 - In the license File URL box, type the URL for the license key website.
 - Or copy the license key text, and paste it into the License Key Text box, separating multiple license keys with a blank line.
 - Click **OK**.

Obtaining and Activating License Keys



For detailed information about license key types, generating a new license key, and upgrading existing license keys, see the [Administration Guide for J Series Services Routers and SRX Series Services Gateways](#).

For additional assistance, you may contact Juniper Networks Customer Care at +1-888-314-5822 (United States) or +1-408-936-1572 (outside the United States). Alternately, you may also open a case online via the Juniper Customer Support Center (CSC) Case Manager.

Copyright 2010 Juniper Networks, Inc. All rights reserved. Juniper Networks, the Juniper Networks logo, Junos, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners. Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.